Transport Canada
Safety and Security

**Civil Aviation** 

Transports Canada Sécurité et sûreté

**Aviation civile** 

TP 9857

Government Publications

CA1 YX71 - C/2

INDEX of
AIRWORTHINESS
DIRECTIVES
APPLICABLE in
CANADA

INDEX des CONSIGNES de NAVIGABILITÉ en VIGUEUR au CANADA

20 JANUARY / JANVIER 2000





Digitized by the Internet Archive in 2023 with funding from University of Toronto

Transports Canada Sécurité et sûreté

**Civil Aviation** 

**Aviation civile** 

INDEX of
AIRWORTHINESS
DIRECTIVES
APPLICABLE in
CANADA

INDEX des CONSIGNES de NAVIGABILITÉ en VIGUEUR au CANADA

20 JANUARY / JANVIER 2000







#### **AVANT-PROPOS**

L'Index des consignes de navigabilité en vigueur au Canada présente une liste de toutes les consignes de navigabilité (CN) et instructions équivalentes qui, à la connaissance de Transports Canada à la date de publication, s'appliquent à des produits aéronautiques immatriculés ou construits au Canada.

La présente émission remplace toutes les émissions précédentes de l'index. L'index remplace également toutes les listes précédentes de CN et de bulletins de service obligatoires (BSO) publiées dans le *Manuel du mécanicien et de l'inspecteur*, bimensuellement dans les Avis aux techniciens d'entretien d'aéronefs et aux propriétaires d'aéronefs (N-AME-AO) et dans le magazine trimestriel *Feed-Back*.

Il est obligatoire de se conformer aux exigences des consignes publiées dans le présent index, lorsqu'elles s'appliquent, pour tous les produits aéronautiques à définition de type approuvée immatriculés au Canada. Les exigences canadiennes relatives à l'application des consignes de navigabilité et des instructions équivalentes sont stipulées dans la sous-partie 593 et l'article 604.84 du *Règlement de l'aviation canadien (RAC)* et selon leurs normes respectives, chapitre 593 du *Manuel de navigabilité* et l'appendice H de la norme 625 du RAC.

Transports Canada (TC) a prié les autorités étrangères de navigabilité de lui communiquer tous les renseignements relatifs au maintien de la navigabilité qui concernent les produits aéronautiques étrangers immatriculés au Canada. TC s'efforce d'informer les propriétaires canadiens des produits aéronautiques concernés de toutes les exigences obligatoires. Toutefois, comme ces renseignements peuvent ne pas être complets, les propriétaires de produits aéronautiques de construction étrangère immatriculés au Canada feraient bien de s'assurer qu'ils reçoivent tous les renseignements relatifs au maintien de la navigabilité directement du constructeur et (ou) de l'état du constructeur afin que leur aéronef ne risque pas d'être utilisé alors qu'il n'est pas en état de navigabilité.

Les textes intégraux de toutes les CN en vigueur publiées par TC sont disponibles dans la publication complémentaire, *Consignes de navigabilité canadiennes* (TP 9856). De plus, beaucoup de CN sont maintenant disponibles au site Web sur Internet de Transports Canada (voir la page xviii pour des détails).

Il est préférable de lire les pages d'introduction qui suivent avant de tenter d'extraire des renseignements de l'index.

Il est à noter qu'en raison du nouveau millénaire, certains pays qui publient des CN utilisent maintenant de nouveaux systèmes de numérotage qui indiquent quatre chiffres pour l'année. Afin de faciliter le mélange de nomenclature de deux et quatre chiffres, l'index incorpore maintenant une présentation améliorée des CN placées par ordre chronologique selon l'année de publication (voir la page xii pour plus de détails).

Le présent index est publié quatre fois par année par la Division du maintien de la navigabilité de la Direction de la certification des aéronefs de l'administration centrale de Transports Canada à Ottawa, Canada.

#### FOREWORD

The *Index of Airworthiness Directives Applicable in Canada*, provides a list of all airworthiness directives (ADs) and equivalent instructions, which are known to Transport Canada on the date of publication to be applicable to aeronautical products registered or manufactured in Canada.

This issue supersedes and replaces all previous issues of the index. It also supersedes all previous lists of applicable ADs and MSBs published in the *Engineering and Inspection (E&I) Manual*, in bi-monthly *Notices to Aircraft Maintenance Engineers and Aircraft Operators* (N-AME-AOs) and in the quarterly magazine, *Feed-Back*.

Compliance with the requirements of the notices listed in this index is mandatory, where applicable, for all approved type designs registered in Canada. Canadian requirements respecting airworthiness directives and equivalent notices are prescribed in Subparts 593 and 604 of the *Canadian Aviation Regulations* (*CARs*), and in their respective standards, Chapter 593 of the *Airworthiness Manual* and CAR Standard 625 Appendix H.

Transport Canada (TC) has requested foreign airworthiness authorities to provide all continuing airworthiness information related to foreign manufactured products registered in Canada. TC endeavours to forward notification of all mandatory requirements to the affected Canadian owners. Since this information may not be complete, owners of Canadian registered aircraft should ensure that they receive all continuing airworthiness information directly from the manufacturer and/or state of manufacture to preclude operation of their aircraft in an unairworthy condition.

The full texts of all current ADs issued by TC are available in the companion publication, *Canadian Airworthiness Directives* (TP 9856). Many ADs are also now available on the Transport Canada Internet World Wide Web site (see page xix for details).

It is recommended that the following introductory pages be read before attempting to extract information from the index.

It should be noted that, because of the new millennium, some countries which issue ADs have now implemented new numbering systems incorporating a 4-digit year. To accommodate the mix of 2-digit and 4-digit nomenclature, the index now incorporates an improved order of presentation, whereby ADs are sorted chronologically according to the year of publication (see page xiii for more details).

This index is published four times a year by the Continuing Airworthiness Division of the Aircraft Certification Branch at Transport Canada headquarters in Ottawa, Canada.

# TABLE DES MATIÈRES

AVANT-PROPOS	ii
TERMINOLOGIE	vi
APPLICABILITÉ	vi
MATIÈRES ET ORGANIATION	viii
Noms des constructeurs	viii
Séries des modèles pour les CN	x
CN des aéronefs	x
Ordre de présentation	x
CN des moteurs et des hélices	xii
CN diverses	
Tableau des codes de nationalité	XiV
COMMENT TROUVER LES CN APPLICABLES	xvi
DISPONIBILITÉ DES CONSIGNES DE NAVIGABILITÉ	xviii
Distribution	xviii
Publications imprimées	xviii
Site Web sur Internet	xviii

#### INDEXES DES CONSIGNES DE NAVIGABILITÉ

Aéronefs

Moteurs

Hélices

Divers

#### **BONS DE COMMANDE**

Consignes de navigabilité canadiennes (TP 9856)

Index des consignes de navigabilité en vigueur au Canada (TP 9857)

\* REMARQUE: IL EST PRÉFÉRABLE QUE L'UTILISATEUR DU PRÉSENT INDEX LISE ET COMPRENNE BIEN LES SECTIONS D'INTRODUCTION AVANT DE TENTER D'EXTRAIRE DES RENSEIGNEMENTS DE LA LISTE DES CN.

# **TABLE OF CONTENTS**

FOREWORD	iii
TERMINOLOGY	vii
APPLICABILITY	vii
CONTENTS AND ORGANIZATION	
Manufacturer Names	ix
AD Model Series	xi
Aircraft ADs	xi
Order of Presentation	xi
Engine and Propeller ADs	xiii
Miscellaneous ADs	xv
Table of Country Codes	XV
HOW TO FIND APPLICABLE ADs	xvii
AVAILABILITY OF AIRWORTHINESS DIRECTIVES	
Distribution	xix
Printed Publications	xix
Internet Web Site	

# AIRWORTHINESS DIRECTIVE INDEXES

Aircraft

**Engines** 

Propellers

Miscellaneous

#### ORDER FORMS

Canadian Airworthiness Directives (TP 9856)
Index of Airworthinesss Directives Applicable in Canada (TP 9857)

\* NOTE: IT IS RECOMMENDED THAT THE USER OF THIS INDEX READ, AND BE FAMILIAR WITH, THE INTRODUCTORY SECTIONS BEFORE ATTEMPTING TO EXTRACT INFORMATION FROM THE AD LISTINGS.

#### **TERMINOLOGIE**

Les termes ci-dessous employés dans le présent manuel doivent être interprétés de la façon suivante:

«Index» fait référence à la publication la plus récente du présent manuel: *Index des consignes de navigabilité en vigueur au Canada* (TP 9857).

«Consigne de navigabilité» ou «CN» doit être interprété de manière à inclure les éléments suivants:

- (a) les consignes de navigabilité publiées par Transports Canada (TC); et
- (b) les consignes de navigabilité et les instructions équivalentes, p. ex., les bulletins de service obligatoires, dont on a informé TC qu'ils avaient été publiés comme étant obligatoires ou qu'ils avaient été déclarés obligatoires par d'autres autorités de navigabilité.

«Produits aéronautiques» comprend tout aéronef, moteur, hélice, et autre appareillage ou composant de ces matériels.

«Aéronefs immatriculés au Canada» fait référence à un aéronef inscrit dans le Registre d'immatriculation des aéronefs civils canadiens à la date de publication du présent index.

# **APPLICABILITÉ**

L'index est une liste de toutes les CN qui, à la connaissance de Transports Canada, s'appliquent à des aéronefs homologués immatriculés au Canada à la date de publication inscrite sur la couverture et sur chaque page de la liste.

L'index est la seule liste de CN applicables qui est reconnue par TC. Contrairement à certaines listes disponibles dans le commerce, qui peuvent inclure, par exemple, toutes les CN publiées par la Federal Aviation Administration (FAA) des États-Unis, le présent index ne comprend que les CN applicables au Canada. L'index ne s'applique pas aux aéronefs qui ne sont pas immatriculés au Canada.

TC a pris des mesures pour être informé de toutes les CN publiées par les autorités étrangères de navigabilité ou par les constructeurs étrangers qui concernent les produits aéronautiques homologués immatriculés au Canada. Toutefois, comme TC ne peut être assuré de recevoir tous ces avis, il ne peut garantir que cet index est complet.

Chaque CN du présent index est attribuée à une marque et à un modèle donnés de produit aéronautique. Toutefois, comme de nombreuses CN spécifient également des numéros de série ou d'autres critères dans leur déclaration d'applicabilité, il faut consulter le texte intégral d'une CN pour déterminer si elle s'applique ou non à chacun des exemplaires du produit aéronautique.

Les questions relatives au contenu, à l'applicabilité et aux autres moyens de se conformer aux CN applicables aux aéronefs immatriculés au Canada devraient être adressées au Centre de Transports Canada le plus proche. Une liste de ces bureaux a été publiée dans l'*Avis de navigabilité*, n° A002.

Les détails réglementaires concernant les conditions d'émission des CN de Transports Canada, les responsabilités des propriétaires et des exploitants, les dispenses, les autres moyens de se conformer, les inscriptions et les attestations des CN sont donnés dans la sous-partie 593 et l'article 604.84 du Règlement de l'aviation canadien (RAC) et selon leurs normes respectives, chapitre 593 du Manuel de navigabilité et l'appendice H de la norme 625 du RAC.

#### **TERMINOLOGY**

Several terms used throughout the remainder of this book should be interpreted as follows:

"Index" refers to the latest issue of this publication, *Index of Airworthiness Directives Applicable in Canada* (TP 9857).

"Airworthiness Directive" or "AD" should be understood to include any of the following:

- (a) Airworthiness directives issued by Transport Canada (TC); and
- (b) Airworthiness directives and equivalent instructions, e.g. mandatory service bulletins (MSBs), which TC has been advised have been issued or declared mandatory by other airworthiness authorities.

"Aeronautical products" include aircraft, engines, propellers and other components or appliances installed therein.

"Canadian registered aircraft" refers to an aircraft which is in the Canadian Civil Aircraft Register on the date of issue of this index.

#### **APPLICABILITY**

This index is a list of all ADs known by Transport Canada to <u>be applicable to approved Canadian registered</u> aircraft on the date of issue, which is indicated on the cover and on each page of the listings.

The index is the only list of applicable ADs recognized by TC. Unlike some commercially available lists which may include, for example, *all* ADs issued by the U.S. Federal Aviation Administration (FAA), this index includes *only* those ADs applicable in Canada. It does not apply to aircraft not registered in Canada.

TC endeavours to obtain notification of all ADs issued by foreign airworthiness authorities or manufacturers in respect of approved Canadian registered aeronautical products. However, as TC cannot be assured of receiving all such notifications, this index cannot be guaranteed for completeness.

Each AD listed in the index is attributed to a particular make and model of aeronautical product. However, as many ADs also specify serial numbers or other criteria in their statement of applicability, the full text of an AD must be consulted to determine whether or not it is applicable to each individual example of the aeronautical product.

Questions concerning the contents, applicability and alternative means of compliance of ADs applicable to Canadian registered aircraft should be addressed to the nearest Transport Canada Centre. A list of all such offices is published in *Airworthiness Notice* No. A002.

Regulatory details of the conditions for issue of Transport Canada ADs, owner and operator responsibilities, exemptions, alternative means of compliance, recording and certification in regard to ADs are available in Subparts 593 and 604 of the *Canadian Aviation Regulations (CARs)* and in their respective standards, Chapter 593 of the *Airworthiness Manual* and CAR Standard 625 Appendix H.

# MATIÈRES ET ORGANISATION

Les CN énumérées dans le présent index sont regroupées en quatre sections principales de la façon suivante:

Aéronefs

Moteurs

Hélices

Divers

L'index est produit à partir des données dans le **Système informatisé de la navigabilité aérienne (SINA)** de Transports Canada. Afin de faciliter la récupération et la présentation logique des quelques 18 000 CN de la base de données de SINA, une norme de mise en forme des données a été intégrée afin d'assurer une terminologie simplifiée, mais uniforme, en particulier pour les noms des constructeurs d'aéronefs.

Parce que la majorité des CN en vigueur au Canada provient d'aùtres pays, ils sont disponibles seulement en anglais. Par conséquent la description brève du sujet de chaque CN est enregistrée dans la banque de données SINA et publiée dans cet index en anglais. Tout autre composant du manuel est publié en format bilingue.

#### Noms des constructeurs

Les noms corporatifs complets des constructeurs d'aéronefs non pas été inscrits tels quels; on utilise plutôt des noms génériques simplifiés, p. ex., Cessna, Douglas et deHavilland.

Il y a également de nombreux exemples où, en raison de changements historiques dans le nom d'un constructeur, des modèles d'aéronef similaires ou identiques à tout autre égard ont été construits et immatriculés sous différentes désignations de «marque» et de modèle, p. ex., Aeronca, Bellanca et Champion 7; ou deHavilland, Hawker Siddeley et British Aerospace 125. Le dédoublement et l'éparpillement des CN pour les modèles similaires sont minimisés dans l'index en énumérant les CN pertinentes sous un même nom de constructeur. Lorsque le nom d'un constructeur alternatif est utilisé, une note renvoie le lecteur au nom sous lequel on peut trouver la CN en cause. Par exemple, un lecteur qui cherche les entrées Aeronca ou Champion modèle 7 trouvera la note «Voir : Bellanca», puisque toutes les CN relatives à l'Aeronca, au Bellanca et au Champion 7 sont inscrites sous le nom du constructeur Bellanca.

Les modèles d'une même «famille» sont généralement regroupés sous un même nom collectif, p. ex., Douglas pour tous les modèles Douglas et McDonnell Douglas, DC-3 à DC-10.

Deux vieux types d'avion, Anson et Harvard, sont inscrits sous leur nom de modèle collectif plutôt que sous le nom du constructeur

Une démarche semblable est utilisée pour les sections *Moteurs* et *Hélices* où, par exemple, tous les moteurs Lycoming et Avco Lycoming sont inscrits sous le nom Avco Lycoming; et tous les moteurs Continental et Teledyne Continental sont inscrits sous ce dernier nom.

### CONTENTS AND ORGANIZATION

The ADs listed in this index are grouped into four major sections as follows:

Aircraft

Engines

**Propellers** 

Miscellaneous

The index is produced from data in the Transport Canada Computerized Airworthiness Information System, or CAIS. To facilitate the retrieval and logical presentation of the more than 17,000 ADs in the CAIS database, an editing standard has been incorporated which provides simplified but consistent terminology, particularly for the names of aircraft manufacturers.

Because the majority of the ADs applicable in Canada originate in other countries, they are available only in the English language. For this reason, the brief subject description of each AD is recorded in the CAIS database and presented in this index in English. All other portions of the index are presented in a bilingual format.

#### **Manufacturer Names**

Full corporate names of aircraft manufacturers have not been listed; instead, simplified generic names are utilized, e.g. Cessna, Douglas and deHavilland.

There are also numerous examples where historical changes in a manufacturer's name have resulted in similar or otherwise identical aircraft models being manufactured and registered under different 'make' and model designations, e.g. Aeronca, Bellanca and Champion 7s; or deHavilland, Hawker Siddeley and British Aerospace 125s. Duplication and scattering of the ADs for such related models is minimized in the index by listing all the appropriate ADs under a single manufacturer name. Wherever such an alternative manufacturer name is used, a note directs the reader to the name under which the ADs will be found. As an example, a reader looking up either Aeronca or Champion Model 7s will be directed to "See: Bellanca", since all ADs on the Aeronca, Bellanca and Champion 7s are listed under the manufacturer name Bellanca.

Related 'family' models are generally grouped under a single common name, e.g. Douglas for all Douglas and McDonnell Douglas models, DC-3 to DC-10.

Two vintage aircraft types, Anson and Harvard, are listed under their common model names rather than under a manufacturer name.

A similar process is incorporated in the *Engine* and *Propeller* sections where, for example, all Lycoming and Avco Lycoming engines are listed under the Avco Lycoming name; and all Continental and Teledyne Continental engines are listed under the latter name.

### Séries des modèles pour les CN

Dans le but d'éviter encore davantage les répétitions, une désignation de «série» est utilisée pour regrouper les modèles similaires d'aéronefs, de moteurs ou d'hélices, habituellement sous le même nom générique de constructeur, lorsqu'une CN s'applique à tous ces produits. Dans certains cas, ces codes de série peuvent ressembler à la désignation de série commerciale reconnue d'un constructeur (p. ex., Boeing 727 série 100), mais il est fréquent qu'elles ne soient pas les mêmes et *le lecteur est prié de noter que les codes de série utilisés dans le présent index ne sont valables que pour les besoins de l'index.* 

À chaque fois qu'un modèle d'aéronef, de moteur ou d'hélice s'est vu attribuer un code de série de modèles, on l'a signalé en ajoutant la désignation du code de série applicable entre parenthèses après la désignation du modèle. Par exemple l'inscription:

AEROSPATIALE AS 350B1 (A

(AS 350 SERIES)

signifie que, pour les besoins du présent index, le modèle Aérospatiale AS 350B1 s'est vu attribué le code de série de modèles de CN «AS 350 Series». En conséquence, les nombreuses CN qui s'appliquent à l'AS 50B1 de même qu'à d'autres modèles semblables, comme les AS 350B, 350B2 et 350D ne sont inscrites qu'une seule fois sous le code de modèle «AS 350 Series». Seules les CN supplémentaires qui ne s'appliquent pas à tous les modèles de la série sont inscrites spécifiquement pour chaque modèle.

### CN des aéronefs

À l'intérieur de la section des CN des aéronefs, chaque inscription comprend les éléments d'information suivants:

Constructeur Nom du constructeur (voir la rubrique *Noms des constructeurs* ci-dessus):

Modèle Désignation du modèle spécifique;

Série de CN (facultatif - voir Séries des modèles pour les CN ci-dessus);

Origine Un code de nationalité de deux lettres indique le pays d'origine de la CN (voir le

Tableau des codes de nationalité pour connaître la signification des codes);

Numéro de consigne Numéro de la CN, y compris la désignation de révision;

Sujet Une courte description du sujet de la CN, qui spécifie le composant touché et (ou)

la nature du problème;

Bulletin de service

Le numéro du ou des bulletins de service connexes du constructeur lorsqu'ils

de référence s'appliquent.

#### **AD Model Series**

To further reduce repetition, a 'series' designation is incorporated to link similar aircraft, engine or propeller models, usually of the same generic manufacturer, when an AD is applicable to all of them. In some cases, these series codes may look similiar to a manufacturer's recognized commercial series designation (e.g. Boeing 727 100 Series) but in many cases they are not the same and the reader is cautioned that the series codes appearing in this index are defined solely for the purpose of the index.

Each aircraft, engine or propeller model, which is assigned to an AD model series, is so indicated by the addition of the applicable series designation in parentheses following the model designation. For example, the listing

AEROSPATIALE
AS 350B1 (AS 350 SERIES)

indicates that, for the purpose of this index, the Aerospatiale Model AS 350B1 has been assigned to an AD model series identified as "AS 350 Series". This allows that the many ADs applicable to the AS 350B1 in common with other similar models, such as the AS 350B, 350B2 and 350D, need only be listed once under the model heading "AS 350 Series". Only those additional ADs, which are not common to all of the series models, are then listed under each individual model.

#### Aircraft ADs

Service Bulletin

Within the Aircraft AD section, each listing includes the following items of information:

Make Manufacturer's name (see Manufacturer Names above)

Model Specific model designation

Series AD series (optional - see AD Model Series above)

Origin Two-letter code to identify country of origin of the AD (see Table of Country Codes

for definitions)

AD Number Number of the AD, including revision designator

Subject A short description of the AD subject, identifying the affected component

and/or problem

Reference The number of the manufacturer's related service bulletin(s), where applicable

χi

#### Ordre de présentation

Les CN de la présente section sont classées et présentées de la manière suivante:

- 1. Constructeur Les noms génériques simplifiés des constructeurs sont présentés en ordre alphabétique.
- 2. Modèle (série) En général, les modèles (et le code de série de modèles de CN, s'il y a lieu) de chaque constructeur sont présentés en ordre numérique selon la désignation du «numéro d'ordre» de base, suivi successivement par les variations de préfixes alphabétiques, puis par les variations de suffixes alphabétiques et numériques, de ces modèles numériques. Par exemple, les CN de Cessna 150 sont inscrites en premier pour le modèle de base 150, suivies par le 150A, 150B, etc., le A150, A150K, etc., puis de la même façon les 152, 170, etc.

Il y a des exceptions à la règle décrite ci-dessus, qui tiennent généralement compte de l'évolution historique d'une ligne de produit ou d'une autre raison logique. Par exemple, le deHavilland CS2F est inscrit avant le deHavilland DHC1. De même, les Douglas A26 et B26 sont inscrits avant les modèles DC-3 à DC-10; et les modèles «C» (C47 et C54) sont placés avec les modèles «DC» équivalents (DC-3 et DC-4, respectivement).

Toutes les CN assignées à une série de modèles sont inscrites immédiatement avant ceux des modèles spécifiques de cette série.

- 3. Origine Lorsque les CN proviennent de plus d'un pays, elles sont regroupées en ordre alphabétique selon le code de nationalité de deux lettres, p. ex., les CN canadiennes «<u>C</u>F» sont inscrites avant les CN britanniques «<u>U</u>K».
- 4. Numéro de CN Les CN d'un même modèle d'aéronef sont publiées par ordre chronologique et/ou numérique. Une tentative a été faite afin de placer les CN par ordre chronologique de l'année de publication de la CN originale (avant révisions) puis par ordre numérique selon le numéro de CN. Ceci dans le but de faciliter les modifications du système de numérotage que différents pays ont incorporé en raison du nouveau millénaire et, par le fait même, rendre plus logique l'ordre de certaine CN. Par exemple, dans les CN canadiennes, américaines, françaises, hollandaises, suisses et italiennes, quatre chiffres sont maintenant incorporés pour indiquer l'année; on s'attend que d'autres pays qui traditionnellement utilisent deux chiffres (p-ex. Royaume-Uni, Brézil et Israël) en feront de même.

Pour les pays qui n'incorpore pas une année d'émission dans leur numéro de CN, la CN demeure dans un ordre numérique tel que donné par l'ordinateur. Toutefois, les bulletins de service obligatoires en provenance du Royaume-Uni (UK) constituent une exception, parce que le numéro de CN de la CAA britannique n'est souvent disponible que quelque temps après la publication du bulletin de service de l'avionneur. Dans ce cas, le numéro du bulletin est doublé et il est inscrit comme s'il s'agissait du numéro de CN jusqu'à ce que ce dernier numéro soit connu.

Avant de déclarer une CN comme étant «manquante» ou «effacée», il est fortement suggéré de passer en revue la liste entière des produits afin de s'assurer que la CN n'a tout simplement été déplacée à un autre endroit sur la liste. Les lecteurs de l'index sont invités a commenter sur l'ordre de classement.

#### **Order of Presentation**

The ADs in this section are sorted and presented in the following order, in succession:

- 1. Make The simplified generic manufacturer names are presented in alphabetical order.
- 2. Model (Series) In general, the models (and AD model series, where applicable) of each manufacturer are presented in numerical order of the basic 'root number' designation, followed successively by the alphabetic prefix variations, then the alphabetic and numeric suffix variations, of those numerical models. For example, Cessna 150 ADs are listed first for the basic 150 model, followed by the 150A, 150B, etc., the A150, A150K, etc., then similarly the 152s, 170s, etc.

There are exceptions to the above, generally reflecting either the historical development of a product line or some other logical reason. For example, the deHavilland CS2F appears before the deHavilland DHC 1. Similarly, the Douglas A26s and B26s appear before the DC-3 to DC-10 models; and the 'C' models (C47s and C54s) are located within the equivalent 'DC' models (DC-3 and DC-4, respectively).

Any ADs assigned to a model series are listed immediately prior to those for the specific models of that series.

- When ADs originate in more than one country, they are grouped in the 3. Origin alphabetical order of the two-letter country code, e.g. 'CF' (Canadian) ADs appear before 'UK' (British) ADs.
- Finally, the ADs for each aircraft model or series are listed in chronological and/or AD Number numerical order. An attempt has been made to list ADs first, chronologically by the year of publication of the original AD (before revisions) then secondly, in numerical order according to the AD number. This is to accommodate the changes in numbering systems which various countries have incorporated due to the new millennium, and to place certain other ADs in a more logical sequence. For example, Canadian, US, French, Dutch, Swiss and Italian ADs now incorporate a 4-digit year in their AD numbers; other countries which have traditionally included a 2-digit year in their numbers (e.g. the UK, Brazil and Israel) are expected to follow suit.

For countries which do not incorporate a year of issue in their AD numbers, the ADs remain in numerical order as sorted by the computer. Note that in the case of some MSBs originating in the UK, because the British CAA AD number is not always available until some time after release of the manufacturer's service bulletin, the MSB number is duplicated and shown as if it were the AD number until such time as the AD number becomes known.

Before declaring any former ADs as 'missing' or 'deleted', readers are encouraged to browse the entire list for a given product to ensure that the AD has not simply been moved to another spot in the list. Readers of the index are invited to comment on the sorting order.

#### CN des moteurs et des hélices

Dans les sections *Moteurs* et *Hélices* de l'index, les CN sont présentées d'une manière très semblable à celle des CN des aéronefs, des renseignements similaires sont fournis et les CN sont classées sensiblement de la même façon.

Nonobstant les règles générales décrites ci-dessus, qui consistent à classer les modèles d'aéronefs selon l'ordre numérique du «numéro d'ordre» de leurs désignations, les moteurs sont généralement regroupés selon leur type en commençant par les moteurs à pistons, suivis des turbopropulseurs, des moteurs à réaction purs, des turbosoufflantes, etc. La première règle de classement de la plupart des moteurs à pistons est selon la cylindrée, p. ex., les Avco Lycoming 145, suivis des 235, des 290, etc. Les moteurs qui ont la même cylindrée nominale sont classés d'abord par les variations de préfixes, puis par les variations de suffixes, sauf que dans le cas des modèles d'Avco Lycoming et de Teledyne Continental qui comprennent un préfixe «O», ils sont inscrits en premier, suivis des autres préfixes en ordre alphabétique, p. ex., O, AEIO, HO, IO, LIO, LO, LTO, TO et VO.

Il est plus difficile d'appliquer des règles de classement uniformes dans le cas des désignations d'hélice complexes, où les numéros de moyeu comprennent souvent la désignation du modèle de base. Dans la mesure du possible, toutefois, les hélices ont été regroupées premièrement selon le nombre de pales, comme l'indiquent leurs désignations de modèles, et ensuite elles sont classées en ordre alphabétique de la même façon que pour les modèles de moteur.

#### **CN** diverses

Les CN qui s'appliquent à des produits aéronautiques autres que des aéronefs, des moteurs ou des hélices sont inscrites dans la section *Divers*. Chaque inscription comprend les renseignements suivants:

Constructeur	Le nom du constructeur	(simplifié - voir	la rubrique	Noms des constructeurs
--------------	------------------------	-------------------	-------------	------------------------

ci-dessus);

Origine Un code de nationalité de deux lettres indique le pays d'origine de la CN (voir le

Tableau des codes de nationalité pour connaître la signification des codes); et

Numéro de CN Le numéro de la CN, y compris le désignatif de la révision.

Sujet Une brève description du suject de la CN, y compris une mention du composant

touché et de la nature du problème, et le numéro du ou des bulletins de service

connexes du constructeur, s'il y a lieu.

Les CN de cette section sont d'abord classées par le nom du constructeur, puis par le numéro de CN.

# Tableau des codes de nationalité

AS	Autriche	ND	Pays-Bas
BZ	Brésil	PL	Pologne
CF	Canada	RO	Roumani
CK	République Tchèque	RU	Russie
FD	Finlande	SN	Suède
FR	France	SP	Espagne
GY	Allemagne	SW	Suisse
IL	Israël	UK	Royaume-Uni
IT	Italie	US	États-Unis
JN	.lanon		

# **Engine and Propeller ADs**

Within the *Engine* and *Propeller* sections of the index, the ADs are presented in a very similar manner to the aircraft ADs - similar information is provided, and it is sorted in much the same way.

Notwithstanding the general rule described above, of sorting aircraft models in the order of their 'numerical root' designations, engines are generally grouped into blocks of piston models, followed by turbo-props, then pure jets, turbo-fans, etc. The primary sort order for the majority of piston engines is by cylinder capacity designation, e.g. Avco Lycoming 145s, followed by 235s, then 290s, etc. Engines having the same basic capacity designation are sorted first by prefix variations, then by suffix variations, except that since the basic Avco Lycoming and Teledyne Continental models incorporate an 'O' prefix, these are listed first, followed by the other prefixes in alphabetical order, e.g. O, AEIO, HO, IO, LIO, LO, LTO, TO and VO.

It is more difficult to apply consistent sorting rules to the complex propeller designations, where hub number often comprises the basic model designation. Where possible, however, propellers have been grouped first according to the number of blades, as indicated in their model designations, then sorted alphabetically in similar manner to the engine models.

#### Miscellaneous ADs

ADs applicable to aeronautical products other than aircraft, engines or propellers are listed in the *Miscellaneous* section. Each listing includes the following:

Make	Manufacturer's name (simplified - see Manufacturer Names above)
Origin	Two-letter code to identify country of origin of the AD (see <i>Table of Country Codes</i> for definitions)
AD Number	Number of the AD, including revision designator
Subject	A short description of the AD subject, including the affected component, the problem and the number of the manufacturer's related service bulletin(s), where applicable

The ADs in this section are sorted first by the manufacturer's name, then by the AD number.

# **Table of Country Codes**

AS	Austria	ND	The Netherlands
BZ	Brazil	PL	Poland
CF	Canada	RO	Romania
CK	Czech Republic	RU	Russia
FD	Finland	SN	Sweden
FR	France	SP	Spain
GY	Germany	SW	Switzerland
IL	Israel	UK	United Kingdom
IT	Italy	US	United States
JN	Japan		

#### COMMENT TROUVER LES CN APPLICABLES

Parmi les principales caractéristiques du mode de présentation de l'index, mentionnons que la marque et le modèle de *tous* les types d'aéronefs homologués qui figurent sur le Registre d'immatriculation des aéronefs civils canadiens à la date de publication, ainsi que leurs moteurs et hélices homologués, sont incrits, même s'il n'y a présentement aucune CN applicable. Par conséquent, le lecteur peut déterminer de façon sûre s'il existe *ou non* des CN applicables pour *chaque* produit aéronautique homologué au Canada.

La compréhension des règles de base du classement et de la présentation des données dans le présent manuel (voir les sections précédentes) devrait permettre de trouver relativement facilement toutes les CN qui s'appliquent à un produit aéronautique donné.

On peut trouver les CN applicables à un produit aéronautique homologué en suivant les trois étapes suivantes:

- 1. À l'intérieur de la section Aéronefs, Moteurs ou Hélices, trouvez toutes les CN inscrites sous la constructeur et le modèle en cause.
- 2. Notez si un code de série de modèles de CN est indiqué entre parenthèses à côté de la désignation du modèle en cause. Si tel est le cas, regardez plus haut dans l'index pour trouver la désignation de la série; toutes les CN inscrites dans cette série sont également applicables.
- 3. Passez en revue la section *Divers* pour trouver les CN applicables aux équipements qui peuvent être montés sur l'aéronef en cause.

Si aucune CN n'est inscrite ni pour le modèle en cause, ni pour la série indiquée, le lecteur peut alors tenir pour acquis qu'à la connaissance de TC il n'y avait aucune CN applicable à la date de publication. Notez toutefois qu'il pourrait y avoir des CN applicables dans la section *Divers* et il est très important de ne pas oublier cette étape de la recherche des CN.

Si le constructeur et le modèle sont introuvables, cherchez ailleurs dans l'index. Si le produit aéronautique en cause demeure introuvable, veuillez contacter le bureau régional ou de district de la Navigabilité de Transports Canada le plus proche, ou les éditeurs de l'index (voir la rubrique *Disponibilité des consignes de navigabilité*).

# HOW TO FIND APPLICABLE ADS

One of the basic premises under which this index is presented, is that the make and model of *every* approved aircraft type listed in the Canadian Civil Aircraft Register on the date of issue, and its approved engine(s) and propeller(s), are listed, even if there are no currently applicable ADs. Thus, the reader can positively determine the existence *or not* of ADs applicable to *every* approved aeronautical product in Canada.

With a basic understanding of how the data are sorted and presented in this book (see the previous sections), it should be relatively easy to find all ADs applicable to a given product.

The ADs applicable to an approved aeronautical product may be found in three steps as follows:

- 1. Within the appropriate Aircraft, Engine or Propeller section, find any ADs listed under the specific make and model.
- Note if an AD model series is identified in parentheses beside the specific model designation. If so, search upwards in the index to find that series designation; any ADs listed under that series are also applicable.
- 3. Browse the *Miscellaneous* section to find ADs applicable to equipment which may be installed on the aircraft.

If no ADs are listed for either the specific model or the indicated series, the reader can assume that no applicable ADs were known to TC on the date of publication. Note, however, that there could be applicable ADs in the *Miscellaneous* section, and it is very important to not forget this step of an AD search.

If the make and model cannot be found, try looking elsewhere in the index. If the product still cannot be found, please contact your nearest Transport Canada regional or district Airworthiness office, or the publishers of the index (see *Availability of Airworthiness Directives*).

# DISPONIBILITÉ DES CONSIGNES DE NAVIGABILITÉ

#### **Distribution**

Les consignes de navigabilité publiées par Transports Canada sont normalement adressées par la poste ou par un moyen plus rapide à tous les propriétaires d'aéronefs immatriculés au Canada concernés. Les CN applicables publiées par les autorités étrangères de navigabilité sont reproduites par TC qui les distribue aux propriétaires canadiens concernés. TC se charge également d'informer (sans toutefois leur envoyer de copies) les propriétaires canadiens concernés de la publication de bulletins de service du constructeur qui ont été déclarés d'application obligatoire par les autorités étrangères de navigabilité concernées. Les propriétaires doivent s'assurer que le ministère soit connaissant de leur adresse courante.

Les propriétaires, les exploitants et les techniciens d'entretien d'aéronefs construits à l'étranger devraient s'assurer de recevoir toutes les données de maintien de la navigabilité directement du constructeur et (ou) de l'état du constructeur. Néanmoins, les bureaux régionaux et de district de la Navigabilité de TC peuvent accepter des demandes raisonnables pour obtenir des reproductions de certaines CN étrangères.

### Publications imprimées

Le présent manuel *Index des consignes de navigabilité en vigueur au Canada* (TP 9857) et la publication complémentaire *Consignes de navigabilité canadiennes* (TP 9856) qui contient le texte intégral de toutes les CN de TC, sont compilés et publiés par la Division du maintien de la navigabilité de la Direction de la certification des aéronefs à l'administration centrale de Transports Canada à Ottawa, Canada. Les éditeurs invitent les lecteurs à leur faire parvenir tous commentaires et opinions sur le contenu, la présentation et l'utilité de ces manuels.

Les publications TP 9856 et TP 9857 sont vendues et distribuées *seulement* par Les Éditions du gouvernement du Canada, à Ottawa. Des bons de commande sont fournis à la fin de la présente publication.

Veuillez adresser vos demandes et commentaires vos

Transports Canada Division du maintien de la navigabilité (AARDG) Ottawa (Ontario) CANADA K1A 0N8

Télécopieur : (613) 996-9178

sur le contenu et la présentation à:

Veuillez adresser vos bons de commande et

questions sur la distribution à:

Les Éditions du gouvernement du Canada Ottawa CANADA K1A 0S9

Téléphone: (819) 956-4800 (Hull, Québec) Télécopieur: (819) 994-1498 ( " )

# Site Web sur Internet

La liste indexée des CN est maintenant disponible au site Web sur Internet de Transports Canada à :

#### http://www.tc.gc.ca/aviation/aircert/continaw/ad-f.htm

Ce site offre le texte complet de toutes les CN de Transports Canada, la plupart des CN de la FAA, et plus tard cela de tous les autres pays.

Il est à noter que le babillard électronique (BBS) du programme RDS a été mis hors service le 1<sup>er</sup> janvier 2000 et n'est plus disponible comme source d'information des CN.

# **AVAILABILITY OF AIRWORTHINESS DIRECTIVES**

#### Distribution

Airworthiness Directives issued by Transport Canada are normally distributed by mail or faster means to all registered owners of the affected aeronautical product. Applicable ADs issued by a foreign airworthiness authority are copied by TC to the affected Canadian owners as they are received. TC also advises (but does not send copies to) affected Canadian owners of the issuance of manufacturers' service bulletins which have been declared mandatory by the appropriate foreign airworthiness authority. Owners are advised to keep TC informed of their current address.

Owners, operators and maintainers of foreign manufactured aircraft should ensure that they receive all continuing airworthiness information directly from the manufacturer and/or state of manufacture. Nonetheless, TC regional and district Airworthiness offices can meet reasonable requests for copies of individual foreign ADs.

#### **Printed Publications**

This book, *Index of Airworthiness Directives Applicable in Canada* (TP 9857), and a companion publication, *Canadian Airworthiness Directives* (TP 9856) which contains the full text of all TC ADs, are compiled and published by the Continuing Airworthiness Division of the Aircraft Certification Branch at Transport Canada headquarters in Ottawa, Canada.

TP 9856 and TP 9857 are sold and distributed *only* through Canadian Government Publishing, in Ottawa. Order forms are included at the back of this publication.

The publishers welcome the comments and opinions of readers on the contents, presentation and utility of these books.

Address enquiries and comments on the *contents* and presentation to:

Transport Canada
Continuing Airworthiness Division (AARDG)
Ottawa, Ontario CANADA
K1A 0N8

Facsimile: (613) 996-9178

Address orders and distribution enquiries to:

Canadian Government Publishing Ottawa CANADA K1A 0S9

Telephone: (819) 956-4800 (Hull, Quebec) Facsimile: (819) 994-1498 ( " )

# **Internet Web Site**

The indexed AD list is now available on the Transport Canada Internet World Wide Web site at:

# http://www.tc.gc.ca/aviation/aircert/continaw/ad.htm

This site also offers the full text of all ADs issued by Transport Canada, most of those issued by the FAA and, as the site develops, more and more of those issued by all other countries.

Note that the SDR Bulletin Board Service (BBS) was decommissioned on 1 January 2000 and is no longer available as a source of AD information.



MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

ł	COMMANDER			
B1A US US US	72-21-01 74-02-02 79-16-04		R SHOCK STRUT SPAR FAILURE PARS	
\$2R US US US US	93-01-03 93-20-05 93-20-06 97-17-03	WING-ALUMINU	SPAR IL ATTACHMENT BRACKET JM OUTBOARD HUCKBOLTS TIGUE CRACKS	SB-AG-29 SB-AG-32 SB-AG-33 SB-AG-39
S2R US US	79-10-10 80-04-06	( S2R SERIES ) SEPARATION C	DF HINGE FROM RUDDER ASSY JBULAR FRONT SPÄR	
S2R	R1340	( S2R SERIES )		
US	<b>T34</b> 80-04-06	( S2R SERIES ) CRACKS IN TU	JBULAR FRONT SPAR	
100 US US US US	68-12-05 68-21-02 68-23-03 73-01-01	RUDDER CONTE AILERON CABL FUEL OCTANE EXHAUST OUTL	LE ASSEMBLY PLACARD	
100 US US US	68-23-03	AILERON CABL FUEL OCTANE EXHAUST OUTL	PLACARD	
112 US US US	<b>SERIES</b> 85-03-04R2 88-05-06 90-04-07		BASE MOD I ATTACHMENT FITTING ) SPAR/AREA MLG SIDE BRACE FITTING	112-45A, 70A 112-72A 112-71C
112 US US US US US	73-14-04 73-14-06 73-24-01 75-22-09 77-01-08	CRACKS IN PR	ROP CONTROLS OP SPINNER BULKHEAD ACE HINGE FAILURE	
112E		( 112 SERIES )		
112T	С	( 112 SERIES )		
112T	CA	( 112 SERIES )		
114 US US US US		FRONT SEAT B VERTICAL FIN	AND AIR DUCTS  ASE MOD  ATTACHMENT FITTING  SPAR/AREA MLG SIDE BRACE FITTING	114-6 114-5A, -21A 114-23A 114-22C
	SERIES		OVER CAR FORWARD ELANCE	90CR1
CF US US US	CF-93-14 59-04-01 59-06-01 59-16-01 61-14-01	STABILIZER R ELEVATOR FRO FUEL LINE RO ENGINE MOUNT	NT SPAR UTING INSPECTION	
US US	98-07-17 98-08-19 98-20-34	FLIGHT IN IC	ATIGUE NG TO FUSELAGE ATTACH POINTS ING CONDITIONS	226 223R1 AND 223R2
500 CF US US	CF-69-06 73-06-02 75-12-09R2	FUEL SIPHONI INADVERTENT	NG STRUCTURAL FAILURE	AEROCON AC6701
US US	87-21-07R1 94-04-13	FUEL FILLER WING FRONT S	OPENINGS PAR LOWER CAP WS 24	SI-209A 90C
				ATPCPAFT/AFRONEES

1

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER

(SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

ORIGINE			SUJET	BULLETIN DE SERVICE DE REF.
	COMMANDER	/		
500	( CUITE)	( 500	SERIES )	
US	NUED / SUITE) 94-04-15		WING FRONT SPAR LOWER CAP WS 96	212
03	34 04 73		TIME THOUSE STATE STATE OF THE	
500B		( 500	SERIES )	
	CF-69-06		WING FRONT SPAR LOWER CAP	AEROCON AC6701
US	64-02-01		MAIN LANDING GEAR	
US US	67-22-01 73-06-02		MAIN LANDING GEAR FUEL SIPHONING	
	75-12-09R2		INADVERTENT STRUCTURAL FAILURE	
US	87-21-07R1		FUEL FILLER OPENINGS	S1-209A
US	94-04-13		WING FRONT SPAR LOWER CAP WS 24	900
F000		( 500	CEDIEC )	
<b>500S</b> CF	CF-93-03	( 500	SERIES ) WING MAIN SPAR LOWER CAPS	215
US	75-12-09R2		INADVERTENT STRUCTURAL FAILURE	a 1 0
US	94-04-11		WING FRONT SPAR LOWER CAP	215
US	94-04-13		WING FRONT SPAR LOWER CAP WS 24	90C
US	94-04-14		WING FRONT SPAR LOWER CAP CORROSION	208A
US	98-08-25R1		REPLACEMENT OF NLG DRAG LINK BOLT	224
500U		( 500	SERIES )	
CF	CF-69-06		WING FRONT SPAR LOWER CAP	AEROCON AC6701
US	73-06-02		FUEL SIPHONING	
US	75-12-09R2		INADVERTENT STRUCTURAL FAILURE	C7 0004
US US	87-21-07R1 94-04-13		FUEL FILLER OPENINGS WING FRONT SPAR LOWER CAP WS 24	SI-209A 90C
US	94-04-14		WING FRONT SPAR LOWER CAP CORROSION	208A
US	98-08-25R1		REPLACEMENT OF NLG DRAG LINK BOLT	224
520	05.00.44		FRONT SPAN LOUSE CAR FRONTAN STANIOS	0000
CF US	CF-93-14		FRONT SPAR LOWER CAP FORWARD FLANGE AILERON BELLCRANK CASTING	90CR1
US	57-09-01 58-01-01		FUEL VENT LINE REPLACEMENT	
US	59~16-01		FUEL LINE ROUTING	
US	62-08-02		FUEL LINE MODIFICATION	
US	63-08-01		FUEL GAGING SYSTEM	
US	73-06-02		FUEL SIPHONING	
US US	75-12-09R2 87-21-07R1		INADVERTENT STRUCTURAL FAILURE FUEL FILLER OPENINGS	SI-209A
US	94-04-13		WING FRONT SPAR LOWER CAP WS 24	90C
US	98-07-17		FLAP CABLE FATIGUE	226
US	98-08-19		CRACKS AT WING TO FUSELAGE ATTACH POINTS	223R1 AND 223R2
US	98-20-34		FLIGHT IN ICING CONDITIONS	
600 S	20			
US	79-10-10		SEPARATION OF HINGE FROM RUDDER ASSY	
US	80-04-06		CRACKS IN TUBULAR FRONT SPAR	
US	93-01-03		WING FRONT SPAR	SB-AG-29
680 S	ERIES		FRONT SPAR LOWER CAP FORWARD FLANGE	00001
US	CF-93-14 57-09-01		AILERON BELLCRANK CASTING	90CR1
US	57-15-01		LANDING GEAR RETAINING PINS	
US	58-01-01		FUEL VENT LINE REPLACEMENT	
US	98-07-17		FLAP CABLE FATIGUE	226
US	98-08-19		CRACKS AT WING TO FUSELAGE ATTACH POINTS	223R1 AND 223R2
U.S	98-20-34		FLIGHT IN ICING CONDITIONS	
680		( 680	SERIES )	
CF	CF-69-06		WING FRONT SPAR LOWER CAP	AEROCON AC6701
US	59-04-01		STABILIZER RIVETS	
US US	59-16-01		FUEL LINE ROUTING	
US	67-28-01 73-06-02		LOWER FRONT SPAR CAP FUEL SIPHONING	
US	75-12-09R2		INADVERTENT STRUCTURAL FAILURE	
US	87-21-07R1		FUEL FILLER OPENINGS	SI-209A
US	94-04-13		WING FRONT SPAR LOWER CAP WS 24	90C
US	94-04-15		WING FRONT SPAR LOWER CAP WS 96	212
680E		( 680	SERIES )	
CF	CF-69-06	, 000	WING FRONT SPAR LOWER CAP	AEROCON AC6701
US	59-04-01		STABILIZER RIVETS	The state of the s
US	59-16-01		FUEL LINE ROUTING	
	PART / AFDONESS			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE - NUMBERO DE CONSIGNE
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE " NU	MERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETI BULLETIN DE SERVICE DE REF
ERO COMI	NANDER		
680E		O SERIES )	
(CONTINUE	D / SUITE)	, and ,	
	0-20-01	WING RIVET REPLACEMENT	
	7-28-01	LOWER FRONT SPAR CAP	
	3-06-02	FUEL SIPHONING	
US 7	5-12-09R2	INADVERTENT STRUCTURAL FAILURE	
US 8	7-21-07R1	FUEL FILLER OPENINGS	SI-209A
	4-04-13	WING FRONT SPAR LOWER CAP WS 24	900
US 9	4-04-15	WING FRONT SPAR LOWER CAP WS 96	212
580F	( 680	SERIES )	
CF C	F-69-06	WING FRONT SPAR LOWER CAP	AEROCON AC6701
	2-05-01	ALTERNATE INDUCTION AIR VALVE	
	2-08-01	FUEL PRESSURE GAUGE DRAIN LINE	
	4-02-01	MAIN LANDING GEAR	
	7-22-01	MAIN LANDING GEAR	
US 7:	3-06-02	FUEL SIPHONING	
US 7!	5-12-09R2	INADVERTENT STRUCTURAL FAILURE	
US 8'	7-21-07R1	FUEL FILLER OPENINGS	SI-209A
	4-04-13	WING FRONT SPAR LOWER CAP WS 24	900
US 98	3-08-25R1	REPLACEMENT OF NLG DRAG LINK BOLT	224
680FL		SERIES )	
	-69-06	WING FRONT SPAR LOWER CAP	AEROCON AC6701
	2-05-01	ALTERNATE INDUCTION AIR VALVE	
	2-08-01	FUEL PRESSURE GAUGE DRAIN LINE	
	1-02-01	MAIN LANDING GEAR	
US 67	7-22-01	MAIN LANDING GEAR	
US 73	3-06-02	FUEL SIPHONING	
US 94	1-04-13	WING FRONT SPAR LOWER CAP WS 24	90C
US 94	1-04-14	WING FRUNT SPAR LUWER CAP CURRUSION	208A
US 98	3-08-25R1	REPLACEMENT OF NLG DRAG LINK BOLT	224
680FLP	( 680	SERIES )	
	-69-06	WING FRONT SPAR LOWER CAP	AEROCON AC6701
	2-05-01	ALTERNATE INDUCTION AIR VALVE	
US 62	2-08-01	FUEL PRESSURE GAUGE DRAIN LINE	
US 67	7-22-01	MAIN LANDING GEAR	
US 73	3-06-02	FUEL SIPHONING	
		FUEL FILLER OPENINGS	SI-209A
US 91	-08-09	WING LOWER SPAR CAP	208
80V	( 680	SERIES )	
	1-10-07	EMERG. LG EXTENSION SYSTEM MOD	
	1-04-13	WING FRONT SPAR LOWER CAP WS 24	90C
	5-19-18	INSTALLATION OF PLACARD	220-2
	3-08-25R1	REPLACEMENT OF NLG DRAG LINK BOLT	224
204			
81 CF CF	-93-14	FRONT SPAR LOWER CAP FORWARD FLANGE	90CR1
	1-10-07	EMER LG EXTENSION SYSTEM MOD	
	-04-13	WING FRONT SPAR LOWER CAP WS 24	90C
	-04-14	WING FRONT SPAR LOWER CAP CORROSION	208A
	5-19-18	INSTALLATION OF PLACARD	220-4
	1-07-17	FLAP CABLE FATIGUE	226
	-08-19	CRACKS AT WING TO FUSELAGE ATTACH POINTS	223R1 AND 223R2
	-08-25R1	REPLACEMENT OF NLG DRAG LINK BOLT	224
	-20-34	FLIGHT IN ICING CONDITIONS	
85			
	-93-15	WING LOWER SPAR CAP	208A
	-93-16	WING RIB CRACKS	211
	-19-01	FLAP SPEED	
	-23-05	INDUCTION AIR ELBOW	
	-21-07R1	FUEL FILLER OPENINGS	SI-209A
	-04-12	WING FRONT SPAR LOWER CAP WS 39	211R1
	-04-14	WING FRONT SPAR LOWER CAP CORROSION	208A
	-04-17	FLAP CABLE FATIGUE	210
OO CERT	cc		
90 SERI US 75	-19-01	FLAP SPEED	
	-03-01	LEFT & RIGHT WING RIVETS	
	-19-05	ENGINE MOUNT SYSTEM	

MAKE / CONSTRUCTEUR (SERIES / SERIE) MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. SUBJECT AERO COMMANDER 690 SERIES (CONTINUED / SUITE) WING FRONT SPAR LOWER CAP WS 39 WING FRONT LOWER CAP 211R1 ÜS 94-04-12 2084 94-04-14 218 INSPECT VERTICAL STABILIZER FOR CRACKS 95-13-02 220-7 INSTALLATION OF PLACARD US 95-19-18 226 FLAP CABLE FATIGUE 98-07-17 CRACKS AT WING TO FUSELAGE ATTACH POINTS 223R1 AND 223R2 98-08-19 224 REPLACEMENT OF NLG DRAG LINK BOLT 98-08-25R1 FLIGHT IN ICING CONDITIONS 98-20-34 ( 690 SERIES ) 690 OIL SUPPLY LINES 73-13-09 115 ( 690 SERIES ) 690A PILOT AND CO-PILOT SIDE WINDOWS US 74-20-12 BATTERY DISCONNECT 75-08-05 BLEED AIR LINE US 75-08-07 77-04-01 TRIM SYSTEM US WING FRONT SPAR LOWER CAP CORROSION 94-04-14 US 220-6 INSTALLATION OF PLACARD US 95-19-18 ( 690 SERIES ) 690B WING MAIN SPAR LOWER CAPS CF CF-93-03 LEFT & RIGHT WING RIVETS 77-03-01 US 215 WING FRONT SPAR LOWER CAP WING FRONT SPAR LOWER CAP CORROSION 94-04-11 2084 94-04-14 US INSTALLATION OF PLACARD 220-7 95-19-18 US ( 690 SERIES ) 690D INSTALLATION OF PLACARD 220-9 95-19-18 US 695 SERIES PLACARD - AFM LIMITATIONS - ICING ENVIRONMENT 87-24-07R1 US 226 98-07-17 FLAP CABLE FATIGUE CRACKS AT WING TO FUSELAGE ATTACH POINTS REPLACEMENT OF NLG DRAG LINK BOLT 223R1 AND 223R2 US 98-08-19 US 98-08-25R1 FLIGHT IN ICING CONDITIONS 98-20-34 US 695A ( 695 SERIES ) ENGINE MOUNT SYSTEMS 84-19-05 US INSPECT VERTICAL STABILIZER FOR CRACKS
INSTALLATION OF PLACARD 218 US 95-13-02 220-11 95-19-18 US 700 AEROMOT **AMT 200** AERONCA C3 K KC O 58B SEE/VOIR: BELLANCA 7 SERIES SEE/VOIR: BELLANCA ( 7 SERIES ) 7AC ( 7 SERIES ) SEE/VOIR: BELLANCA 7BCM ( 7 SERIES ) SEE/VOIR: BELLANCA 7CCM SEE/VOIR: BELLANCA S7CCM SEE/VOIR: BELLANCA 7DC ( 7 SERIES ) SEE/VOIR: BELLANCA S7DC 7EC ( 7 SERIES ) SEE/VOIR: BELLANCA

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

	NOWERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
AERONC S7EC	A	( 7 SERIES ) SEE/VOIR: BELLANCA	
11 SE	RIES		
11AC US US US US US US US US US US US	47-20-01 47-20-02 47-30-01 47-30-05 48-04-02 48-13-07 49-11-02 49-15-01 52-28-01	( 11 SERIES )  GASCOLATOR BOWLS  OLEO STRUT  LIFT STRUT  EXHAUST STACKS  WING LEADING EDGE  ELEVATOR TURNBUCKLE FORKS  REAR FUSELAGE WING ATTACHMENT  SEAT BELT ANCHORAGE  AUXILIARY FUEL TANK	
S11AC US US US US	48-13-07 49-11-02 49-15-01 52-28-01	( 11 SERIES )  ELEVATOR TURNBUCKLE FORKS  REAR FUSELAGE WING ATTACHMENT  SEAT BELT ANCHORAGE  AUXILIARY FUEL TANK	
US US US	48-04-02 49-11-02 49-15-01	( 11 SERIES ) WING LEADING EDGE REAR FUSELAGE WING ATTACHMENT SEAT BELT ANCHORAGE	
S11BC 11CC US	49-11-02	( 11 SERIES ) ( 11 SERIES ) REAR FUSELAGE WING ATTACHMENT	
S11CC	73 11 02	( 11 SERIES )	
CF US US US US	CF-52-05 48-38-01 48-43-02 61-16-01 68-20-05	RADIO LEAD OIL COOLER INSTALLATION CONTINENTAL C-125-2 ENGINES LIFT STRUT FITTINGS FUEL TANK INSPECTION	
S15AC US US US US	48-38-01 61-16-01 68-20-05	OIL COOLER INSTALLATION LIFT STRUT FITTINGS FUEL TANK INSPECTION	
	A 65 SERIES		
65C		( AERONCA 65 SERIES )	
65CA US	47-30-08	( AERONCA 65 SERIES ) SEAT MODIFICATION	
65LA US	47-30-08	( AERONCA 65 SERIES ) SEAT MODIFICATION	
65LB		( AERONCA 65 SERIES )	
65TAC		( AERONCA 65 SERIES )	
65TC		( AERONCA 65 SERIES )	
S65CA US	47-30-08	SEAT MODIFICATION	
AEROSPA ATR 42 CF FR FR FR FR FR FR	300 CE-95-01P2	FLIGHT / VOICE COCKPIT RECORDERS	42-57-0043 A001-25-22 IPECD ASB ATR 42-79-0002 ATR 42-27-0004 &0008 ATR 42-23-0002 42-34-0004,-A0016

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

	PATIALE		
	12 300		
	NUED / SUITE)		40 20 0000 40 400
FR	87-091-006(B)R1	MAIN LANDING GEAR WHEELS	42-32-006R5, -40-1R2
FR	87-155-007(B)	MAIN LANDING GEAR WHEELS ELEVATOR TRIMS PROPELLER BRAKE CONTROL SYSTEM AUTOPILOT ROLL ACT TOR FUEL QUANTITY IND IONS RUDDER CONTROL CHANNEL CABLES ENGINE / PROPELLER FLEXIBLE CONTROL SHAFTS HONEYWELL-SPERRY NAVIGATION EQUIPMENT MAIN GEAR WHEEL BEARINGS PROPELLER BRAKE CONTROL PUSHBUTTON SMOKE DETECTOR - CARGO COMPARTMENT AREA GOODYEAR AIRCRAFT TIRES STRUCTURAL MODS - FATIGUE TEST FINDINGS PITCH TRIM OIL PRESSURE TRANSMITTER MANIFOLD DRAIN PLUG	42-27-0010,-0015
FR	87-156-008(B)R1	PROPELLER BRAKE CONTROL SYSTEM	42-61-0013R1,-0014R1
FR	87-173-009(B)	AUTOPILOT ROLL ACT * TOR	42-22-0005, -0006
FR	88-051-010(B)R2	FUEL QUANTITY IND . IONS	ATR 42-28-0021
FR	88-070-011(B)	RUDDER CONTROL CHANNEL CABLES	AIR 42-27-0027
FR	88-080-012(B)	ENGINE / PROPELLER FLEXIBLE CONTROL SHAFTS	ATR 42-76-0002R1
FR	88-092-013(B)	HONEYWELL-SPERRY NAVIGATION EQUIPMENT	42-34-0024, -0025
FR	88-135-014(B)	MAIN GEAR WHEEL BEARINGS	ATR 42-32-0018R1
FR	88-14/-015(8)	PROPELLER BRAKE CONTROL PUSHBUTTON	ATR 42-61-0010R2
FR	88-186-016(B)R1	SMOKE DETECTOR - CARGO COMPARTMENT AREA	ATR 42-26-0009,0010
FR	88-187-IMP(AB)R1	GOODYEAR AIRCRAFT TIRES	ATR 42-32A0022
FR	89-017-017(B)R2	STRUCTURAL MODS - FATIGUE TEST FINDINGS	ATR 42-53-0023,0042
FR	89-033-019(B)R1	PITCH TRIM	ATR 42-27-0029
FR	89-042-018(B)R1	OIL PRESSURE TRANSMITTER MANIFOLD DRAIN PLUG	
FR	89-067-020(B)R2	MLG RETRACTION JACKS FITTING BOLTS	ATR 42-53-0045R1
FR	89-077-021(B)R3	AILERON TAB INBOARD HINGE PIN	ATR 42-57-0028 &0030
FR	89-093-022(B)	AUTOMATIC CUT-OFF / VOICE RECORDERS	ATR 42-23-0018
FR	89-120-023(B)R1	ANTI-ICING ADVISORY SYSTEM	42-30-0017, -0018
		PASSENGER / CREW DOOR LIFTING DEVICE	ATR 42-52-0019
FR	89-197-025(B)R1	ENGINE FIRE EXTINGUISHING SYSTEM	ATR 42-26A0014R1
FR	90-028-026(B)	NOSE LANDING GEAR RETRACTION SYSTEM	ATR 42-32-0021, 0028
FR	90-029-027(B)	EMERGENCY LIGHTING	ATR 42-33-0017
FR	89-138-024(B)R1 89-197-025(B)R1 90-028-026(B) 90-029-027(B) 90-030-028(B)R1	PROPELLER BRAKE	ATR 42-61-0022R2
FR	90-109-029(B) 90-155-030(B)R1 90-163-031(B) 90-193-032(B)R2 90-201-033(B)R2	MLG RETRACTION JACKS FITTING BOLTS AILERON TAB INBOARD HINGE PIN AUTOMATIC CUT-OFF / VOICE RECORDERS ANTI-ICING ADVISORY SYSTEM PASSENGER / CREW DOOR LIFTING DEVICE ENGINE FIRE EXTINGUISHING SYSTEM NOSE LANDING GEAR RETRACTION SYSTEM EMERGENCY LIGHTING PROPELLER BRAKE MAIN FRAMES EMERGENCY OXYGEN SYSTEM FOR CABIN ATTENDANTS LANDING GEAR BAY AREA REINFORCING PLATE HYDRAULIC SYSTEM LOW PRESSURE WARNING ROLL DEPARTURE MANUAL DISCONNECT AUTOPILOT NOSE LANDING GEAR	ATR 42-53-0057
FR	90-155-030(B)R1	EMERGENCY OXYGEN SYSTEM FOR CABIN ATTENDANTS	ATR 42-35-008
FR	90-163-031(B)	LANDING GEAR BAY AREA REINFORCING PLATE	ATR 42-53-0043
FR	90-193-032(B)R2	HYDRAULIC SYSTEM LOW PRESSURE WARNING	ATR 42-29-A0013
FR	90-201-033(B)R2	ROLL DEPARTURE MANUAL DISCONNECT AUTOPILOT	ATR 42-27-0050 0051
	01 005 000(0)	NOSE LANDING GEAR	ATR 42-32-0025
FR	91-005-036(B) 91-033-038(B)R2 91-068-039(B)	MAIN LANDING GEAR	ATR 42-32-0036R3
FR	91-068-039(B)	FLIGHT CONTROLS	ATR 42-27-0052
FR	91-081-040(B)R1	MAIN LANDING GEAR	ATR 42-32-0038R1
FR	91-157-041(B)	MAIN LANDING GEAR FLIGHT CONTROLS MAIN LANDING GEAR NOSE LANDING GEAR - DYE PENETRANT INSPECTION	42-32-0039
FR	91-214-042(B)		
FR	91-216-043(B)R1	ENGINE CONTROLS	42-76-0009
FR	91-237-044(B)	MAIN LANDING GEAR  MAIN LANDING GEAR  NOSE LANDING GEAR - DYE PENETRANT INSPECTION FLIGHT CONTROLS - TRIM TABS ENGINE CONTROLS  AUTO PILOT - ROLL OUT-OF-TRIM RH SERVICE DOOR LINING REF S 252 11419 STRUCTURE FATIGUE TESTS ECE PUSH BUTTON PITCH CONTROL AUTORIOT	42-22-0015 & 27-0058
FR	92-043-045(B)	RH SERVICE DOOR LINING REF S 252 11419	JAR 25-583 A
FR	92-044-046(B)R2	STRUCTURE FATIGUE TESTS	52~0058.59.53-0076
FR	92-122-047(B)	ECE PUSH BUTTON	ATR 42-31-0023
FR	92-133-048(B)R1	PITCH CONTROL AUTOPILOT OUTER WINGS - NDT INSPECTION PITCH TRIM CONTROLS FLIGHT CONTROL RODS ROLL TRIM	ATR 42-27-0063
FR	92-197-049(B)	AUTOPILOT	ATR 42-22-0012
FR	93-190-051(B)	OUTER WINGS - NDT INSPECTION	ATR 42-57-0040,0038
FR	93-205-052(B)	PITCH TRIM CONTROLS	42-27-0066
FR	94-003-053(B)	FLIGHT CONTROL RODS	42-27-0071, -0049
FR	94-004-054(B)	ROLL TRIM	42-27-00140070
FR	94-005-055(B)	NOSE LANDING GEAR NARDI HINGE PINS	42-32-0064
FR	94-162-056(B)	PITCH TRIM CONTROLS  FLIGHT CONTROL RODS  ROLL TRIM  NOSE LANDING GEAR NARDI HINGE PINS  KARMAN FAIRING ATTACHMENT CLIPS  MAIN LANDING GEAR SIDE BRACE PIN  ELECT HARNESS FRONT AREA  TIME LIMITS  WINDSHIELD FRAME  WING REAR SPAR CORRSION  MLG LEGS - BARREL - SWINGING LEVER HINGE	42-53-0063 -0081
FR	95-051-058(B)	MAIN LANDING GEAR SIDE BRACE PIN	42-32-0070
FR	95-103-059(B)	ELECT HARNESS FRONT ARFA	25-00630094
FR	95-104-060(B)	TIME LIMITS	MAINT PLAN DOC
FR	95-126-061(B)	WINDSHIELD FRAME	42-53-0093 & 0094
FR	95-127-063(B)	WING REAR SPAR CORRSION	42-57-0044
FR	1996-294(B)R4	MLG LEGS - BARREL - SWINGING LEVER HINGE	MD 631-32-132 & 122
FR	96-109-063(B)	FNGINE NACELLE DRAIN SYSTEM	42-71-0010
FR	96-131-064(B)	MAIN LANDING GEAR - PINS (EDDATHM)	ATP 42-32-009180093
FR	96-230-066(B)	STANDRY HORIZON-POWED SLIDDLY (EDDATIM)	42-34-0090
FR	96-256-068(B)	WING REAR SPAR CORRSION MLG LEGS - BARREL - SWINGING LEVER HINGE ENGINE NACELLE DRAIN SYSTEM MAIN LANDING GEAR - PINS (ERRATUM) STANDBY HORIZON-POWER SUPPLY (ERRATUM) STICK SHAKER/PUSHER SYSTEM	42-34-0090
FR	96-289-069(B)R1	FORWARD CARGO COMPARTMENT NETS	42-27-0083
FR	97-115-070(B)R1	FUSELAGE-MAIN LANDING GEAR ACTUATOR FITTING	42-25-0108
FR	97-159-071(B)	KARMAN FAIRING PANEL FASTENERS	42-53-0097 & 0112
FR	98-069-073(B)	ENGINE MOUNT & UPPER FAIRING STIFFENER	42-54-0019
FR	98-070-074(B)		42-54-0019
FR	98-147-075(B)	ROTRON CIRCULATION FAN WINGS-INNER SKIN/REAR SPAR JUNCTION	
FR	98-148-076(B)R1		42-57-0010, 0050
FR	1999-014-076(B)R1	CANCELLATION OF AD T98-148-076(B)	
FR	1999-165-077(B)	ICING CONDITIONS SEVERE ICING CONDITIONS	ATR42-30-0064R1
		SEVERE TOTING CONDITIONS	ATR42-30-0064RT
SA 31	5B		
CF	CF-98-15	EXTERNAL RESCUE SYSTEMS	CAR 702.21
FR FR	71-042-001(B) 72-009-002(B)	MAIN ROTOR HUB FREE WHEEL LUBRICATION - TAIL ROTOR GEAR BOX	01-25

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

EROS	PATIALE		
SA 3			
	INUED / SUITE)		
FR	72-096-003(B)	MAIN ROTOR BLADES	01-04
FR	72-152-004(B)	MAIN GEAR BOX	05-02
FR	73-039-005(B)	MAIN GEARBOX COUPLING	01-05
FR	74-079-006(B)	MAIN GEARBOX	01-08
FR	74-141-007(B)	MAIN ROTOR HEAD	65-15
FR	75-164-011(B)	MAIN ROTOR HUB - HYDRAULIC DAMPERS	65-20
FR	77-201-014(B)	MGB - OIL PUMP DRIVE DRIVE SHAFT SPLINES	05-12R1
FR	77-203-015(B)	TELEC NOISE FILTERS	01-10
FR	78-226-016(B)	MGB - SECONDARY STAGE PLANETARY GEAR ASSEMBLY	01-13
FR	79-016-017(B)R1	INTERMEDIATE BEARING ASSEMBLY	01-14R2
FR	79-053-018(B)	FREEWHEEL UNIT LUBRICATION	65-06R1, 05-14
FR	80-194-020(B)	MAIN GEARBOX OUTPUT FLANGE	05-16
FR	80-250-021(B)	FWD ATTACHMENT TRANSMISSION SUPPORT PLATFORM	05-17
FR	82-029-022(B)	TAIL ROTOR GEARBOX SUPPORT LUGS	05-19
FR	83-084-025(B)R1	MAIN GEARBOX "A" FRAMES	01-18R1
FR	83-204-026(B)R1	SUPERCEDED BY 96-277-037(B)	
FR	84-084-027(B)R1	TAIL ROTOR PITCH CHANGE CONTROL ROD	01-19R1
FR	84-099-028(B)R1	MAIN GEAR BOX	01-20,05-25
FR	84-134-029(B)	MAIN ROTOR HUB	65-34
FR	85-194-030(B)R1	SUPERCEDED BY 96-277-037(B)	
FR	88-025-031(B)R1	SUPERCEDED BY AD 96-277-037(B)	
FR	89-162-032(B)R1	MAIN ROTOR BLADES - LIFE LIMITS	
FR	92-130-033(B)	EDEEMILEEL	01.27
FR	93-104-034(B)R2	MAIN ROTOR BLADES, FRETTING CORROSION	65-38
FR	94-048-IMP(B)	MAIN ROTOR BLADE/HEAD VIBRATION	SIL 1-11-92A
FR	96-071-035(B)	ELECTRIC FUEL COCK CHECK	ELT MANUAL DEVIO
FR	96-081-036(B)R1	MAIN ROTOR BLADE ATTACHMENT FITTINGS HORIZONTAL STABILIZER SPAR	MM CHAP5 REVO3-96
FR	96-277-037(A)R2	HORIZONTAL STABILIZER SPAR	55.01 REV2. 05.15
FR	T98-286-042(A)	BLADE CRACKING	05-36
FR	98-089-038(A)R1	SUPERCEDED BY AD 98-171-039(A)R1	00 00
FR	98-171-039(A)R1	MAIN ROTOR BLADE SPAR TO CUFF ASSEMBLY	SERV TEL 01-30
	98-277-040(A)R1		
FR		MAIN RUIUR BLADE SKIN AND RODI REINFORCEMENT	(15.34
FR FR		MAIN ROTOR BLADE SKIN AND ROOT REINFORCEMENT BLADE CRACKING	05.34
FR FR FR	98-288-042(A) 98-303-041(A)	BLADE CRACKING	05.34 05-36
FR	98-288-042(A)	MAIN ROIDE BLADE SKIN AND ROOT REINFORCEMENT BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE	05-36
FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A)	BLADE CRACKING MAIN GEAR BOX	05.34 05-36
FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE	O5-36
FR FR FR CF	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS	05-36 CAR 702.21
FR FR FR CF FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN	05-36 CAR 702.21 01-25
FR FR FR GA 31 CF FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION	05-36 CAR 702.21 01-25 65-85
FR FR FR CF FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES	05-36 CAR 702.21 01-25 65-85 01-31
FR FR FR CF FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES	O5-36  CAR 702.21  O1-25  65-85  O1-31  O5-47
FR FR CF FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING	05-36 CAR 702.21 01-25 65-85 01-31 05-47 01-32
FR FR FR CF FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-040-017(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31
FR FR FR CF FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34
FR FR FR CF FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-097-014(B) 72-097-016(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101
FR FR CF FR FR FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS	O5-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54
FR FR FR CF FR FR FR FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-163-024(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107
FR FR FR CF FR FR FR FR FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-097-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-173-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40
FR FR FR CF FR FR FR FR FR FR FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 76-024-027(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40
FR FR FR CF FR FR FR FR FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-097-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-173-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1
FR FR FR CFR FR FR FR FR FR FR FR FR FR FR FR FR F	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 76-024-027(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62
FR FR FR A CFR FR FR FR FR FR FR FR FR FR FR FR FR F	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 76-024-027(B) 77-053-029(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42
FR FR FR CFR FR FR FR FR FR FR FR FR FR FR FR FR F	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-063-030(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63
FR FR CF FR FR FR FR FR FR FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-103-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-063-030(B) 77-064-031(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX. SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42 05-63 05-60/2
FR FR FR A CF FR FR FR FR FR FR FR FR FR FR FR FR FR	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-063-030(B) 77-064-031(B) 77-136-032(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX. SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES MAIN GEAR BOXES TAIL ROTOR GEARBOX. SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42 05-63 05-60/2 01-38/1
FR FR A CFR FR FR FR FR FR FR FR FR FR FR FR FR F	98-288-042(A) 98-303-041(A) 1999-129-043(A) 6B CF-98-15 71-043-013(B) 72-007-014(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-107-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-063-030(B) 77-064-031(B) 77-136-032(B) 77-136-032(B) 77-202-033(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42 05-63 05-60/2 01-38/1 01-44
FR FR A 31 A CF FF	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-030(B) 77-064-031(B) 77-136-032(B) 77-202-033(B) 77-202-033(B) 77-205-034(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX. SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES MAIN GEAR BOXES TAIL ROTOR GEARBOX. SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-63 O5-60/2 O1-38/1 O1-44 O1-45
FR FR FR GF FFR FFR FFR FFR FFR FFR FFR	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-030(B) 77-064-031(B) 77-136-032(B) 77-205-034(B) 77-205-034(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-60/2 O1-38/1 O1-44 O1-44 O1-45 O1-46
FR A 31 A CF FF	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-064-031(B) 77-136-032(B) 77-064-031(B) 77-136-032(B) 77-205-034(B) 78-139-035(B) 78-225-036(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX SITUTEMEN BOX SITUTEMEN BOX SITUTEMEN BOX SITUTEMEN BOX SITUTERMEDIATE BEARING	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42 05-63 05-60/2 01-38/1 01-44 01-45 01-46 01-47
FR FR A CF FFR FFR FFR FFR FFR FFR FFR FFR FFR F	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-030(B) 77-064-031(B) 77-064-031(B) 77-205-034(B) 77-205-034(B) 77-205-034(B) 78-139-035(B) 78-139-035(B) 78-225-036(B) 78-225-036(B) 78-015-038(B)R1	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX SIRVINGER BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-63 O5-60/2 O1-38/1 O1-45 O1-45 O1-45 O1-47 65-81
FR FR A CF FFR FFR FFR FFR FFR FFR FFR FFR FFR F	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-064-031(B) 77-136-032(B) 77-136-032(B) 77-205-034(B) 77-205-034(B) 77-136-032(B) 77-136-032(B) 77-136-032(B) 77-156-038(B) 77-156-038(B) 77-156-038(B) 78-228-037(B) 78-139-035(B) 78-139-035(B) 78-150-038(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-60/2 O1-38/1 O1-45 O1-45 O1-45 O1-47 65-81 O5-66 R3
FR 31 CFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-030(B) 77-063-030(B) 77-063-030(B) 77-063-030(B) 77-205-034(B) 78-139-035(B) 78-125-036(B) 78-228-037(B) 79-015-038(B)R1 79-051-038(B)R1 79-051-039(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42 05-63 05-60/2 01-38/1 01-45 01-45 01-46 01-47 65-81 05-66 R3 05-66R2
FR 31 CFRFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-063-030(B) 77-063-030(B) 77-064-031(B) 77-063-030(B) 77-064-031(B) 77-053-029(B) 77-064-031(B) 77-053-034(B) 77-053-036(B) 77-053-036(B) 77-053-036(B) 77-053-036(B) 78-225-036(B) 78-228-037(B) 79-015-038(B)R1 79-051-039(B) 80-062-041(A)R2 80-062-041(B)R1	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER ~ EMERGENCY FLOTATION GEAR	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-60/2 O1-38/1 O1-45 O1-45 O1-45 O1-47 65-81 O5-66 R3
FR 31 CF FF F	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-030(B) 77-064-031(B) 77-064-031(B) 77-055-034(B) 77-055-034(B) 77-055-034(B) 77-055-036(B) 77-064-031(B) 77-055-036(B) 78-228-037(B) 78-228-037(B) 78-035-034(B) 78-035-034(B) 78-035-034(B) 78-035-034(B) 78-035-034(B) 78-035-034(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER - EMERGENCY FLOTATION GEAR MAIN GEARBOX "A" FRAMES	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42 05-63 05-60/2 01-38/1 01-45 01-45 01-46 01-47 65-81 05-66 R3 05-66R2
FR 31 CFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-014(B) 72-146-016(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-039(B) 77-063-030(B) 77-064-031(B) 77-064-031(B) 77-065-034(B) 77-055-034(B) 77-055-036(B) 77-055-036(B) 77-055-036(B) 77-055-036(B) 78-139-035(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER ~ EMERGENCY FLOTATION GEAR MAIN GEARBOX "A" FRAMES MAIN GEARBOX "A" FRAMES MAIN GEARBOX OUTPUT FLANGE	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-60/2 O1-38/1 O1-44 O1-45 O1-46 O1-47 65-81 O5-66 R3 O5-66R2 O1-49/R3
FRR 31 CFRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRR	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-015(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-063-030(B) 77-064-031(B) 77-063-030(B) 77-064-031(B) 77-055-034(B) 77-055-036(B) 78-139-035(B) 78-225-036(B) 78-225-036(B) 78-225-036(B) 78-0251-039(B) 80-062-041(A)R2 80-062-041(B)R1 80-083-044(B)R2 80-195-042(B) 80-0251-043(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX. SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER - EMERGENCY FLOTATION GEAR MAIN GEARBOX "A" FRAMES MAIN GEARBOX "UTPUT FLANGE TRANSMISSION FORWARD ATTACHMENT FITTING	O5-36  CAR 702.21 O1-25 65.85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-60/2 O1-38/1 O1-45 O1-45 O1-46 O1-47 65-81 O5-66 R3 O5-66R2 O1-49/R3 O5-68
FR FR A CF FFR FFR FFR FFR FFR FFR FFR FFR FFR F	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-007-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-030(B) 77-064-031(B) 77-064-031(B) 77-136-032(B) 77-020-033(B) 77-055-034(B) 78-139-035(B) 78-225-036(B) 78-228-037(B) 79-051-039(B) 78-051-039(B) 80-062-041(A)R2 80-062-041(B)R1 80-083-044(B)R2 80-195-042(B) 80-251-043(B) 84-085-045(B)R1	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX. SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AFRAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER - EMERGENCY FLOTATION GEAR MAIN GEARBOX OUTPUT FLANGE TRANSMISSION FORWARD ATTACHMENT FITTING TAIL ROTOR PITCH CHANGE CONTROL ROD	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-63 O5-60/2 O1-38/1 O1-44 O1-45 O1-47 65-81 O5-66 R3 O5-66R2 O1-49/R3 O5-68 O5-69 O1-50/R1
FR FR A CF FF FF FF FF FF FF FF FF FF FF FF FF F	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-014(B) 72-146-016(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-063-030(B) 77-064-031(B) 77-064-031(B) 77-064-031(B) 77-055-034(B) 77-055-036(B) 77-050-036(B) 77-050-036(B) 77-064-031(B) 78-135-036(B) 78-225-036(B) 78-225-036(B) 78-225-036(B) 78-225-036(B) 78-045-045(B) 80-062-041(A)R2 80-062-041(B)R1 80-083-044(B)R2 80-195-042(B) 80-051-043(B) 84-085-045(B)R1	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER - EMERGENCY FLOTATION GEAR MAIN GEARBOX "A" FRAMES MAIN GEARBOX "A" FRAMES MAIN GEARBOX "OUTPUT FLANGE TRANSMISSION FORWARD ATTACHMENT FITTING TAIL ROTOR PITCH CHANGE CONTROL ROD MAIN ROTOR HUB	05-36  CAR 702.21 01-25 65-85 01-31 05-47 01-32 53-31 01-34 65-101 05-54 65-107 01-40 01-41 05-60 R1 05-62 01-42 05-63 05-60/2 01-38/1 01-44 01-45 01-46 01-47 65-81 05-66 R3 05-66R2 01-49/R3 05-68 05-69
FRRR A CFERERERERERERERERERERERERERERERERERERER	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-014(B) 72-146-016(B) 73-040-017(B) 73-096-018(B) 74-073-019(A) 74-173-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-039(B) 77-063-030(B) 77-064-031(B) 77-136-032(B) 77-205-034(B) 78-139-035(B) 78-225-036(B) 78-225-036(B) 78-225-036(B) 78-030-030(B) 79-015-038(B)R1 79-051-039(B) 80-062-041(A)R2 80-062-041(B)R1 80-083-044(B)R2 80-195-042(B) 80-251-043(B) 84-085-045(B)R1 84-135-045(B)	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER ~ EMERGENCY FLOTATION GEAR MAIN GEARBOX "A" FRAMES MAIN GEARBOX "A" FRAMES MAIN GEARBOX "A" FRAMES TRANSMISSION FORWARD ATTACHMENT FITTING TAIL ROTOR BLADES MAIN ROTOR BLADES	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-63 O5-60/2 O1-38/1 O1-44 O1-45 O1-47 65-81 O5-66 R3 O5-66R2 O1-49/R3 O5-68 O5-69 O1-50/R1
FRR 31  A CF FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	98-288-042(A) 98-303-041(A) 1999-129-043(A)  6B  CF-98-15 71-043-013(B) 72-097-014(B) 72-146-016(B) 73-096-018(B) 74-073-019(A) 74-140-020(B) 75-100-021(A) 75-163-024(B) 75-231-026(B) 76-024-027(B) 77-053-029(B) 77-063-030(B) 77-064-031(B) 77-064-031(B) 77-064-031(B) 77-055-034(B) 77-055-036(B) 77-050-036(B) 77-050-036(B) 77-064-031(B) 78-135-036(B) 78-225-036(B) 78-225-036(B) 78-225-036(B) 78-225-036(B) 78-045-045(B) 80-062-041(A)R2 80-062-041(B)R1 80-083-044(B)R2 80-195-042(B) 80-051-043(B) 84-085-045(B)R1	BLADE CRACKING MAIN GEAR BOX TAIL ROTOR BLADE SERVICE LIFE  EXTERNAL RESCUE SYSTEMS MAIN ROTOR DRAG HINGE PIN FREE-WHEEL LUBRICATION TAIL ROTOR STRUTS OR CONTROL CABLES MAIN GEAR BOXES MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT MAIN GEARBOX OIL MAIN ROTOR HEAD DRAG DAMPERS HYDRAULIC DAMPERS MAIN GEAR BOXES EMERGENCY FLOTATION GEAR MAIN GEAR BOXES TAIL ROTOR GEARBOX SERVO CONTROL UNITS DIRECTIONAL CONTROL CABLES MAIN GEAR BOXES NOISE FILTERS AERAZUR EMERGENCY FLOTATION GEAR TAIL GEAR BOX STRUT MAIN GEAR BOX INTERMEDIATE BEARING FREEWHEEL UNITS AERAZUR EMERGENCY FLOTATION GEAR NITROGEN CYLINDER - EMERGENCY FLOTATION GEAR MAIN GEARBOX "A" FRAMES MAIN GEARBOX "A" FRAMES MAIN GEARBOX "OUTPUT FLANGE TRANSMISSION FORWARD ATTACHMENT FITTING TAIL ROTOR PITCH CHANGE CONTROL ROD MAIN ROTOR HUB	O5-36  CAR 702.21 O1-25 65-85 O1-31 O5-47 O1-32 53-31 O1-34 65-101 O5-54 65-107 O1-40 O1-41 O5-60 R1 O5-62 O1-42 O5-63 O5-60/2 O1-38/1 O1-44 O1-45 O1-46 O1-47 65-81 O5-66 R3 O5-66R2 O1-49/R3 O5-69 O1-50/R1 65-128

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

AEROSP			
	NUED / SUITE)		
FR	92-132-051(B)	FREEWHEEL UNIT	01-61 65-137R1
FR FR	93-105-052(B)R2 94-047-IMP(B)	MAIN ROTOR BLADE FRETTING MAIN ROTOR BLADE/HEAD VIBRATION	CTI 4-14-00A
FR	96-073-053(B)	ELECTRIC FUEL COCK CHECK	FLT MANUAL REV 3
FR	96-082-054(B)R1	MAIN RTOR BLADE ATTACHMENT FITTINGS	WIN CHAP 5 REV US-96
FR	98-088-055(A)	MAIN ROTOR BLADES - CUFF TO SPAR ASSY	01-64
FR	98-170-056(A)R1	MAIN ROTOR BLADES - CUFF TO SPAR	01-64, 01-65 05-92R1
FR	98-285-057(A)R1	MAIN ROTOR BLADES TAIL ROTOR BLADE SKIN	05-9281
FR FR	98-287-059(A) 98-304-058(A)	MAIN GEAR BOX	03 33
FR	1999-128-060(A)	TAIL ROTOR BLADE SERVICE LIFE	01-66
SE 31			
CF	CF-98-15	EXTERNAL RESCUE SYSTEMS	CAR 702.21
FR	62-018-001(B)	MILL BOTTON DI LOS	56-33-015
FR	64-009-002(B)	TAIL ROTOR BLADE TAIL BOOM - FRAME 6 CONTROL CABLE PASSAGE / WINCH TAIL ROTOR CONTROL PLATE / CABLES TAIL ROTOR HOUSING / BLADES	53-33-041
FR	66-008-003(B)	CONTROL CABLE PASSAGE / WINCH	65-13, 25-30
FR	66-028-004(B)	TAIL ROTOR HOUSING / PLANES	65-34
FR FR	67-027-005(B) 67-031-006(B)	CENTRE SECTION / FIXED TAIL SURFACE ATTACH CLAMPS	05-25, 55-06
FR	68-002-007(B)	TAIL BOOM FORWARD / REAR ATTACH FITTINGS	53-13
FR	68-023-008(B)	REAR ROTOR HUB	01-11
FR	68-067-009(B)	TAIL BOOM - MAIN & REAR TRANSMISSION HOUSINGS	53~20
FR	69-026-010(B)	BODY STRUCTURES - TAIL BOOM / ROTOR CONTROLS  CABLE - TAIL ROTOR CONTROL RUN	0115, 65-58 01-18
FR FR	70-057-011(B) 70-080-012(B)	OSCILLATION LIMITER - REAR ROTOR CONTROL CABLES	53-27
FR	71-043-013(B)	TAIL ROTOR CONTROL - MAIN ROTOR HEAD	01-23, 01-25
FR	72-007-014(B)	FREE WHEEL LUBRICATION - TAIL ROTOR GEAR BOX	01-28, 01-29
FR	72-097-015(B)	TAIL ROTOR - CONTROL CABLES / STRUTS	01-30, 01-31
FR	72-146-016(B)	TAIL ROTOR CONTROL TIE-WIRES	01-31 01-32
FR FR	73-040-017(B)	MAIN GEARBOX COUPLING TAIL BOOM ATTACHMENT AT FRAME 8	53-31
FR	73-096-018(B) 74-140-020(B)	MAIN ROTOR HEAD	65-101
FR	75-163-024(B)	MAIN ROTOR HUB - HYDRAULIC DAMPERS	65-107
FR	75-231-026(B)	MAIN GEAR BOXES	01-40
FR	76-024-027(B)	CO2 CYLINDERS - EMERGENCY FLOTATION GEAR	01-41
FR	77-063-030(B)	STRUT - TAIL ROTOR GEARBOX	05-62 01-42
FR FR	77-064-031(B) 77-136-032(B)	SAMM 4300 SERVO-CONTROL UNIT DIRECTIONAL CONTROL CABLES	05-63
FR	77-202-033(B)	MGB - OIL PUMP DRIVE SHAFT SPLINED COUPLING	05-60R1
FR	77-205-034(B)	TELEC NOISE FILTERS	01-38
FR	78-139-035(B)	PYROMECA CARTRIDGES - EMERGENCY FLOTATION GEAR	01-44
FR	78-225-036(B)	TAIL GEARBOX STRUT ASSEMBLY	01-45
FR FR	78-228-037(B) 79-015-038(B)R1	MGB - SECONDARY STAGE PLANETARY GEAR ASSEMBLY INTERMEDIATE BEARING ASSEMBLY	01-46 01-47R2
FR	79-015-038(B)R1	FREEWHEEL UNIT LUBRICATION	65-81R1, 05-65
FR	80-062-041(A)R2	EMERGENCY FLOTATION INFLATING HEAD CORROSION	05.66R3
FR	80-195-042(B)	MAIN GEARBOX OUTPUT FLANGE	05-68
FR	80-251-043(B)	FWD ATTACHMENT TRANSMISSION SUPPORT PLATFORM	05-69
FR	83-083-044(B)R2	MAIN GEARBOX "A" FRAMES	01-49R3
FR FR	84-085-045(B)R1 84-135-046(B)	TAIL ROTOR PITCH CHANGE CONTROL ROD MAIN ROTOR HUB	01-50R1 65-128
FR	89-163-047(B)R1	MAIN ROTOR HOD MAIN ROTOR BLADES - LIFE LIMITS	
FR	90-200-048(B)R2	FITTING OF BODY STRUCTURE CLUSTER 6 D	05~85R1
FR	91-020-049(A)R2		05-84 R2
FR	91-202-050(B)	HORIZONTAL STABILIZER SPAR TUBES LUCAS AIR EQUIPT HOIST	25.61
FR	92-132-051(B)	FREEWHEEL	01.61 65-137
FR FR	93-105-052(B)R2 94-047-IMP(B)	MAIN ROTOR BLADE, FRETTING CORROSION MAIN ROTOR BLADE/HEAD VIBRATION	SIL 1-11-92A
FR	96-073-053(B)	ELECTRIC ELLEL COCK CHECK	FLT MANUAL REV 3
FR	96-082-054(B)R1	MAIN RTOR BLADE ATTACHMENT FITTINGS	MM CHAP 5 REV 03-96
FR	98-088-055(A)R1	SUPERCEDED BY AD 98-170-056(A)R1	
FR	98-170-056(A)R1	MAIN ROTOR BLADE CUFF TO SPAR AASEMBLY	SERV TEL 01-65
FR FR	98-285-057(A)R1		05.92R1
FR	98-287-059(A) 98-304-058(A)	TAIL ROTOR BLADE SKIN MAIN GEAR BOX	MOD 072241
FR	1999-128-060(A)	TAIL ROTOR BLADE SERVICE LIFE	
CA 24			
SA 318 CF	CF-98-15	EXTERNAL RESCUE SYSTEMS	CAR 702.21
FR	69~027-025(B)	REAR ROTOR CONTROL	65-58
FR	70-015-026(B)	REAR ROTOR BLADES / FUSELAGE FAIRINGS	01-13, 53-25
	DAFT/AFPONEES		

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)
SUBJECT
SUJET

	The second secon	30321	BULLETIN DE SERVICE DE REF
AEROSPA	TIALE		
SA 318			
	UED / SUITE)		
FR	71-044-027(B)	MAIN ROTOR HUB	01-25
FR	72-008-028(B)	FREE WHEEL LUBRICATION	65-85
FR	72-098-029(B)	MAIN ROTOR BLADES	01-30
FR	73-038-030(B)	MAIN GEAR BOX COUPLING SYSTEM	01-32
FR	74-080-031(B)	MAIN GEAR BUX	01-37
FR	75-099-032(B)	DRAG DAMPERS	05-54
FR	75-146-034(B)	MAIN ROTOR HEAD - HYDRAULIC DAMPERS	65-107
FR	77-065-035(B)	SERVO CONTROL UNITS	01-42
FR	77-206-036(B)	LETEC MOTZE LIFLEKZ	01-38
FR	79-014-037(B)R1	INTERMEDIATE BEARING ASSEMBLY	01.47R2
FR	79-052-038(B)	LUBRICATION - MAIN GEAR BOX / CLUTCH FREEWHEEL UNI	TS 65-81, 05-65
FR	80-193-039(B)R2	STABILIZER SPAR TUBE ATTACHMENT-SEE 93-111-051(B)	05-67R3
FR	80-197-040(B)	MAIN GEAR BOX OUTPUT FLANGE	05-68
FR	80-249-041(B)	TRANSMISSION SUPPORT PLATFORM	05-69
FR	82-028-042(B)	TAIL ROTOR GEAR BOX SUPPORT LUGS	05-71
FR	82-167-043(B)R1	SUPERCEDED BY 96-278-054(B)	
FR	84-086-044(B)R1	TAIL ROTOR PITCH CHANGE CONTROL ROD	01-50R1
FR	85-141-045(B)R1	SUPERCEDED BY 96-278-054(B)	
FR	89-164-047(B)R1	MAIN ROTOR BLADES - LIFE LIMITS	
FR	92-131-049(B)	FREEWHEEL	01.61
FR	93-111-051(B)R1	SUPERCEDED BY AD 96-278-054(R)	
FR	93-112-050(B)	MGB 'A' FRAMES LIFE LIMITS	01-49R3
FR	96-072-053(B)	ELECTRIC FUEL COCK CHECK	FLT MANUAL REV 3
FR	96-278-054(A)R2	HORIZONTAL STABILIZER SPAR	55 10 REV 1
FR	97-135-055(A)R2	MGB 'A' FRAMES LIFE LIMITS ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADE	05-91R1
FR	98-286-056(A)	BLADE CRACKING	05-94
FR	1999-127-057(A)	TAIL ROTOR BLADE SERVICE LIFE	00 04
118	1333 127 037(A)	TATE ROTOR BEADE SERVICE LIFE	
SA 318	0		
CF	CF-98-15	EXTERNAL RESCUE SYSTEMS	CAR 702.21
FR	66-001-021(B)	EXTERNAL RESCUE SYSTEMS MAIN ROTOR BLADES - RETIREMENT LIFE REAR TRANSMISSION REAR ROTOR CONTROL / MAIN ROTOR SHAFT MAIN TRANSMISSION OIL SYSTEM COUPLINGS REAR ROTOR CONTROL	65-30
FR	66-038-022(B)	DEAD TRANSMISSION	65-30
FR	68-021-023(B)	DEAD DOTOD CONTROL / MAIN DOTOD CHAFT	65-34R1, 05-26
FR	69-012-024(B)	MAIN TRANSMISSION OIL SYSTEM COURTINGS	65-61
FR	69-027-025(B)	REAR ROTOR CONTROL	65-58
		REAR ROTOR CONTROL REAR ROTOR BLADES / FUSELAGE FAIRINGS	01-12 52-25
FR	70-015-026(B)	MAIN ROTOR HUB	01-13, 53-25
FR	71-044-027(B)		65-85
FR	72-008-028(B)	PREE WHEEL LUDRICATION	01-00
FR	72-098-029(B)	MAIN ROTOR BLADES MAIN GEAR BOX COUPLING SYSTEM	01-30
	73-038-030(B)	MATN CEAR BOX COUPLING SYSTEM	01-32
FR	74-080-031(B)	MAIN GEAR BOX	05-54
FR	75-099-032(B)	DRAG DAMPERS	05-54
FR	75-146-034(B)	MAIN ROTOR HEAD - HYDRAULIC DAMPERS SERVO CONTROL UNITS	65-107
FR	77-065-035(B)	SERVU CUNTRUL UNITS	01-42
FR	77-206-036(B)	TELEC NOISE FILTERS	01-38
FR	79-014-037(B)R1	INTERMEDIATE BEARING ASSEMBLY	01.47R2
FR	79-052-038(B)	LUBRICATION - MAIN GEAR BOX / CLUTCH FREEWHEEL UNI	
FR	80-193-039(B)R2	STABILIZER SPAR TUBE ATTACHMENT-SEE 93-111-051(B)	
FR	80-197-040(B)	MAIN GEAR BOX OUTPUT FLANGE	05-68
FR	80-249-041(B)	TRANSMISSION SUPPORT PLATFORM	05-69
FR	82-028-042(B)	TAIL ROTOR GEAR BOX SUPPORT LUGS	05-71
FR	82-167-043(B)R1	SUPERCEDED BY 96-278-054(B)	04 5004
FR	84-086-044(B)R1	TAIL ROTOR PITCH CHANGE CONTROL ROD	01-50R1
FR	85-141-045(B)R1	SUPERCEDED BY 96-278-054(B)	
FR	89-163-032(B)	MAIN ROTOR BLADES - SERVICE LIFE LIMIT	
FR	89-164-047(B)R1	MAIN ROTOR BLADES - LIFE LIMITS	
FR	92-131-049(B)	FREEWHEEL	01.61
	93-111-051(B)R1	SUPERCEDED BY AD 96-278-054(B)	
FR		MGB 'A' FRAMES LIFE LIMITS	01-49R3
FR FR		MOD A TRANCO CITE CINITIO	
FR	93-112-050(B)	ELECTRIC FUEL COCK CHECK	FLT MANUAL REV 3
FR FR	93-112-050(B) 96-072-053(B)	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR	55.10REV1, 01.52,
FR FR FR	93-112-050(B) 96-072-053(B) 96-278-054(A)R2	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR	
FR FR FR FR	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES	55.10REV1, 01.52,
FR FR FR FR FR	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A)	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING	55.10REV1, 01.52, 05-91R1
FR FR FR FR FR	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES	55.10REV1, 01.52, 05-91R1
FR FR FR FR FR FR	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A) 1999-127-057(A)	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING	55.10REV1, 01.52, 05-91R1 05-94
FR FR FR FR FR FR	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A) 1999-127-057(A) SERIES	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING TAIL ROTOR BLADE SERVICE LIFE	55.10REV1, 01.52, 05-91R1
FR FR FR FR FR FR CF	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A) 1999-127-057(A) SERIES CF-86-09	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING TAIL ROTOR BLADE SERVICE LIFE  INTERIOR FURNISHINGS - METAIR	55.10REV1, 01.52, 05-91R1 05-94
FR FR FR FR FR CF CF	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A) 1999-127-057(A) SERIES CF-86-09 CF-98-15	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING TAIL ROTOR BLADE SERVICE LIFE  INTERIOR FURNISHINGS - METAIR EXTERNAL RESCUE SYSTEMS	55.10REV1, 01.52, 05-91R1 05-94
FR FR FR FR FR CF CF	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A) 1999-127-057(A) SERIES CF-86-09 CF-98-15 82-191-003(B)	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING TAIL ROTOR BLADE SERVICE LIFE  INTERIOR FURNISHINGS - METAIR EXTERNAL RESCUE SYSTEMS MAIN ROTOR HEAD SPINDLE	55.10REV1, 01.52, 05-91R1 05-94 023 METAIR CAR 702.21
FR FR FR FR FR CF CF FR FR	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A) 1999-127-057(A)  SERIES CF-86-09 CF-98-15 82-191-003(B) 83-094-005(B)R1	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING TAIL ROTOR BLADE SERVICE LIFE  INTERIOR FURNISHINGS - METAIR EXTERNAL RESCUE SYSTEMS MAIN ROTOR HEAD SPINDLE TAIL ROTOR DRIVE SHAFT	55.10REV1, 01.52, 05-91R1 05-94 023 METAIR CAR 702.21 05-02,01-01
FR FR FR FR FR CF CF	93-112-050(B) 96-072-053(B) 96-278-054(A)R2 97-135-055(A)R2 98-286-056(A) 1999-127-057(A) SERIES CF-86-09 CF-98-15 82-191-003(B)	ELECTRIC FUEL COCK CHECK HORIZONTAL STABILIZER SPAR IN FLIGHT DISRUPTION OF MAIN ROTOR BLADES BLADE CRACKING TAIL ROTOR BLADE SERVICE LIFE  INTERIOR FURNISHINGS - METAIR EXTERNAL RESCUE SYSTEMS MAIN ROTOR HEAD SPINDLE	55.10REV1, 01.52, 05-91R1 05-94 023 METAIR CAR 702.21 05-02,01-01 71-03 R1

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

AEROSPATIALE				
AS 332	SERIES			
(CONTINU	JED / SUITE)	CABIN ROOF	78-298-00-16	
	83-114-008(B) 83-144-010(B)	TATE DRIVE CHAFT DEADINGS	01-02,53-19	
FP	83-157-011(B)R1			
		TAIL ROTOR HINGE ENGINE / MAIN GEARBOX COWLINGS TAIL GEARBOX FORWARD SUPPORT FITTING INCLINED DRIVE SHAFT FAIRING	05-06,53-64	
FR	83-202-013(B)	TAIL GEARBOX FORWARD SUPPORT FITTING	05-05A,53-18	
	04 100 014(D)		22 04	
FR	84-145-15(B)	YAW DAMPER BODY AUTOMATIC PILOT SYSTEM	22-04R1	
FR FR	85-063-016(B) 85-067-017(B)	INTERMEDIATE GEARBOX	01-10	
FR	85-140-018(B)	MAIN GEARBOX - ACCESSORY GEARBOX	01-12	
FR	85-151-019(B)R1		05-07, 01-20	
FR	85-169-020(B)R2	OIL FILTER - MAIN GEAR BOX ENGINE AIR INTAKE	53-62,71-07	
FR	85-214-021(B)	DE-ICING SYSIEM	01-09 56-80	
FR	85-215-022(B)	ENGINE FIRE EXTINGUISHING SYSTEM PARTS - SERVICE LIFE LIMITS		
FR FR	86-041-024(B) 86-121-025(B)R1	PARTS - SERVICE LIFE LIMITS MAIN ROTOR HEAD SLEEVES TAIL ROTOR HUB SLEEVE CLEVICES ELECTRICAL POWER GENERATING SYSTEM MAIN ROTOR HEAD SLEEVE ASSEMBLIES HORIZONTAL STABILIZER FREQUENCY ADAPTER T/R BLADE BUSHINGS	05-09R3	
FR	86-121-023(B)K1	TAIL ROTOR HUB SLEEVE CLEVICES	05-10,05-11	
FR	87-012-027(B)R1	ELECTRICAL POWER GENERATING SYSTEM	05-12,24-10	
FR	87-078-028(B)R1	MAIN ROTOR HEAD SLEEVE ASSEMBLIES	05-19A	
FR	87-093-029(B)R1	HORIZONTAL STABILIZER	55-01R1	
FR	87-103-030(B)R1	FREQUENCY ADAPTER	05-17 05-15R2 & R3	
FR FR	87-112-031(B)R3 87-114-032(B)			
FR	87-114-032(B) 87-157-033(B)	AUTOPILOT UNIT VALVES FLIGHT CYCLES / SERVICE LIFE LIMITS M. R BLADES-LEADING EDGE STRIP FIRE EXTINGUISHING PERCUSSION SYSTEM	01-18	
FR	88-097-034(B)R2	FLIGHT CYCLES / SERVICE LIFE LIMITS	01-23	
FR	88-099-035(B)R4	M R BLADES-LEADING EDGE STRIP	05-22R3	
FR	89-057-036(B)	HF-SSB WIRE ANTENNA LUCAS AIR EQUIPMENT RESCUE HOIST SUPERCEDED BY 96-263-060(B)	01-25	
FR	89-135-037(B)	HF-SSB WIRE ANTENNA	23-05	
FR	90-078(AB)	LUCAS AIR EQUIPMENT RESCUE MUIST	65.07	
FR FR	90-127-039(B)R1		1/90 TECH DIR	
FR	90-136-038(B) 90-161-040(B)R2	INTERMEDIATE GEARBOX AFT ATTACHMENT RIB	05.27R2	
FR	90-230-041(B)R3	INTERMEDIATE GEARBOX AFT ATTACHMENT RIB TAIL ROTOR PITCH CHANGE ROD BEARING CHECK	05.29R1	
FR	91-012-042(B)R3	CRACKS UN TAIL RUTUR MEAD SPINDLES	01.30 13301 2	
FR	91-037-043(B)		23.07	
FR	91-206-044(B)	LANDING GEAR ACTUATOR FAIRING	05.35	
FR	91-240-045(B)R3	TAIL ROTOR DRIVE SHAFTS	05.37R2 01.32	
FR FR	91-248-046(B) 91-249-047(B)R1	FUEL FILTER ELECTRICAL CABINET	01.31R1	
FR	91-254(AB)	AIR CONDCOMPRESSOR WHEEL AND SCROLL	ABG SEMCA 3502-21-01	
FR	92-143-048(B)	ELECTRIC POWER SYSTEM	24.20	
FR	92-146-049(B)	INSPECTION OF INTERMEDIATE GEARBOX	01.35	
FR	93-106-050(B)	SWASHPLATE SCISSORS	01-36R1	
FR	93-131-051(B)R1	EPICYCLIC MODULE INCORRECT BOLTS SLING INSTALLATION - 3 TON CARGO HOOK	01-37 01-38R1	
FR	94-150-052(B)R1	TAIL POSITION LIGHT	01-38	
FR FR	94-217-053(B) 95-029-054(B)	DE-ICING MAIN ROTOR BLADES (P/N 332A11-030-03/04)	SERVICE TELEX 01-42	
FR	95-143-055(B)	ELECTRICAL BONDING BRAIDS TAIL ROTOR	64.14 R2	
FR	95-262-056(B)R1	TAIL ROTOR HEAD PITCH CHANGE SPIDER	01.00.43	
FR	96-074-057(B)	TAIL ROTOR SHAFT FLAPPING HINGE RETAINERS	05.00.41	
FR	96-100-058(B)	TAIL ROTOR SHAFT FLAPPING HINGE RETAINERS SPINDLES AND FLAPPING HINGES INTERMEDIATE GEARBOX FORWARD MOUNT EYE BOLT SHAFT BEARING	01.00.44	
FR	96-263-060(AB)R1	INTERMEDIATE GEARBOX FORWARD MOUNT	01.00.47 01-00-52R1	
FR .	T97-174-063(AB) 97-109-061(AB)R1 97-174-063(AB)	PILOTS/COPILOTS DOOR HINGE TENON	RPLC97-109-061(B)	
FR FR	97-109-061(AB)R1 97-174-063(AB)	MAIN ROIDE HEAD BLADE HURN EYE BULIS	01-00-52R1	
FR	97-202-062(AB)	SINGLE DOLE CIRCULI BREAKERS	01-00-49	
FR	97-288-065(AB)	REDUCING POWER TO ENGINE FOLLOWING OVSP/SURV LIGHT	TELEX 01.00.44	
FR	97-292-064(AB)	MRB LEADING EDGE SS PROTECTIVE STRIPS	05.00.43	
FR	97-322-067(A)R1	T.G.B CHECKING FOR ANGULAR PLAY	05-00-44	
FR	1998-318-071(A)R2		SBT 01.00.56_R1	
FR	98-254-070(A)	ELECTRICAL CONNECTION MODULES HORIZONTAL STABILIZER SPAR TUBE	01.00.51 01.00.57 R1	
FR FR	1999-039-073(A)R1 1999-257-074(A)	ENGINE TO MGB COUPLING	63.00.58	
AS 332C (AS 332 SERIES)				
FR	1998-155-069(A)R1	DE ICED TAIL ROTOR BLADES - ROTATING COLLECTOR	05.00.45R1	
FR	1998-201-068(A)R2	ICE FORMATION ON MULTI PURPOSE AIR INTAKES	01.00.54 ST 01.00.58	
FR	1998-487-072(A)R1	HOIST ARM FITTING BOLTS	ST 01.00.58	
AS 332	L (AS	332 SERIES )		
FR	1998-155-069(A)R1	DE ICED TAIL ROTOR BLADES - ROTATING COLLECTOR	05.00.45R1	
FR	1998-201-068(A)R2	ICE FORMATION ON MULTI PURPOSE AIR INTAKES	01.00.54	
ATROPAFT / AFRONFES 20 JANUARY / JANUARY 2000				

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

			BULLETIN DE SERVICE DE REF.
AFROSP	ATIALE		
AS 33		222 CERYEC )	
	NUED / SUITE)	332 SERIES )	
FR	1998-487-072(A)R1		
1	1990-407-072(A)R1	HOIST ARM FITTING BOLTS	ST 01.00.58
CA 24	4.0		
SA 34 CF	0F 00 4F		
FR	CF-98-15	EXTERNAL RESCUE SYSTEMS	CAR 702.21
	72-126-001(B)	MAIN GLANDON COWLINGS	01-01
FR	73-036-003(B)	PRELOADING OF SWASHPLATE BEARING	05-04
FR	73-037-002(B)	TAIL SERVO JACK	67-01
FR	73-047-004(B)	FORWARD / REAR MGB "A" FRAME	01-02
FR	73-072-005(B)	FUEL SYSTEM SUMP	28-01
FR	73-095-006(B)	SERVICE LIFE LIMITS	
FR	73-127-007(B)	FUEL FILTER ELEMENT	28-02
FR	73-128-008(B)	MAIN GEARBOX FORWARD "A" FRAME	01-02
FR	74-012-009(B)	AIR DEFLECTOR FUEL TANK VENT	53-02
FR	75-039-012(B)	MAIN GEARBOX	05-10
FR	75-040-011(B)R1	OIL PUMP / HYDRAULIC UNIT DRIVE GEAR MAIN ROTOR HUB	05-09
FR	75-052-013(B)	MAIN ROTOR HUB	65-10
FR	75-204-016(B)R1	TAIL ROTOR DRIVE SHAFT	05-07R3
FR	76-227-017(B)	LANDING GEAR	01-10
FR	77-032-018(B)	FRONT / REAR LEGS - RIGID TYPE LANDING GEAR	05-15
FR	77-200-020(B)	FREEWHEEL UNIT	
FR	77-204-019(B)	TELEC NOTSE FILTERS	()1-19
FR	78-138-022(B)	PYROMECA CARTRIDGES - EMERGENCY FLOTATION GFAR	01-17
FR	79-073-025(B)	PYROMECA CARTRIDGES - EMERGENCY FLOTATION GEAR BOLT - NON-ROTATING SCISSORS / CONICAL HOUSING	01-18
FR	79-250-026(B)	ATTACHMENT BOLTS - MGB "A" FRAME	01-16R1
FR	80-060-027(B)	ATTACHMENT BOLTS - MGB "A" FRAME MGB - INPUT PINION FLANGE / SLOT NUT	65-19
FR	80-061-028(A)R2	NITROGEN CYLINDER HEAD - EMERGENCY FLOTATION GEAR	05-19R3
FR	80-098-029(B)	LANDING GEAR LEG	05-18R1
FR	82-062-030(B)	FREEWHEEL FLANGE BEARING	05 00
FR	82-100-031(B)	TAIL GEARBOX UPPER ATTACH LUGS	65-22
FR	82-183-032(B)	MGB - SLOTTED NUT / BEVEL GEAR	65-24R1
FR	83-074-033(B)	LANDING GEAR REAR TIE BAR	32-02
FR	88-167-034(B)	TAIL GEARBOX UPPER ATTACH LUGS MGB - SLOTTED NUT / BEVEL GEAR LANDING GEAR REAR TIE BAR LOW FREQUENCY LOW LANDING GEAR LUCAS AIR FOULDT HOIST	05 24
FR	91-203-035(B)	LUCAS AIR EQUIPT HOIST	25 05
FR	92-011-036(B)R1	INTERMEDIATE GEARBOX ATTACHMENT LUG	65.43R1
FR	94-194-037(B)	SERVOCONTROL SETTINGS	SB 05-31
FR	97-144-038(B)	LUCAS AIR EQUIPT HOIST INTERMEDIATE GEARBOX ATTACHMENT LUG SERVOCONTROL SETTINGS TGB SUPPORT TRIPOD MAIN ROTOR HEAD PITCH-CHANGE ROD	05-32
FR	1998-551-039(A)	MAIN ROTOR HEAD PITCH-CHANGE ROD	TELEX INFO 00079
AS 350	SERIES		
CF	CF-82-02	IMPELLER AND FUEL PUMP COVER FREEZING - MAIN SERVO CONTROL VALVE FUSELAGE/TAILBOOM JUNCTION FRAME EXTERNAL RESCUE SYSTEMS	391-28-81 SL
CF	CF-84-11	FREEZING - MAIN SERVO CONTROL VALVE	67.05
CF	CF-93-12R1 CF-98-15	FUSELAGE/TAILBOOM JUNCTION FRAME	05.16
CF	CF-98-15	EXTERNAL RESCUE SYSTEMS	CAR 702.21
FR	78-193-001(B)R1		05-01
FR	78-204-002(B)	MAIN ROTOR SHAFT ASSEMBLY	65-01
FR	78-227-003(B)R1	ENGINE/MGB HOUSING - RETIREMENT OF RETIREMENT LIFE	5-99 R7 MSR
FR	79-012-004(B)	REAR TRANSMISSION BOX ANCHOR SCREWS	65-07
FR	79-013-005(B)	REAR TRANSMISSION BOX ANCHOR SCREWS ROTOR CONTROL YAW CHAIN	67-01
FR	79-104-006(B)	MAIN ROTOR HEAD	
FR	79-133-007(B)	LEFT HAND LATERAL BAGGAGE HOLD DOOR	52-04
FR	79-134-008(B)		01-03
FR	79-174-009(B)		
FR	79-217-011(B)	TAIL ROTOR	65-13
FR	80-104-013(B)		65-18
FR	80-184-015(B)R1	BOLTS - HUB TO MAIN ROTOR SHAFT	05-04R1
FR	81-067-016(B)		25-29
FR	81-084-017(B)	ENGINE - MAIN GEARBOX JUNCTION	01-06
FR	81-094-018(B)R2	MAIN GEAR BOX	05-06R2
FR	81-184-020(B)	TAIL ROTOR PITCH CHANGE HORN	01-07R2
FR	81-203-021(B)	UPPER / LOWER FINS	05-07,55-02
FR	81-223-022(B)	LOWER FIN	55-02
FR	82-023-023(B)	FUEL FILTER	01-08
FR	82-024-024(B)	TAIL ROTOR BLADES LEADING EDGES	
FR	82-077-025(A)R5	SUPERCEDED BY 98-173-073(A)	
FR	82-098-026(B)	UPPER FIN ATTACHMENT FITTING	05-09
FR	82-158-027(B)	FUEL FILTER BY-PASS	28-05
FR	82-175-029(B)	MAIN GEARBOX	05-12
FR	83-075-033(B)	TAIL ROTOR LEADING EDGES	01-10
FR	83-173-036(B)	MAIN ROTOR MAST SHAFT	05-13R1
FR	84-064-037(B)R3	TAIL ROTOR BLADE SPARS	05-11R5
FR	85-068-038(B)	MAIN GEARBOX BEVEL REDUCTION GEAR MODULE	05-10R1
FR	85-095-040(B)	MAIN ROTOR SHAFT	05-15

MAKE / CONSTRUCTEUR

MODEL / MODELE (SERIES / SERIE)

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.		
AEROSPA	ATIALE				
	SERIES				
	UED / SUITE)				
FR	85-112-041(B)	FUEL FILTER DRAIN PIPE FUEL FILTER / MAIN GEARBOX FILTERING CARTRIDGES	28-06R1		
FR	85-135-042(B)	FUEL FILTER / MAIN GEARBOX FILTERING CARTRIDGES	O1-14A		
	86-030-043(B)	EMERGENCY FLOTATION GEAR	32-06A		
	/- /- /- /- /- /- /- /- /- /-	MAIN ROTOR HEAD - ROVING SLEEVE BEAMS			
FR	86-077-046(B)R2	FUEL FILTER DRAIN FUEL FILTER FUEL FILTER HELICOPTER GROUND PERFORMANCE	28-07		
FR	86-097-047(B)	FUEL FILTER	28-08		
FR	86-125-048(B)R1	HELICOPTER GROUND PERFORMANCE	O1-17A		
FR	87-088-049(B)	HELICOPIER GROUND PERFORMANCE SLIDING DOORS FLIGHT CYCLE CALCULATION SPHERICAL THRUST BEARING BOLTS DUNLOP SERVOCONTROLS SPHERICAL THRUST BEARINGS	52-18		
FR	87-115-050(B)	FLIGHT CYCLE CALCULATION	01-09		
FR	87-161-051(B)	FLIGHT CYCLE CALCULATION SPHERICAL THRUST BEARING BOLTS DUNLOP SERVOCONTROLS	01-20		
FR	88-184-052(B)R1	DUNLOP SERVOCONTROLS	01-21R1		
FR	89-081-053(B)	SPHERICAL THRUST BEARINGS	01-23		
FR	89-155-054(B)R4	SPHERICAL THRUST BEARINGS SWASHPLATE BEARING RATTEDY TEMPERATURE PROBE	62-12R2		
FR	90-198-056(B)R1	RATTERY TEMPERATURE PROBE	01 29		
FR	91-125(AR)	ELECTRICAL BONDING -LUCAS AIR FOULD HOIST	25.42		
FR	91-127-050(R)	T R PITCH CONTROL LEVER EXPANSION PIN-AARDG 91 13	01 33		
FR	91-159-060(B)	TAIL ROTOR DRIVESHAFT BEARINGS	01.34		
FR	91-165-059(P)P1	FIECTRIC HOIST INSTALLATION	25.42R1		
FR	92-144-061(B)	T R PITCH CONTROL LEVER EXPANSION PIN-AARDG 91 13 TAIL ROTOR DRIVESHAFT BEARINGS ELECTRIC HOIST INSTALLATION "JOLLIET" ELT ANTENNA	25 45		
FR	92-145-061(B)	HVDDAIII TO SVSTEM	01 36		
FR FR	92-179-062(B)	MAIN POTOR DITCH CHANGE HORN DUCHES	62 21		
FR	92-179-064(B)K1	MAIN DOTOR MACT ACCEMBLY	01-41		
FR FR	93-030-065(B)	HYDRAULIC SYSTEM MAIN ROTOR PITCH CHANGE HORN BUSHES MAIN ROTOR MAST ASSEMBLY DOOR "CLEAR VISION" WINDOW MGB OIL PRESSURE SWITCH	05-25D1		
FR	93-090-067(B)R1	MCD CIT DDCCCUDE CHITCH	CEDVICE TELEVIOL 40		
FR	94-087-068(B)	MGB OIL PRESSURE SWITCH CYCLIC PITCH CHANGE CONTROL ROD TIMKEN MAIN ROTOR SHAFTS 355A37-0000 ALL DASH #'S MGB SUSPENSION BI-DIRECTIONAL CROSS BEAM	SERVICE TELEX 01-43		
FR	94-180-069(B)	CYCLIC PITCH CHANGE CONTROL ROD	01-42		
FR	94-279-070(B)R1	TIMKEN MAIN ROTOR SHAFTS 355A37-0000 ALL DASH #'S	TELEX 01-44		
FR	96-156-071(B)R1	MGB SUSPENSION BI-DIRECTIONAL CROSS BEAM	05.00.28		
FR	97-147-072(AB)	TAIL BOOM ATTACHMENT BOLTS TAIL ROTOR DRIVE SHAFT BRGS. CANCELS 82-077-025(B) SINGLE-POLE CIRCUIT BREAKER	01.00.46		
FR	98-173-073(A)	TAIL ROTOR DRIVE SHAFT BRGS. CANCELS 82-077-025(B)	05.00.08R5		
FR	98-511-074(A)	SINGLE-POLE CIRCUIT BREAKER	01.00.47		
FR	1999-085-076(A)R2	TAIL ROTOR HUB PITCH CHANGE PLATE BEARING	05.00.29 R2		
AS 350	)B ( A:	S 350 SERIES )			
CF	CF-85-02	AIR CRUISER FLOTATION KIT	350.18		
CF	CF-90-07R2	FREE WHEEL CREEPING			
CF	CF-92-01	FREEWHEEL UNIT (SUPERSEDES FR 91-156(B)R1)	ARRIEL 292 72 0146		
FR	79-210-010(B)	ENGINE REDUCTION GEAR MAGNETIC PLUG	01-04		
FR	79-254-012(B)	AIR CRUISER FLOTATION KIT FREE WHEEL CREEPING FREEWHEEL UNIT (SUPERSEDES FR 91-156(B)R1) ENGINE REDUCTION GEAR MAGNETIC PLUG MAGNETIC PLUG WARNING SYSTEM MAGNETIC PLUG OPERATING INSTRUCTIONS FLIGHT IN FALLING SNOW	77-02		
FR	80-165-014(B)	MAGNETIC PLUG OPERATING INSTRUCTIONS	77-02		
FR	93-067-066(B)	FLIGHT IN FALLING SNOW			
AS 350	BA (AS	S 350 SERIES )			
FR	93-067-066(B)	FLIGHT IN FALLING SNOW			
AS 350	B1 (AS	S 350 SERIES )			
CF	CF-90-07R2	FREE WHEEL CREEPING			
CF	CF-92-01	FREE WHEEL CREEPING FREEWHEEL UNIT (SUPERSEDES FR 91-156(B)R1)	ARRIEL 292 72 0146		
FR	92-159-063(B)R2	ENGINE BAY FIRE DETECTION	TELEX 01.38 SB 26-01		
FR	93-067-066(B)	FLIGHT IN FALLING SNOW			
CF CF-92-01 FREEWHEEL URLIT (SUPERSEDES FR 91-156(B)R1) ARRIEL 292 72 0146 FR 92-159-063(B)R2 ENGINE BAY FIRE DETECTION TELEX 01.38 SB 26-01 FR 93-067-066(B) FLIGHT IN FALLING SNOW					
AS 350B2 ( AS 350 SERIES )					
CF	CF-92-01	FREEWHEEL UNIT (SUPERSEDES FR 91-156(B)R1)	ARRIEL 292 72 0146		
FR	92-159-063(B)R2	ENGINE BAY FIRE DETECTION	TELEX 01.38 SB 26-01		
FR	93-067-066(B)	FREEWHEEL UNIT (SUPERSEDES FR 91-156(B)R1) ENGINE BAY FIRE DETECTION FLIGHT IN FALLING SNOW	000 00 20 01		
AS 350	B3 ( AS	350 SERIES )			
FR	1999-017-075(A)	CLIMBING SPEED CURVES			
FR	1999-512-077(A)	NR INDICATOR - LIGHTING	33.00.17		
1 ^	1333 312 0//(A)	IN INDICATOR CIGHTING	55.00.17		
AS 350	OD ( AG	350 SERIES )			
CF	CF-85-02		350.18		
OF.	0, 03-02	AIR CRUISER FLOTATION KIT	550.10		
AS SEE	SERIES				
CF		ENGINE ELAMEQUIC	80.02		
CF	CF-87-01R3	ENGINE FLAMEOUTS			
CF	CF-93-12R1	FUSELAGE/TAILBOOM JUNCTION FRAME	05.16		
	CF-98-15	EXTERNAL RESCUE SYSTEMS	CAR 702.21		
FR	81-183-001(B)	TAIL ROTOR PITCH CHANGE HORN	01-01		
FR	81-204-002(B)	UPPER / LOWER FINS	05-01,55-01		
FR	81-224-003(B)	ENGINES - UNDER SUPPORTS	01-03		
FR	82-025-004(B)	LEADING EDGES - STAINLESS STEEL PROTECTIONS	05 00 00 05		
FR	82-078-005(A)R5	TAIL ROTOR DRIVE SHAFT BEARINGS	05.00.02 R5		
	AFT (AFDONESS				

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE		SUJET	REFERÊNCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
AEROSPA	ATTALE			
	SERIES			
	UED / SUITE)			
FR	82-099-006(B)		UPPER FIN ATTACHMENT FITTING	OF 02
FR	82-157-007(B)		EIDEMALL TICHTMECC	05-03 71-04
FR	82-180-009(B)		MAIN GEARBOX - OIL MONITORING	05-07 63-02
FR			TAIL ROTOR - LEADING EDGES	01-06
FR FR	83-115-015(B) 83-166-018(B)		HURIZUNIAL STABILIZER	05-10
FR	83-174-020(B)		PLANET PINION CAGE	01-07R2
	84-017-021(B)		MAIN ROTOR MAST SHAFT HORIZONTAL STABILIZER	05-08R1
FR	84-045-022(B)R4			01-01
FR	84-081-023(B)		TAIL ROTOR BLADE SPARS MAIN GEARBOX LUBRIFICATION SYSTEM	355-05-06 R6 71-03
FR	85-069-024(B)		BEVEL REDUCTION GEAR MODULE	05-05
FR	85-094-025(B)		MAIN ROTOR SHAFT	05-13
FR	86-006-026(B)		FIRE PROTECTION SYSTEM	26-01
FR	86-032-027(B)		EMERGENCY FLOTATION GEAR	32-04A
FR FR	86-035-028(B)R1		MAIN ROTOR HEAD - ROVING SLEEVE BEAM HELICOPTER GROUND PERFORMANCE	01-13
FR	86-126-029(B) 86-150-030(B)		HYDRAULIC SYSTEM	01-14A
FR	87-038-032(B)		MAIN GEARBOX SUSPENSION BARS	29-01
FR	87-089-033(B)		SLIDING DOORS	05-16 52-10
FR	87-116-034(B)		FLIGHT CYCLE CALCULATION	01-17
FR	87-160-035(B)		SPHERICAL THRUST BEARING BOLTS	01-19
FR	88-057-036(B)R2		FLIGHT CYCLE CALCULATION SPHERICAL THRUST BEARING BOLTS MGB OIL COOLING FAN	05-20R2
FR	88-183-037(B)R1		DUNLOP SERVOCONTROLS	01-21R1
FR	89-156-039(B)R3		SWASHPLATE BEARING	62-16R2
FR	90-061-040(B)		FUEL LINES	01-28
FR FR	90-199-041(B)R1 91-125(AB)		BATTERY TEMPERATURE PROBE ELECT. BONDING-LUCAS AIR EQUIP. HOIST	01.32
FR	91-138-043(B)		T R PITCH CONTROL LEVER EXPANSION PIN- AARDG91 14	25.30
FR	91-158-044(B)		TAIL ROTOR DRIVESHAFT BEARINGS	01.35
FR	91-164-042(B)		ELECTRIC HOIST INSTALLATION	25.30
FR	92-142-045(B)		"JOLLIET" ELT ANTENNA	25.33
FR	92-183-046(B)R1		MAIN ROTOR PITCH CHANGE HORN BUSHES	62.24
FR	93-031-047(B)		MAIN ROTOR MAST ASSEMBLY	01-37
FR	93-089-048(B)R1		DOOR "CLEAR VISION" WINDOW	05-26R1
FR FR	93-137-049(B)		ENGINE FIRE DETECTION	26-03 AND 26-04
FR	94-088-050(B) 94-179-051(B)		MAIN ROTOR MAST ASSEMBLY DOOR "CLEAR VISION" WINDOW ENGINE FIRE DETECTION MGB DIL PRESSURE SWITCH CYCLIC PITCH CHANGE CONTROL ROD	O1-28
FR	94-280-052(B)R1		TIMEEN MAIN POIDS SHAFTS 355A37-0000 ALL DASH #75	1 E I E X () 1 = 2/1
FR	96-155-053(B)R1		MGB SUSPENSION BI-DIRECTIONAL CROSS BEAM	05.00.29
FR	97-146-054(AB)		MGB SUSPENSION BI-DIRECTIONAL CROSS BEAM TAIL BOOM ATTACHMENT SCREWS	01.00.43
FR	98-510-055(A)		SINGLE-POLE CIRCUIT BREAKER	01.00.44
FR	1999-083-056(A)		P2 SYSTEM - 3 WAY COUPLING	
FR	1999-084-057(A)R	2	TAIL ROTOR HUB PITCH-CHANGE PLATE BEARING	05.00.30 R2
AS 355	E (	AS	355 SERIES )	
CF CF	CF-84-12	~~	FREEZING - MAIN SERVO CONTROL VALVE	67.01
FR	89-082-038(B)		SPHERICAL THRUST BEARINGS	01-25
AS 355	F (	AS	355 SERIES )	
CF	CF-86-06		MAIN ROTOR SERVO JACKS	67.07
AS 355	F1 (	AS	355 SERIES )	67.07
CF	CF-86-06		MAIN ROTOR SERVO JACKS	67.07
A\$ 355	F2 (	AS	355 SERIES )	
A5 355	r2 (	AS	333 SERIES /	
AEROST A	R			
RX6				
	75-19-04		VALVE SYSTEM	
	76-03-04		GONDOLA LINER	
US	81-21-02R1		HOOK AND PILE FASTENER TAPE FUEL SUPPLY HOSE ASSEMBLIES	120
US	86-10-11R1		ADVANCED FIBER TECHNOLOGY SUSPENSION CABLES	129
US	90-25-09		MOVARIOLD   IDEN   FORMOLOGY   3031 EN31011 OADLES	
RX7 SE	DIFC	,		
	86-10-11R1		FUEL SUPPLY HOSE ASSEMBLIES	120
US	90-25-09		ADVANCED FIBER TECHNOLOGY SUSPENSION CABLES	129
US	93-16-13		AEROQUIP FUEL LINE LEAKS	132
***************************************				
RX7	,	RX7	SERIES )	
US	81-21-02R1		HOOK AND PILE FASTENER TAPE	

	AD NUMBER NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.			
AEROSTA						
RX8	93-16-13	AEROQUIP FUEL LINE LEAKS	132			
RXS 8						
<b>S49A</b> US	93-16-13	AEROQUIP FUEL LINE LEAKS	132			
S52A						
\$55A S US US US	ERIES 86-10-11R1 90-25-09 93-16-13	FUEL SUPPLY HOSE ASSEMBLIES ADVANCED FIBER TECHNOLOGY SUSPENSION CABLES AEROQUIP FUEL LINE LEAKS	120 129 132			
<b>S55A</b> US US US	75-19-04 80-01-03 81-21-02R1	( S55A SERIES )  VALVE SYSTEM  PARACHUTE TOP RELEASE  HOOK AND PILE FASTENER TAPE				
US	86-10-11R1 90-25-09 93-16-13	FUEL SUPPLY HOSE ASSEMBLIES ADVANCED FIBER TECHNOLOGY SUSPENSION CABLES AEROQUIP FUEL LINE LEAKS	120 129 132			
US	ERIES 86-10-11R1 90-25-09 93-16-13	FUEL SUPPLY HOSE ASSEMBLIES ADVANCED FIBER TECHNOLOGY SUSPENSION CABLES AEROQUIP FUEL LINE LEAKS	120 129 132			
US	75-19-04 80-01-03 81-21-02R1	( S60A SERIES ) VALVE SYSTEM PARACHUTE TOP RELEASE HOOK AND PILE FASTENER TAPE				
US	81-21-02R1 86-10-11R1 90-25-09	HOOK AND PILE FASTENER TAPE FUEL SUPPLY HOSE ASSEMBLIES ADVANCED FIBER TECHNOLOGY SUSPENSION CABLES	120 129			
<b>S71A</b> US	93-16-13	AEROQUIP FUEL LINE LEAKS	132			
	86-10-11R1 90-25-09	FUELSUPPLY HOSE ASSEMBLIES ADVANCED FIBER TECHNOLOGY SUSPENSION CABLES	120 129			
90C						
<b>110P</b> US	93-16-13	AEROQUIP FUEL LINE LEAKS	132			
AEROTECH	NIK EH VIVAT					
CK CK CK	MIIIA-011A 1-002/96 4-099/98	TORQUE ON ROCKER ARM COVER NUTS AIRBRAKE CONTROL CABLE ELEVATOR DRIVE COLOUR MARKING	MIIIA-011A 13-044A SEH13-003A			
AIR TRAC	T-112/1999R1 CTOR	TAIL/FUSELAGE ATTACHMENT FITTINGS	SEH 13-005A			
	96-24-08 98-25-01	PARKING BRAKE VALVE FLAP AND AILERON PUSHROD INTERFERENCE	SL 76 SL 140			
US US US US US	82-06-12 83-18-01 92-07-14 96-24-08 97-14-05 98-25-01	MAIN LANDING GEAR STRUTS FUSELAGE ATTACH FITTINGS WING SPAR CAPS PARKING BRAKE VALVE INSPECTION OF VERTICAL FIN FLAP AND AILERON PUSHROD INTERFERENCE	SL45 SL47 SL 90 SL 76 SL 138 SL 140			
<b>AT 401</b> US	96-24-08	PARKING BRAKE VALVE	SL 76			

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT SUJET REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			BULLETIN DE SERVICE DE REF.
AIR TR	ACTOR		
AT 40	1		
US US	NUED / SUITE) 97-14-05	INSPECTION OF VERTICAL FIN FLAP AND AILERON PUSHROD INTERFERENCE	
US	98-25-01	FLAP AND ATLEBON PHISHED INTERESPENCE	SL 138
		TEN AND ATELKON POSHROD INTERPERENCE	SL 140
AT 40			
US	98-25-01	FLAP AND AILERON PUSHROD INTERFERENCE	SL 140
AT 402	24		
		FLAP AND AILERON PUSHROD INTERFERENCE	SI 140
		THE	
AT 502			
US	98-25-01	FLAP AND AILERON PUSHROD INTERFERENCE	SL 140
AT 802	2		
US	96-04-08	REPLACEMENT OF MAIN LANDING GEAR LEGS	SL 104A
US	97-04-11	TAIL LANDING GEAR SPRING	
AIRBUS			
	SERIES		
FR	77-126(B)	FLIGHT DECK & PASSENGER CABIN FLOORS	
FR	1984-140-064(B)R3	FUSELAGE INSP. FOR BULGING AND DEBONDING	A300.53.148
FR	1986-187-076(B)R4	NO. 2 FLAP TRACKS	A300.57.141R7
FR FR	89-063(AB) 1990-222-116(B)R5	SAMM SWITCHES - CRIMPING AGING STRUCTURE INSPECTION PROGRAM	SEVERAL
	92-113(B)R1	FIRE SUPPRESSION-CLASS & CARGO HOLD	
FR	1997-006-210(B)R1	WING ROOT BOTTOM SKIN CORROSION	A300.57.204
FR	97-236(IMP)	FWD AND AFT CARGO DOOR HOOKS	A300, EB52, 004
FR	1998-122-244(B)R1	SLIDE AND SLIDE RAFTS REGULATOR VALVE	A300.25.464
FR FR	1998-151-247(B)R2 1998-263-255(B)R3	MLG ATTACH FITTING AT RIB 5 ALTERNATE BRAKING SYSTEM CHECK	A300.57A0234 R2
FR	1998-449-265(B)R1	WING BOXES REAR HINGE FITTINGS	AOT 32-19R2 A300.57.142, 143
FR	98-121-243(B)	SLIDE BAFTS DEPLOYMENT SYSTEM	A300 25 465
FR	98-447-264(B)	PITCH ARTIFICIAL FEEL UNIT	A300-27-184
FR	98-448-262(B)	RAM AIR TURBINES	A300-29-0106
FR FR	98-480-269(B)	APU - FUEL FEEDLINE	A300-49-0049R1
FR	98-481-270(B) 1999-006-263(B)	FUSELAGE - AFT FITTING OF FRAME FR40 RAM AIR TURBINE UPLOCK UNIT	A300-53-6048 A399-29-0109
FR	1999-049-268(B)	INSPECTION OF LONGITUDINAL LAP JOINTS	A300-53-0216
FR	1999-076-267(B)	WING CENTER BOX	A300-53-0298 R3
FR	1999-209-281(B)	FUSELAGE SKIN CORROSION	A300-53-0328
FR	1999-240-288(B)R1	RUDDER SERVO SPRINGS ERRATIC RUDDER MOVEMENT DURING APPROACH	AOT A300-22A0114
FR FR	1999-268-292(B) 1999-284-290(B)	LANDING GEAR - BRAKE BAR FITTINGS	A300-32-0430
FR	1999-404-293(B)	OUTER TANKS-HIGH LEVEL SENSOR	A300-28-0077
FR	1999-410-294(B)R1	INSP - STRIKER MECHANISM DOOR EMERGENCY ACTUATORS	
FR	1999-435-296(B)	DC ELECTRICAL POWER TR UNITS	A300-24-0089 DR REV
FR FR	1999-511-297(B)	SEAT - ARTICULATED AND DUMMY TRACKS FUSELAGE-FR47 SPLICE FITTING (ATA 50)	A300.53.188, 329 ADT A300-53A0350
FR	1999-515-298(B)	FUSELAGE-LONGITUDINAL SKIN SPLICE	AOT A300-53A0352
FR	2000-007-301(B)	PITCH TRIM	ADT A300-22A0115
A300B4	203 ( A	300 SERIES ) ENGINE PYLON PIPING	A300.51.006
FR FR	75-179-001(B)	ENGINE PYLON FUEL & HYDRAULICS	A300.54.007
FR	77-037-008(B)	ENGINE PYLON FUEL & HYDRAULICS UNIVERSAL JOINT BOLTS WING BOTTOM DOUBLER ALIXIL LADY POWER UNIT	
FR	77-038-009(B)	WING BOTTOM DOUBLER	A300.57.009
FR	//-164-UTT(D)	AOXILIANI I OWEN ONLI	A300.57.053
FR	77-167-012(B)	AIRBRAKES 1 & 2 MLG SHOCK STRUT	A300.57.053 A300.32.033, 32.148
FR FR	78-174-014(B) 78-210-015(B)R1	LEADING EDGE FLAP GAP SEALS	A300.57.063R2
FR	79-105-016(B)R1	CARGO DOOR FRAME	A300.53.108
FR	79-125-018(B)	KEEL BEAM INSPECTION	A300.53.096, 53.079
FR	80-068-022(B)R1	HORIZONTAL STABILIZER	A300.55.017, 55.022 A300.55.006
FR	80-069-023(B)R1	HORIZONTAL STABILIZER MLG ACTUATOR ARM	A300.32.287
FR FR	80-079-024(B) 80-116-025(B)	POWERPLANTS WITH SHORT EXHAUST PIPE	
FR	80-151-027(B)	BRAKE PEDAL POSITION TRANSMITTER SUPPORT	A300.32.264, 32.267
FR	80-218-028(B)R2	REAR PRESSURE BULKHEAD	A300.53.152R4
FR	80-219-029(B)	PITOT HEAT ELECTRICAL CIRCUIT	A300.30.026 A300.22.025
FR	80-222-030(B)	ELEVATOR TRIM MLG ACTUATOR ROD	4000.22.020
FR FR	81-042-032(B)R1 81-058-033(B)	APU ELECTRICAL GENERATION	A300.24.028, 24.050
FR	81-081-035(B)	BRAKING SYSTEM TITEFLEX PLUMBING	A300.32.310

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

AIRBUS	000 ( 400	o Series )	
	203 ( A30 ED / SUITE)		
	81-085-036(B)	HORIZONTAL STABILIZER LUCAS ACTUATOR	A300.27.132
1	81-155-038(B)	ENGINE FILON FOLL FLONDING	A300.28.039
	81-174-041(B)	MLG SWIVEL LINK FRONT CARGO COMPARTMENT FIRE SAFETY LANDING GEAR MODIFICATION	MHB 470.32.386
	82-022-044(B)	FRONT CARGO COMPARTMENT FIRE SAFETY	A300.25.332
	82-086-047(B)		
	82-160-049(B)R1	MLG HINGE ARM	SEVERAL A300.32.348, 352,355
	83-051-050(B)R1 83-052-051(B)	MIC LITALICE	A300 32 365
	83-052-051(B)	APU FIRE EXTINGUISHER SYSTEM STRUCTURAL INSPECTION AND MODIFICATIONS	AOT /26/83/02
	83-102-053(B)R2	STRUCTURAL INSPECTION AND MODIFICATIONS	SEVERAL
	00_4/7_AEE(D)	ELAD ACTUATION RELICIONNICS	AROO 27 159
	83-148-056(B)	LEADING EDGE FLAP BELLCRANKS	A300.27.151
FR	84-007-058(B)R1	SUPERSEDED BY 89-109-097(B)	CANCELLED
FR	84-007-058(B)R1 84-066-061(B)R2 85-152-069(B) 85-153-070(B)R1	FLAP BALL SCREWJACK	A.300~27-172
FR	85-152-069(B)	FLAP BALL SCREWACK FUSELAGE FRAME NO.47 - ATTACHMENTS SUPERSEDED BY 89-109-097(B)	A300.53.200
FR FR	85-153-070(B)R1	SUPERSEDED BY 89-109-097(B)	4300 73 007
FR	86-072-072(R)	NOSE GEAD STOLLT ATTACH DIN	A300.32.374, 2023
FR	86-165-075(B)	REAR PRESSURE BULKHEAD INSPECTION	A300.53.213
FR	87-019-077(B)R1	FUEL FLOWMETER PLUMBING NOSE GEAR STRUT ATTACH PIN REAR PRESSURE BULKHEAD INSPECTION FUSELAGE LONGITUDINAL LAP JOINTS	A300.53.206
FR	87-100-080(B)	NOSE GEAR BARREL	A30032.382, 6019
FR	87-121-081(B)	FLAP TRACKS NO. 2 TO 6	A300.57.150, 6013
FR	87-132-082(B)R2	SECONDARY LATCHING SYSTEM / ENGINE CORE COWL DOORS	A300-071-053R1
FR	88-060-085(B)	VICKER HYDRAULIC PUMPS	
	88-061-083(B)	REAR PASSENGER DOOR	A300-53-221
	88-142-087(B)	MAIN LANDING GEAR BARREL HINGE ARMS NOSE LANDING GEAR BARREL	A300-32-118
FR FR	88-143-088(B) 88-181-089(B)R1	METALIZING OF FIRE EXTINGUISHER CARTRIGES	A300-32-388
FR	88-185-090(B)R3	SUPPOSEDED BY MAINT MANUAL DEVISION	CANCELLED
	1989-061-092(B)R4		A300-53-211R5
	89-040-091(B)R1	MAIN LANDING GEAR	
FR	89-068-093(B)R1	MAIN LANDING GEAR REAR PRESSURE BULKHEAD DOORS - EMERG ACTUATOR DAMPER STOPS EMERGENCY LIGHTING	A300.53.217, 218
	89-092-095(B)	DOORS - EMERG. ACTUATOR DAMPER STOPS	A300.52.130
	89-107-096(B)R4	EMERGENCY LIGHTING	A300.33.117, 119
FR	89-109-097(B)R7	SUPP STRUCTURAL INSPECTION PROGRAM HORIZONTAL STABILIZER TOP SKINS	SEVERAL
FR	89-157-099(B)	MUC BOCKE	A300.55.035
	90-005-101(B)R2 90-020-102(B)	MICH BUGIE	A300.32.394 A300.53.269, 270
	90-027-103(B)	MLG BOGIE HORIZONTAL STABILIZER ATTACH YOKE AIR CRUISER EMERGENCY EVACUATION SLIDES HYDRAULIC FIRE CUT-OUT VALVES	A300 25 430
		THE CONTRACTOR STATE OF THE CO	A300.29.096
	90-056-106(B)R1	ENGINE FIRE EXTINGUISHER PLUMBING	A300.26.055
	90-074-108(B)	EMERGENCY EVACUATION LIFERAFT SLIDES	A300.25.429
	90-093-110(B)R1	FUSELAGE MID-SECTION SKIN AT FRAME 30A	A300.53.283, 285
	90-149-115(B)	HYDRAULIC FIRE CUT-OUT VALVES ENGINE FIRE EXTINGUISHER PLUMBING EMERGENCY EVACUATION LIFERAFT SLIDES FUSELAGE MID-SECTION SKIN AT FRAME 30A LANDING GEAR BOGIE CORROSION PREVENTION AND CONTROL EVACUATION SLIDES - PIN LANYARD EVACUATION SLIDES - GIRT BAR	A300.32.394, 396
	90-196-117(B)	CORROSION PREVENTION AND CONTROL	A300 CPC PROGRAM
	90-215-119(B)	EVACUATION SLIDES - PIN LANYARD	A300.25.434
FR S	90-218-120(B) 91-103-123(B)R1	APIL FIFE FFED PLIMBING	A300 49 049 A0T49=01
FR 9	91-124-122(B)R3	EVACUATION SLIDES - PIN LANYARD  EVACUATION SLIDES - GIRT BAR  APU FUEL FEED PLUMBING  RAM AIR TURBINE DEPLOYMENT CABLE  DOOR FRAMES - CORROSION & FATIGUE  FUEL SHUT-OFF VALVE SELECTOR KNOB  ENGINE PYLON LOWER SPAR  ENGINE PYLON - ACCESS DOOR REINFORCEMENT	A300.29.097
	91-132-124(B)	DOOR FRAMES - CORROSION & FATIGUE	A300.53.204. 233
FR 9	91-173-126(B)R1	FUEL SHUT-OFF VALVE SELECTOR KNOB	A300.28.055, 061
	1992-049-130(B)R4	ENGINE PYLON LOWER SPAR	A300.54.071, 079
	92-082-131(B)	ENGINE PYLON - ACCESS DOOR REINFORCEMENT FLIGHT MANUAL REVISION	A300.54.0046, 0070
	92-156-133(B)	FLIGHT MANUAL REVISION	TREV 5.02.00/1
FR 9	92-21/-134(B)	HYDRAULIC FIRE SHUT-OFF VALVES 101 VU ELECTRONIC RACK LOWER ATTACHMENTS	ADT 29/07
FR 9	92-253-138(B)R1 92-274-140(B)R1	NLG-BOTTOM OF SHOCK ABSORBER REPL	4300.53.294, 300
	1993-228-154(B)R3	ENGINE PYLON LOWER SPAR	A300-54-6014R1
	93-032-142(B)	GENERATOR CONTROL UNIT - PROTECTIVE COVER	A300.24.0082
	93-063-145(B)R1	NOSE LANDING GEAR FREE FALL JAMMING	AOT 32-06
FR 9	93-074-144(B)	FUEL JETTISON PIPES - LIGHTNING PROTECTION	A300.28A.0065
	93-136-146(B)R4	DOWTY RAM AIR TURBINE - NON-ROTATION	A300.29.101,A0T29.08
	93-150-147(B)	AFT FUSELAGE LONGITUDINAL SKIN JOINTS	A300.53.211,A0T53.05
	93-154-149(B)	AGING STRUCTURE MODIFICATION PROGRAM	SEVERAL
	94-011-152(B) 94-104-160(B)R2	EVACUATION SLIDES COCKPIT SIDE WINDOWS	AOT 25-07
	94-185-165(B)R2	AUTOPILOT OVERRIDE PROTECTION	A300.56.008, A0T56-01 A300.22.112
	94-187-163(B)R1	CHAFING OF PANEL 101 VU ELECTRICAL BUNDLE	A300.24.086, 087
	34-10/-103(BIKI		
	94-187-163(B)R1	UNCOMMANDED THRUST REVERSER LEVER UNLOCK	A300.78.015
	94-205-166(B)R1 94-207-168(B)R1	UNCOMMANDED THRUST REVERSER LEVER UNLOCK WING REAR SPAR WEB BETWEEN RIBS 1-2	
FR 9	94-205-166(B)R1	UNCOMMANDED THRUST REVERSER LEVER UNLOCK	A300.78.015

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

	NOMENO DE CONTINUE	50321	BULLETIN DE SERVICE DE REF
AIRBUS			
		OO SERIES )	
	NUED / SUITE)	OO SERIES )	
FR	95-163-182(B)R4	DAM ATD THOUTHE HOLDER	
FR	95-163-182(B)R4 95-164-183(B)	RAM AIR TURBINE UPLOCK PIN	A300.29.108, 109
FR	95-182-184(B)	AUTOPILOT SERVO MOTORS - ADJUSTMENT APU - BLEED AIR PIPING	AOT 27-20
FR	95-185-187(B)R1	MODIFICATION TUDING	A300.36.033
FR	95-245-192(B)	MODIFICATION - THRUST REVERSER CONTROL	A300.78.015R2
FR	96-052-197(B)	FUSELAGE REAR PRESSURE BULKHEAD	A300.53.302
FR	96-135-199(B)R1	NLG FREE FALL EXTENSION MECHANISM	A300.32.418
FR	96-242-208(B)R2	AFT DOOR FRAMES - STRESS CORROSION	A300.53.303
FR	96-270-209(B)R1	RUDDER SERVO-CONTROL DESYNCHRONIZATION	A300.27.188, 55.044
FR	1997-124-223(B)R1	THROTTLE CONTROL LEVER BEARINGS	A300.76.018
FR		PASSENGER DOORS STOP FITTINGS	A300.53.309
FR	97-063-214(B)R1	FUSELAGE FORWARD CANTED FRAMES	A300.53.314
FR	97-080-211(B)R2 97-082-215(B)	INNER AIRBRAKES - CENTER HINGE FITTINGS	A300.57.229, 231
FR		MAIN FUEL SYSTEM-NON RETURN VALVES	A300.28.063, 071
FR	97-113-221(B)R2 97-151-224(B)R1	LANDING GEAR FREE FALL EXTENSION	A300.32.272,A0T32-14
		LAVATORIES - PRESSURE BETWEEN TOILET AND CABIN	A300.38.034
FR	97-176-229(B)	PRESSURIZED FLOOR PANEL RIVETS	A300.53.331
FR	97-357-231(B)	EMER. EXITS - FUSELAGE SKIN CORROSION	A300.53.301
FR	97-358-232(B)	ENGINE PYLON THRUST AND SIDELOAD FITTING	A300.57.232
FR	97-359-233(B)	CABIN STOWAGE BOX REINFORCED STRUTS	A300.25.395
FR	97-371-235(B)	FUSELAGE BONDED LONGITUDINAL LAP JOINTS	A300.53.148, 209
FR	97-372-236(B)	FUSELAGE - GANTRY LOWER FLANGE	AOT 53-11
FR	98-028-242(B)	FUSELAGE FRAME 40 - REAR FITTING AT STRINGER 27	A300.53.332
FR	98-123-245(B)	BULK CARGO COMPARTMENT DOOR FRAME	A300.53.109, 339
FR	98-150-246(B)	AFT FUSELAGE LONGITUDINAL SKIN JOINTS	A300.53.305, 306
FR	98-174-248(B)	FUEL TANKS BONDING LEADS	A300.28.072, 073
FR	98-356-259(B)	FIRE SHUT-OFF VALVES	MAINT MANUAL
FR	98-375-260(B)	OVERTORQUE OF ENGINE MOUNT BOLTS	ADT 71-07
FR	98-378-257(B)	CF6-50 ENGINE THRUST REVERSER SYSTEM	MRAS 78.3001R2
FR	1999-236-284(B)	INSP LONGITUDINAL LAP JOINTS	A300-53-0341
	0=====		
	SERIES		
CF	CF-90-18	LITTON LTN 90,LTN 90-100 INERTIAL REFERENCE UNIT	
CF	CF-91-17	LAVATORY FIRE EXTINGUISHERS - OPERATION	AOT 26-04
FR	85-030-066(B)	RETRACTION ACTUATOR	A310-32-2012
FR	85-033-067(B)R3	NO 2 FLAP SCREWJACK - SECONDARY LOAD DRIVE PATH	A310-27-2037
FR	85-111-068(B)R1	SUNDSTRAM RAM AIR TURBINE	A310-29-6006
FR	86-028-072(B)	EMERGENCY EXIT DOORS - OPENING MECHANISM	A310-52-2017
FR	86-072-073(B)	NOSE LANDING GEAR - STRUT ATTACHMENT PIN	A310-32-2023
FR	86-102-074(B)	REAR PRESSURE BULKHEAD - ATTACHMENT ANGLES	A310-53-2025
FR	87-100-080(B)	BARREL UPPER PART	A310-32-2036
FR	88-060-085(B)	VICKER HYDRAULIC PUMPS	1010 50 0000
FR	88-061-083(B)	REAR PASSENGER DOOR EMERGENCY EXITS - LOCKING MECHANISM NOSE LANDING GEAR BARREL	A310-53-2038
FR	88-073-084(B)	EMERGENCY EXITS - LOCKING MECHANISM	A310-52-2024
FR	88-143-088(B)	NOSE LANDING GEAR BARREL	A310-32-2040
FR	88-181-089(B)R1	ENGINE FIRE EXTINGUISHER	A310-26-2016
FR	89-063(AB)	SAMM SWITCHES - CRIMPING	
FR	89-092-095(B)	DOORS - DAMPER & EMERGENCY OPERATIONS CYLINDER	A310-52-2018
FR	89-107-096(B)R4	EMERGENCY LIGHTING SYSTEM	33-2014R1,-2015R5
FR	89-170-IMP(AB)R1	LITTON - INERTIAL REFERENCE UNITS LTN 90 & 90-100	
FR	90-005-101(B)R2	MAIN LANDING GEAR BOGIE BEAM	A310-32-2053, 2054
FR	90-042-107(B)	FIRE SHUT-OFF VALVE	A310-29-2025
FR	90-074-108(B)	BF GOODRICH ESCAPE SLIDE RAFT	A310-25-2049
FR	90-092-109(B)R3	FLAP TRANSMISSION SYSTEM - UNIVERSAL JOINT ASSYS	A310~27~2054 REV 2
FR	90-097-111(B)	INSPECT CABIN FLOOR STRUCTURE	A310-53-2056,-2013
FR	90-098-112(B)R1	RUDDER DISBONDING ,	A310-55-2010
FR	90-135-113(B)R1	EMERGENCY DXYGEN CONTAINERS	A310-35-2002 R2
FR	90-149-115(B)	MAIN LANDING GEAR BOGIE BEAM INSPECTION	A310-32-2053R1,-2054
FR	90-197-118(B)	GENERATOR CONROL UNIT	A310-24-2040
FR	90-215-119(B)	SLIDES AND SLIDE RAFTS PIN LANYARD	A310-25-2054
FR	90-218-120(B)	EVACUATION ESCAPE SLIDES POSITION OF GIRT BAR	AOT 25-01
FR	91-096-121(B)R2	FORWARD AND AFT ENGINE MOUNT LINKS ASSEMBLIES	A310-71-2011
FR	91-103-123(B)R1	APU - FUEL FEEDLINE	49-01 R3 ADT
FR	91-132-124(B)	DOOR SURROUNDINGS - CORROSION & FATIGUE INSP	A310-53-2030 R5
FR	91-148(AB)	ABEX ENGINE DRIVEN PUMPS P/N 65066-06 - INSP	
FR	91-155-125(B)	PILOT'S & CO-PILOT'S SEAT END STOP - ADJUSTMENT	SOGERMA 25-188
FR	91-234-127(B)R3	REAR ATTACHMENT MLG BARREL - VISUAL INSPECTION	AOT 32-04R1
FR	92-010-129(B)	SLAT/FLAP WING TIP BRAKE SOLENOID INSPECTION	A310-27-2042,2046 R1
FR	92-106-132(B)R5	STRUCTURE FATIGUE	53-2014,-2016 ETC
FR	92-106-132(B)N3	FLIGHT MANUAL - BRAKING PERFORMANCE LOSS	
FR	92-156-133(B) 92-217-134(B)	FIRE SHUT-OFF VALVES OPERATIONAL TEST	AOT 29/07 AUG 28 92
	92-217-134(B) 92-230-135(B)R1	GREEN HYD SYS INSP & GEAR BOX SEAL REPLACEMENT	A310-72-2020
FR FR	92-253-138(B)R1	INSPECTION OF 101 VU RACK LOWER ATTACHMENTS	A310-53-2077.
FK	J2 233 103(B)K1		
			ATRCDAET / AEDONEES

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

AIRBUS			
	SERIES		
FR FR	NUED / SUITE)	NLG BOTTOM OF SHOCK ABSORBER	
FR	92-274-140(B)R1 92-275-139(B)R1	SLAT TRANSMISSION SYS - UNIVERSAL JOINT ASSY	27-2060, -2061
FR	93-039-143(B)R2	MLG ATT BETWEEN DRAG STRUT & RETRACT ACT - INSP	470-32-744 REV 1
FR	93-063-145(B)R1	NOSE LANDING GEAR FREE FALL JAMMING - VISUAL INSP	AOT 32-06, 3 MAR 93
FR	93-136-146(B)R4	DOWTY RAM AIR TURBINE	29-2039R1, -2078
FR	93-202-153(B)R1	FLC - FEEL & LIMITATION COMPUTER	AOT 27-14
FR	94-104-160(B)R2	COCKPIT FIXED SIDE WINDOWS	AOT 56-01R1, 56-2002
FR	94-169-161(B)R1 94-185-165(B)R2	SMOKE DETECTION IN LAVATORIES AUTOPILOT OVERRIDING PROTECTION	ADT 26-12 JUN/6/94 -22-2036,-22-2040
FR FR	94-186-164(B)	PRESS REDUCING VALVE FIRE EXTING FLOW METER SYS	A310-26-2010
FR	94-187-163(B)R1	CHAFING OF PANEL 104VU ELECT BUNDLE BY EXT LADDER	AOT 24-05 REV 1
FR	94-188-162(B)R3	SOGERMA-SOCEA PILOTS SEATS BACK REST LOCK ATTACH	25-229, -25-2091
FR	94-285-173(B)R1	COCKPIT SLIDING WINDOWS (LH & RH)	ADT 30-01R2 6/3/95
FR	1995-052-176(B)R1	THRUST REVERSERS	AOT 78-05R1
FR	95-073-178(B)R1	FLAT TRANSMISSION SYSTEM BEARINGS	27-2067R1, -2074
FR	95-074-179(B)	SLAT TRANSMISSION SYSTEM BEARINGS	A310-27-2040 REV 2
FR FR	95-163-182(B)R4 95-164-183(B)	RAM AIR TURBINE UPLOCK PIN RIGGING OF AUTOPILOT ACTUATORS	AOT 29-16, 29-2076
FR	95-182-184(B)	APU - BLEED AIR DUCTS	36-2032
FR	95-202-188(B)R1	FEEL & LIMITATION COMPUTER	27-2068, 2070
FR	95-206-189(B)	CARBON FIBER ELEVATORS	55-2016
FR	95-243-190(B)	LAVATORIES - SMOKE DETECTION SYS	AOT 26-16
FR	95-246-193(B)	MOD RUDDER TRIM CONTROL SWITCHES & KNOBS	27-2071R2
FR	96-008-175(B)R2	FUSELAGE - CHAFING PLATE OF WING ROOT	53-2070, -2069R2
FR FR	96-021-196(B) 96-052-197(B)	CHAFING OF THE ELECTRICAL WIRE BUNDLE	24-2065
FR	96-135-199(B)R1	NOSE LDG FREE FALL EXTENSION SYSTEM FRAMES OF AFT DOORS - STRESS CORROSION	32~2098 53-2079
FR	96-186-204(B)R1	SMOKE DETECTION IN LAVATORIES	26-2030
FR	96-239-205(B)R1	PERIODIC FUNCTIONAL TEST OF OPENING EMERGENCY EXIT	
FR	96-240-206(B)R1	RUDDER TRIM SYS CNTRL SWITCH & CNTRL KNOB INSTALL	
FR	96-242-208(B)R2	RUDDER SERVO-CONTROL DESYNCHRONIZATIION	27-2082,55-2026
FR	96-270-209(B)R1	ENG CNTRL ~ REPLACEMENT OF BEARING THROTTLE LEVERS	
FR	1997-006-210(B)R1	WING BOTTOM SKINS	A310-57-2061
FR FR	1997-124-223(B)R1 97-061-212(B)R1	INSPECTION OF PASSENGER DOOR STOP FITTINGS FUSELAGE - INSPECTION OF REAR PRESSURE BULKHEAD	53-2087
FR	97-082-215(B)	MAIN FUEL SYSTEM - MOD NRV IN WING TANKS	53-2036, -2092 A310-28-2053
FR	97-098-216(B)	STATIC PORTS - AIR DATA STATIC LINES	A.O.T. 34-04
FR	97-110-218(B)	N1(OR EPR) LIMIT SETTING ON TRP (THRUST RATING)	22-2025, -2027, -2031
FR	97-111-219(B)	RUDDER TRIM CONTROL SWITCH	27-2084
FR	97-113-221(B)R2	LANDING GEAR FREE FALL EXTENSION	A.D.T. 32-14 R1
FR	97-143-227(B)	AFT CARGO COMPARTMENT FOWARD CONTAINER LATCH	AOT 25-05_REV 3
FR FR	97-152-225(B)	101VU PANEL WIRE BUNDLE WEAR DUE TO CHAFING	E0 0070D4
FR	97-175-228(B)R1 97-324-234(B)	WING TO FUSELAGE UPPER FAIRING ATTACHMENTS (ATA53) CF6-80A3 AFT ENGINE MOUNT LINK CRACK	AOT 71-06
FR	97-358-232(B)	ATA 57- WING - PYLON THRUST & SIDELOAD FITTING	57-2075
FR	97-373-237(B)	AUTOPILOT OVERRIDE PROTECTION (ATA 22)	22-2044, -2047
FR	1998-122-244(B)R1	SLIDES & SLIDE RAFTS - MOD OF REGULATOR VALVE	25-2119
FR	1998-263-255(B)R3	ALTERNATE BRAKING SYSTEM CHECK	AOT 32-19R2
FR	1998-340-254(B)R1	EMERGENCY EXITS - BEARINGS OF OPENING MECHANISM	A310-52-2061R1
FR	1998-483-271(B)R1	SPOILER NO 3 - ACTUATOR ATTACHMENT FITTING	A310-57-2078
FR FR	98-123-245(B) 98-174-248(B)	FUSELAGE BULK CARGO COMPARTMENT DOOR FRAME FUEL TANKS - BONDING LEADS	53-2106
FR	98-174-248(B) 98-175-249(B)	FLIGHT CONTROLS RUDDER TRIM	28-2128, -2130 27-2077 REV 1
FR	98-271-253(B)	THS ACTUATOR HYDAULIC MOTORS	27-2077 REV 1 27-2081, ~2088
FR	98-275-251(B)	THRUST REVERSER CONTROL SYSTEM	78A1005R3,78A1015R4
FR	98-354-256(B)	TRIM TANK - WATER SCAVENGE PUMPS	A310-28-2058 REV 3
FR	98-356-259(B)	FIRE SHUTT-OFF VALVES	
FR	98-379-258(B)	THRUST REVERSER SYSTEM	78-1002 R2
FR FR	98-448-262(B) 98-450-261(B)	RAM AIR TURBINES	A310-29-2078
FR	98-450-261(B) 98-480-269(B)	WING TO FUSE UPPER FARINGS  APU - FUEL FEEDLINE	A310-49-2012D1
FR	98-504-274(B)	CF6-80C2 ENGINE AFT MOUNT L/H LINK	A310-49-2012R1 GE 72-A947
FR	1999-006-263(B)	RAM AIR TURBINE UPLOCK UNIT	A310-29-2077
FR	1999-012-275(B)	RUDDER TRIM CONTROL KNOB	
FR	1999-013-276(B)	FRAME 73A AT AFT PAX DOOR	A310-53-2107
FR	1999-077-278(B)	101VU PANEL	A310-24-2078
FR	1999-180-282(B)	CENTER TANK METTALLIC VAPOR SEAL	A310-28A2139 R1
FR FR	1999-181-283(B)R1 1999-237-285(B)	THRUST REVERSERS	AUT 78-09R02/22
FR	1999-238-286(B)R1	PYLON INSP APU FIRE DETECT	A310-54-2022
FR	1999-239-287(B)	PYLON LOWER SPAR INSP	A310-26-6038R2 A310-54-2017/23
FR	1999-242-289(B)	THRUST REV DIRECTIONAL PILOT VALVE	AOT A310-78A2017/04

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

ATDDUC	<b>C</b>		
AIRBUS			
	SERIES		
(CONTI	NUED / SUITE)		
FR	1999-268-292(B)	ERRATIC RUDDER MOVEMENT DURING APPROACH INSP - STRIKER MECHANISM DOOR EMERGENCY ACTUATORS DC ELECTRICAL POWER TR UNITS	AOT A310-22A2O50
FR	1999-410-294(B)R1	INSP - STRIKER MECHANISM DOOR EMERGENCY ACTUATORS	A310-52-2065
FR	1999-435-296(B)	DC ELECTRICAL POWER TR UNITS	A310-24-6068 OR REV
FR	1999-510-299(B)	FLIGHT CONTROLS- FLAP CONTROL SCREW JACK NO. 1	A310-24-6068 UR REV
FR	1999-511-297(B)	SEAT - ARTICULATED AND DUMMY TRACKS	A310-27-2075K1
FR	2000-007-301(B)	PITCH TRIM	A310-53-2102
1 '''	2000 007 301(B)	FITCH IKIW	AOT A310-22A2O53
A310	204 ( 42	40 (550,750 )	
ASTO	304 ( A3	10 SERIES )	
1010	CERTES		
	SERIES		
FR	1996-271-092(B)R3	INBOARD FLAP TRUNNION	A320-27-1066R5
FR	97-203-102(B)R1	PROBE HEAT COMPUTER	30-1036
FR	97-269-103(B)	TOILET RINSE VALVE	38-1049
FR	97-385-112(B)R1		A320-32-1187
FR	1998-262-120(B)R4	ALTERNATE BRAKING SYSTEM CHECK	A320-32-1200
FR	1998-293-118(B)R1	IAE FRONT ENGINE MOUNT MODIFICATION	A020 02 1200
FR	1998-482-122(B)R1	PASS AND EMER DOORS ACTUATOR STRIKE MECHANISM	A320-52-1094 R1
FR	1998-509-123(B)	CENTRAL FUSELAGE - FRAME AND FRAME FEET	
FR	98-178-115(B)		A320-53-1128
FR	98-451-121(B)	IMPROVEMENT OF AVIONIC PROTECTION FROM WATER	25-1186
- FR	1000-050 100(D)	ILS RECEIVER	A320-34-1163
FR	1999-050-126(B)	FORWARD THRUST LINKS REPLACEMENT	A320-171-1020
FR	1999-074-127(B)	SLIDING TABLE / COCKPIT FOOTREST	
FR	1999-124-129(B)		A320-32-1197
FR	1999-232-132(B)	OFFWING ESCAPE SLIDE	A320-25-1156R1
FR	1999-243-133(B)R1	OFFWING ESCAPE SLIDE MLG DOOR ACT FITTING_INSP RELAY 11QG RELOCATION AND CONTACT INSPECTION	AOT A320-52A1086
FR	1999-263-134(B)	RELAY 11QG RELOCATION AND CONTACT INSPECTION	A320-24-1092R1 OR 2
FR	1999-356-136(B)	ESCAPE SLIDE	A320-25-1215
FR	1999-358-137(B)R1	MAIN LANDING GEAR SLIDING TUBE INSP.	A320-32-1189
FR	1999-361-138(E)	LITTON GPSSU	A320-34-1191/96
FR	1999-362-139(B)	FLIGHT CONTROLS SPOILER SERVOCONTROLS MODIFICATION	
FR	1999-411-140(B)	FLIGHT MANAGEMENT GUIDANCE SYS	A320 27 1120/27
	1999 411 140(B)	RAT ACTUATOR	A320-29-1088
US	1999-412-141(B) 99-25-07	BFGOODRICH BRAKE ASSY P/N 2-1598 OR 2-1600	BF 2-1598-32-1 DR -2
A319		19 SERIES )	ADT 20 45
FR	97-177-101(B)	LANDING GEAR GRAVITY FREE FALL CNTRL MECH RIGGING	
FR			
í	98-152-114(B)	PROBE HEAT COMPUTER TEST PROCEDURES	30-1036 REV 2
A320	SERIES	PROBE HEAT COMPUTER TEST PROCEDURES	30-1036 REV 2
A320	SERIES	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS	30-1036 REV 2 A320-24-1013, -1031
A320		PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK	30-1036 REV 2 A320-24-1013, -1031 A320-29-1030
<b>A320</b> FR	SERIES 89-100-002(B)R1	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS	30-1036 REV 2  A320-24-1013, -1031  A320-29-1030  A320-24-1022, -1035
A320 FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024
A320 FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES	30-1036 REV 2  A320-24-1013, -1031  A320-29-1030  A320-24-1022, -1035  A320-28-1024  A320-34-1012
A320 FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024
A320 FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES	30-1036 REV 2  A320-24-1013, -1031  A320-29-1030  A320-24-1022, -1035  A320-28-1024  A320-34-1012
A320 FR FR FR FR FR FR FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM	30-1036 REV 2  A320-24-1013, -1031  A320-29-1030  A320-24-1022, -1035  A320-28-1024  A320-34-1012  A320-32-1035, -1048
A320 FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300	A320-24-1013, -1031 A320-29-1030 A320-29-1022, -1035 A320-28-1024 A320-34-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973
A320 FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1	AUTOMATIC LANDING IN CAT III CONDITIONS  RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL	A320-24-1013, -1031 A320-29-1030 A320-29-1022, -1035 A320-28-1024 A320-34-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973
A320 FR FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024 A320-34-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028
A320 FR FR FR FR FR FR FR FR FR FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1	PROBE HEAT COMPUTER TEST PROCEDURES  AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3	A320-24-1013, -1031 A320-29-1030 A320-29-1022, -1035 A320-28-1024 A320-34-1012 A320-32-1035, -1048 ADT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012
A320 FR FR FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1 90-190-015(B) 91-119-017(B)R1	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT	A320-24-1013, -1031 A320-29-1030 A320-29-1030 A320-28-1022, -1035 A320-32-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4
A320 FR FR FR FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1 90-138-014(B)R1 90-190-015(B) 91-119-017(B)R1 91-152-019(B)	AUTOMATIC LANDING IN CAT III CONDITIONS  RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024 A320-34-1012 A320-34-1012 A320-32-1035, -1048 AOT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 AOT 29-4 AOT 25-02
A320 FR FR FR FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1 90-190-015(B) 91-119-017(B)R1 91-152-019(B) 91-153-018(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS	A320-24-1013, -1031 A320-29-1030 A320-29-1022, -1035 A320-28-1024 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2
A320 FR FR FR FR FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1 90-190-015(B) 91-119-017(B)R1 91-153-018(B) 91-182-020(B)R2 91-227-021(B)R1	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE	A320-24-1013, -1031 A320-29-1030 A320-29-1030 A320-28-1022, -1035 A320-28-1024 A320-32-1035, -1048 ADT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 ADT 29-4 AOT 29-4 AOT 29-4 A320-24-1044 REV 2 A320-24-1044RS
A320 FR FR FR FR FR FR FR FR FR FR FR FR FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-1038-014(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE	A320-24-1013, -1031 A320-29-1030 A320-29-1030 A320-28-1022, -1035 A320-28-1024 A320-32-1035, -1048 ADT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 ADT 29-4 AOT 29-4 AOT 29-4 A320-24-1044 REV 2 A320-24-1044RS
A320 FR FR FR FR FR FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1 90-190-015(B) 91-119-017(B)R1 91-152-019(B) 91-153-018(B) 91-182-020(B)R2 91-227-021(B)R1 91-272-023(B)R2 92-048-024(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024 A320-34-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-27-1043 REV1 A320-28-1024 REV1
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-153-018(B)  91-153-018(B)  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL	30-1036 REV 2  A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024 A320-32-1035, -1048 ADT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 ADT 29-4 ADT 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320 SERIES A320-32-1094
A320 FR FR FR FR FR FR FR FR FR FR FR FR FR	SERIES 89-100-002(B)R1 89-160-003(B)R2 89-198-004(B)R1 90-017-005(B)R2 90-018-006(B)R2 90-026-007(B)R2 90-076-008(B)R1 90-102-011(B)R1 90-138-014(B)R1 90-190-015(B) 91-119-017(B)R1 91-152-019(B) 91-153-018(B) 91-182-020(B)R2 91-227-021(B)R1 91-272-023(B)R2 92-048-024(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS	A320-24-1013, -1031 A320-29-1030 A320-29-1030 A320-28-1022, -1035 A320-28-1024 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-22-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-32-1094 A320-32-1094 A320-32-1094 A320-32-1094 A320-32-1094 A320-32-1061 REV 2
A320 FR FR FR FR FR FR FR FR FR FR FR FR FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-153-018(B)  91-153-018(B)  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-24-1022, -1035 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-32-1061 REV 2 A320-32-1061 REV 2 A320-32-1061 REV 2
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-138-014(B)R1  91-152-019(B)  91-153-018(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  91-27-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1022, -1035 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320 SERIES A320-32-1064 REV 2 A320-32-1064 REV 2 A320-32-1064 REV 2 A320-32-1064 REV 2 A320-33-1069 A320-53-1069 A320-53-1069
A320 FR FR FR FR FR FR FR FR FR FR FR FR FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  91-27-021(B)R1  91-272-023(B)R2  91-27-025(B)R1  92-164-026(B)  92-198-027(B)  92-198-027(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 13 & 14 FUS - INSP CENTER WING BOX -INSP - UPPER STRINGER	A320-24-1013, -1031 A320-29-1030 A320-29-1030 A320-28-1022, -1035 A320-28-1024 A320-32-1012 A320-32-1015, -1048 ADT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 ADT 29-4 AOT 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320 SERIES A320-32-1094 A320-32-1061 REV 2 A320-53-1069 A320-53-1036 A320-57-1030
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-277-021(B)R1  91-277-021(B)R1  91-278-021(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-199-028(B)  92-199-028(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1022, -1035 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320 SERIES A320-32-1064 REV 2 A320-32-1064 REV 2 A320-32-1064 REV 2 A320-32-1064 REV 2 A320-33-1069 A320-53-1069 A320-53-1069
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-1038-014(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-199-028(B)  92-200-029(B)  92-200-029(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER	A320-24-1013, -1031 A320-29-1030 A320-29-1030 A320-28-1022, -1035 A320-28-1024 A320-32-1012 A320-32-1015, -1048 ADT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 ADT 29-4 AOT 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320 SERIES A320-32-1094 A320-32-1061 REV 2 A320-53-1069 A320-53-1036 A320-57-1030
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-138-014(B)R1  91-152-019(B)  91-1153-018(B)  91-153-018(B)  91-1272-021(B)R1  91-272-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-199-028(B)  92-200-029(B)  92-201-030(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES. NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-24-1022, -1035 A320-34-1012 A320-34-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-27-1012 A0T 29-4 A0T 29-4 A0T 25-02 A320-34-1044 REV 2 A320-34-1044 REV 2 A320-34-1044 REV 2 A320-34-1046 REV 2 A320-32-1061 REV 2 A320-32-1061 REV 2 A320-53-1036 A320-53-1036 A320-53-1030 A320-53-1030
### A 3 2 0 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-153-018(B)  91-153-018(B)  91-153-018(B)  91-1227-021(B)R1  91-277-021(B)R1  91-277-021(B)R1  91-279-028(B)R2  92-048-024(B)  92-198-027(B)  92-199-028(B)  92-200-029(B)  92-201-030(B)  92-203-032(B)  92-203-032(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX -INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN RIBS 1 & 2 - INSP	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1022, -1035 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320 SERIES A320-32-1094 A320-32-1061 REV 2 A320-32-1061 REV 2 A320-53-1036 A320-53-1036 A320-53-1036 A320-53-1036 A320-53-1036 A320-53-1044
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-199-028(B)  92-200-029(B)  92-201-030(B)  92-201-030(B)  92-204-034(B)  92-204-034(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NIG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN FIBSS 1 & 2 - INSP PRESSURE FLOOR BETWEEN FRAMES 42 & 43	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024 A320-34-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-32-1061 REV 2 A320-32-1061 REV 2 A320-53-1069 A320-53-1030 A320-53-1014 A320-53-1014 A320-53-1002 A320-57-1021 A320-57-1021
### A 3 2 0	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-227-021(B)R1  91-27-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-199-028(B)  92-200-030(B)  92-200-030(B)  92-203-032(B)  92-204-034(B)  92-205-033(B)R2  92-204-034(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN FRAMES 42 & 43 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1044 REV 1 A320-38-1084 A320-32-1061 A320-32-1061 A320-32-1061 A320-32-1061 A320-53-1064 A320-53-1064 A320-53-1064 A320-53-1014 A320-53-1002 A320-53-1002 A320-53-1024 A320-57-1021
### A 3 2 0	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-153-018(B)  91-1227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-199-028(B)  92-201-030(B)  92-201-030(B)  92-203-032(B)  92-204-034(B)  92-205-033(B)R2  92-211-036(B)R1  92-205-033(B)R2  92-211-036(B)R1	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES. NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN RIBS 1 & 2 - INSP PRESSURE FLOOR BETWEEN FRAMES 42 & 43 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR PYLON FUEL RETURN LINE CONNECTION	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1022, -1035 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320 SERIES A320-32-1061 REV 2 A320-33-1069 A320-53-1030 A320-53-1030 A320-53-1030 A320-53-1030 A320-53-1030 A320-53-1041 A320-53-1002 A320-53-1002 A320-53-1021 A320-53-1024 A320-53-1024 A320-53-1024 A320-53-1024 A320-53-1045 A0T 28-04
### A 3 2 0	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-199-028(B)  92-199-028(B)  92-200-029(B)  92-201-030(B)  92-203-032(B)  92-205-033(B)R2  92-201-036(B)R1  92-228-037(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX -INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN RIBS 1 & 2 - INSP PRESSURE FLOOR BETWEEN FRAMES 42 & 43 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR PYLON FUEL RETURN LINE CONNECTION	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1024 A320-34-1012 A320-34-1012 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-34-1044 REV 2 A320-34-1044 REV 2 A320-34-1043 REV1 A320 SERIES A320-27-1043 REV1 A320-53-1069 A320-57-1030 A320-57-1030 A320-57-1030 A320-57-1030 A320-57-1045 A320-53-1024 A320-53-1024 A320-53-1024 A320-53-1045 A0T 28-04 A0T 26-07
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-138-014(B)R1  90-138-014(B)R1  90-15(B)  91-152-019(B)  91-153-018(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-199-028(B)  92-200-029(B)  92-201-030(B)  92-201-030(B)  92-203-032(B)  92-204-034(B)  92-211-036(B)R1  92-228-037(B)  92-236-038(B)  92-236-038(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN RIBS 1 & 2 - INSP PRESSURE FLOOR BETWEEN FRAMES 42 & 43 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR PYLON FUEL RETURN LINE CONNECTION LAVATORY SMOKE DETECTION ELECTRIC TERMINAL BLOCKS	30-1036 REV 2  A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-32-1024 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-SERIES A320-32-1061 REV 2 A320-32-1069 A320-32-1069 A320-53-1036 A320-57-1030 A320-53-1036 A320-57-1021 A320-53-1024 A3
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-201-030(B)  92-201-030(B)  92-201-030(B)  92-203-032(B)  92-204-034(B)  92-205-033(B)R2  92-211-036(B)R1  92-236-033(B)R2  92-236-033(B)R2  92-236-033(B)R2  92-236-038(B)  92-236-038(B)  92-2371-039(B)R3  93-056-040(B)R3	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES. NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN RIBS 1 & 2 - INSP PRESSURE FLOOR BETWEEN FRAMES 42 & 43 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR PYLON FUEL RETURN LINE CONNECTION LAVATORY SMOKE DETECTION ELECTRIC TERMINAL BLOCKS BF GOODRICH CARBON BRAKES	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1022, -1035 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-32-1064 REV 2 A320-33-1064 A320-32-1064 REV 2 A320-33-1064 A320-53-1069 A320-53-1064 A320-32-11144 A320-32-1065
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-138-014(B)R1  90-138-014(B)R1  90-15(B)  91-152-019(B)  91-153-018(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-199-028(B)  92-200-029(B)  92-201-030(B)  92-201-030(B)  92-203-032(B)  92-204-034(B)  92-211-036(B)R1  92-228-037(B)  92-236-038(B)  92-236-038(B)	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX -INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN RIBS 1 & 2 - INSP PRESSURE FLOOR BETWEEN FRAMES 42 & 43 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR PYLON FUEL RETURN LINE CONNECTION LAVATORY SMOKE DETECTION ELECTRIC TERMINAL BLOCKS BF GOODRICH CARBON BRAKES RAM AIR TURBINE BALL BEARING	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1022, -1035 A320-32-1035, -1048 ADT 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 ADT 29-4 ADT 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-SRIES A320-32-1094 A320-53-1036 A320-53-1036 A320-53-1036 A320-53-1036 A320-53-1036 A320-53-1044 A320-53-1024 A320-53-1045 ADT 28-04 ADT 26-07 ADT 28-04 ADT 26-07 ADT 24-02 DEC 21/92 A320-32-1114 A99-1061, -29-1065
A320 FR	SERIES  89-100-002(B)R1  89-160-003(B)R2  89-198-004(B)R1  90-017-005(B)R2  90-018-006(B)R2  90-026-007(B)R2  90-076-008(B)R1  90-102-011(B)R1  90-138-014(B)R1  90-190-015(B)  91-119-017(B)R1  91-152-019(B)  91-153-018(B)  91-182-020(B)R2  91-227-021(B)R1  91-272-023(B)R2  92-048-024(B)  92-117-025(B)R1  92-164-026(B)  92-198-027(B)  92-201-030(B)  92-201-030(B)  92-201-030(B)  92-203-032(B)  92-204-034(B)  92-205-033(B)R2  92-211-036(B)R1  92-236-033(B)R2  92-236-033(B)R2  92-236-033(B)R2  92-236-038(B)  92-236-038(B)  92-2371-039(B)R3  93-056-040(B)R3	AUTOMATIC LANDING IN CAT III CONDITIONS RAM AIR TURBINE EJECTION JACK STAND-BY GENERATOR CONTROL UNIT (GCU) FUEL PROBES ANGLE OF ATTACK SENSORS INTERRUPTION OF LANDING GEAR RETRACTION PASSENGER ADDRESS SYSTEM GARRET APU GTCP36-300 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR CONTROL LOW PRESSURE FIRE FUEL SHUT-OFF VALVE TRIMMABLE HORIZONTAL SURFACE RELAY 36 CE 3 HYDRAULIC FIRE SHUT OFF VALVE - INTERNAL SHORT OVERWING ESCAPE SLIDE WIRE LOOM CHAFING / CONDUIT EXITS PITOT TUBE ELEVATOR SERVOCONTROLS - INSPECTION FUEL QUANTITY PROBES. NOSE WHEEL STEERING CONTROL REINFORCEMENT OF NLG WHEELS FASTENERS SKIN PANEL TO FRAME 15 JUNCT FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP FASTENERS SKIN PANEL TO FRAMES 13 & 14 FUS - INSP CENTER WING BOX - INSP - UPPER STRINGER CENTER FUS - REINFORCE STRUCT BELLY FAIRING - MOD REINFORCEMENT OF STRUCT BETWEEN FRAMES 1 & 2 FUS WING REAR SPAR BETWEEN RIBS 1 & 2 - INSP PRESSURE FLOOR BETWEEN FRAMES 42 & 43 TRIMMABLE HORIZONTAL STABILIZER ACTUATOR PYLON FUEL RETURN LINE CONNECTION LAVATORY SMOKE DETECTION ELECTRIC TERMINAL BLOCKS BF GOODRICH CARBON BRAKES	A320-24-1013, -1031 A320-29-1030 A320-24-1022, -1035 A320-28-1022, -1035 A320-32-1035, -1048 A0T 23/89/01 GARRET ASB 3649A5973 A320-27-1031 A320-28-1028 A320-27-1012 A0T 29-4 A0T 25-02 A320-24-1044 REV 2 A320-34-1024R3 A320-27-1043 REV1 A320-32-1064 REV 2 A320-33-1064 A320-32-1064 REV 2 A320-33-1064 A320-53-1069 A320-53-1064 A320-32-11144 A320-32-1065

20 JANUARY/JANVIER 2000

19

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

URIGINE	NOMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
AIRBUS	EDIEC		
A320 S			
FR	UED / SUITE) 93-107-045(B)	REINFORCEMENT OF FRAME 20 FUSELAGE - MOD	A320-53-1017
FR	93-107-045(B) 93-108-044(B)	WINGS - REINFORCEMENT OF AILERON SUPPORT FRAMES	A320-53-1017 A320-57-1002
FR	93-123-046(B)R1	TRIMABLE HORZ STAB LIGHTNING STRIKE PROTECTION	27-1041R1.29-1058R1
FR	93-163-043(B)	BRAKING SYSTEM REPLACE RELAYS 24 GG & 25 GG	A320-32-1115
FR	93-191-047(B)	FUEL SYS ELECT WIRING ATTACH CLIPS AT RIB 6	A320-28-1052 REV 1
FR	93-203-049(B)R3	AUTOMATIC LANDING	34-1008, 27-1081
FR	93-207-048(B)R1	JAMMING OF PASSENGER DOORS	A320-52-1027
FR	94-056-051(B)	CARGO FIRE EXTINGUISHER BOTTLE ELECT CONNECTION	AOT 26-10
FR	94-059-054(B)	THRUST REVERSER CHECK VALVE	29-1048 R1
FR	94-168-058(B)R1	SMOKE DETECTION IN LAVATORIES	ADT 26-12 JUN/6/94
FR	94-211-059(B)R2	FLAPS LOCKED	A320-31-1080
FR	94-239-060(B)	JAMMING OF PASSENGER DOOR SAFETY PIN	A320-52-1057
FR	95-004-062(B)R1	JAMMING OF PASSENGER DOORS	52-1064, -1066
FR FR	95-016-063(B) 95-145-070(B)R1	MAIN LDG SHOCK ABSORBER UPPER BEARING DOWEL HYD FIRE SHUT-OFF VALVE	A320-32-1144 29-1071
	95-203-072(B)	LATERAL CONT LAW IN CASE OF FAILURE/JAMMING FLAPS	
FR	1996-271-092(B)R3	INBOARD FLAP TRUNNION	A320-27-1062 A320-27-1066R5
FR	96-007-073(B)	SMOKE DETECTION IN LAVATORIES	26-1017, -1037
FR	96-011-075(B)	AVIONIC - TRICKLING WATER HATCH DOOR SEALING	53-1070
FR	96-040-076(B)	AVIONIC PROTECTION (VUS 90 & 91) TRICKLING WATER	24-1054
FR	96-053-077(B)R1	MAIN LANDING GEAR FREE FALL EXTENSION SYSTEM	53-1023 REV 7
FR	96-079-079(B)	FLAPS LOCKED (IMPROVED FLIGHT WARNING COMPUTER)	31-1080
FR	96-169-081(B)	ACTIVATION SPOILER FUNCTION "PHASE LIFT DUMPING"	-27-1088
FR	96-170-082(B)	FUEL PUMP STRAINER	-28-1044 REV 9
FR	96-171-083(B)	SLIDE/SLIDE RAFT RELEASE CABLE	AOT 25-12 REV 1
FR	96-172-084(B)	COLLINS RADIO-ALTIMETER ANTENNAS	AOT 34-03, -34-1030
FR	96-187-085(B)R2	CAPACITOR LANDING GEAR RETRACTION CNTRL CIRCUIT	32-1139R1
FR	96-234-087(B) 96-236-089(B)	FUS INSP GUSSET FRAME ATTACH HOLE DOOR FRAME 66	53-1071, -1072
FR FR	96-236-089(B) 96-237-090(B)ERRATUM	FUS INSP LONGITUDINAL FLOOR BEAMS AT FRAME 43 FUS INSP CONNECTING ANGLE FRAME 56 & STRINGER 38	53-1085, -1008
FR	96-238-091(B)	FUS INSP OF FRAME 60 & 62 BULK CARGO DOOR FRAME	53-1084R1, -1011
FR	96-272-098(B)R1	LORAL DFDR F800 DAMPING RACK INSTALLATION	53-1021R1,-1022R1 31-1088R2
FR	96-298-093(B)R2	FUSELAGE - INSPECTION FRAME 68	53-1089, -53-1090
FR	96-299-094(B)	WING/FUSELAGE JOINT CRUCIFORM FITTINGS - INSPECT	57-1051R1
FR	97-083-096(B)	WING-INSPECTION BOTTOM SKIN BETWEEN RIB13-22	A320-57-1056
FR	97-084-097(B)	WING INSPECTION - ANGLES ON REAR SPAR	A320-57-1090, 1025R2
FR	97-085-099(B)	SLATS-FLAPS CONTROL COMPUTER	A320-27-1096
FR	97-203-102(B)R1	PROBE HEAT COMPUTER	30-1036
FR	97-269-103(B)	TOILET RINSE VALVE	38-1049
FR	97-309-104(B)	WING - INSPECTION CENTER BOX BOTTOM PANEL	57-1082R1
FR	97-311-105(B)	WING - INSPECTION FRONT SPAR VERTICAL STRINGERS	57-1017
FR FR	97-312-106(B)	FUSELAGE INSPECTION LONGITUDINAL LAP JOINTS	53-1057
FR	97-313-107(B)R1 97-314-108(B)	FUSELAGE - INSPECTION FRAMES 38 TO 41	53-1031
FR	97-314-108(B)	FUSELAGE - INSPECTION FRAME 46/STRINGER 37 FUSELAGE - REINFORCEMENT OF THE STRUCTURE SECT 18	53-1033, -1034
FR	97-316-110(B)	WING - INSPECTION CONNECTION FRAMES 43 & 44	53-1110, -1131
	97-385-112(B)R1	INSPECTION OF MLG FWD PINTLE CROSS BOLT	53-1015, -1083R2 A320-32-1187
FR	1998-262-120(B)R4	ALTERNATE BRAKING SYSTEM CHECK	A320-32-1187
FR	1998-482-122(B)R1	PASS AND EMER DOORS ACTUATOR STRIKE MECHANISM	A320-52-1094 R1
	1998-509-123(B)	CENTRAL FUSELAGE - FRAME AND FRAME FEET	A320-53-1128
	1998-537-124(B)R1	AIRBORN GROUND CHECK MODULE	A320-29-1086
	98-154-113(B)	REINFORCEMENT - FRAME 35 - STRINGERS 30 & 31	53-1137
	98-178-115(B)	IMPROVEMENT OF AVIONIC PROTECTION FROM WATER	25-1186
	1999-050-126(B)	FORWARD THRUST LINKS REPLACEMENT	A320-171-1020
	1999-074-127(B)	SLIDING TABLE / COCKPIT FOOTREST	
	1999-075-128(B)	FLIGHT CONTROLS - STIFF RUDDER PEDALS	A300-53-0298 R3
FR	1999-124-129(B)	NLG WHEEL ROTATION	A320-32-1197
FR	1999-148-130(B)	PASSENGER DOOR SAFETY PIN GREASING	A320-52-1057 R6
FR FR	1999-232-132(B)	OFFWING ESCAPE SLIDE	A320-25-1156R1
FR	1999-243-133(B)R1 1999-263-134(B)	MLG DOOR ACT FITTING INSP RELAY 11QG RELOCATION AND CONTACT INSPECTION	AOT A320-52A1086
	1999-264-135(B)	WING INSP REAR SPAR	A320-24-1092R1 DR 2
	1999-356-136(B)	ESCAPE SLIDE	A320-25-1215
		MAIN LANDING GEAR SLIDING TUBE INSP.	A320-25-1215 A320-32-1189
FR	1999-361-138(B)	LITTON GPSSU	A320-32-1189 A320-34-1191/96
	1999-362-139(B)	FLIGHT CONTROLS SPOILER SERVOCONTROLS MODIFICATION	A320-27-1126/27
	1999-411-140(B)	FLIGHT MANAGEMENT GUIDANCE SYS	
		BFGOODRICH BRAKE ASSY P/N 2-1598 OR 2-1600	BF 2-1598-32-1 OR -2
A320 2	( 102	O SERIES )	
FR	89-023-001(B)R1	ELECTRICAL POWER - ARTUS TRANSFORMER RECTIFIER	A320-24-1024, -1028
FR	90-096-010(B)	MAIN LANDING GEAR WHEEL AXLE	32-1031R1
47000	AFT / AFDONESS		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

			BULLETIN DE SERVICE DE REF.
ATROU	16		
AIRBU			
	) 211 ( A3:	20 SERIES )	
	INUED / SUITE)		
FR	90-108-012(B)R1	EMERGENCY DXYGEN CONTAINORS	35-1002R1
FR	91-243-022(B)	CFM56-5 ELECTRICAL HARNESS - HUMIDITY/CORROSION	71-01R1 AOT
FR	94-030-050(B)	JUNCTION BOX AND ELECT HARNESS CFM 56-5A	A320-71-1011
FR	94-057-052(B)	MLG FWD PINTIE CROSS BOLT	32-1119
FR	94-166-056(B)	FUS INSPIRIORE FWD CORNER SITDING WINDOW FRAME A	53-1044, -1082
FR	95-097-065(B)	PICK UP ANGLE BETWEEN FRAME 35 & 36	53-1027, -1028
FR	95-098-066(B)	PICK UP ANGLE BETWEEN FRAME 35 & 36 REINFORCEMENT OF PRESSURE FLOOR FITTING FLOOR FITTINGS AT FRAME 36	57~1013
FR	95-099-067(B)		57-1028 -1029
FR	95-100-068(B)	BRACKET BETWEEN SHROUD BOX & FIXED SHROUD	57-1034, -1035
FR	96-235-088(B)	FUSELAGE INSPECTION SLIDING WINDOW FRAME	53-1065
			35 1003
A320	212 ( A32	O SERIES )	
FR	90-108-012(B)R1	EMERGENCY DXYGEN CONTAINERS	35-1002R1
FR	91-243-022(B)	CFM56-5 ELECTRICAL HARNESS - HUMIDITY CORROSION	71-01R1 AOT
FR	94-030-050(B)	JUNCTION BOX AND FLECT HARNESS CEM 56-54	A320-71-1011
FR	94-057-052(B)	EMERGENCY OXYGEN CONTAINERS  EMERGENCY OXYGEN CONTAINERS  CFM56-5 ELECTRICAL HARNESS - HUMIDITY CORROSION  JUNCTION BOX AND ELECT HARNESS CFM 56-5A  MLG FWD PINTLE CROSS BOLT	32-1119
A320	232 ( A32	O SERIES )	
FR	1998-293-118(B)R1		A320-71-1021
FR	98-152-114(B)	PROBE HEAT COMPUTER TEST PROCEDURES	30-1036 REV 2
		TEST TROCEDURES	00 1000 KLV 2
A330	SERIES		
FR	94-281-005(B)R2	RAM AIR TURBINE	29-30-16
FR	94-283-006(B)R1		ADC 30-01R2
FR	95-009-007(B)	FUEL SYSTEM TRIM LINE PRESSURE SWITCH	ADC 28-05
FR	95-009-007(B) 95-089-010(B)	DEACTIVATION AVIONICS GRND REFRIGERATIONUNIT	21-=30-28
FR	95-160-016(B)R4	FLAP TRACK FATRING	57-3038
FR	95-240-021(B)R1	WATER SERVICE DOOR (164 AR)	52-3034
FR	95-248-022(B)	REINFORCEMENT STRINGER 39 FRAMES 53.2 & 53.3	53-3021
FR	1996-006-024(R)R1	REINFORCEMENT OF JOINT AT FRAMES 48 TO 53.2	21-3027, 53-3015
FR	1996-006-024(B)R1 96-013-026(B)R2	MAIN LDG - SHORTENING MECHANISM ADJUSTABLE LINK	A330-32-3052
FR	96-048-028(B)R1	FLT CNTRLS - REPLACEMENT OF FCPC, FCSC, FCDC, FWC	
FR	96-134-031(B)R2	FLT CNTRLS - REPLACEMENT OF FCPC, FCSC, FCDC, FWC LDG FREE FALL EXTENSION ELECTRICAL CIRCUIT ELECT POWER - APU FUEL PUMPS ELECT SUPPLY	32-3048
FR	96-136-032(B)R1	FLECT POWER - APIL FUEL PUMPS FLECT SUPPLY	MMEL NO. 01-24/0E1
FR	96-159-033(B)R2	MAIN LDG SHORTENING MECHANISM - BELLCRANK	32-3047, -3050R1
FR	96-177-038(B)	THS LIGHTNING STRIKE PROTECTION IMPROVEMENT	55-3016
FR	1997-265-056(B)R1	LIFE LIMITS	AMM CHAPTER 05 R8
FR	97-004-041(B)	CARGO DOOR FRAME WORK REINFORCEMENT FRAME 59A & 65	
FR		MAIN LDG OPERATIKONAL CHECK OF DELAY & CHECK VALVE	
FR	97-007-042(B)R2 97-017-043(B)R2	AC ELECTRIC MOTOR DRIVEN HYDRAIL TO DIMP	AOT 29-2181
FR	97-017-043(B)R2 97-086-046(B)R1	AC ELECTRIC MOTOR DRIVEN HYDRAULIC PUMP BRAKING SYS LANDING ON CONTAMINATED RUNWAYS	32-3062
FR	97-086-048(B)	BRAKING SYS - LANDING ON CONTAMINATED RUNWAYS	32-3062
FR	97-142-048(B) 97-154-049(B)R1		A330-34-3044
FR	97-154-049(B)K1	ATA 24 - TRANSFO-RECTIFIERS (FR) (AUXILEC)	
	97-386-060(B)	STEERING LIMITS	A330-32-3091
FR	T98-473-083(B)		A330-32-3086
FR	1998-264-075(B)R4	MID AND AFT PASSENGER/CREW DOORS EMERGENCY EXIT	
FR	1998-484-081(B)R1		A330-52-3051
FR	1998-538-087(B)R1		A000 02 0001
FR	1998-539-088(B)	ELEVATOR SERVOCONTROLS MAIN LANDING GEAR - DOORS	52-3049
FR	98-268-073(B)R1	MLG - OUTBOARD BRAKE ROD ATTACHMENT PIN	A330-32-3084
FR	98-352-076(B)	LOWED KEELDEAM ETTTING	A330-57-3032 R3
FR	98-454-082(B)	LOWER KEELBEAM FITTING ALLIED SIGNAL INSTRUMENT LANDING SYSTEM RECEIVERS	A330-34-3068
FR	98-455-077(B) 98-507-085(B) 1999-046-091(B)R4	DOOD ACTUATOR STRIKER MECHANISM	A330-52-3048
FR	98-507-085(B)	DOOR ACTUATOR STRIKER MECHANISM	4220-2842060 B2
FR	1999-046-091(B)R4	FUEL TRIM TRANSFER LINE	A330-25-3105
FR	1999-048-090(B)R1	FUEL TRIM TRANSFER LINE SLIDING TABLE / COCKPIT FOOTREST BLUE MAIN HYD. POWER-EMERG. BRAKING	29-3054 & 32-3083R2
FR	1999-111-093(B)	BLUE MANACEMENT GUIDANCE & ENVELODE COMPUTED	A330-22-3009
FR	1999-123-092(B)		A000 ZZ 3005
FR	1999-142-093(B)	AD NUMBER CORRECTED TO 1999-142-097(B)	A330-22-3021
FR	1999-142-097(B)	FLIGHT CONTROL UNIT TRIMMABLE HORIZONTAL STABILIZER ACTUATOR	A330-27A3070R1
FR	1999-300-099(B)		A330-34-3082/86
FR	1999-354-101(B)	LITTON GPSSU	7000 04 0002/00
	( 422	o center )	
A330		O SERIES ) ICE PROTECTION - WING ANTI ICE VALVE	A330-30-3020
FR	1996-184-036(B)R2		A330-29-3057R1
FR	1999-144-094(B)R1	RAM AIR TURBINE - SUNDSTRAND	A330-32-3092
FR	1999-160-096(B)R1	STEERING LIMITS AND MAIN GEAR INSP	A330 25 3086
FR	1999-178-086(B)	SLIDE/RAFT-INSPECT SLIDE/RAFT RELEASE PIN	A330-25 3006 A330-32-3096R1
FR	1999-350-100(B)R1	MAIN LANDING GEAR PIVOT PIN REPLACEMENT	A330-52-3096R1
FR	1999-406-103(B)	HYD BRACKET FATIGUE GREEN RESIVOIR	A330-25-3096R1
FR	1999-442-104(B)	PAX CREW DOOR FRAME LINING	A330-25-3096R1
FR	1999-449-105(B)	REINFORCEMENT OF FRAME 40	A000 00 0000

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

	LE TROMETTO BE CONSTONE	30321	BULLETIN DE SERVICE DE REF.
ATROU	C		
AIRBU		ACCO CERTES )	
(CONT	INUED / SUITE)	A330 SERIES )	
FR	1999-508-106(B)	INSPECTION LOWER SECTIONS FRAME 48 TO 53.2	The state of the s
	1333 308 100(B)	INSPECTION LOWER SECTIONS FRAME 48 TO 53.2	A330-53-3067R2
A330	243 (	A330 SERIES )	
FD	1996-194-026(8)00	ICE DOCTECTION WING ANTI- TOP WALVE	A330-30-3020
FR	1997-118-047(B)R1	THRUST REVERSER OPENING MECH. RR TRENT 700	A330-30-3020
FR	1999-144-094(B)R1	RAM AIR TURBINE - SUNDSTRAND	A330-29-3057R1
FR	1999-160-096(B)R1	STEERING LIMITS AND MAIN GEAR INSP	A330-32-3092
FR.	1999-350-100(B)R1	THRUST REVERSER OPENING MECH. RR TRENT 700  RAM AIR TURBINE - SUNDSTRAND  STEERING LIMITS AND MAIN GEAR INSP  MAIN LANDING GEAR PIVOT PIN REPLACEMENT  PAX CREW DOOR FRAME INVING	A330-32-3096R1
			A330-25-3096R1
FR	1999-508-106(B)	INSPECTION LOWER SECTIONS FRAME 48 TO 53.2	A330-53-3067R2
1000	000		
A330	322 (	A330 SERIES )	
FR FR	1995-271-025(B)R2	THOMSON LOW RANGE RADIO ALTIMETER (LRRA)	AOT 34-02
FR	95-032-008(B)R1 95-053-009(B)R3		27-30-26
FR	95-090-011(B)R1	HYDRAULIC SENSE LINE	29-3012, -3015, -3019
FR	95-124-012(B)	INBOARD AILERON SERVO CONTROL (ALLIED SIGNAL)	27-30-31
FR	95-146-014(B)R1	AFT TRACK ATTACHMENT TRACK 2-5 FLAP HYDRAULIC FIRE SHUTOFF VALVE WESTLAND	57-3028
FR	95-149-015(B)	FIGHT CONTROLS - SPOTLER SERVE CONTROLS	29-3018
FR	95-176-017(B)R2	FLIGHT CONTROLS - SPOILER SERVO CONTROLS NLG AFT DOORS	27-3034
FR	95-177-018(B)	SLIDE/SLIDES RAFT PACKBOARD	52-3016, -3035
FR	95-187-020(B)	SLIDE/SLIDES RAFT PACKBOARD LANDING GEAR FREEFALL ACTUATORS	25-3030 32-3042
FR	1996-184-036(B)R2	ICE PROTECTION - WING ANTI ICE VALVE	A330-30-3020
FR	96-038-027(B)R1	AILERON SERVO CONTROLS (ALLIED SIGNAL/MOOG)	27-3032
FR	96-056-029(B)	CENTRE FUSELAGE - CENTRE LINE PANEL/STRUCTURE	53-3019, -3020
FR	96-106-030(B)	AFI CARGO COMPARTMENT DOOR	52-3023 -3024
FR	96-174-034(B)R1	FUEL DISTRIBUTION - ENGINE PYLONS SHROUD LINE	28-3045
FR	97-064-044(B)R3		AOT 27-22
FR	97-178-051(B)	AIR CONDITIONING PACK CNTRL RAM AIR OUTLET DUCT	21-3058 -2059
FR			57-3047 -2049
FR	97-204-053(B)	REINFORCE THE DOUBLER FOR THE OUTELOW VALVE(313HL)	52-2004
FR	97-266-057(B)	ELECT PWR SUPPLY (6GF) SEGREGATION OF FREE FALL REAR FUSELAGE - FRAME 73A INSPECTION	32-3048
FR	97-270-055(B)	REAR FUSELAGE - FRAME 73A INSPECTION	53-3036
FR	97-361-058(B)R2	MLG - SHORTENING MECH BELLCRANK NUT LOCKING BOLTS	32-3056
FR FR	1998-100-067(B)R2	YAW DAMPER ACTUATOR ON ACTIVE POSITION	27-2055
FR	1998~192-071(B)R1	INSP FOR CRACKS BELOW VHF2 ANTENNA FRAMES 54 & 55	53-3094 REV 2
FR	1998-473-083(B)R2 1998-540-089(B)R1	MAIN LANDING GEAR	A330-32-3091
FR	98-022-062(B)R1	MAIN LANDING GEAR REPLACEMENT OF AFT CASCADE SUPPORTS WING BLEED LEAK DETECTION	PW4G-100-A78-67
FR	98-023-063(B)	WING BLEED LEAK DETECTION	A330-36-3012
FR	98-024-064(B)	CNTR FUS FITTED WITH TYPE "A" EMERGENCY EXIT DOOR	53-3039 REV 1
FR	98-098-065(B)	REINFORCEMENT OF KEEL ANGLE OF FRNT SPAR FRAME 40 REINFORCE DOOR FRAMES TYPE A EMERGENCY EXIT DOORS	57-3046
FR	98-099-066(B)	FUEL DENSITOMETERS - ATA 28	
FR	98-101-068(B)	DOORRAME MODIFY DOOR STOP FITTING PASS FRNT DOOR	28-3044 REV 1
FR	98-124-069(B)	INTRODUCE NEW FLT CNTRL FCPC & FCSC STND M11	53-3044
FR	98-291-074(B)	REINFORCE FRAME 65 BETWEEN STRINGER 22A & 22X	27-3056, -3057 53-3058 REV 2
FR	1999-144-094(B)R1	RAM AIR TURBINE - SUNDSTRAND	
	1999-178-086(B)		A330-29-3057R1 A330 25 3086
FR	1999-331-098(B)	NOSE GEAR AFT DOORS	A330 25 3086 A330-52-3055
FR	1999-350-100(B)R1	MAIN LANDING GEAR PIVOT PIN DEDI ACEMENT	1220 20 200001
FR	1999-406-103(B)	HYD BRACKET FATIGUE GREEN RESIVOIR	A330-53-3088R3
FR	1999-442-104(B)	HYD BRACKET FATIGUE GREEN RESIVOIR PAX CREW DOOR FRAME LINING REINFORCEMENT OF FRAME 40	A330-25-3096R1
FR	1999-449-105(B)		A330-53-3093
FR	1999-508-106(B)	INSPECTION LOWER SECTIONS FRAME 48 TO 53.2	A330-53-3067R2
1220	342 ( A		
A330 3	1005-074 005/D	330 SERIES )	
FR	95-181-019(B)R1	THOMSON LOW RANGE RADIO ALTIMETER (LRRA)	AOT 34-02
FR	1997-118-047(B)R1	FLIGHT IN ICING	A330-73-3006
FR	1998-473-083(B)R2	THRUST REVERSER OPENING MECH. RR TRENT 700	A330-78-3006
FR	1999-350-100(B)R1	MAIN LANDING GEAR DIVOT DIN DERLA GEARANT	A330-32-3091
FR	1999-406-103(B)	MAIN LANDING GEAR PIVOT PIN REPLACEMENT	A330-32-3096R1
FR	1999-442-104(B)	HYD BRACKET FATIGUE GREEN RESIVOIR PAX CREW DOOR FRAME LINING	A330-53-3088R3
FR	1999-449-105(B)	REINFORCEMENT OF FRAME 40	A330-25-3096R1
FR	1999-508-106(B)	INSPECTION LOWER SECTIONS FRAME 48 TO 53.2	A330-53-3093
		THE COURT SECTIONS PRAINE 48 TO 53.2	A330-53-3067R2
A330 3		330 SERIES )	
FR	1997-118-047(B)R1	THRUST REVERSER OPENING MECH. RR TRENT 700	1220-78-2000
FR	1998-473-083(B)R2	MAIN LANDING GEAR	A330-78-3006 A330-32-3091
FR	1999-350-100(B)R1	MAIN LANDING GEAR PIVOT PIN REPLACEMENT	A330-32-3091 A330-32-3096R1
FR	1999-442-104(B)	PAX CREW DOOR FRAME LINING	A330-25-3096R1
FR	1999-508-106(B)	INCOCCTION LOUIS CECT	A330-53-3067R2

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

		30027	BULLETIN DE SERVICE DE REF.
AIRBUS			
1	SERIES		
FR	1997-267-072(B)R1	LIFE LIMITS	
FR	97-087-056(B)	BRAKING SYSTEM	AMM CHAPTER 05 R6
FR	97-156-063(B)R1	RADIO ALTIMETER	A340-32-4087
FR	97-180-066(B)	ATP CONDITIONING DACK ONTO, DAMA ATP CUT-	A340-92-4024
FR	97-181-067(B)	AIR CONDITIONING PACK CNTRL RAM AIR OUTLET DUCT	21-4073, -4074
FR	97-182-070(B)R3	FWD FLAP TRACK ATTACH (3 THRU 5) OF INBD/OTBD FLAP	57-4051, -4052
FR	97-387-077(B)	INSTALLATION OF SW GUARDS FOR EDP SW PUSH BUTTONS	
FR	1998-265-093(B)R4	ATA 24 - TRANSFO-RECTIFIERS (TR) (AUXILEC)	24-4026
FR	1998-475-103(B)R2	ALTERNATE BRAKING SYSTEM CHECK MAIN LANDING GEAR	A340-32-4122R1
FR	1998-506-104(B)R1		A340-32-4047
FR	1998-543-105(B)R2	EMERGENCY BRAKING	A340-32-4117R2
FR	98-133-087(B)	THRUST REVERSER PIVOTING DOOR ROLLER FITTING	A340-78-4017
FR	98-153-088(B)	ENG FIRE & OVERHEAT DETECT FOOLPROOFING CONNECT	26-4022
FR	98-353-094(B)	CENTER LANDING GEAR - GEAR GLAND NUT	32~4083
FR	98-456-097(B)	MLG - OUTBOARD BRAKE ROD ATTACHMENT PIN	A340-32-4120
FR	98-485-101(B)	ALLIED SIGNAL INSTRUMENT LANDING SYSTEM RECEIVERS	
FR	98-508-106(B)	MID AND AFT PASSENGER/CREW DOOR EMEG EXIT	A340-52-4061
		DOOR ACTUATOR STRIKER MECHANISM	A340-52-4059
FR	98-541-109(B)	ELEVATOR SERVOCONTROLS	
FR	98-542-108(B)	MID AND AFT DOOR STAY MECHANISM	A340-52-4062
FR	1999-047-110(B)R1	SLIDING TABLE / COCKPIT FOOTREST	A340-25-4131
FR	1999-110-112(B)	ABSC BRAKES	A340-32-4129
FR	1999-143-114(B)	FLIGHT CONTROL UNIT	A340-22-4020
FR	1999-145-115(B)	RAM AIR TURBINE - SUNDSTRAND	A340-29-4052 R1
FR	1999-146-116(B)	CENTER LANDING GEAR ATTACHMENT FITTINGS	A340-53-4094/4109 R1
FR	1999-179-107(B)	INSP SLIDE PARACHUTE PIN RELEASE INSTALLATION	A340-25-4115
FR	1999-299-120(B)	TRIMMABLE HORIZONTAL STABILIZER ACTUATOR	A340-27A4077R1
FR	1999-355-123(B)	LITTON GPSSU	A340-34-4089
A340 3		O SERIES )	
FR	94-282-013(B)R3	RAM AIR TURBINE	29-4015
FR	95-072-017(B)R2	ENG BLEED AIR SYS PRE-COOLER FAN AIR DUCT	36-4010, 54-4004
FR	95-081-018(B)R3	FLT MANUAL ENG INCORRECT N1 LIMIT SETTING	AOT-73-02
FR	95-125-023(B)	FLAP (LH/RH) GUIDE BUSHES	57-4031, -4032
FR	95-130-024(B)	(LH/RH) SPHERICAL WASHERS	57-4033
FR	95-147-026(B)	FLT CNTRL - SPOILER SERVO CNTRLS LH/RH	27-4041
FR	95-148-027(B)R1	HYD FIRE SHUT-OFF VALVE	AOT 29-15
FR	95-161-028(B)R5	FLAP TRACK FAIRING	57-4041
FR	95-178-029(B)R2	NOSE LANDING GEAR AFT DOORS	ADT 52-10, 52-4023
FR	95-179-030(B)	SLIDE/SLIDE RAFT PACKBOARDS	ADT 25-10, 25-4046
FR	95-189-032(B)	LDG FREE FALL ACTUATOR	32-4066
FR	95-241-033(B)R2	WATER SERVICE DOOR (164 AR)	52-4042
FR	95-255-036(B)	THRUST REVERSERS LOCKING (CFM56-5C ENG)	78-4010
FR	95-272-038(B)R1	LOW RANGE RADIO ALTIMETER	A340-34-4013
FR	96-014-040(B)R2	MAIN LDG - SHORTENING MECH - AJUSTABLE LINK	ADT 32-12, -32-4076
FR	96-039-041(B)R1	AILERON SERVO CONTROLS (ALLIED SIGNAL/MOOG)	27-4039
FR	96-105-043(B)R1	CENTER FUSELAGE - VERTICAL BEAM Y=O AT FR 53-2	53-4043
FR	96-107-044(B)	AFT CARGO COMPARTMENT DOOR	52-4031, -4032
FR	96-133-045(B)R2	LDG GEAR FREE FALL EXTENSION ELECT CIRCUIT	32-4072
FR	96-160-046(B)R1	MAIN LANDING GEAR - SHORTENING MECHISM - BELLCRANK	
FR	96-178-049(B)	THS LIGHTNING PROTECTION IMPROVEMENT	AOT55-03,SB -55-4017
FR	1997-363-076(B)R3	ATA 32 CLG INSPECTION OF THE CLG RH INBOARD LUG	32-4091, -4097
FR	97-005-054(B)	CARGO DOOR FRAMEWORK	A340-53-4063
FR	97-008-058(B)R1	MAIN LANDING GEAR	32-4082, -32-4092
FR	97-018-059(B)R2	ELECTRIC HYDRAULIC PUMPS	AOT 29-21R1
FR	97-065-055(B)R3		AOT 27-23
FR	97-103-057(B)R1	ENG BLEED AIR SYS THRUST REVERSER PRECOOLER SCOOP	
FR	97-103-057(B)R1	CENTER LANDING GEAR DOOR HINGE PINS	53-4070, -4031
FR	97-114-060(B) 97-166-065(B)	ENGINES CFM 56-5C - INSTALLATION OF (ECUS) FADEC	73-4012
		REINFORCE THE DOUBLER FOR THE OUTFLOW VALVE(313HL)	53-4096
FR	97-205-069(B)	ELECT PWR SUPPLY (6GF) SEGREGATION FREE FALL EXT	32-4072
FR	97-268-073(B)		53-4050
FR	97-271-071(B)	REAR FUSELAGE - FRAME 73A INSPECTION INSP FOR CRACKS BELOW VHF2 ANTENNA FRAMES 54 & 55	53-4050 53-4105 REV 2
FR	1998-193-089(B)R1		A340-78-4012
FR	1998-355-095(B)R1	THRUST REVERSER LOCKING	
FR	98-026-079(B)		53-4053 REV 1
FR	98-027-080(B)		57-4058
FR	98-102-081(B)	REINFORCE DOORFRAME FOR TYPE A EMERGENCY EXIT DOOR	
FR	98-103-082(B)	FUEL DENSITOMETERS	28-4069
FR	98-104-083(B)	YAW DAMPER ACTUATOR ON ACTIVE POSITION	27-4063
FR	98-105-084(B)	DOORFRAMES MOD DOOR STOP FITTING PASS FRNT DOOR	53-4059
FR	98-126-085(B)	INTRODUCE NEW FLT CNTRL FCPC & FCSC STND L14 .	27-4061, -4064
FR	98-270-091(B)R1	MAIN LANDING GEAR - DOORS	52-4060
FR	98-295-092(B)	MLG SHORTENING MECH REPLACE BELLCRANK NUT BOLTS	32-4080 REV 2
FR	1999-045-111(B)R4	FUEL TRIM TRANSFER LINE	A340-28A4077 R2

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
AIRBUS				
A340 3		( A3	40 SERIES )	
	NUED / SUITE)			
FR	1999-241-113(B)		CENTER REAR LANDING GEAR DOORS FWD HINGE INSP	A340-52-4065R1
FR	1999-265-117(B)		THRUST REVERSER LOCKING	A340-78-4012R5
FR	1999-330-119(B)		NOSE GEAR AFT DOORS	A340-52-4068
FR	1999-351-122(B)		MAIN LANDING GEAR PIVOT PIN	A340-32-4135R1
FR	1999-407-124(B)		HYD BRACKET FATIGUE GREEN RESIVOIR	A340-53-4100R3
FR	1999-441-125(B)		PAX CREW DOOR FRAME LINING	A340-25-4125R1
FR	1999-448-126(B)		REINFORCEMENT OF FRAME 40	A340-53-4104R2
FR	1999-503-127(B)		FUSELAGE-REINFORCEMENT OF FRAME 48 TO 53.2 JOINT	
FR FR	1999-504-128(B)		WINGS TRAILING FLAP-TOP SKIN BOLTING-ATA 57	A340-57-4006R1
FR	1999-528-130(B) 1999-529-131(B)		CENTER FUSELAGE- LOWER KEELBEAM FITTING	A340-57-4036R5
FR	2000-016-133(B)		INSP LWR SECT OF FRAME 48 TO 53.2 STRINGER PASSAGE CFM 56-5C ENGINES-INSP.OF EXHAUST CENTERBODY	
	2000 010 133(B)		CIN 36 3C ENGINES INSP. OF EXHAUST CENTERBODY	AUT A340-78A4019
ALON				
A2				
US	94-18-04R1		WING STRUCTURE	29 REV B
				23 //2 / 5
A2A				
US	94-18-04R1		WING STRUCTURE	29 REV B
AMERICA				
AA 1 S				
US	70-05-05		EXHAUST SYSTEM	116
us	70-25-05		TRIM ACTUATOR	69-1A
US	72-06-02		CONTROL CABLES	
US	72-07-10		LOOSE RIVETS	
US	73-13-07		AIRPLANE SPINS	
US US	75-07-04 75-09-07		RUDDER CONTROL BAR ASSEMBLIES	
US	76-17-03		MIXTURE CONTROL	
US	78-13-04		DELAMINATIONS IN BONDED SKINS	
03	70 10 04		FUEL MEASUREMENT GAUGE	
AA 1		( ΔΔ	1 SERIES )	
US	71-04-03	, ~~	NOSE GEAR STRUT	121A
			MOSE SEAR STROT	IZIA
AA 1A		( AA	1 SERIES )	
				***************************************
AA 1B		( AA	1 SERIES )	
44 40				
AA 1C		( AA	1 SERIES )	
AA 5 S	FDIES			
US	89-18-08		FUEL SYSTEM & COMPONENTS	470 00
	95-19-15			176, 22
	.33 13 13		WING BOLTS	SB-185
AA 5		( AA	5 SERIES )	
US	72-06-02	, ,,,,,	CONTROL CABLES	
US	75-07-04		RUDDER CONTROL BAR ASSEMBLIES	
US	77-07-04		CARB HEAT VALVE ASSY	
US	79-22-04		AILERON SYSTEM	
US	81-24-03		ENGINE POWER LOSS PREVENTION	
AA 5A		( AA	5 SERIES )	
US	76-01-02		ENGINE COWL	
US	76-17-03		DELAMINATIONS IN BONDED SKIN	
US	76-22-09		OIL COOLERS	
US	77-07-04		CARBURETOR HEAT VALVE ASSY	
US	77-08-03		· STATIC SYSTEM	
US	79-22-04		AILERON SYSTEM	
US	81-24-03		ENGINE POWER LOSS PREVENTION	
AA ED			F (FD) (F)	
AA 5B		( AA	5 SERIES )	
US US	75-07-04		RUDDER CONTROL BAR ASSEMBLIES	
US	76-01-02 76-04-05		ENGINE COWL	
US	76-04-05		CARBURETOR MIXTURE CONTROL WIRE	
US	76-17-03		DELAMINATIONS IN BONDED SKIN	
US	77-08-03		OIL COOLERS	
US	79-22-04		STATIC SYSTEM AILERON SYSTEM	***************************************
US	81-24-03		ENGINE POWER LOSS PREVENTION	
			The state of the s	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

ANSON			
CF	CF-50-04	CHOOK CTOUT	
CF	CF-50-05	SHOCK STRUT ATTACHMENT BRACKET, SASKATCHEWAN GOV	SGA 35-1,35-2
CF	CF-51-07	VERTICAL FIN POST - GLUE JOINT	
UK	1496 PRE 80	WING - GLUE JOINTS	
UK	1497 PRE 80	TAILPLANE WIRE BRACING	108
UK	1498 PRE 80	GUARD RUDDER BAR TORQUE TUBES PETROL TRAP BOOST GAUGE LINES	. 121
UK	1499 PRE 80	AILERON HINGE	122
UK	1500 PRE 80	PILOT'S EMERGENCY EXIT	173
UK	1501 PRE 80	FLAP HYDRAULIC CIRCUIT	265 289
UK	1502 PRE 80	OIL TANK COCK AND THERMOMETER POCKET	308
UK	1503 PRE 80	TAILWHEEL ROCKER BEAM	654
UK	1504 PRE 80	STRENGTHENED WING	661
UK	1505 PRE 80	ENGINE FIRE WARNING	669
UK	1506 PRE 80	WHEELS, TYRES AND BRAKES	687
UK	1507 PRE 80	MAINPLANE SPARS	695
UK	1508 PRE 80	REAR SEAT ATTACHMENT	709
UK	1509 PRE 80 1510 PRE 80	DRAINAGE IMPROVEMENTS	716
UK	1511 PRE 80	ACCUMULATORS CHARGING PRESSURE	725
UK	1512 PRE 80	PASSENGER SEAT	732
UK	1513 PRE 80	'PRESS TO SPEAK' SWITCH AGS COUPLINGS	744
UK	1514 PRE 80	OIL COOLER SUPPORT CLIP	750
UK	1515 PRE 80	MAIN UNDERCARRIAGE	759 762
UK	1516 PRE 80	CANCEL MOD. NO.733	773
UK	1517 PRE 80	UNDERCARRIAGE RETRACTION CONTROL	775
UK	1518 PRE 80	COMPASS	777
UK	1519 PRE 80	COWL FASTENERS	782
UK	1520 PRE 80	FEATHERING FEED PIPE	795
UK	1521 PRE 80	MAIN OLEO LEG	797
UK	1522 PRE 80	OIL COOLER SUPPORT CLIP	825
UK	1523 PRE 80	PORT AND STARBOARD BULKHEADS	844
UK	1524 PRE 80	BULIS FURK TO THE BRAKE FLANGE	873
UK	1525 PRE 80	OIL COOLER SUPPORT BRACKET	899
UK	1526 PRE 80	ASHTRAYS	CIVIL MOD. 9
UK	1527 PRE 80	LABELS TO MEET ARB REQUIREMENTS	CIVIL MOD. 32
UK	1528 PRE 80	AILERON CABLE / VOLTAGE REGULATOR LEADS CONSTANT SPEED TRAILING AERIAL WINCH	CIVIL MOD. 33
UK	1529 PRE 80 1530 PRE 80	FORWARD CABIN ESCAPE HATCH	CIVIL MOD. 49 CIVIL MOD. 53
UK	1531 PRE 80	CABIN ESCAPE HATCH	CIVIL MOD. 56
UK	1532 PRE 80	SPAR BOOM JOINTS	NOS.76,80 & 88
UK	1533 PRE 80	TRAILING FOGE RIBS	T.S.B. NO.84
UK	1534 PRE 80	TOP SUPPORT BRACKETS UNDERCARRIAGE JACK CHANNELS	T.S.B. NO.85
UK	1535 PRE 80	AILERON OPERATING LEVERS	T.S.B. NO.87
UK	1536 PRE 80	MAIN UNDERCARRIAGE RADIUS ROD	NO.89 & NO.90
UK	1537 PRE 80	LOCKING HANDLE, 2ND PILOT'S CONTROL COLUMN	T.S.B. NO.91
UK	1538 PRE 80	PILOTS' ESCAPE HATCH	T.S.B. NO.92
UK	1539 PRE 80	WINGS WOODSCREWS	MOD. NO.695
V8 MOI	AIRCRAFT DEL F		
10 1.10			
	ON TRADERS		
ATL 98	3 CARVAIR		
AVIONAL	JTICA		
M100S			
ΙT	61-9/M100S-1	RUDDER	
IT	62-10/M100S-2	FUSELAGE - RIB # 7	
IT	62-43/M100S-3	TAIL SKID & KEEL STRIP	
ΙT	65-9/M100S-4	STRUCTURAL IMPROVEMENT - WING & FUSELAGE	0/14 1005
ΙŢ	67-15/M100S-6	PLACARD - WINCH LAUNCHING	9/M. 100S
ΙT	69-132/M.100S-8	ELEVATOR CONTROL SYSTEM	10/M.100S 8/M.100S REV A
IT	69-132/M.100S-8 69-62/M.100S-5R1 69-78/M.100S-7	AILERON INNER END PLYWOOD COVERING	5/M. 1005 KEV A
IT	69-78/M. 100S-7	AILERON SPAR	
ΙŢ	70-96/M. 1005-9	LOWER RUDDER HINGE PIVOT LOWER RUDDER HINGE PIN	11/M 100S
IT	71-56/M.100S-10	LOWER RODUCK HINGE FIN	17,111,1003
AYRES			
S2R SE	RIES	SEE/VOIR: AERO COMMANDER	₹
COD		R SERIES ) SEE/VOIR: AERO COMMANDER	
S2R	( 52)	A JERIES / SEL/ VOIR. MERO COMMANDER	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)

ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET			REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
S2R R	1340	( S2R SERIES )	SEE/VOIR:	AERO COMMANDE	R
S2R T	34	( S2R SERIES )	SEE/VOIR:	AERO COMMANDE	R
		( JEN JENIES )	022, 002		
FIREFI	WORKS Y 6				
US US	75-12-08 75-17-36	REGO TRIGGER VALVES REGO BURNER VALVE			
US	81-05-03	FUEL TANK SHUT-OFF V	ALVE		
FIREFL	Y 6B				
US	75-12-08	REGO TRIGGER VALVES			
US	75-17-36 81-05-03	REGO BURNER VALVE FUEL TANK SHUT-OFF VA	ALVE		
FIREFL					
US	75-12-08	REGO TRIGGER VALVES			
US	75-17-36 81-05-03	REGO BURNER VALVE FUEL TANK SHUT-OFF VA	ALVE		
		FOLL FARR SHOT SET V			
FIREFL US	75-12-08	REGO TRIGGER VALVES			
US	81-05-03 84-04-03	FUEL TANK SHUT-OFF VA	ALVE		
0.5	84-04-03	ENVELOPE JUMPER CORD			B20
FIREFL	. <b>Y 8</b> 75-12-08	REGO TRIGGER VALVES			
		MEGO INTOGEN VALVES			
	. <b>Y 8 24</b> 75-12-08	REGO TRIGGER VALVES			
US	81-05-03	FUEL TANK SHUT-OFF VA	ALVE		
FIREFL					
US	75-12-08	REGO TRIGGER VALVES			
FIREFL					
05	75-12-08	REGO TRIGGER VALVES			
FIREFL	Y 10 75-12-08	REGO TRIGGER VALVES			
		NEGO INIGGER VALVES			
FIREFL	Y 11B				
BEAGLE A61	AUSTER				
UK	2488 PRE 80	TAILPLANE FRONT ATTAC			
UK UK	2489 PRE 80 2490 PRE 80	TAILPLANE ATTACHMENT RUDDER CONTROL CABLES			50
UK	2491 PRE 80	ENGINE MOUNTING ATTAC	CHMENT BOLTS		NO.A9 & NO.54
UK UK	2492 PRE 80 015-11-80	TOXIC TYPE FIRE EXTIN	IGUISHERS		NO.A14 & NO.58 NO.RFS/AUS/3
ВЕЕСН		The state of the s			1.0.10 3/ A03/ 3
3N					
CF US	CF-70-01 72-16-02R3	WING REINFORCEMENT MO VOLPAR NOSE GEAR FORK			DWG 18-5011
US	72-25-06	NOSE GEAR EXTENSION			
US US	75-27-09R2 77-19-07	WING STRUCTURE CONTROL COLUMN ASSEMB	U V		
US	78-10-01	LOWER RUDDER TORQUE T			
3NM					
CF US	CF-70-01	WING REINFORCEMENT MO			DWG 18-5011
US	72-16-02R3 72-25-06	VOLPAR NOSE GEAR FORK NOSE GEAR EXTENSION			
US US	75-27-09R2 77-19-07	WING STRUCTURE CONTROL COLUMN ASSEMB	U V		
US	78-10-01	LOWER RUDDER TORQUE T			
зт					
CF CF	CF-70-01 CF-70-02	WING REINFORCEMENT MO	D BRISTOL 2227		DWG 18-5011
US	75-27-09R2	MAXIMUM A.U.W. WING STRUCTURE			
US	77-19-07	CONTROL COLUMN ASSEMB	LY		SI 0889-155
ATRCR	AFT/AFRONESS				

MAKE / CONSTRUCTEUR
MODEL / MODELE

DOEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
DEFOU			
BEECH 3TM			
CF	CF-70-01	WING DEINEDDOCMENT AND	
US	72-16-02R3	WING REINFORCEMENT MOD BRISTOL 2227 VOLPAR NOSE GEAR FORK	DWG 18-5011
US	72-25-06	NOSE GEAR EXTENSION	
US	75-27-09R2	WING STRUCTURE	
US	77-19-07	CONTROL COLUMN ASSEMBLY	
US	78-10-01	LOWER RUDDER TORQUE TUBE	
D17S			
US	48-51-01	CONTROL WHEEL CHAFT INCREATION	
US	99-05-13	CONTROL WHEEL SHAFT INSPECTION FUEL SELECTOR-INCORRECT POSITIONING	
		THE SECTION THOUNKEST FUSTITUNING	
SC17R			
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	i i
SD17S			
US	99-05-13	FILE SELECTOR-INCORDECT POSTTIONING	
	33 03 13	FUEL SELECTOR-INCORRECT POSITIONING	
18 SEF	RIES		
CF	CF-81-12	WING LOWER SPAR	
C18S	OF 60 60	( 18 SERIES )	
CF CF	CF-63-08 CF-65-01	FLOAT TUBES MEMBERS -36 & -37	112-1
US	47-06-08	EDO FRONT FLOAT STRUTS STARTER SOLENOID AND BUSS LEAD WIRE	BRISTOL 14518
US	47-06-09	LANDING GEAR RETRACTING MECHANISM	
US	47-33-03	TAIL CONE DRAIN HOLES	
US	47-33-04	FUEL TANK GASKETS	
US	47-33-05	HORIZONTAL STABILIZER SPAR	
US	48-14-03	WING CENTER SECTION SPAR	
US US	48-34-01 48-51-01	STABILIZER ATTACHMENT FITTINGS	
US	49-15-03	CONTROL WHEEL SHAFT INSPECTION FUEL TANK VENT SYSTEM	
US	65-03-01	GAP SEAL STRIPS	
US	75-27-09R2	WING STRUCTURE	
US	77-19-07	CONTROL COLUMN ASSEMBLY	
0400		( to center )	
D18S CF	CE-62-09	( 18 SERIES )	112-1
CF	CF-63-08 CF-65-01	FLOAT TUBES MEMBERS -36 & -37 EDO FRONT FLOAT STRUTS	BRISTOL 14518
US	47-33-05	HORIZONTAL STABILIZER SPAR	D.(1310L 14310
US	47-33-06	STABILIZER SPAR REPLACEMENT	
US	47-33-07	ALTERNATE STATIC SOURCE	
US	47-34-01	EXPANSION TYPE FILLER CAP	
US US	47-34-02	TAIL CONE DRAIN HOLES	
US	47-34-03 48-13-01	FUEL CELL SEAL  GENERATOR CONTROL BOX INSULATION	
US	48-34-01	STABILIZER ATTACHMENT FITTINGS	
US	49-29-02	RUDDER SPRING BUSHINGS	
US	59-18-02	FUEL LINE MODIFICATION	
US	65-03-01	GAP SEAL STRIPS	
US	66-30-01	STATIC PRESSURE LINE VOLPAR TRI-GEAR	
US US	68-23-06 72-16-02R3	VOLPAR TRI-GEAR VOLPAR NOSE GEAR FORK	
US	72-16-02R3 72-25-06	NOSE GEAR EXTENSION	
US	75-27-09R2	WING STRUCTURE	
US	77-19-07	CONTROL COLUMN ASSEMBLY	
US	78-10-01	LOWER RUDDER TORQUE TUBE	
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
E 4 D C		( 10 CEDIEC )	
E18S		( 18 SERIES ) TAIL WHEEL AXLE	
US	56-20-01 65-03-01	( 18 SERIES ) TAIL WHEEL AXLE GAP SEAL STRIPS	
	56-20-01	TAIL WHEEL AXLE	
US US	56-20-01 65-03-01	TAIL WHEEL AXLE  GAP SEAL STRIPS  STATIC PRESSURE LINE  VOLPAR TRI-GEAR	
US US US US	56-20-01 65-03-01 66-30-01 68-23-06 72-16-02R3	TAIL WHEEL AXLE  GAP SEAL STRIPS  STATIC PRESSURE LINE  VOLPAR TRI-GEAR  VOLPAR NOSE GEAR FORK	
US US US US US	56-20-01 65-03-01 66-30-01 68-23-06 72-16-02R3 72-25-06	TAIL WHEEL AXLE  GAP SEAL STRIPS  STATIC PRESSURE LINE  VOLPAR TRI-GEAR  VOLPAR NOSE GEAR FORK  NOSE GEAR EXTENSION	
US US US US US US	56-20-01 65-03-01 66-30-01 68-23-06 72-16-02R3 72-25-06 75-27-09R2	TAIL WHEEL AXLE  GAP SEAL STRIPS  STATIC PRESSURE LINE  VOLPAR TRI-GEAR  VOLPAR NOSE GEAR FORK  NOSE GEAR EXTENSION  WING STRUCTURE	
US US US US US US US	56-20-01 65-03-01 66-30-01 68-23-06 72-16-02R3 72-25-06 75-27-09R2 77-19-07	TAIL WHEEL AXLE  GAP SEAL STRIPS  STATIC PRESSURE LINE  VOLPAR TRI-GEAR  VOLPAR NOSE GEAR FORK  NOSE GEAR EXTENSION  WING STRUCTURE  CONTROL COLUMN ASSEMBLY	
US US US US US US US US	56-20-01 65-03-01 66-30-01 68-23-06 72-16-02R3 72-25-06 75-27-09R2	TAIL WHEEL AXLE  GAP SEAL STRIPS  STATIC PRESSURE LINE  VOLPAR TRI-GEAR  VOLPAR NOSE GEAR FORK  NOSE GEAR EXTENSION  WING STRUCTURE	
US US US US US US US	56-20-01 65-03-01 66-30-01 68-23-06 72-16-02R3 72-25-06 75-27-09R2 77-19-07 78-10-01 99-05-13	TAIL WHEEL AXLE  GAP SEAL STRIPS STATIC PRESSURE LINE VOLPAR TRI-GEAR VOLPAR NOSE GEAR FORK NOSE GEAR EXTENSION WING STRUCTURE CONTROL COLUMN ASSEMBLY LOWER RUDDER TORQUE TUBE FUEL SELECTOR-INCORRECT POSITIONING	
US US US US US US US US	56-20-01 65-03-01 66-30-01 68-23-06 72-16-02R3 72-25-06 75-27-09R2 77-19-07 78-10-01	TAIL WHEEL AXLE  GAP SEAL STRIPS  STATIC PRESSURE LINE  VOLPAR TRI-GEAR  VOLPAR NOSE GEAR FORK  NOSE GEAR EXTENSION  WING STRUCTURE  CONTROL COLUMN ASSEMBLY  LOWER RUDDER TORQUE TUBE	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
BEECH			
G18S		( 18 SERIES )	
US	68-23-06	VOLPAR TRI-GEAR	
US	72-16-02R3	VOLPAR NOSE GEAR FORK	
US	72-25-06	NOSE GEAR EXTENSION	
US US	75-27-09R2	WING STRUCTURE	
US	77-19-07 78-10-01	CONTROL COLUMN ASSEMBLY	
US	99-05-13	LOWER RUDDER TORQUE TUBE FUEL SELECTOR-INCORRECT POSITIONING	
		TOLL SELECTOR INCORRECT POSTTIONING	
H18		( 18 SERIES )	
US	68-23-06	VOLPAR TRI-GEAR	
US US	72-16-02R3 72-25-06	VOLPAR NOSE GEAR FORK	
US	75-27-09R2	NOSE GEAR EXTENSION WING STRUCTURE	
US	77-19-07	CONTROL COLUMN ASSEMBLY	
US	78-10-01	LOWER RUDDER TORQUE TUBE	
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
19A			
US	70-15-03	FUEL SELECTOR VALVE	
US	71-25-03	FEUL AND DIL RESTRICTOR	SI 0470 044
US	73-12-11	CARBURETOR AIR BOX VALVE	SI 0473-241
US	73-20-07R2	WING ATTACH BOLTS / BRACKETS	
US US	73-23-03 73-23-06	FLEXIBLE INDUCTION AIR DUCTS	
US	74-23-09	THROTTLE CONTROL CABLE	
US	75-01-04	INFLIGHT SITUATIONS FUEL SELECTOR VALVE	
US	75-17-37	CARBURETOR MIXTURE AND / OR HEAT CONTROL	
US	76-25-05	AILERON CONTROL	
US	77-03-05	MAIN LANDING GEAR	
US US	78-04-01 85-05-02	WING FLAP CONTROL	
US	87-02-08	FUEL SELECTOR GUARD MOD	
US	89-24-09	FASTENERS - STABILATOR HINGE ASSEMBLY AILERON PUSH ROD	2182
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	2198
B19			
US	71-25-03	FUEL AND ON DECOMPOSE	
US	73-12-11	FUEL AND OIL RESTRICTOR CARBURETOR AIR BOX VALVE	
US	73-20-07R2	WING ATTACH BOLTS / BRACKETS	
US	73-23-03	FLEXIBLE INDUCTION AIR DUCTS	
US US	73-23-06	THROTTLE CONTROL CABLE	
US	73-25-04 74-05-01	MAXIMUM DESIGN WEIGHT PLACARD	
	74-14-02	RESTRICTED FUEL VENT TANK LINES CARBURETOR AND AIR CONTROLS	
US	74-14-05	PLACARD, SPINS	
US	75-01-04	FUEL SELECTOR VALVE	
	75-17-37	CARBURETOR MIXTURE AND / OR HEAT CONTROL	
	76-10-09 76-25-05	WING FLAPS	
	77-03-05	AILERON CONTROL MAIN LANDING GEAR	
	78-04-01	WING FLAP CONTROL	
	78-16-06	STRUCTURAL INTEGRITY OF TRIM TAB ROD	
	85-05-02	FUEL SELECTOR GUARD MOD	
	87-02-08	FASTENERS - STABILATOR HINGE ASSEMBLY	2182
	89-24-09 99-05-13	AILERON PUSH ROD	. 2198
		FUEL SELECTOR-INCORRECT POSITIONING	
23 SERI			
	89-24-09	AILERON PUSH ROD	2198
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	2.00
23		( 23 SERIES )	
US (	63-06-01	CABIN DOOR HINGE	
	64-06-01	CABIN HEATER / MUFFLER WELD ASSY	
	35-11-01	INSTRUMENT STATIC SYSTEM	
	65-19-02 68-17-06	AILERON CONTROL COLUMN LINKS	
	70-15-03	PARKING BRAKE	
	73-12-11	FUEL SELECTOR VALVE CARBURETOR AIR BOX VALVE	
US .	73-20-07R2	WING ATTACH BOLTS / BRACKETS	
	73-23-03	FLEXIBLE INDUCTION AIR DUCTS	
	73-23-06 74-23-09	THROTTLE CONTROL CABLE	
	7 20 09	INFLIGHT SITUATIONS	

MAKE / CONSTRUCTEUR

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) REFERENCE SERVICE BULLETIN BEECH 23 ( 23 SERIES ) (CONTINUED / SUITE) FUEL SELECTOR VALVE 75-01-04 115 115 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL 76-25-05 AILERON CONTROL 77-03-05 US MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 85-05-02 FUEL SELECTOR GUARD MOD 87-02-08 US FASTENERS - STABILATOR HINGE ASSEMBLY 2182 A23 ( 23 SERIES ) US 65-19-02 AILERON CONTROL COLUMN LINKS 68-17-06 US PARKING BRAKE US 70-15-03 FUEL SELECTOR VALVE 73-20-07R2 US WING ATTACH BOLTS / BRACKETS 73-23-03 US FLEXIBLE INDUCTION AIR DUCTS 75-01-04 115 FUEL SELECTOR VALVE CARBURETOR MIXTURE AND / OR HEAT CONTROL US 75-17-37 76-25-05 AILERON CONTROL 77-03-05 LIS MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL FUEL SELECTOR GUARD MOD US 85-05-02 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY A23 19 ( 23 SERIES ) 68-17-06 US PARKING BRAKE 70-15-03 FUEL SELECTOR VALVE CARBURETOR AIR BOX VALVE US 73-12-11 US 73-20-07R2 WING ATTACH BOLTS / BRACKETS 73-23-03 FLEXIBLE INDUCTION AIR DUCTS
THROTTLE CONTROL CABLE US 73-23-06 115 INFLIGHT SITUATIONS US 74-23-09 US 75-01-04 FUEL SELECTOR VALVE CARBURETOR MIXTURE AND / OR HEAT CONTROL 115 75-17-37 76-25-05 AILERON CONTROL 77-03-05 MAIN LANDING GEAR WING FLAP CONTROL 78-04-01 115 US 85-05-02 FUEL SELECTOR GUARD MOD FASTENERS - STABILATOR HINGE ASSEMBLY US 87-02-08 2182 A23 24 ( 23 SERIES ) US 68-17-06 PARKING BRAKE FUEL SELECTOR VALVE 70-15-03 115 US 71-25-03 FUEL AND OIL RESTRICTOR 73-20-07R2 US WING ATTACH BOLTS / BRACKETS 73-23-03 FLEXIBLE INDUCTION AIR DUCTS US 75-01-04 FUEL SELECTOR VALVE US CARBURETOR MIXTURE AND / OR HEAT CONTROL US 75-17-37 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US WING FLAP CONTROL US 78-04-01 FUEL SELECTOR GUARD MOD US 85-05-02 FASTENERS - STABILATOR HINGE ASSEMBLY 2182 87-02-08 US ELECTRIC FUEL BOOST PUMP US 88-10-01 ( 23 SERIES ) **A23A** 68-17-06 PARKING BRAKE US FUEL SELECTOR VALVE US 70-15-03 US 71-25-03 FUEL AND OIL RESTRICTOR WING ATTACH BOLTS / BRACKETS US 73-20-07R2

73-23-03 75-01-04

75-17-37

76-25-05 77-03-05

78-04-01 85-05-02

87-02-08

70-15-03

71-25-03

73-12-11

73-20-07R2

US

US

US

US

115

**B23** 

US

US

2182

CARBURETOR MIXTURE AND / OR HEAT CONTROL

FASTENERS - STABILATOR HINGE ASSEMBLY

FLEXIBLE INDUCTION AIR DUCTS

FUEL SELECTOR VALVE

WING FLAP CONTROL
FUEL SELECTOR GUARD MOD

CARBURETOR AIR BOX VALVE

WING ATTACH BOLTS / BRACKETS

AILERON CONTROL

( 23 SERIES )

MAIN LANDING GEAR

FUEL SELECTOR VALVE FUEL AND OIL RESTRICTOR

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUJET

C23	2182
B23	2182
CONTINUED	2182
US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS US 73-23-06 THROTTLE CONTROL CABLE US 74-23-09 INFLIGHT SITUATIONS US 75-01-04 FUEL SELECTOR VALVE US 75-01-05 AILERON CONTROL US 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  C23 (2 SERIES) US 73-12-11 CARBURETOR AIR BOX VALVE US 73-20-07072 WING ATTACH BOLTS / BRACKETS US 73-23-06 THROTTLE CONTROL CABLE US 74-05-01 RESTRICTOR AIR DUCTS US 74-14-02 CARBURETOR AIR DUCTS US 74-14-05 PLACARD, SPINS US 75-01-04 FUEL SELECTOR VALVE US 75-01-04 FUEL SELECTOR VALVE US 75-01-05 MAIN LANDING GEAR US 76-10-09 WING ATTACH BOLTS US 76-25-05 AILERON CONTROL US 78-04-01 WING FLAP US 78-04-01 WING FLAPS US 78-04-01 FUEL SELECTOR VALVE US 78-04-01 WING FLAPS US 88-10-01 ELECTRIC FUEL BOOST PUMP 24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 25 SELECTOR INCORRECT POSITIONING  A24R US 71-25-03 FUEL AND OIL RESTRICTOR	2182
US 73-23-06 THROTTLE CONTROL CABLE US 74-23-09 INFLIGHT SITUATIONS US 75-01-04 FUEL SELECTOR VALVE US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL US 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  C23 (23 SERIES) US 71-25-03 FUEL AND OIL RESTRICTOR US 73-12-11 CARBURETOR AIR BOX VALVE US 73-20-07R2 WING ATTACH BOLTS / BRACKETS US 73-23-06 FLEXIBLE INDUCTION AIR DUCTS US 73-23-06 THROTTLE CONTROL CABLE US 74-05-01 RESTRICTED FUEL TANK VENT LINES US 74-14-02 CARBURETOR AND AIR CONTROLS US 75-17-37 CARBURETOR WINDERTOR AND AIR CONTROLS US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL US 76-10-09 WING FLAPS US 76-25-05 AILERON CONTROL US 78-04-01 WING FLAPS US 78-04-01 WING FLAPS US 78-04-01 WING FLAPS US 88-10-00 FUEL SELECTOR FUEL TANK VENT LINES CARBURETOR MIXTURE AND / OR HEAT CONTROL US 78-04-01 WING FLAPS US 78-04-01 WING FLAPS US 88-10-00 FUEL SELECTOR FUEL TANK VENT ABROD US 85-05-02 FUEL SELECTOR FUEL TANK VENT ABROD US 88-05-00 FUEL SELECTOR FUEL SELECTOR FUEL SELECTOR WING FLAPS US 88-10-01 WING FLAP CONTROL US 88-10-01 WING FLAP CONTROL US 88-10-01 WING FLAP CONTROL US 88-10-01 FUEL SELECTOR FUEL BOOST PUMP 24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 25 SELECTOR FUEL AND OIL RESTRICTOR	2182
US   74-23-09	2182
US 75-01-04 FUEL SELECTOR VALVE  US 75-17-37 CABBURETOR MIXTURE AND / OR HEAT CONTROL  US 76-25-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  C23 (23 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR  US 73-12-11 CARBURETOR AIR BOX VALVE  US 73-20-07R2 WING ATTACH BOLTS / BRACKETS  US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS  US 73-23-06 THROTTLE CONTROL CABLE  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-14-05 PLACARD, SPINS  US 75-01-04 FUEL SELECTOR VALVE  US 75-01-04 FUEL SELECTOR VALVE  US 76-10-09 WING FLAPS  US 76-10-09 WING FLAPS  US 78-04-01 WING FLAP CONTROL  US 78-04-01 WING FLAPS  US 78-04-01 WING FLAP CONTROL  US 88-10-01 ELECTOR FUEL BOOST PUMP  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP  25 SELECTOR INCORRECT POSITIONING  A24R  US 71-25-03 FUEL SELECTOR INCORRECT POSITIONING  A24R  US 71-25-03 FUEL SELECTOR INCORRECT POSITIONING	2182
US 75-17-37	2182
US	2182
US 77-03-05	2182
US 78-04-01 WING FLAP CONTROL  US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  C23 (23 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR  US 73-12-11 CARBURETOR AIR BOX VALVE  US 73-20-007R2 WING ATTACH BOLTS / BRACKETS  US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS  US 73-23-06 THROTTLE CONTROL CABLE  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-14-02 CARBURETOR AND AIR CONTROLS  US 74-14-05 PLACARD, SPINS  US 75-01-04 FUEL SELECTOR VALVE  US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL  US 76-10-09 WING FLAPS  US 76-25-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 85-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP 2  US 99-05-13 FUEL AND OIL RESTRICTOR	2182
US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  C23 (23 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR  US 73-12-11 CARBURETOR AIR BOX VALVE  US 73-20-07R2 WING ATTACH BOLTS / BRACKETS  US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-14-02 CARBURETOR AND AIR CONTROLS  US 74-14-05 PLACARD, SPINS  US 75-01-04 FUEL SELECTOR VALVE  US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL  US 76-10-09 WING FLAPS  US 76-25-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 85-05-03 FUEL SELECTOR FURN HINGE ASSEMBLY  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP  2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R  (24 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR	2182
US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  C23 (23 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR  US 73-12-11 CARBURETOR AIR BOX VALVE  US 73-20-07R2 WING ATTACH BOLTS / BRACKETS  US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-14-02 CARBURETOR AND AIR CONTROLS  US 74-14-05 PLACARD, SPINS  US 75-01-04 FUEL SELECTOR VALVE  US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL  US 76-10-09 WING FLAPS  US 76-25-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 85-05-03 FUEL SELECTOR FURN HINGE ASSEMBLY  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP  2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R  (24 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR	2182
C23	2182
US 71-25-03	
US 71-25-03	
US 73-12-11 CARBURETOR AIR BOX VALVE US 73-20-07R2 WING ATTACH BOLTS / BRACKETS US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS  US 73-23-06 THROTTLE CONTROL CABLE US 74-05-01 RESTRICTED FUEL TANK VENT LINES US 74-14-05 PLACARD, SPINS US 75-01-04 FUEL SELECTOR VALVE US 75-17-37 CARBURETOR AND AIR CONTROLS US 76-10-09 WING FLAPS US 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  24 SERIES US 99-05-13 FUEL SALECTOR INCORRECT POSITIONING  A24R  (24 SERIES ) US 71-25-03 FUEL AND OIL RESTRICTOR	
US 73-20-07R2 US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS US 73-23-06 US 74-05-01 US 74-05-01 US 74-14-02 US 74-14-05 US 75-01-04 US 75-01-04 FUEL SELECTOR VALVE US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL US 76-10-09 US 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US 78-04-01 US 78-04-01 US 78-04-01 US 78-16-06 US 78-04-01 US 78-16-06 US 78-04-01 US 78-16-06 US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING A24R (24 SERIES) US 71-25-03 FUEL AND OIL RESTRICTOR	
US 73-23-03 FLEXIBLE INDUCTION AIR DUCTS  US 73-23-06 THROTTLE CONTROL CABLE  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-14-02 CARBURETOR AND AIR CONTROLS  US 74-14-05 PLACARD, SPINS  US 75-01-04 FUEL SELECTOR VALVE  US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL  US 76-10-09 WING FLAPS  US 76-025-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP 2  US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R  (24 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR	
US 73-23-06 THROTTLE CONTROL CABLE  US 74-05-01 RESTRICTED FUEL TANK VENT LINES  US 74-14-02 CARBURETOR AND AIR CONTROLS  US 75-01-04 FUEL SELECTOR VALVE  US 75-01-04 FUEL SELECTOR VALVE  US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL  WING FLAPS  US 76-10-09 WING FLAPS  US 76-25-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  24 SERIES  US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R  (24 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR	
US 74-05-01 RESTRICTED FUEL TANK VENT LINES US 74-14-02 CARBURETOR AND AIR CONTROLS US 75-01-04 PLACARD, SPINS US 75-01-04 FUEL SELECTOR VALVE US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL US 76-10-09 WING FLAPS US 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R (24 SERIES) US 71-25-03 FUEL AND OIL RESTRICTOR	
US 74-14-02 CARBURETOR AND AIR CONTROLS US 75-01-04 PLACARD, SPINS US 75-01-04 FUEL SELECTOR VALVE US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL US 76-10-09 WING FLAPS US 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R (24 SERIES) US 71-25-03 FUEL AND OIL RESTRICTOR	
US 74-14-05 PLACARD, SPINS  US 75-01-04 FUEL SELECTOR VALVE  US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL  US 76-10-09 WING FLAPS  US 76-25-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD  US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP  US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R  US 71-25-03 FUEL AND OIL RESTRICTOR	
US 75-01-04 US 75-17-37 US 76-10-09 US 76-10-09 US 76-25-05 US 76-25-05 US 78-04-01 US 78-04-01 US 78-16-06 US 85-05-02 US 87-02-08 US 87-02-08 US 88-10-01 US 88-10-01 US 99-05-13  A24R US 71-25-03  FUEL SELECTOR VALVE CARBURETOR MIXTURE AND / OR HEAT CONTROL US TRO-02-05  WING FLAP CONTROL STRUCTURAL INTEGRITY OF TRIM TAB ROD US 87-02-08  FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13  FUEL SELECTOR-INCORRECT POSITIONING  A24R US 71-25-03  FUEL AND OIL RESTRICTOR	
US 75-01-04 US 75-17-37 US 76-10-09 US 76-10-09 US 76-25-05 US 76-25-05 US 78-04-01 US 78-04-01 US 78-16-06 US 85-05-02 US 87-02-08 US 87-02-08 US 88-10-01 US 88-10-01 US 99-05-13  A24R US 71-25-03  FUEL SELECTOR VALVE CARBURETOR MIXTURE AND / OR HEAT CONTROL US TRO-02-05  WING FLAP CONTROL STRUCTURAL INTEGRITY OF TRIM TAB ROD US 87-02-08  FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13  FUEL SELECTOR-INCORRECT POSITIONING  A24R US 71-25-03  FUEL AND OIL RESTRICTOR	
US 76-10-09 WING FLAPS US 76-25-05 AILERON CONTROL US 77-03-05 MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R US 71-25-03 FUEL AND OIL RESTRICTOR	
US 76-25-05 AILERON CONTROL  US 77-03-05 MAIN LANDING GEAR  US 78-04-01 WING FLAP CONTROL  US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP 2  US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R (24 SERIES)  US 71-25-03 FUEL AND OIL RESTRICTOR	
US 77-03-05 MAIN LANDING GEAR US 78-04-01 WING FLAP CONTROL US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R (24 SERIES) US 71-25-03 FUEL AND OIL RESTRICTOR	
US 78-04-01 WING FLAP CONTROL US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R US 71-25-03 FUEL AND OIL RESTRICTOR	
US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD US 85-05-02 FUEL SELECTOR GUARD MOD US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R US 71-25-03 FUEL AND DIL RESTRICTOR	
US 85-05-02 FUEL SELECTOR GUARD MOD  US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP 2  US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R (24 SERIES )  US 71-25-03 FUEL AND OIL RESTRICTOR	
US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2  24 SERIES  US 88-10-01 ELECTRIC FUEL BOOST PUMP 2  US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R  US 71-25-03 FUEL AND DIL RESTRICTOR	
24 SERIES US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R US 71-25-03 FUEL AND DIL RESTRICTOR	
US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R (24 SERIES ) US 71-25-03 FUEL AND DIL RESTRICTOR	2182
US 88-10-01 ELECTRIC FUEL BOOST PUMP 2 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R (24 SERIES ) US 71-25-03 FUEL AND OIL RESTRICTOR	
US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING  A24R ( 24 SERIES ) US 71-25-03 FUEL AND OIL RESTRICTOR	
A24R ( 24 SERIES ) US 71-25-03 FUEL AND OIL RESTRICTOR	217
US 71-25-03 FUEL AND OIL RESTRICTOR	
US 71-25-03 FUEL AND OIL RESTRICTOR	
US 73-20-07R2 WING ATTACH BOLTS / BRACKETS	
US 75-01-04 FUEL SELECTOR VALVE	
US 75-17-37 CARBURETOR MIXTURE AND / OR HEAT CONTROL	
US 76-25-05 AILERON CONTROL	,
US 78-04-01 WING FLAP CONTROL US 85-05-02 FUEL SELECTOR GUARD MOD	
	2182
US 89-24-09 AILERON PUSH ROD 2	198
B24R ( 24 SERIES )	
· · · · · · · · · · · · · · · · · · ·	
***************************************	
US 78-04-01 WING FLAP CONTROL	
US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD	
US 85-05-02 FUEL SELECTOR GUARD MOD	
	182
US 89-24-09 AILERON PUSH ROD 2	198
(24 CERTES )	
C24R (24 SERIES)	
US 78-04-01 WING FLAP CONTROL	
US 78-16-06 STRUCTURAL INTEGRITY OF TRIM TAB ROD	
US 85-05-02 FUEL SELECTOR GUARD MOD	100
US 87-02-08 FASTENERS - STABILATOR HINGE ASSEMBLY 2	182
33 SERIES	
THE TOTAL PROPERTY OF THE PROP	
EARLY OF EOCK ROLLERS	
CHGINE OIL	
IIC 04-47-04	
115 03-04-03	200
LIC OF OA OO	399
CHARLE 11 WING CARRY-INROUGH PRAME 2	399 333R1 360

MAKE / CONSTRUCTEUR MODEL / MODELE

(SERIES / SERIE)

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN REECH 33 SERIES (CONTINUED / SUITE) 96-12-22 115 ENGINE DIL FILTER ADAPTERS ASSEMBLIES ATTACHED SKETCH CABIN DOOR HANDLE LOCKING LIS 97-14-15 2693 US 98-21-21 BOB FIELDS AEROACCESSORIES STC F33A ( 33 SERIES ) US 70-03-05 TURNING TYPE TAKEOFFS US 71-24-10 SECURITY OF CONTROL WHEEL US 89-05-02 MAGNESIUM ELEVATOR CONTROL FITTINGS 2242R1 F33C ( 33 SERIES ) TURNING TYPE TAKEOFFS US 70-03-05 LIS 71-24-10 SECURITY OF CONTROL WHEEL US 83-17-05 CHANGES TO AFM RE MANEUVERS 89-05-02 US MAGNESIUM ELEVATOR CONTROL FITTINGS 2242R1 115 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING F33A ( 33 SERIES ) US 71-24-10 SECURITY OF CONTROL WHEEL LANDING GEAR SHOCK STRUT PISTON LANDING GEAR SHOCK STRUT PISTON STROBE LIGHT SYSTEM US 73-14-03 US 74-03-02 74-24-03 "Y" TYPE SHOULDER HARNESS US 76-22-02 US 79-01-01 SCREWS IN CONTROL SYSTEM CO-PILOTS AND PASSENGERS SEAT
CABIN FIREWALL - MORTELL 931 SOUND DEADENER
PILOT & CO-PILOTS SEAT ATTACHMENTS 87-18-06R1 2175 88-20-01 2249 US 88-21-02 2010R1,2233 91-18-19 PILOT & CO-PILOT SHOULDER HARNESS 2394 91-20-08 US FRESH AIR BLOWER 2380 LORAN LATERAL DEVIATION 93-03-02 115 2496 US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING G33 ( 33 SERIES ) 76-03-05 HOUSING CABLE AND BATTERY RELAY US US 79-01-01 SCREWS IN CONTROL SYSTEM 35 SERIES TRAILING ANTENNA REWORK US 49-26-01 49-48-01 THOMPSON FUEL PUMP 115 51-14-01 FUEL BOOSTER PUMP REMOVAL US US 55-22-01 OIL OUTLET CHECK VALVE CONTROL WHEELS 62-08-03 69-18-01 FUEL SYSTEM MODIFICATION ENGINE FUEL INTERRUPTION US 72-11-02 LANDING GEAR UPLOCK ROLLERS 72-22-01 US 75-05-02 ENGINE OIL 115 WINDOW EMER EGRESS PROV US 84-09-01 MAGNESIUM ELEVATOR CONTROL FITTINGS 2242R1 US 89-05-02 VARIOUS EMPENNAGE INSPECTION
ENGINE OIL FILTER ADAPTERS ASSEMBLIES US 94-20-04 ATTACHED SKETCH 96-12-22 115 RUDDERVATOR DIFFERENTIAL TAIL CONTROL ROD ASSY US 97-06-11 BOB FIELDS AEROCESSORIES STC 98-21-21 UŞ FUEL SELECTOR-INCORRECT POSITIONING 99-05-13 US ( 35 SERIES ) 35 47-47-07 ENGINE IDENTIFICATION PLATE 115 FUEL LINE CHAFING US 47-47-08 US 48-08-01 STARTER REWORK AILERON CHAIN 115 49-04-01 EMERGENCY FUEL PUMP "O" RINGS US 49-31-01 FUEL SELECTOR VALVE REWORK 53-01-02 US CONTROL WHEELS 62-08-03 FUSELAGE MODIFICATION 63-25-01 FUEL SELECTOR VALVE WARNING LIGHT 72-18-01 US ENGINE LUBRICATION US 75-15-08 STABILIZER ATTACH FITTING US 76-05-04 AWD VNE RESTRICTION 98-13-02 ( 35 SERIES ) 35 33 62-08-03 CONTROL WHEELS US ALTERNATOR SUPPORT BRACKET US 65-14-01 TURNING TYPE TAKEOFFS US 70-03-05 ENGINE LUBRICATION 75-15-08 US

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE SUJECT

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
ВЕЕСН				
35 33		( 35	SERIES )	
	NED / SUITE)			
US US	91-17-01 93-24-03		ELEVATOR TRIM TAB ACTUATOR RUDDER SPAR	2399
US	95-04-03		CRACKS IN WING CARRY-THROUGH FRAME	2333R1 2360
1212111212				2300
35A33 US	62-08-03	( 35	SERIES )	
US	70-03-05		CONTROL WHEELS TURNING TYPE TAKEOFFS	
US	75-15-08		ENGINE LUBRICATION	
US US	91-17-01		ELEVATOR TRIM TAB ACTUATOR	2399
US	93-24-03 95-04-03		RUDDER SPAR CRACKS IN WING CARRY-THROUGH FRAME	2333R1
				2360
35B33	00 00 00	( 35	SERIES )	
US US	62-08-03 70-03-05		CONTROL WHEELS TURNING TYPE TAKEOFFS	
US	75-15-08		ENGINE LUBRICATION	
US	76-03-05		HOUSING CABLE AND BATTERY RELAY	
US US	79-01-01		SCREWS IN CONTROL SYSTEM	
US	91-17-01 93-24-03		ELEVATOR TRIM TAB ACTUATOR RUDDER SPAR	2399
US	95-04-03		CRACKS IN WING CARRY-THROUGH FRAME	2333R1 2360
25.000		(		2000
35C33 US	70-03-05		SERIES ) TURNING TYPE TAKEOFFS	
US	71-24-10		SECURITY OF CONTROL WHEEL	
US	75-15-08		ENGINE LUBRICATION	
US US	76-03-05 79-01-01		HOUSING CABLE AND BATTERY RELAY	
US	91-17-01		SCREWS IN CONTROL SYSTEM ELEVATOR TRIM TAB ACTUATOR	
US	93-24-03		RUDDER SPAR	2399 2333R1
US	95-04-03		CRACKS IN WING CARRY-THROUGH FRAME	2360
35C33A		( 35 9	SERIES )	
	70-03-05		TURNING TYPE TAKEOFFS	
	71-24-10		SECURITY OF CONTROL WHEEL	
	79-01-01 91-17-01		SCREWS IN CONTROL SYSTEM ELEVATOR TRIM TAB ACTUATOR	
US	93-24-03		RUDDER SPAR	2399 2333R1
US	95-04-03		CRACKS IN WING CARRY-THROUGH FRAME	2360
135		( 35 9	SERIES )	
US	49-26-01		TRAILING ANTENNA REWORK	
	49-31-01		EMERGENCY FUEL PUMP "O" RINGS	
	49-48-01 50-42-01		THOMPSON FUEL PUMP	
US	51-14-01		ELEVATOR TAB REPLACEMENT FUEL BOOSTER PUMP REMOVAL	
	53-01-02		FUEL SELECTOR VALVE REWORK	
	59-08-01		LANDING GEAR LIMIT SWITCHES	
	62-08-03 63-25-01		CONTROL WHEELS FUSELAGE MODIFICATION	
US (	69-18-01		FUEL SYSTEM MODIFICATION	
	72-18-01		FUEL SELECTOR VALVE WARNING LIGHT	
	75-15-08 76-05-04		ENGINE LUBRICATION	
	98-13 <b>-</b> 02		STABILIZER ATTACH FITTING VNE RESTRICTION	ALID
			,	AWD
35 US 5	53-01-02		ERIES )	
	59-08-01		FUEL SELECTOR VALVE REWORK LANDING GEAR LIMIT SWITCHES	
US 6	62-08-03		CONTROL WHEELS	
	3-25-01		FUSELAGE MODIFICATION	
	69-18-01 72-18-01		FUEL SYSTEM MODIFICATION	
	75-15-08		FUEL SELECTOR VALVE WARNING LIGHT	
US 7	76-05-04		STABILIZER ATTACH FITTING	
US S	98-13-02	١	/NE RESTRICTION	AWD
35		( 25 5	ERIES )	
110	3-01-02			
US 5	59-08-01	F L	UEL SELECTOR VALVE REWORK ANDING GEAR LIMIT SWITCHES	
US 5			UEL SELECTOR VALVE REWORK	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE			SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
BEECH					
C35	UED / CULTE)	(	35	SERIES )	
US	UED / SUITE) 72-18-01			FUEL CELECTOR WALVE WARNED	
US	75-15-08			FUEL SELECTOR VALVE WARNING LIGHT ENGINE LUBRICATION	
US	97-14-15			CABIN DOOR HANDLE LOCKING	2693
D35			35	SERIES )	
US	62-08-03	,	33	CONTROL WHEELS	
US	75-15-08			ENGINE LUBRICATION	
US	97-14-15			CABIN DOOR HANDLE LOCKING	2693
E35		(	35	SERIES )	
US	62-08-03			CONTROL WHEELS	
US US	75-15-08 97-14-15			ENGINE LUBRICATION	
03	37 14 13			CABIN DOOR HANDLE LOCKING	2693
F35		(	35	SERIES )	
US	62-08-03			CONTROL WHEELS	
US	75-15-08			ENGINE LUBRICATION	
G35		(	35	SERIES )	
US	62-08-03			CONTROL WHEELS	
US	97-14-15			CABIN DOOR HANDLE LOCKING	2693
H35		(	35	SERIES )	
US	62-08-03			CONTROL WHEELS	
US US	65-14-01 70-03-05			ALTERNATOR SUPPORT BRACKET	
US	75-15-08			TURNING TYPE TAKEOFFS ENGINE LUBRICATION	
US	95-04-03			CRACKS IN WING CARRY-THROUGH FRAME	2360
US	97-14-15			CABIN DOOR HANDLE LOCKING	2693
J35		(	35	SERIES )	
US	62-08-03			CONTROL WHEELS	
US	65-14-01			ALTERNATOR SUPPORT BRACKET	
บร บร	70-03-05			TURNING TYPE TAKEOFFS	
US	75-15-08 95-04-03			ENGINE LUBRICATION CRACKS IN WING CARRY-THROUGH FRAME	2360
US	97-14-15			CABIN DOOR HANDLE LOCKING	2693
K35		-	25	SERIES )	
US	62-08-03	(	35	CONTROL WHEELS	
US	65-14-01			ALTERNATOR SUPPORT BRACKET	
US	70-03-05			TURNING TYPE TAKEOFFS	
US US	75-15-08 95-04-03			ENGINE LUBRICATION CRACKS IN WING CARRY-THROUGH FRAME	2360
US	97-14-15			CABIN DOOR HANDLE LOCKING	2693
***		,	-	050750	
M35 US	62-08-03	(	35	SERIES ) CONTROL WHEELS	
UŞ	70-03-05			TURNING TYPE TAKEOFFS	
US	75-15-08			ENGINE LUBRICATION	
US	95-04-03			CRACKS IN WING CARRY-THROUGH FRAME	2360
US	97-14-15			CABIN DOOR HANDLE LOCKING	2033
N35		(	35	SERIES )	
US	62-08-03			CONTROL WHEELS	
US US	70-03-05 75-15-08			TURNING TYPE TAKEOFFS ENGINE LUBRICATION	
	95-04-03			CRACKS IN WING CARRY-THROUGH FRAME	2360
	97-14-15			CABIN DOOR HANDLE LOCKING	2693
P35			35	SERIES )	
	62-08-03	,	33	CONTROL WHEELS	
	64-27-01			CONTROL WHEEL COLUMN AFT STOP	
	70-03-05			TURNING TYPE TAKEOFFS	
	75-15-08 76-03-05			ENGINE LUBRICATION HOUSING CABLE AND BATTERY RELAY	
	95-04-03			CRACKS IN WING CARRY-THROUGH FRAME	2360
	97-14-15			CABIN DOOR HANDLE LOCKING	2693
S35		(	35	SERIES )	
	64-27-01	,	33	CONTROL WHEEL COLUMN AFT STOP	
	70-03-05			TURNING TYPE TAKEOFFS	

MAKE / CONSTRUCTEUR

(SERIES / SERIE)

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. BEECH 535 ( 35 SERIES ) (CONTINUED / SUITE) 75-01-07 EXHAUST SYSTEM FAILURES US 92-17-01 US FUEL SYSTEM LEAK 2420 CRACKS IN WING CARRY-THROUGH FRAME US 95-04-03 2360 97-14-15 CABIN DOOR HANDLE LOCKING 2693 V25 ( 35 SERIES ) US 70-03-05 TURNING TYPE TAKEOFFS 71-24-10 75-01-07 SECURITY OF CONTROL WHEEL US EXHAUST SYSTEM FAILURES US 92-17-01 FUEL SYSTEM LEAK US 2420 US 95-04-03 97-14-15 CRACKS IN WING CARRY-THROUGH FRAME 2360 US CABIN DOOR HANDLE LOCKING 2693 V35A 70-03-05 ( 35 SERIES ) LIS TURNING TYPE TAKEOFFS US 71-24-10 75-01-07 SECURITY OF CONTROL WHEEL US EXHAUST SYSTEM FAILURES 92-17-01 US FUEL SYSTEM LEAK 2420 US 95-04-03 CRACKS IN WING CARRY-THROUGH FRAME 2360 US 97-14-15 CABIN DOOR HANDLE LOCKING 2693 V35R ( 35 SERIES ) US 71-24-10 SECURITY OF CONTROL WHEEL US 73-14-03 LANDING GEAR SHOCK STRUT PISTON LANDING GEAR SHOCK STRUT PISTON 74-03-02 US US 74-24-03 STROBE LIGHT SYSTEM 75-01-07 115 EXHAUST SYSTEM FAILURES "Y" TYPE SHOULDER HARNESS
SCREWS IN CONTROL SYSTEM US 76-22-02 US 79-01-01 2175 87-18-06R1 115 CO-PILOTS AND PASSENGERS SEAT 88-21-02 US PILOT & CO-PILOTS SEAT ATTACHMENTS 2010R1.2233 US 91-18-19 US 91-20-08 US 92-17-01 PILOT & CO-PILOT SHOULDER HARNESS 2394 FRESH AIR BLOWER 2380 FUEL SYSTEM LEAK 2420 US 95-04-03 US 97-14-15 CRACKS IN WING CARRY-THROUGH FRAME 2360 CABIN DOOR HANDLE LOCKING 2693 36 SERIES 84-09-01 LIS WINDOW EMER EGRESS PROVISIONS ENGINE OIL FILTER ADAPTERS ASSEMBLIES ATTACHED SKETCH US 96-12-22 97-14-15 US CABIN DOOR HANDLE LOCKING 2693 98-21-21 115 BOB FIELDS AEROCESSORIES STC US 99-05-13 FUEL SELECTOR-INCORRECT POSITIONING 36 ( 36 SERIES ) TURNING TYPE TAKEOFFS US 70-03-05 US 70-12-02 CENTER SEAT TRACKS US 71-24-10 SECURITY OF CONTROL WHEEL ENGINE FUEL INTERRUPTION WHEEL US 72-11-02 US 72-22-01 LANDING GEAR UPLOCK ROLLERS 74-12-02 115 AFT FACING SEATS US 75-05-02 ENGINE OIL US 89-05-02 MAGNESIUM ELEVATOR CONTROL FITTINGS 2242R1 HS 91-17-01 ELEVATOR TRIM TAB ACTUATOR 2399 US 93-24-03 RUDDER SPAR 2333R1 US 95-04-03 CRACKS IN WING CARRY-THROUGH FRAME 2360 436 ( 36 SERIES ) US 70~12-02 CENTER SEAT TRACKS 71-24-10 SECURITY OF CONTROL WHEEL ENGINE FUEL INTERRUPTION US 72-11-02 US 72-22-01 LANDING GEAR UPLOCK ROLLERS 115 73-14-03 LANDING GEAR SHOCK STRUT PISTON LANDING GEAR SHOCK STRUT PISTON 74-03-02 US 74-12-02 AFT FACING SEATS LIS 74-24-03 STROBE LIGHT SYSTEM US 75-05-02 ENGINE OIL "Y" TYPE SHOULDER HARNESS
SCREWS IN CONTROL SYSTEM
CO-PILOTS AND PASSENGERS SEAT US 76-22-02 79-01-01 US US 87-18-06R1 2175 2249 2010R1,2233 88-20-01 CABIN FIREWALL - MORTELL 931 SOUND DEADENER 88-21-02 US PILOT & CO-PILOTS SEAT ATTACHMENTS

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER	(SERIES / SERIE)	
ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
BEECH		
A36 (CONTINUED / SUITE)	( 36 SERIES )	
US 91-17-01	ELEVATOR TRIM TAB ACTUATOR	2399
US 91-18-19 US 91-20-08	PILOT & CO-PILOT SHOULDER HARNESS	2394
US 92-18-11	FRESH AIR BLOWER LANDING GEAR ELECTRICAL CIRCUIT	2380
US 93-03-02	LORAN LATERAL DEVIATION	2437
US 93-24-03 US 95-04-03	RUDDER SPAR	2333R1
US 99-09-15	CRACKS IN WING CARRY-THROUGH FRAME FLIGHT CONTROL MECHANISM CLEARANCE	2360 27-3232
A36TC		
US 84-08-04	( 36 SERIES ) OIL RETURN LINE CHECK VALVE	
US 87-08-05	FUEL SYSTEM	2033
US 87-18-06R1 US 88-21-02	CO-PILOTS AND PASSENGERS SEAT	2175
US 91-17-01	PILOT & CO-PILOTS SEAT ATTACHMENTS ELEVATOR TRIM TAB ACTUATOR	2010R1,2233 2399
US 91-20-08	FRESH AIR BLOWER	2380
US 92-17-01 US 93-24-03	FUEL SYSTEM LEAK RUDDER SPAR	2420
US 95-04-03	CRACKS IN WING CARRY-THROUGH FRAME	2333R1 2360
ВЗ6ТС	( 36 SERIES )	
US 99-09-15	FLIGHT CONTROL MECHANISM CLEARANCE	27-3232
45 SERIES		
<b>A45</b> US 61-26-01	OIL PICKUP HOSES	
US 62-24-01	STABILIZER SPAR	
US 72-22-01	LANDING GEAR UPLOCK ROLLERS	
US 75-24-11 US 89-05-02	CABLE AND BELLCRANK ASSYS MAGNESIUM ELEVATOR CONTROL FITTINGS	2242R1
US 91-17-01	ELEVATOR TRIM TAB ACTUATOR	2399
US 99-05-13 US 99-12-02	FUEL SELECTOR-INCORRECT POSITIONING WING STRUCTURAL FATIGUE	
C45G	( 45 SERIES )	
CF CF-63-08	FLOAT TUBES MEMBERS -36 & -37	112-1
CF CF-65-01 US 59-18-02	EDO FRONT FLOAT STRUTS FUEL LINE MODIFICATION	BRISTOL 14518
US 60-16-01	EMERGENCY ELEC SWITCH / SEATS	
US 66-30-01	STATIC PRESSURE LINE	
US 68-23-06 US 72-16-02R3	VOLPAR TRI-GEAR VOLPAR NOSE GEAR FORK	
US 72-25-06	NOSE GEAR EXTENSION	
US 75-27-09R2 US 77-19-07	WING STRUCTURE CONTROL COLUMN ASSEMBLY	
US 77-19-07 US 78-10-01	LOWER RUDDER TORQUE TUBE	
<b>C45H</b> CF CF-63-08	FLOAT TUBES MEMBERS -36 & -37	112-1
CF CF-65-01	EDO FRONT FLOAT STRUTS	BRISTOL 14518
US 59-18-02	FUEL LINE MODIFICATION	
US 60-16-01 US 65-03-01	EMERGENCY ELEC SWITCH / SEATS GAP SEAL STRIPS	
US 66-30-01	STATIC PRESSURE LINE	
US 68-23-06	VOLPAR TRI-GEAR	
US 72-16-02R3 US 72-25-06	VOLPAR NOSE GEAR FORK NOSE GEAR EXTENSION	
US 75-27-09R2	WING STRUCTURE	
US 77-19-07 US 78-10-01	CONTROL COLUMN ASSEMBLY LOWER RUDDER TORQUE TUBE	
	FONEK HODDEK 191140E 1995	
D45 US 62-24-01	STABILIZER SPAR	
US 72-22-01	LANDING GEAR UPLOCK ROLLERS	
US 75-24-11	CABLE AND BELLCRANK ASSYS	2242R1
US 89-05-02 US 91-17-01	MAGNESIUM ELEVATOR CONTROL FITTINGS ELEVATOR TRIM TAB ACTUATOR	2399
US 99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
US 99-12-02	WING STRUCTURAL FATIGUE	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE SUBJECT
SUBJECT

	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE HEF.
BEECH			
TC45G	05 00 00	FLOAT TUBES MEMBERS -36 & -37	112-1
CF	CF-63-08	EDO FRONT FLOAT STRUTS	BRISTOL 14518
CF	CF-65-01	FUEL LINE MODIFICATION	
US US	59-18-02 60-16-01	EMERGENCY ELECTRICAL SWITCH/SEATS	
US	65-03-01	GAP SEAL STRIPS	
US	66-30-01	STATIC PRESSURE LINE	
US	68-23-06	VOLPAR TRI-GEAR	
US	72-16-02R3	VOLPAR NOSE GEAR FORK	
US	72-25-06	NOSE GEAR EXTENSIONS	
US	75-27-09R2	WING STRUCTURE	
US	77-19-07	CONTROL COLUMN ASSEMBLY	
US	78-10-01	LOWER RUDDER TORQUE TUBE	
03	70 10 01		
50 SEF	RIES		
US	84-09-01	WINDOW EMER EGRESS PROV	
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
C50		( 50 SERIES )	
US	58-13-02	TAIL LIGHT ASSEMBLY	
US	62-08-03	CONTROL WHEELS	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-02R2	IN-FLIGHT FIRES	
US	79-13-01	POWERPLANT FIRE DETECTION / CONTAINMENT	
US	85-22-05	NUT AND BOLT REPLACEMENT	2693
US	97-14-15	CABIN DOOR HANDLE LOCKING	2030
UŞ	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
E50		( 50 SERIES )	
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
US	33-03-13	TOLL SELECTOR TROOKILOT TOST TORTING	
H50		( 50 SERIES )	
US	62-08-03	CONTROL WHEELS	
	78-11-01	POWERPLANT FIRES	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-02R2	IN-FLIGHT FIRES	
US	79-13-01	POWERPLANT FIRE DETECTION / CONTAINMENT	
US	85-22-05	NUT AND BOLT REPLACEMENT	
	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
US	99-03-13		
		7012 02120701 21122111221 1 2 2 2 2 2 2 2 2 2 2 2 2	
US <b>55 SEF</b>	RIES		
<b>55 SEF</b> US	RIES 84-09-01	WINDOW EMER EGRESS PROV	ATTACHED CVETCH
55 SEF US US	RIES 84-09-01 96-12-22	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
<b>55 SEF</b> US US US	RIES 84-09-01 96-12-22 97-14-15	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING	ATTACHED SKETCH 2693
<b>55 SEF</b> US US US US US	81ES 84-09-01 96-12-22 97-14-15 98-21-21	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC	ATTACHED SKETCH 2693
55 SEF US US US	RIES 84-09-01 96-12-22 97-14-15	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING	ATTACHED SKETCH 2693
55 SEF US US US US US	81ES 84-09-01 96-12-22 97-14-15 98-21-21	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING	ATTACHED SKETCH 2693
55 SEF US US US US US US	84-09-01 96-12-22 97-14-15 98-21-21 99-05-13	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES )	ATTACHED SKETCH 2693
55 SEF US US US US US US	84-09-01 96-12-22 97-14-15 98-21-21 99-05-13	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM	ATTACHED SKETCH 2693
55 SEF US US US US US US D55 US	84-09-01 96-12-22 97-14-15 98-21-21 99-05-13 68-14-01 68-26-06	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION	ATTACHED SKETCH 2693
55 SEF US US US US US US D55 US US	RIES 84-09-01 96-12-22 97-14-15 98-21-21 99-05-13 68-14-01 68-26-06 71-24-10	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL	ATTACHED SKETCH 2693
55 SEF	84-09-01 96-12-22 97-14-15 98-21-21 99-05-13 68-14-01 68-26-06 71-24-10 72-01-02	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES	ATTACHED SKETCH 2693
55 SEF US	84-09-01 96-12-22 97-14-15 98-21-21 99-05-13 68-14-01 68-26-06 71-24-10 72-01-02 72-11-02	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION	ATTACHED SKETCH 2693
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-22-01	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS	ATTACHED SKETCH 2693
55 SEF US	RIES 84-09-01 96-12-22 97-14-15 98-21-21 99-05-13 68-14-01 68-26-06 71-24-10 72-01-02 72-11-02 72-22-01 73-21-02	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES	ATTACHED SKETCH 2693
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-12-01  73-21-02  73-26-08	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS	ATTACHED SKETCH 2693
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-22-01  73-21-02  73-26-08  75-16-10	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB	ATTACHED SKETCH 2693
55 SEF US	RIES 84-09-01 96-12-22 97-14-15 98-21-21 99-05-13  68-14-01 68-26-06 71-24-10 72-01-02 72-11-02 72-22-01 73-21-02 73-26-08 75-16-10 79-01-01	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM	ATTACHED SKETCH 2693
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-22-01  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS	2693 2242R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-12-01  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR	2242R1 2242R1 2269R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-12-01  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS	2693 2242R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-12-01  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-12-01  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-12-01  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  (55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  72-11-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  73-21-02  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR  ( 55 SERIES ) SECURITY OF CONTROL WHEEL	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  (55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR  (55 SERIES ) SECURITY OF CONTROL WHEEL OIL DRAIN TUBES	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  73-21-02  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  (55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR  (55 SERIES ) SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01  71-24-10  72-01-02  72-21-02  72-21-02  72-21-02  72-22-01  73-14-03	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR  ( 55 SERIES ) SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS LANDING GEAR UPLOCK ROLLERS LANDING GEAR UPLOCK STRUT PISTON	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-11-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01  71-24-10  72-01-02  72-11-02  72-21-02	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  ( 55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR  ( 55 SERIES ) SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  72-22-01  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01  71-24-10  72-01-02  72-22-01  71-24-10  72-01-02  72-22-01  73-21-02  72-11-02  72-22-01  73-14-03  73-21-02	WINDOW EMER EGRESS PROV  ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  (55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR  (55 SERIES ) SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS LANDING GEAR SHOCK STRUT PISTON FAILURE OF FLEX HOSE ASSEMBLIES	2242R1 2242R1 2269R1 2362R1
55 SEF US	RIES  84-09-01  96-12-22  97-14-15  98-21-21  99-05-13  68-14-01  68-26-06  71-24-10  72-01-02  73-21-02  73-26-08  75-16-10  79-01-01  89-05-02  90-08-14  91-15-20  91-17-01  71-24-10  72-01-02  72-21-02  73-26-08	WINDOW EMER EGRESS PROV ENGINE OIL FILTER ADAPTERS ASSEMBLIES CABIN DOOR HANDLE LOCKING BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING  (55 SERIES ) PNEUMATIC DE-ICER SYSTEM PLACARD INSTALLATION SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB SCREWS IN CONTROL SYSTEM MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR CRACKED ENGINE MOUNTS ELEVATOR TRIM TAB ACTUATOR  (55 SERIES ) SECURITY OF CONTROL WHEEL OIL DRAIN TUBES ENGINE FUEL INTERRUPTION LANDING GEAR UPLOCK ROLLERS LANDING GEAR UPLOCK ROLLERS LANDING GEAR SHOCK STRUT PISTON FAILURE OF FLEX HOSE ASSEMBLIES ROLL AND PITCH SERVO CLAMPS	2242R1 2242R1 2269R1 2362R1

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

		20151	BULLETIN DE SERVICE DE REF.
BEECH			
E55		( 55 SERIES )	
	NUED / SUITE)	( 33 SERIES )	
US	76-13-05	ELECTRICAL POWER	
US	76-22-02	"Y" TYPE SHOULDER HARNESS	
US	77-02-04	WING TIP STROBE LIGHTS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	87-18-06R1	CO-PILOTS AND PASSENGERS SEAT	2175
US	88-21-02	PILOT & CO-PILOTS SEAT ATTACHMENTS	2010R1,2233
US US	90-08-14	FORWARD WING SPAR	2269R1
US	91-15-20 91-17-01	CRACKED ENGINE MOUNTS	2362R1
US	91-18-19	ELEVATOR TRIM TAB ACTUATOR	2399
US	98-04-24	PILOT & CO-PILOT SHOULDER HARNESS	2394
	55 54 24	OPERATING IN SEVERE ICING CONDITIONS	AWD
56TC			····· ······ · ··· · · · · · · · · · ·
US	67-29-01	RUDDER SPAR WEB	
US	68-14-01	PNEUMATIC DE-ICER SYSTEM	
US	71-24-09	AIRSPEED PLACARD AND INDICATOR MARKIN S	
US	71-24-10	SECURITY OF CONTROL WHEEL	
US	72-22-01	LANDING GEAR UPLOCK ROLLERS	
US	75-16-10	ELEVATOR TRIM TAB	
US	77-02-04	WING TIP STROBE LIGHTS	
US US	79-01-01 84-09-01	SCREWS IN CONTROL SYSTEM	
US	89-05-02	WINDOW EMER EGRESS PROV	224004
US	90-08-14	MAGNESIUM ELEVATOR CONTROL FITTINGS FORWARD WING SPAR	2242R1
US	91-17-01	ELEVATOR TRIM TAB ACTUATOR	2269R1 2399
US	97-14-15	CABIN DOOR HANDLE LOCKING	2693
US	98-21-21	BOB FIELDS AEROCESSORIES STC	2033
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
58			
US	71-24-10	SECURITY OF CONTROL WHEEL	
US	72-01-02	OIL DRAIN TUBES	
US	72-11-02	ENGINE FUEL INTERRUPTION	
US	72-22-01	LANDING GEAR UPLOCK ROLLERS	
US US	73-14-03 73-21-02	LANDING GEAR SHOCK STRUT PISTON	
US	74-03-02	FAILURE OF FLEX HOSE ASSEMBLIES  LANDING GEAR SHOCK STRUT PISTON	
US	74-12-02	AFT FACING SEATS	
US	74-24-03	STROBE LIGHT SYSTEM	
US	75-16-10	ELEVATOR TRIM TAB	
US	76-13-05	ELECTRICAL POWER	
US	76-22-02	"Y" TYPE SHOULDER HARNESS	
US	77-02-04	WING TIP STROBE LIGHTS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	84-09-01	WINDOW EMER EGRESS PROV	0.100
US	87-16-11	PLACARD - ICING	2180
US	87-18-06R1	CO-PILOTS AND PASSENGERS SEAT	2175
US	88-21-02	PILOT & CO-PILOTS SEAT ATTACHMENTS FORWARD WING SPAR	2010R1,2233 2269R1
US US	90-08-14 91-15-20	CRACKED ENGINE MOUNTS	2362R1
US	91-17-01	ELEVATOR TRIM TAB ACTUATOR	2399
US	91-18-19	PILOT & CO-PILOT SHOULDER HARNESS	2394
US	92-23-04	ENGINE THROTTLE CONTROL SUPPORT ANGLE CLIP	2439
US	93-01-23	FUEL - CROSSFEED CHECK VALVES	2454
US	93-03-02	LORAN LATERAL DEVIATION	2496
US	97-14-15	CABIN DOOR HANDLE LOCKING	2693
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	98-04-24	OPERATING IN SEVERE ICING CONDITIONS	AWD
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	27-3232
US	99-09-15	FLIGHT CONTROL MECHANISM CLEARANCE	21-3232
EOD			
58P	76-17-02	CABIN WINDOW	
US US	76-17-02 77-08-04	ENGINE MOUNT FITTINGS	
US	77-13-08	RIGHT AND LEFT TRUSS ASSEMBLY	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	85-11-04	AFM PLACARD - SEATS	
US			0475
	87-18-06R1	CO-PILOTS & PASSENGERS SEAT	2175
US		PILOT & CO-PILOTS SEAT ATTACHMENTS	2010R1,2233
US US	87-18-06R1		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE SUBJECT
SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
BEEGH			
BEECH 58P			
	NUED / SUITE)		
US	92-23-04	ENGINE THROTTLE CONTROL SUPPORT ANGLE CLIP	2439
US	97-09-09	CABIN WINDOW LONGERON CRACKS	2630, 2691
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	98-04-24 98-21-21	OPERATING IN SEVERE ICING CONDITIONS	AWD
US US	98-21-21 99-05-13	BOB FIELDS AEROCESSORIES STC	
03	33 03 13	FUEL SELECTOR-INCORRECT POSITIONING	
58TC			
US	77-08-04	ENGINE MOUNT FITTINGS	
US	77-13-08	RIGHT AND LEFT TRUSS ASSEMBLY	
US US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	84-09-01 87-18-06R1	WINDOW EMER EGRESS CO-PILOTS & PASSENGERS SEAT	0.4.75
US	88-21-02	PILOT & CO-PILOTS SEAT ATTACHMENTS	2175 2010R1,2233
US	91-17-01	ELEVATOR TRIM TAB ACTUATOR	2399
US	91-18-19	PILOT & CO-PILOT SHOULDER HARNESS	2394
US	92-23-04	ENGINE THROTTLE CONTROL SUPPORT ANGLE CLIP	2439
US US	97-14-15	CABIN DOOR HANDLE LOCKING	2693
	97-25-01 98-04-24	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	98-21-21	OPERATING IN SEVERE ICING CONDITIONS BOB FIELDS AEROCESSORIES STC	AWD
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
60 SEF			
US US	72-22-04	ELEVATOR MOVEMENT INTERFERENCE	
US	83-08-05 97-25-01	AIR CONDITIONER MODIFICATION OUTFLOW SAFETY VALVE CRACKING	0404 04
US	99-03-11	CABIN HEAT CONTROL WIRING	2484 R1
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	24-3097
60	74 05 05	( 60 SERIES )	
US US	74-05-05 74-12-02	PILOT'S SIDE WINDOW	
US	75-06-09	AFT FACING SEATS ELEVATOR INBOARD HINGE SUPPORT	
US	77-02-04	WING TIP STROBE LIGHTS	
US	77-14-08	WATER IN FUSELAGE	
US	80-04-07	OUTBOARD WING PANEL NUTS	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US US	95-22-03 98-04-24	FLIGHT IN KNOWN ICING CONDITIONS	4115
	33 04 24	OPERATING IN SEVERE ICING CONDITIONS	AWD
A60		( 60 SERIES )	
US	71-05-03	KNOWN ICING CONDITIONS	
US	74-05-05	PILOT'S SIDE WINDOW	
US US	74-12-02	AFT FACING SEATS	
US	74-24-03 75-06-09	STROBE LIGHT SYSTEM	
US	77-02-04	ELEVATOR INBOARD HINGE SUPPORT WING TIP STROBE LIGHTS	
UŞ	77-14-08	WATER IN FUSELAGE	
US	80-04-07	OUTBOARD WING PANEL NUTS	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	95-22-03	FLIGHT INTO KNOWN ICING CONDITIONS	
B60		( 60 SERIES )	
US	74-24-03	( 60 SERIES ) STROBE LIGHT SYSTEM	
US	76-13-05	ELECTRICAL POWER	
US	77-14-08	WATER IN FUSELAGE	
US	80-04-07	OUTBOARD WING PANEL NUTS	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
65 SER	IES		
65		( 65 SERIES )	
CF	CF-79-13	WING STRUCTURE	
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF US	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	62-08-03 64-24-02	CONTROL WHEELS	
US	76-09-01	WING ATTACH BOLTS EMERGENCY EXIT DOOR	
US	77-22-01	FUSELAGE STRUCTURE	
ATDOD	AFT/AFRONEES		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

		SUJET	BULLETIN DE SERVICE DE REF.
BEECH			
65		( 65 SERIES )	
	NUED / SUITE)		
US	78-11-01	POWERPLANT FIRES	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-02R2	IN-FLIGHT FIRES	
US	79-16-01	WING STRUCTURE	
US US	81-23-01R1	BEECH KIT OR STC	
US	85-22-05 95-20-01R1	NUT AND BOLT REPLACEMENT	
US	95-20-01K1	CABIN DOOR REQUIREMENT FOR OPERATION	
65 88		( 65 SERIES )	
CF	CF-81-25R4	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	ST 1209
US	69-06-06	RUDDER SPAR CRACKS	31 1200
US	76-10-10 77-22-01	CABIN DOOR	
US	77-22-01	FUSELAGE STRUCTURE	
US	78-11-01	POWERPLANT FIRES	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-02R2	IN-FLIGHT FIRES	
US US	81-23-01R1	BEECH KIT OR STC	
US	85-01-01 85-22-05	ACRYLIC WINDOWS	
03	03-22-05	NUT AND BOLT REPLACEMENT	
65 90			
CF	CF-68-15	WHEEL CONE BEARINGS	
CF	CF-79-13	WING STRUCTURE	
CF	CF-80-22	PROP REVERSING LINKAGE INTERCONNECT	
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	68-21-04	ICE DAMAGE TO ENGINE	
US	69-06-06	RUDDER SPAR CRACKS	
US	70-22-01	HEATER PRESSURE SWITCH WING STRUCTURE	
US	70-25-04	WING STRUCTURE	SI 0394-018
US	72-20-03	HEATER OVERHEAT	
US US	75-08-16	FUEL CONTAMINATION	
US	76-10-10 77-22-01	CABIN DOOR FUSELAGE STRUCTURE	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-16-01	WING STRUCTURE	
US	81-23-01R1	BEECH KIT OR STC	
US	82-23-02	ELEVATOR CONTROL	
US	85-01-01	· ACRYLIC WINDOWS	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US	88-04-07	WING LOWER FORWARD SPAR ATTACHMENT	2248
US	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM	2312
US	92-07-05	RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS PILOT & CO-PILOTS CHAIRS LOCKING PINS	2432 2444 R1
US	97-06-06	POWER LEVERS	2444 K!
US US	97-25-03	FUEL FLOW INTERRUPTION	2718 R1
US	98-15-13 99-10-07	ELEVATOR CONTROL CABLE UNDERFLOOR INTERFERENCE	2710111
. U.S	33 10-07	ELEVATOR CONTROL CADEL GROCK LOOK INTERVENCE	
65A90			
CF	CF-80-22	PROP REVERSING LINKAGE INTERCONNECT	
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	68-21-04	ICE DAMAGE TO ENGINE	
US	69-06-06	RUDDER SPAR CRACKS	
US	72-20-03	HEATER OVERHEAT	
US	75-08-16	FUEL CONTAMINATION	
US	76-10-10	CABIN DOOR	
	77-22-01	FUSELAGE STRUCTURE	
US	78-11-06	ELEVATOR CONTROL PUSH PORS	
	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	81-23-01R1	BEECH KIT OR STC ELEVATOR CONTROL	
US	82-23-02	ACRYLIC WINDOWS	
US	85-01-01	NUT AND BOLT REPLACEMENT	
US US	85-22-05 87-04-24	ELEVATOR TRIM CABLE SYSTEM	2028R3
US	87-04-24 87-22-01R1	NOSE LANDING GEAR FORK	2102R3
	O. EL OIN		

MAKE / CONS MODEL / MI		(SERIES / SERIE)	REFERENCE SERVICE BULLETIN
ORIGIN	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	BULLETIN DE SERVICE DE REF.
ВЕЕСН			
65A90	/		
	UED / SUITE)	WING LOUGH FORWARD COAR ATTACKMENT	
US	88-04-07	WING LOWER FORWARD SPAR ATTACHMENT	2248
US	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM	2312
US	92-07-05	RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01 97-06-06	ENGINE TRUSS-TO FIREWALL BOLTS PILOT & CO-PILOTS CHAIRS LOCKING PINS	2432 2444 R1
US	97-25-03	POWER LEVERS	2444 RT
US	98-15-13	FUEL FLOW INTERRUPTION	2718 R1
US	99-10-07	ELEVATOR CONTROL CABLE UNDERFLOOR INTERFERENCE	2/10 KI
65B80			
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	69-06-06	RUDDER SPAR CRACKS	
US	74-16-04	RESTRICTED ELEVATOR TRAVEL	
US	74-24-03	STROBE LIGHT SYSTEM	
US	76-09-01	EMERGENCY EXIT DOOR	
US	76-22-02	"Y" TYPE SHOULDER HARNESS	
US	77-02-04	WING TIP STROBE LIGHTS	
US	77-22-01	FUSELAGE STRUCTURE	
US	78-11-01	POWERPLANT FIRES	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	79-01-02R2	IN-FLIGHT FIRES	
US	81-23-01R1	BEECH KIT OR STC	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US	88-04-07	WING LOWER FORWARD SPAR ATTACHMENT	2248
US	98-04-24	OPERATING IN SEVERE ICING CONDITIONS	AWD
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
A65			
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	76-09-01	EMERGENCY EXIT DOOR	
US	77-22-01	FUSELAGE STRUCTURE	
US	78-11-01	POWERPLANT FIRES	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-02R2	IN-FLIGHT FIRES	
US	81-23-01R1	BEECH KIT OR STC	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US	88-04-07	INCONEL NUTS - LOWER FWD SPAR ATTACHMENTS	2248
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
70			
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	74-24-03	STROBE LIGHT SYSTEM	
US	76-09-01	EMERGENCY EXIT DOOR	
US	77-02-04	WING TIP STROBE LIGHTS	
US	77-22-01	FUSELAGE STRUCTURE	
US	78-11-01	POWERPLANT FIRES	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
	79-01-02R2	IN-FLIGHT FIRES	
	81-23-01R1	BEECH KIT OR STC	
	85-22-05	NUT AND BOLT REPLACEMENT	
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
	88-04-07	WING LOWER FORWARD SPAR ATTACHMENT	2248
76			
US	78-20-08	TRIM TABS PUSH RODS	
	79-09-04	ENGINE STARTER RELAY FAILURES	
	79-17-06	MAIN LANDING GEAR	
	79-23-06	REPLACING STOP BOLT NUTS	
US	80-07-06	RUDDER AND RUDDER TRIM TAB	
	80-19-12R1	ENGINE MOUNT STRUCTURE	
US	82-02-03	ELEVATOR CONTROL CABLE	
	97-06-10	MAIN LANDING GEAR 'A' FRAME	0004 B0
		CONTAIN LAND AND A LAND A LAND	2361 R3

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
BEECH			
76	HED / CLITTE)		
US	UED / SUITE) 99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	
		. OLE SELECTOR INCORRECT PUSITIONING	
<b>77</b> US	79-23-05	ATT 4 0 1 11 11 11 11 11 11 11 11 11 11 11 11	
US	80-07-06	ATTACHMENT BOLT THREADS AND NUT PLATE RUDDER AND RUDDER TRIM TAB	
US	80-07-07	AILERON CONTROL SYSTEM	
US	80-21-10	ENGINE MOUNT ATTACHMENT	
US US	82-09-03 83-23-03	SHOULDER HARNESS PROTECTION	
US	91-23-01	BALANCE WEIGHT ATTACH BRACKET INSTLN NOSE LANDING GEAR FORK	004484
US	99-05-13	FUEL SELECTOR-INCORRECT POSITIONING	2241R1
90 SER	IES		
US	96-03-13	MLG DRAG LEG LOCK LINK	SB 2607R1
US	97-06-06	PILOT AND CO-PILOTS CHAIR LOCKING PINS	2444 R1
US	97-23-17 97-25-01	PNUEMATIC PRESSURIZATION SYSTEM OUTFLOW SAFETY VALVE CRACKING	2676
US	97-25-03	POWER LEVERS	2484 R1
US	98-15-13	FUEL FLOW INTERRUPTION	2718 R1
B90			
CF	CF-80-22	PROP REVERSING LINKAGE INTERCONNECT	
CF CF	CF-81-25R5 CF-81-35	WING LOWER OUTBOARD FITTING	
CF	CF-81-35 CF-82-06	WING LOWER FORWARD ATTACHMENT WING PANEL ATTACHMENT BOLT	SI 1208
US	68-21-04	ICE DAMAGE TO ENGINE	31 1200
US	69-06-06	RUDDER SPAR CRACKS	
US US	72-20-03	HEATER OVERHEAT	***************************************
US	75-08-16 76-10-10	FUEL CONTAMINATION CABIN DOOR	
US	77-02-04	WING TIP STROBE LIGHTS	
US	77-22-01	FUSELAGE STRUCTURE	
US	78-11-06	ELEVATOR CONTROL CABLE	
US US	78-22-05 79-01-01	ELEVATOR CONTROL PUSH RODS SCREWS IN CONTROL SYSTEM	
US	80-09-03R1	PLACARD - OXYGEN	
US	81-23-01R1	BEECH KIT OR STC	
US	82-23-02	ELEVATOR CONTROL	
US US	85-01-01 85-22-05	ACRYLIC WINDOWS NUT AND BOLT REPLACEMENT	
US	87-04-24	ELEVATOR TRIM CABLE SYSTEM	2028R3
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
	88-04-07	WING LOWER FORWARD SPAR ATTACHMENT	2248
US US	89-22-14 90-08-17	AILERON FLUTTER AFT FUSELAGE MOISTURE DRAIN SYSTEM	2256 2312
US	92-07-05	RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2432
US	93-17-01	LEADING EDGE FUEL CELL	2475
US US	97-06-06 97-25-01	PILOT & CO-PILOTS CHAIRS LOCKING PINS OUTFLOW SAFETY VALVE CRACKING	2444 R1 2484 R1
	97-25-03	POWER LEVERS	
US	98-15-13	FUEL FLOW INTERRUPTION	2718 R1
US	99-10-07	ELEVATOR CONTROL CABLE UNDERFLOOR INTERFERENCE	
C90			
	CF-80-22	PROP REVERSING LINKAGE INTERCONNECT	
	CF-81-25R5	WING LOWER OUTBOARD FITTING WING LOWER FORWARD ATTACHMENT	
	CF-81-35 CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
	74-16-04	RESTRICTED ELEVATOR TRAVEL	
US	74-24-03	STROBE LIGHT SYSTEM	
	76-04-02	SEAT LACKING PINS CABIN DOOR	
	76-10-10 76-22-02	"Y" TYPE SHOULDER HARNESS	
	77-02-04	WING TIP STROBE LIGHTS	
US	77-07-06	RUDDER CONTROL CABLE	
	77-18-04	CABIN PRESSURIZATION	
	77-22-01 78-11-06	FUSELAGE STRUCTURE  ELEVATOR CONTROL CABLE	
	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	80-09-03R1	PLACARD - OXYGEN	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
555011			
BEECH C90			
	NUED / SUITE)		
US	81-09-01	LANDING GEAR RETRACT SYSTEM	
US	81-23-01R1	BEECH KIT OR STC	
US	85-01-01	ACRYLIC WINDOWS	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	87-04-24	ELEVATOR TRIM CABLE SYSTEM	2028R3
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US	88-04-07	WING LOWER FORWARD SPAR ATTACHMENT	2248
US	89-22-14	AILERON FLUTTER	2256
US US	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM RUDDER TRIM TAB WATER DRAINAGE	2312
US	92-07-05 92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2365R1 2432
US	93-17-01	LEADING EDGE FUEL CELL	2432
US	97-06-06	PILOT & CO-PILOTS CHAIRS LOCKING PINS	2444 R1
US	97-23-17	PNEUMATIC PRESSURIZATION SYSTEM	2676
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	97-25-03	POWER LEVERS	
US	98-15-13	FUEL FLOW INTERRRUPTION	2718 R1
US	99-10-07	ELEVATOR CONTROL CABLE UNDERFLOOR INTERFERENCE	
C90A	07-00-0404	NOCE LANDING CEAR FORK	0.40000
US US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US	89-22-14 90-08-17	AILERON FLUTTER AFT FUSELAGE MOISTURE DRAIN SYSTEM	2256
US	92-15-01	ENGINE-TRUSS-TO-FIREWALL BOLTS	2312
US	93-17-01	LEADING EDGE FUEL CELL	2432 2475
US	96-11-12	OPTIONAL ELECTRIC TRIM	SB 2631
US	97-06-06	PILOT & CO-PILOTS CHAIRS LOCKING PINS	2444 R1
US	97-23-17	PNEUMATIC PRESSURIZATION SYSTEM	2676
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	97-25-03	POWER LEVERS	
US	98-15-13	FUEL FLOW INTERRUPTION	2718 R1
US	99-09-10	LANDING GEAR HAND PUMP	32-3073R1
US	99-09-15	FLIGHT CONTROL MECHANISM CLEARANCE	27-3232
US US	99-10-07 99-18-15	ELEVATOR CONTROL CABLE UNDERFLOOR INTERFERENCE	APP NIVI
03	99-16-15	IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PU	MP NIL
E90			
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	74-16-04	RESTRICTED ELEVATOR TRAVEL	
US	74-24-03	STROBE LIGHT SYSTEM	
US	76-04-02	SEAT LOCKING PINS	
US US	76-10-10 76-22-02	CABIN DOOR "Y" TYPE SHOULDER HARNESS	
US	77-02-04	WING TIP STROBE LIGHTS	
US	77-07-06	RUDDER CONTROL CABLE	
US	77-18-04	CABIN PRESSURIZATION	
US	77-22-01	FUSELAGE STRUCTURE	······
US	78-11-06	ELEVATOR CONTROL CABLE	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	80-09-03R1	PLACARD - OXYGEN	
US	81-09-01	LANDING GEAR RETRACT SYSTEM	
US	81-23-01R1	BEECH KIT OR STC	
US	85-01-01 85-22-05	ACRYLIC WINDOWS	
US US	87-04-24	NUT AND BOLT REPLACEMENT	
US	87-22-01R1	ELEVATOR TRIM CABLE SYSTEM	2028R3
US	88-04-07	NOSE LANDING GEAR FORK WING LOWER FORWARD SPAR ATTACHMENT	2102R3
US	89-22-14	AILERON FLUTTER	2248 2256
US	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM	2312
US	92-07-05	RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01	ENGINE TRUSS-TO EIDEWALL BOLTS	2432
US	97-06-06	PILOT & CO-PILOTS CHAIRS LOCKING PINS	2444 R1
US	97-23-17	PNEUMATIC PRESSURIZATION SYSTEM	2676
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	97-25-03	POWER LEVERS	
US	98-15-13 99-10-07	FUEL FLOW INTERRUPTION	2718 R1
03	33 10-07	ELEVATOR CONTROL CABLE UNDERFLOOR INTERFERENCE	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)

ORIGINE ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
BEECH			SOLETIME SE SENVICE DE REF
F90		( 90 SERIES )	
CF	CF-81-39	DE-ICING ELECTRICAL SYSTEM	1170
US	80-07-05	BOLT AND NUT, WING SECTION	
US	83-07-14	ONE-PLY WINDOW REPLACEMENT	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	87-04-24	ELEVATOR TRIM CABLE SYSTEM	2028R3
US	91-12-11	COCKPIT ACRYLIC SIDEWINDOWS	2208R1
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2432
US US	95-13-03	CIRCUIT BREAKER FOR ELECTRICAL LANDING GEAR	R MOTOR 2035 REV 3
US	97-23-17 97-25-01	PNEUMATIC PRESSURIZATION SYSTEM	2676
US	98-04-24	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	99-10-07	OPERATING IN SEVERE ICING CONDITIONS ELEVATOR CONTROL CABLE UNDERFLOOR INTERFER	AWD ENCE
95 SEF	RIES		
US	72-11-02	ENGINE FUEL INTERRUPTION	
US	72-22-01	LANDING GEAR UPLOCK ROLLERS	
US	84-09-01	WINDOW EMER EGRESS PROV	
US	89-05-02	MAGNESIUM ELEVATOR CONTROL FITTINGS	2242R1
US	90-08-14	FORWARD WING SPAR	2269R1
US	91-17-01	ELEVATOR TRIM TAB ACTUATOR	2399
US	97-14-15	CABIN DOOR HANDLE LOCKING	2693
US US	98-21-21 99-05-13	BOB FIELDS AEROCESSORIES STC FUEL SELECTOR-INCORRECT POSITIONING	
95		( 95 SERIES )	
US	62-08-03	CONTROL WHEELS	
US	75-13-02	PROPELLER BLADE VIBRATION	
US	75-16-10	ELEVATOR TRIM TAB	
95 55		95 SERIES )	
US	62-08-03	CONTROL WHEELS	
US	67-29-01	RUDDER SPAR WEB	
US	68-26-06	PLACARD INSTALLATION	
US	72-01-02	OIL DRAIN TUBES	
US US	73-26-08 75-16-10	ROLL AND PITCH SERVO CLAMPS ELEVATOR TRIM TAB	
95A55		95 SERIES )	
US	62-08-03	CONTROL WHEELS	
US	67-29-01	RUDDER SPAR WEB	
US	68-26-06	PLACARD INSTALLATION	
US	72-01-02	OIL DRAIN TUBES	
US	73-26-08	ROLL AND PITCH SERVO CLAMPS	
US	75-16-10	ELEVATOR TRIM TAB	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
95855	07.00.01	95 SERIES )	
US	67-29-01	RUDDER SPAR WEB	
US US	68-26-06	PLACARD INSTALLATION  SECURITY OF CONTROL WHEEL	
US	71-24-10 72-01-02	OIL DRAIN TUBES	
US	73-14-03	LANDING GEAR SHOCK STRUT PISTONS	
US	73-26-08	ROLL AND PITCH SERVO CLAMPS	
US	74-03-02	LANDING GEAR SHOCK STRUT PISTON	
US	74-24-03	STROBE LIGHT SYSTEM	
US	75-16-10	ELEVATOR TRIM TAB	
US	76-22-02	"Y" TYPE SHOULDER HARNESS	
US	77-02-04	WING TIP STROBE LIGHTS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	204004 2022
US	88-21-02	PILOT & CO-PILOTS SEAT ATTACHMENTS	2010R1,2233
US	91-18-19	PILOT & CO-PILOT SHOULDER HARNESS	2394
95C55	67 00 04	95 SERIES ) RUDDER SPAR WEB	
US	67-29-01	PLACARD INSTALLATION	
US	68-26-06	SECURITY OF CONTROL WHEEL	***************************************
US US	71-24-10 72-01-02	OIL DRAIN TUBES	
		FAILURE OF FLEX HOSE ASSEMBLIES	
US	73-21-02 73-26-08	ROLL AND PITCH SERVO CLAMPS	
US	75-16-10	ELEVATOR TRIM TAB	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	91-15-20	CRACKED ENGINE MOUNTS	2362R1

MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE) ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT BULLETIN DE SERVICE DE REF BEECH R95 ( 95 SERIES ) CONTROL WHEELS 62-08-03 PROPELLER BLADE VIBRATION 75-13-02 75-16-10 ELEVATOR TRIM TAB ( 95 SERIES )
CONTROL WHEELS B95A 62-08-03 68-26-06 PLACARD INSTALLATION 75-13-02 PROPELLER BLADE VIBRATION US US 75-16-10 ELEVATOR TRIM TAB ( 95 SERIES ) PLACARD INSTALLATION D954 US 68-26-06 71-24-10 SECURITY OF CONTROL WHEEL 75-13-02 PROPELLER BLADE VIBRATION ELEVATOR TRIM TAB 75-16-10 ( 95 SERIES )
PNEUMATIC DE-ICER SYSTEM E95 68-14-01 US 68-26-06 PLACARD INSTALLATION US 71-24-10 SECURITY OF CONTROL WHEEL SI 0254-156 75-13-02 US PROPELLER BLADE VIBRATION 99 SERIES 69-06-06 115 RUDDER SPAR CRACKS US 69-08-02 ELEVATOR SPAR WEB 69-24-02R3 MAXIMUM SPEED 70-10-01 INSTRUMENT PANEL CIRCUIT BOARDS US 71-05-03 KNOWN ICING CONDITIONS US 71-06-01 FAULTS, FAILURES, IMPROPER OPER SECURITY OF CONTROL WHEEL ADAPTERS US 72-26-01 NOSE COMPARTMENT DOOR LATCH US 74-16-03 RESTRICTED FLEVATOR TRAVEL US 90-12-07 WING ATTACH BOLTS 2248 US 92-15-13 WING FRONT SPAR LOWER CAP & COMPONENTS US 95-13-03 CIRCUIT BREAKER FOR ELECTRICAL LANDING GEAR MOTOR 2035 REV 3 96-03-13 MLG DRAG LEG LOCK LINK \$B 2607 R1 US 96-09-13 SEVERE ICING US 97-06-06 PILOT NAD CO-PILOTS CHAIR LOCKING PINS 2444 R1 97-25-03 POWER LEVERS 99 ( 99 SERIES ) CF CF-80-22 PROP REVERSING LINKAGE INTERCONNECT CF CF-81-35 WING LOWER FORWARD ATTACHMENT CF CF-82-06 WING PANEL ATTACHMENT BOLT SI 1208 72-10-04R2 US LANDING GEAR SYSTEM US 72-20-03 HEATER OVERHEAT US 75-15-07 LANDING GEAR SYSTEM US 76-22-03 ELEVATOR CONTROL US 78-22-05 ELEVATOR CONTROL PUSH RODS US 79-01-01 SCREWS IN CONTROL SYSTEM 80-07-05 BOLT AND NUT, WING SECTION US 81-18-08R3 REVISED AFM US 81-23-01R1 BEECH KIT OR STC NUT AND BOLT REPLACEMENT US 85-22-05 87-03-06R1 US ELEVATOR HINGE ATTACHMENT 2132 US 87-22-01R1 NOSE LANDING GEAR FORK 2102R3 US 88-04-07 WING LOWER FORWARD SPAR ATTACHMENT 2248 90-15-18 VERTICAL STABILIZER MAIN SPAR SI 0530-134 R1 US 92-07-05 RUDDER TRIM TAB WATER DRAINAGE 2365R1 92-15-01 ENGINE TRUSS-TO FIREWALL BOLTS 2432 99A ( 99 SERIES ) CF CF-81-35 WING LOWER FORWARD ATTACHMENT SI 1208 CF CF-82-06 WING PANEL ATTACHMENT BOLT SI 1208 US 72-10-04R2 LANDING GEAR SYSTEM 72-20-03 HEATER OVERHEAT US 75-15-07 LANDING GEAR SYSTEM US 76-22-03 ELEVATOR CONTROL US 78-22-05 ELEVATOR CONTROL PUSH RODS 79-01-01 SCREWS IN CONTROL SYSTEM US 80-07-05 BOLT AND NUT, WING SECTION US 81-18-08R3 REVISED AFM 81-23-01R1 BEECH KIT OR STC

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

ONIGINE	NOMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF
BEECH				
99A		( 99	SERIES )	
	UED / SUITE)			
US	85-22-05		NUT AND BOLT REPLACEMENT	
US	87-03-06R1		ELEVATOR HINGE ATTACHMENT	2132
US	87-22-01R1		NOSE LANDING GEAR FORK	2102R3
US	88-04-07		WING LOWER FORWARD SPAR ATTACHMENT	2248
US	90-15-18		VERTICAL STABILIZER MAIN SPAR	SI 0530-134 R1
US	92-07-05		RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01		ENGINE TRUSS-TO FIREWALL BOLTS	2432
B99		( 99	SERIES )	
CF	CF-81-35		WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06		WING PANEL ATTACHMENT BOLT	SI 1208
US	72-10-04R2		LANDING GEAR SYSTEM	0.1 1200
US	72-20-03		HEATER OVERHEAT	
US	74-24-03		STROBE LIGHT SYSTEM	
US	75-15-07		LANDING GEAR SYSTEM	
US	76-22-02		"Y" TYPE SHOULDER HARNESS	
US	76-22-03		ELEVATOR CONTROL	
US	78-22-05		ELEVATOR CONTROL PUSH RODS	
US	79-01-01		SCREWS IN CONTROL SYSTEM	
	80-07-05		BOLT AND NUT, WING SECTION	
US	81-18-08R3		REVISED AFM	
US	81-23-01R1		BEECH KIT OR STC	
US	85-22-05		NUT AND BOLT REPLACEMENT	
US	87-03-06R1		ELEVATOR HINGE ATTACHMENT	2132
US	87-22-01R1		NOSE LANDING GEAR FORK	2102R3
US	88-04-07		INCONEL NUTS - LOWER FWD SPAR ATTACHMENTS	2248
US	90-15-18		VERTICAL STABILIZER MAIN SPAR	SI 0530-134 R1
US	92-07-05		VERTICAL STABILIZER MAIN SPAR RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01		ENGINE TRUSS-TO FIREWALL BOLTS	2432
100				
100 CF	CE_01_0EDE		WING LOWER OUTBOARD FITTING	
C.F.	CF-81-25R5		WING LOWER OUTBOARD FITTING	
CF CF	CF-81-35		WING LOWER FORWARD ATTACHMENT	CT 4000
	CF-82-06		WING PANEL ATTACHMENT BOLT	SI 1208
	74-16-03		RESTRICTED ELEVATOR TRAVEL	
	74-24-03		STROBE LIGHT SYSTEM	
US US	76-10-10		CABIN DOOR	
US	76-22-03		ELEVATOR CONTROL	
	77-02-04		WING TIP STROBE LIGHTS	
US	78-22-05 79-01-01		ELEVATOR CONTROL PUSH RODS SCREWS IN CONTROL SYSTEM	
			PLACARD - DXYGEN	
	80-09-03R1			
	81-23-01R1		BEECH KIT OR STC	
	85-01-01		ACRYLIC WINDOWS	
	85-22-05 87-03-0684		NUT AND BOLT REPLACEMENT	2132
	87-03-06R1		ELEVATOR HINGE ATTACHMENT	2102R3
	87-22-01R1		NOSE LANDING GEAR FORK	2102K3 2248
	88-04-07		WING LOWER FORWARD SPAR ATTACHMENT	2312
	90-08-17		AFT FUSELAGE MOISTURE DRAIN SYSTEM	2365R1
	92-07-05		RUDDER TRIM TAB WATER DRAINAGE ENGINE TRUSS-TO FIREWALL BOLTS	2432
	92-15-01		CIRCUIT BREAKER FOR ELECTRICAL LANDING GEAR MOTOR	
	95-13-03		MLG DRAG LEG LOCK LINK	SB 2607 R1
	96-03-13		PILOT & CO-PILOTS CHAIRS LOCKING PINS	2444 R1
	97-06-06			2484 R1
	97-25-01		OUTFLOW SAFETY VALVE CRACKING POWER LEVERS	2 .0-7 171
	97-25-03		OPERATING IN SEVERE ICING CONDITIONS	AWD
	98-04-24		FUEL FLOW INTERRRUPTION	2718 R1
US	98-15-13		TOLE TOW INTERMINOT TON	
A 100				
	CF-81-25R5		WING LOWER OUTBOARD FITTING	
	CF-81-35		WING LOWER FORWARD ATTACHMENT	
	CF-82-06		WING PANEL ATTACHMENT BOLT	SI 1208
	74-16-03		RESTRICTED ELEVATOR TRAVEL	
	74-18-04		FUEL SUMP DRAIN LINE	
	74-24-03		STROBE LIGHT SYSTEM	
	76-04-02		SEAT LOCKING PINS	
	76-10-10		CABIN DOOR	
	76-22-02		"Y" TYPE SHOULDER HARNESS	
US			ELEVATOR CONTROL	
US US	76-22-02 76-22-03 77-02-04		ELEVATOR CONTROL WING TIP STROBE LIGHTS	

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
BEECH			
A100			
	UED / SUITE)		
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	80-09-03R1	PLACARD - OXYGEN	
US	81-23-01R1	BEECH KIT OR STC	
US	85-01-01	ACRYLIC WINDOWS	
US	85-22-05	NUT AND BOLT REPLACEMENT	0.1.00
US	87-03-06R1	ELEVATOR HINGE ATTACHMENT NOSE LANDING GEAR FORK WING LOWER FORWARD SPAR ATTACHMENT AFT FUSELAGE MOISTURE DRAIN SYSTEM	2132
US	87-22-01R1	NOSE LANDING GEAR FURK	210283
US US	88-04-07 90-08-17	WING LUWER FURWARD SPAR ATTACHMENT	2240
US	92-07-05	RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2432
US	95-13-03	CIRCUIT BREAKER FOR ELECTRICAL LANDING GEAR MOTOR	
US	96-03-13	MLG DRAG LEG LOCK LINK	SB 2607 R1
US	97-06-06	PILOT & CO-PILOTS CHAIRS LOCKING PINS	2444 R1
US	97-23-17	PNEUMATIC PRESSURIZATION SYSTEM	
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	97-25-03	POWER LEVERS	2404 1(1
US	98-15-13		2718 R1
B100			
CF	CF-81-25R5	WING LOWER OUTBOARD FITTING	
CF	CF-81-35	WING LOWER FORWARD ATTACHMENT	
CF	CF-82-06	WING PANEL ATTACHMENT BOLT	SI 1208
US	76-22-02	"Y" TYPE SHOULDER HARNESS	
US	76-22-02 76-22-03 77-18-04 78-22-05	ELEVATOR CONTROL	
US	77-18-04	CABIN PRESSURIZATION	
US	78-22-05	ELEVATOR CONTROL PUSH RODS	
US	79-01-01	SCREWS IN CONTROL SYSTEM	
US	81-23-01R1	BEECH KIT OR STC	
US	85-01-01	ACRYLIC WINDOWS	
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	86-24-09	FLIGHT MANUAL - LIMITATIONS / ICING ENVIRONMENT	
US	87-03-06R1	ELEVATOR HINGE ATTACHMENT	2132
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US	88-04-07	WING LOWER FORWARD SPAR ATTACHMENT	2248
US	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM	2312
US	92-07-05	RUDDER TRIM TAB WATER DRAINAGE	2365R1
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2432
US	95-13-03	CIRCUIT BREAKER FOR ELECTRICAL LANDING GEAR MOTOR	2035 REV 3
US	97-06-06	PILOT & CO-PILOTS CHAIRS LOCKING PINS PNEUMATIC PRESSURIZATION SYSTEM	2444 R1
US	97-23-17		2676
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	97-25-03	POWER LEVERS	
US	98-15-13	FUEL FLOW INTERRRUPTION	2718 R1
200 SE	DIEC		
	75-14-03	ALITODILOT	
US	89-22-14	AUTOPILOT AILERON FLUTTER	2256
US	95-13-03	CIRCUIT BREAKER FOR ELECTRICAL LANDING GEAR MOTOR	
US	96-03-13	MLG DRAG LEG LOCK LINK	SB 2607 R1
US	96-09-13	CEVEDE TOING	
US	97-06-06	PILOT AND CO-PILOTS CHAIR LOCKING PINS	2444 R1
US	97-23-17	PNEUMATIC PRESSURIZATION SYSTEM	2676
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	97-25-03	POWED LEVEDS	
US	98-15-13	FUEL FLOW INTERRUPTION	2718 R1
US	98-20-38	FLIGHT IN ICING CONDITIONS	2/10 K1
US	98-21-35	MLG ACTUATOR CLEVIS	2728
		The relief of the same	2720
200		200 SERIES )	
US	74-24-03	STROBE LIGHTS	0655-362
US	75-25-01	GENERATOR OUTPUT LEADS	SI 0768-358
US	75-26-04	FUEL TRANSFER SYSTEM	
US	76-03-07	RUDDER CONTROL	SI 0778-153
US	76-04-02	SEAT LOCKING PINS	SI 0789-314
US	76-09-02	WING CENTRE SECTION	SI 0775-062
US	76-10-10	CABIN DOOR	
US	76-12-10	WING DEICE BOOTS	SI 0822-193
US	76-22-02	"Y" TYPE SHOULDER HARNESS	
US	77-02-07	PROPELLER FEATHERING	
US	77-13-07	WING DESIGN LOADS	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGIN NUMBER SUBJECT
ORIGINE NUMBERO DE CONSIGNE SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
BEECH			
200		( 200 SERIES )	
(CONTIN	JUED / SUITE)		
US	77-18-04	CABIN DOOR	
US	79-01-01	CONTROL SYSTEM	
US	80-07-05	CONTROL SYSTEM OUTER WING PANELS PLACARD-OCYGEN ONE-PLY WINDOW REPLACEMENT	
US US	80-09-03R1 83-07-14 85-22-05	PLACARD-OCYGEN	
US	85-22-0F	ONE-PLY WINDOW REPLACEMENT	
US	87-04-24	NUT AND BOLT REPLACEMENT	
US	87-22-01R1	ELEVATOR TRIM CABLE SYSTEM NOSE LANDING GEAR FORK WING MAIN OUTBROAD SPAR	2028R3
US	89-02-03	NOSE LANDING GEAR FORK	2102R3
US	89-19-04R1	WING - MAIN OUTBOARD SPAR WING FUEL BAY UPPER SKIN PANEL AFT FUSELAGE MOISTURE DRAIN SYSTEM COCKPIT ACRYLIC SIDEWINDOWS AFT COWLING DOORS	2240
US	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM	2040R3
US	91-12-11	COCKPIT ACRYLIC SIDEWINDOWS	220881
US	92-10-12 92-15-01 93-25-07 97-25-01	AFT COWLING DOORS	2416R1
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	
US US	93-25-07	ENGINE TRUSS-TO FIREWALL BOLTS CRACKED STRINGERS REAR PRESSURE BULKHEAD OUTFLOW SAFETY VALVE CRACKING	2472R1
US	98-15-13	OUTFLOW SAFETY VALVE CRACKING	2484 R1
03	90-12-13	FUEL FLOW INTERRRUPTION	2718 R1
B200		( 200 SERIES )	
US	83-07-14	ONE-PLY WINDOW REPLACEMENT	1214
US	85-22-05		
US	87-04-24	ELEVATOR TRIM CABLE SYSTEM  NOSE LANDING GEAR FORK  WING FUEL BAY UPPER SKIN PANEL  AFT FUSELAGE MOISTURE DRAIN SYSTEM  LOWER FORWARD WING ATTACH FITTINGS  COCKPIT ACRYLIC SIDEWINDOWS	2028R3
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US	89-19-04R1	WING FUEL BAY UPPER SKIN PANEL	2040R3
US US	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM	2312
US	91-12-10	AFT FUSELAGE MOISTURE DRAIN SYSTEM LOWER FORWARD WING ATTACH FITTINGS COCKPIT ACRYLIC SIDEWINDOWS COLLINS EFIS AFT COWLING DOORS	
US	92-06-11	COLLING FETS	0.400
US	92-10-12	AFT COWLING DOORS  ENGINE TRUSS-TO FIREWALL BOLTS  CRACKED STRINGERS REAR PRESSURE BULKHEAD  OUTFLOW SAFETY VALVE CRACKING  ENGINE FIRE DETECTION SYSTEM  LANDING GEAR HAND RUMP	2423
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2432
US	93-25-07	CRACKED STRINGERS REAR PRESSURE BULKHEAD	2472R1
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	98-10-05	ENGINE FIRE DETECTION SYSTEM	2701
US	33 03 10		32-30/3KI
US US	99-09-15	FLIGHT CONTROL MECHANISM CLEARANCE	27-3232
05	99-18-15	IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP	NIL
B200C		( 200 SERIES )	
US	83-07-14	ONE-PLY WINDOW REPLACEMENT	1214
US	85-22-05	NUT AND BOLT REPLACEMENT	
US	87-04-24	NOT AND SOLT REPLACEMENT  ELEVATOR TRIM CABLE SYSTEM  NOSE LANDING GEAR FORK  WING FUEL BAY UPPER SKIN PANEL  AFT FUSELAGE MOISTURE DRAIN SYSTEM  LOWER FORWARD WING ATTACH FITTINGS  COCKPIT ACRYLIC SIDEWINDOWS	2028R3
US	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
US US	89-19-04R1	WING FUEL BAY UPPER SKIN PANEL	2040R3
UŞ	91-12-10	I DWED EDDWADD WING ATTACH FITTINGS	2312
US	91-12-11	LOWER FORWARD WING ATTACH FITTINGS COCKPIT ACRYLIC SIDEWINDOWS AFT COWLING DOORS ENGINE TRUSS-TO FIREWALL BOLTS	2208R1
US	92-10-12	AFT COWLING DOORS	2416R1
US	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2432
US	93-25-07	CRACKED STRINGERS REAR PRESSURE BULKHEAD OUTFLOW SAFETY VALVE CRACKING FINGINE FIRE DETECTION SYSTEM	2472R1
US	97-25-01	OUTFLOW SAFETY VALVE CRACKING	2484 R1
US	98-10-05	ENGINE FIRE DETECTION SYSTEM	
US	99-09-10	CRACKED STRINGERS REAR PRESSURE BULKHEAD OUTFLOW SAFETY VALVE CRACKING ENGINE FIRE DETECTION SYSTEM LANDING GEAR HAND PUMP	32-30/3KT
300 SE			
US	89-22-14	AILERON FLUTTER	2256
US	97-23-17	PNEUMATIC PRESSURIZATION SYSTEM	2676
US	97-25-01		2484 R1
US	97-25-03	POWER LEVERS	
US	98-04-24	OPERATING IN SEVERE ICING CONDITIONS	AWD
US	98-15-13	FUEL FLOW INTERRUPTION	2718 R1 2728
US	98-21-35	MLG ACTUATOR CLEVIS	2120
300		( 300 SERIES )	
	87-04-24	ELEVATOR TRIM CABLE SYSTEM	2028R3
	87-22-01R1	NOSE LANDING GEAR FORK	2102R3
	89-19-04R1	WING FUEL BAY UPPER SKIN PANELS	2040R3
	90-08-17	AFT FUSELAGE MOISTURE DRAIN SYSTEM	2312
US	91-12-10	LOWER FORWARD WING ATTACH FITTINGS	
	91-12-11	COCKPIT ACRYLIC SIDEWINDOWS	2208R1
	92-06-11	COLLINS EFIS	2423 2432
	92-15-01	ENGINE TRUSS-TO FIREWALL BOLTS	2329
US	93-01-20	UPPER AFT COWLING ACCESS DOOR LATCHES	2020

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

BECON	ORIGINE	NUMERO DE CONSIGNE			SUJET	BULLETIN DE SERVICE DE RET.
GOOD   GERTES   CONTINUED   SUITE   CRACKED STRINGERS BEAR PRESSURE BULKHEAD   2472R1   US 99-04-24   CURFLON SAFETY VALVE CRACKING   2484 R1   US 99-04-24   LANDING GEAR HAND PUMP   32-3073R1    B300   SPI-20-14R1   GOOD   SPERITING IN SEVERE ICING CONDITIONS   AND   US 91-20-14R1   GOOD   SPERITING IN SEVERE ICING CONDITIONS   AND   US 92-15-01   CONTINUED   SPERITING INSERT ICING CONDITIONS   AND   US 92-25-07   CRACKED STRINGERS REAR PRESSURE BULKHEAD   2472R1   US 92-25-07   CRACKED STRINGERS REAR PRESSURE BULKHEAD   2472R1   US 93-25-07   CRACKED STRINGERS REAR PRESSURE BULKHEAD   2472R1   US 93-02-10   CULFLON SAFETY VALVE CRACKING   2484 R1   US 98-04-24   OPERATING IN SEVERE ICING CONDITIONS   AND   US 98-04-24   OPERATING IN SEVERE ICING CONDITIONS   AND   US 99-09-15   FLIGHT CONTROL MECHANISM CLEARANCE   27-3222   US 99-18-15   FLIGHT CONTROL MECHANISM CLEARANCE   27-3222   US 99-18-15   IMPROPERTY MACHINED LIDRING GEAR EMERGENCY HAND PUMP   NIL   US 99-09-15   FLIGHT CONTROL MECHANISM CLEARANCE   27-3222   US 99-09-16   FLIGHT CONTROL MECHANISM CLEARANCE   27-3222   US 99-09-15   FLIGHT CONTROL MECHANISM CLEARANCE   27-3222   US 99-09-15   FLIGHT CONTROL MECHANISM CLEARANCE   27-3222   US 99-09-16   FLIGHT CONTROL MECHANISM CLEARANCE   27-3222   US 99-09-16   FLIGHT CONTROL MECHANISM CLEARANCE   27-322   US 99-09-15   FLIGHT CONTROL MECHANISM CLEARANCE   27-322   US 99-16-16   FLIGHT CONTROL MECHANISM CLEARANCE   27-322   US 99-10-10   FLIGHT CONTROL MECHANISM CLEARANCE   27-323   US 99-10-10   FLIGHT CONTROL MECHANISM CLEARANCE   27-323   US 99-10-10   FLIGHT CONTROL MECHANISM						
CONTINUED	BEECH					
US 93-25-07 CRACKES TRINGERS REAR PRESSURE BULNHEAD 24/28/1 US 97-26-14 CANDING GEAR PRIVATE CRACKING AND 1 US 99-09-10 CANDING GEAR PRIVATE CRACKING AND 1 US 99-09-10 CANDING GEAR PAND PUMP CONDITIONS AND 1 29-307381  B300 STES 9 US 91-20-1481 CANDING GEAR HAND PUMP CONDITIONS AND 1 US 92-15-01 CANDING GEAR HAND PUMP CONDITIONS AND 2 US 93-25-07 CRACKES STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 93-25-07 CRACKES STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 93-25-07 CRACKES STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 93-01-01 CAGIN SEATS TRY VALVE CRACKING 24/43 R11 US 98-01-10 CAGIN SEATS TRY VALVE CRACKING 24/43 R11 US 98-01-13 FUEL FLOW INTERRRUPTION 2718 R1 US 98-09-10 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-19-15 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-19-15 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-19-15 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-29-16 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/40 R1 US 99-29-12 TELL FLOW INTERRRUPTION CLEARANCE 24/40 R1 US 99-29-12 TELL FLOW INTERRRUPTION CLEARANCE 24/40 R1 US 99-29-12 FUEL FLUTER AND BYPASS VALVE STRINGERS REAR PRESSURE PUMP MICE STR	300		(	300	SERIES )	
US 93-25-07 CRACKES TRINGERS REAR PRESSURE BULNHEAD 24/28/1 US 97-26-14 CANDING GEAR PRIVATE CRACKING AND 1 US 99-09-10 CANDING GEAR PRIVATE CRACKING AND 1 US 99-09-10 CANDING GEAR PAND PUMP CONDITIONS AND 1 29-307381  B300 STES 9 US 91-20-1481 CANDING GEAR HAND PUMP CONDITIONS AND 1 US 92-15-01 CANDING GEAR HAND PUMP CONDITIONS AND 2 US 93-25-07 CRACKES STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 93-25-07 CRACKES STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 93-25-07 CRACKES STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 93-01-01 CAGIN SEATS TRY VALVE CRACKING 24/43 R11 US 98-01-10 CAGIN SEATS TRY VALVE CRACKING 24/43 R11 US 98-01-13 FUEL FLOW INTERRRUPTION 2718 R1 US 98-09-10 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-19-15 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-19-15 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-19-15 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/7281 US 99-29-16 LANDING GEAR HAND PUMP MICE STRINGERS REAR PRESSURE BULNHEAD 24/40 R1 US 99-29-12 TELL FLOW INTERRRUPTION CLEARANCE 24/40 R1 US 99-29-12 TELL FLOW INTERRRUPTION CLEARANCE 24/40 R1 US 99-29-12 FUEL FLUTER AND BYPASS VALVE STRINGERS REAR PRESSURE PUMP MICE STR	(CONTIN	UED / SUITE)				
US 97-25-01	US	93-25-07			CRACKED STRINGERS REAR PRESSURE BULKHEAD	2472R1
B300	US	97-25-01			OUTFLOW SAFETY VALVE CRACKING	2484 R1
B300		98-04-24			OPERATING IN SEVERE ICING CONDITIONS	AWD
B300		99-09-10			LANDING GEAR HAND PLIMP	32-3073R1
US 91-20-14RI PERFORMANCE CHARTS 2423 US 92-06-11 COLLINS EFIS 2423 US 92-15-01 ENGINE TRUSS-TO FIREWALL BOLTS 2423 US 92-15-01 COLLINS EFIS 2439 US 97-25-01 COLVENS AND CONTROL STATEMENT AND CONTRO		33 03 10			LANDING GEAT TOTAL	
US   91-20-1481   PERFORMANCE CHARTS   2423   US   92-06-11   COLLINS EFIS   2423   US   92-15-01   ENGINE TRUSS-TO FIREWALL BOLTS   2423   US   92-15-01   ENGINE TRUSS-TO FIREWALL BOLTS   2423   US   92-15-01   COLVENS AFETY VALVE CRACKING   2444   US   94-0-20   COLVENS EATS INCRESS REAR PRESSURE BULKHEAD   2424   US   98-0-2-10   COLVENS EATS INCRESS REAR PRESSURE BULKHEAD   2444   US   98-0-2-10   COLVENS EATS INCRESS REAR PRESSURE BULKHEAD   2444   US   98-0-2-10   COLVENS EATS INCRESS REAR PRESSURE BULKHEAD   2444   US   98-0-2-10   COLVENS EATS INCRESS REAR PRESSURE BULKHEAD   2444   US   98-0-2-10   FULL FLOW INTERRUPTION   2450   COLVENS   2451   COL	B200		- (	200	ccpice )	
US   92-06-11   COLLINS FIS   2473   US   92-15-01   ENGINE TRUSS-TO FIREWALL BOLTS   2472   US   93-25-07   CRACKED STRINGERS REAR PRESSURE BULKHEAD   2472   US   94-01-01   CABIN SHAFETY VALVE CRACKING   2484 R1   US   94-01-01   CABIN SHAFETY VALVE CRACKING   2484 R1   US   98-04-24   OPERATING IN SEVERE ICING CONDITIONS   AWD   US   98-15-13   FUEL FLOW INTERRUPTION   2718 R1   US   99-02-16   ELEVATOR TRIM ACTUATOR ICING   2620   US   99-09-15   FLICHT CONTROL MECHANISM CLEARANCE   27-3232   US   99-09-15   SEVERE ICING   SEVERE ICING CONTROL MECHANISM CLEARANCE   27-3232   US   96-09-13   SEVERE ICING   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   96-09-13   SEVERE ICING   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   96-09-15   SEVERE ICING   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   97-02-16   SEVERE ICING   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   97-02-16   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   97-02-16   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   97-12-16   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   97-02-16   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   97-02-16   SEVERE ICING SEAR EMERGENCY HAND PUMP NIL   US   97-02-16   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   97-02-16   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   98-09-10-10   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   98-01-10   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   98-01-01   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   98-01-10   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   98-02-17   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   98-02-17   SEVERE ICING SEAR HAND SEAR EMERGENCY HAND PUMP NIL   US   98-02-17   SEVERE ICING SEAR SEAR EMERGENCY HAND PUMP NIL   US   98-02-17   SEVERE ICING SEAR SEAR EM		01 00 1401	(			
US   32-08-07					PERFURMANCE CHARTS	2422
US 92-08-07 US 94-08-07 US 94-01-01 US 94-01-01 US 94-01-01 US 97-25-01 US 97-25-01 US 97-25-01 US 98-04-24 US 98-04-24 US 98-04-24 US 98-02-16 US 98-02-16 US 98-02-16 US 99-02-16 US 99-02-16 US 99-09-10 US 99-09-10 US 99-09-15 US 99-09-16 US 99-09-16 US 99-09-16 US 99-09-16 US 99-09-16 US 99-09-10 US 99-09-16 US 99-19-09 US 99-		92-06-11			COLLINS EFIS	2423
US 98-15-13		92-15-01			ENGINE TRUSS-TO FIREWALL BOLTS	2432
US 98-15-13		93-25-07			CRACKED STRINGERS REAR PRESSURE BULKHEAD	
US 98-15-13	US	94-01-01			CABIN SEATS	
US 98-15-13	US	97-25-01			OUTFLOW SAFETY VALVE CRACKING	2484 R1
U.S.   99-09-10	US	98-04-24			OPERATING IN SEVERE ICING CONDITIONS	AWD
U.S.   99-09-10	US	98-15-13			FUEL FLOW INTERRRUPTION	2718 R1
1900   SERIES   SEVERE ICING   SP-08-15   THEOREM PARCHINED LINONS GEAR EMERGENCY HAND PUMP NIL	US	99-02-16			ELEVATOR TRIM ACTUATOR ICING	2620
1900   SERIES   SEVERE ICING   SP-08-15   THEOREM PARCHINED LINONS GEAR EMERGENCY HAND PUMP NIL	US	99-09-10			LANDING GEAR HAND PUMP	32-3073R1
US   99-18-15	IIS	99-09-15			FLIGHT CONTROL MECHANISM CLEARANCE	27-3232
1900   SERIES		99-18-15			IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PLIMP	NITI
US 96-09-13 US 96-22-12 US 97-06-06 US 97-06-06 US 97-15-13R2 US 97-15-13R2 US 97-15-13R2 US 97-15-13R2 US 97-25-03 US 97-25-03 US 97-22-16 US 97-22-16 US 97-22-16 US 97-22-16 US 97-22-16 US 97-22-17 US 97-25-03 US 97-26-15 US 97-26-15 US 97-26-15 US 98-21-20 US 98-21-20 US 98-21-20 DODR EXPERIDATION OF LUBRICATION FITTINGS IN AIRSTAIRS 2572R1 US 98-21-20 US 98-21-20 DODR EXPERIDATION OF LUBRICATION FITTINGS IN AIRSTAIRS 2572R1 US 98-21-20 US 98-21-20 DODR EXPERIDATION OF LUBRICATION FITTINGS IN AIRSTAIRS 2572R1 US 98-10-03 FLAP ROLLER DOORS US 98-21-20 DODR EXPERIDATION OF LUBRICATION PLACARD 2741 REV 1 US 98-01-03 FLAP ROLLER BEARINGS AND ATTACH BRACKETS 27-3168 US 99-04-08 MAIN LANDING GEAR HYDRAULIC ACTUATOR 32-3141 US 87-04-24 ELEVATOR TRIM CABLE SYSTEM 2028R3 US 87-04-24 ELEVATOR TRIM CABLE SYSTEM 2028R3 US 87-05-02 POH & AFM US 87-22-01R1 US 87-04-24 ELEVATOR TRIM CABLE SYSTEM 2423 US 99-06-11 COLLINS EFIS 2423 US 93-01-16 FUEL IN STALL WARNING VANE 2430 US 99-20-61 HOT BATTERY BUS BAR 2562 US 95-02-18 ENGINE TRUSS CRACKS US 95-02-18 ENGINE TRUSS CRACKS US 95-02-17 ELEVATOR TRIM TAB CONTROL US 96-02-17 ELEVATOR TRIM TAB CONTROL US 96-02-10 US 96-02-11 US 96-02-17 ELEVATOR TRIM TAB CONTROL US 97-03-01 UN SKIN DEBONDING OR WINDOW WARPING 2686 US 97-03-01 UN 96-15-01 UN SKIN DEBONDING OR WINDOW WARPING 2686 US 97-10-14 UNS SHIP SERVICE MOUNTING BOLTS 2651 US 99-09-15 FLICH CONTROL MECHANISM CLEARANCE 27-0323 US 99-09-15 FLICH CONTROL MECHANISM CLEARANCE 27-0323 US 99-12-07 OXYGEN MASK LANNARD PIN FAILING TO PULL US 99-18-15 IMPROPERLY MACHINED LINDING FARE ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LINDING FARE ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LINDING FARE ELECTRIC ELEVATOR TRIM 27-3080 US 99-16-12 US 99-16-12 US 9	03	99 18 19			THE NOT ENER PROPERTY ENDING GEAR EMERGENCY THAT TO THE	1412
US   96-09-13   SEVERE ICING   US   96-02-12   FUEL FILTER AND BYPASS VALVE   US   97-06-06   PILOT AND CO-PILOTS CHAIR LOCKING PINS   2444 R1   US   97-15-13R2   INSTALLATION OF LUBRICATION FITTINGS IN AIRSTAIRS   2572R1   US   97-22-16   BLOWER ASSEMBLY BEARINGS   2721   US   97-26-05   DOWER LEVENT DOWER SERVENT   2721   US   97-26-15   MLG ROD END FAILURE   2730   US   97-26-16   MLG ROD END FAILURE   2730   US   98-21-20   DOOR EXTERTOR OPERATING INSTRUCTION PLACARD   2741 REV   1   US   98-21-20   DOOR EXTERTOR OPERATING INSTRUCTION PLACARD   2740 REV   1   1   1   1   1   1   1   1   1	1000	CDIEC				
US   97-26-03   POWER LEVERS   US   97-26-15   MLG ROD END FAILURE   2730   US   98-21-20   DOOR EXTERIOR OPERATING INSTRUCTION PLACARD   2741 REV   1   US   98-26-16   EMERGENCY EXIT DOORS   2740 REV   1   US   99-01-03   FLAP ROLLER BEARINGS AND ATTACH BRACKETS   27-3158   US   99-04-08   MAIN LANDING GEAR HYDRAULIC ACTUATOR   32-3141		OC CO CO			CEVEDE TOTAL	
US   97-26-03   POWER LEVERS   US   97-26-15   MLG ROD END FAILURE   2730   US   98-21-20   DOOR EXTERIOR OPERATING INSTRUCTION PLACARD   2741 REV   1   US   98-26-16   EMERGENCY EXIT DOORS   2740 REV   1   US   99-01-03   FLAP ROLLER BEARINGS AND ATTACH BRACKETS   27-3158   US   99-04-08   MAIN LANDING GEAR HYDRAULIC ACTUATOR   32-3141		96-09-13			SEVEKE ICING	CB 0078
US   97-26-03   POWER LEVERS   US   97-26-15   MLG ROD END FAILURE   2730   US   98-21-20   DOOR EXTERIOR OPERATING INSTRUCTION PLACARD   2741 REV   1   US   98-26-16   EMERGENCY EXIT DOORS   2740 REV   1   US   99-01-03   FLAP ROLLER BEARINGS AND ATTACH BRACKETS   27-3158   US   99-04-08   MAIN LANDING GEAR HYDRAULIC ACTUATOR   32-3141		96-22-12			FUEL FILTER AND BYPASS VALVE	SB 26/8
US   97-26-03   POWER LEVERS   US   97-26-15   MLG ROD END FAILURE   2730   US   98-21-20   DOOR EXTERIOR OPERATING INSTRUCTION PLACARD   2741 REV   1   US   98-26-16   EMERGENCY EXIT DOORS   2740 REV   1   US   99-01-03   FLAP ROLLER BEARINGS AND ATTACH BRACKETS   27-3158   US   99-04-08   MAIN LANDING GEAR HYDRAULIC ACTUATOR   32-3141		97-06-06			PILOT AND CO-PILOTS CHAIR LOCKING PINS	2444 R1
US   97-26-03   POWER LEVERS   US   97-26-15   MLG ROD END FAILURE   2730   US   98-21-20   DOOR EXTERIOR OPERATING INSTRUCTION PLACARD   2741 REV   1   US   98-26-16   EMERGENCY EXIT DOORS   2740 REV   1   US   99-01-03   FLAP ROLLER BEARINGS AND ATTACH BRACKETS   27-3158   US   99-04-08   MAIN LANDING GEAR HYDRAULIC ACTUATOR   32-3141	US	97-15-13R2			INSTALLATION OF LUBRICATION FITTINGS IN AIRSTAIRS	25/2R1
1900C	US	97-22-16			BLOWER ASSEMBLY BEARINGS	2721
1900C	US	97-25-03			POWER LEVERS	
1900C	US	97-26-15			MLG ROD END FAILURE	2730
1900C	US	98-21-20			DOOR EXTERIOR OPERATING INSTRUCTION PLACARD	2741 REV 1
1900C	US	98-26-16			EMERGENCY EXIT DOORS	2740 REV 1
1900C	IIS	99-01-03			FLAP ROLLER BEARINGS AND ATTACH BRACKETS	27-3158
1900C	115	99-04-08			MAIN LANDING GEAD HYDRAULIC ACTUATOR	32-3141
US 87-05-02 PDH & AFM  US 87-20-01R1 NOSE LANDING GEAR FORK 2102R3  US 93-06-11 COLLINS EFIS 2423  US 93-01-16 FUEL IN STALL WARNING VANE 2430  US 94-20-05 HOT BATTERY BUS BAR 2562  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  1900D (1900 SERIES)  US 95-02-17 ELEVATOR TRIM TAB CONTROL  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  US 95-26-14 CABIN PARTITION FAILURE  US 95-26-14 CABIN PARTITION FAILURE  US 97-03-01 WINDSHIED HEATING CIRCUIT  US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686  US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES  US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES  US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS  US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS  US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE  US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE  US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  4701  CF CF-61-06 MAIN ROTOR BLADES  CF CF-62-10 STC SHI-512  CF CF-68-17 WOOD MAIN ROTOR BLADES  CF CF-88-08 MAIN ROTOR BLADES  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 HURLOFTER SECUE SYSTEMS  CAR 702-21  US 49-34-02 ATTACHMEN SON THE VENTRAL FIN 70	03	33 04 08			MAIN EANDING GEAR INDRAGEIC ACTORION	32 3141
US 87-05-02 PDH & AFM  US 87-05-02 PDH & AFM  US 97-06-11 NOSE LANDING GEAR FORK 2102R3  US 93-01-16 FUEL IN STALL WARNING VANE 2430  US 93-01-16 FUEL IN STALL WARNING VANE 2430  US 94-20-05 HOT BATTERY BUS BAR 2562  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  1900D (1900 SERIES)  US 95-02-17 ELEVATOR TRIM TAB CONTROL  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  US 95-26-14 CABIN PARTITION FAILURE SB 2556  US 95-16-01 WINDSHIED HEATING CIRCUIT TELEX AD 2556  US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686  US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686  US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651  US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643  US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714  US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232  US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  4701  CF CF-61-06 MAIN ROTOR BLADES  CF CF-62-10 STC SHI-512  CF CF-68-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 HOLD FROM SHADES  CF CF-88-15 HELL PUMP ROCKER PIN  US 49-34-02 ATTACHMEN ON THE VENTRAL FIN 70	19000			1000	CEDIEC )	
US 87-05-02 PDH & AFM  US 87-05-02 PDH & AFM  US 97-06-11 NOSE LANDING GEAR FORK 2102R3  US 93-01-16 FUEL IN STALL WARNING VANE 2430  US 93-01-16 FUEL IN STALL WARNING VANE 2430  US 94-20-05 HOT BATTERY BUS BAR 2562  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  1900D (1900 SERIES)  US 95-02-17 ELEVATOR TRIM TAB CONTROL  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  US 95-26-14 CABIN PARTITION FAILURE SB 2556  US 95-16-01 WINDSHIED HEATING CIRCUIT TELEX AD 2556  US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686  US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686  US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651  US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643  US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714  US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232  US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  4701  CF CF-61-06 MAIN ROTOR BLADES  CF CF-62-10 STC SHI-512  CF CF-68-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 HOLD FROM SHADES  CF CF-88-15 HELL PUMP ROCKER PIN  US 49-34-02 ATTACHMEN ON THE VENTRAL FIN 70		95-01-0701	(	1300	DEDECOMANCE DECLITEMENTS	
US 87-05-02 PDH & AFM  US 87-05-02 PDH & AFM  US 97-06-11 NOSE LANDING GEAR FORK 2102R3  US 93-01-16 FUEL IN STALL WARNING VANE 2430  US 93-01-16 FUEL IN STALL WARNING VANE 2430  US 94-20-05 HOT BATTERY BUS BAR 2562  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  1900D (1900 SERIES)  US 95-02-17 ELEVATOR TRIM TAB CONTROL  US 95-02-18 ENGINE TRUSS CRACKS  US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539, 2591  US 95-26-14 CABIN PARTITION FAILURE SB 2556  US 95-16-01 WINDSHIED HEATING CIRCUIT TELEX AD 2556  US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686  US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686  US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651  US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643  US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714  US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232  US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  4701  CF CF-61-06 MAIN ROTOR BLADES  CF CF-62-10 STC SHI-512  CF CF-68-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-88-17 HOLD FROM SHADES  CF CF-88-15 HELL PUMP ROCKER PIN  US 49-34-02 ATTACHMEN ON THE VENTRAL FIN 70		85-21-07RT			FIGURIANCE REQUIREMENTS	000000
US 92-06-11 COLLINS EFIS 2423 US 93-01-16 FUEL IN STALL WARNING VANE 2430 US 94-20-05 HOT BATTERY BUS BAR 2562 US 95-02-18 ENGINE TRUSS CRACKS 2255R6 US 95-02-17 ELEVATOR TRIM TAB CONTROL US 95-02-17 ELEVATOR TRIM TAB CONTROL US 95-02-18 ENGINE TRUSS CRACKS 2255R6 US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539,2591  1900D (1900 SERIES )  US 95-02-18 ENGINE TRUSS CRACKS 2255R6 US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539,2591 US 95-26-14 CABIN PARTITION FAILURE SB 2556 US 96-15-01 WINDSHIELD HEATING CIRCUIT TELEX AD US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686 US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651 US 97-17-08 INSPECTION OF PROPELLER MOUNTING BOLTS 52-0092 US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANYARD PIN FAILURG TO PULL 35-3233 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL 4701 CF CF-61-06 MAIN ROTOR BLADES CF CF-62-10 STC SHI-512 CF CF-62-10 STC SHI-512 CF CF-88-08 MAIN ROTOR BLADES CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-88-17 HEL LOOPTER RESCUE SYSTEMS CAR 702.21 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-47-02 TAIL ROTOR DRIVE SYSTEM		01-04-24			ELEVATOR TRIM CABLE STSTEM	
US 92-06-11 COLLINS EFIS 2423 US 93-01-16 FUEL IN STALL WARNING VANE 2430 US 94-20-05 HOT BATTERY BUS BAR 2562 US 95-02-18 ENGINE TRUSS CRACKS 2255R6 US 95-02-17 CEPRMATION IN PLUMBING - INSTRUMENT AIR SB 2539,2591  1900D (1900 SERIES ) US 95-02-17 ELEVATOR TRIM TAB CONTROL US 95-02-18 ENGINE TRUSS CRACKS 2255R6 US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539,2591 US 95-26-14 ENGINE TRUSS CRACKS 2255R6 US 95-26-14 CABIN PARTITION FAILURE SB 2556 US 96-15-01 WINDSHIELD HEATING CIRCUIT TELEX AD US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686 US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651 US 97-17-08 INSPECTION OF PROPELLER MOUNTING BOLTS 52-0092 US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-18-07 OXYGEN MASK LANYARD PIN FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL 47D1 CF CF-61-06 MAIN ROTOR BLADES CF CF-62-10 STC SHI-512 CF CF-88-08 MAIN ROTOR BLADES CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-88-17 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70	US	87-05-02			POH & AFM	
US   95-02-18   ENGINE TRUSS CRACKS   22539,2591	US	87-22-01R1			NOSE LANDING GEAR FORK	
US   95-02-18   ENGINE TRUSS CRACKS   22539,2591	US	92-06-11			COLLINS EFIS	
US   95-02-18   ENGINE TRUSS CRACKS   22539,2591	US	93-01-16			FUEL IN STALL WARNING VANE	2430
US   95-02-18   ENGINE TRUSS CRACKS   22539,2591	US	94-20-05			HOT BATTERY BUS BAR	2562
1900	US	95-02-18			ENGINE TRUSS CRACKS	2255R6
1900	US	95-14-02			ICE FORMATION IN PLUMBING - INSTRUMENT AIR	SB 2539,2591
US   95-02-17						
US   95-02-17	1900D		(	1900	SERIES )	
US   95-02-18	LIS	95-02-17			FLEVATOR TRIM TAB CONTROL	
US 95-14-02 ICE FORMATION IN PLUMBING - INSTRUMENT AIR SB 2539,2591 US 95-26-14 CABIN PARTITION FAILURE SB 2556 US 96-15-01 WINDSHIELD HEATING CIRCUIT TELEX AD US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686 US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651 US 97-17-08 INSPECTION OF PROPELLER MOUNTING BOLTS 52-0092 US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANYARD PIN FAILING TO PULL 35-3233 US 99-16-12 TO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  47D1 CF CF-61-08 BUBBLE ASSEMBLIES CF CF-62-10 STC SHI-512 CF CF-83-06 SUPERCEDED BY 80-10-04 CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A CF CF-88-08 MAIN ROTOR BLADE GRIPS CF CF-88-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69		05 00 40			ENGINE TRUCK CRACKS	2255R6
US 96-15-01 WINDSHIELD HEATING CIRCUIT TELEX AD US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686 US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651 US 97-17-08 INSPECTION OF PROPELLER MOUNTING BOLTS 52-0092 US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANYARD PIN FAILING TO PULL 35-3233 US 99-16-12 TO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  **BELL**  47D1** CF** CF-61-06 MAIN ROTOR BLADES CF** CF-62-10 STC SHI-512 CF** CF-83-06 SUPERCEDED BY 80-10-04 CF** CF-88-08 MAIN ROTOR BLADE GRIPS CF** CF-88-17 WOOD MAIN ROTOR BLADES CF** CF-88-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69		95-14-03			TOE FORMATION IN DILIMBING - INSTRUMENT AID	SR 2539 2591
US 96-15-01 WINDSHIELD HEATING CIRCUIT TELEX AD US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686 US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651 US 97-17-08 INSPECTION OF PROPELLER MOUNTING BOLTS 52-0092 US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANYARD PIN FAILING TO PULL 35-3233 US 99-16-12 TO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  **BELL**  47D1** CF** CF-61-06 MAIN ROTOR BLADES CF** CF-62-10 STC SHI-512 CF** CF-83-06 SUPERCEDED BY 80-10-04 CF** CF-88-08 MAIN ROTOR BLADE GRIPS CF** CF-88-17 WOOD MAIN ROTOR BLADES CF** CF-88-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69		95-26-14			CARIN DADTITION FAILURE	SR 2556
US 97-03-01 WING SKIN DEBONDING OR WINDOW WARPING 2686 US 97-10-14 CRACKS IN STABILON ATTACHMENT ANGLES 2651 US 97-17-08 INSPECTION OF PROPELLER MOUNTING BOLTS 52-0092 US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANYARD PIN FAILING TO PULL 35-3233 US 99-16-12 TO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  47D1 CF CF-61-06 MAIN ROTOR BLADES CF CF-62-10 STC SHI-512 CF CF-62-10 STC SHI-512 CF CF-83-06 SUPERCEDED BY 80-10-04 CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	06-15-04			WINDCHIEFD HEATING CIDCHIT	TELEY AD
US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANVARD PIN FAILING TO PULL 35-3233 US 99-16-12 TO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  ### APD1  CF CF-61-06 MAIN ROTOR BLADES CF CF-62-10 STC SHI-512  CF CF-62-06 SUPERCEDED BY 80-10-04 CF CF-83-06 SUPERCEDED BY 80-10-04 CF CF-88-07 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	05	98-15-01			WINDSHIELD HEATING CIRCUIT	OCOC AD
US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANVARD PIN FAILING TO PULL 35-3233 US 99-16-12 TO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  ### APD1  CF CF-61-06 MAIN ROTOR BLADES CF CF-62-10 STC SHI-512  CF CF-62-06 SUPERCEDED BY 80-10-04 CF CF-83-06 SUPERCEDED BY 80-10-04 CF CF-88-07 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	97-03-01			WING SKIN DEBUNDING OK WINDOW WARPING	2000
US 98-09-12 LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS 2643 US 98-13-11 "GROUND FINE SWITCH INSTALLATION KIT" 2714 US 99-09-15 FLIGHT CONTROL MECHANISM CLEARANCE 27-3232 US 99-12-07 OXYGEN MASK LANVARD PIN FAILING TO PULL 35-3233 US 99-16-12 TO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080 US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  ### APD1  CF CF-61-06 MAIN ROTOR BLADES CF CF-62-10 STC SHI-512  CF CF-62-06 SUPERCEDED BY 80-10-04 CF CF-83-06 SUPERCEDED BY 80-10-04 CF CF-88-07 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	97-10-14			CRACKS IN STABILON ATTACHMENT ANGLES	2651
US 99-16-12 IO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080  99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  47D1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-61-08 BUBBLE ASSEMBLIES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	97-17-08			INSPECTION OF PROPELLER MOUNTING BOLTS	52-0092
US 99-16-12 IO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080  99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  47D1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-61-08 BUBBLE ASSEMBLIES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	98-09-12			LOSS OF AIRCRAFT COMMUNICATIONS SYSTEMS	2643
US 99-16-12 IO PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080  99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  47D1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-61-08 BUBBLE ASSEMBLIES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	98-13-11			"GROUND FINE SWITCH INSTALLATION KIT"	2714
US 99-16-12 IN PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080  99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  47D1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-61-08 BUBBLE ASSEMBLIES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	99-09-15			FLIGHT CONTROL MECHANISM CLEARANCE	27-3232
US 99-16-12 IN PREVENT FAILURE OF THE ELECTRIC ELEVATOR TRIM 27-3080  99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  BELL  47D1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-61-08 BUBBLE ASSEMBLIES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	99-12-07			OXYGEN MASK LANYARD PIN FAILING TO PULL	35-3233
US 99-18-15 IMPROPERLY MACHINED LNDNG GEAR EMERGENCY HAND PUMP NIL  ### ATD1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-61-08 BUBBLE ASSEMBLIES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADE GRIPS 47-85-12 REV A  CF CF-88-07 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US	99-16-12			TO PREVENT FAILURE OF THE ELECTRIC FLEVATOR TRIM	27-3080
### ### ##############################					IMPROPERLY MACHINED INDNG GEAR EMERGENCY HAND PLIMP	
47D1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADES 47-85-12 REV A  CF CF-88-17 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	03	00 10 10			THE ENE PROPERTY CONTRACTOR THREE PORT	
47D1  CF CF-61-06 MAIN ROTOR BLADES  CF CF-62-10 STC SHI-512  CF CF-83-06 SUPERCEDED BY 80-10-04  CF CF-88-08 MAIN ROTOR BLADES 47-85-12 REV A  CF CF-88-07 WOOD MAIN ROTOR BLADES  CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21  US 48-13-02 FUEL PUMP ROCKER PIN  US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	RELL					
CF         CF-61-06         MAIN ROTOR BLADES           CF         CF-61-08         BUBBLE ASSEMBLIES           CF         CF-62-10         STC SHI-512           CF         CF-83-06         SUPERCEDED BY 80-10-04           CF         CF-88-08         MAIN ROTOR BLADE GRIPS         47-85-12 REV A           CF         CF-88-17         WOOD MAIN ROTOR BLADES         CAR 702.21           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           US         48-13-02         FUEL PUMP ROCKER PIN           US         49-34-02         ATTACHING CLAMPS ON THE VENTRAL FIN         70           US         49-47-02         TAIL ROTOR DRIVE SYSTEM         69						
CF         CF-61-08         BUBBLE ASSEMBLIES           CF         CF-62-10         STC SHI-512           CF         CF-83-06         SUPERCEDED BY 80-10-04           CF         CF-88-08         MAIN ROTOR BLADE GRIPS         47-85-12 REV A           CF         CF-88-17         WOOD MAIN ROTOR BLADES         CAR 702.21           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           US         48-13-02         FUEL PUMP ROCKER PIN         TO           US         49-34-02         ATTACHING CLAMPS ON THE VENTRAL FIN         70           US         49-47-02         TAIL ROTOR DRIVE SYSTEM         69		CF-61-00			MAIN BOTOR PLANES	
CF         CF-62-10         STC SHI-512           CF         CF-83-06         SUPERCEDED BY 80-10-04           CF         CF-88-08         MAIN ROTOR BLADE GRIPS         47-85-12 REV A           CF         CF-88-17         WOOD MAIN ROTOR BLADES           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           US         48-13-02         FUEL PUMP ROCKER PIN           US         49-34-02         ATTACHING CLAMPS ON THE VENTRAL FIN         70           US         49-47-02         TAIL ROTOR DRIVE SYSTEM         69						
CF         CF-83-06         SUPERCEDED BY 80-10-04           CF         CF-88-08         MAIN ROTOR BLADE GRIPS         47-85-12 REV A           CF         CF-88-17         WOOD MAIN ROTOR BLADES         CAR 702.21           US         48-13-02         HELICOPTER RESCUE SYSTEMS         CAR 702.21           US         49-34-02         FUEL PUMP ROCKER PIN         70           US         49-47-02         TAIL ROTOR DRIVE SYSTEM         69						
CF       CF-88-08       MAIN ROTOR BLADE GRIPS       47-85-12 REV A         CF       CF-88-17       WOOD MAIN ROTOR BLADES         CF       CF-98-15       HELICOPTER RESCUE SYSTEMS       CAR 702.21         US       48-13-02       FUEL PUMP ROCKER PIN         US       49-34-02       ATTACHING CLAMPS ON THE VENTRAL FIN       70         US       49-47-02       TAIL ROTOR DRIVE SYSTEM       69						
CF CF-88-17 WOOD MAIN ROTOR BLADES CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 48-13-02 FUEL PUMP ROCKER PIN US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69						
CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           US         48-13-02         FUEL PUMP ROCKER PIN           US         49-34-02         ATTACHING CLAMPS ON THE VENTRAL FIN         70           US         49-47-02         TAIL ROTOR DRIVE SYSTEM         69					MAIN ROTOR BLADE GRIPS	47-85-12 REV A
CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           US         48-13-02         FUEL PUMP ROCKER PIN         70           US         49-34-02         ATTACHING CLAMPS ON THE VENTRAL FIN         70           US         49-47-02         TAIL ROTOR DRIVE SYSTEM         69		CF-88-17				
US 48-13-02 FUEL PUMP ROCKER PIN US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	CF	CF-98-15				CAR 702.21
US 49-34-02 ATTACHING CLAMPS ON THE VENTRAL FIN 70 US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69	US				FUEL PUMP ROCKER PIN	
US 49-47-02 TAIL ROTOR DRIVE SYSTEM 69						70
110						
The state of the s						
					THE TOTAL THOU THOSE DOLLARS	00

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

	TOWNER OF CONTONE	SUJET	BULLETIN DE SERVICE DE REF.
BELL			
47D1			
	NUED / SUITE)		
US	50-06-01	VENTRAL FIN REPLACEMENT	71
US US	50-38-02 51-26-01	COOLIN FAN REWORK	72
US	51-26-01	TAIL ROTOR REINFORCEMENT	75
US	51-29-01	ENGINE MOUNT REPLACEMENT TAIL ROTOR GEARBOX SHAFT	
US	52-01-01	BLADE GRIP ADAPTER LOCKS	
US	52-01-06	TAIL BOOM SPOILER	
US	52-01-07	ENGINE COOLING FAN	
US	52-05-03	ENGINE MOUNT SAFETY STRAP	
US	52-07-01	LOADING DECAL	
US US	52-21-01 52-28-03	LORD MOUNT GUARDS	
US	52-28-03	TAIL ROTOR GEARBOX SHAFT	
US	53-01-01	TAIL ROTOR PINION SHAFT GEARBOX MOUNTING SLEEVE	
US	54-24-01	ANTI-TORQUE PEDAL STOPS	
US	55-05-01	PITCH CONTROL LINK	
US	55-16-01	TAIL ROTOR HUB FILLET	
US	56-05-01	TAIL ROTOR DRIVE SHAFTS	
US	56-15-02	SWASHPLATE CONTROL RING	
US	56-20-03	TAIL ROTOR HUB BOLTS	
US US	56-25-02 57-07-02	TAIL ROTOR PITCH BEARINGS	
US	57-07-02	ROTOR HUB EQUALIZER LINK TAIL ROTOR DRIVE SHAFTS	
US	57~08~02	PARKER CHECK VALVE	
US	57-12-04	TAIL ROTOR BLADE INSPECTION	
US	58-23-01	TAIL ROTOR PITCH CHANGE BEARINGS	
US	58-26-02	M-S MA4-5AA CARBURETOR	
US	59-05-01	TAIL ROTOR BLADE INSPECTION	
US	60-10-01	SCISSOR LEVER BOLTS	129
US	61-22-01	PITCH LINK ROD END BEARING	
US	62-23-02	MAIN ROTOR MAST THRUST BEARING	
US US	62-27-02 65-04-01	WOOD TAIL ROTOR BLADES FREEWHEELING CLUTCH	
US	70-08-02	TAIL ROTOR DRIVE SHAFT	
US	70-10-08	TAIL ROTOR GRIPS	
US	70-11-04	WOOD MAIN ROTOR BLADES	
US	70-14-01	TAIL ROTOR PITCH	
US	70-14-02	TAIL ROTOR HUB ASSY BOLT	
US	73-19-02	TAIL ROTOR YOKE	
US	73-19-04	MAIN ROTOR BLADE GRIP	
US US	74-07-01 74-08-02	MAIN ROTOR CONTROL TUBE ASSY MAIN CONTROL STABILIZER BAR ASSY	
US	75-18-06	TAIL ROTOR PITCH CONTROL	
US	76-12-01	TAIL ROTOR HUB BOLT	
US	76-12-02	TAIL ROTOR YOKE	
US	77-21-01	TAIL ROTOR GEAR BOXES	
US	78-03-01	HOPPER SUPPORT BRACKET (STC SH357SW)	
US	80-10-04R1	TAIL ROTOR BLADES	
US	80-21-09R1	TAIL ROTOR PITCH LINK	ASB 47-80-5 REV A ASB 47-80-6
US	81-04-03	TAIL ROTOR DRIVE ASSEMBLY TAIL ROTOR BLADE ASSY	ASB 47-84-11
US US	85-08-03 85-15-04	TAIL ROTOR BLADE YOKE P/N 74-641-057-9	A35 47 37 11
US	85-15-04 86-06-08R1	MAIN ROTOR BLADE GRIPS	
US	96-06-12	TAIL ROTOR BLADE ASSY P/N 047-642-117-105	ASB 47-96-21
US	98-07-09	STABILIZER BAR DAMPER LINK ASSEMBLY	47-96-22
47G S	ERIES		
CF	CF-61-06	MAIN ROTOR BLADES	
CF	CF-61-08	BUBBLE ASSEMBLIES	
CF	CF-62-10	STC SHI-512 SUPERCEDED BY 80-10-04	
CF CF	CF-83-06 CF-88-08	MAIN ROTOR BLADE GRIPS	47-85-12 REV A
CF	CF-88-08 CF-88-17	WOOD MAIN POTOR BLADES	
CF	CF-90-23	STABILIZER BAR DAMPER FRAME CLAMP	ASB 47-81-7
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	48-13-02	FUEL PUMP ROCKER PIN	
US	51-27-01	ENGINE MOUNT REPLACEMENT	
US	52-01-06	TAIL BOOM SPOILER	
US	52-05-03	ENGINE MOUNT SAFETY STRAP	
US	52-21-01	LORD MOUNT GUARDS	
US	52-28-03	TAIL ROTOR GEARBOX SHAFT TAIL ROTOR HUB FILLET	
US	55-16-01	TATE ROTOR TIDE LITERAL	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT

0111011	TO NOTICE OF CONSTONE	30001	BOLLETIN DE SERVICE DE REF.
0511			
BELL	CERTER		
	SERIES		
	INUED / SUITE)		
US	56-05-01	TAIL ROTOR DRIVE SHAFTS	
US	56-15-02	SWASHPLATE CONTROL RING	
US	56-25-02	TAIL ROTOR PITCH BEARINGS	
US	57-07-02	ROTOR HUB EQUALIZER LINK	
US	57-08-01	TAIL ROTOR DRIVE SHAFTS	
US	57-12-04	TAIL ROTOR BLADE INSPECTION	
US	58-26-02	M-S MA4-5AA CARBURETOR	
US	59-05-01	TAIL ROTOR BLADE INSPECTION	
US	60-10-01	SCISSOR LEVER BOLTS	129
US	61-22-01	PITCH LINK ROD END BEARING	120
US	62-23-02	MAIN ROTOR MAST THRUST BEARING	
US	62-27-02	WOOD TAIL ROTOR BLADES	
ÜS	65-04-01	FREEWHEELING CLUTCH	
US	70-08-02	TAIL ROTOR DRIVE SHAFT	
US	70-10-08	TAIL ROTOR GRIPS	
US	70-14-02	TAIL ROTOR HUB ASSY BOLT	
US	72-02-05		
US	73-19-04	CONTROL ROD ASSEMBLY	47-146
US		MAIN ROTOR BLADE GRIP	
	74-07-01	MAIN ROTOR CONTROL TUBE ASSY	
US	74-08-02	MAIN CONTROL STABILIZER BAR ASSY	
US	77-21-01	TAIL ROTOR GEAR BOXES	
US	78-03-01	HOPPER SUPPORT BRACKET (STC SH357SW)	
US	79-23-07	SOLOY CONVERSION PER STC SH657NW	
US	80-10-04R1	TAIL ROTOR BLADES	
US	80-21-09R1	TAIL ROTOR PITCH LINK	ASB 47-80-5 REV A
US	81-04-03	TAIL ROTOR DRIVE ASSEMBLY	ASB 47-80-6
US	85-08-03	TAIL ROTOR BLADE ASSY	ASB 47-84-11
US	85-15-04	TAIL ROTOR BLADE YOKE P/N 74-641-057-9	
US	86-06-08R1	MAIN ROTOR BLADE GRIPS	
US	91-20-10	MAIN ROTOR GRIPS (NON APPROVED PARTS)	
US	96-06-12	TAIL ROTOR BLADE ASSY P/N 047-642-117-105	ASB 47-96-21
US	98-07-09	STABILIZER BAR DAMPER LINK ASSEMBLY	47-96-22
		The state of the s	77 30 22
47G		( 47G SERIES )	
US	54-24-01	ANTI-TORQUE PEDAL STOPS	
US	55-05-01	PITCH CONTROL LINK	
US	55-14-01	BEARING HANGER SUPPORT BRACKET	
US	55-25-01	BELLCRANK ATTACHMENT BOLT	
US	56-01-01	VENTRAL FIN SUPPORT	400
US	56-20-03		103
US	56-21-01	TAIL ROTOR HUB BOLTS	
US	57-08-02	HYDRAULIC BOOST CYLINDERS	
US		PARKER CHECK VALVE	
US	58-23-01	TAIL ROTOR PITCH CHANGE BEARINGS	
	70-11-04	WOOD MAIN ROTOR BLADES	
US	70-14-01	TAIL ROTOR PITCH	
US	73-19-02	TAIL ROTOR YOKE	
US	75-18-06	TAIL ROTOR PITCH CONTROL	
US	76-12-01	TAIL ROTOR HUB BOLT	
US	76-12-02	TAIL ROTOR YOKE	
47G2		( 47G SERIES )	
US	56-01-01	VENTRAL FIN SUPPORT	103
US	56-20-03	TAIL ROTOR HUB BOLTS	
US	56-21-01	HYDARULIC BOOST CYLINDERS	
US	58-23-01	TAIL ROTOR PITCH CHANGE BEARINGS	
US	58-26-01	ENGINE COOLING FIN INDEX PLATE ASSY	
US	61-14-02	FLOAT CROSS TUBE	122
US	70-11-04	WOOD MAIN ROTOR BLADES	132
US	70-14-01		
US	73-19-02	TAIL ROTOR PITCH	
US	75-18-06	TAIL ROTOR YOKE	
US	76-12-01	TAIL ROTOR PITCH CONTROL	
US		TAIL ROTOR HUB BOLT	
03	76-12-02	TAIL ROTOR YOKE	
47G2A		450 050	
		( 47G SERIES )	
US	56-01-01	VENTRAL FIN SUPPORT	103
US	61-14-02	FLOAT CROSS TUBE	132
US	85-02-06	AN / NAS STANDARD BOLTS	
47G3B		( 47G SERIES )	
US	61-14-02	FLOAT CROSS TUBE	132
U\$	85-02-06	AN / NAS STANDARD BOLTS	102
ATDC	PAFT / AFPONEES		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

ONIGINA	NOMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
0511				
8ELL 47G3E	2.0	( 470	0.000	
US			SERIES )	
US	85-02-06		FLOAT CROSS TUBE	132
	03 02 00		AN / NAS STANDARD BOLTS	
47G4		( 47G	SERIES )	
US	85-02-06		AN / NAS STANDARD BOLTS	
			7. MAS STANDARD BULTS	
47G4A		( 47G	SERIES )	
US	85-02-06		AN / NAS STANDARD BOLTS	
	ERIES			
CF	CF-61-06		MAIN ROTOR BLADES	
CF	CF-61-08		BUBBLE ASSEMBLIES	
CF	CF-62-10		STC SHI-512	
CF CF	CF-83-06 CF-88-08		SUPERCEDED BY 80-10-04	
CF	CF-88-08		MAIN ROTOR BLADE GRIPS	47-85-12 REV A
CF	CF-90-23		WOOD MAIN ROTOR BLADES	
CF	CF-98-15		STABILIZER BAR DAMPER FRAME CLAMP	ASB 47-81-7
US	48-13-02		HELICOPTER RESCUE SYSTEMS FUEL PUMP ROCKER PIN	CAR 702.21
US	51-27-01		ENGINE MOUNT REPLACEMENT	
US	52-01-06		TAIL BOOM SPOILER	
US	52-05-03		ENGINE MOUNT SAFETY STRAP	
US	52-21-01		LORD MOUNT GUARDS	
US	52-28-03		TAIL ROTOR GEARBOX SHAFT	
US	55-16-01		TAIL ROTOR HUB FILLET	
US	56-05-01		TAIL ROTOR DRIVE SHAFTS	
US	56-15-02		SWASHPLATE CONTROL RING	
US	56-25-02		TAIL ROTOR PITCH BEARINGS	
US	57-07-02		ROTOR HUB EQUALIZER LINK	
US	57-08-01		TAIL ROTOR DRIVE SHAFTS	
US	57-12-03		ENGINE SPRAG SPINDLE	
US	57-12-04		TAIL ROTOR BLADE INSPECTION	
US US	58-02-01 58-09-01		ROTOR BLADE BOND SEPARATION MAIN ROTOR BLADE INSPECTION	
US	58-17-01		ROTOR COUNTERWEIGHT BRACKET	
US	58-26-01		ENGINE COOLING FAN INDEX PLATE ASSY	
US	58-26-02		M-S MA4-5AA CARBURETOR	
US	59-05-01		TAIL ROTOR BLADE INSPECTION	
US	60-10-01		SCISSOR LEVER BOLTS	129
US	61-22-01	1	PITCH LINK ROD END BEARING	1
US	62-10-01		ELEVATOR MODIFICATION	56 SL
US	62-23-02	ľ	MAIN ROTOR MAST THRUST BEARING	
US	62-27-02		WOOD TAIL ROTOR BLADES	
US	65-04-01		FREEWHEELING CLUTCH	
US	70-08-02		TAIL ROTOR DRIVE SHAFT	
US	70-10-08		TAIL ROTOR GRIPS	17-146
US	72-02-05		CONTROL ROD ASSEMBLY	47-146
US	73-19-04		MAIN ROTOR BLADE GRIP MAIN ROTOR CONTROL TUBE ASSY	
US US	74-07-01		WAIN CONTROL TOBE ASSY WAIN CONTROL STABILIZER BAR ASSY	
US	74-08-02 77-21-01		TAIL ROTOR GEAR BOXES	
US	78-03-01		HOPPER SUPPORT BRACKET (STC SH357SW)	
US	80-10-04R1		TAIL ROTOR BLADES	
US	80-21-09R1		TAIL ROTOR PITCH LINK	ASB 47-80-5 REV A
US	81-04-03		TAIL ROTOR DRIVE ASSEMBLY	ASB 47-80-6
US	85-08-03		TAIL ROTOR BLADE ASSY	ASB 47-84-11
US	86-06-08R1		MAIN ROTOR BLADE GRIPS	
US	91-20-10		MAIN ROTOR GRIPS (NON APPROVED PARTS)	
US	96-06-12		TAIL ROTOR BLADE ASSY P/N 047-642-117-105	ASB 47-96-21
US	98-07-09	5	STABILIZER BAR DAMPER LINK ASSEMBLY	47-96-22
			CENTEC )	
47J			SERIES )	
US	85-02-06	1	AN / NAS STANDARD BOLTS	
		/ 47 1	crotec )	
47J2	04 00 04		SERIES )	
US	61-03-01		NN / NAS STANDARD BOLTS	
US	85-02-06	-	NIA / HAD DIMINDAND DOCTO	
204B				
CF	CF-88-23R1	F	BLADE STRAP PINS	A8-27-45
CF	CF-90-06		TAIL ROTOR PITCH CHANGE CHAIN	
CF	CF-90-16R3		MAIN ROTOR YOKE	204-90-25 REV A
CF	CF-91-27		MERGENCY ESCAPE RELEASE HANDLE COVERS	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

<i>BELL</i> 204B			
2/1/10			
	W.ED / CULTURE		
	NUED / SUITE)	AET FAOTAG CEAT UEADDECTC	
CF	CF-91-29R1	AFT FACING SEAT HEADRESTS	204-02-20 BEV A
CF	CF-94-07	ZINC PRIMER AS OVERHEAT INDICATOR	204-93-39 REV A
CF	CF-95-07	42-DEGREE GEAR BOX_P/N 204-040-003-023 OR -037	SUPERCEDES 95-10-0
CF	CF-95-20R1	BOLTS OF FLIGHT CONTROL SERVO ACTUATORS	204-67-01
CF	CF-96-06	EMERGENCY ESCAPE PANELS	CAR 700 04
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	67-06-01	TAIL ROTOR BLADES	
US	67-24-01	SLIDERS ON TAIL ROTOR ASSY	
US	69-15-07	FLOAT KIT TUBE	
US	70-06-02	TAIL ROTOR GRIP ASSY	
US	73-17-04	TAIL ROTOR GRIPS	
US	74-23-02	TAIL ROTOR PITCH	
US	75-26-03	EMERGENCY EXIT HANDLE	
US	75-26-05	MAIN ROTOR BLADES	
US	76-02-06	MAIN ROTOR BLADES	
US	76-12-07	TAIL ROTOR CHAINS	
US	77-17-05	EMERGENCY EXIT LATCH PIN	
US	78-20-07	SHOULDER RADIUS FITTING	
US	78-21-02	EXTERNAL LOAD LINK ASSEMBLY	
US	79-20-05	MAIN ROTOR HUB ASSEMBLY	
US	80-17-09	MAIN ROTOR STRAPS	100 001 -
US	81-19-02	MAIN ROTOR YOKE	ASB 204-81-11
US	88-25-05	TAIL ROTOR GRIP ASSEMBLY	
US	89-08-05	MAIN TRANSMISSION - SPIRAL BEVEL GEARS	
US	89-20-12	TAIL ROTOR HUB (BOGUS PART)	
US	90-01-11	TAIL ROTOR DUPLEX BEARING	
US	90-03-10	ALUMINUM TAIL ROTOR GRIPS	
US	92-07-08	SWASHPLATE SUPPORT ASSEMBLY	204-91-32
US	92-13-10	TAIL ROTOR DRIVESHAFT HANGER BEARINGS	SUPERCEDES 91-24-1
US	92-23-01	TAIL ROTOR DRIVESHAFT HANGER BEARINGS PREVENT SEPERATION MAIN ROTOR PILLOW BLOCKS	204-90-27 REV A
US	93-17-12	MAIN ROTUR TRANSMISSION LOWER PLANETARY SPIDER	SUPERCEDES 92-11-0
US	96-12-25	TAIL ROTOR BLADE DEBONDING	ASB 204-96-48 REV
US	98-24-15	MAIN ROTOR MAST / TRUNNION	204-95-47
US	99-17-03	FAILURE OF TAILBOOM VERTICAL FIN SPAR	ASB 204B-98-50
205 SE	RIFS		
		MEDITAL ETAL COAR ALO	
US	99-18-02	VERTICAL FIN SPAR CAP	ASB 205-98-70
US	99-18-02		ASB 205-98-70
US 205A 1	99-18-02 (	( 205 SERIES )	
US <b>205A 1</b> CF	99-18-02 I ( CF-90-16R3	( 205 SERIES ) MAIN ROTOR YOKE	ASB 205-98-70 205-90-36 REV A
US 205A 1 CF CF	99-18-02 I ( CF-90-16R3 CF-91-27	205 SERIES ) MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS	
US  205A 1  CF  CF  CF	99-18-02 I ( CF-90-16R3 CF-91-27 CF-91-29R1	( 205 SERIES )  MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS  AFT FACING SEAT HEADRESTS	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF	99-18-02 I ( CF-90-16R3 CF-91-27 CF-91-29R1 CF-94-07	205 SERIES )  MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS  AFT FACING SEAT HEADRESTS  ZINC PRIMER AS OVERHEAT INDICATOR	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  CF	99-18-02 (CF-90-16R3 CF-91-27 CF-91-29R1 CF-94-07 CF-95-20R1	205 SERIES )  MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS  AFT FACING SEAT HEADRESTS  ZINC PRIMER AS OVERHEAT INDICATOR  BOLTS OF FLIGHT CONTROL SERVO ACTUATORS	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  CF  CF	99-18-02 (	205 SERIES )  MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS  AFT FACING SEAT HEADRESTS  ZINC PRIMER AS OVERHEAT INDICATOR  BOLTS OF FLIGHT CONTROL SERVO ACTUATORS  EMERGENCY ESCAPE PANELS	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  CF  US	99-18-02 (CF-90-16R3 CF-91-27 CF-91-29R1 CF-94-07 CF-95-20R1 CF-96-06 69-15-07	MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  US  US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02	MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  US  US  US	99-18-02  (CF-90-16R3 (F-91-27 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02	205 SERIES ) MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  US  US  US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03	MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  US  US  US  US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04	MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  US  US  US  US  US  US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US	99-18-02  (CF-90-16R3 (F-91-27 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01	MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH	205-90-36 REV A
US 205A 1 CF CF CF CF US US US US US US US US US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03	MAIN ROTOR YOKE EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR GRIPS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES	205-90-36 REV A
US 205A 1 CF CF CF CF US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES	205-90-36 REV A
US 205A 1 CF CF CF CF US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT	205-90-36 REV A
US 205A 1 CF CF CF CF US	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 (70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (F-91-27 (CF-91-29R1 (F-94-07 (CF-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03 77-10-07	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 (70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 77-17-03	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03 77-17-03	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN	205-90-36 REV A
US  205A 1  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 77-17-03 77-17-03 77-17-05 78-14-07	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN	205-90-36 REV A
US 205A 1 CF CF CF CF CF US	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 (70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03 77-17-05 78-14-07 78-20-07	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN	205-90-36 REV A
US 205A 1 CF CF CF CF US	99-18-02  (CF-90-16R3 (F-91-27 (CF-91-29R1 (F-94-07 (CF-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03 77-17-03 77-17-03 77-17-05 78-14-07 78-21-02	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR	205-90-36 REV A
US 205A 1 CF CF CF CF CF US	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 (70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03 77-17-05 78-14-07 78-20-07	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR SHOULDER RADIUS FITTING	205-90-36 REV A
US 205A 1 CF CF CF CF US	99-18-02  (CF-90-16R3 (F-91-27 (CF-91-29R1 (F-94-07 (CF-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03 77-17-03 77-17-03 77-17-05 78-14-07 78-21-02	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR GRIPS TAIL ROTOR GRIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR SHOULDER RADIUS FITTING EXTERNAL LOAD LINK ASSEMBLY	205-90-36 REV A
US 205A 1 CF CF CF CF CF US	99-18-02  (CF-90-16R3 (F-91-27 (F-91-29R1 (F-94-07 (F-95-20R1 (F-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 77-17-03 77-17-05 78-14-07 78-20-07 78-21-02 79-20-05	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR SHOULDER RADIUS FITTING EXTERNAL LOAD LINK ASSEMBLY MAIN ROTOR HUB ASSEMBLY MAIN ROTOR HUB ASSEMBLY MAIN ROTOR STRAPS	205-90-36 REV A
US 205A 1 CF CF CF CF CF US	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-95-20R1 (CF-96-06 69-15-07 (70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-02-06 76-010-01 76-12-07 76-14-03 77-17-05 78-14-07 78-20-07 78-21-02 79-20-05 80-17-09	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS  EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE SENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR SHOULDER RADIUS FITTING EXTERNAL LOAD LINK ASSEMBLY MAIN ROTOR HUB ASSEMBLY	205-90-36 REV A 205-93-58 REV A 205-67-01
US 205A 1 CF CF CF CF US	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-03 75-26-05 76-02-06 76-01-001 76-12-07 76-14-03 77-17-05 78-14-07 778-20-07 78-21-02 79-20-05 80-17-09 80-21-05	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR RIPS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR SHOULDER RADIUS FITTING EXTERNAL LOAD LINK ASSEMBLY MAIN ROTOR HUB ASSEMBLY MAIN ROTOR HUB ASSEMBLY MAIN ROTOR STRAPS LANDING GEAR CROSS TUBES MAIN ROTOR YOKE	205-90-36 REV A 205-93-58 REV A 205-67-01
US 205A 1 CF CF CF CF CF US	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-96-06 69-15-07 70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-03 75-26-05 76-02-06 76-06-02 76-10-01 76-12-07 76-14-03 77-17-05 78-14-07 77-17-05 78-14-07 78-20-07 78-21-02 79-20-05 80-17-09 80-21-05 81-19-02 86-17-10 92-07-08	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR FIPS TAIL ROTOR PITCH EMERGENCY EXIT HANDLE MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR SHOULDER RADIUS FITTING EXTERNAL LOAD LINK ASSEMBLY MAIN ROTOR STRAPS LANDING GEAR CROSS TUBES MAIN ROTOR STRAPS LANDING GEAR CROSS TUBES MAIN ROTOR STRAPS LANDING GEAR CROSS TUBES MAIN ROTOR TRUNNION BEARING HOUSING SWASHPLATE SUPPORT ASSEMBLY	205-90-36 REV A  205-93-58 REV A  205-67-01  ASB 204-81-11  205-86-24RA
US  205A 1  CF  CF  CF  CF  CF  US  US  US  US  US  US  US  US  US  U	99-18-02  (CF-90-16R3 (CF-91-27 (CF-91-27 (CF-91-29R1 (CF-94-07 (CF-95-20R1 (CF-95-20R1 (CF-96-06 69-15-07 (70-06-02 71-21-02 73-16-03 73-17-04 74-02-01 74-23-02 75-26-03 75-26-05 76-02-06 76-02-06 76-01-01 76-12-07 77-17-03 77-17-03 77-17-05 78-14-07 78-20-07 78-21-02 79-20-05 80-17-09 80-21-05 81-19-02 86-17-10	MAIN ROTOR YOKE  EMERGENCY ESCAPE RELEASE HANDLE COVERS AFT FACING SEAT HEADRESTS ZINC PRIMER AS OVERHEAT INDICATOR BOLTS OF FLIGHT CONTROL SERVO ACTUATORS EMERGENCY ESCAPE PANELS FLOAT KIT TUBE TAIL ROTOR GRIP ASSY TAIL FIN AND BOOM LANDING GEAR CROSS TUBES TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR TRUNNION BEARINGS TAIL ROTOR BLADES MAIN ROTOR BLADES MAIN ROTOR BLADES MAIN ROTOR BLADES FIRE EXTINGUISHER CIRCUIT TAIL BOOM TAIL ROTOR CHAINS CROSS TUBE ASSEMBLIES ENGINE-TO-TRANSMISSION ASSY TAIL ROTOR BLADE PITCH HORN EMERGENCY EXIT LATCH PIN SKID LANDING GEAR SHOULDER RADIUS FITTING EXTERNAL LOAD LINK ASSEMBLY MAIN ROTOR HUB ASSEMBLY MAIN ROTOR HUB ASSEMBLY MAIN ROTOR STRAPS LANDING GEAR CROSS TUBES MAIN ROTOR STRAPS LANDING GEAR CROSS TUBES MAIN ROTOR STRAPS LANDING GEAR CROSS TUBES	205-90-36 REV A 205-93-58 REV A 205-67-01

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

			SOJET	BULLETIN DE SERVICE DE REF.
DELL				
BELL				
205A		( 205	SERIES )	
	NUED / SUITE)			
US	92-23-01		PREVENT SEPERATION MAIN ROTOR PILLOW BLOCKS	205-90-38 REV A
US US	92-27-21		TAIL ROTOR DRIVE SHAFT	205-92-49
US	93-17-12		MAIN ROTOR TRANSMISSION LOWER PLANETARY SPIDER	SUPERCEDES 92-11-07
US	94-18-09		MAIN TRANSMISSION LOWER PLANETARY SPIDER	205-93-54
US	98-11-14 98-24-15		TAIL ROTOR YOKE ASSY FAILURE	ASB205-96-68/69
US	99-17-03		MAIN ROTOR MAST / TRUNNION	205-95-65
03	99-17-03		FAILURE OF TAILBOOM VERTICAL FIN SPAR	ASB 205-98-71 REV A
205B		( 20E	CEDITE	
US	81-19-02	( 205	SERIES )	
US	92-07-08		MAIN ROTOR YOKE	ASB 205-81-16
US	92-13-10		SWASHPLATE SUPPORT ASSEMBLY	204-91-32
US	92-23-01		TAIL ROTOR DRIVESHAFT HANGER BEARINGS	SUPERCEDES 91-24-16
us	92-27-21		PREVENT SEPERATION MAIN ROTOR PILLOW BLOCKS TAIL ROTOR DRIVE SHAFT	212-90-62 REV A
US	93-17-12		MAIN ROTOR TRANSMISSION LOWER PLANETARY SPIDER	205-92-49
US	94-18-09		MAIN TRANSMISSION LOWER PLANETARY SPIDER	SUPERCEDES 92-11-07
US	98-11-14		TAIL ROTOR YOKE ASSY FAILURE	412-93-72 REV A
US	98-24-15		MAIN ROTOR MAST / TRUNNION	ASB205-96-68/69
	20 2. 70		PIATIV ROTOR PIAST / TROMITON	205-90-01 REV A
206 S	ERIES			
CF	CF-95-11R2		UNAPPROVED BOLTS, FLIGHT CONTROL SERVO ACTUATORS	206-67-02,206-67A-01
CF	CF-95-17		CROSSTUBE FAILURES	AA-ASB 94045/94046
CF	CF-96-11		FUEL CELL VENT TUBE - WATER INGESTION	206-95-156
CF	CF-97-03		MAST AND TRUNNION RETIREMENT LIFE	200 33 130
CF	CF-98-15		HELICOPTER RESCUE SYSTEMS	CAR 702.21
CF	CF-98-43		CROSSTUBE ASSEMBLIES	OAR 702.21
US	82-16-12		WITH CHADWICK C-22 AFS PER STC SH139W	CHADWICK SB 20-81-01
US	95-09-06			206-90-54/206L-90-67
				200 30 34/2001 30 0/
206A		( 206	SERIES )	
CF	CF-72-09	,	BLADE RETENTION FITTINGS/PINS	
CF	CF-78-09		REPLACEMENT OF SEAT BELT RIVETS	
CF	CF-91-35		CABIN ROOF BOXBEAM	
CF	CF-95-19		TEMP-PLATES OVERHEAT INDICATORS	ASB 206-93-76 REVB
US	67-22-02		GROUNDING OF FUEL BOOST PUMPS	
US	68-04-02		FAILURE OF EXHAUST STACK CLAMPS	
US	69-11-02		CYCLIC CONTROL SYSTEM	
US	69-11-04		CONTROL PEDAL FORCE	
US	69-12-07		MAGNESIUM TAIL BOOM	
US	69-15-02		MAGNESIUM CYCLIC BELLCRANK SUPPORT	
US	69-16-02		HYDRAULIC ACTUATORS	
US	69-17-02		CYCLIC CONTROL SYSTEM	
US	70-07-03		PLANETARY GEAR SUPPORT SPIDERS	
US	70-14-05		VOLTAGE REGULATOR	
US	70-14-06		FIRE WALL TO COMPRESSOR SEAL	
US	71-08-03		PARTICAL SEPERATOR KIT	
US	71-18-04		MAIN ROTOR BLADE SPAR	
US	72-19-01		MAIN ROTOR RETENTION STRAPS	
US	73-08-03		PYLON SUPPORT LINK	
US	73-12-01		VERTICAL FIN SKIN CRACKS	
US	73-19-08		STRAP FITTINGS AND PINS	
US	73-19-09		PITCH LINK ASSEMBLIES	
US	73-21-03		VERTICAL FIN SUPPORT FORGINGS	
US	74-08-12		TAIL BOOM SKIN SPLICE	
US	74-19-03		HORIZONTAL STABILIZER RIBS	
US	74-24-01		MAIN ROTOR BLADE GRIPS	
US	74-25-10		ROTOR BRAKE DISC	
US	75-06-03		PITCH LINK ASSEMBLY	
US	75-06-10		CABIN ROOF STRAPS	
US	75-09-09		TAIL ROTOR CONTROL TUBE	
US	75-18-07		ROTOR BLADE PILLOW BLOCK ASSYS MAIN ROTOR HUB YOKES	
US	76-04-09		REPLACEMENT STRAPS	
US	76-15-03		TAIL ROTOR DRIVE SHAFT	
US				
US	77-10-06		POTOD BLADE STRAPS	
	78-11-02R1		ROTOR BLADE STRAPS	
US	78-11-02R1 78-16-01		TAIL ROTOR DRIVE SHAFT	
US	78-11-02R1 78-16-01 79-10-01		TAIL ROTOR DRIVE SHAFT EXTERNAL LOAD CARRYING DEVICES	
US US	78-11-02R1 78-16-01 79-10-01 80-17-05		TAIL ROTOR DRIVE SHAFT EXTERNAL LOAD CARRYING DEVICES TAIL ROTOR BLADES	ASB 206-80-7 REV A
US US US	78-11-02R1 78-16-01 79-10-01 80-17-05 80-18-04R1		TAIL ROTOR DRIVE SHAFT EXTERNAL LOAD CARRYING DEVICES TAIL ROTOR BLADES MAIN ROTOR TRUNNION	ASB 206-80-7 REV A ASB 206-79-5
US US US US	78-11-02R1 78-16-01 79-10-01 80-17-05 80-18-04R1 81-04-08		TAIL ROTOR DRIVE SHAFT EXTERNAL LOAD CARRYING DEVICES TAIL ROTOR BLADES MAIN ROTOR TRUNNION DRIVESHAFT ASSEMBLY	ASB 206-79-5
US US US	78-11-02R1 78-16-01 79-10-01 80-17-05 80-18-04R1		TAIL ROTOR DRIVE SHAFT EXTERNAL LOAD CARRYING DEVICES TAIL ROTOR BLADES MAIN ROTOR TRUNNION	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

OHIOME	NOIVIERO DE CONSTONE	303E1		
DELL				
BELL 206A		( 206 SERIES		
	HIED / CHITTE)	( 200 SEKIES	,	
	NUED / SUITE)	TAIL ROTO	DO VOVE	
US US	86-24-01 87-10-11	MAIN ROTO		206-87-37, -44
US			DR YOKE ASSEMBLY	200 07 07, 44
US	88-23-03 89-10-11R1		SION - ENGINE INDUCTION & DEFLECTION KIT	
US	89-22-01R1	MAIN ROTO		
US	90-21-03		DE TIP WEIGHT	
			FLOAT BAGS	206L-89-63,206-89-49
US	91-03-12		OR BLADES (FALSIFIED COMPONENT RECORDS)	2001 85 05,200 85 45
US US	92-01-05		ISMISSION SUNGEAR	206-90-56,206L-90-69
	92-06-12 92-09-07		FIN SUPPORTS	206-91-60
US			OR BLADES CRACKS	ASB 206-93-77
US	94-15-07		E SUPPORT ASSEMBLY	
US US	94-19-02		E SUPPORT ASSEMBLY R TRUNNION	206-93-75 206L-93-90
	94-20-03		OR DRIVESHAFT MISALIGNMENT	206-92-69/206L-92-84
US	94-24-11	TAIL RUIC	DRIVESHAFI MISALIGNMENT	206-92-69/2061-92-64
2000		( DOC SERVES		
206B		( 206 SERIES		
CF	CF-72-09		ENTION FITTINGS/PINS	
CF	CF-78-09		NT OF SEAT BELT RIVETS	
CF	CF-91-35		F BOXBEAM	100 000 00 70 BEVE
CF	CF-95-19		ES OVERHEAT INDICATORS	ASB 206-93-76 REVB
US	71-18-04		R BLADE SPAR	
US	72-19-01		R RETENTION STRAPS	
US	73-08-03		PORT LINK	
US	73-12-01		FIN SKIN CRACKS	
US	73-19-08		TINGS AND PINS	
US	73-19-09		K ASSEMBLIES	
US	73-21-03		FIN SUPPORT FORGINGS	
	74-08-12		SKIN SPLICE	
US	74-19-03		L STABILIZER RIBS	
US	74-24-01		R BLADE GRIPS	
US	74-25-10	ROTOR BRA		
US	75-06-03		K ASSEMBLY	•
US	75-06-10	CABIN ROO		
US	75-09-09		R CONTROL TUBE	
US	75-18-07		DE PILLOW BLOCK ASSYS	
US	76-04-09	MAIN ROTO	R HUB YOKES	
US	76-05-01	INBOARD R		
US	76-15-03	REPLACEME		
US	77-10-06		R DRIVE SHAFT	
	78-11-02R1	ROTOR BLA		
US	78-16-01		R DRIVE SHAFT	
US	79-10-01		LOAD CARRYING DEVICES	
US	80-17-05	TAIL ROTO	R BLADES	
US	80-18-04R1		R TRUNNION	ASB 206-80-7 REV A
US	81-04-08	DRIVESHAF	T ASSEMBLY	ASB 206-79-5
US	85-25-01	CYCLIC CO	NTROL STICK	206-85-29,206L-85-36
US	85-26-06	TAIL ROTO	R BLADES	
US	86-24-01	TAIL ROTO	R YOKE	
US	87-10-11	MAIN ROTO		206-87-37, -44
US	88-23-03		R YOKE ASSEMBLY	
US	89-10-11R1		ION - ENGINE INDUCTION & DEFLECTION KIT	
US	89-22-01R1	MAIN ROTO		
US	90-13-01R1	TAIL ROTO		
US	90-21-03		DE TIP WEIGHT	
US	91-03-12		FLOAT BAGS	206L-89-63,206-89-49
US	91-23-15	ENGINE RP	M SENSOR	SOLOY 02-680
US	92-01-05		R BLADES (FALSIFIED COMPONENT RECORDS)	
US	92-06-12		SMISSION SUNGEAR	206-90-56,206L-90-69
US	92-09-07		FIN SUPPORTS	206-91-60
US	94-15-07		R BLADES CRACKS	
US	94-19-02		E SUPPORT ASSEMBLY	206-93-74 REVB
US	94-20-03		R TRUNNION	206-93-75 206L-93-90
US	94-24-11		R DRIVESHAFT MISALIGNMENT	206-92-69/206L-92-84
206L		( 206 SERIES )		
CF	CF-95-19		ES OVERHEAT INDICATORS	ASB 206L-93-91 REVB
CF	CF-98-27	TATI BOOM	MODIFICATION	ASB 206L-87-47 REV C
CF	CF-98-42R2	REINFORCE	MENT OF THE TAIL BOOM SKIN	2061 -99-115RA
US	76-14-05	FUEL SYST	EM COMPONENTS	LUGE DO LIDRA
US	78-11-02R1	ROTOR BLA		
US	78-24-06R1		L STABILIZER	
US	80-17-05	TAIL ROTO		
	DAET / AEDONIEES			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

CONTINUED	ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
206L   CONTINUED / SUITE	BELL			
	206L	( :	206 SERIES )	
US 82-05-03  WERTZONTAL STABILIZER ASSEMBLY  US 83-03-04  MAIN ROTOR BLADES  CYCLIC CONTROL, STICK  SEP-06-04  MAIN ROTOR BLADES  US 85-09-04  MAIN ROTOR MAST  US 86-24-01  TAIL ROTOR YOKE ASSEMBLY  US 87-10-11  MAIN ROTOR MAST  US 88-23-03  TAIL ROTOR YOKE ASSEMBLY  US 88-23-03  TAIL ROTOR YOKE ASSEMBLY  US 90-12-03  TAIL ROTOR YOKE ASSEMBLY  US 90-12-03  TAIL ROTOR WAST  US 90-21-03  TAIL ROTOR WAST  SEMBLY SEMBLY SEMBLY  US 90-21-03  TAIL ROTOR WAST  SEMBLY SEMBLY SEMBLY  US 90-21-03  US 92-01-05  MAIN ROTOR BLADES  US 94-15-07  MAIN ROTOR BLADES  US 94-20-11  TAIL ROTOR YOKE ASSEMBLY  US 94-20-13  US 94-20-13  MAIN ROTOR BLADES  US 94-20-13  US 94-20-13  US 94-20-13  MAIN ROTOR BLADES  CF CF-99-19  TAIL ROTOR DORTVESHAT MISALIONMENT  206-92-69/206L-92-84  US 94-24-11  TAIL ROTOR DORTVESHAT MISALIONMENT  206-92-99/206L-92-84  US 94-24-11  TAIL ROTOR DORTVESHAT MISALIONMENT  206-92-99/206L-92-84  US 94-24-11  TAIL ROTOR DORTVESHAT MISALIONMENT  206-92-99/206L-92-84  US 94-24-68H  MAIN ROTOR BLADES  CF CF-99-19  FILL MIGRATION THROUGH DAIN TUBES  ASS 206L-90-19 REV  ASS 20		UED / SUITE)		
US 83-03-04 CHECK OF SHEAR HEADS-FLOAT INFLATION VALVES			MAIN ROTOR TRUNNION	ASB 206L-80-9 REV A
US 85-09-04   MAIN ROTOR BLADES   268-8-29-2061-85-36   2061-85-36			HORIZONTAL STABILIZER ASSEMBLY	
US 85-28-01 US 87-10-11 MAIN ROTOR BLADES US 87-20-03 US 87-20-03 US 87-20-03 US 87-20-03 US 88-26-03 US 89-26-03 US 89-26-13 US 89-26-13 US 89-26-13 US 90-15-01R1 US 90-11-01R1 US 90-11-01R1 US 90-11-01R1 US 90-12-01R1 US 90-12-01R1 US 91-02-12 EMERGENCY FLOAT BAGS US 91-02-12 EMERGENCY FLOAT BAGS US 91-02-12 US 91-10-12 US 91-02-12 US 91-10-12 US 91-	US	85-09-04	MAIN BOTOR BLADES	
US 85-26-06 US 88-20-01 US 88-20-03 US 88-20-03 US 88-20-03 US 88-20-03 US 88-20-03 US 89-20-13 HORIZONTAL STABILIZER US 89-20-18 US 89-20-18 US 89-20-19 US 90-13-01RI TALL ROTINE BLADES US 90-13-01RI TALL ROTINE BLADES US 90-13-01RI TALL ROTINE BLADES US 91-20-15 US 91-20-15 EMERGENCY FLOAT BAGS US 91-20-15 EMERGENCY FLOAT BAGS US 92-00-0-05 MAIN ROTINE READES (FALSIFIED COMPONENT RECORDS) US 92-00-12 MAIN ROTINE READES CRACKS US 92-00-12 MAIN TRANSMISSION SUNGEAR US 94-20-03 MAIN ROTINE READES CRACKS US 94-20-03 MAIN ROTINE READES CRACKS US 94-20-10 US 94-20-03 MAIN ROTINE READES US 94-20-10 TALL ROTINE BLADES US 94-20-00 TALL ROTI	US	85-25-01		ASB 206L-85-35
US 86-24-01 TAIL ROTOR YOKE  US 87-10-11  MAIN ROTOR MAST US 88-26-03  LILL ROTOR YOKE ASSEMBLY  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-52  2061-88-63, 206-89-49  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-79  2061-89-63, 206-89-8	US	85-26-06		206-85-29,206L-85-36
US 88-29-03 TAIL ROTOR YOKE ASSEMBLY US 88-29-03 FUEL SYSTEM FLOW SWITCHES US 89-20-03 FUEL SYSTEM FLOW SWITCHES US 89-20-03 FUEL SYSTEM FLOW SWITCHES US 90-21-03 TAIL ROTOR SLADES US 90-21-03 TAIL ROTOR SLADES US 90-21-03 TAIL ROTOR SLADES US 91-23-15 EMERGENCY FLOAT BAGS US 91-23-15 EMERGENCY FLOAT BAGS US 92-01-05 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS) US 92-06-12 MAIN TRANSHISSION SUNGEAR US 92-01-05 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS) US 94-20-03 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS) US 94-20-03 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS) US 94-20-03 MAIN ROTOR TRUNNION US 94-20-10 MAIN ROTOR TRUNNION US 94-20-10 MAIN ROTOR TRUNNION US 94-20-10 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-92-69/2061-92-84  206L 1 (206 SERIES) CC CC-96-10 FLIEL MIGRATION THROUGH DRAIN TUBES ASS 2061-89-91 GRUP ASSEMBLY CF CF-98-27 TAILBOOM MODIFICATION CF CF-98-27 TAILBOOM MODIFICATION CF CF-98-27 TAILBOOM MODIFICATION CF CF-98-42R RENNERCEMENT OF THE TAIL BOOM SKIN US 78-11-02R1 ROTOR BLADE STRADES US 78-11-02R1 ROTOR BLADE STRADES US 78-20-66R1 MAIN ROTOR TRUNNION ASS 2061-80-91 FISHA US 80-18-04R1 MAIN ROTOR TRUNNION ASS 2061-80-13 VA SES 2061-8				
U.S.	US	87-10-11		206-87-37, -44
US 89-20-13				
US   89-22-01R1			HODIZONIAL CIARLITZER	206L-88-52
US 90-13-0181				
US 90-21-03	US			
US 91-23-15			T / R BLADE TIP WEIGHT	
US   92-01-05   MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS)   US   94-15-07   MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS)   US   94-19-02   SWASHPLATE SUPPORT ASSEMBLY   206-93-75   2061-90-69   AND RECORDS   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-90   206-93-75   2061-93-91   REVB   206-93-75   2061-93-90   206-93-75   2061-93-91   REVB   206				
US   92-06-12				SOLOY 02-680
US 94-19-07				000 00 50 0001 00 00
US   94-19-02   SWASHPLATE SUPPORT ASSEMBLY   206-93-76   206-93-76   206-93-90   US   94-20-03   MAIN ROTOR TRIUNITION   206-93-76   206-93-90   US   94-20-03   MAIN ROTOR TRIUNITION   206-92-69/206L-93-90   US   94-20-03   MAIN ROTOR TRIUNITION   206-92-69/206L-93-90   US   94-20-03   MAIN ROTOR TRIUNITION   206-93-91   REVB   206-85-25   REVB   206			MAIN DOTOD BLADES CDACKS	100 000 00 00
US   94-24-11   TATL ROTOR DRIVESHAFT MISALIGNMENT   206-93-75 206L-93-90   206-92-95/206L-92-90   206-92-95/206L-92-90   206-92-95/206L-92-90   206-92-95/206L-92-90   206-92-95/206L-92-90   206-92-95/206L-92-90   206-92-91   REVB   206-92-92   REVB   206-92			SWASHPLATE SUPPORT ASSEMBLY	206-93-74 REVB
206L   1			MAIN ROTOR TRUNNION	206-93-75 206L-93-90
CF   CF-96-19	US	94-24-11	TAIL ROTOR DRIVESHAFT MISALIGNMENT	206-92-69/206L-92-84
CF   CF-96-19	2061 1	( )	OCC CEDIES )	
CF		CF-95-19		ASB 2061 -02-04 DEVD
CF			FUEL MIGRATION THROUGH DRAIN TUBES	
CF   CF-98-42R2	CF		KRATOS TURBINE OUTLET TEMPERATURE INDICATORS	
US			TAILBOOM MODIFICATION	
US				206L-99-115RA
U.S. 80-18-04R1   MAIN ROTOR TRUNNION   2061-80-9 REV A				
US				2061 -80-9 PEV A
US			MAIN ROTOR GRIP	ASB 206L-80-15
US			FUEL / OIL LINE DAMAGE	
US				
US 85-25-01 CYCLIC CONTROL STICK 206-85-29,206L-85-36 US 87-10-11 MAIN ROTOR MAST 206-87-37, -44 US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 TAIL ROTOR PLANT 206L-85-36 US 88-23-03 FUEL SYSTEM FLOW SWITCHES 206L-88-52 US 88-20-13 HORIZONTAL STABILIZER US 89-20-13 HORIZONTAL STABILIZER US 90-13-01R1 TAIL ROTOR PLANES US 90-21-03 TAIL ROTOR BLADES US 90-21-03 TAIL ROTOR BLADES US 91-03-12 EMERGENCY FLOAT BAGS US 91-03-12 EMERGENCY FLOAT BAGS 206L-89-63,206-89-49 US 92-06-12 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS) US 92-06-12 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS) US 94-15-07 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS) US 94-19-02 SWASHPLATE SUPPORT ASSEMBLY 206-93-77 206L-93-90 US 94-20-03 MAIN ROTOR TRUNNION 206-93-75 206L-93-90 US 94-24-11 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-93-75 206L-93-90 US 94-24-11 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-93-75 206L-93-91 CF CF-95-19 TEMP-PLATES OVERHEAT INDICATORS ASB 206L-93-91 REVB CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-93-115RA US 78-11-02R1 ROTOR BLADES STRAPS US 85-09-04 MAIN ROTOR BLADES STRAPS US 85-26-06 MAIN ROTOR BLADES US 87-10-11 STABILIZER ASSEMBLY US 88-23-03 TAIL ROTOR BLADES US 88-23-03 TAIL ROTOR BLADES US 88-20-13 HORIZONTAL STEEK US 89-20-13 HORIZONTAL STEEK US 89-20-13 HORIZONTAL STEEK US 90-13-01R1 TAIL ROTOR BLADES TAIL ROTOR MAST TAIL ROTOR MAST TAIL ROTOR BLADES TAIL ROTOR BLADES US 89-20-11 HORIZONTAL STABILIZER US 90-13-01R1 TAIL ROTOR BLADES TAIL ROTOR BLADES TAIL ROTOR BLADES US 89-20-13 HORIZONTAL STABILIZER US 90-13-01R1 TAIL ROTOR BLADES US 89-20-13 HORIZONTAL STABILIZER US 90-13-01R1 TAIL ROTOR BLADES TAIL ROTOR BL			CHECK OF SHEAR HEADS-FLOAT INFLATION VALVES	
US				
US				200 85 29,2061-85-36
US				206-87-37, -44
US		87-15-01		
US 89-20-13 HORIZONTAL STABILIZER  US 89-22-01R1 MAIN ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  US 90-21-03 T / R BLADE TIP WEIGHT  US 91-03-12 EMERGENCY FLOAT BAGS 206L-89-63, 206-89-49  US 92-01-05 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS)  US 92-06-12 MAIN TRANSMISSION SUNGEAR 206-93-77  US 94-19-02 SWASHPLATE SUPPORT ASSEMBLY 206-93-74 REVB  US 94-20-03 MAIN ROTOR TRUNNITON 206-93-75 206L-93-90  US 94-20-03 MAIN ROTOR DRIVESHAFT MISALIGNMENT 206-92-69/206L-92-84  206L 3 (206 SERIES )  CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-93-91 REVB  CF CF-98-27 TAILBOOM MODIFICATION ASE 206L-87-47 REV C  CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA  US 78-11-02R1 ROTOR BLADES TRAPS  US 85-25-01 CYCLIC CONTROL STICK 206-85-29, 206L-85-36  US 85-26-06 TAIL ROTOR BLADES  US 88-23-03 HORIZON ASSEMBLY  US 88-23-03 HORIZONTAL STABILIZER  US 89-22-01R1 MAIN ROTOR BLADES  US 89-22-01R1 TAIL ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES				
US				206L-88-52
US 90-13-01R1				
US 90-21-03				
US 91-03-12 EMERGENCY FLOAT BAGS 206L-89-63, 206-89-49  US 92-01-05 MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS)  US 92-06-12 MAIN TRANSMISSION SUNGEAR 206-90-56, 206L-90-69  US 94-15-07 MAIN ROTOR BLADES CRACKS ASB 206-93-77  US 94-19-02 SWASHPLATE SUPPORT ASSEMBLY 206-93-75 206L-93-90  US 94-20-03 MAIN ROTOR TRUNNION 206-93-75 206L-93-90  US 94-24-11 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-92-69/206L-92-84  206L 3 (206 SERIES)  CF CF-95-19 TEMP-PLATES OVERHEAT INDICATORS ASB 206L-93-91 REVB  CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-96-103 REV A  CF CF-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C  CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA  US 78-11-02R1 ROTOR BLADE STRAPS  US 85-09-04 MAIN ROTOR BLADES ASB 206L-85-35  US 85-26-06 TAIL ROTOR BLADES  US 85-26-06 TAIL ROTOR BLADES  US 87-10-11 MAIN ROTOR MAST 206-85-29,206L-85-36  US 87-10-11 MAIN ROTOR MAST 206-85-29,206L-85-36  US 88-23-03 TAIL ROTOR BLADES  US 88-23-03 TAIL ROTOR BLADES  US 89-20-13 HORIZONTAL STABILIZER  US 89-22-01R1 MAIN ROTOR BLADES  US 89-20-101 MAIN ROTOR BLADES  US 89-21-01 TAIL ROTOR BLADES  US 89-22-01R1 MAIN ROTOR BLADES  US 89-21-03 TAIL ROTOR BLADES  US 89-21-03 TAIL ROTOR BLADES  US 89-21-03 TAIL ROTOR BLADES  US 89-22-01R1 MAIN ROTOR BLADES  US 89-21-03 TAIL ROTOR BLADES  US 89-22-01R1 MAIN ROTOR BLADES  US 89-21-03 TAIL ROTOR BLADES  US 89-21-03 TAIL ROTOR BLADES  US 89-22-01R1 MAIN ROTOR BLADES  US 89-21-03 TAIL ROTOR BLADES  US 89-22-01R1 MAIN ROTOR BLADES				
US 92-06-12 MAIN TRANSMISSION SUNGEAR 206-90-56,206L-90-69 US 94-15-07 MAIN ROTOR BLADES CRACKS ASB 206-93-77 SURSHPLATE SUPPORT ASSEMBLY 206-93-74 REVB US 94-20-03 MAIN ROTOR TRUNNION 206-93-75 206L-93-90 US 94-24-11 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-92-69/206L-92-84 PAGE 206 SERIES CONTROL TRUNDION 206-92-69/206L-92-84 PAGE 206 SERIES CONTROL TRUDICATORS ASB 206L-93-91 REVB CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-96-103 REV A CF CF-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA US 78-11-02R1 ROTOR BLADE STRAPS US 85-09-04 MAIN ROTOR BLADE STRAPS US 85-25-01 CYCLIC CONTROL STICK 206-85-29, 206L-85-36 US 85-25-01 TAIL ROTOR BLADES TAIL ROTOR BLADES TAIL ROTOR BLADES US 87-10-11 MAIN ROTOR MAST 206-87-37, -44 STAIL ROTOR BLADES US 88-23-03 TAIL ROTOR MAST 206-87-37, -44 STAIL ROTOR STABILIZER ASSEMBLY US 89-22-01R1 MAIN ROTOR BLADES TABILIZER STABILIZER US 89-21-03 MAIN ROTOR BLADES TABILIZER STABILIZER				206L-89-63,206-89-49
US 94-15-07				000 00 50 0001 00
US 94-19-02 SWASHPLATE SUPPORT ASSEMBLY 206-93-74 REVB US 94-20-03 MAIN ROTOR TRUNNION 206-93-75 206L-93-90 US 94-24-11 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-92-69/206L-92-84  206L 3 (206 SERIES)  CF CF-95-19 TEMP-PLATES OVERHEAT INDICATORS ASB 206L-93-91 REVB CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-96-103 REV A CF CF-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA  US 78-11-02R1 ROTOR BLADE STRAPS US 85-09-04 MAIN ROTOR BLADE STRAPS US 85-25-01 CYCLIC CONTROL STICK 206-85-29, 206L-85-36 US 87-10-11 MAIN ROTOR BLADES US 87-10-11 MAIN ROTOR MAST 206-85-29, 206L-85-36 US 87-10-11 STABILIZER ASSEMBLY US 88-23-03 HORIZONTAL STABILIZER US 89-22-01R1 MAIN ROTOR BLADES US 89-22-01R1 TAIL ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES US 90-21-03 T/R BLADES TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES  TEMPERSPICE FOR TAIL ROTOR BLADES US 90-21-03 T/R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES  TEMPERSPICE FOR TAIL ROTOR BLADES  TEMPERSPICE FOR TAIL ROTOR BLADES US 90-21-03 T/R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES US PO-21-03 T/R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES US PO-21-03 T/R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES				
US 94-20-03 MAIN ROTOR TRUNNION US 94-24-11 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-93-75 206L-93-90 US 94-24-11 TAIL ROTOR DRIVESHAFT MISALIGNMENT 206-92-69/206L-92-84  206L 3 (206 SERIES)  CF CF-95-19 TEMP-PLATES OVERHEAT INDICATORS ASB 206L-93-91 REVB CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-96-103 REV A CF CF-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA  US 78-11-02R1 ROTOR BLADE STRAPS US 85-09-04 MAIN ROTOR BLADES US 85-25-01 CYCLIC CONTROL STICK 206-85-29, 206L-85-36 US 85-26-06 TAIL ROTOR BLADES US 87-10-11 MAIN ROTOR MAST 206-85-29, 206L-85-36 US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 HORIZONTAL STABILIZER US 89-22-01R1 MAIN ROTOR BLADES US 89-22-01R1 MAIN ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES US 90-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TRUNNION ASSESSMENT AND ROTOR BLADES US 90-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES  TEMPERSPICE FOR TAIL ROTOR BLADES US 90-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES US PO-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES US 90-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES US PO-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES US PO-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TRUNNION ASSESSMENT AND ROTOR BLADES US PO-21-03 T/ R BLADE TIP WEIGHT  TEMPERSPICE FOR TAIL ROTOR BLADES US PO-21-03 T/ R BLADE TIP WEIGHT				
TAIL ROTOR DRIVESHAFT MISALIGNMENT   206-92-69/206L-92-84			MAIN ROTOR TRUNNION	
206L 3 ( 206 SERIES )  CF CF-95-19 TEMP-PLATES OVERHEAT INDICATORS ASB 206L-93-91 REVB CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-96-103 REV A CF CF-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA US 85-09-04 MAIN ROTOR BLADES ASB 206L-85-35 US 85-25-01 CYCLIC CONTROL STICK 206-85-29,206L-85-36 US 85-25-01 TAIL ROTOR BLADES ASB 206L-85-36 US 87-10-11 MAIN ROTOR MAST 206-87-37, -44 US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 HORIZON TAIL ROTOR YOKE ASSEMBLY US 89-20-13 MAIN ROTOR BLADES ASP-20-13 MAIN ROTOR BLADES ASP-20-140 MA				206-92-69/206L-92-84
CF CF-95-19 TEMP-PLATES OVERHEAT INDICATORS ASB 206L-93-91 REVB CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-96-103 REV A ASB 206L-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA  US 78-11-02R1 ROTOR BLADE STRAPS US 85-09-04 MAIN ROTOR BLADES ASB 206L-85-35 CYCLIC CONTROL STICK 206-85-29, 206L-85-36 US 85-25-01 CYCLIC CONTROL STICK 206-85-29, 206L-85-36 US 85-26-06 TAIL ROTOR BLADES  US 87-10-11 MAIN ROTOR MAST 206-87-37, -44  US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 TAIL ROTOR YOKE ASSEMBLY US 88-23-03 HORIZONTAL STABILIZER US 89-22-01R1 MAIN ROTOR BLADES  US 89-22-01R1 TAIL ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  T / R BLADE TIP WEIGHT  TAMEROFRON FOR THE TOR TOR SECONDARY ASSEMBLY  TAMEROFRON FOR THE TORS ASSEMBLY  TAIL ROTOR BLADES  T / R BLADE TIP WEIGHT  TAMEROFRON FOR THE TORS ASSEMBLY  TAMEROFRON FOR THE TORS ASSEMBLY  TAMEROFRON FOR THE TORS ASSEMBLY  TAIL ROTOR BLADES  T / R BLADE TIP WEIGHT  TAMEROFRON FOR THE TORS ASSEMBLY  TAIL ROTOR BLADES  TAMEROFRON FOR THE TORS ASSEMBLY  TAIL ROTOR BLADES  TAMEROFRON FOR THE TORS ASSEMBLY  TAIL ROTOR BLADES  TAMEROFRON FOR THE TORS ASSEMBLY  TAMEROFRON FOR THE TORS ASSEMBLY  TAIL ROTOR BLADES  TAIL ROTOR BLADES  TORS ASSEMBLY  TORS ASSEMBLY ASSEMBLY  TORS ASSEMBLY  TORS ASSEMBLY  ASB 206L-99-115RA  ASB 206L-99-115RA  ASB 206L-99-115RA  TAIL ROTOR BLADES  TORS ASSEMBLY  TAIL ROTOR BLADES  TORS ASSEMBLY  TAIL ROTOR BLADES  TORS ASSEMBLY  T			on CEDIEC )	
CF CF-96-10 FUEL MIGRATION THROUGH DRAIN TUBES ASB206L-96-103 REV A CF CF-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C CF -98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA US 85-09-04 MAIN ROTOR BLADES ASB 206L-85-35 CYCLIC CONTROL STICK 206-85-29,206L-85-36 US 85-25-01 CYCLIC CONTROL STICK 206-85-29,206L-85-36 US 85-26-06 TAIL ROTOR BLADES 206-85-29,206L-85-36 US 87-10-11 MAIN ROTOR MAST 206-87-37, -44 US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 TAIL ROTOR YOKE ASSEMBLY US 89-20-13 HORIZONTAL STABILIZER US 89-22-01R1 MAIN ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES TAIL ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES TAIL ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES TAIL ROTO	206L 3		O6 SERIES /	ASR 2061 -93-91 PEVP
CF CF-98-27 TAILBOOM MODIFICATION ASB 206L-87-47 REV C CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA  US 78-11-02R1 ROTOR BLADE STRAPS  US 85-09-04 MAIN ROTOR BLADES ASB 206L-85-35  US 85-25-01 CYCLIC CONTROL STICK 206-85-29,206L-85-36  US 85-26-06 TAIL ROTOR BLADES  US 87-10-11 MAIN ROTOR MAST 206-87-37, -44  US 87-15-01 STABILIZER ASSEMBLY  US 88-23-03 TAIL ROTOR YOKE ASSEMBLY  US 89-20-13 HORIZONTAL STABILIZER  US 89-2-01R1 MAIN ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  US 90-21-03 T / R BLADES TIP WEIGHT  TAMEROFORY FLOAT RAGS				
CF CF-98-42R2 REINFORCEMENT OF THE TAIL BOOM SKIN 206L-99-115RA  US 78-11-02R1 ROTOR BLADE STRAPS  US 85-09-04 MAIN ROTOR BLADES  US 85-25-01 CYCLIC CONTROL STICK 206-85-29,206L-85-36  US 85-26-06 TAIL ROTOR BLADES  US 87-10-11 MAIN ROTOR MAST 206-87-37, -44  US 87-15-01 STABILIZER ASSEMBLY  US 88-23-03 TAIL ROTOR YOKE ASSEMBLY  US 89-20-13 HORIZONTAL STABILIZER  US 89-22-01R1 MAIN ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  US 90-21-03 T / R BLADE TIP WEIGHT  TAMEROENICY FLOAT RAGS			TAILBOOM MODIFICATION	ASB 206L-87-47 REV C
US 78-11-02R1 ROTOR BLADE STRAPS US 85-09-04 MAIN ROTOR BLADES 206-85-35 US 85-25-01 CYCLIC CONTROL STICK 206-85-29,206L-85-36 US 85-26-06 TAIL ROTOR BLADES US 87-10-11 MAIN ROTOR MAST 206-87-37, -44 US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 TAIL ROTOR YOKE ASSEMBLY US 89-20-13 HORIZONTAL STABILIZER US 89-22-01R1 MAIN ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES US 90-21-03 T / R BLADE TIP WEIGHT US 90-21-03 T / R BLADE TIP WEIGHT			REINFORCEMENT OF THE TAIL BOOM SKIN	
US 85-09-04 MAIN ROTOR BLADES US 85-25-01 CYCLIC CONTROL STICK 206-85-29,206L-85-36 US 85-26-06 TAIL ROTOR BLADES US 87-10-11 MAIN ROTOR MAST 206-87-37, -44 US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 TAIL ROTOR YOKE ASSEMBLY US 89-20-13 HORIZONTAL STABILIZER US 99-21-0181 MAIN ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES US 90-21-03 T / R BLADE TIP WEIGHT  LEMERGE LOAD RAGS			ROTOR BLADE STRAPS	
US 85-26-06 TAIL ROTOR BLADES  US 87-10-11 MAIN ROTOR MAST 206-87-37, -44  US 87-15-01 STABILIZER ASSEMBLY  US 88-23-03 TAIL ROTOR YOKE ASSEMBLY  US 89-20-13 HORIZONTAL STABILIZER  US 89-22-01R1 MAIN ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  US 90-21-03 T / R BLADE TIP WEIGHT  US 90-21-03 T / R BLADE TIP WEIGHT	US		MAIN ROTOR BLADES	
US 87-10-11 MAIN ROTOR MAST  US 87-15-01 STABILIZER ASSEMBLY  US 88-23-03 TAIL ROTOR YOKE ASSEMBLY  US 89-20-13 HORIZONTAL STABILIZER  US 89-22-01R1 MAIN ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  US 90-21-03 T / R BLADE TIP WEIGHT  EMPERSALVE FLOAT BAGS				200-65-29,2061-85-36
US 87-15-01 STABILIZER ASSEMBLY US 88-23-03 TAIL ROTOR YOKE ASSEMBLY US 89-20-13 HORIZONTAL STABILIZER US 89-22-01R1 MAIN ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES US 90-21-03 T / R BLADE TIP WEIGHT US 90-21-03 T / R BLADE TIP WEIGHT				206-87-37, -44
US 88-23-03				
US 89-20-13 HORIZONIAL STABILIZER  US 89-22-01R1 MAIN ROTOR BLADES  US 90-13-01R1 TAIL ROTOR BLADES  US 90-21-03 T / R BLADE TIP WEIGHT  US 90-21-03 T / R BLADE TIP WEIGHT  US 90-21-03 T / R BLADE TIP WEIGHT			TAIL ROTOR YOKE ASSEMBLY	
US 89-22-01R1 MAIN ROTOR BLADES US 90-13-01R1 TAIL ROTOR BLADES US 90-21-03 T / R BLADE TIP WEIGHT US 90-21-03 T / R BLADE TIP WEIGHT				
US 90-21-03  T / R BLADE TIP WEIGHT				
05 90 21 05 20G -99-63 20G-99-49 1				
05 91-05 12				206L-89-63.206-89-49
	US	91-03-12		

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

( SERIES / SERIE)
SUBJECT
SUJET

BELL			
206L	3	( 206 SERIES )	
	INUED / SUITE)		
US	92-01-05	MAIN ROTOR BLADES (FALSIFIED COMPONENT RECORDS)	
US	92-06-12	MAIN TRANSMISSION SUNGEAR	206-90-56,206L-90-69
US	94-15-07	MAIN ROTOR BLADES CRACKS	ASB 206-93-77
US	94-19-02	SWASHPLATE SUPPORT ASSEMBLY	206-93-74 REVB
US	94-20-03	MAIN ROTOR TRUNNION	206-93-75 206L-93-90
US	94-24-11	TAIL ROTOR DRIVESHAFT MISALIGNMENT	206-92-69/206L-92-84
206L	4	( 206 SERIES )	
CF	CF-96-10	FUEL MIGRATION THROUGH DRAIN TUBES	ASB206L-96-103 REV A
CF	CF-98-11	HIGH ALTITUDE TAIL ROTOR KIT	206L-96-104 REV A
CF	CF-98-20	COLLECTIVE IDLER LINK & LEVER RETIREMENT LIVES	206L-98-110
CF	CF-98-34	HYDRAULIC RELIEF VALVE	206L-98-111
CF	CF-98-42R2	REINFORCEMENT OF THE TAIL BOOM SKIN	206L-99-115RA
US	94-15-07	MAIN ROTOR BLADES CRACKS	ASB 206-93-77
US	94-20-03	MAIN ROTOR TRUNNION	206-93-75 206L-93-90
212			
CF	CF-88-23R1	BLADE STRAP PINS	A8-27-45
CF	CF-90-16R3	MAIN ROTOR YOKE	212-90-60 REV A
CF	CF-91-27	EMERGENCY ESCAPE RELEASE HANDLE COVERS	
CF	CF-91-29R1	AFT FACING SEAT HEADRESTS	
CF	CF-94-07	ZINC PRIMER AS OVERHEAT INDICATOR	212-93-89 REV A
CF	CF-95-20R1	BOLTS OF FLIGHT CONTROL SERVO ACTUATORS	212-67-01
CF	CF-96-06	EMERGENCY ESCAPE PANELS	
CF	CF-97-04	FUEL LINE - CHANGE TO STAINLESS ELBOW FITTING	212-96-157
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
us	74-02-01	TAIL ROTOR TRUNNION BEARINGS	
US	74-08-03	TAIL FIN FORWARD SPAR CAP ANGLE	
US	74-20-05	ELEVATOR MODIFICATION	
US	75-07-01	HIGH FREQUENCY VIBRATION	
US	75-26-03	EMERGENCY EXIT HANDLE	
US	75-26-05	MAIN ROTOR BLADES	
US	76-02-06	MAIN ROTOR BLADES	
US	76-14-03	CROSS TUBE ASSEMBLIES	
US	77-05-02	MAIN ROTOR BLADES	
US	77-10-05	CRACKS IN MAIN ROTOR BLADES SKIN	
US	77-17-03	TAIL ROTOR BLADE PITCH HORN	
US	77-17-05	EMERGENCY EXIT LATCH PIN	
US	78-09-02	EMERGENCY FLOAT KITS	
US	78-14-07	SKID LANDING GEAR	
US	78-17-03	SPIRAL BEVEL GEAR	
US	78-20-07	SHOULDER RADIUS FITTING	
US	78-21-02	EXTERNAL LOAD LINK ASSEMBLY	
US	79-05-08	EMER FLOTATION (DITCHING) EQUIPMENT	
US	79-20-05	MAIN ROTOR HUB ASSEMBLY	
US	80-17-09	MAIN ROTOR STRAPS	
US	80-21-05	LANDING GEAR CROSS TURES	
US	81-10-07	SWASHPLATE SUPPORT	ASB 212-81-22
US	81-19-01	MAIN ROTOR YOKE	ASB 212-81-23
US	86-17-09	TAIL ROTOR TRUNNION BEARING HOUSING	212-86-39RA
US	89-08-05	MAIN TRANSMISSION - SPIRAL BEVEL GEARS	
US	90-03-09	T / R TRUNNION BEARING HOUSING ASSEMBLY	212-86-39 REV A
US	90-26-11	MAIN ROTOR DRAG BRACE ASSEMBLY	212-90-59
US	92-07-08	SWASHPLATE SUPPORT ASSEMBLY	212-91-72
US	92-09-05	ENG DRIVESHAET COURTING ADAPTER	212-91-67
US	92-13-10	TAIL ROTOR DRIVESHAFT HANGER BEARINGS	SUPERCEDES 91-24-16
US	92-13-10	PREVENT SEPERATION MAIN ROTOR PILLOW BLOCKS	212-90-62 REV A
US	93-05-01	POSSIBLE MAIN ROTOR YOKE FATIGUE FAILURE	
US	93-05-01	MAIN ROTOR TRANSMISSION LOWER PLANETARY SPIDER	SUPERCEDES 92-11-07
US	94-18-09	MAIN TRANSMISSION LOWER PLANETARY SPIDER	
US	98-11-15	TAIL ROTOR YOKE ASSY FAILURE.	ASB 212-96-100/101
US	98-24-15	MAIN ROTOR MAST / TRUNNION	212-95-97
US	30 24-13	WILLIA HOLOH MWOL / LINDINGTON	
214	SERIES		
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	77-03-04	FUSELAGE SPLICE FITTING	SI 214-76-6
US	77-17-05	EMERGENCY EXIT LATCH PIN	214-77-4
US		TAIL FIN SPAR	
US	78-08-08 80-17-09	TAIL FIN SPAR MAIN ROTOR STRAPS	214-80-13
US	81-02-10	CLUTCH ASSEMBLY	214-80-13
US	81-12-03	SPINDLE RETENTION BOLTS	ASB 214-81-17
US	82-06-07	TAIL ROTOR YOKE	214-81-18
	02 00 07	TATE NOTON TONE	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN

### STATES   CONTINUED / SUITE    1. S 84-05-51	ORIGINE	NOMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
214-84-26 US 84-05-51 US 84-05-51 US 84-05-51 US 84-05-51 US 85-23-05 MAIN RUTOR DRAG BRACE ASSEMBLY 214-84-26 US 85-21-06 MAIN RUTOR DRAG BRACE ASSEMBLY 214-84-26 US 87-10-00 US 87-10-00 MAIN RUTOR DRAG BRACE ASSEMBLY 214-86-36, 37 US 87-10-00 US 97-06-02 MAIN RUTOR VOKE ASSY US 97-06-02 US 97-15-04 MAIN RUTOR VOKE ASSY US 98-18-01 US 98-18-01 TRINNION FAITURE FAITURE PREVENTION US 98-18-01 US 98-18-01 TRINNION FAITURE FAITURE PREVENTION US 98-18-01 US 99-05-07 TAIL MOTOR VOKE ASSY FAITURE US 99-05-07 TAIL MOTOR PITCH HORN CRACKS US 99-05-07 TAIL MOTOR VOKE ASSY FAITURE US 99-05-07 TAIL MOTOR VOKE ASSYMBLY US 99-05-07 TAIL MOTOR VOKE ASSYMBLY US 99-05-05 TAIL MOTOR CONTROL VOKE ASSYMBLY US 99-05-07 TAIL MOTOR CONTROL VOKE ASSYMBLY US 99-05-05 TAIL MOTOR CONTROL VOKE ASSYM	RELI			
CONTINUED		ERIES		
US 84-06-51  US 87-8-06  MAIN ROTOR PARG BRACE ASSEMBLY  214-84-26  US 87-10-66  US 87-11-06  MAIN ROTOR PARG BRACE ASSEMBLY  214-84-26  US 87-10-60  US 97-01-10  MAIN ROTOR YOKE ASSW PLATES  US 97-06-02  US 97-06-02  US 97-15-03  MAIN ROTOR YOKE ASSW PLATES  US 97-06-02  US 97-15-03  MAIN ROTOR YOKE ASSW PLATES  US 97-06-02  US 97-15-04  MAIN ROTOR YOKE ASSW PLATES  US 97-06-02  MAIN ROTOR YOKE ASSW PLATES  US 97-06-02  MAIN ROTOR YOKE ASSW PLATES  US 98-02-17  TAIL ROTOR YOKE ASSW PLATES  US 99-02-17  TAIL ROTOR YOKE ASSW FATIGUE  214-96-57  PILLOW PLATE PRIMER TEMP INDICATORS  CF CF-98-15  CF CF-98-15  HELICOPTER RESOLE SYSTEMS  CAP 702-21  CF CF-98-15  MAIN ROTOR PRIMER TEMP INDICATORS  CF CF-98-15  MAIN ROTOR PRIMER PRIMER TEMP INDICATORS  CR 702-21  CF CF-98-15  MAIN ROTOR PRIMER PRIMER TEMP INDICATORS  CR 702-21  CF CF-98-15  MAIN ROTOR PRIMER PRIMER PRIMER PRIMER ASS 222-98-81  CF CF-98-15  MAIN ROTOR PRIMER PRIMER PRIMER PRIMER ASS 222-98-81  MAIN ROTOR PRIMER PRIME				
U.S.   88-18-06   MAIN ROTOR DRAGE BASEMBLY   214-85-28			COLLECTIVE SLEEVES	
US 88-20-06 US 87-11-06 US 97-11-06 US 97-06-02 US 97-06-03 US 97-06-02 US 97-06-03 US 97-06-03 US 97-06-03 US 98-23-18 US 98-23-18 US 98-23-18 US 98-23-18 US 98-23-18 US 99-02-17 TAIL ROTRE YOKE ASSY DIER, FAITGUE FAILURE EN SUPERCEDES 94-02-05 US 98-23-18 US 99-02-17 TAIL ROTRE YOKE ASSY FAITGUE 214-94-59 US 99-03-07 PILLOW BLOCK BEARING BOLTS 214-94-59  214-94-59  214-94-69  214-94-69  214-94-69 US 98-03-07 PILLOW BLOCK BEARING BOLTS 214-94-59  214-94-59  214-94-59 US 99-05-07 PILLOW BLOCK BEARING BOLTS 222-99-67 REV A CR. 702-21 CF CF-98-16 MAIN ROTOR PITCH HORN CRACKS ASB 222-99-67 REV A CR. 702-21 US 82-09-53 WERTLOAL FIN ATTACHMENT BOLTS ASB 222-99-82 REV A CR. 702-21 US 82-09-53 MAIN ROTOR SHARD BOUBLERS ASB 222-99-82 REV A DEVELOPMENT BOLD BOUBLERS ASB 222-99-83 US 82-16-06 US 83-09-03 MAIN ROTOR SHARD BOUBLERS ASB 222-92-17 US 83-12-01 US 87-19-01 WAIN ROTOR SHARD BOUBLERS ASB 222-92-17 WAIN ROTOR SHARD BOURLERS ASB 222-92-19 US 89-09-03 MAIN ROTOR SHARD BOURLERS ASB 222-92-90 WAIN ROTOR SHARD BOURLERS ASB 222-92-90 WAIN ROTOR SHARD BOURLERS ASB 222-92-90 WAIN ROTOR SHARD BOURLERS ASB 222-93-90 WAIN ROTOR SHARD BOURLERS A	US	85-18-06	MAIN ROTOR DRAG BRACE ASSEMBLY	
US   86-20-06		85-23-05	COLLECTIVE SIFFVE	
US 97-06-02 US 97-15-04 US 97-15-04 US 97-15-04 US 97-15-04 US 97-15-04 US 97-15-04 US 98-18-01 US 98-			MAIN ROTOR DRAG BRACE ASSEMBLY	214 84 26
MAIN ROTOR YOKE ASSY   24-89-4-91			COLLECTIVE HUB LOCKING PLATES	214-86-36 -37
MAIN TRANS. UPPER PLANETARY CARRIER   \$1494-55			MAIN ROTOR YOKE ASSV	
Section   Sect			LOWER PLANETARY SPIDER, FATIGUE FAILURE	
US 99-23-18 US 99-02-17 US 99-05-07 PILLOW BLOCK BEARING BOLTS 214-94-54  214B  (214 SERIES)  222 SERIES CF CF-94-06 CF CF-98-15 CF CF-98-16 CF CF-98-17 CF CF-98-17 CF CF-98-17 CF CF-98-17 CF CF-98-18 CF CF-98-18 CF CF-98-19 CF CF-98-19 CF CF-98-19 CF CF-98-19 CF CF-98-10 CF CF-98-			MAIN TRANS. UPPER PLANETARY CARRIER	SUPERCEDES 94-02-05
US 99-02-17 TAIL ROTOR YOKE ASSY FATIQUE 214-90-57 99-05-07 PILLOW BLOCK BEARING BOLTS 214-90-57 214B 1 (214 SERIES )  2122 SERIES CF CF-94-06 CF CF-93-15 HELICOPTER RESCUE SYSTEMS CAR 702-21 CF CF-98-16 MAIN ROTOR PITCH HORN CRACKS ASB 222-98-81 CF CF-98-16 VERTICAL FIN ATTACHMENT BOLTS ASB 222-98-81 CF CF-98-21 VERTICAL FIN ATTACHMENT BOLTS ASB 222-98-81 CF CF-98-21 VERTICAL FIN ATTACHMENT BOLTS ASB 222-98-81 US 82-09-53 PROPER RETENTION SWASHCHATE ORIVE PIN 22-99-84, 222U-99-55 US 82-16-06 MAIN ROTOR SYSTEMS ASB 222-98-82 REV A US 82-16-06 MAIN ROTOR SPAR DOUBLERS ASB 222-98-81 US 83-09-03 MAIN ROTOR SPAR DOUBLERS ASB 222-82-20 US 84-12-02 NODAL BEAM SUPPORT FITTING ASB 222-82-10 US 87-19-01 TAIL ROTOR CONTROL US 87-19-01 FACET LABELS US 88-04-03 MAIN ROTOR SPAR DOUBLERS US 88-04-03 MAIN ROTOR SPAR DOUBLERS US 88-17-05 HORIZON ASB 222-82-92-93 US 89-17-05 HORIZON ASB 222-92-93 US 89-17-05 HORIZON ASB 222-92-93 US 89-17-05 HORIZON ASB 222-92-93 US 89-17-05 HORIZON ASB 222-93-30 US 89-17-05 HORIZON ASB 222-92-93 US 89-17-05 HORIZON ASB 222-92-93 US 89-17-05 HORIZON ASB 222-92-93 US 89-17-05 HORIZON ASB 222-93-30 US 89-17-05 HORIZON ASB 222-93-83 US 89-25-04 TAIL ROTOR BOOST O'LLINGER SUPPORT BRACKET BULKHAD 222-89-18 US 89-25-04 SA 22-29-29-29-29-29-29-29-29-29-29-29-29-2			(KAVNAR) PARREL NUTC	
214B   ( 214 SERIES )			TAIL BUTUS ACCA EVITAGE	214-97-59
214B   ( 214 SERIES )	US	99-05-07	PILLOW BLOCK BEARING BOLTS	214-96-57
222   SERIES   CF	2140			214 34 34
CF			( 214 SERIES )	
CF	214B 1	<u>.</u>	( 214 SERIES )	
CF         CF-98-15         HELLCOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-21         MIN ROTOR PITCH HORN CRACKS         ASB 222-99-81           CF         CF-99-21         VERTICAL FIN ATTACHMENT BOLTS         ASB 222-99-82 REV A           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         ASB 222-89-82 REV A           US         82-16-06         MAIN ROTOR SPARA DOUBLERS         ASB 222-82-16           US         83-09-03         MAIN ROTOR SPARA DOUBLERS         ASB 222-82-17           US         84-12-02         NODAL BEAM SUPPORT FITTING         ASB 222-83-20           US         84-12-02         NODAL BEAM SUPPORT FITTING         ASB 222-83-20           US         87-16-07         CHIP DETECTOR - ARM REVISION         ASB 222-83-20           US         87-16-07         CHIP DETECTOR - ARM REVISION         ASB 222-88-39           US         87-19-01         FACET UBBLE         ASB 222-89-32           US         87-19-01         FACET UBBLE         222-88-98-39           US         89-17-05         HAIN ROTOR CONTAL STABLIZER ASSEMBLY         222-88-98-3           US         89-17-05         HAIN ROTOR CONTAL STABLIZER ASSEMBLY         222-89-95-3         222-89-95-3           US         93-	222 SE	ERIES		
CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 CF CF-98-16 MAIN ROTOR PITCH HORN CRACKS ASB 222-98-81 CF CF-98-12 VERTICAL FIN ATTACHMENT BOLTS ASB 222-98-82 CF CF-99-13 SWASHPLATE DRIVE LINKS TB 222-99-82 US 82-09-53 SWASHPLATE DRIVE LINKS TB 222-99-82 US 82-16-06 MAIN ROTOR SPAR DOUBLERS ASB 222-82-15 US 82-16-06 MAIN ROTOR SPAR DOUBLERS ASB 222-82-15 US 82-16-02 MAIN ROTOR TRUNNION ASB 222-82-15 US 82-14-11 TALL EGGR. CONTROL US 87-19-02 NUTS & WASHERS SPEINE PLATE / DRIVE HUB ASSEMBLY US 87-13-01 CHIP DETECTOR - AFM REVISION US 87-13-07 MAIN ROTOR FLAPPING BEARING US 87-19-07 FACET LABBLS US 87-19-01 FACET LABBLS US 89-17-05 HORIZONTAL STABILIZER ASSEMBLY US 87-19-01 FACET LABBLS US 89-17-05 HORIZONTAL STABILIZER ASSEMBLY US 89-17-05 HORIZONTAL STABILIZER RASSEMBLY US 89-18-14 HAND ROTOR FLAPPING BEARINGS US 89-18-14 RASSEMBLY US 89-25-04 STABILIZER STABILIZER SASSEMBLY US 89-25-04 STABILIZER SASS			ZINC CHROMATE PRIMER TEMP INDICATORS	222-93-67 RFV A
CF   CF-98-19	CF		HELICOPTER RESCUE SYSTEMS	
CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PINN         222-99-84, 222-99-84           US         82-09-53         SWASHPLATE DRIVE LITING         TB 222-81-41           US         83-09-03         MAIN ROTOR SPAR DOUBLERS         ASB 222-81-41           US         84-12-02         MODAL BEAM SUPPORT FITTING         ASB 222-83-20           US         85-14-11         TAIL ROTOR CONTROL         ASB 222-85-33           US         87-09-0282         NUTS & WASHERS - SPLINE PLATE / DRIVE HUB ASSEMBLY           US         87-13-07         MAIN ROTOR FLAPPING BEARING         22-86-39RA           US         87-19-01         FACET LABELS         STC. SH187950           US         88-179-03         MAIN ROTOR VOKE ASSEMBLY         222-86-39RA           US         89-17-05         HORIZONTAL STABILIZER ASSEMBLY         222-89-53, -27           US         89-17-05         HORIZONTAL STABILIZER ASSEMBLY         222-89-53, -22-92-960           CF         CF-93-24         CRACKED PLAPPER BEARINGS         222-99-80           CF         CF-94-02         CRACKED PLAPPER BEARINGS         222-92-96.0           CF         CF-99-12         FLAPPING BEARING-TO-VOKE ATTACHMENT BOLTS         ASB 222-98-83           US         83-02-51         MAIN ROTOR CO			MAIN ROTOR PITCH HORN CRACKS	ASB 222-98-81
US 82-09-53 SWASHPLATE DRIVE LINKS TB 222-81-41 US 82-16-06 MAIN ROTOR SPAR DOUBLERS AS 222-82-15 US 83-09-03 MAIN ROTOR SPAR DOUBLERS AS 222-82-15 US 83-09-03 MAIN ROTOR TRUNNION AS 222-82-17 US 84-12-02 NDDAL BEAM SUPPORT FITTING AS 222-83-20 US 87-13-01 TAIL ROTOR CONTROL US 87-13-01 CHIP DETECTOR - AFM REVISION US 87-15-07 MAIN ROTOR FLAPPING BEARING 222-86-39RA US 87-19-01 FACET LABELS STO SHINE PLATE / DRIVE HUB ASSEMBLY US 87-19-01 FACET LABELS STO SHINE PLATE / DRIVE HUB ASSEMBLY US 88-02-03 MAIN ROTOR FLAPPING BEARING 222-88-46 US 89-17-05 HARIZONTAL STABILIZER ASSEMBLY 222-89-53, -227 US 93-08-14 MAIN ROTOR FLAPPING BEARINGS 222-89-53, -227 CF CF -92-24 (22 SERIES ) CF CF -94-02 INSTALLATION OF BACKUP ALTIMETER AND ASI BHT-222-FM-1, -2 CF CF-96-03R2 TAIL ROTOR BLADE SKIN CRACKING 222-93-76RA US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM ASB 222-89-58, 83-55  222B CF CF -99-12 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS ASB 222-89-83 US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM ASB 222-89-55, 883-55  222B CF CF -99-12 (22 SERIES ) CF CF -99-12 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS ASB 222-89-58, 83-55  222B CF CF -99-12 MAIN ROTOR CONTROL WALKING BEAM ASB 222-89-55, 883-55  222B CF CF -99-12 (22 SERIES ) CF CF -99-12 (22 SERIES ) CF CF -99-12 (32 SERIES ) CF CF -99-12 (42 SERIES ) CF CF -99-12 (43 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS ASB 222-89-83  MAIN ROTOR CONTROL WALKING BEAM ASB 222-89-55, 883-55  222U CF CF -99-12 (52 SERIES ) CF CF -99-12 (74 CRACKED FLAPPER BEARING ASB 222-89-55 & 83-55  222U CF CF -99-12 (74 CRACKED FLAPPER BEARING ASB 222-89-55 & 83-55  222U SF R-15-06 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-89-55 & 83-55  222U CF CF-99-13 (74 CRACKED FLAPPER BEARING ASB 230-99-55 & 83-55  222U CF CF-99-10 (74 CRACKED FLAPPER BEARING ASB 230-99-55 & 83-55  221 CRACKED FLAPPER BEARING ASB 230-99			VERTICAL FIN ATTACHMENT BOLTS	
US			SWASHDIATE DRIVE LINKS	222-99-84,222U-99-55
US			MAIN POTOD SDAD DOUBLEDS	1B 222-81-41
US				
US 87-90-02R2 NUTS 8 WASHERS - SPLINE PLATE / DRIVE HUB ASSEMBLY US 87-19-01 CHIP DETECTOR - AFM REVISION US 87-15-07 MAIN ROTOR FLAPPING BEARING US 87-19-01 FACET LABELS US 88-22-03 MAIN ROTOR FLAPPING BEARING US 88-17-05 HORIZONTAL STABILIZER ASSEMBLY US 98-07-05 HORIZONTAL STABILIZER ASSEMBLY US 93-08-14 MAIN ROTOR FLAPPING BEARINGS 222-88-46 US 93-08-14 MAIN ROTOR FLAPPING BEARINGS 222-99-80, 222-92-30/222-92-60  222 CF CF -92-24 CRACKED FLAPPER BEARINGS CF CF-94-02 INSTALLATION OF BACKUP ALITIMETER AND ASI BHT-222-FM-1, -2 CF CF -99-03R2 TAIL ROTOR BLADE SKIN CRACKING US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM US 83-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-83 US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM 222-83-18 US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM 222-83-18 US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM 222-88-18 US 83-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-83 US 83-02-51 MAIN ROTOR CONTROL WALKING BEAM 222-88-18 US 83-02-50 TAIL BOODST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-83 US 83-02-51 TAIL BOODST BEARINGS CF CF-99-12 CRACKED FLAPPER BEARINGS CF CF-99-12 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-83 US 83-02-51 TAIL BOODST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-85 XS 89-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-85 XS 89-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-55 XS 89-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-55 XS 89-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-55 XS 89-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-55 XS 89-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-98-55 XS 89-25-04 TAIL ROTOR BLADE SKIN CRACKING 222U-92-37 XS 89-25-04 TAIL ROTOR BLADE SKIN CRACKING 222U-95-47RA CF CF-99-16 TAIL ROTOR BLADE SKIN CRACKING 230-95-8 REV A CF CF-99-16 TAIL ROTOR BLADE SKIN CRACKING 230-95-8 REV A CF CF-99-16 PROPER RETENION SWASHPLATE DRIVE PIN CF CF-99-16 PROPER RETE				
US	US	85-14-11		
US		87-09-02R2	NUTS & WASHERS - SPLINE PLATE / DRIVE HUB ASSEMBLY	
US				
US				
US   93-08-14   MAIN ROTOR FLAPPING BEARINGS   222U-92-33/222-92-60				
US   93-08-14   MAIN ROTOR FLAPPING BEARINGS   222U-92-33/222-92-60			MAIN ROTOR YOKE ASSEMBLY	
CF			MAIN ROTOR FLAPPING REARINGS	
CF         CF-92-24         CRACKED FLAPPER BEARINGS         222-92-60           CF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222-95-76RA           CF         CF-99-12         FLAPPING BEARING-TO-VOKE ATTACHMENT BOLTS         ASB 222-98-83           US         89-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD         222-89-55,883-55           222B           CF         CF-99-12         MAIN ROTOR CONTROL WALKING BEAM         222-83-18           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         222-83-18           US         83-15-06         TAILBOOM FAILURE         222-85-28           US         89-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD         222-85-28           CE           CF         CF-92-24         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD         222-85-28           CE         CF-92-24         TAILBOOM FAILURE         222-85-28           CE         CF-92-24         CRACKED FLAPPER BEARINGS         222U-95-38-88           CE         CF-92-24         CRACKED FLAPPER BEARINGS         222U-95-38-88			MAIN NOTON FERTILING BERNINGS	2220 32 00, 222 32 00
CF         CF-94-O2         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-99-12         FLAPPING BEARING-TO-VOKE ATTACHMENT BOLTS         ASB 22-98-83           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         ASB 222-98-83           US         89-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-89-55,883-55           222B         (22 SERIES )         FLAPPING BEARING-TO-VOKE ATTACHMENT BOLTS         ASB 222-98-83           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         222-83-18           US         87-15-06         TAILBOOM FAILURE         222-85-28           US         89-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-89-55 & 83-55           222U         (22 SERIES )         CF CF-92-24         CRACKED FLAPPER BEARINGS         222U-92-33           UF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           UF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           UF         CF-99-12         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           US         87-15-06         TAILBOOM ASSEMBLY         222U-96-47RA           US         87-15-06         TAIL ROTOR BLADE SKIN CRACKING			( 222 SERIES )	
CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222-95-76RA           CF         CF-99-12         FLAPPING BEARING-TO-VOKE ATTACHMENT BOLTS         ASB 222-98-83           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         ASB 222-89-55, &83-55           222B         (22 SERIES)         (22 SERIES)         ASB 222-98-83           CF         CF-99-12         MAIN ROTOR CONTROL WALKING BEAM         222-89-83           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         222-89-83           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         222-89-58           US         83-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-89-55 & 83-55           222U         (222 SERIES)         222-85-28           US         89-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-89-55 & 83-55           222U         (222 SERIES)         222U-95-33           CF         CF-92-24         CRACKED FLAPPER BEARINGS         222U-95-38           CF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           CF         CF-99-12         FLAPPING BEARING-TO-VOKE ATTACHMENT			CRACKED FLAPPER BEARINGS	
CF			INSTALLATION OF BACKUP ALTIMETER AND ASI	
US			TAIL RUTUR BLADE SKIN CRACKING	
US			MAIN DOTOD CONTROL WALKING REAM	
222B         ( 222 SERIES )           CF         CF-99-12         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 222-98-83           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         222-83-18           US         87-15-06         TAILBOOM FAILURE         222-85-28           US         89-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD         222-89-55 & 83-55           222U         ( 222 SERIES )         CRACKED FLAPPER BEARINGS         222U-92-33           CF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-99-12         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           CF         CF-99-12         FLAPPING BEARING-TC-YOKE ATTACHMENT BOLTS         ASB 222U-98-54           US         87-15-06         TAILBOOM ASSEMBLY         222U-95-3           230         CF         CF-99-12         FLAPPING BEARING-TC-YOKE ATTACHMENT BOLTS         ASB 230-98-54           230         TAIL ROTOR BLADE SKIN CRACKING         230-93-2 REV A         220-95-3           230         TAIL ROTOR BLADE SKIN CRACKING         230-93-2 REV A         230-95-8 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-9			MATIN KOTOK ODMINOE WALKING BEAM	
CF         CF-99-12         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 222-98-83           US         83-02-51         MAIN ROTOR CONTROL WALKING BEAM         222-83-18           US         89-25-04         TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD         222-89-55 & 83-55           222U         (222 SERIES)         222U-92-33           CF         CF-92-24         CRACKED FLAPPER BEARINGS         222U-92-33           CF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           CF         CF-99-12         FLAPPING BEARING-TC-YOKE ATTACHMENT BOLTS         ASB 22U-98-54           US         87-15-06         TAILBOOM ASSEMBLY         222U-85-3           230         CF         CF-94-06         ZINC CHROMATE TYPE TEMP INDICATORS         230-93-2 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-95-8 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-95-8 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-99-16         MAIN ROTOR ROTOR PARCHER         ASB 230-98-14           CF<	00	00 20 0-1	THE HOLD BOOST OF ELIBER SOLITOR DIRECTOR	
US	222B	(		
US 87-15-06 TAILBOOM FAILURE 222-85-28 US 89-25-04 TAIL ROTOR BOOST CYLINDER SUPPORT BRACKET BULKHEAD 222-89-55 & 83-55  222U ( 222 SERIES ) CF CF-92-24 CRACKED FLAPPER BEARINGS 222U-92-33 CF CF-94-02 INSTALLATION OF BACKUP ALTIMETER AND ASI BHT-222-FM-1, -2 CF CF-96-03R2 TAIL ROTOR BLADE SKIN CRACKING 222U-95-47RA CF CF-99-12 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS ASB 222U-95-3  230 CF CF-94-06 ZINC CHROMATE TYPE TEMP INDICATORS 230-93-2 REV A CF CF-96-03R2 TAIL ROTOR BLADE SKIN CRACKING 230-95-8 REV A CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 CF CF-98-17 MAIN ROTOR PITCH HORN CRACKS ASB 230-98-13 CF CF-98-22 VERTICAL FIN ATTACHMENT BOLTS ASB 230-98-13 CF CF-99-13 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS ASB 230-98-15 CF CF-99-16 PROPER RETENTION SWASHPLATE DRIVE PIN 230-99-16  407 CF CF-96-19R4 ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1 CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP ASB 407-97-7 CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015 CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK 407-97-7 CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP		CF-99-12		
US 89-25-04				
222U         ( 222 SERIES )           CF         CF-92-24         CRACKED FLAPPER BEARINGS         222U-92-33           CF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           CF         CF-99-12         FLAPPING BEARING-TC-YOKE ATTACHMENT BOLTS         ASB 222U-98-54           US         87-15-06         TAILBOOM ASSEMBLY         222U-85-3           230         CF         CF-94-06         ZINC CHROMATE TYPE TEMP INDICATORS         230-93-2 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-93-2 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-13           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-14 REV A           CF         CF-99-13         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 230-98-15           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         230-99-16           407         ACTION REQ'D TO RETURN FLEET			TAILBOOM FAILURE	
CF         CF-92-24         CRACKED FLAPPER BEARINGS         222U-92-33           CF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           CF         CF-99-12         FLAPPING BEARING-TC-YOKE ATTACHMENT BOLTS         ASB 222U-98-54           US         87-15-06         TAILBOOM ASSEMBLY         230-93-2 REV A           230         CF         CF-94-06         ZINC CHROMATE TYPE TEMP INDICATORS         230-93-2 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-93-2 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-13           CF         CF-98-22         VERTICAL FIN ATTACHMENT BOLTS         ASB 230-98-14           CF         CF-99-13         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 230-98-15           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         230-99-16           407           CF         CF-97-08         TAIL ROTOR HANGER BEARIN	US	89-25-04	TAIL KUTUK BUUST CYLINDER SUPPURT BRACKET BULKMEAD	222-03-00 0 83-00
CF         CF-94-02         INSTALLATION OF BACKUP ALTIMETER AND ASI         BHT-222-FM-1, -2           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           CF         CF-99-12         FLAPPING BEARING-TC-YOKE ATTACHMENT BOLTS         ASB 222U-98-54           US         87-15-06         TAILBOOM ASSEMBLY         22U-85-3           230         CF         CF-94-06         ZINC CHROMATE TYPE TEMP INDICATORS         23O-93-2 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         23O-95-8 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 23O-98-13           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 23O-98-14           CF         CF-99-13         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 23O-98-15           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         23O-99-16           407         CF         CF-97-08         TAIL ROTOR HANGER BEARING SUPPORT GAP         ASB 407-97-7           CF         CF-97-15         MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND         CEB-A-73-6015           CF         CF-97-19         INSPECT T/R ASSY COU	222U	(	222 SERIES )	
CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         222U-95-47RA           CF         CF-99-12         FLAPPING BEARING-TC-YOKE ATTACHMENT BOLTS         ASB 222U-98-54           US         87-15-06         TAILBOOM ASSEMBLY         222U-85-3           230         CF         CF-94-06         ZINC CHROMATE TYPE TEMP INDICATORS         230-93-2 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-93-2 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-13           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-13           CF         CF-99-13         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 230-98-14           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         230-99-16           407         CF         CF-97-08         TAIL ROTOR HANGER BEARING SUPPORT GAP         ASB 407-97-7           CF         CF-97-15         MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND         CEB-A-73-6015           CF         CF-97-19         INSPECT T/R ASSY COUPLINGS.CHECK DIL COOLER BRAK         407-97-7           CF         CF-97-20R1         THOMAS COUPLING -		CF-92-24		
CF				
US   87-15-06   TAILBOOM ASSEMBLY   222U-85-3				
230  CF				
CF         CF-94-06         ZINC CHROMATE TYPE TEMP INDICATORS         230-93-2 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-95-8 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-13           CF         CF-98-22         VERTICAL FIN ATTACHMENT BOLTS         ASB 230-98-14 REV A           CF         CF-99-13         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 230-98-15           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         230-99-16           407           CF         CF-96-19R4         ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1           CF         CF-97-08         TAIL ROTOR HANGER BEARING SUPPORT GAP         ASB 407-97-7           CF         CF-97-15         MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND         CEB-A-73-6015           CF         CF-97-19         INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK         407-97-7           CF         CF-97-20R1         THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP	US	87-15-06	TATEDUUM ASSEMBLY	2220 00 0
CF         CF-94-06         ZINC CHROMATE TYPE TEMP INDICATORS         230-93-2 REV A           CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-95-8 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-13           CF         CF-98-22         VERTICAL FIN ATTACHMENT BOLTS         ASB 230-98-14 REV A           CF         CF-99-13         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 230-98-15           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         230-99-16           407           CF         CF-96-19R4         ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1           CF         CF-97-08         TAIL ROTOR HANGER BEARING SUPPORT GAP         ASB 407-97-7           CF         CF-97-15         MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND         CEB-A-73-6015           CF         CF-97-19         INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK         407-97-7           CF         CF-97-20R1         THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP	230			
CF         CF-96-03R2         TAIL ROTOR BLADE SKIN CRACKING         230-95-8 REV A           CF         CF-98-15         HELICOPTER RESCUE SYSTEMS         CAR 702.21           CF         CF-98-17         MAIN ROTOR PITCH HORN CRACKS         ASB 230-98-13           CF         CF-98-22         VERTICAL FIN ATTACHMENT BOLTS         ASB 230-98-14 REV A           CF         CF-99-13         FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS         ASB 230-98-15           CF         CF-99-16         PROPER RETENTION SWASHPLATE DRIVE PIN         230-99-16           407           CF         CF-96-19R4         ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1           CF         CF-97-08         TAIL ROTOR HANGER BEARING SUPPORT GAP         ASB 407-97-7           CF         CF-97-15         MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND         CEB-A-73-6015           CF         CF-97-19         INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK         407-97-7           CF         CF-97-20R1         THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP		CF-94-06		
CF CF-98-17 MAIN ROTOR PITCH HORN CRACKS  CF CF-98-22 VERTICAL FIN ATTACHMENT BOLTS  CF CF-99-13 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS  CF CF-99-16 PROPER RETENTION SWASHPLATE DRIVE PIN  230-99-16  407  CF CF-96-19R4 ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1  CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP ASB 407-97-7  CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND  CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK 407-97-7  CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP		CF-96-03R2		
CF CF-98-22 VERTICAL FIN ATTACHMENT BOLTS ASB 230-98-14 REV A CF CF-99-13 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS ASB 230-98-15  CF CF-99-16 PROPER RETENTION SWASHPLATE DRIVE PIN 230-99-16  407 CF CF-96-19R4 ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1  CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP ASB 407-97-7  CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015  CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK 407-97-7  CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP				
CF CF-99-13 FLAPPING BEARING-TO-YOKE ATTACHMENT BOLTS ASB 230-98-15 CF CF-99-16 PROPER RETENTION SWASHPLATE DRIVE PIN 230-99-16  407 CF CF-96-19R4 ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1 CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP ASB 407-97-7 CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015 CF CF-97-19 INSPECT T/R ASSY COUPLINGS.CHECK DIL COOLER BRAK 407-97-7 CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP				
CF CF-99-16 PROPER RETENTION SWASHPLATE DRIVE PIN 230-99-16  407 CF CF-96-19R4 ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1 CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP ASB 407-97-7 CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015 CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK 407-97-7 CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP				
407  CF CF-96-19R4 ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1  CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP ASB 407-97-7  CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015  CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK 407-97-7  CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP				
CF CF-96-19R4 ACTION REQ'D TO RETURN FLEET BACK TO FLIGHT STATUS OSN 407-96-1  CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP ASB 407-97-7  CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015  CF CF-97-19 INSPECT T/R ASSY COUPLINGS.CHECK DIL COOLER BRAK 407-97-7  CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP	Cr	01 -95-10	THOSE THE SERVICE OF THE STATE	
CF CF-97-08 TAIL ROTOR HANGER BEARING SUPPORT GAP  CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015  CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK OIL COOLER BRAK 407-97-7  CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP			ACTION DEGAIN TO DETUDN SUBSET BACK TO SUBSET OFFICE	OSN 407-06-4
CF CF-97-15 MIN FUEL FLOW OVERSPEED VALVE-FLIGHT MANUAL AMEND CEB-A-73-6015 CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK DIL CODLER BRAK 407-97-7 CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP				
CF CF-97-19 INSPECT T/R ASSY COUPLINGS. CHECK DIL CODLER BRAK 407-97-7 CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP				
CF CF-97-20R1 THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP			INSPECT T/R ASSY COURTINGS CHECK DIT COULER BRAK	407-97-7
			THOMAS COUPLING - CANCELLATION OF 25 HOUR INSP	
		J. 51 201(1		

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER (SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	BULLETIN DE SERVICE DE REF.
BELL			
407			
	NUED / SUITE)		
CF	CF-97-22	SWASHPLATE DUPLEX BEARING	ASB 407-97-11
CF CF	CF-98-06 CF-98-09	MANUAL CARGO HOOK RELEASE TAIL ROTOR GEARBOX ATTACHMENT NUTS	407-98-16 ASB 407-97-14
CF	CF-98-09 CF-98-10R1	VERTICAL FIN	ASB 407-97-14 ASB 407-98-17REV A
CF	CF-98-13	FADEC FAIL WARNING HORN	407-97-12
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
CF	CF-98-19	DOOR LATCH ROD ASSEMBLY	407-98-18
CF	CF-98-25R1	REPLACEMENT OF DRIVE SHAFT P/N 206-340-300-103	ASB 407-98-19
CF	CF-98-28	HYDRAULIC RELIEF VALVE	ASB 407-98-20
CF	CF-98-36R6	MINIMIZE RISK OF TAIL BOOM STRIKE DURRING FLIGHT	407-99-27RA
CF CF	CF-99-02 CF-99-04	MAIN ROTOR PITCH HORN ASSEMBLY	407-99-25
CF	CF-99-08	AIRWORTHINESS LIMITATIONS OIL COOLER BLOWER BEARINGS	407-98-23
CF	CF-99-17	TAILBOOM SKIN CRACKS	407-99-26
CF	CF-99-19	DOOR LATCH MECHANISM BASEPLATE ASSEMBLY	407-99-30
CF	CF-99-25	CREW SEAT BELT	407-99-29
CF	CF-2000-02	OIL COOLER DRIVESHAFT BEARINGS	
412 SI		UEL TORRES DECAME OUT	
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US US	97-11-04 98-07-03	MAST AND SPLINE PLATE PATIGUE	ASB 412-94-81 REV B
US	98-07-03	TAIL ROTOR YOKE FATIGUE FAILURE	ASB412-96-89
412		( 412 SERIES )	
CF	CF-94-07	ZINC PRIMER AS OVERHEAT INDICATOR	412-93-79 REV A
CF	CF-95-20R1	BOLTS OF FLIGHT CONTROL SERVO ACTUATORS	212-67-01
US	82-26-51R1	YOKE ASSEMBLIES SERVICE TIME	ASB 412-82-9
US	85-07-01	MAIN ROTOR PITCH HORN	ASB 412-83-12 REV A
US	86-16-11	TAIL ROTOR TRUNNION BEARING HOUSING	412-86-25RA
US	89-08-05	MAIN TRANSMISSION - SPIRAL BEVEL GEARS	
US US	90-03-09 92-09-05	T/R TRUNNION BEARING HOUSING ASSEMBLY ENG DRIVESHAFT COUPLING ADAPTER	412-86-25 REV A
US	92-13-10	TAIL ROTOR DRIVESHAFT HANGER BEARINGS	412-91-53 SUPERCEDES 91-24-16
US	93-02-07	VERTICAL FIN SPAR	412-92-65
US	93-17-12	MAIN ROTOR TRANSMISSION LOWER PLANETARY SPIDER	SUPERCEDES 92-11-07
US	94-18-09	MAIN TRANSMISSION LOWER PLANETARY SPIDER	412-93-72 REV A
US	97-07-06	SWASHPLATE SUPPORT ASSY	ASB 412-92-58
US	99-23-23	MAIN ROTOR YOKE	412-98-93
44005		( 440 CERYES )	
412CF US	99-23-23	( 412 SERIES )  MAIN ROTOR YOKE	44005 00 5
0.5	33 23 23	MAIN RUTUR YOKE	412CF-98-5
427			
430			
CF	CF-97-12	POWER OUTPUT GEARS P/N 23056617 FATIGUE LIFE	CEB A-72-5009
CF	CF-97-13	MAIN ROTOR TIP PATH SEPARATION AT 140 KNOTS	430-97-2
CF	CF-97-23R1	REINSTATE APPROVED VNE OF 150 KNOTS	430-98-08
CF CF	CF-98-07 CF-98-15	DIGITAL TRIPLE TORQUE INDICATOR	430-97-3
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS VERTICAL FIN ATTACHMENT BOLTS	CAR 702.21 ASB 430-98-05
CF	CF-98-29	LATERAL CONTROL TUBE	ASB 430-98-05 ASB 430-98-6
CF	CF-99-26	AUTOPILOT RESOLVER	430-99-11
BELLANC			
7 SERI			
CF	CF-89-08R1	FOLDING SEATBACK FRAMES	SL NO. 401
US US	48-08-02	(SEE CLEVELAND PRODUCTS, EQUIPMENT)	
US	48-21-01 48-39-01	ACCELERATOR PUMP LINKAGE	
		CONTROL STICK REWORK	
7AC		( 7 SERIES )	
CF	CF-63-02	SKI CABLES	
US	47-20-01	GASCOLATOR BOWLS	
US	47-20-02	OLEO STRUT	
US	47-30-01	LIFT STRUT	
US US	47-30-05 48-04-02	EXHAUST STACKS	
US	49-11-02	WING LEADING EDGE REAR FUSELAGE WING ATTACHMENT	
		NEAR TOSELAGE WING ATTACHIVENT	
7ACA		( 7 SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT REFERENCE SERVICE BUILLETIN BELLANCA 7BCM ( 7 SERIES ) CF CF-63-02 SKI CABLES US 47-20-01 GASCOLATOR BOWLS US 49-11-02 REAR FUSELAGE WING ATTACHMENT 7CCM ( 7 SERIES ) CF CF-63-02 SKI CABLES S7CCM CF CF-63-02 SKI CABLES ( 7 SERIES ) 7DC S7DC CF CF-63-02 SKI CABLES 7EC ( 7 SERIES ) SKI CABLES CF CF-63-02 US 56-04-01 CONTROL STICK SOCKET S7EC ( 7 SERIES ) CF CF-63-02 SKI CABLES 7FCA ( 7 SERIES ) CF CF-89-08R1 FOLDING SEATBACK FRAMES SI NO 401 67-03-02 71-20-04 FUEL SHUTOFF VALVE BRACKET US LOWER FUSELAGE LONGERON US US 72-20-06 AEROBATIC FLIGHT PLACARD US 75-17-16 ENGINE POWER LOSS 76-22-01 US ADJUSTABLE FRONT SEAT US 79-22-01 EXHAUST SYSTEM US 80-21-06 MUFFLER CORE AND BODY ASSYS COMPETITION HARNESS INSTALLATION US 81-16-04 US 89-18-06 SEAT BACK SL 401 US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 412, 413, 415 7FC ( 7 SERIES ) FIREPROOF STEERING LINK BOOT SL 31 US 57-20-01 7GC SERIES FOLDING SEATBACK FRAMES SL NO. 401 CF CF-89-08R1 ACCELERATOR PUMP LINKAGE US 48-21-01 US 64-04-03 AIR DOOR HINGE OPERATING LIMITATIONS 77-22-05 MUFFLER CORE AND BODY ASSYS US 80-21-06 ( 7GC SERIES )

CF	CF-63-02			SKI	CABL	.ES
7GCA		(	7GC	SER	IES	)

CE-63-02

7GC

US

/GCAA		- (	/ GC	SEKIES /
CF	CF-89-08R1			FOLDING SEATBACK FRAMES
US	67-03-02			FUEL SHUTOFF VALVE BRACKET
US	71-20-04			LOWER FUSELAGE LONGERON
US	72-18-03			CORROSION OF RUDDER & ELEVATOR CABLES
US	72-20-06			AEROBATIC FLIGHT PLACARD

ENGINE POWER LOSS
ADJUSTABLE FRONT SEAT 75-17-16 US 76-22-01 COMPETITION HARNESS INSTALLATION 81-16-04 US SEAT BACK US 89-18-06

( 7GC SERIES ) 7GCB FUEL SHUTOFF VALVE BRACKET 67-03-02 US

( 7GC SERIES )
FOLDING SEATBACK FRAMES 7GCBC CF-89-08R1 CF FUEL SHUTOFF VALVE BRACKET US 67-03-02 LOWER FUSELAGE LONGERON 71-20-04 US CORROSION OF RUDDER & ELEVATOR CABLES
AEROBATIC FLIGHT PLACARD 72-18-03 US US 72-20-06 ENGINE POWER LOSS US 75-17-16 ADJUSTABLE FRONT SEAT 76-22-01 US

AIRCRAFT/AERONEFS

SL NO. 401

SI 401

SL NO. 401

81-16-04

COMPETITION HARNESS INSTALLATION

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT
SUBJECT

### ### ### ### ### ### ### ### ### ##			
Tright   T			
Tright   T	BELLANCA		
CONTINUED / SUITE     US 89-18-06		( 7GC SERIES )	
US 96-18-02 US 96-18-02 US 96-18-02 NETAL SPAR WINGS (SUPERSEDES 96-03-11) SL 412, 413, 415  7KC SERIES CF CF-89-08R1 US 64-04-03 AIR DOOR HINGE MUFFLER CORE AND BODY ASSYS  7KC  (7KC SERIES) CC CF-89-08R1 US 48-21-01 US 48-21-01 US 48-21-01 US 48-21-01 US 71-20-04 LOWER FUSELAGE LONGERON US 71-20-04 LOWER FUSELAGE LONGERON US 72-20-06 ARCOBATILITY LIGHT PLACARD US 72-20-06 ARCOBATILITY LIGHT PLACARD US 77-22-05 US 76-22-01 US 77-22-05 US 78-21-06 US 80-118-03 US 80-1	(CONTINUED / CL	TTE)	
US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) S. L. 412, .413, .415  PXC SERIES CF CF-89-08R1 US 64-04-03 US 80-21-06 AIR DODGY HINGS MUFFLER CORE AND BODY ASSYS  PXC  TXCAB CF CF-89-08R1 CF CF-89-08R1 CF CF-89-08R1 CF CF-89-08R1 CF CF-89-08R1 US 48-21-01 US 48-21-01 US 48-21-01 US 48-21-01 US 77-18-03 CCREATION FOR BUDDER & ELEVATOR CABLES ARROWALD FOR BUDDER & ELEVATOR CABLES US 77-18-03 US 72-20-06 US 75-17-16 ENGINE POWER LOSS US 76-21-06 US 81-16-04 US 89-18-06 SEAT BACK  BACK CF CF-89-08R1 CF CF-89-08R1 US 89-18-06 SEAT BACK  BACK CF CF-89-08R1 US 74-17-16 US 74-17-16 US 89-18-06 SEAT BACK  BACK CF CF-89-08R1 US 74-17-16 U	(CUNTINUED / SU	116)	CI 404
TKC   SERIES			
TKC	US 96-18-0	2 METAL SPAR WINGS (SUPERSED	ES 96-03-11) SL 412, 413, 415
TKC			
TKC	7KC SERIES		
TKC	CF CF-89-C	8R1 FOLDING SEATBACK FRAMES	SL NO. 401
TKC	115 64-04-0	3 AIR DOOR HINGE	
TKC			
TRCAB	03 80-21-0	6 MOTTLER CORE AND BODT ASST.	
TRCAB			
CF         CF-89-08RI         FOLDING SEATBACK FRAMES         SL NO. 401           US         48-21-01         ACCELERATOR PUMP LINNAGE           US         77-18-03         CORROSION DE RUDDER 8 ELEVATOR CABLES           US         77-20-06         CORROSION DE RUDDER 8 ELEVATOR CABLES           US         77-20-05         DECATION SEAT           US         77-22-05         DEPRATING LIMITATIONS           US         80-21-06         MUFFLER CORE AND BODY ASSYS           US         81-16-04         COMPETITION HARNESS INSTALLATION           US         89-18-06         SEAT BACK           SEGES SERIES         CF         CF           CF         CF-99-08RI         FOLDING SEATBACK FRAMES           US         48-21-01         ACCELERATOR PUMP LINNAGE           US         48-21-01         ACCELERATOR PUMP LINNAGE           US         75-04-12         MARKINGS ON TACHOMETR           US         75-07-16         MERCHAUST SYSTEM           US         77-10-16         ENGINE POWER LOSS           US         79-12-10         ENGLANDIS SYSTEM           US         99-18-06         SEAT BACK           US         99-18-06         SEAT BACK           US         99-18	7KC	( /KC SERIES )	
CF         CF-89-08RI         FOLDING SEATBACK FRAMES         SL NO. 401           US         48-21-01         ACCELERATOR PUMP LINNAGE           US         77-18-03         CORROSION DE RUDDER 8 ELEVATOR CABLES           US         77-20-06         CORROSION DE RUDDER 8 ELEVATOR CABLES           US         77-20-05         DECATION SEAT           US         77-22-05         DEPRATING LIMITATIONS           US         80-21-06         MUFFLER CORE AND BODY ASSYS           US         81-16-04         COMPETITION HARNESS INSTALLATION           US         89-18-06         SEAT BACK           SEGES SERIES         CF         CF           CF         CF-99-08RI         FOLDING SEATBACK FRAMES           US         48-21-01         ACCELERATOR PUMP LINNAGE           US         48-21-01         ACCELERATOR PUMP LINNAGE           US         75-04-12         MARKINGS ON TACHOMETR           US         75-07-16         MERCHAUST SYSTEM           US         77-10-16         ENGINE POWER LOSS           US         79-12-10         ENGLANDIS SYSTEM           US         99-18-06         SEAT BACK           US         99-18-06         SEAT BACK           US         99-18			
US 71-20-04 US 71-20-04 US 71-20-04 US 71-20-05 US 72-18-03 CORROSION OF RUDDER & ELEVATOR CABLES US 75-20-06 US 75-20-06 US 75-20-06 US 76-22-01 US 77-22-05 US 80-21-06 US 80-21-06 US 89-18-06 US 89-18-01 US 74-20-01 US 74-15-07 US 75-04-12 US 76-12-01 US 7	7KCAB	( 7KC SERIES )	
US 71-20-04 US 71-20-04 US 71-20-04 US 71-20-05 US 72-18-03 CORROSION OF RUDDER & ELEVATOR CABLES US 75-20-06 US 75-20-06 US 75-20-06 US 76-22-01 US 77-22-05 US 80-21-06 US 80-21-06 US 89-18-06 US 89-18-01 US 74-20-01 US 74-15-07 US 75-04-12 US 76-12-01 US 7	CF CF-89-C	8R1 FOLDING SEATBACK FRAMES	SL NO. 401
US 71-20-04 US 72-18-03 US 72-18-03 US 72-18-03 US 72-18-03 US 75-17-16 US 75-17-16 US 75-17-16 US 75-17-16 US 75-22-01 US 75-17-16 US 76-22-01 US 75-17-16 US 76-22-01 US 75-17-16 US 76-22-01 US 75-20-05 US 75-17-16 US 76-22-01 US 80-21-06 US 80-21-06 US 80-21-06 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-07 US 89-18-06 US 89-18-06 US 89-18-06 US 74-15-07 US 74-20-11 US 74-15-07 US 75-04-16 US 74-15-07 US 75-04-16 US 75-04-16 US 75-04-16 US 75-02-01 US 75-04-16 US 75-02-01 US 75-03-01 US 75		1 ACCEL FRATOR PUMP LINKAGE	
US 75-17-16 US 76-22-01 US 77-22-05 US 77-22-05 US 77-22-05 US 89-18-06 US 75-04-12 US 75-04-12 US 75-17-16 US 75-17-16 US 75-17-16 US 89-18-06 US 89-18-07 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-07 US 77-18-03 US 72-20-06 US 72-18-03 US 72-20-06 US 72-18-03 US 72-20-01 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-07 US 79-22-01 US 80-21-06 US 80-	115 71-20-0		
US 75-17-16 US 76-22-01 US 77-22-05 US 77-22-05 US 77-22-05 US 89-18-06 US 75-04-12 US 75-04-12 US 75-17-16 US 75-17-16 US 75-17-16 US 89-18-06 US 89-18-07 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-07 US 77-18-03 US 72-20-06 US 72-18-03 US 72-20-06 US 72-18-03 US 72-20-01 US 89-18-06 US 89-18-06 US 89-18-06 US 89-18-07 US 79-22-01 US 80-21-06 US 80-	115 70-10-0	CORPOSTON OF DUDDED & ELEVA	TOP CARLES
US 75-17-16 US 76-22-01 US 77-22-05 US 77-22-05 US 77-22-05 US 89-18-06 US 75-04-12 US 75-04-12 US 75-17-16 US 75-17-16 US 75-17-16 US 89-18-06 US 89-18-07 US 77-18-03 US 78-22-01 US 89-18-06 US 78-17-16 US 89-18-06 US 89-18-06 US 81-16-04 US 80-21-06 US 81-16-04 US 80-21-06 US 80-21-06 US 81-16-04 US 80-21-06 US 81-16-04 US 80-21-06 US 81-16-04 US 80-18-102 US 81-16-04 US 96-18-02 US 11-6-01 US 96-18-02 US 11-6-01 US 63-20-01 US 63-20-01 US 79-19-05 US 79-19-05 US 79-19-05 US 79-19-05 US 79-19-05 US 46-41-03 US 46-4	115 72 18 0	CORROSION OF RODDER & ELLV	
US 76-22-01 US 77-22-05 US 80-21-06 WIFFLER CORE AND BODY ASSYS US 81-16-04 US 89-18-06 SEAT BACK SEAT BACK US 89-18-06 SEAT BACK SEAT BACK SL 401  BGCBC SERIES CF CF-89-08R1 GF 48-21-01 US 76-22-01 US 76-04-12 US 76-04-12 US 76-18-06 US 76-22-01 US 76-18-06 US 96-18-06 US 72-20-06 AEROBATIC FLIGHT PLACARD US 72-18-03 CORROSION OF RUDDER & ELEVATOR CABLES US 72-20-06 AEROBATIC FLIGHT PLACARD US 76-22-01 US 76-22-01 US 96-18-06 US 96-	05 /2-20-0	6 AERODATIC FLIGHT PLACARD	
US	05 75-17-1		
### BGCBC SERIES   FOLDING SEATBACK FRAMES   SL NO. 401  ### SEAT SHOW SEAT		1 ADJUSTABLE FRONT SEAT	
### BGCBC SERIES   FOLDING SEATBACK FRAMES   SL NO. 401  ### SEAT SHOW SEAT		5 OPERATING LIMITATIONS	
### BGCBC SERIES   FOLDING SEATBACK FRAMES   SL NO. 401  ### SEAT SHOW SEAT	US 80-21-0	MUFFLER CORE AND BODY ASSY:	
### BGCBC SERIES   FOLDING SEATBACK FRAMES   SL NO. 401  ### SEAT SHOW SEAT	US 81-16-0	4 COMPETITION HARNESS INSTAL	ATION
### SECRICS   FOLDING SEATBACK FRAMES   SL NO. 401		SFAT BACK	SI 401
CF	33 03 18 0	OLAT DAVIC	0.00
CF	OCCOR CERTES		
CF   CF-92-O7R1		EQ. D. T	
US 48-21-01 US 74-15-07 US 75-04-12 US 75-04-12 US 76-22-01 US 76-22-01 US 76-22-01 US 76-22-01 US 79-22-01 US 89-18-06 US 89-18-06 US 98-08-06 US 98-08-06 US 98-08-06 US 98-08-09 US 98-05-04 US 98-05-05 US 98-05 US 98-05-05 US 98-05-05 US 98-05-05 US 98-05-05 US 98-05-			
US   74-15-07   PROPELLER MOUNTING	CF CF-92-0		SUPERSEDED BY 98-05-04
US 75-04-12		1 ACCELERATOR PUMP LINKAGE	
US 75-04-12	US 74-15-0	7 PROPELLER MOUNTING	
US 75-17-16 US 76-22-01 US 79-22-01 US 79-22-01 US 99-18-06 US 99-18-06 US 99-05-04 WOODEN WING SPARS_(SUPERSEDES 96-03-11) US 98-05-04 WOODEN WING SPARS_(SUPERSEDES 87-18-09) BGCBC  (BGCBC SERIES)  BGCBCW (BGCBC SERIES)  BKCAB CF CF-89-08R1 US 48-21-01 US 72-20-06 US 72-20-06 US 72-20-06 US 72-20-01 US 75-17-16 US 75-22-01 US 75-22-01 US 79-22-01 US 79-22-01 US 79-22-01 US 88-21-06 US 88-21-06 US 88-21-06 US 88-21-06 US 88-21-06 US 89-18-06 US 89-18-06 US 89-18-06 US 81-16-04 US 90-15-15R1 US 90-15-15R1 US 90-15-15R1 US 90-15-15R1 US 90-15-15R1 US 90-15-15R1 US 63-06-02 US 63-06-02 US 63-20-07 US 64-41-03 US 46-41-03 US 4	US 75-04-1	MARKINGS ON TACHOMETER	
US   76-22-01	115 75-17-1	ENGINE POWED LOSS	
US			
US			
US   96-18-02			
### BGCBC ### BGCBC SERIES    ### BGCBC ### BGCBCC ### BGCBC ### BGCBC ### BGCBCC ###		SEAT BACK	SL 401
### BGCBC ### BGCBC SERIES    ### BGCBC ### BGCBCC ### BGCBC ### BGCBC ### BGCBCC ###	US 96-18-0	2 METAL SPAR WINGS (SUPERSEDI	ES 96-03-11) SL 412, 413, 415
### BGCBC ### BGCBC SERIES    ### BGCBC ### BGCBCC ### BGCBC ### BGCBC ### BGCBCC ###	US 98-05-0	4 WOODEN WING SPARS (SUPERSE	DES 87-18-09) SL 417 REV B
BKCAB			
BKCAB			
### BKCAB    CF			
### BKCAB    CF			
CF	8GCBC	( 8GCBC SERIES )	
CF	8GCBC	( 8GCBC SERIES )	
US	8GCBC#	( 8GCBC SERIES )	
US   72-18-03   CORROSION OF RUDDER & ELEVATOR CABLES     US   72-20-06   AEROBATIC FLIGHT PLACARD     US   74-23-04   RIB FLANGES     US   75-17-16   ENGINE POWER LOSS     US   76-22-01   ADJUSTABLE FRONT SEAT     US   79-22-01   EXHAUST SYSTEM     US   80-21-06   MUFFLER CORE AND BODY ASSYS     US   81-16-04   COMPETITION HARNESS INSTALLATION     US   89-18-06   SEAT BACK   SL 401     US   90-15-15R1   UPPER WING SPAR FITTINGS     US   90-18-02   METAL SPAR WINGS (SUPERSEDES 96-03-11)   SL 410, 411, 414    14   13   SERIES     US   48-21-01   ACCELERATOR PUMP LINKAGE     US   51-16-01   TRIM TAB MODIFICATION     US   52-17-01   LANDING GEAR CHAIN GUARD     US   63-06-02   RUDDER BELLCRANK     US   63-17-01   MAIN LANDING GEAR     US   63-20-01   BRAKE CYLINDER SUPPORT BRACKET     US   76-20-07   WOOD DECAYED WING SPARS     US   46-41-03   RUDDER BELLCRANK REPLACEMENT     US   46-41-03   CONTROL WALF ING     US   46-41-03   CONTROL WALF INGE     US   46-41-03   CONTROL WALF ING     US   47-07-01   FUEL SELECTOR VALVE INDEXING	8GCBC 8GCBC# 8KCAB	( 8GCBC SERIES )	
US 72-20-06 AEROBATIC FLIGHT PLACARD  US 76-17-16 ENGINE POWER LOSS  US 76-17-16 ENGINE POWER LOSS  US 76-22-01 ENHAUST SYSTEM  US 80-21-06 MUFFLER CORE AND BODY ASSYS  US 81-16-04 COMPETITION HARNESS INSTALLATION  US 90-15-15R1 UPPER WING SPAR FITTINGS  US 90-15-15R1 UPPER WING SPAR FITTINGS  US 90-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES  US 48-21-01 ACCELERATOR PUMP LINKAGE  US 51-16-01 TRIM TAB MODIFICATION  US 52-17-01 LANDING GEAR CHAIN GUARD  US 52-28-02 FUEL PUMP RELIEF VALVE  US 63-06-02 RUDDER BELLCRANK  US 63-06-01 BRAKE CYLINDER SUPPORT BRACKET  US 76-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL BUSHING  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS	8GCBC#  8KCAB  CF CF-89-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES	
US 72-20-06 AEROBATIC FLIGHT PLACARD  US 76-17-16 ENGINE POWER LOSS  US 76-17-16 ENGINE POWER LOSS  US 76-22-01 ENHAUST SYSTEM  US 80-21-06 MUFFLER CORE AND BODY ASSYS  US 81-16-04 COMPETITION HARNESS INSTALLATION  US 90-15-15R1 UPPER WING SPAR FITTINGS  US 90-15-15R1 UPPER WING SPAR FITTINGS  US 90-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES  US 48-21-01 ACCELERATOR PUMP LINKAGE  US 51-16-01 TRIM TAB MODIFICATION  US 52-17-01 LANDING GEAR CHAIN GUARD  US 52-28-02 FUEL PUMP RELIEF VALVE  US 63-06-02 RUDDER BELLCRANK  US 63-06-01 MAIN LANDING GEAR  US 63-20-01 MAIN LANDING GEAR  US 76-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL BUSHING  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS	8GCBC#  8KCAB  CF CF-89-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PLIMP LINKAGE	SL NO. 401
US 75-17-16 ENGINE POWER LOSS US 76-22-01 ADJUSTABLE FRONT SEAT US 79-22-01 EXHAUST SYSTEM US 80-21-06 MUFFLER CORE AND BODY ASSYS US 81-16-04 COMPETITION HARNESS INSTALLATION US 89-18-06 SEAT BACK SL 401 US 90-15-15R1 UPPER WING SPAR FITTINGS US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES US 48-21-01 ACCELERATOR PUMP LINKAGE US 48-21-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-17-01 LANDING GEAR CHAIN GUARD US 52-28-02 FUEL PUMP RELIEF VALVE US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-17-01 BRAKE CYLINDER SUPPORT BRACKET US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 79-19-05 ALLERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS FUEL SELECTOR VALVE INDEXING	8GCBC#  8KCAB  CF CF-89-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PLIMP LINKAGE	SL NO. 401
US 75-17-16 ENGINE POWER LOSS US 76-22-01 ADJUSTABLE FRONT SEAT US 79-22-01 EXHAUST SYSTEM US 80-21-06 MUFFLER CORE AND BODY ASSYS US 81-16-04 COMPETITION HARNESS INSTALLATION US 89-18-06 SEAT BACK SL 401 US 90-15-15R1 UPPER WING SPAR FITTINGS US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES US 48-21-01 ACCELERATOR PUMP LINKAGE US 48-21-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-17-01 LANDING GEAR CHAIN GUARD US 52-28-02 FUEL PUMP RELIEF VALVE US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-17-01 BRAKE CYLINDER SUPPORT BRACKET US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 79-19-05 ALLERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS FUEL SELECTOR VALVE INDEXING	8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0	( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVA	SL NO. 401
US 76-22-01 ADJUSTABLE FRONT SEAT  US 79-22-01 EXHAUST SYSTEM  US 80-21-06 MUFFLER CORE AND BODY ASSYS  US 81-16-04 COMPETITION HARNESS INSTALLATION  US 89-18-06 SEAT BACK SL 401  US 90-15-15R1 UPPER WING SPAR FITTINGS  US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES  US 48-21-01 ACCELERATOR PUMP LINKAGE  US 51-16-01 TRIM TAB MODIFICATION  US 52-17-01 LANDING GEAR CHAIN GUARD  US 52-28-02 FUEL PUMP RELIEF VALVE  US 63-06-02 RUDDER BELLCRANK  US 63-17-01 MAIN LANDING GEAR  US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET  US 63-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES)  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  FUEL SELECTOR VALVE INDEXING	8GCBC#  8KCAB CF CF-89-0 US 48-21-0 US 72-18-0 US 72-20-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVA	SL NO. 401
US 79-22-01 EXHAUST SYSTEM US 80-21-06 MUFFLER CORE AND BODY ASSYS US 81-16-04 COMPETITION HARNESS INSTALLATION US 89-18-06 SEAT BACK SL 401 US 90-15-15R1 UPPER WING SPAR FITTINGS US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES US 48-21-01 ACCELERATOR PUMP LINKAGE US 51-16-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-17-01 LANDING GEAR CHAIN GUARD US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-20-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHTING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC 8GCBC# 8KCAB CF CF-89-0 US 48-21-0 US 72-18-0 US 72-20-0 US 74-23-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEV/ AEROBATIC FLIGHT PLACARD RIB FLANGES FINGINE POWER LOSS	SL NO. 401
US 79-22-01 EXHAUST SYSTEM US 80-21-06 MUFFLER CORE AND BODY ASSYS US 81-16-04 COMPETITION HARNESS INSTALLATION US 89-18-06 SEAT BACK SL 401 US 90-15-15R1 UPPER WING SPAR FITTINGS US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES US 48-21-01 ACCELERATOR PUMP LINKAGE US 51-16-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-17-01 LANDING GEAR CHAIN GUARD US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-20-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHTING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 72-20-0  US 74-23-0  US 75-17-1	( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEV/ AEROBATIC FLIGHT PLACARD RIB FLANGES FINGINE POWER LOSS	SL NO. 401
US 81-16-04 COMPETITION HARNESS INSTALLATION US 89-18-06 SEAT BACK SL 401 US 90-15-15R1 UPPER WING SPAR FITTINGS US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES  US 48-21-01 ACCELERATOR PUMP LINKAGE US 51-16-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-17-01 LANDING GEAR CHAIN GUARD US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEV/ AEROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT	SL NO. 401
US 89-18-06 SEAT BACK SL 401  US 90-15-15R1 UPPER WING SPAR FITTINGS  US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES  US 48-21-01 ACCELERATOR PUMP LINKAGE  US 51-16-01 TRIM TAB MODIFICATION  US 52-17-01 LANDING GEAR CHAIN GUARD  US 52-28-02 FUEL PUMP RELIEF VALVE  US 63-06-02 RUDDER BELLCRANK  US 63-17-01 MAIN LANDING GEAR  US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET  US 76-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES)  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVA AFROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM	SL NO. 401
US 90-15-15R1 UPPER WING SPAR FITTINGS US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES US 48-21-01 ACCELERATOR PUMP LINKAGE US 51-16-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-28-02 FUEL PUMP RELIEF VALVE US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVA AEROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYS	SL NO. 401
US 90-15-15R1 UPPER WING SPAR FITTINGS US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES US 48-21-01 ACCELERATOR PUMP LINKAGE US 51-16-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-28-02 FUEL PUMP RELIEF VALVE US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 72-20-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 81-16-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEV/ AEROBATIC FLIGHT PLACARD FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYS COMPETITION HARNESS INSTALE	SL NO. 401 ATOR CABLES S. ATION
US 96-18-02 METAL SPAR WINGS (SUPERSEDES 96-03-11) SL 410, 411, 414  14 13 SERIES  US 48-21-01 ACCELERATOR PUMP LINKAGE US 51-16-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-28-02 FUEL PUMP RELIEF VALVE US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHTING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 89-18-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SCORROSION OF RUDDER & ELEVATE ACCEPTAGE AND FROM THE PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM COMPETITION HARNESS INSTALLS SEAT BACK	SL NO. 401  ATOR CABLES  SATION SL 401
14 13 SERIES  US	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 89-18-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SCORROSION OF RUDDER & ELEVATE ACCEPTAGE AND FROM A FIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM COMPETITION HARNESS INSTALLS SEAT BACK	SL NO. 401  ATOR CABLES  SATION SL 401
US 48-21-01 ACCELERATOR PUMP LINKAGE  US 51-16-01 TRIM TAB MODIFICATION  US 52-17-01 LANDING GEAR CHAIN GUARD  US 52-28-02 FUEL PUMP RELIEF VALVE  US 63-06-02 RUDDER BELLCRANK  US 63-17-01 MAIN LANDING GEAR  US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET  US 76-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES )  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHTING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 90-15-1	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SEATBACK FRAMES ACCELERATOR PUMP LINKAGE ACCORNOSION OF RUDDER & ELEVATE ACCORD ACCORD FRUDDER & ELEVATE ACCORD FR	SL NO. 401  ATOR CABLES  SATION  SL 401
US 48-21-01 ACCELERATOR PUMP LINKAGE  US 51-16-01 TRIM TAB MODIFICATION  US 52-17-01 LANDING GEAR CHAIN GUARD  US 52-28-02 FUEL PUMP RELIEF VALVE  US 63-06-02 RUDDER BELLCRANK  US 63-17-01 MAIN LANDING GEAR  US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET  US 76-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES)  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHTING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 90-15-1	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SEATBACK FRAMES ACCELERATOR PUMP LINKAGE ACCORNOSION OF RUDDER & ELEVATE ACCORD ACCORD FRUDDER & ELEVATE ACCORD FR	SL NO. 401  ATOR CABLES  SATION  SL 401
US 51-16-01 TRIM TAB MODIFICATION US 52-17-01 LANDING GEAR CHAIN GUARD US 52-28-02 FUEL PUMP RELIEF VALVE US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SEATBACK FRAMES ACCELERATOR PUMP LINKAGE ACCORNOSION OF RUDDER & ELEVATE ACCORD ACCORD FRUDDER & ELEVATE ACCORD FR	SL NO. 401  ATOR CABLES  SATION  SL 401
US 52-17-01 LANDING GEAR CHAIN GUARD US 52-28-02 FUEL PUMP RELIEF VALVE US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES ) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SEATBACK FRAMES ACCORROSION OF RUDDER & ELEVATOR FRAMES ACCORDED FROM FRAMES ACCORDED FROM FRAMES ACCORDED FROM FRAMES FROM SEAT BACK SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE	SL NO. 401  ATOR CABLES  SATION  SL 401
US 52-28-02 FUEL PUMP RELIEF VALVE  US 63-06-02 RUDDER BELLCRANK  US 63-17-01 MAIN LANDING GEAR  US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET  US 76-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES )  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHTING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 81-16-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVATE ACTION OF RUDDER &	SL NO. 401  ATOR CABLES  SATION  SL 401
US 63-06-02 RUDDER BELLCRANK US 63-17-01 MAIN LANDING GEAR US 76-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES ) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL BUSHING US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 80-21-0  US 80-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVARY AND FRAMES ALLOW A RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM ACCOMPETITION HARNESS INSTALL SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE ACCELERATOR PUMP LINKAGE TRIM TAB MODIFICATION	SL NO. 401  ATOR CABLES  SATION  SL 401
US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL BUSHING US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 48-21-0  US 52-17-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVACE ACCEPTAGE	SL NO. 401  ATOR CABLES  SATION  SL 401
US 63-17-01 MAIN LANDING GEAR US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL BUSHING US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 52-17-0  US 52-28-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVACE ACCEPTAGE	SL NO. 401  ATOR CABLES  SATION  SL 401
US 63-20-01 BRAKE CYLINDER SUPPORT BRACKET US 76-20-07 WOOD DECAYED WING SPARS US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES ) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 75-17-1  US 76-22-0  US 79-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 52-17-0  US 52-28-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SEATBACK FRAMES ACCELERATOR PUMP LINKAGE TO AFROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTANDED FOR ACCELERATOR PUMP LINKAGE TRIM TAB MODIFICATION METAL SPAR WINGS (SUPERSEDE TRIM TAB MODIFICATION LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE	SL NO. 401  ATOR CABLES  SATION  SL 401
US 76-20-07 WOOD DECAYED WING SPARS  US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES )  US 46-41-01 RUDDER BELLCRANK REPLACEMENT  US 46-41-02 AILERON CONTROL BUSHTING  US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS  US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 80-21-0  US 80-15-1  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 52-17-0  US 52-28-0  US 63-06-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1	SL NO. 401  ATOR CABLES  SATION  SL 401
US 79-19-05 AILERON CONTROL SYSTEM  14 13 (14 13 SERIES) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 52-17-0  US 52-17-0  US 53-06-0  US 63-17-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE FOR PUMP LINKAGE FOR PUMP LINKAGE FOR PUMP LINKAGE FOR POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM FOR PUMP LINKAGE FOR PUMP LINKAGE FOR PUMP LINKAGE FOR PUMP LINKAGE FRIM TAB MODIFICATION LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE PUMP RELIEF VALVE FUED FOR PUMP LINKAGE FUEL PUMP RELIEF VALVE PUMP LINKAGE FUEL PUMP RELIEF VALVE PUMP RELIEF PUMP RELIEF PUMP RELIEF VALVE PUMP RELIEF PUMP RELIEF PUMP RELIEF PUMP RELIEF PUMP RELIEF PUMP REL	SL NO. 401  ATOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414
14 13 ( 14 13 SERIES ) US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 52-28-0  US 63-06-0  US 63-17-0  US 63-20-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVACE ACCORDANCE FOR A FUNCTION OF RUDDER & ELEVACE ACCORDANCE FROM THE FLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM ADJUSTABLE FRONT SEAT EXHAUST SYSTEM FUMPETION HARNESS INSTALL SEAT BACK COMPETITION HARNESS INSTALL SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE TRIM TAB MODIFICATION LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE RUDDER BELLCRANK MAIN LANDING GEAR BRAKE CYLINDER SUPPORT BRACE	SL NO. 401  ATOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414
US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 51-16-0  US 52-28-0  US 63-06-0  US 63-07-0  US 63-20-0  US 76-20-0  US 76-20-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVARION ENGINEER FOR SEAT ALL SEAT ACCELERATOR POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYST ACCEPTED AND BODY ASSYST ACCEPTED AND BODY ASSYST ACCEPTED AND BODY ASSYST ACCEPTED AND ACCEPTED A	SL NO. 401  ATOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414
US 46-41-01 RUDDER BELLCRANK REPLACEMENT US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 51-16-0  US 52-28-0  US 63-06-0  US 63-07-0  US 63-20-0  US 76-20-0  US 76-20-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVARION ENGINEER FOR SEAT ALL SEAT ACCELERATOR POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYST ACCEPTED AND BODY ASSYST ACCEPTED AND BODY ASSYST ACCEPTED AND BODY ASSYST ACCEPTED AND ACCEPTED A	SL NO. 401  ATOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414
US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 52-17-0  US 52-28-0  US 63-06-0  US 63-17-0  US 63-20-0  US 79-20-0  US 79-20-0  US 79-20-0  US 79-20-0  US 79-19-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEV. AEROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM COMPETITION HARNESS INSTALL SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE TRIM TAB MODIFICATION LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE RUDDER BELLCRANK MAIN LANDING GEAR BRAKE CYLINDER SUPPORT BRACK WOOD DECAYED WING SPARS	SL NO. 401  ATOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414
US 46-41-02 AILERON CONTROL BUSHING US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 75-17-1  US 76-22-0  US 80-21-0  US 80-21-0  US 89-18-0  US 90-15-1  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 52-28-0  US 63-06-0  US 63-20-0  US 63-20-0  US 79-19-0  14 13	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SERIES BY ACCELERATOR PUMP LINKAGE AEROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYS COMPETITION HARNESS INSTALISED SEAT BACK SEA	SL NO. 401  ATOR CABLES  SATION SL 401 SS 96-03-11) SL 410, 411, 414
US 46-41-03 CONTROL WHEEL UNIVERSAL JOINTS US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 75-17-1  US 76-22-0  US 80-21-0  US 80-21-0  US 89-18-0  US 90-15-1  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 52-28-0  US 63-06-0  US 63-20-0  US 63-20-0  US 79-19-0  14 13	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE SERIES BY ACCELERATOR PUMP LINKAGE AEROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYS COMPETITION HARNESS INSTALISED SEAT BACK SEA	SL NO. 401  ATOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414
US 47-07-01 FUEL SELECTOR VALVE INDEXING	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 72-20-0  US 74-23-0  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 52-17-0  US 52-17-0  US 63-06-0  US 63-06-0  US 63-17-0  US 63-20-0  US 79-19-0  14 13  US 46-41-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVARION FROM PROPER & ELEVARION FROM POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM MUFFLER COMPETITION HARNESS INSTALL SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE TRIM TAB MODIFICATION LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE RUDDER BELLCRANK MAIN LANDING GEAR BRAKE CYLINDER SUPPORT BRACK WOOD DECAYED WING SPARS AILERON CONTROL SYSTEM (14 13 SERIES )	SL NO. 401  ATOR CABLES  SATION SL 401 SS 96-03-11) SL 410, 411, 414
The state of the s	8GCBC  8GCBC#  8KCAB  CF CF-89-0 US 48-21-0 US 72-20-0 US 74-23-0 US 75-17-1 US 76-22-0 US 80-21-0 US 89-18-0 US 90-15-1 US 96-18-0  14 13 SERIES US 48-21-0 US 52-17-0 US 52-28-0 US 63-06-0 US 63-17-0 US 63-20-0 US 79-19-0  14 13 US 46-41-0 US 46-41-0 US 46-41-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEV. AEROBATIC FLIGHT PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYSTEM COMPETITION HARNESS INSTALL SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE TRIM TAB MODIFICATION LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE RUDDER BELLCRANK MAIN LANDING GEAR BRAKE CYLINDER SUPPORT BRAGE WOOD DECAYED WING SPARS AILERON CONTROL SYSTEM	SL NO. 401  ATOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414
I LAF TITINGL BRACKET	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-20-0  US 75-17-1  US 76-22-0  US 80-21-0  US 80-21-0  US 89-18-0  US 90-15-1  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 51-16-0  US 52-28-0  US 63-06-0  US 63-20-0  US 63-20-0  US 79-19-0  14 13  US 46-41-0  US 46-41-0  US 46-41-0  US 46-41-0  US 46-41-0  US 46-41-0	( 8GCBC SERIES )  ( 8GCBC SERIES )  ( 8GCBC SERIES )  BR1 FOLDING SEATBACK FRAMES ACCELERATOR PUMP LINKAGE CORROSION OF RUDDER & ELEVATE ACCORDING FROM THE PLACARD RIB FLANGES ENGINE POWER LOSS ADJUSTABLE FRONT SEAT EXHAUST SYSTEM MUFFLER CORE AND BODY ASSYS COMPETITION HARNESS INSTALL SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE TRIAL SEAT BACK UPPER WING SPAR FITTINGS METAL SPAR WINGS (SUPERSEDE TRIAL TAB MODIFICATION LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE RUDDER BELLCRANK MAIN LANDING GEAR BRAKE CYLINDER SUPPORT BRACK WOOD DECAYED WING SPARS ATLERON CONTROL SYSTEM  ( 14 13 SERIES )  RUDDER BELLCRANK REPLACEMENT ALLERON CONTROL BUSHING CONTROL BUSHING CONTROL BUSHING CONTROL WHEEL UNIVERSAL JO:	SL NO. 401  NTOR CABLES  SATION  SL 401  SS 96-03-11)  SL 410, 411, 414  CKET
	8GCBC  8GCBC#  8KCAB  CF CF-89-0  US 48-21-0  US 72-18-0  US 74-23-0  US 75-17-1  US 76-22-0  US 80-21-0  US 89-18-0  US 90-15-1  US 96-18-0  14 13 SERIES  US 48-21-0  US 52-17-0  US 52-17-0  US 63-06-0  US 63-06-0  US 63-06-0  US 63-17-0  US 79-19-0  14 13  US 46-41-0  US 46-41-0	( BGCBC SERIES )  ( BGCBC SERIES )  ( BGCBC SERIES )  BR1	SL NO. 401  ATOR CABLES  SLATION  SL 401  SS 96-03-11)  SL 410, 411, 414  CKET

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT

REFERENCE SERVICE BULLETIN

CHICHE	NOWERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
BELLAN	CA			
14 13		( 14	13 SERIES )	
(CONTIN	NED / SUITE)	, , , ,	TO SERIES /	
US	47-25-09		FIN AND STABILIZER FITTINGS	
US	47-32-17		LANDING GEAR INSPECTION COVERS	
US US	47-32-18		SPROCKET COTTER PIN	
US	47-51-13 48-05-03		CABIN HEAT CONTROL VALVE	
US	48-13-06		TRIM TAB BRACKET BOLTS	
US	49-13-02		ENGINE COWL BRACKETS LANDING GEAR DRAG STRUT	
			LANDING GEAR DRAG STRUT	
14 13		( 14	13 SERIES )	
US	46-41-01		RUDDER BELLCRANK REPLACEMENT	
US	46-41-02		AILERON CONTROL BUSHING	
US US	46-41-03		CONTROL WHEEL UNIVERSAL JOINTS	
US	47-07-01 47-14-01		FUEL SELECTOR VALVE INDEXING	
US	47-25-09		FLAP HINGE BRACKET FIN AND STABILIZER FITTINGS	
US	47-32-17		LANDING GEAR INSPECTION COVERS	
US	47-32-18		SPROCKET COTTER PIN	
US	48-05-03		TRIM TAB BRACKET BOLTS	
US	48-13-06		ENGINE COWL BRACKETS	
US	49-13-02		LANDING GEAR DRAG STRUT	
US US	51-16-01		TRIM TAB MODIFICATION	
US	52-17-01 52-28-02		LANDING GEAR CHAIN GUARD FUEL PUMP RELIEF VALVE	
US	63-06-02		RUDDER BELLCRANK	
US	63-17-01		MAIN LANDING GEAR	
US	63-20-01		BRAKE CYLINDER SUPPORT BRACKET	
US	76-20-07		WOOD DECAYED WING SPARS	
44 40		.,	40.000	
14 13 US	49-13-02	( 14	13 SERIES ) LANDING GEAR DRAG STRUT	
US	52-17-01		LANDING GEAR CHAIN GUARD	
	52-28-02		FUEL PUMP RELIEF VALVE	
US	63-06-02		RUDDER BELLCRANK	
US	63-17-01		MAIN LANDING GEAR	
US	63-20-01		BRAKE CYLINDER SUPPORT BRACKET	
US	76-20-07		WOOD DECAYED WING SPARS	
14 19	SERIES			
US	48-21-01		ACCELERATOR PUMP LINKAGE	
US	51-16-02		TRIM TAB MODIFICATION	
US	53-16-01		ELEVATOR TRIM TAB LOOSENESS	NO. 4
14 19		( 40	40 CEDIEC )	
US US	63-06-02	( 14	19 SERIES ) RUDDER BELLCRANK	
US	76-08-04		WOOD DETERIORATION	
14 19		( 14	19 SERIES )	
US	63-06-02		RUDDER BELLCRANK	
US US	72-01-01 76-08-04		ENGINE FLEX HOSE ASSYS WOOD DETERIORATION	
03	70-08-04		WOOD DETERIORATION	
14 19	3	( 14	19 SERIES )	
US	72-01-01		ENGINE FLEX HOSE ASSYS	
US	76-08-04		WOOD DETERIORATION	
US	77-22-02		NOSE LANDING GEAR ENGINE MOUNT MLG - LH & RH DRAG STRUT LANDING GEAR FITTING ASSY	B-106
US	90-02-17		MILG LITA KIT DAAG STAGT LANDING GLAR TITTING ASSY	5 100
14 19	3A	( 14	19 SERIES )	
US	68-23-08		HORIZONTAL TAIL SURFACE	
US	69-12-04		STABILIZER STRUT CLEVIS	
US	72-01-01		ENGINE FLEX HOSE ASSYS	
US	75-20-06		VERTICAL TUBES WOOD DETERIORATION	
US US	76-08-04 77-22-02		NOSE LANDING GEAR ENGINE MOUNT	
US	90-02-17		MLG - LH & RH DRAG STRUT LANDING GEAR FITTING ASSY	B-106
00	00 02 17			
17 30	SERIES			
	48-21-01		ACCELERATOR PUMP LINKAGE	
US	76-23-03R1		EXHAUST SYSTEM QUICK DRAIN VALVES - WING MAIN & AUX FUEL TANKS	
US US	86-25-06 87-11-01R1		FUEL CAPS & DRAINS	SL B-105
US	96-18-07		NOSE LANDING GEAR DRAG STRUT BRACKET INSPECTION	SL B-107

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE SUBJECT
SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET
DELL ANCA	
BELLANCA 17 30 SERIES	
(CONTINUED / SUITE)	BOR FIFLDS AFROCESSORIES STC
US 98-21-21	ROR FIELDS VEROCESPORIES 210
17 30	( 17 30 SERIES )
US 68-23-08	HORIZONTAL TAIL SURFACE STABILIZER STRUT CLEVIS
US 69-12-04 US 71-10-01	FUEL LEAKAGE
US 72-01-01	ENGINE FLEX HOSE ASSYS
US 72-13-03	FUEL BOOST PUMP CIRCUIT
US 75-20-06 US 76-08-04	VERTICAL TUBES WOOD DETERIORATION
US 77-22-02	NOSE LANDING GEAR ENGINE MOUNT
US 90-02-17	MLG - LH & RH DRAG STRUT LANDING GEAR FITTING ASSY B-106
17 30A	( 17 30 SERIES )
US 72-01-03	ENGINE FUEL HOSE
US 73-03-03	ENGINE INDUCTION BOX BOLTS
US 73-05-02 US 75-20-06	RUDDER CONTROL SYSTEM  VERTICAL TUBES
US 76-08-04	WOOD DETERIORATION
US 77-22-02	NOSE LANDING GEAR ENGINE MOUNT
US 90-02-17	MLG - LH & RH DRAG STRUT LANDING GEAR FITTING ASSY B-106
17 31 SERIES	
US 48-21-01	ACCELERATOR PUMP LINKAGE
US 86-25-06	QUICK DRAIN VALVES - WING MAIN & AUX FUEL TANKS FUEL CAPS & DRAINS SL B-105
US 87-11-01R1 US 96-18-07	NOSE LANDING GEAR DRAG STRUT BRACKET INSPECTION SL B-107
US 98-21-21	BOB FIELDS AEROCESSORIES STC
47 244	( 17 31 SERIES )
17 31A US 72-01-03	ENGINE FUEL HOSE
US 73-05-02	RUDDER CONTROL SYSTEM
US 75-11-06	CHECK VALVE
US 75-20-06 US 76-08-04	VERTICAL TUBES WOOD DETERIORATION
US 76-23-03R1	EXHAUST SYSTEM
US 90-02-17	MLG - LH & RH DRAG STRUT LANDING GEAR FITTING ASSY B-106
17 31ATC	( 17 31 SERIES )
US 72-01-03	ENGINE FUEL HOSE
US 73-05-02	RUDDER CONTROL SYSTEM
US 75-11-06 US 75-20-06	CHECK VALVE VERTICAL TUBES
US 76-08-04	DETERIORATION
US 90-02-17	MLG - LH & RH DRAG STRUT LANDING GEAR FITTING ASSY B-106
BOEING	
PT 17	
75 CEDIES	
75 SERIES CF CF-61-07	FUEL GAUGE SIGHT GLASS
US 46-24-01	WING DRAIN HOLES
US 49-23-01	FUSELAGE TRUSS
US 50-06-02 US 60-08-02	WING SPAR INSPECTION LONGERON CRACKS
US 63-13-01	INSPECTION OF PROPELLERS
75	( 75 SERIES )
A75	( 75 SERIES )
A75N1	( 75 SERIES )
B75N1	( 75 SERIES )
D75N1	( 75 SERIES )
E75	( 75 SERIES )
E75N1	( 75 SERIES )

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

	NOWERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
BOEING			
720B S			
CF	CF-96-04	CORROSION PREVENTION & CONTROL PROGRAMS	
	00 00 01	ENGINE OIL FILIER PRESSURE SYSTEM	1586
US	63-11-01	MAIN LANDING GEAR TRUCK BEAM INSP.	1780
US	64-15-02	WING SKIN CRACKS	100201
US	65-21-02	FORWARD REVERSER SWITCH BRACKET WING UPPER SURFACE SKIN	2039
US	66-01-01	WING UPPER SURFACE SKIN	2309
US	66-07-01	MAIN LANDING GEAR REAR AXLES	2221/2246
US	79-19-01R2	SPETCE STRINGERS INSPECTION	3226R5
US	79-24-04R1	HORIZONTAL STABILIZER	3332R2
US	87-08-09	WITHOGEN IN LATION A / C TIKES	
US	91-22-04	MAIN CARGO DOOR	3311
US	92-10-10	MAIN CARGO DOOR BRAKE WEAR LIMITS MIDSPAR FITTING AGING AIRCRAFT	
US	93-11-02	MIDSPAR FITTING AGING AIRCRAFT	3183 R5
US	94-10-06	AGING AIRCRAFT	D6-54996
US	95-17-01	UPPER FORWARD SKIN PANELS - WING TO CENTER SECTION	2590 REV B
720 02		( 720B SERIES )	
US	90-25-07	AGING AIRCRAFT	D6-54928
US	92-03-12		3240 REV 3
US	93-05-17	"E-F" WINDOW POST	2983 REV 5
727 SE			
CF		CORROSION PREVENTION & CONTROL PROGRAMS	
US	64-03-01	FUEL TANK ACCESS DOORS	28-7
US	64-06-03	FLIGHT SPOILER ACTUATOR ROD	27-18
US	64-12-02		78-10R1
US			
US	64-26-01 65-03-02	DEACTIVATION OF THE AUTOPILOT HORIZONTAL STABILIZER DRAIN HOLES	22~7
US	65-03-02	HORIZONTAL STABILIZER DRAIN HOLES	55-14A
03	65-17-01	THRUST REVERSER ACTUATOR PISTON	78-18
US	66-08-02	FLAP DRIVE COUPLING SLEEVE	
US	66-22-02	PNEUMATIC BRAKE SYSTEM	29-22
	66-23-01	FUEL LINE B NUTS	28-25
US	66-24-01	TRIM SYSTEM BRAKE	
US	66-29-01		71-27
US	66-30-02	FUEL AND ELECTRICAL LINES	28-26
US	67-02-01	TRAILING EDGE BEAM	55-15
US	67-07-01	SPERRY SP-50 AUTOPILOT	TA-697-104 SPERRY
US	67-14-02	LANDING GEAR SIDE STRUT	32-79R1
US	67-22-03	MAIN GEAR DOWNLOCK ROD .	32-123R1
	68-08-02	LANDING GEAR SIDE STRUT MAIN GEAR DOWNLOCK ROD AFT TRUNNION EXTENSION	32-153
US	68-10-02	HEATER BLANKETS  DEFLECTOR DOORS  GEAR DOWNLOCK ACTUATING SYSTEM  CRACKS IN HORIZONTAL STABILIZER  DAMAGE TO WIRE BUNDLES  RUDDER PEDAL DISPLACEMENT	2 GENERAL ELECTRIC
US	68-10-05	DEFLECTOR DOORS	78-51R1
US	68-14-02	GEAR DOWNLOCK ACTUALING SYSTEM	32-160
US	68-15-01	CRACKS IN HORIZONIAL STABILIZER	55-1886
US	68-15-04	DAMAGE TO WIRE BUNDLES	24-27
US		RUDDER PEDAL DISPLACEMENT	20-36K1
US	69-04-01	RUDDER FEDAL DISPLACEMENT OPERATION OF BATTERY SWITCH TAKEOFF WARNING SYSTEM	27-10201
US	69-12-02	TAKEOFF WARNING SYSTEM	27-102K1
US	69-15-05	ENGINE FIRE EXTINGUISHER	26-04 APCO
US	69-16-01	GENERATOR LOSS	24-48
US	69-20-06 69-25-01	CIRCUIT OVERLOADS	24-48
US	69-25-01	GENERATOR CONTROL CIRCUIT	66-102 WEST INCHOUSE
US	69-25-02	GENERATOR SYSTEM LOCKOOT	66-103 WESTINGHOUSE
US	69-25-03		71-43
US	70-26-03	MAIN GENT THOUSAND	57-115
US	71-09-04		32-188
US	71-26-01	MAIN LANDING GEAR ACTUATOR BEAM	32-196R1
US	72-12-01	MAIN GEAR DOWNLOCK SHAFT	32-180R1
US	72-25-03	MAIN GEAR TRUNNION SUPPORT BEAM	57-122
US	73-06-01	LEADING EDGE SLAT ACTUATORS	27-129 727-52-83R1
US	73-09-04	ENTRY DOOR HINGE	
US	73-26-06	CORROSION OF TORSION SHAFTS	727-32-203
US	74-09-05	EMERGENCY EXITS	727-25-214 727-55-59
US	74-10-08		707 20-018
US	74-18-09	LANDING GEAR ACTUATORS	727-32-218
US	74-21-03	FIRE HAZARD	727-25-211
US	74-23-03	AIR CONDITIONING PACKS	727-36-17R2/18R1/22
US	75-05-01	CONTROL CABLE PULLEYS	727-27-155R1
US	75-09-04R1	CENTER SECTION FITTING	727-55-0062 R4
US	75-20-09	WING VIBRATIONS	727-57-137
	76-07-05	NOSE LANDING GEAR	727-32-203R3/205/223 727-53-128R2
US		BODY CORROSION OR CRACKING	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

005 7 446			
BOEING			
	SERIES		
	NUED / SUITE)		
US	76-15-06	ELEVATOR BALANCE PANEL HINGES	727-55-A65
US	77-03-02R2	FUEL FEED HOSE ASSEMBLIES	727-28-51
US	77-13-15	FLOOR BEAM CRACKING	727-53-134R3
US	77-18-06	HORIZONTAL STABILIZER	727-55-A69
US	78-01-08	AUTOMATIC THROTTLES	727-31-30
US	78-11-07	HORIZONTAL STABILIZERS	727-55-A73
US	78-24-05R1	GALLEY DOOR & EMERGENCY GIRT BAR THRUST REVERSER ASSEMBLY MAIN LANDING GEAR-UP LANDINGS CRACKS OR MISSING PIECES IN SLIDERS AUTO SPEEDBRAKE SYSTEM	727-25-A247
US	78-26-07	THRUST REVERSER ASSEMBLY	727-78-A86
US	79-04-01R3	MAIN LANDING GEAR-UP LANDINGS	727-32-211R4/
US	79-10-05	CRACKS OR MISSING PIECES IN SLIDERS	727-57-A147
US	79-11-02 79-20-06	AUTO SPEEDBRAKE SYSTEM	727-31-A44R1
US	79-20-06	AUTO SPEEDBRAKE SYSTEM SIDE STRUT ASSEMBLIES	727-32-268R1
US	79-20-06 79-23-02 80-02-0182	"CARRY-ALL" INTERIOR AUXILIARY BODY FUEL TANK INSTALLATION	727-35-A18/A1014
US	00 02 01112	AGATETATO BODY TOLE TANK INSTALLATION	727-28A0062R5
US	80-07-02	FLIGHT CONTROL SYSTEMS	
US	80-08-01R1	PLACARD ON AFT STAIRWAY	727-52-A124
US	80-08-10R1	MAIN DECK CARGO DOORS	727-52-A124
US	80-22-12R2	LEADING EDGE DEVICES	/2/=31=50R1
US	81-19-07	AIR FLOW MULTIPLIER	727-21A95
US	82-10-03	AIR FLOW MULTIPLIER HYDRAULIC TUBE ASSEMBLIES	727-21-202R1
US	82-22-01	ACTUATOR PISTONS	727-27-209
US	83-01-05R2	UNDETECTED ENGINE STARTER OPERATION	
US	85-16-05	FIRE PREVENTION - LAVATORIES	727-25-277
US	85-19-01	ROSEMOUNT AOA SENSORS CRACKS IN BODY STATION 1183 HLT FIRE EXTINGUISHER DISCHARGE OUTLETS ABEX HYDRAULIC PUMP MOTOR WING REAR SPAR TERMINAL FITTINGS	727-34-A0223
US	85-20-03 86-19-03 87-02-05R1 87-04-15	CRACKS IN BODY STATION 1183	727-53-A0173
US	86-19-03	HLT FIRE EXTINGUISHER DISCHARGE OUTLETS	727-26-A0034
US	87-02-05R1	ABEX HYDRAULIC PUMP MOTOR	727-29-47R2/-55/
US	87-04-15	WING REAR SPAR TERMINAL FITTINGS	727-57-103R3
US	87-06-10		727-32-0341
US	87-08-09 87-22-06 87-24-03	NUTROGENTIME ATTOM A / C TIDES	
US	87-22-06	MAIN LANDING GEAR LEVER ELEVATOR REAR SPAR MAIN LANDING GEAR	727-32-267R1
US	87-24-03	ELEVATOR REAR SPAR	727-55-0087
US	88-01-02 88-17-06 88-20-07	MAIN LANDING GEAR	727-32-251
US	88-17-06	WING UPPER SURFACE STRINGERS	727-57A159R1
US	88-20-07	PIVOT TRUNNION - MAIN LANDING GEAR DOOR ACTUATOR	727-32-0358
US	88-20-07 88-22-09		
US	88-24-01	TAKEOFF WARNING SYSTEM MAIN LANDING GEAR SUPPORT LINK SHAFT MAIN LANDING GEAR DOWNLOCK	727-32-306R1
US	88-24-12	MAIN LANDING GEAR DOWNLOCK	727-32-0237R5
US	89-07-05 89-20-04	AILERON POWER CONTROL UNIT	727-27A0220R1
US	89-20-04	INSPECTION - FUSELAGE SKIN / LAP JOINT	727-53A0200R1
US	09-21-02	ENGINE MOUNT COME BOLT NO!	
US	89-23-17	1 & 3 ENGINES - AFT MOUNT SUPPORT FITTINGS	727-54-0017
US	90-02-08	LANDING GEAR CONTROL SELECTOR VALVE ACTUATOR ARM	727-32-0372R2
US	90-02-16	WING CENTRE SECTION FRONT SPAR TAKEOFF CONFIGURATION WARNING SYSTEM (TOCWS)	727-57-0177
US	90-03-18	TAKEOFF CONFIGURATION WARNING SYSTEM (TOCWS)	727-31-29,33,35,36
US	90-04-08	FUSELAGE SKIN CONFIGURATION	, , , , , , , , , , , , , , , , , , , ,
US	90-06-09	AGING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT	D6-54860 REV C
US	90-07-05	INBOARD TRAILING EDGE FLAP TRACKS	727-57-117R5, -0178R3
US	90-12-11R1	ENSURE PROPER ESCAPE SLIDE RELEASE	727-25A0293
US	90-15-12	PREVENT MIGRATION OF ENGINE MOUNT BOLTS	OSL-727RE-007 R1
US	90-15-12 90-20-02	ENSURE PROPER ESCAPE SLIDE RELEASE PREVENT MIGRATION OF ENGINE MOUNT BOLTS CRACKS IN FRONT SPAR WEB WING CENTER SECTION	727-57-0107R8
US	90-20-14	CRACKS FWD CARGO COMP SIDEWALL FRAMES	727-53-0068R4
US	90-20-18	DELAMINATION UPPPER BODY SKIN TEAR STRAPS	727-53-0082R5
US	90-21-19	MAINE CARGO DOOD LOCKDING	D-COO AET
US	90-24-11	DETECT CRACKS AT BODY STN 1183 PRESS BULKHEAD	727-53A0171
US	90-25-03	CORROSION PREVENTION AND CONTROL	D6-54924 BOEING
US	90-26-09	PREVENT LOSS OF PRESSURIZATION	727-53-0084
US	91-03-09	PREVENT FIRE HAZARD OF LOOSE ITEMS IN RAFT STORE	
US	91-06-06	PREVENT RAPID DECOMPRESSION	727-23-0271 727-53-0072R5
	91-07-11	PREVENT FAILURE OF NO 2 CARGO DOOR	727-534019991
US	91-09-03	PREVENT SEPARATION OF INBD TE FLAP	727-33A0199R1
US	91-09-05	CREW CALL HORN ELECTRICAL CIRCUIT	727-32-340 R1 727-23-0052
US	91-09-06	FUEL CHECK VALVE/PRESSURE ACTIVATED SHUTOFF VALVE	727-294006702
US		FORWARD ENTRY DOOD FRAME	727-52-0452 DC
US	91-15-21	FORWARD ENTRY DOOR FRAME AUXILIARY FUEL TANKS	727-00-0440-04
US	91-22-04		727-28-0110_R1
US	91-22-04	MAIN CARGO DOOR	727-52-0142 REV 2
US		MAIN LANDING GEAR WHEEL WELL PRESSURE FLOOR	727-53A0124
US	92-02-03	BODY SECTION 870 TERMINAL FITTING MAIN DECK CARGO DOOR LATCH LOCKPINS	121-53-0194
US	92-06-14	FAILURE OF PODY STATION OF STATION	707 50 0105 55
US	92-12-03		727-53-0126 R6
US	92-12-08	FUSELAGE AFT LOWER LOBE FRAMES	727-53A0195R1
	JZ 12 00	BRAKES - MAXIMUM WEAR LIMITS	
	DATT /AFRONIETO		

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

		BULLETIN DE SERVICE DE REF
BOEING		
727 SERIES		
(CONTINUED / SUITE)		
US 92-19-10	CORROSION AFT CARGO COMP BELLY PANELS MLG WHEEL WELL PRESSURE FLOOR BENDIX BRAKES - NASCO ROTORS	727-53-0085 REV 4
US 92-19-11 US 93-02-08	MLG WHEEL WELL PRESSURE FLOOR	727-53-0149R2 OR R3
	BENDIX BRAKES - NASCO ROTORS	STC SA3948NM
US 93-05-17 US 93-07-15	"E-F" WINDOW POST CLASS B CARGO COMPARTMENT	727-53-0086 R11
US 94-02-04		
US 94-04-03	SLAT TRACK ROLLER BEARING BOLTS	727-53-0197 R1
US 94-05-04	AGING AIRCRAFT	727-57-0172 R3
US 94-07-08	AGING AIRCRAFT	D6-54860 REV G
US 94-23-10	LAVATORY DRAIN SYSTEM	737-38-0021 R1
US 95-19-08	ATTACHMENT BOLTS ON ENGINE NOSE COWLING	
US 96-06-05 US 97-02-09	ELEVATOR REAR SPAR	727-55-0089
US 97-02-09 US 97-03-04	MLG ACTOATOR RIB FITTING	727-32-0383
US 97-05-08	FUEL CAP ASSEMBLY	727-28A0062 R2
US 97-25-15	FWD SUPPORT 1 & 3 ENG FLANGES & VERT WEB - INSP WING REAR SPAR WEB	727-54A0010R4
US 98-04-29	MANUAL EXTENSION GEARROX ASSEMBLIES	727-22-270
US 98-11-03R1	DTR FOR EACH SSI IN BOEING D6-48040-1	SSID D6-48040-1
US 98-18-20	FUEL SYSTEM CROSSFEED AND ENGINE SHUTOFF VALVES	3310 00 48040 1
US 98-23-51	FUSELAGE SKIN LAP JOINTS	727-53-0072
US 98-26-18	CARGO FLOOR LUADING	
US 98-26-19	CARGO FLOOR LOADING	
US 98-26-20	CARGO FLOOR LOADING	
US 98-26-21	CARGO FLOOR LOADING	
US 99-04-22 US 99-12-52	LOWER ROW OF FASTENERS LOWER LAP JOINTS	
US 99-12-52 US 99-18-05	IN-TANK-FUEL BOOST PUMP WIRING CRACKING OF THE VERTICAL BEAM OF AFT PRESS. BLKHD. NLG WHEEL WELL - PRESSURE WEB	707 50 0040 8 005500
US 99-20-10	NIG WHEEL WELL - DESCRIPT WER	727-53-0210 & 0055R9
US 99-24-06	FUEL BOOSTER PUMP	727-28A0125 R1
33 21 00	TOLE BOOSTER TOM	727 28A0125 K)
727 22	( 727 SERIES )	
707 000	/ day order	
727 22C	( 727 SERIES )	
727 25	( 727 SERIES )	
727 25C	( 727 SERIES )	
727 27C	( 727 SERIES )	
US 83-02-09	MAIN CARGO DOORSKIN INSPECTION	727-52-79R4
US 89-16-03	MAIN CARGO DOORSKIN INSPECTION MAIN CARGO DOOR LATCH SUPPORT FITTINGS	727-53A0177R1
727 44C	( 727 SERIES )  MAIN CARGO DOORSKIN INSPECTION	727-52-79R4
US 83-02-09 US 89-16-03	MAIN CARGO DOOR LATCH SUPPORT FITTINGS	727-53A0177R1
US 89-16-03	MATIN CANGO DOOK EATOH SOFFORT TITLINGS	
727 51C	( 727 SERIES )	
US 83-02-09	MAIN CARGO DOORSKIN INSPECTION	727-52-79R4
US 89-16-03	MAIN CARGO DOOR LATCH SUPPORT FITTINGS	727-53A0177R1
727 82	( 727 SERIES )	
727 90C	( 727 SERIES )	727-52-79R4
US 83-02-09	MAIN CARGO DOORSKIN INSPECTION MAIN CARGO DOOR LATCH SUPPORT FITTINGS	727-52-79R4 727-53A0177R1
US 89-16-03	MAIN CARGO DOOK LATCH SUPPORT FITTINGS	727 30A0177K1
727 92C	( 727 SERIES )	
	• • • • • • • • • • • • • • • • • • • •	
727 100 SERIES		
CF CF-96-04	CORROSION PREVENTION & CONTROL PROGRAMS	00. 7
US 64-03-01	FUEL TANK ACCESS DOORS	28-7
US 64-06-03	FLIGHT SPOILER ACTUATOR ROD	27-18 78-10R1
US 64-12-02	THRUST REVERSERS CABIN COVE LIGHTS	75 10101
US 64-22-02	DEACTIVATION OF THE AUTOPILOT	22-7
US 64-26-01	HORIZONTAL STABILIZER DRAIN HOLES	55-14A
US 65-03-02 US 65-17-01	THRUST REVERSER ACTUATOR PISTON	78-18
US 66-08-02	FLAP DRIVE COUPLING SLEEVE	
US 66-22-02	PNEUMATIC BRAKE SYSTEM	29-22
US 66-23-01	. FUEL LINE B NUTS	28-25
US 66-24-01	TRIM SYSTEM BRAKE	74 07
US 66-29-01	ENGINE COWL PANEL LATCH	71-27

MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE) ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

SUJET

BOEING 727 100 SERIES (CONTINUED / SUITE) FUEL AND ELECTRICAL LINES 66-30-02 28-26 67-02-01 TRAILING EDGE BEAM 55-15 115 67-07-01 SPERRY SP-50 AUTOPILOT TA-697-104 SPERRY 67-14-02 LANDING GEAR SIDE STRUT MAIN GEAR DOWNLOCK ROD 32-79R1 67-22-03 32-123R1 115 68-08-02 AFT TRUNNION EXTENSION 32-153 US 68-10-02 HEATER BLANKETS 2 GENERAL ELECTRIC US 68-10-05 DEFLECTOR DOORS 78-51R1 68-14-02 GEAR DOWNLOCK ACTUATING SYSTEM 32-160 68-15-01 CRACKS IN HORIZONTAL STABILIZER 55-1886 68-15-04 DAMAGE TO WIRE BUNDLES 24-27 US 69-03-02 RUDDER PEDAL DISPLACEMENT
OPERATION OF BATTERY SWITCH 25-36R1 69-04-01 24-44 69-12-02 TAKEOFF WARNING SYSTEM 27-102R1 69-15-05 ENGINE FIRE EXTINGUISHER 26-04 APCD 69-16-01 GENERATOR LOSS 69-20-06 CIRCUIT OVERLOADS 24-48 69-25-01 GENERATOR CONTROL CIRCUIT 24-47 US 69-25-02 GENERATOR SYSTEM LOCKOUT 66-103 WESTINGHOUSE 69-25-03 ENGINE CONE BOLT US 71-43 US 70-26-03 MAIN GEAR TRUNNION SUPPORT BEAM 57-115 71-09-04 MAIN GEAR ACTUATOR BEAM 32-188 71-26-01 MAIN LANDING GEAR ACTUATOR BEAM 32-196R1 72-12-01 MAIN GEAR DOWNLOCK SHAFT
MAIN GEAR TRUNNION SUPPORT BEAM 32-180R1 72-25-03 57-122 LEADING EDGE SLAT ACTUATORS 73-06-01 27-129 US 73-09-04 ENTRY DOOR HINGE 727-52-83R1 73-26-06 CORROSION OF TORSION SHAFTS 727-32-203 74-09-05 EMERGENCY EXITS 727-25-214 US 74-10-08 HORIZONTAL STABILIZER PINS 727-55-59 74-18-09 LANDING GEAR ACTUATORS 727-32-218 74-21-03 FIRE HAZARD 727-25-211 727-36-17R2/18R1/22 74-23-03 AIR CONDITIONING PACKS US 75-05-01 CONTROL CABLE PULLEYS 727-27-155R1 US SLIDE LATCH CABLE 75-05-10 727-25-223 75-09-04R1 US CENTER SECTION FITTING 727-55-0062 R4 75-20-09 WING VIBRATIONS 727-57-137 US 76-07-05 NOSE LANDING GEAR 727-32-203R3/205/223 US 76-13-01 BODY CORROSION OR CRACKING 727-53-128R2 US 76-15-06 ELEVATOR BALANCE PANEL HINGES 727-55-A65 US 76-17-07 STATIC PORT SYSTEM 727-34-94/57/25-42R1 US 76-18-11 AFT CARGO DOOR 727-52-A102R2 US 77-02-02 STATIC PORT FITTINGS 727-34-94/57/25-42R1 77-03-02R2 FUEL FEED HOSE ASSEMBLIES US 727-28-51 727-53-134R3 77-13-15 US FLOOR BEAM CRACKING 77-18-06 HORIZONTAL STABILIZER 727-55-A69 AUTOMATIC THROTTLES US 78-01-08 727-31-30 US 78-11-07 727-55-A73 HORIZONTAL STABILIZERS 78-24-05R1 GALLEY DOOR & EMERGENCY GIRT BAR US 727-25-A247 US 78-26-07 THRUST REVERSER ASSEMBLY 727-78-A86 US 79-04-01R3 MAIN LANDING GEAR-UP LANDINGS 727-32-211R4/.. 79-09-01 ELEC LEADS / HYD LINES CHAFING CRACK OR MISSING PIECES IN SLIDERS US 24-30 79-10-05 727-57-A147 US 79-11-02 AUTO SPEEDBRAKE SYSTEM 727-31-A44R1 US 79-20-06 SIDE STRUT ASSEMBLIES "CARRY-ALL" INTERIOR 727-32-268R1 US 79-23-02 727-35-A18/A1014 727-28A0062R5 115 80-02-01R2 AUXILIARY BODY FUEL TANK INSTALLATION US 80-07-02 FLIGHT CONTROL SYSTEMS
PLACARD ON AFT STAIRWAY US 80-08-01R1 US 80-08-10R1 MAIN DECK CARGO DOORS 727-52-A124 LEADING EDGE DEVICES 80-22-12R2 727-31-50R1 81-02-09 AIRSTAIR EMERGENCY SYSTEM 727-52-120 US 81-19-07 AIR FLOW MULTIPLIER 727-21A95 US 82-10-03 HYDRAULIC TUBE ASSEMBLIES
ACTUATOR PISTONS 727-21-202R1 82-22-01 727-27-209 83-01-05R2 US UNDETECTED ENGINE STARTER OPERATION 84-08-05R1 PITOT-STATIC SYSTEMS 85-16-05 US FIRE PREVENTION - LAVATORIES 727-25-277 US 85-19-01 ROSEMOUNT ADA SENSORS 727-34-A0223 US 85-20-03 CRACKS IN BODY STATION 1183 727-53-A0173 US 86-19-03 HLT FIRE EXTINGUISHER DISCHARGE OUTLETS 727-26-A0034 US 87-02-05R1 ABEX HYDRAULIC PUMP MOTOR 727-29-47R2/-55/..

REFERENCE SERVICE BUILLETIN

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

SUBJECT

STC - FLOOR PROXIMITY LIGHTING SYSTEM	57-103R3
727 100 SERIES	
(CONTINUED / SUITE)	
US 87-04-15 WING REAR SPAR TERMINAL FITTINGS 727- US 87-05-51 STC - FLOOR PROXIMITY LIGHTING SYSTEM	
US 87-05-51 STC - FLOOR PROXIMITY LIGHTING SYSTEM	
LIC 97 OC 40	
US 87-06-10 MAIN LANDING GEAR BEARINGS 727-	
US 87-08-09 NITROGEN INFLATION A / C TIRES  US 87-22-06 MAIN LANDING GEAR LEVER 727- US 87-24-03 ELEVATOR REAR SPAR 727- US 88-01-02 MAIN LANDING GEAR	32-0341
US 87-22-06 MAIN LANDING GEAR LEVER 727-	32-267P1
US 87-24-03 ELEVATOR REAR SPAR 727-	55-0087
US 87-22-06 MAIN LANDING GEAR LEVER 727- US 87-24-03 ELEVATOR REAR SPAR 727- US 88-01-02 MAIN LANDING GEAR 727- US 88-17-06 WING UPPER SURFACE STRINGERS 727-	32-251
US 88-17-06 WING UPPER SURFACE STRINGERS 727- US 88-20-07 PIVOT TRUNNION - MAIN LANDING GEAR DOOR ACTUATOR 727- US 88-22-09 TAKEOFF WARNING SYSTEM US 88-24-01 MAIN LANDING GEAR SUPPORT LINK SHAFT 727- US 88-24-12 MAIN LANDING GEAR DOWNLOCK 727- US 89-07-05 AILERON POWER CONTROL UNIT 727- US 89-20-04 INSPECTION - FUSELAGE SKIN / LAP JOINT 727- US 89-21-02 ENGINE MOUNT CONE BOLT NUT US 89-23-17 1 & 3 ENGINES - AFT MOUNT SUPPORT FITTINGS 727- US 90-02-08 LANDING GEAR CONTROL SELECTOR VALVE ACTUATOR ARM 727- US 90-02-16 WING CENTER SECTION SELECTOR VALVE ACTUATOR ARM 727-	57A159R1
US 88-20-07 PIVOT TRUNNION - MAIN LANDING GEAR DOOR ACTUATOR 727-	32-0358
US 88-22-09 TAKEOFF WARNING SYSTEM US 88-24-01 MAIN LANDING GEAR SUPPORT LINE SHAET	
US 88-24-01 MAIN LANDING GEAR SUPPORT LINK SHAFT 727-	32-306R1
US 89-07-05 ATTERDN POWER CONTROL UNIT 727-	32-0237R5
US 89-20-05 ALLERUN PUWER CONTROL UNIT 727-	27A0220R1
US 89-21-02 FNGINE MOLINT CONF BOLT NUT	53A0200R1
US 89-23-17 1 & 3 FNGINES - AFT MOUNT SUPPORT FITTINGS 737-	
US 90-02-08 LANDING GEAR CONTROL SELECTOR WALVE ACTUATOR ADM. 727-	54-0017 R2
US 90-02-16 WING CENTRE SECTION FRONT SDAP	32-0372R2
US 90-03-18 TAKFOFF CONFIGURATION WARNING SYSTEM (TOCKS) 727-	57-0177
US 88-24-12 MAIN LANDING GEAR DOWNLOCK 727- US 89-07-05 AILERON POWER CONTROL UNIT 727- US 89-20-04 INSPECTION - FUSELAGE SKIN / LAP JOINT 727- US 89-21-02 ENGINE MOUNT CONE BOLT NUT US 89-23-17 1 & 3 ENGINES - AFT MOUNT SUPPORT FITTINGS 727- US 90-02-08 LANDING GEAR CONTROL SELECTOR VALVE ACTUATOR ARM 727- US 90-02-16 WING CENTRE SECTION FRONT SPAR 727- US 90-03-18 TAKEOFF CONFIGURATION WARNING SYSTEM (TOCWS) 727- US 90-04-08 FUSELAGE SKIN CONFIGURATION	31-29,33,35,36
US 90-02-08 LANDING GEAR CONTROL SELECTOR VALVE ACTUATOR ARM 727-US 90-02-16 WING CENTRE SECTION FRONT SPAR 727-US 90-03-18 TAKEOFF CONFIGURATION WARNING SYSTEM (TOCWS) 727-US 90-04-08 FUSELAGE SKIN CONFIGURATION US 90-06-09 AGING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT D6-5.	4860 REV C
US 90-07-05 INBOARD TRAILING FORF FLAP TRACKS	4860 REV C 57-117R5,-0178R3
US 90-12-11R1 ENSURE PROPER ESCAPE SLIDE RELEASE 727-	2540202
US 90-06-09 AGING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT D6-5. US 90-07-05 INBOARD TRAILING EDGE FLAP TRACKS 727-! US 90-12-11R1 ENSURE PROPER ESCAPE SLIDE RELEASE 727-! US 90-15-12 PREVENT MIGRATION OF ENGINE MOUNT BOLTS OSL- US 90-20-02 CRACKS IN FRONT SPAR WEB WING CENTER SECTION 727-!	727RF-007 P1
US 90-20-02 CRACKS IN FRONT SPAR WEB WING CENTER SECTION 727-	57-0107R8
US 90-12-11R1 ENSURE PROPER ESCAPE SLIDE RELEASE 727- US 90-15-12 PREVENT MIGRATION OF ENGINE MOUNT BOLTS OSL- US 90-20-02 CRACKS IN FRONT SPAR WEB WING CENTER SECTION 727- US 90-20-14 CRACKS FWD CARGO COMP SIDEWALL FRAMES 727- US 90-20-18 DELAMINATION UPPPER BODY SKIN TEAR STRAPS 727- US 90-21-10 CRACKING / CORRISON FUSELAGE CROWN SKIN 727- US 90-21-19 MAIN CARGO DOOR LOCKTINS 90-21-19	53-0068R4
US 90-20-18 DELAMINATION UPPPER BODY SKIN TEAR STRAPS 727-	53-0082R5
US 90-21-10 CRACKING / CORRISON FUSELAGE CROWN SKIN 727-	53-0109 R4
US 90-21-19 MAIN CARGO DOOR LOCKPINS R-690	
US 90-24-11 DETECT CRACKS AT BODY STN 1183 PRESS BULKHEAD 727-9	53A0171
US 90-25-03 CORROSION PREVENTION AND CONTROL D6-54	4924 BOEING
US 90-26-09 PREVENT LOSS OF PRESSURIZATION 727-	53-0084
	25-0271
US 91-06-06 PREVENT RAPID DECOMPRESSION 727-5	53-0072R5
US 91-07-11 PREVENTED FAITURE DE NO 2 CARGO DOOR 727-9	53A0199R1
US 91-09-03 PREVENT SEPARATION OF INBD TE FLAP 727-	32-340 R1
US 91-09-05 CREW CALL HORN ELECTRICAL CIRCUIT 727-7	23-0052
US 91-09-06 FUEL CHECK VALVE/PRESSURE ACTIVATED SHUTOFF VALVE 727-2 US 91-09-07 FORWARD ENTRY DOOR FRAME 727-5	28AUU67R2
US         91-09-07         FORWARD ENTRY DOOR FRAME         727-5           US         91-15-21         AUXILIARY FUEL TANKS         727-2	53-0153 R6
US 91-15-21 AUXILIARY FUEL TANKS 727- US 91-22-04 MAIN CARGO DOOR 727-	
IIS 01-22-09 MAIN LANDING GEAD WHEEL WELL BRESSURE SLOOP 727-8	5340124
	53-0194
US 92-02-03 MAIN DECK CARGO DOOR LATCH LOCKPINS	
US 92-02-03 MAIN DECK CARGO DOOR LATCH LOCKPINS US 92-06-14 FAILURE OF BODY STATION 950 SIDE FITTING 727-E US 92-12-03 FUSELAGE AFT LOWER LOBE FRAMES 727-E	53-0126 R6
US 92-12-03 FUSELAGE AFT LOWER LOBE FRAMES 727-5	53A0195R1
US 92-12-08 BRAKES - MAXIMUM WEAR LIMITS	
US 92-19-10 CORROSION AFT CARGO COMP BELLY PANELS 727-5	53-0085 REV 4
03 32 13-11 MILL WILL WILL FRESSORE 1 LOOK	53-0149R2 OR R3
US 93-02-08 BENDIX BRAKES - NASCO ROTORS STC S	5A3948NM
	53-0086 REV 11
US 93-07-15 CLASS B CARGO COMPARTMENT	
US 94-02-04 EDDY CORRENT INSPECTION OF FRAME FLANGE AND WEB 727-5	53-0197 R1
US 94-04-03 SLAT TRACK ROLLER BEARING BOLTS 727-5	57-0172 R3
US 94-05-04 AGING AIRCRAFT	4000 DEV 5
US 94-07-08 AGING AIRCRAFT D6-54 US 94-23-10 LAVATORY DRAIN SYSTEM 737-2	4860 REV G
US 94-23-10 EAVATORY BRAIN STSTEM	38-0021 R1
US 95-15-06 FUEL CRUSS FEED VALVE ACTUATOR 61163	3-28-08
US 95-19-08 ATTACHMENT BOLTS ON ENGINE NOSE COWLING	
US 96-02-06 WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	55-0089
	33 0009
US 96-16-08 MAIN DECK CARGO DOOR	32-0383
05 57 02 05	28AOO62 R2
	LUAUUUZ NZ
US 97-23-02 ROLLS ROYCE TAY 651-54 US 97-25-15 WING REAR SPAR WEB 727-5	57AO182
MANUAL EXTENSION GEARBOX ASSEMBLIES 727-3	32-279
7777	D6-48040-1
	53-0072
US 98-26-18 CARGO FLOOR LOADING	
US 98-26-19 CARGO FLOOR LOADING	
55 55 25 75	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

ORIGIN	E NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
BOEING			
(CONTI	100 SERIES INUED / SUITE)		
US	98-26-20	CARGO FLOOR LOADING	
US	98-26-21	CARGO FLOOR LOADING	
US	99-04-22	LOWER ROW OF FASTENERS LOWER LAP JOINTS	
US	99-12-52	IN-TANK-FUEL BOOST PUMP WIRING	
US	99-18-05	CRACKING OF THE VERTICAL BEAM OF AFT PRESS. BLKHD.	727-53-0210 & 005589
US	99-20-10	NLG WHEEL WELL - PRESSURE WEB	727-53-0145 R1
US	99-21-10	LOWER FUSELAGE SKIN PANELS	727-53-0083 R4
US	99-24-06	FUEL BOOSTER PUMP	727-28A0125 R1
~~~			
727 1	1160	( 727 100 SERIES )	
727 1	171C	( 727 100 SERIES )	
		( ) ZET TOO SERIES /	
	172C	( 727 100 SERIES )	
US		MAIN CARGO DODRSKIN INSPECTION	727-52-79R4
US	89-16-03	MAIN CARGO DOOR LATCH SUPPORT FITTINGS	727-53AO177R1
707 0	NOO CEDIEC		
CF CF	200 SERIES	CODDOCTON DESCRIPTION A CONTROL DESCRIPTION	
	CF-96-04 64-03-01	CORROSION PREVENTION & CONTROL PROGRAMS	00 7
US	64-06-03	FUEL TANK ACCESS DOORS	28-7
US	64-12-02	FLIGHT SPOILER ACTUATOR ROD THRUST REVERSERS	27-18 78-10R1
US	64-22-02	CABIN COVE LIGHTS	78-10R1
US	64-26-01		22-7
US	65-03-02	DEACTIVATION OF THE AUTOPILOT HORIZONTAL STABILIZER DRAIN HOLES	55-14A
US	65-17-01	THRUST REVERSER ACTUATOR PISTON	78-18
US	66-08-02	FLAP DRIVE COUPLING SLEEVE	, 5 . 5
US	66-22-02	PNEUMATIC BRAKE SYSTEM	29-22
US	66-23-01	FOEL EINE B NOTS	28-25
US	66-24-01	TRIM SYSTEM BRAKE	
US	66-29-01	ENGINE COWL PANEL LATCH	71-27
US US	66-30-02	FUEL AND ELECTRICAL LINES	28-26
US	67-02-01 67-07-01	TRAILING EDGE BEAM	55-15
US	67-14-02		TA-697-104 SPERRY
US	67-22-03	LANDING GEAR SIDE STRUT MAIN GEAR DOWNLOCK ROD	32-79R1
US	68-08-02	MAIN GEAR DOWNLOCK ROD AFT TRUNNION EXTENSION	32-123R1 32-153
US	68-10-02	HEATER BLANKETS	2 GENERAL ELECTRIC
US	68-10-05	DEEL FORCE AND A	78-51R1
US	68-14-02	GEAR DOWNLOCK ACTUATING SYSTEM	32-160
US	68-15-01	CRACKS IN HORIZONTAL STABILIZER	55-18R6
US	68-15-04	DAMAGE TO WIRE BUNDLES	24-27
US	69-03-02	RUDDER PEDAL DISPLACEMENT	25-36R1
US	69-04-01	OPERATION OF BATTERY SWITCH	24-44
US US	69-12-02 69-15-05	TAREUFF WARNING SYSTEM	27-102R1
US	69-16-01	ENGINE FIRE EXTINGUISHER	26-04 APCO
US	69-20-06	GENERATOR LOSS CIRCUIT OVERLOADS	24 49
US	69-25-01	CIRCUIT OVERLOADS GENERATOR CONTROL CIRCUIT	24-48
US	69-25-02	OCCUPATION ON CONTRACT OF THE	24-47
US	69-25-03	FNGINE CONE BOLT	66-103 WESTINGHOUSE 71-43
US	70-26-03	MAIN GEAR TRUNNION SUPPORT BEAM	57-115
US	71-09-04	MAIN GEAR ACTUATOR BEAM	32-188
US	71-26-01		32-196R1
US	72-12-01	MAIN GEAR DOWNLOCK SHAFT	32-180R1
US	72-25-03	MAIN GEAR TRUNNION SUPPORT BEAM	57-122
US	73-06-01	LEADING EDGE SLAT ACTUATORS	27-129
US	73-09-04	ENTRY DOOR HINGE	727-52-83R1
US	73-26-06	CORROSION OF TORSION SHAFTS	727-32-203
US US	74-09-05	EMERGENCY EXITS	727-25-214
US	74-10-08 74-18-09	HORIZONTAL STABILIZER PINS	727-55-59
US	74-18-09		727-32-218
US	74-23-03	FIRE HAZARD AIR CONDITIONING PACKS	727-25-211
	74-24-06	NOSE LANDING GEAR	727-36-21
US.		amiliano and a sur	727-32-222 727-27-155R1
US US	75-05-01		121-21-195K1
	75-05-10	SLIDE LATCH CABLE	727-25-222
US US US			727-25-223 727-55-0062 R4
US US US	75-05-10 75-09-04R1 75-20-09	CENTER SECTION FITTING	727-55-0062 R4
US US US US	75-05-10 75-09-04R1 75-20-09 <b>76-</b> 07-05	CENTER SECTION FITTING WING VIBRATIONS NOSE LANDING GEAR	727-55-0062 R4 727-57-137
US US US	75-05-10 75-09-04R1 75-20-09	CENTER SECTION FITTING WING VIBRATIONS NOSE LANDING GEAR	727-55-0062 R4

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

			BULLETIN DE SERVICE DE REF.
BOEING			
727 2	OO SERIES		
(CONTI	NUED / SUITE)		
US	77-02-02	STATIC PORT FITTINGS FUEL FEED HOSE ASSEMBLIES FLOOR BEAM CRACKING	<u></u>
US	77-03-02R2	FUEL FEED HOSE ASSEMBLIES	727-34-94/57/25-42R1
US	77-13-15	FLOOR BEAM CRACKING HORIZONTAL STABILIZER AUTOMATIC THROTTLES HORIZONTAL STABILIZERS GALLEY DOOR & EMERGENCY GIRT BAR THRUST REVERSER ASSEMBLY MAIN LANDING GEAR-UP LANDINGS	727-28-51 727-53-134R3
US	77-18-06	HORIZONTAL STABILIZER	727-55-134R3
US	78-01-08 78-11-07	AUTOMATIC THROTTLES	727-31-30
US	78-11-07	HORIZONTAL STABILIZERS	727-55-473
US	78-24-05R1	GALLEY DOOR & EMERGENCY GIRT BAR	727-25-4247
US	78-26-07	GALLEY DOOR & EMERGENCY GIRT BAR THRUST REVERSER ASSEMBLY	727-78-A86
US	79-04-01R3	MAIN LANDING GEAR-UP LANDINGS	727-32-211R4/
US	79-10-05	CRACK OR MISSING PIECES IN SLIDERS	727-57-A147
US US	79-11-02	THRUST REVERSER ASSEMBLY  MAIN LANDING GEAR-UP LANDINGS  CRACK OR MISSING PIECES IN SLIDERS  AUTO SPEEDBRAKE SYSTEM  SIDE STRUT ASSEMBLIES  "CARRY-ALL" INTERIOR  AUXILIARY BODY FUEL TANK INSTALLATION FLIGHT CONTROL SYSTEMS	727-31-A44R1
US	79-23-02 80-02-01R2 80-07-02 80-08-01R1	SIDE STRUI ASSEMBLIES	727-32-268R1
US	90-03-0103	"CARRY-ALL" INTERIOR	727-35-A18/A1014
US	80-07-02	AUXILIARY BUDY FUEL TANK INSTALLATION	727-280062R5
US	80-08-01R1	DI ACADO CALACT CTATOLIAN	
US	80-08-10R1	MAIN DECK CARGO DOORS	727-52-A124
US	80-14-04	WIRE BUNDLES IN AIR COND	727-52-A124
US	80-22-12R2	LEADING EDGE DEVICES	727-21-88R2
us	81-19-07	WIRE BUNDLES IN AIR COND LEADING EDGE DEVICES AIR FLOW MULTIPLIER	727-21195
US	81-20-04R1	MAIN DECK CARGO DOORS WIRE BUNDLES IN AIR COND LEADING EDGE DEVICES AIR FLOW MULTIPLIER H S PRESSURIZATION CONTROLLERS HYDRAULIC TUBE ASSEMBLIES	727-21496
US	81-20-04R1 82-10-03 82-22-01 83-01-05R2	HYDRAULIC TUBE ASSEMBLIES	727-21A96 727-21-202R1
US	82-22-01	ACTUATOR PISTONS  UNDETECTED ENGINE STARTER OPERATION  ELEVATOR REAR SPAR INSPECTION	727-27-209
US	83-01-05R2	UNDETECTED ENGINE STARTER OPERATION	121 21 203
US	84-22-02 85-16-05 85-19-01 85-20-03	UNDETECTED ENGINE STARTER OPERATION ELEVATOR REAR SPAR INSPECTION FIRE PREVENTION - LAVATORIES ROSEMOUNT AGA SENSORS CRACKS IN BODY STATION 1183 RAMAIR PLENUM CHAMBER INSP	727-55-0085
US	85-16-05	FIRE PREVENTION - LAVATORIES	727-25-277
US	85-19-01	ROSEMOUNT AOA SENSORS	727-34-A0223
US	85-20-03	CRACKS IN BODY STATION 1183	727-53-A0173
US	85-24-02	RAMAIR PLENUM CHAMBER INSP FRAME - CARGO DOOR CUTOUT	727-51-17
US	86-17-05R1	RAMAIR PLENOM CHAMBER INSP FRAME - CARGO DOOR CUTOUT HLT FIRE EXTINGUISHER DISCHARGE OUTLETS ABEX HYDRAULIC PUMP MOTOR WING REAR SPAR TERMINAL FITTINGS STC - FLOOR PROXIMITY LIGHTING SYSTEM MAIN LANDING GEAR BEARINGS	727-53-A0169R2
US	86-19-03	HLT FIRE EXTINGUISHER DISCHARGE OUTLETS	727-26-A0034
US	87-02-05R1	ABEX HYDRAULIC PUMP MOTOR	727-29-47R2/-55/
US	87-04-15	WING REAR SPAR TERMINAL FITTINGS	727-57-103R3
US	87-05-51	STC - FLOOR PROXIMITY LIGHTING SYSTEM	
US	87-06-10	WING REAR SPAR TERMINAL FITTINGS STC - FLOOR PROXIMITY LIGHTING SYSTEM MAIN LANDING GEAR BEARINGS NITROGEN INFLATION A / C TIRES MAIN LANDING GEAR LEVER	727-32-0341
US	87-08-09	NITROGEN INFLATION A / C TIRES	707 00 00704
US US	87-22-06	MAIN LANDING GEAR LEVER	727-55-0087
US	87-24-03	ELEVATOR REAR SPAR MAIN LANDING GEAR	727-33-0087
US	87-22-06 87-24-03 88-01-02 88-17-06	WING UPPER SURFACE STRINGERS	727-57A159R1
US	88-20-07	PIVOT TRUNNION - MAIN LANDING GEAR DOOR ACTUATOR	727-32-0358
US	88-22-09	TAKEDEE WARNING SYSTEM	
		MAIN LANDING GEAR SUPPORT LINK SHAFT	727-32-306R1
US	88-24-01 88-24-12	MAIN LANDING GEAR SUPPORT LINK SHAFT MAIN LANDING GEAR DOWNLOCK	727-32-0237R5
ÜS	89-07-05	AILERON POWER CONTROL UNIT	727-27A0220R1
US	89-07-05 89-20-04	INSPECTION - FUSELAGE SKIN / LAP JOINT	727-53A0200R1
US	89-21-02	ENGINE MOUNT CONE BOLT NUT	
US	89-23-17	1 & 3 ENGINES - AFT MOUNT SUPPORT FITTINGS	727-54-0017 R2
US	90-02-08	LANDING GEAR CONTROL SELECTOR VALVE ACTUATOR ARM	727-32-0372R2
US	90-02-08 90-02-16 90-03-18 90-04-08	WING CENTRE SECTION FRONT SPAR	727-57-0177
US	90-03-18	TAKEOFF CONFIGURATION WARNING SYSTEM (TOCWS)	727-31-29,33,35,36
US	90-04-08	FUSELAGE SKIN CONFIGURATION	DC 54860 D5V 6
US	90-06-09 90-07-05 90-12-11R1 90-15-12	AGING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT	D6-54860 REV C
US	90-07-05	INBOARD TRAILING EDGE FLAP TRACKS	727-57-117R5,-0178R3
US	90-12-11R1	ENSURE PROPER ESCAPE SLIDE RELEASE	727-25A0293
US	90-15-12	PREVENT MIGRATION OF ENGINE MOUNT BOLTS CRACKS IN FRONT SPAR WEB WING CENTER SECTION	OSL-727RE-007 R1 727-57-0107R8
US	90-20-02	CRACKS IN PROMI STAR WED WING CENTER SECTION	727-53-0068R4
US	90-20-14	CRACKS FWD CARGO COMP SIDEWALL FRAMES	
US	90-20-18	DELAMINATION UPPPER BODY SKIN TEAR STRAPS	727-53-0082R5 727-53A0171
US	90-24-11	DETECT CRACKS AT BODY STN 1183 PRESS BULKHEAD CORROSION PREVENTION AND CONTROL	D6-54924 BDEING
US	90-25-03	PREVENT LOSS OF PRESSURIZATION	727-53-0084
US	90-26-09	PREVENT FIRE HAZARD OF LOOSE ITEMS IN RAFT STORE	727-25-0271
US	91-03-09	PREVENT RAPID DEPRESSURIZATION DUE TO CRACKS	727-53A0204 R3
US	91-03-19R1	PREVENT RAPID DECOMPRESSION	727-53-0072R5
US	91-06-06	PREVENT FAILURE OF NO 2 CARGO DOOR	727-53A0199R1
US	91-07-11	PREVENT SEPARATION OF INBD TE FLAP	727-32-340 R1
US US	91-09-03 91-09 <b>-</b> 05	CREW CALL HORN ELECTRICAL CIRCUIT	727-23-0052
US	91-09-05	FUEL CHECK VALVE/PRESSURE ACTIVATED SHUTOFF VALVE	727-28A0067R2
US	91-09-06	FORWARD ENTRY DOOR FRAME	727-53-0153 R6
US	91-09-07	PREVENT RAPID DECOMPRESSION	727-53A0203
US	91-15-21	AUXILIARY FUEL TANKS	727-28-0110_R1
03	01 10 21		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUJECT
SUJECT

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
BOEING				
	OO SERIES			
	NUED / SUITE)		MATHER CARGO COOR	
US US	91-22-04 91-22-08		MAIN CARGO DOOR	727-52-0142 REV 2 727-53A0124
US	91-24-11R1		MAIN LANDING GEAR WHEEL WELL PRESSURE FLOOR BODY SECTION 870 TERMINAL FITTING	727-53-0124
US	92-06-14		FAILURE OF BODY STATION 950 SIDE FITTING	
US	92-12-03		FUSELAGE AFT LOWER LOBE FRAMES	727-53A0195R1
US	92-12-08		BRAKES - MAXIMUM WEAR LIMITS	, , , , , , , , , , , , , , , , , , , ,
US	92-19-10		CORROSION AFT CARGO COMP BELLY PANELS	727-53-0085 REV 4
US	92-19-11		MLG WHEEL WELL PRESSURE FLOOR	727-53-0149R2 OR R3
US	93-02-08		BENDIX BRAKES - NASCO ROTORS	STC SA3948NM
US	93-05-17		"E-F" WINDOW POST	727-53-0086 REV 11
US	93-07-15		CLASS B CARGO COMPARTMENT	
US	94-02-04		EDDY CURRENT INSPECTION OF FRAME FLANGE AND WEB	727-53-0197 R1
US	94-04-03		SLAT TRACK ROLLER BEARING BOLTS	727-57-0172 R3
US	94-05-04		AGING AIRCRAFT	
US	94-07-08		AGING AIRCRAFT	D6-54860 REV G
US	94-23-10		LAVATORY DRAIN SYSTEM	737-38-0021 R1
US	95-15-06		FUEL CROSS FEED VALVE ACTUATOR	61163-28-08
US	95-19-08		ATTACHMENT BOLTS ON ENGINE NOSE COWLING	
US	96-02-06		WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	
US	96-06-05		ELEVATOR REAR SPAR	727-55-0089
US	96-16-08		MAIN DECK CARGO DOOR	
US US	96-25-15		EXPANDABLE WINDSHEAR	505 00 005
US	97-02-09		MLG ACTOATOR RIB FITTING	727-32-0383
US	97-03-04 9 <b>7-2</b> 5-15		FUEL CAP ASSEMBLY WING REAR SPAR WEB	727-28A0062R2
US	98-04-29			727-57A0182
US	98-11-03R1		MANUAL EXTENSION GEARBOX ASSEMBLIES DTR FOR EACH SSI IN BOEING D6-48040-1	727-32-279
US	98-18-20		FUEL SYSTEM CROSSFEED AND ENGINE SHUTOFF VALVES	D6-48040-1
US	98-23-51		FUSELAGE SKIN LAP JOINTS	727-53-0072
us	98-26-18		CARGO FLOOR LOADING	121-53-0012
US	98-26-19		CARGO FLOOR LOADING	
	98-26-20		CARGO FLOOR LOADING	
US	98-26-21		CARGO FLOOR LOADING	
US	99-04-22		LOWER ROW OF FASTENERS LOWER LAP JOINTS	
US	99-12-52		IN-TANK-FUEL BOOST PUMP WIRING	
US	99-18-05		CRACKING OF THE VERTICAL BEAM OF AFT PRESS. BLKHD.	. 727-53-0210 & 0055R9
US	99-20-10		NLG WHEEL WELL - PRESSURE WEB	727-53-0145 R1
US	99-23-13		FUSELAGE SKINS NO 1 CARGO DOOR BS 560 AND BS 620	727-53A0219 R1
US	99-24-06		FUEL BOOSTER PUMP	727-28A0125 R1
727 2	J4	( 727	200 SERIES )	
707 0	4.0	( ====	000 055550 )	
727 2	12	( 727	200 SERIES )	
727 2	4.4	/ 707	OOO CERTEE	
121 2	14	( /2/	200 SERIES )	
727 2	17	( 727	200 SERIES )	
121 2		( 121	ZUU SEKIES )	
727 22	21	( 727	200 SERIES )	
121 2		(121	ZOO JEKIES )	
727 22	25	( 727	200 SERIES )	
		121	NOV GERTLO /	
727 22	27	( 727	200 SERIES )	
		, , , , ,		
727 23	31	( 727	200 SERIES )	
		, , , , , ,	,	
727 23	33	( 727	200 SERIES )	
		,		
727 26	60	( 727	200 SERIES )	
727 26	64	( 727	200 SERIES )	
727 27	77	( 727	200 SERIES )	
	OO SERIES			
CF	CF-84-08R2		WIRE CHAFING IN WING LEADING EDGE	737-SL-24-27
CF	CF-96-04		CORROSION PREVENTION & CONTROL PROGRAMS	
US	68-25-02		SCREWS IN PRINTED CIRCUIT	24-1009R1
US	69-12-06		AILERON TAB MAST FITTINGS	57-1040
US	69-17-01		AUXILIARY POWER UNIT	49A1761 AIRESEARCH
US US	69-20-06 70-04-03		CIRCUIT OVERLOADS	24-1011
- 03	70-04-03		PLACARD APU FIRE EXTINGUISHER	26-1011
ATRO	RAFT/AFRONES			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

1			TOTAL ME GENTINGE BE MEIT
POETN	C		
BOEIN			
	200 SERIES		
(CONT	INUED / SUITE)		
US	70-06-03	TAKEOFF WARNING SYSTEM	
US	70-09-01	ODERATION OF STATES	27-1031
US	70-18-06	OPERATION OF BATTERY SWITCH	24-1010R1
	70-18-06	EMERGENCY HATCH HANDLE	52-1034
US	73-09-04	CRACKS IN ENTRY DOOR HINGE	737-52-104481
US	74-09-05	EMERGENCY EXITS	737-25-1101
US	74-20-02	PITOT-STATIC TUBING	
US	74-21-03	FIRE HAZARD	737-34-1031
US		FIRE MAZARD	737-25-1096/1108
	75-04-08	HYDRAULIC SYSTEM ELECTRICAL WIRING	29-1004R1
US	75-05-01	CONTROL CABLE PULLEYS	737-27-1073R1
US	75-05-09	FUEL VALVE WIRE BUNDLES	737-28-1022
US	75-20-02		
US	75-24-09	GROUND SPOILERS	737-27-1041R4 737-27-1080 737-52-1004/1034/
US	75-25-00	GROUND SPUILERS	737-27-1080
	75-25-02	HATCH COVER AND LINING	737-52-1004/1034/
US	76-01-03	FLOOR BEAMS	737-53-1044
US	76-11-05R1	CONTROL SYSTEM VIBRATION	737-55A1020R3
US	76-01-03 76-11-05R1 76-26-02 78-04-02	· CARGO DOORS	
US	78-04-02	ATTACH BOLT REPLACEMENT	737-52-1065, R5
		ATTACT BOLT REFEACEMENT	
US	78-13-07	TRAILING EDGE FLAP	737-57-1082R4/1084R2
US	79-07-03	THRUST LEVER OPERATION	727 24 4000
US	79-23-02	"CARRY-ALL" INTERIOR	737-35-A1014
US	79-26-02	GPWS FLAP POSITION SWITCHES	
110	00 00 0000		707 0044000 0514 0
115	80-07-02RZ	AUXILIARY BODY FUEL TANK INSTALLATION	737-28A1032 REV 2
US	80-07-02	AUXILIARY BODY FUEL TANK INSTALLATION FLIGHT CONTROL SYSTEMS HORIZONTAL STABILIZER TRIM ACTUATOR	
US	80-09-05	HORIZONTAL STABILIZER TRIM ACTUATOR	737-27-1101
US	80-22-12R2	LEADING EDGE DEVICES	737-31-1038R3
US	80-26-51	CONTROL SYSTEM JAMMING	27A1109
US	81-20-04R1	U C DRECCIPITATION CONTROLLERS	707 04 14004
	81-20-04R1	H S PRESSURIZATION CONTROLLERS LOWER BODY SKINS CORROSION	737-21-A1064
US	82-01-09	LOWER BODY SKINS CORROSION	737-53A1042R3
US	83-01-05R2	UNDETECTED ENGINE	
US	84-10-04	APU FEEDER CABLE	737-24-1038
US	84-20-03R1	AFT PRESSURE BULKHEAD	737-53-1075R1
US	84-23-05		707 55 107581
	84-23-05	HORIZONTAL STABILIZER FORWARD AIRSTAIR ADJACENT FRAMES INSP	737-35A1029R3
US	85-01-06	FORWARD AIRSTAIR ADJACENT FRAMES INSP BBL 70 85 RIB UPPER CHORD INSP AUTOPILOT ACCESSORY UNITS MOD	737-53A1064R3
US	85-01-07	BBL 70 85 RIB UPPER CHORD INSP	737-57-1087R4
US	85-02-03	AUTOPILOT ACCESSORY UNITS MOD	737-22-1062
US	85-03-06R1		
US	05 00 0011	APPROVED FUEL	
	85-12-51 85-16-05	APPROVED FUEL	555 65 1151
US	85-16-05	FIRE PREVENTION - LAVATORIES	737-25-1171
US	85-19-01		737-27A116
US	85-22-02	BBL RIB UPPER CHORD INSP	737-57-1137R2
US	85-25-04	ESCAPE SLIDES INSP / MOD	737-25A1182R2
US	86-05-04	ESCAPE SLIDE COVER RESTRAINING STRAFS	707 254110202
US	86-12-04	ESCAPE SLIDE COVER RESTRAINING STRAPS HORIZONTAL STABILIZER REAR SPAR HORIZONTAL STABILIZER ATTACH LUG	/3/-55-1034
US	86-12-05	HORIZONTAL STABILIZER ATTACH LUG	737-55-1033
US	86-18-04	SELF LOCKING NUTS	737-SL-27-38
US	86-19-03	HLT FIRE EXTINGUISHER DISCHARGE OUTLETS	737-26A1029
		ABEX HYDRAULIC PUMP MOTOR	737-29-1029R2
US	87-02-05R1	ADEA TITURAULIC PUMP MUTUR	
US	87-02-07	LOWER WING SURFACE FUEL TANK ACCESS COVER	707 50 4060
US	87-07-03	AIRSTAIR EXIT HANDLE	737-52-1083
US	87-08-09	NITROGEN INFLATION A / C TIRES	
US	87-26-03	WEATHER RADAR RECEIVER - TRANSMITTER	737-34A1208R1
	88-07-04	TIRE BURST GUARDS	737-32-1202
US	88-07-04	WING FRONT SPAR UPPER CORD STRUCTURE	737-57A1081R10
US	88-11-04	WING FRUNT SPAR OFFER CORD STRUCTURE	
US	88-11-12	FWD / AFT BODY FRAMES ADJACENT TO CARGO DOOR	737-53-1051R4
US	88-14-07	NON-MODULAR AFT LAVATORIES SHROUD	
US	88-19-04	CABIN PRESSURE SAFETY RELEASE VALVE	737-21-1096
US	88-21-03R1	AFM CHANGES - FUEL CROSSFEED VALVE	
		TAKEOFF WARNING SYSTEM	
US	88-22-09	FUCELACE LAD IOINTS	737-53A1039R5
US	88-22-11R1	FUSELAGE LAP JOINTS	
US	89-02-04	NOSE LANDING GEAR ACTUATOR SUPPORT FITTING	
US	89-03-51	FIRE PROTECTION SYSTEM	M-7272-89-0532
US	89-04-03	COCKPIT DOOR - BLOWOUT PANELS	737-52A1105R1
		GENERATOR CONTROL UNIT - FILTER MODULE	87-101 WESTINGHOUSE
US	89-07-13	GENERALDE CONTROL ON THE TELEN MODULE	J
US	89-08-08	THRUST REVERSERS	707 00 1000
US	89-08-12R1	ENGINE FIRE / OVERHEAT DETECTION MODULE	737-26-1063
US	89-09-03	SOLID HEAD FASTENERS - LAP SPLICES	737-53A1039R4
	89-11-06R1	FORWARD LOWER CARGO COMPARTMENT FRAMES	737-53A1027R3
US		AFT RIGHT LAVATORY PARTITION BEAM	
US	89-12-02	FLICHT ATTENDANTS CEATS	113 TRANS AERO
US	89-14-11	FLIGHT ATTENDANTS SEATS	
US	89-15-08	SECOND OBSERVER'S SEAT	737-SL-25-41-A
US	89-21-02	ENGINE MOUNT CONE BOLT NUT	
US	89-22-04	INSPECTION - FUSELAGE STRINGER 14 LAP JOINT	737-53A1135
US	39 22 04	110.001101. 10010142 01111101.	

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIES
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJI

CIVITIN	JUED / SUITE)		
US	90-06-02	AGING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT WALTER KIDDE APU FIRE DETECTION SYSTEM	D6-38505RC
US	90-06-04	WALTER KIDDE APU FIRE DETECTION SYSTEM	M-7272-90-0735
US	90-12-11R1	ENSURE PROPER ESCAPE SLIDE RELEASE	737-2541270
US	90-17-20	T. 15 TO 101 DOLTO	COR EM. 100001
US	90-20-22 90-21-15 90-24-04 90-25-01	FLAP TRACK BULIS  FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY  HORIZONTAL STABILIZER REAR SPAR  PREVENT LOSS OF OUTBOARD FLAP  CORROSION PREVENTION AND CONTROL  PREVENT FUEL FORM CHARLING OF WITHE BUNDLES	737-57A1197
US	90-21-15	HORIZONTAL STABILIZER REAR SPAR	737-55A1031R2
US	90-24-04	PREVENT LOSS OF OUTBOARD FLAP	737-57A1206
US	90-25-01	CORROSION PREVENTION AND CONTROL	D6-38528RA
US	90-25-12	PREVENT FIRE FROM CHAFING OF WIRE BUNDLES	737-35-1033
US	90-26-05	FLIGHT ATTENDANT SEATS	
US	91-05-08 91-07-01	PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION	1 737-SL-76-2-A
US	91-07-01	PREVENT BLANKING OF EFIS DISPLAY	EFIP-701E-34-03
US	91-07-04 91-07-14 91-08-12 91-09-05	PREVENT RAPID DECOMPRESSION	737-53-1078R1
US	91-07-14	PREVENT HIGH VOLTAGE SHOCK HAZARD	
US	91-08-12	PREVENT HIGH VOLTAGE SHOCK HAZARD INSPECT FOR DISBONDED DOUBLERS CREW CALL HORN ELECTRICAL CIRCUIT AUXILIARY FUEL TANKS	737-53-1124
US	91-09-05	CREW CALL HORN ELECTRICAL CIRCUIT	737-23-1059
JS	91-16-08	AUXILIARY FUEL TANKS	737-28A1034 R2
US	91-16-08 91-21-12	RADIO CONTROL PANELS	707 20A 1004 KZ
JS	92-03-07	APU - SHROUD & FUEL DRAINS	737-SD-49-14R A O
US	92-07-10	CHAFING OF WIDES	727-24-107702 100
JS	92-08-06	SDEDDY SD177 AUTODITOT ELIGHT CONTROL COMPLITERS	737-224 107782, 108
JS			727-28-1047 DEVA
JS JS	92-09-02 92-15-03 92-19-16		
JS SL	92-15-03	OVERHEAD STORAGE BIN ATTACHMENTS MAIN DECK CARGO DOOR LOCK	727-2541222 02
JS JS	92-13-16	MAIN DECK CARCO DOOD LOCK	737-25A1283 K2
JS	92-25-04	OXYGEN MASKS	737-52-1006
JS	92-21-04 92-25-04 92-25-09	BONDED DOUBLERS & SPLICES	737-35A1037R1,103
JS	92-25-05	DONNED DOODLERS & SPLICES	737-53-1076R2
JS JS	93-01-27	REPLACE PLASTIC CONTROL CABLE GUARDS	737-27A1164
JS JS	93-05-17	"E-L" MINDOM NOT	737-53-1023 REV 1
JS	93-07-15	"E-F" WINDOW POST CLASS B CARGO COMPARTMENT AGING AIRCRAFT STRUCTURAL INTEGRITY - INSP/MOD CARGO DOOR FRAMES	200 20 00505 2511
12	93-08-04	AGING AIRCRAFT STRUCTURAL INTEGRITY - INSP/MOD	DOC D6-38505 REV
JS	93-14-10	CARGO DUUK FRANES	737-53-1096
JS	93-15-08R1	IPECO PILOTS AND CO-PILOTS SEATS	
JS	93-17-02	WING MAIN FUEL TANK FLOAT SWITCH	737-SL-28-36
JS	93-14-10 93-15-08R1 93-17-02 93-17-03 93-17-08 94-25-05 95-01-06R1	BFGOODRICH EVACUATION SLIDES	
JS	93-17-08	AGING AIRCRAFT	737-32A1224 REV 3
JS	94-25-05	STRUCTURAL MODIFICATIONS	/3/-53A11//
		The state of the s	737-53-0003 REV 3
JS	95-02-08	FUSELAGE SUPPORT STRUCTURE	737-53-1154
JS	95-06-05	LOWER JAMB OF UPPER DECK MAIN CARGO DOOR MAIN RUDDER POWER CONTROL UNITS	737-53-0004
JS	95-06-53 95-12-17	MAIN RUDDER POWER CONTROL UNITS	737-27-1185
JS	95-12-17		
JS	95-15-06	FUEL CROSS FEED VALVE ACTUATOR	61163-28-08
JS	95-23-10	EMERGENCY PROCEDURES FOR APU SHUT DOWN	
JS	96-02-06	WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	
JS	96-02-06 96-04-03 96-10-06	PREVENT SEPARATION OF NOSE COWL	71-03
JS	96-10-06	LOWER GATE HINGE ON FORWARD GALLEY SERVICE DOOR	737-52A1124
15	96-17-04	SURRORT FITTING - KOUGED FLAD ACTUATOD	737-57-1129R1
JS	96-22-11 96-23-04 96-23-51 96-26-07	HYDRAULIC FUSE ASSEMBLY	737-SL-29-21
IS	96-23-04	STATIC INVERTERS	737-24A1113
JS	96-23-51	RUDDER POWER CONTROL UNIT	737-27A1202 R1
IS	96-26-07	FLIGHT CONTROLS	
JS	97-01-10	AILERON CONTROL TRANSFER MECHANISM FUEL CAP ASSEMBLY AILERON CENTERING SPRINGS AILERON AND ELEVATOR PCU SELTANO CONCOUNTS OF REALING BURDED DWD CONTROL UNIT	27-1033
IS	97-03-04	FUEL CAP ASSEMBLY	737-28A1032 R5
IS	97-04-01	AILERON CENTERING SPRINGS	737-2541052 KS
JS	97-05-09	ATLERON AND ELEVATOR POLI	
JS	97-05-10	AILERON AND ELEVATOR PCU SEIZING, CRACKING OF BEARING RUDDER PWR CNTRL UNIT	707_CL_07_440D
	97-05-10 97-09-14	REWORKED OR OVERHAULED AIL & ELEV PCU'S - INSP	737-SL-27-112B
IS	97-09-14 97-09-15R1	YAW DAMPER - ENGAGE SOLENOID VALVE	737-3L-27-3U
IS		VAW DAMBED SYSTEM	
IS	97-14-03 97-14-04	YAW DAMPER SYSTEM	707 0711000 00
		MAIN RUDDER POWER CONTROL UNIT (PCU)	737-27A1202 R2
JS JS	97-18-06	MAIN WHEEL WELL CORROSION	
IS	97-19-03	PILOTS AND CO-PILOTS SEATS	A001-25-74 ISSUE :
IS	97-22-07	EDDY CURRENT BETWEEN FUSELAGE STNS 259. AND 1016	737-53A1177
IS	97-26-01	RUDDER PEDAL FORCES	
IS	98-02-01	PREVENTION OF UNCOMMANDED YAWING OF AIRCRAFT	
IS	98-03-09	AILERONS	
IS	98-03-10	PILOTS SEATS AND SEAT LOCKS	737-25-1334
JS	98-04-41	STRUCTUAL INTEGRITY JAMB AREA FUS MAIN CARGO DOOR	
JS	98-11-04R1	STRUCTURAL INSPECTION AND REPAIR	D6-37089 SSID REV
JS	98-11-52	MAIN TANK AFT BOOST PUMP WIRING	737-28A1120
JS	98-13-12R1		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

		BULLETIN DE SERVICE DE REF
BOEING 737 200 SERIES		
(CONTINUED / SUITE)		
US 98-14-09 US 98-18-20	FORWARD ENGINE MOUNT SUPPORT	737-5441012
US 98-22-10	FUEL SYSTEM CROSSFEED AND ENGINE SHUTOFF VALVES FORWARD SERVICE DOOR SUPPORT STRUCTURE	737-53A1108R1
US 98-25-06 US 98-26-24	AFT CARGO DOOR FRAME CORNERS BENDIX MAIN WHEEL ASSEMBLIES	737-52-1079 R5
US 99-01-16 US 99-03-04	FWD WATER SUPPLY DRAIN VALVE POSITION	737-32-026 737-38-1043
US 99-04-23	FUEL SYSTEM WIRING VERTICAL FIN INSTALLATION	737-53-1107
US 99-05-12 US 99-05-15	CENTER FUEL TANK FLOAW SWITCH WIRING	737-28A1132
US 99-08-23	ELEVATOR TAB ATTACHMENT NUTS FASTENER HOLES AFT PRESSURE BULKHEAD	737-SL-27-118-A
US 99-10-12 US 99-11-05	ENSURE STRUCTURAL INTEGRITY OF MLG RUDDER PCU SECONDARY SERVO VALVE SLIDE	737-32A1224R3
US 99-12-08	CRACKS BETWEEN STRINGERS 19L & 25L & STN 360-540	737-27A1221R1 R1 737-53A1160 R1
US 99-19-27 US 99-21-15	MAIN LANDING GEAR WHEEL ASSEMBLY TIE BOLTS MAIN TANK AFT BOOST PUMP WIRING	BFG 3-1439-32-13 737-28A112OR1
US 99-22-16 US 99-23-20	FLIGHT DECK DOOR UPPER DECOMPRESSION PANEL	737-52-1128
US 99-24-06	TRANSIENT SUPRESSION DIODE - REFUELING VALVE FUEL BOOSTER PUMP	737-28-1115 737-28A1134 R1
US 99-24-08 US 99-25-02	AIRPLANE BATTERY CHARGER SPOILER MIXER MECHANISM	TLEX M-7200-99-01528
US 99-26-07	ENGINE AFT MOUNT CONE BOLT	737-27A1213 737-71A1212/1250
737 2A3	( 737 200 SERIES )	
737 2A9C	( 737 200 SERIES )	
737 2E1	( 737 200 SERIES )	
737 2H4	( 737 200 SERIES )	
737 2L9	( 737 200 SERIES )	
737 2T2C	( 737 200 SERIES )	
737 2T4	( 737 200 SERIES )	
737 2T5	( 737 200 SERIES )	
737 217	( 737 200 SERIES )	
737 204	( 737 200 SERIES )	
737 210C	( 737 200 SERIES )	
737 217	( 737 200 SERIES )	
737 242C	( 737 200 SERIES )	
737 247	( 737 200 SERIES )	
737 248C	( 737 200 SERIES )	
737 275	( 737 200 SERIES )	
737 275C	( 737 200 SERIES )	
737 281	( 737 200 SERIES )	
737 284	( 737 200 SERIES )	
737 291	( 737 200 SERIES )	
737 296	( 737 200 SERIES )	
737 297	( 737 200 SERIES )	
<b>737 400 SERIES</b> US 89-03-51	ENGINE & CARGO COMPARTMENTS FIRE PROTECTION SYSTEM	M-7272-89-0532
US 89-04-03	. COCKPIT DOOR - BLOWOUT PANELS GENERATOR CONTROL UNIT - FILTER MODULE	737-52A1105R1
US 89-07-13 US 89-08-12R1	ENGINE FIRE / OVERHEAT DETECTION MODULE	87-101 WESTINGHOUSE 737-26-1063
CO JANUARY / JANUATE	2 2000	TRCRAFT/AFRONESS

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-52A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-25-04 OXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US MAIN FUEL TANK FLOAT SWITCH 737-51-28	
TOTAL   TOTA	
CODNITIONED	
US	
US	
US	1039R4
US 89-15-08 US 89-18-51 US 89-23-05 US 89-23-05 US 89-23-05 US 89-23-10 US 89-25-02 US 89-25-02 US 90-06-02 US 90-06-02 AGINS AIRPLANE STRUCTURAL MODIFICATION DOCUMENT US 90-06-02 AGINS AIRPLANE STRUCTURAL MODIFICATION DOCUMENT D6-38506 US 90-06-04 WALTER KIDDE APU FIRE DETECTION SYSTEM M-7272-9 US 90-08-11 ENSURE SLIDE WILL INFLATE US 90-09-11 ENSURE SLIDE WILL INFLATE US 90-10-5-11 US 90-10-5-12 US 90-10-5-14 US 90-15-14 US 90-15-14 US 90-15-14 US 90-15-14 US 90-15-14 US 90-15-17 US 90-15-14 US 90-15-17 US 90-17-20 US 90-17-20 US 90-17-20 US 90-22-2 FLEE FIRE AUGUST FIRE & OVERHEAT DETECTION SYSTEM 737-28-11 US 90-21-15 US 90-21-15 HORIZONTAL STABILIZER FEAR SPAR US 90-22-1 US 90-21-15 HORIZONTAL STABILIZER FEAR SPAR US 90-23-12 PREVENT APUR ROTOR FAILURE DUE OVERTEMPERATURE 737-574.1 US 90-24-04 PREVENT APUR ROTOR FAILURE DUE OVERTEMPERATURE 737-574.1 US 90-25-10 US	89-2127
US 89-18-08 US 89-18-06 US 89-23-05 US 89-23-05 US 89-23-05 US 89-23-10 US 89-25-02 US 89-25-02 US 89-25-02 US 89-25-02 US 90-06-02 AGINS AIRLAND STRUCTURAL MODIFICATION DOCUMENT US 90-06-02 AGINS AIRLAND STRUCTURAL MODIFICATION DOCUMENT US 90-06-04 US 90-06-04 WALTER KIDDE APU FIRE DETECTION SYSTEM M-7272-9 US 90-08-11 ENSURE SLIDE WILL INFLATE US 90-09-11 ENSURE SLIDE WILL INFLATE US 90-10-51 US 90-10-51 US 90-10-51 US 90-10-51 US 90-10-52 US 90-10-52 US 90-10-52 US 90-15-14 US 90-15-13 US 90-15-14 US 90-15-14 US 90-15-15 US 90-15-16 US 90-15-16 US 90-15-16 US 90-15-17 US 90-17-20 US 90-17-20 US 90-17-20 US 90-17-20 US 90-17-20 US 90-22-12 US 90-20-22 US 90-22-15 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-17-20 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-14 US 90-20-14 US 90-21-15 US 90-22-10 US 90-23-12 US 90-24-04 US 90-25-10 US 9	1027R3
US 89-18-08 US 89-18-06 US 89-23-05 US 89-23-05 US 89-23-05 US 89-23-10 US 89-25-02 US 89-25-02 US 89-25-02 US 89-25-02 US 90-06-02 AGINS AIRLAND STRUCTURAL MODIFICATION DOCUMENT US 90-06-02 AGINS AIRLAND STRUCTURAL MODIFICATION DOCUMENT US 90-06-04 US 90-06-04 WALTER KIDDE APU FIRE DETECTION SYSTEM M-7272-9 US 90-08-11 ENSURE SLIDE WILL INFLATE US 90-09-11 ENSURE SLIDE WILL INFLATE US 90-10-51 US 90-10-51 US 90-10-51 US 90-10-51 US 90-10-52 US 90-10-52 US 90-10-52 US 90-15-14 US 90-15-13 US 90-15-14 US 90-15-14 US 90-15-15 US 90-15-16 US 90-15-16 US 90-15-16 US 90-15-17 US 90-17-20 US 90-17-20 US 90-17-20 US 90-17-20 US 90-17-20 US 90-22-12 US 90-20-22 US 90-22-15 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-17-20 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-12 US 90-20-14 US 90-20-14 US 90-21-15 US 90-22-10 US 90-23-12 US 90-24-04 US 90-25-10 US 9	1231R1
US 89-18-03 US 89-18-05 US 89-20-05 ENGINE THROTTLE CABLE US 89-20-05 ENGINE THROTTLE CABLE US 89-20-10 US 90-10-11 US 90-11-11 US 90-11-11 US 90-12-11 US 90-12-11 US 90-12-11 US 90-14-02 REPLACEMENT OF RUDGE RELEASE US 90-14-02 REPLACEMENT OF RUDGE RELEASE US 90-15-14 US 90-15-14 US 90-15-14 US 90-15-14 US 90-15-14 US 90-17-20 REPLACEMENT OF RUDGE TRIM CONTROL KNOB US 90-17-20 FLAP TRACK BOLTS US 90-17-20 FLAP TRACK BOLTS US 90-21-15 HORIZONTAL STABILIZER REAR SPAR US 90-21-15 HORIZONTAL STABILIZER REAR SPAR US 90-22-12 PREVENT APUR ROTOR FAILURE DUE OVERTEMPERATURE US 90-22-12 PREVENT APUR ROTOR FAILURE DUE OVERTEMPERATURE US 90-23-14 US 90-25-14 US 90-25-14 US 90-25-15 US 90-25-15 US 90-25-15 US 90-25-16 US 90-25-16 US 90-25-17 US 90-25-17 US 90-25-17 US 90-25-18 US 90-25-19 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-01 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD US 91-07-01 US 91-07-0	NS AERO
US 89-23-05 ENGINE THROTTLE CABLE  US 89-23-10 ENGINE ICE INSESTION  US 89-23-10 ENGINE ICE INSESTION  US 89-23-10 ENGINE ICE INSESTION  US 89-23-52 BOLTS - FORWARD LEFT ENTRY DOOR  377-774  US 90-02-18 TAKEOFF CORP.  US 90-03-18 TAKEOFF CORP.  US 90-06-04 MALTER KIDDE APUP IRE DETECTION SYSTEM  M-7272-9  US 90-06-04 MALTER KIDDE APUP IRE DETECTION SYSTEM  M-7272-9  US 90-10-15 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-10-16 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-10-17 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-10-18 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-10-19 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-10-11 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-11-12 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-12-11 ENDING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT  US 90-15-10 ENDING ENDING THE DETECTION SYSTEM  173-28-11  US 90-15-11 ENDING AIRPLANE STRUCTURAL MODIFICATION  US 90-15-12 PREVENT FOR STRUCTURAL MODIFICATION  US 90-15-14 KIDDE ENSINE FIRE & OVERHEAT DETECTION SYSTEM  173-28-11  US 90-15-14 KIDDE ENSINE FIRE & OVERHEAT DETECTION SYSTEM  173-28-11  US 90-15-14 KIDDE ENSINE FIRE & OVERHEAT DETECTION SYSTEM  173-28-11  US 90-15-14 KIDDE ENSINE FIRE & OVERHEAT DETECTION SYSTEM  173-28-11  US 90-21-15 HORIZONTAL STABILIZER REAR SPAR  US 90-21-15 HORIZONTAL STABILIZER REAR SPAR  US 90-22-15 HORIZONTAL STABILIZER REAR SPAR  US 90-22-16 HORIZONTAL STABILIZER REAR SPAR  US 90-23-12 PREVENT LOSS OF OUTBOARD FLAP  US 90-23-12 PREVENT FIRE FROM CHAFING OF WIRE BUNDLES  173-55-11  US 90-25-14 WIRE BUNDLES  173-55-12  US 90-25-14 WIRE BUNDLES  173-55-12  US 90-25-14 WIRE BUNDLES  173-55-12  US 90-26-05 FILE THE FROM CHAFING OF WIRE BUNDLES  173-53-10  US 91-09-10 PREVENTION AND CONTROL  US 91-09-12 FIRE SKIND WIRE BUNDLES  173-53-10  US 91-09	
US 89-23-10	
US 89-23-10	
US 89-25-02   BOLTS - FORWARD LEFT ENTRY DOOR   737-7741	-80-1
US 89-25-02	05 1
US   90-06-02   AGING AIRPLANN STRUCTURAL MODIFICATION DOCUMENT   De-38505   US   90-06-04   WALTER KIDDE APU FIRE DETECTION SYSTEM   M-7272-9   W-7272-9   W-7272-	1005
US   90-06-02   AGING AIRPLANE STRUCTURAL MODIFICATION DOCUMENT   De-38505   US   90-09-11   ENSURE SLIDE WILL INFLATE   103-25-1'   US   90-10-51   CONTROL WHEEL INSTALLATION   103-25-1'   US   90-12-11R1   ENSURE PROPER ESCAPE SLIDE RELEASE   737-25A1   US   90-14-02   REPLACEMENT OF RUDDER TRIM CONTROL KNOB   737-25A1   US   90-15-03   FUEL FEED TUBE   FIRE & OVERHEAT DETECTION SYSTEM   737-25A1   US   90-15-17   PREVENT ENGINE FIRE & OVERHEAT DETECTION SYSTEM   737-25A1   US   90-15-17   PREVENT ENGINE FIRE & OVERHEAT DETECTION SYSTEM   737-25A1   US   90-17-20   FLAP TRACK BOLTS   737-57A1   US   90-17-20   FLAP TRACK BOLTS   737-57A1   US   90-22-22   FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY   737-57A1   US   90-23-12   PREVENT APU ROTOR FAILURE DUE OVERTMERATURE   737-49-11   US   90-24-04   PREVENT LOSS OF OUTBOARD FLAP   737-57A1   US   90-25-12   PREVENT APU ROTOR FAILURE DUE OVERTMERATURE   737-49-11   US   90-25-12   PREVENT TOR NOR CONTROL DE OVERTMERATURE   737-55A1   US   90-25-14   WIRE BUNDLES   737-55A1   US   90-25-14   WIRE BUNDLES   737-55A1   US   90-25-14   WIRE BUNDLES   737-55A1   US   90-26-05   FLIGHT ATTENDANT SEATS   US   91-07-04   PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION   737-55A1   US   91-07-04   PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION   737-55A1   US   91-07-04   PREVENT RAPID DECOMPRESSION   737-53-10   US   91-07-04   PREVENT RAPID   PREVENT RAPID   91-07-04   PREVENT RAPID   91-	
US   90-06-04   WALTER KIDDE APU FIRE DETECTION SYSTEM   M-7272-9	
US 90-09-11 ENSURE SLIDE WILL INFLATE US 90-10-51 CONTROL WHEEL INSTALLATION US 90-112-11R1 ENSURE PROPER ESCAPE SLIDE RELEASE US 90-14-02 REPLACEMENT OF RUDDER TRIM CONTROL KNOB 19-10-503 FUEL FEED TUBE US 90-15-03 FUEL FEED TUBE US 90-15-14 KIDDE ROBINE FIRE & OVERHEAT DETECTION SYSTEM 737-28-16 US 90-15-17 PREVENT ENGINE FIRE & OVERHEAT DETECTION SYSTEM 737-28-16 US 90-17-20 FLAP TRACK BOLTS US 90-20-22 FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-5741 US 90-20-21 FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-5741 US 90-23-12 PREVENT ADJ ROTOR FAILURE DUE OVERTEMPERATURE 737-5541 US 90-23-12 PREVENT ADJ ROTOR FAILURE DUE OVERTEMPERATURE 737-5541 US 90-25-01 CORROSION PREVENTION AND CONTROL US 90-25-14 PREVENT ADJ ROTOR FAILURE DUE OVERTEMPERATURE 737-35-16 US 90-25-14 WIRE BUNDLES 737-35-16 US 90-25-14 WIRE BUNDLES 737-35-16 US 90-26-05 FUEL AND STANDARD FROM THE BUNDLES 737-35-17 US 91-07-01 PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-S1-10 US 91-07-04 PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-S1-10 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-25-12 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-25-12 US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-25-12 US 91-09-15 FUEL THING WIRTH SHORE W	
US   90-10-51	
US   90-14-01R1	17
US 90-14-02 REPLACEMENT OF RUDDER TRIM CONTROL KNOB  US 90-15-03 FUEL FEED TUBE  US 90-15-14 KLDDE ENGINE FIRE & OVERHEAT DETECTION SYSTEM 737-28-10  US 90-15-17 PREVENT ERINE FUEL STARVATION 737-26-11  US 90-17-20 FLAP TRACK BOLTS 737-57-31  US 90-22-22 FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-57-31  US 90-21-15 MORIZONTAL STABILIZER REAR SPAR 737-55-31  US 90-23-12 PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-55-31  US 90-23-12 PREVENT LOSS OF OUTBOARD FLAP 737-57-31  US 90-25-01 CORROSION PREVENTION AND CONTROL D6-385281  US 90-25-12 PREVENT FIRE FROM CHAFING OF WIRE BUNDLES 737-35-10  US 90-25-14 WIRE BUNDLES 737-35-10  US 90-26-05 FLIGHT ATTENDANT SEATS  US 90-26-05 PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-55-11  US 91-07-04 PREVENT BLANKING OF EFIS DISPLAY EFIP-7011  US 91-07-04 PREVENT RAPID DECOMPRESSION 737-53-11  US 91-07-04 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-25-11  US 91-08-12 INSPECT FOR DISBONDED DOUBLERS 737-33-10  US 91-09-05 CREW CALL HORN ELECTRICAL CIRCUIT 737-23-11  US 91-09-12 FIRE EXTINGUISHING WIRING 737-26-10  US 91-09-12 FIRE EXTINGUISHING WIRING 737-26-10  US 91-09-14 WING MAIN FUEL TANKS 737-25-11  US 91-09-15 CREW CALL HORN ELECTRICAL CIRCUIT 737-23-11  US 91-09-16 WING MAIN FUEL TANKS 737-25-11  US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-52-12  US 91-09-10 HIGH VOLTAGE SHOCK HAZARD 737-25-11  US 91-09-11 WING MAIN FUEL TANKS 737-25-11  US 91-20-04 STABILIZER TRIM ASSEMBLY 737-25-12  US 91-20-04 STABILIZER TRIM ASSEMBLY 737-25-12  US 91-20-04 STABILIZER TRIM ASSEMBLY 737-25-12  US 91-20-01 WING MAIN FUEL TANKS 737-53-10  US 91-20-04 FLAP TRACK SUPPORT BOLTS 737-53-10  US 91-20-04 FLAP TRACK SUPPORT BOLTS 737-53-10  US 91-20-04 FLAP TRACK SUPPORT BOLTS 737-53-10  US 92-04-07 WIRE BUNDLES 737-53-10  US 92-05-09 AFM CHANGES AUXILIARY TRACK 737-52-22  US 92-07-09 AFM CHANGES AUXILIARY TRACK 737-52-22  US 92-07-09 AFM CHANGES AUXILIARY TRACK 737-52-12  US 92-07-09 AFM CHANGES AUXILIARY TRACK 737-52-12  US 92-07-09 AFM CHANGES AUXILIARY TRACK 737-52-10  US 92-07-	
US   90-15-03	1270
US 90-15-14  NE 105 PO-15-17  PREVENT ENGINE FIGE & OVERHEAT DETECTION SYSTEM 737-26-11  US 90-17-20  FLAP TRACK BOLTS  T37-57-31  US 90-20-22  FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-57-31  US 90-21-15  HORIZONTAL STABILIZER REAR SPAR 737-55-31  US 90-23-12  PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-55-31  US 90-23-12  PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-49-11  US 90-25-01  CORROSION PREVENTION AND CONTROL D6-385281  US 90-25-14  WIRE BUNDLES  T37-57-11  US 90-26-05  FLIGHT ATTENDANT SEATS  US 90-26-05  FLIGHT ATTENDANT SEATS  US 91-07-04  PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-SD-16  US 91-07-04  PREVENT BLANKING OF EFIS DISPLAY  EFIP-701  US 91-07-04  PREVENT RAPID DECOMPRESSION  T37-53-11  US 91-09-12  INSPECT FOR DISBONDED DOUBLERS  737-25-12  US 91-09-12  FIRE EXTINGUISHING WITHOR  T37-25-12  US 91-09-12  FLIGHT ANKS  T37-25-12  US 91-09-17  FLAP TRACK BOLTS  T37-25-11  US 91-09-17  FLAP TRACK SOLPPORT BOLTS  T37-57-31  US 91-09-17  FLAP TRACK BOLTS  T37-25-10  US 91-09-17  FLAP TRACK SUPPORT BOLTS  T37-25-11  US 91-10-09  TARCH SUPPORT BOLTS  T37-25-11  US 91-20-11  WING MAIN FUEL TANKS  T37-25-11  US 91-20-14  WING MAIN FUEL TANKS  T37-25-12  US 91-20-04  STABILIZER TRIM ASSEMBLY  T37-25-12  US 91-25-06  THRUST REVERSER AUXILIARY BRACKET  T37-25-12  US 91-25-06  THRUST REVERSER ALIVILIARY BRACKET  T37-25-12  US 92-03-07  APU - SHROUD & FILE GRACKET  T37-25-12  US 92-03-07  APU - SHROUD & FILE GRACKET  T37-25-12  US 92-04-07  WIRE BUNDLES  T37-25-12  US 92-07-09  AFM CHANGES - AUTOPLICT  US 92-08-11  FLIGHT TANKS FOR AUXILIARY TRACK  T37-25-12  US 92-03-07  APU - SHROUD & FILE GRACKET  T37-25-10  US 92-04-07  WIRE BUNDLES  T37-25-10  US 92-05-09  BONDED DOUBLERS SPLICES  T37-35-10  US 92-07-09  AFM CHANGES - AUTOPLICT  T37-25-10  US 92-07-09  AFM CHANGES - AUTOPLICT  T37-25-10  US 92-07-09  AFM CHANGES - AUTOPLICT  T37-25-10  US 92-07-09  AFM CHANGES ENDINE  T37-25-10  US 93-05-17  E - F WINDOW POSTS  T37-55-10  US 93-05-17  E - F WINDOW POSTS  T37-50-10  US	
US 90-17-20  FLAP TRACK BOLTS  90-20-22  FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-57A1  US 90-20-22  FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-55A1  US 90-23-12  PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-55A1  US 90-23-12  PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-49-11  US 90-25-01  CORROSION PREVENTION AND CONTROL  90-25-12  PREVENT FIRE FROM CHAFING OF WIRE BUNDLES 737-35-12  US 90-25-14  WIRE BUNDLES  737-35-12  US 90-25-14  WIRE BUNDLES  737-35-12  US 91-05-08  PREVENT APID DO ECOMPRESSION  91-07-01  PREVENT RAPID DE COMPRESSION  737-53-10  US 91-07-04  PREVENT RAPID DE COMPRESSION  737-35-11  US 91-08-12  US 91-08-12  US 91-08-12  US 91-09-15  CREW CALL HORN ELECTRICAL CIRCUIT  737-23-11  US 91-16-08  AUXILIARY FUEL TANKS  91-20-14  WING MAIN FUEL TANKS  91-20-14  WING MAIN FUEL TANKS  91-20-14  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 91-22-09  AFM LANDING  STAT-55A-12  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 92-07-09  AFM CHANGES - AUTOPILOT  373-25-12  US 92-16-01  FLOR PARKES  737-25-12  US 92-25-09  BREAK WEAR LIMITS  2-1474-29  US 92-25-09  BREAK WEAR LIMITS  2-1474-32  US 92-25-09  BRONDED DOUBLERS SPLICES  737-35-10  US 93-05-17  E F WINDOW POSTS  737-53-10  US 93-05-17  E F WINDOW POSTS  737-53-10  US 93-07-15  US 93-07-15  US 93-17-02  WING MAIN FUEL TANK FLOAT SWITCH  737-53-10  US 93-07-15  US 93-17-02  WING MAIN FUEL TANK FLOAT SWITCH  737-51-08  WING MAIN FUEL TANK FLOAT SWITCH  737-51-08  WING MAIN FUEL TANK FLOAT SWITCH  737-51-08  WING MAIN FUEL TANK FLOAT SWITCH	1055R1
US 90-17-20  FLAP TRACK BOLTS  90-20-22  FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-57A1  US 90-20-22  FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY 737-55A1  US 90-23-12  PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-55A1  US 90-23-12  PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-49-11  US 90-25-01  CORROSION PREVENTION AND CONTROL  90-25-12  PREVENT FIRE FROM CHAFING OF WIRE BUNDLES 737-35-12  US 90-25-14  WIRE BUNDLES  737-35-12  US 90-25-14  WIRE BUNDLES  737-35-12  US 91-05-08  PREVENT APID DO ECOMPRESSION  91-07-01  PREVENT RAPID DE COMPRESSION  737-53-10  US 91-07-04  PREVENT RAPID DE COMPRESSION  737-35-11  US 91-08-12  US 91-08-12  US 91-08-12  US 91-09-15  CREW CALL HORN ELECTRICAL CIRCUIT  737-23-11  US 91-16-08  AUXILIARY FUEL TANKS  91-20-14  WING MAIN FUEL TANKS  91-20-14  WING MAIN FUEL TANKS  91-20-14  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 91-22-09  AFM LANDING  STAT-55A-12  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 91-24-04  ESCAPE SLIDE DEPLOYMENT  373-25-12  US 92-07-09  AFM CHANGES - AUTOPILOT  373-25-12  US 92-16-01  FLOR PARKES  737-25-12  US 92-25-09  BREAK WEAR LIMITS  2-1474-29  US 92-25-09  BREAK WEAR LIMITS  2-1474-32  US 92-25-09  BRONDED DOUBLERS SPLICES  737-35-10  US 93-05-17  E F WINDOW POSTS  737-53-10  US 93-05-17  E F WINDOW POSTS  737-53-10  US 93-07-15  US 93-07-15  US 93-17-02  WING MAIN FUEL TANK FLOAT SWITCH  737-53-10  US 93-07-15  US 93-17-02  WING MAIN FUEL TANK FLOAT SWITCH  737-51-08  WING MAIN FUEL TANK FLOAT SWITCH  737-51-08  WING MAIN FUEL TANK FLOAT SWITCH  737-51-08  WING MAIN FUEL TANK FLOAT SWITCH	1055R1
US   90-17-20	1072R4
US   90-20-22   FUEL VAPOUR LEAKS TO LE LANDING LIGHT CAVITY   737-57A1     US   90-21-15   HORIZONTAL STABILIZER REAR SPAR   737-55A1     US   90-23-12   PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE   737-49-10     US   90-25-01   CORROSION PREVENTION AND CONTROL DE-38528     US   90-25-12   PREVENT FIRE FROM CHAFING OF WIRE BUNDLES   737-35-10     US   90-25-14   WIRE BUNDLES   737-35-10     US   90-25-14   WIRE BUNDLES   737-35-10     US   90-26-05   FLIGHT ATTENDANT SEATS     US   90-26-05   FLIGHT ATTENDANT SEATS     US   91-07-01   PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-SL-70     US   91-07-04   PREVENT BAINKING OF FITS DISPLAY   EFIP-701     US   91-07-04   PREVENT RAPID DECOMPRESSION   737-53-10     US   91-09-14   PREVENT RAPID DECOMPRESSION   737-53-10     US   91-09-12   INSPECT FOR DISBONDED DUBLERS   737-53-11     US   91-09-05   CREW CALL HORN ELECTRICAL CIRCUIT   737-23-10     US   91-09-12   FIRE EXTINGUISHING WIRING   737-66-10     US   91-09-17   FLAP TRACK SUPPORT BOLTS   737-5741     US   91-09-17   FLAP TRACK SUPPORT BOLTS   737-5741     US   91-20-04   STABILIZER TRIM ASSEMBLY   737-28-A10     US   91-20-11   WING MAIN FUEL TANK FLOAT SWITCH   737-25-12     US   91-21-13   FUEL SHUTOFF CABLE PULLEY BRACKET   737-76-10     US   91-24-04   ESCAPE SLIDE DEPLOYMENT   737-55-12     US   91-25-06   THRUST REVERSER AUXILIARY TRACK   737-55-12     US   91-24-03   BREAK WEAR LIMITS   737-52-40     US   92-07-09   AFM CHANGES - AUTOPILOT   737-25-10     US   92-07-09   AFM CHANGES - AUTOPILOT   737-35-10     US   92-05-09   BONDED DOUBLERS   737-35-10     US   92-25-09   BONDED DOUBLERS   737-35-10     US   92-25-09   BONDED DOUBLERS   737-35-10     US   93-05-17   E - F. WINDOW POSTS   737-53-10     US   93-07-15   CLASS BE CARD COMPARTMENT   737-51-28     US   93-17-02   WING MAIN FUEL TANK LOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK LOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TAN	
US 90-23-12	
US 90-23-12 PREVENT APU ROTOR FAILURE DUE OVERTEMPERATURE 737-49-11 US 90-25-01 CORROSION PREVENTION AND CONTROL D6-385281 US 90-25-12 PREVENT ILDS FROM CHAFING OF WIRE BUNDLES 737-35-16 US 90-25-14 WIRE BUNDLES 737-35-16 US 90-26-05 FLIGHT ATTENDANT SEATS 737-SL-76 US 91-05-08 PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-SL-76 US 91-07-01 PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-SL-76 US 91-07-04 PREVENT BLANKING OF EFIS DISPLAY EFIP-701E US 91-07-04 PREVENT RAPID DECOMPRESSION 737-S3-16 US 91-07-14 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-53-11 US 91-08-12 INSPECT FOR DISBONDED DOUBLERS 733-53-11 US 91-09-15 CREW CALL HORN ELECTRICAL CIRCUIT 737-23-16 US 91-09-17 FIRE EXTINGUISHING WIRING 737-26-16 US 91-09-17 FIRE EXTINGUISHING WIRING 737-26-16 US 91-09-17 FIRE EXTINGUISHING WIRING 737-28-12 US 91-20-04 STABILIZER TRIM ASSEMBLY 7337-28A1 US 91-20-04 STABILIZER TRIM ASSEMBLY 7337-28A1 US 91-21-13 FUEL TANKS 737-28-12 US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-526-12 US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-526-12 US 92-03-07 APU SHROWD FUEL TANKS 737-526-12 US 92-03-07 APU SHROWD FUEL DEPLOYMENT 737-25-12 US 92-03-07 APU SHROWD FUEL DEPLOYMENT 737-25-12 US 92-04-07 WIRE BUNDLES 737-25-12 US 92-04-07 WIRE BUNDLES 737-25-12 US 92-05-09 BREAK WEAR LIMITS 2-1474-32 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-25-09 BONDED DUBLERS & PILCES 737-25-12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-25-12 US 92-25-09 BONDED DUBLERS & SPLICES 737-25-12 US 92-25-09 BONDED DUBLERS & SPLICES 737-25-12 US 93-05-17 E PWINDOW POSTS 737-55-10 US 93-05-17 E PWINDOW POSTS 737-55-10 US 93-07-15 CLASS BCARGE ENGINE 737-75-10 US 93-07-15 CLASS BCARGE ENGINE 737-75-10 US 93-07-15 US 93	
US 90-24-04 PREVENT LOSS OF OUTBOARD FLAP US 90-25-01 CORROSION PREVENTION AND CONTROL D6-38528I US 90-25-14 WIRE BUNDLES 737-35-16 US 90-26-05 FLIGHT ATTENDANT SEATS US 91-05-08 PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-51-26 US 91-07-01 PREVENT BLANKING OF EFIS DISPLAY US 91-07-01 PREVENT RAPID DECOMPRESSION 737-53-16 US 91-07-04 PREVENT RAPID DECOMPRESSION 737-53-16 US 91-07-14 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-25-12 US 91-08-12 INSPECT FOR DISBONDED DOUBLERS 737-53-11 US 91-09-15 CREW CALL HORN ELECTRICAL CIRCUIT 737-23-16 US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-56-11 US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-5741 US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-5741 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-22-11 US 91-21-13 FUEL TANK FLOAT SWITCH 737-52-21 US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-22-04 FLAP REVERSER AUXILIARY TRACK 737-S2-78 US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-52-78 US 92-04-07 WIRE BUNDLES 737-59-19 US 92-04-07 WIRE BUNDLES 737-59-19 US 92-05-10 CHAFING OF WIRES 737-52-10 US 92-07-10 CHAFING OF WIRES 737-52-10 US 92-07-10 CHAFING OF WIRES 737-52-10 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-22-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-25-09 BONDED DOUBLERS SPILES 737-53-10 US 92-25-09 BONDED DOUBLERS SPILES 737-52-10 US 92-25-09 BONDED DOUBLERS SPILES 737-53-10 US 92-25-09 BONDED DOUBLERS SPILES 737-53-10 US 93-05-17 E PWINDOW POSTS 737-53-10 US 93-07-15 CLASS BCARGO COMPARTMENT US 93-15-081 IPECO PILLOTS SEATS US 93-10-015 CLASS BCARGO COMPARTMENT US 93-15-081 IPECO PILLOTS AND CO-PILLOTS SEATS US 93-10-015 CLASS BCARGO COMPARTMENT US 93-15-081 IPECO PILLOTS AND CO-PILLOTS SEATS US 93-07-15 CLASS BCARGO COMPARTMENT	
US   90-25-01   CORROSION PREVENTION AND CONTROL   D6-385281   US   90-25-12   PREVENT FIRE FROM CHAFING OF WIRE BUNDLES   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   737-35-10   7	
US 90-25-14	
US 90-26-05  US 91-05-08  US 91-05-08  PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-SL-76  US 91-07-01  PREVENT BLANKING OF EFIS DISPLAY  EFIP-701  US 91-07-04  PREVENT HIGH VOLTAGE SHOCK HAZARD  737-53-16  US 91-07-14  PREVENT HIGH VOLTAGE SHOCK HAZARD  737-53-16  US 91-09-05  CREW CALL HORN ELECTRICAL CIRCUIT  737-23-16  US 91-09-12  FIRE EXTINGUISHING WIRING  91-09-17  FLAP TRACK SUPPORT BOLTS  737-57412  US 91-09-17  FLAP TRACK SUPPORT BOLTS  737-57412  US 91-20-11  WING MAIN FUEL TANK FLOAT SWITCH  737-22-11  US 91-20-11  WING MAIN FUEL TANK FLOAT SWITCH  737-25-12  US 91-21-13  FUEL SHUTOFF CABLE PULLEY BRACKET  737-56-10  US 91-22-04  SFARDINGES SLIDE DEPLOYMENT  737-25A-12  US 92-03-07  APU - SHROUD & FUEL DRAINS  737-59-19  US 92-04-07  WIRE BUNDLES  737-59-19  US 92-07-09  AFM CHANGES - AUTOPILOT  TAT-24-10  US 92-07-09  AFM CHANGES - AUTOPILOT  TAT-25-10  US 92-15-03  BREAK WEAR LIMITS  92-16-01  FLOOR PANELS  737-52-10  US 92-25-04  MAIN DECK CARGO DOOR LOCK  737-52-10  US 92-25-04  MAIN DECK CARGO DOOR LOCK  737-52-10  US 92-25-09  BONDED DOUBLERS  737-75-10  US 92-25-09  BONDED DOUBLERS  737-75-10  US 93-05-17  E F WINDOW POSTS  737-75-10  US 93-05-17  FERVENT LOSS OF ENGINE CONTROL SWITCH  737-72-11  TOT-10-10  TAT-24-10  TOT-10-10  TOT-24-10  TOT-10-10  TOT-10-10	
US 90-26-05 PREVENT LOSS OF ENGINE CONTROL DUE CABLE CORROSION 737-SL-76 US 91-07-01 PREVENT BLANKING OF EFIS DISPLAY EFIP-7016 US 91-07-04 PREVENT RAPID DECOMPRESSION 737-53-16 US 91-07-14 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-25-12 US 91-08-12 INSPECT FOR DISBONDED DOUBLERS 737-53-10 US 91-09-05 CREW CALL HORN ELECTRICAL CIRCUIT 737-23-10 US 91-09-12 FIRE EXTINGUISHING WIRING 737-26-10 US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-57A12 US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-58A10 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-28A10 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-27-11 US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-SL-28 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-SL-78 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-25A-12 US 92-04-07 WIRE BUNDLES US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-25A12 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-15-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-15-05 BREAK WEAR LIMITS 737-25A12 US 92-15-06 DVERHEAD STORAGE BIN ATTACHMENTS 737-25A12 US 92-25-04 OXYGEN MASKS 737-25A10 US 92-25-09 BONDED DOUBLERS 737-35A10 US 92-25-09 BONDED DOUBLERS 737-72A11 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-72A11 US 93-05-05 AFM CHANGES SPLICES 737-73-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-05-07 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-081 IPECO PILLOTS SABTS US 93-17-02 WINK MAIN FUEL TANK FLOAT SWITCH 737-51-20	
US	
US   91-07-04   PREVENT BLANKING OF EFIS DISPLAY   EFIP-701    US   91-07-14   PREVENT RAPID DECOMPRESSION   737-53-16   US   91-07-14   PREVENT HIGH VOLTAGE SHOCK HAZARD   737-25-16   US   91-08-12   INSPECT FOR DISBONDED DOUBLERS   737-53-17   US   91-09-05   CREW CALL HORN ELECTRICAL CIRCUIT   737-23-16   US   91-09-12   FIRE EXTINGUISHING WIRING   737-26-16   US   91-09-17   FLAP TRACK SUPPORT BOLTS   737-57A12   US   91-16-08   AUXILIARY FUEL TANKS   737-57A12   US   91-20-04   STABILIZER TRIM ASSEMBLY   737-27-11   US   91-20-04   STABILIZER TRIM ASSEMBLY   737-27-11   US   91-21-12   RADIO CONTROL PANELS   US   91-21-13   FUEL SHUTOFF CABLE PULLEY BRACKET   737-76-10   US   91-22-04   ESCAPE SLIDE DEPLOYMENT   737-25A12   US   91-22-04   ESCAPE SLIDE DEPLOYMENT   737-25A12   US   91-25-06   THRUST REVERSER AUXILIARY TRACK   737-SL-78   US   92-03-07   APU - SHROUD & FUEL DRAINS   737-50-49   US   92-07-09   AFM CHANGES - AUTOPILOT   737-24-10   US   92-07-10   CHAFING OF WIRES   737-24-10   US   92-07-10   CHAFING OF WIRES   737-24-10   US   92-08-11   FLIGHT ATTENDS SEAT   US   92-15-03   BREAK WEAR LIMITS   2-1474-32   US   92-15-03   BREAK WEAR LIMITS   2-1474-32   US   92-15-04   MAIN DECK CARGO DOOR LOCK   737-52-10   US   92-25-04   OXYGEN MASKS   737-25A10   US   92-25-04   OXYGEN MASKS   737-35A-10   US   92-25-04   OXYGEN MASKS   737-35A-10   US   93-07-15   CLASS B CARGO COMPARTMENT   US   93-15-08R1   IPECO PILOTS AND CO-PILOTS SEATS   US   93-15-08R1   IPECO PILOTS AND C	76-2-4
S   91-07-04   PREVENT RAPID DECOMPRESSION   737-53-16     US   91-08-12   INSPECT FOR DISBONDED DOUBLERS   737-53-16     US   91-09-05   CREW CALL HORN ELECTRICAL CIRCUIT   737-23-16     US   91-09-12   FIRE EXTINGUISHING WIRING   737-26-16     US   91-09-17   FLAP TRACK SUPPORT BOLTS   737-26-16     US   91-10-9-17   FLAP TRACK SUPPORT BOLTS   737-28-16     US   91-20-04   STABILIZER TRIM ASSEMBLY   737-28-16     US   91-20-11   WING MAIN FUEL TANK FLOAT SWITCH   737-52-12     US   91-21-12   RADIO CONTROL PANELS   737-25-12     US   91-21-13   FUEL SHUTOFF CABLE PULLEY BRACKET   737-76-10     US   91-24-04   ESCAPE SLIDE DEPLOYMENT   737-25-12     US   91-25-06   THRUST REVERSER AUXILIARY TRACK   737-58-12     US   92-03-07   APU - SHROUD & FUEL DRAINS   737-58-28     US   92-04-07   WIRE BUNDLES   737-24-10     US   92-07-10   CHAFING OF WIRES   737-24-10     US   92-08-11   FLIGHT ATTENDS SEAT   15     US   92-16-01   FLOOR PANELS   737-25-12     US   92-16-01   FLOOR PANELS   737-25-12     US   92-16-01   FLOOR PANELS   737-25-12     US   92-25-04   OXYGEN MASKS   737-35A11     US   92-25-04   OXYGEN MASKS   737-35A10     US   92-25-09   BONDED DOUBLERS & SPLICES   737-27-11     US   93-01-27   REPLACE PLASTIC CONTROL CABLE GUARDS   737-53-10     US   93-01-27   REPLACE PLASTIC CONTROL CABLE GUARDS   737-53-10     US   93-05-05   AFM CHANGES = NGINE   737-53-10     US   93-07-15   CLASS B CARGO COMPARTMENT   737-51-28     US   93-15-08R1   IPECO PILOTS AND CO-PILOTS SEATS   1920-10     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93-17-02   WING MAIN FUEL TANK FLOAT SWITCH   737-51-28     US   93	15-24-02
US 91-07-14 PREVENT HIGH VOLTAGE SHOCK HAZARD 737-25-12 US 91-08-12 INSPECT FOR DISBONDED DOUBLERS 737-53-11 US 91-09-05 CREW CALL HORN ELECTRICAL CIRCUIT 737-23-16 US 91-09-17 FIRE EXTINGUISHING WIRING 737-26-10 US 91-16-08 AUXILIARY FUEL TANKS 737-57A12 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-27-11 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-27-11 US 91-21-12 RADIO CONTROL PANELS US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-525A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-59-49 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-59-49 US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-07-10 CHAFING OF WIRES 737-53-10 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53-10 US 92-24-04 MAIN DECK CARGO DOOR LOCK 737-25-12 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35-10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35-10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35-10 US 93-05-17 E F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-17-02 WING MAIN THE L TANK FLOAT SWITCH 737-51-28	107004
US 91-08-12 INSPECT FOR DISBONDED DOUBLERS 737-53-11 US 91-09-05 CREW CALL HORN ELECTRICAL CIRCUIT 737-23-10 US 91-09-17 FIRE EXTINGUISHING WIRING 737-26-10 US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-57A12 US 91-20-04 SAUXILIARY FUEL TANKS 737-28A10 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-27-11 US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-27-11 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-SD-48 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-SD-48 US 92-04-07 WIRE BUNDLES US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-07-10 CHAFING OF WIRES 737-53A11 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-55A12 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25A12 US 92-25-04 OXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-57A12 US 91-16-08 AUXILIARY FUEL TANKS 737-28A10 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-28A10 US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-5L-28 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-SL-78 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-SD-49 US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-25A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25A12 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53A10 US 93-05-17 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-17 F- WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPPECO PILOTS SEATS US NO SHAP CHANGES ENGINE 737-53-10 US 93-07-15 US MING MAIN FUEL TANK FLOAT SWITCH 737-51-28	1200
US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-57412 US 91-16-08 AUXILIARY FUEL TANKS 737-28A10 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-28-11 US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-SL-78 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-SD-49 US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-52-10 US 92-24-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-05-17 REPLACE PLASTIC CONTROL CABLE GUARDS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPPECO PLIOTS SMITCH 737-51-28	1124
US 91-09-17 FLAP TRACK SUPPORT BOLTS 737-57412 US 91-16-08 AUXILIARY FUEL TANKS 737-28A10 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-28-11 US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-SL-78 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-SD-49 US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-52-10 US 92-24-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-05-17 REPLACE PLASTIC CONTROL CABLE GUARDS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPPECO PLIOTS SMITCH 737-51-28	1059
US 91-16-08 AUXILIARY FUEL TANKS 737-57A12 US 91-20-04 STABILIZER TRIM ASSEMBLY 737-27-11 US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-27-11 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-5L-78 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-5D-49 US 92-04-07 WIRE BUNDLES US 92-04-07 WIRE BUNDLES US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-52A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52A12 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-04 OXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-25-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT 737-53-10 US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US NOT TO SEATS	1007
US 91-20-04 STABILIZER TRIM ASSEMBLY 737-28-10 US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-27-11 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25-12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-5L-78 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-SD-49 US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53-11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-53-11 US 92-24-04 MAIN DECK CARGO DOOR LOCK 737-52-12 US 92-25-04 OXYGEN MASKS 737-35-10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27-11 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS SMITCH 737-51-28	
US 91-20-11 WING MAIN FUEL TANK FLOAT SWITCH 737-21-12 US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTDFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-SL-78 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-SD-49 US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-25A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-25-04 OXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-17 E - F WINDOW POSTS 737-27A11 US 93-07-15 CLASS B CARGO COMPARTMENT 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT 737-53-10 US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 91-21-12 RADIO CONTROL PANELS US 91-21-13 FUEL SHUTOFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE SLIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-52-12 US 92-03-07 APU - SHROUD & FUEL DRAINS 737-5D-49 US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-15-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-55A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-25-04 OXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS SEATS US MING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 91-21-13 FUEL SHUTDFF CABLE PULLEY BRACKET 737-76-10 US 91-24-04 ESCAPE \$LIDE DEPLOYMENT 737-25A12 US 91-25-06 THRUST REVERSER AUXILIARY TRACK 737-SL-78 US 92-03-07 APU - \$SHROUD & FUEL DRAINS 737-SD-49 US 92-04-07 WIRE BUNDLES US 92-07-09 AFM CHANGES - AUTOPILOT 737-24-10 US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-55A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-55A11 US 92-24-04 MAIN DECK CARGO DOOR LOCK 737-55-10 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-10 US 92-25-04 OXYGEN MASKS 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-53-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT 193-08-15 US 93-15-08R1 IPPECO PILOTS AND CO-PILOTS SEATS US 93-15-08R1 IPPECO PILOTS AND CO-PILOTS SEATS US NOT TO SEATS USING MAIN FUEL TANK FLOAT SWITCH 737-51-28	28-36
US 92-07-09	
US 92-07-09	1023
US 92-07-09	221
US 92-07-09	18-22
US 92-07-09	19-14R A OR B
US 92-07-10 CHAFING OF WIRES 737-24-10 US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 DVERHEAD STORAGE BIN ATTACHMENTS 737-55A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-04 DXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 92-07-10 CHAFING OF WIRES  92-08-11 FLIGHT ATTENDS SEAT  US 92-15-03 BREAK WEAR LIMITS  92-16-01 FLOOR PANELS  US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS  92-21-04 MAIN DECK CARGO DOOR LOCK  US 92-24-04 THRUST REVERSER CONTROL SYSTEM  US 92-25-04 OXYGEN MASKS  US 92-25-04 OXYGEN MASKS  US 92-25-09 BONDED DOUBLERS & SPLICES  US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS  US 93-05-17 E - F WINDOW POSTS  US 93-07-15 CLASS B CARGO COMPARTMENT  US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH  737-51-28	084 R1
US 92-08-11 FLIGHT ATTENDS SEAT US 92-15-03 BREAK WEAR LIMITS 2-1474-32 US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 DVERHEAD STORAGE BIN ATTACHMENTS 737-25A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-04 DXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-25A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-52-10 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-52-10 US 92-25-04 DXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-35A10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 92-16-01 FLOOR PANELS 737-53A11 US 92-19-16 OVERHEAD STORAGE BIN ATTACHMENTS 737-25A12 US 92-21-04 MAIN DECK CARGO DOOR LOCK 737-25A12 US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-04 OXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-SI-28	32-16
US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-04 DXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-SL-28	
US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-04 DXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-SL-28	
US 92-24-04 THRUST REVERSER CONTROL SYSTEM 737-25-12 US 92-25-04 DXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-SL-28	
US 92-25-04 OXYGEN MASKS 737-35A10 US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 92-25-09 BONDED DOUBLERS & SPLICES 737-53-10 US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 93-01-27 REPLACE PLASTIC CONTROL CABLE GUARDS 737-27A11 US 93-05-05 AFM CHANGES ENGINE 737-77-10 US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	07602
US 93-05-05	164
US 93-05-17 E - F WINDOW POSTS 737-53-10 US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	
US 93-07-15 CLASS B CARGO COMPARTMENT US 93-15-08R1 IPECO PILOTS AND CO-PILOTS SEATS US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-SI-28	031 K1
US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-51-28	023R11
US 93-17-02 WING MAIN FUEL TANK FLOAT SWITCH 737-SI-28	
	8-36
IIS 94 OC 44	
IIS 94-21-0684 TUBUST DEVELOPE ACCESS FANEL /3/-5/-12	
03 94-21-05K1	053
US 94-26-12 /37-53A11	177
737-57-12	221
FUSELAGE SUPPORT STRUCTURE 737-53-11	
MAIN RUDDER POWER CONTROL UNITS 737-27-11	
US 95-09-01 FIREWALL FOR THRUST REVERSER FAN COWLS 737-78410	
AIRCRAFT/AFRONESS	

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

		90007	BULLETIN DE SERVICE DE REF.
BOET	16		
BOEII			
/3/	400 SERIES		
(CUN	TINUED / SUITE)		
US	95-10-05	HORIZONTAL STABILIZER TRIM ELECTRIC ACTUATOR	737-27A1191 REV 1
US	95-15-06	ACTUATORS ON FUEL SYSTEM	6113-28-08
US	95-23-10	EMERGENCY PROCEDURES FOR APIJ SHIT DOWN	
US	96-10-06	LOWER GATE HINGE ON ECONARD CALLEY SERVICE DOOR	737-52A1124
US	96-10-08	WIRE BUNDLE IN ELECTRICAL/ELECTRONICS BAY	737-SL-24-106
US	96-18-04	GIRT RESTRAINING STRAPS OF FORWARD DOORS	737-25A1221
US	96-23-51	RUDDER POWER CONTROL UNIT	
US	96-25-17	TIE LINKS OF ELEVATOR FEEL & CENTERTAIC UNIT	737-27A1202 R1
US	96-26-07	TIE LINKS OF ELEVATOR FEEL & CENTERING UNIT	/3/-2/A11942
US	97-02-16	PROVINCTY CHITCH BOLLING ALERT	
US	97-03-04	FIGURE ACCEPTAGE ALERI	737-2741199
US	97-03-04 97-04-01	FUEL CAP ASSEMBLY	737-28A1032 R5
US	97 04 01	AILERON CENTERING SPRINGS	737-27-1155NSC1
	31 03 03	AILERON AND ELEVATOR PCU	737-SL-27-71-A
US	97-05-10	SEIZING, CRACKING OF BEARING RUDDER PWR CNTRL UNIT	737-SL-27-112B
US	97-06-09	AILERON/RUDDER TRIM CONTROL MODULE	737-27A1198
US	97-09-14	REWORKED OR OVERHAULED AIL & ELEV PCU'S - INSP	737-SL-27-30
US	97-09-15R1	YAW DAMPER - ENGAGE SOLENOID VALVE	
US	97-14-03	YAW DAMPER SYSTEM	
US	97-14-04	MAIN RUDDER POWER CONTROL UNIT (PCU)	737-27A1202 R2
US	97-26-01	RUDDER PEDAL FORCES	
US	98-02-01	PREVENTION OF UNCOMMANDED YAWING OF AIRCRAFT	
US	98-02-51	HORIZONTAL STABILIZER FASTENERS	
US	98-03-09	ATI FRONS	
US	98-07-16	RELOCATE HYDRAUL IC FUSE	727-20-1071
US	98-11-52	RELOCATE HYDRAULIC FUSE MAIN TANK AFT BOOST PUMP WIRING RUDDER CONTROL SYSTEM	737-29-10/1
US	98-13-12R1	DIIDAED CONTROL SYSTEM	737-2841120
US	98-25-06	DOOD FLAME & CROSS PEAMS AT AFT CARCO DOOD	/3/-2/A1212
	98-25-06	DOOR FRAME & CROSS BEAMS AT AFT CARGO DOOR	737-52A1079
US	99-01-16	FWD WATER SUPPLY DRAIN VALVE POSITION	737-38-1043
US	99-03-04	FUEL SYSTEM WIRING	
US	99-05-12	CENTER FUEL TANK FLOAW SWITCH WIRING	737-28A1132
US	99-05-15	ELEVATOR TAB ATTACHMENT NUTS	737-SL-27-118-A
US	99-08-23	FASTENER HOLES AFT PRESSURE BULKHEAD	
US	99-10-12	ENSURE STRUCTURAL INTEGRITY OF MLG TRAILING EDGE FLAP LIMIT SWITCH	737-32A1224R3
US	99-10-13	TRAILING EDGE FLAP LIMIT SWITCH	737-27A1228
US	99-11-05	RUDDER PCU SECONDARY SERVO VALVE SLIDE MAIN WHEEL ASSEMBLIES - TIE BOLTS	737-27A1221 R1
US	99-19-27	MAIN WHEEL ASSEMBLIES - TIE BOLTS	3-1398-32-16
US	99-21-15	FUEL BOOST PUMP WIRING	737-28A1120
US	99-24-06	FUEL PROCTED DUMP	727 2044424 84
US	99-24-08		TLEX M-7200-99-01528
US	99-25-02	SPOILER MIXER MECHANISM	737-2741213
		Of Other Planet Planet Planet	
737	46M	( 737 400 SERIES )	
, , ,	7011	( 757 400 DERILES /	
747	200 CERTEC		
	200 SERIES	CORROSION PREVENTION & CONTROL PROGRAMS	
CF	CF-96-04	CRACKS IN FLAP TRACKS	57-2011 ASB
US	70-14-03	CRACKS IN FLAT TRACKS	74 2011 A3D
US	70-22-06	ENGINE COWL FLUID DRAIN INSTRUMENT PANEL ASSEMBLY	21-2065
US	70-23-03	INSTRUMENT PANEL ASSEMBLY	31-2065
US	70-24-02	MIC WHEEL BEAKING	39-1112
US	70-26-01	PASSENGER EVACUATION SYSTEM	20, 0024
US	71-02-04	LOAD EVENER INDICATOR TUBE	32-2031
US	71-17-02	BODY GEAR STEERING	32-2113
US	72-04-01	UNSCHEDULED STABILIZER TRIM	27-2054R3
US	72-08-01	LANDING GEAR ALTERNATE ACTUATORS	747-32-2118
US	74-08-10	FURWARD ELECTRONIC DATCHES	747-52-2088
US	74-19-06	PASSENGER DOOR CRANKS	747-52-2090
US	74-19-07	FLAP CONTROL HANDLE	747-27-2121R1
US	74-21-03		747-25-2245
US	75-04-06	PITOT-STATIC TUBING	747-35-2058
		CONTROL CABLE PULLEYS	747-27-2133
US	75-05-01	FLIGHT CREW WARNING	747-27-2128
US	75-05-11	FLOOR CAPABILITY	
US	75-15-05	POSSIBLE LAVATORY FIRES	747-38-2021
US	75-19-03		
US	75-20-05	FLAP SEPARATIONS	747-57-2119/2126 747-SL-28-3
US	76-14-06	FUEL LEAK PREVENTION	141-3L-20-3
US	77-12-07	FUEL VALVE ACTUATOR ASSYS	747 05 0070
US	78-05-08R3	COOL GAS GENERATORS	747-25-2373
US	78-07-09	DEPRESSURIZATION VENT	747-25-2306
US	78-08-04	OUTFLOW VALVE ASSEMBLIES	747-21-2139
US	79-05-04	AUXILIARY FUEL TANKS	747-28-2067/2091R1
US	79-06-02	FUEL TANK BOOST PUMP WIRING	747-28-A2092
	79-09-03	AURAL WARNING SYSTEM	747-31A2056
US			

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER SUBJECT
ORIGINE NUMERO DE CONSIGNE SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
BOEING			
747 20	DO SERIES		
	NED / SUITE)		
US	79-17-02R2	TRUSS & LATCH SUPPORT FITTING	747-53-2200
US	79-18-02	PACKBOARD LANYARDS	747-25A2467
US	79~20-11	LIGHTENING PROTECTION OF FUEL SYSTEM	
US US	80-07-02	FLIGHT CONTROL SYSTEMS	
US	80-08-02 80-14-11	ENGINE STRUT ROOT AREA WALL THICKNESS	747-54-2070
US	80-19-05	NOSE CARGO DOORS LEADING EDGE FLAP SYSTEMS	747-52A2167R1
	80-20-01	STRINGER MODIFICATION	747-27-2204
ÜŞ	80-20-02	B.F. GOODRICH SLIDES	747-53-2114R3 747-25-2543
US	80-25-03	SHEAR PIN RESTRAINTS	141-25-2543
US	81-15-06	CREW OVERHEAD HATCH ASSY	747-52A218OR1
US	81-22-51	AFM REVISION	747-77-2061
US	82-04-01	FAIRING MOUNTED (OFF-WING) SLIDES	747-25A2581
US	82-18-05	SMOKE DETECTION TUBE MOD	747-28-2083R1
US	82-24-02	OXYGEN FIRE PREVENTION	747-3542032
US	82-26-01	DUAL CHANNEL AUTOPILOT WITH M & L UNIT	747-22-2031
US	83-02-10	ICING PREVENTION	
US	83-05-09	WLG JURY STRUT SPINDLES	747-32-2261R1
US	83-08-02	FLAPTRACK FUSE BOLTS	747-57-2206R1
US	83-11-02	FLOOR BEAMS	747-53-2224R3
US	83-13-08	PLACARD - AUTOPILOT	747-57A2225
US	83-21-02R1	TRAILING EDGE FLAP TRACKS	747-57A2225R1
US	84-02-05	ENGINE ANTI-ICING SYSTEM	747-77-2060
US	84-03-06	LG ASSY. COMPONENTS	
US US	84-19-01 84-25-04	TENSION TIE AT BS INSPECTION	747-53-2088R2
US	85-02-01	AUTOPILOT BATTERY POWER	747-22A2152
US		BFG SLIDE / RAFTS O-RINGS	25-090R1 BF GOODRICH
US	85-22-12 85-25-55	PRESSURE BULKHEAD INSPECTION	747-22-12
US	86-01-51R1	S.B. 747-76A-2063, REV. 1 ENGINE STRUT DRAINS	747-76A-2063R1
US	86-05-01	FORWARD ENGINE MOUNT NUTS	747-21-2155R3
US	86-05-11R1	NACELLE STRUTS - NUTS	747-71A2216
US	86-07-03	FAN COWL SUPPORT STRUT STOWAGE MECH.	86-05-11R1
US	86-07-06	INBOARD PYLON UPPER LINK - FORWARD LUG	747-54-2111R4
US	86-08-02	VERTICAL FIN ACCESS COVER	747-534-2111R4
US	86-08-03	STRUT LOWER AFT BULKHEAD	747-54A2117R1
US	86-09-07R1	LOWER LONGITUDINAL LAP JOINT INSP.	747-53A2267 R3
US	86-10-10	ENGINE THRUST CONTROL CABLES	747-76A2065
US	86-11-01R1	INNER & OUTER WHEEL BEARINGS	747-32-2272
US	86-16-05	INSPECT BULKHEAD WEB & CHORD	747-53-2220R4
US	86-16-06	ESCAPE SLIDE NUTS	747-25A2696R2
US	86-18-01	INSPECT BODY FRAME STRUCTURE	747-53A2237R1
US	86-18-06	BOLTS - TRAILING EDGE FLAP TRACKS	747-57A2234
US US	86-19-03	HLT FIRE EXTINGUISHER DISCHARGE OUTLETS	747-26A2108/A2110
US	86-23-01 87-01-02	H-11 BOLTS	747-57A2235
	87-04-07	ESCAPE SLIDE ATTACHMENT	747-25A271O
US	87-06-11	EVACUATION SYSTEM CARGO RESTRAINTS	747 5040055
US	87-07-06	PASSENGER DOOR EMERGENCY RESERVOIRS	747-53A2273
	87-08-09	NITROGEN INFLATION A / C TIRES	747-52A22O1
	87-12-04	HYDRAULIC SYSTEM	747-29-2063
	87-16-13		747-53A2279R1
US	87-24-02	INSPECT LONGERON FITTINGS	747-53A228OR1
US	87-24-09	WEATHER RADAR RECEIVER - TRANSMITTER	747-34A2286
US	88-05-07	APU FUEL LINE	747-49-2051
US	88-13-05	AUTOPILOT / FLIGHT DIRECTOR (LCRU)	747-22-2166
US	89-03-51	ENGINE & CARGO COMPARTMENTS FIRE PROTECTION SYSTE	M
US	89-04-05	NLG WHEEL WELL AREA (EXTERIOR / INTERIOR)	747-53-2112R7
	89-05-04R1	FLAP TRACKS	747-57A2229R9
	89-06-03	AEROQUIP GO1 TYPE FUEL NOSES	
	89-08-03R1	AEROQUIP GO1 TYPE FUEL NOSES FUSELAGE - BODY CROWN CREASE BEAM ENGINE CONTROL CABLE BUILEY DACKET	747-53-2297, 2244
	89-08-09	ENGINE CONTROL CABLE PULLEY BRACKET	747-76A2O74
	89-12-07	WING CENTRE CAVITY - AILERON CONTROL CABLES	
	89-12-10	INBOARD FUEL TANK ACCESS DOORS	
	89-15-02	STABILIZER LIMIT SWITCH ASSEMBLY	747-27-2228R1
	89-15-07	FITTINGS - WING LANDING GEAR BEAM	747-57-2244R1
	89-21-03	OXYGEN GENERATOR RELEASE CABLE ASSEMBLY	747-35A2065
	89-21-09	FUSELAGE SKIN BODY STN 460	747-53-2289R1
	89-23-07 89-23-19	H-11 SIEEL BOLTS	747-51-2043 R5
	90-03-12	HORIZONTAL STABILIZER HINGE FITTINGS	747-53A2314
	90-06-06	CONTROL CABLE BLOCK PLATES	747-25-2776
	00 00	STRUCTURAL MODS & TRAILING EDGE FLAP TRACKS	747-53A2229R8
ATROD	AFT/AFPONEES		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

BOEING	3		
	200 SERIES		
(CONT.	MUED / CUITTE)		
US	00-00 10	**************************************	
	90-06-12	BULKHEAD - BODY STN 1241	747-53-2299R1
US	90-06-14R1	BULKHEAD - BODY STN 1241 PREVENT PRESSURE LOSS DUE CRACKS NOSE WELL BOX LANDING GEAR TRUNION PREVENT INADVERTENT OPENING CARGO DOORS DETECT CRACKS FRONT PRESS BULKHEAD ENSURE OPERATION OF DOOR SLIDES	747~53-2293 R6
US	90-06-18R1	LANDING GEAR TRUNION	747-32-2190R7
US	90-09-06	PREVENT INADVERTENT OPENING CARGO DOORS	747-52A2206R2
US	90-09-09	DETECT CRACKS FRONT PRESS BULKHEAD	747-53-2064
US	90-10-03	ENSURE OPERATION OF DOOR STORE	747 50 2004
US	90-11-02	DEVENT ADIL FIDE FORM DEVENTANCE FROM	747-52A2217
US	90-11-02 90-11-08	PREVENT APU FIRE FROM PENETRATING FIREWALL PREVENT FUEL ENTERING FWD CARGO COMPARTMENT SUPERNUMERARY OXYGEN SYS BLEED RELIEF VALVE B.F. GOODRICH DOOR 3 LOWER DOOR COVER	747-53A2317
US	90-13-05	TREVENT FUEL ENTERING FWD CARGO COMPARIMENT	747-57A2247 R3
US	90-13-05	SUPERNUMERARY DXYGEN SYS BLEED RELIEF VALVE	747-35A2061
	90-13-09	B.F. GOODRICH DOOR 3 LOWER DOOR COVER	25-229 BFG
US	90-15-06	SUPERNUMERARY OXYGEN SYS BLEED RELIEF VALVE B.F. GOODRICH DOOR 3 LOWER DOOR COVER INSPECT FUSELAGE SKIN INSPECT NOSE WHEEL WELL VERTICAL BEAMS TRAILING EDGE FLAP SPINDLES	747-53-2307 REV 2
US	90-15-51	INSPECT NOSE WHEEL WELL VERTICAL BEAMS	747~53A2338
US	90-17-19 90-20-10 90-20-20 90-21-09	TRAILING EDGE FLAP SPINDLES FAILURE OF TE FLAP TRACK FAIL-SAFE STRAPS PREVENT ENGINE SEPARATION	747-27-2280R3
US	90-20-10	FAILURE OF TE FLAP TRACK FAIL-SAFE STRAPS	747-57-218784
US	90-20-20	PREVENT ENGINE SEPARATION	747-54-2123
US	90-21-09	FAILURE OF CROSSOVER PNEUMATIC DUCTS	747-54-2123
US	90-21-13	LATEURE OF CRUSSOVER PREUMATIC DUCTS	747-36-2078R1
	00-21-13	TYDRAULIC & PNEUMATIC LINES IN 2 & 3 STRUIS	747-29-2051
US	30-21-17	FAILURE OF CROSSOVER PNEUMATIC DUCTS HYDRAULIC & PNEUMATIC LINES IN 2 & 3 STRUTS FUSELAGE LAP SKIN SPLICE PREVENT LOSS OF CABIN PRESSURE	747-53A2303
US	90-23-14	PREVENT LOSS OF CABIN PRESSURE	747-53-2253R2
US	90-21-13 90-21-17 90-23-14 90-23-16	PREVENT PARTIAL GEAR LIP OF GEAR HIS LANDINGS	747-32-2361R1
US	50-24-09	INSPECT FLAP TRACK FURWARD END CLEVIS LUGS	747-57-2231R2
US	90-25-05	CORROSION PREVENTION AND CONTROL	
US	90-25-08	PREVENT CARGO COMPARTMENT FIRE FROM MIGRATING	
US	90-25-10	CORROSION PREVENTION AND CONTROL PREVENT CARGO COMPARTMENT FIRE FROM MIGRATING PREVENT LOSS OF REDUNDANCY IN ELEV CONTROL	747-27A2253R4
US	90-26-10	PREVENT RAPID DECOMPPRESSION	747-53A2321 REV5
US	90-26-10 91-03-13 91-03-17 91-05-17	VERIFY APPLICATION OF FUEL TANK BARRIER PREVENT FLAP TRACK FAILURES	747-57-2253R1
US	91-03-13 91-03-17	DEVENT FLAD TRACK FATURES	747-57-2256 R2
	91-03-17	PREVENT FLAP TRACK FAILURES	
US	91-05-17	HORIZONTAL STABILIZER - FUS STN 2598 BULKHEAD WEB ELIMINATE POTENTIAL OF AN ENGINE FUEL FIRE	747-53A2332
US	91-05-19	ELIMINATE POTENTIAL OF AN ENGINE FUEL FIRE	747-36A2097 R2
US	91-06-03	PREVENT CABIN PRESSURE LOSS	
US	91-06-08	PREVENT DAMAGE TO WING PANELS AND WIRING	747-36A2O74R4
US	91-05-19 91-06-03 91-06-08 91-09-11	PREVENT DAMAGE TO WING PANELS AND WIRING DRAIN MAST SHIELDES FORWARD FUSELAGE STRUCTURE PROTECTIVE SLEEVE ON WIRE BREAKOUT AND OXYGEN LINE	747-38A2O77
US	91-11-01 91-13-11 91-15-24 91-18-04	FORWARD FUSELAGE STRUCTURE	747-53A2265R8
US	91-13-11	PROTECTIVE SLEEVE ON WIRE BREAKOUT AND OXYGEN LINE	747-35-2059 REV 2
US	91-15-24	AUXILIARY POWER UNIT PNEUMATIC DUCTS	747 36-2081R1
US	01-19-04	FUSELAGE FRAMES	747-53-2302
US	01-00-00	FIRE PROTECTION SYSTEM PLUMBING	747-26A2094R1
0.5	91-20-06	FIRE PROTECTION SYSTEM PLUMBING	747-20A2U34K1
US	91-20-06 91-21-12 91-22-05 91-25-02	RADIO CONTROL PANELS	747 05 0704
US	91-22-05	OVERHEAD STOWAGE BINS	747-25-2734
US	91-25-02	B F GOODRICH SINGLE-PIECE RAMP SLIDE	4A3416-25-233 BFG
US			747-53A2326
US	92-02-13	DEPRESSION PANEL AND FLAPPER VALVE GIRT BAR END FITTINGS & FLOOR BRACKETS PASSENGER OXYGEN SYSTEM FLOW CONTROL UNITS AUXILIARY POWER UNIT PNEUMATIC DUCT RESTRAINT FUEL TUBES - ENGINE STRUTS	747-21A2312, 2317
US	92-02-17	GIRT BAR END FITTINGS & FLOOR BRACKETS	747-25-2754
110	92-04-03	PASSENGER OXYGEN SYSTEM FLOW CONTROL UNITS	747-35-2074 R1
US	92-04-05	ALIXIL TARY POWER UNIT PNEUMATIC DUCT RESTRAINT	747-36A2087
	92-04-03	FILE THREE - ENGINE STRUTS	747-28-2153 / 2154
US	92-06-01	AUXILIARY POWER UNIT PNEUMATIC DUCT RESTRAINT FUEL TUBES - ENGINE STRUTS EVFACUATION SYSTEM PACKBOARD AND COVER ASSEMBLIES EMERGENCY DOOR POWER ASSIST SYSTEM BODY STN 1241 BULKHEAD FORGING	747-2542889
US	92-06-03	ENTROCENCY DOOD DOWED ACCIET CYCTEM	747-5242237
US	92-06-07	EMERGENCY DOUR POWER ASSIST SYSTEM	747-53-2283 R4
US	92-08-02	BUDY SIN 1241 BULKHEAD FURGING	141-33-2203 K4
US	92-14-02	LIFE RAFT MOORING LINE AND INFLATION RATE	1
US	92-14-07	BODY STN 1241 BULKHEAD FORGING LIFE RAFT MOORING LINE AND INFLATION RATE PREVENT INADEQUATE FIRE AGENT LEVELS ESCAPE SLIDES	747-26A2179,R1,R2
US	92-16-08	ESCAPE SLIDES	747-25-2132
US	92-18-12	BRAKES - MAYIMOM MEAR CIMILS	2602012-32-001K2 BEN
US	92-24-51	NACELLE STRUT MIDSPAR FUSE PINS	2063R9, A2155R1.2168
US	92-27-04		D6-35999
	02-02-14	AGING AIRCRAFT FORWARD AND AFT BOTTLE BORE FUSE PINS	54-2066R2,2155,2168
US	93-03-14	CLASS B CARGO COMPARTMENT	747-26-227
US	93-07-15	FUSELAGE INTERNAL STRUCTURE	747-53-2349
US	93-08-12	PORTAL LATOUR DIN CURRENT FITTINGS - CARGO DOOR	747-52-2186
US	93-10-01	OKINE ENTON TENTON	747-76A2083 R1 R2
US	93-17-06	NO 1 STRUT IDLER PULLEY SUPPORT BRACKET ASSY	
US	93-17-07	NACELLE ATTACH FITTING	747-54A2152 REV 3
US	93-18-07	FIRE EXTINGUISHER DISCHARGE TUBES	747-26A2214 REV 3
US	93-20-04	BF GOODRICH EVACUATION SLIDE/RAFTS	4A3221-25-250
US	94-01-15	FASCIA PANELS	747-25A3056
	04-02-05	PASSENGER OXYGEN SYSTEM RESEVOIR MASK ASSEMBLIES	
US	94-03-05	WIRE BUNDLES	747-24A2186R1
US	94-05-07	CRACKED OR FRACTURED H-11 STEEL BOLTS	747-51-2048 R1
US	94-07-06	DUCT COURT INCS - WINC LEADING EDGE	
US	94-09-13	DUCT COUPLINGS - WING LEADING EDGE	747-71A2269
US	94-10-05	FORWARD EDWER ENGINE MOON! BOL!	747-7142269
US	94-10-10	ENGINE FAN THRUST REVERSER	
US	94-12-04	LAF OCTIVIO	747-53-2367 R1
US	94-12-09	SKIN LAP JOINTS IN FUSELAGE UPPER LOBE	747-53-2307 R2
			A TOCOACT /ACDONICES

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

		30001	
BOEING	3		
747 2	200 SERIES		
	NUED / SUITE)		
US	94-13-06	RAPID DECOMPRESSION	747-53-2371
US			
	94-15-06	WING TO BODY FAIRING - LOWER LOBE LAP JOINTS	747-53A2312 OR R1
US	94-15-17	FUSELAGE LONGITUDINAL LAP JOINTS	747-53-2366
US	94-15-18	DTR FOR EACH SSI IN BOEING D6-35022 REV D	SSID D6-35022 REV D
US	94-17-01	HIGH FREQUENCY CURRENT INSPECTION - LAP JOINTS	747-53A2267 OR REV 3
US	94-17-09	BFGOODRICH EVACUATION RAMP/SLIDES	7A1418-25-253
US	94-17-17	INBD & OUTBD STRUT FWD SPAR CHORDS, STIFFENERS	747-54-2160 REV 1
US	94-22-08	PYLON SKIN	747-54-2091R5
US			
	95-02-07	STRUT DRAINAGE AREA	747-28-2160 REV 1
US	95-10-16	NACELLE STRUT AND WING STRUCTURE	747-54A2195R1
US	95-11-03	POTABLE WATER TANK	747-38A21O5
US	95-13-05	NACELLE STRUT AND WING STRUCTURE	747-54A2157
US	95-13-06	NACELLE STRUT AND WING STRUCTURE	747-54A2156 R2
US	95-13-07	NACELLE STRUT AND WING STRUCTURE	747-54A2158
US	95-15-52	MODIFY LONGITUDINAL FLOOR BEAMS	, , , o , , , _ , , , , , , , , , , , ,
US	95-16-02	REVERSIBLE GEARBOX PNEUMATIC DRIVE UNIT (PDU)	747 7040404
		REVERSIBLE GEARBOA PINEUMATIC DRIVE UNIT (PDU)	747-78A2131
US	95-20-05	PYLON BRACE FITTINGS	747-52-2062 REV 7
US	96-01-03	WEIGHT LIMITATION	
US	96-01-51	PRESSURIZATION VENT DOOR	
US	96-02-06	WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	
US	96-06-06	AUTOLAND SYSTEM	747-22A2213 R2
US	96-07-10	OVERHEAD STORAGE BINS HINGE PINS	747-25A3095 REV 1
US	96-11-03		
		FUEL LINE IN 1 & 4 ENGINE STRUTS	747-35A2O97 R3
US	96-14-01	PASSENGER OXYGEN SUPPLY LINES	
US	96-22-01	ELEVATOR SERVO ASSEMBLIES	747-27A2348 REV 1
US	96-22-11	HYDRAULIC FUSE ASSEMBLY	747-SL-32-19
US	96~23-02	DISBONDING AND CRACKING OF SKIN PANELS	747-53A2409, 53-2272
US	96-23-05	CORROSION ON GIRT BAR SUPPORT FITTINGG	747-53A2378 REV 1
US	96-26-04	NWW PRESSURE BULKHEAD	
US	96-26-06	BOOSTER PUMPS	747 0040004
			747-28A22O4
US	96-26-52R1	ENGINE PYLON	747-54A2157
US	97-03-17	FUEL PUMP WIRING	747-28A2194 R1
US	97-03-19	DOOR #3 DOOR OPENING THRUSTERS	747-25-2951
US	97-05-01	EDDY CURRENT(HFEC)FRONT SPAR WEB CENTER WING	747-57A2298R1
US	97-08-05	SWITCHES - CABIN ATTENDENTS PANEL	747-33A2252
US	97-12-03	PYLON MIDSPAR FITTINGS	
US		CORROSION OR CRACKING OF FUSE PINS	747-54-2118R1
	97-14-06	CURRUSION OR CRACKING OF FUSE PINS	747-52A2166 R1
US	97-20-01R1	ENGINE PYLON LOWER SPAR FITTING LUG	747-54-2062 R8
US	97-25-06	SCAVENGE PUMP	747-28A2206
US	97-26-07	TEFLON SLEEVING AND WIRE BUNDLES	747-28A22O4 R1
US	97-26-21	LONGERON SPLICE FITTINGS BODY STATION 2598	747-53A2410
US	98-02-02	FORWARD ENGINE MOUNT	747-54A2069R4
US	98-03-10	PILOTS SEATS AND SEAT LOCKS	
US			747-25-3132
	98-07-15	CRACKS OF THE SKIN AND INTERNAL DOUBLERS STA 460	747-53A2396 R1
US	98-08-15	WING STRUT	747-54A2158 R2
US	98-08-23	ENGINE FLAMEOUT DUE TO JP-4/JET B FUEL	747-11A2O52
US	98-09-17	UPPER DECK FLOOR BEAMS	747-53A2420
US	98-10-10	ELECTRICAL WIRING IN FUEL TANKS	747-28A22O4
US	98-13-12R1	RUDDER CONTROL SYSTEM	747-27A2368
US	98-14-17	SCAVENGE PUMP	
US	98-16-13	FORWARD AND AFT INNER CHORDS OF BS 2598 BULKHEAD	747-28A2215
	09-16-10	CENTED TANK OVERTRE / LETTICON CHES DURING	747-53A2423
US	98-16-19	CENTER TANK OVERIDE/JETTISON FUEL PUMPS	747-28A2212 REV 2
US	98-17-13	ENGINE FIRE DETECTION SYSTEM	747-26A2250
US	98-18-23	CARGO DOOR - ALUMINUM LATCH SUPPORT FITTINGS	747-53A2377R2
US	98-20-20	AFT PRESSURE BULKHEAD	747-53-2275R1 TO R6
US	98-20-37	CABIN ATTENDANT'S PANEL SWITCHES	
US	98-20-40	FUEL AND SURGE TANK SHIELDED WIRING	
US	98-21-17		747-5040474 04
		MAIN LANDING GEAR SPRING BEAM	747-52A2171 R1
US	98-21-29	FUEL SHUTOFF VALVE PART NUMBERS	747-28A2199
US	98-25-52	OVERRIDE/JETTISON FUEL PUMPS	
UŞ	98-26-13	MAIN ENTRY DOOR STOP SUPPORT FITTINGS	747-53-2358
US	98-26-23	REAR SPAR WEB CENTER WING AREA	747-57-2263 R1
US	99-01-10	ENGINE STRUT DIAGONAL BRACE LUGS	747-54-2126R5
US	99-04-01	STRUT SKIN AND SPRING BEAM FITTINGS	747-54A2172
US	99-05-02	OUTBOARD SEQUENCE CARRIAGE FITTING WING FOREFLAP	747-5740200
US	99-05-06		
		NUMBER 1 AND 4 NACELLE STRUTS	747-54A2184
US	99-07-03	MAIN DOOR EDGE FRAME WEB & DOUBLER FATIGUE CRACKS	
US	99-07-12	LOWER LOBE FUSELAGE FRAMES	747-53A2408
US	99-08-01	LOWER LOBE FUSELAGE FRAMES  2 AND 3 ENGINE UPPER LINK ASSEMBLY CENTRE FUEL TANK INSPECTION.	747-54A2187
US	99-08-02R1	CENTRE FUEL TANK INSPECTION	747-28A2210
US	99-08-10	LAVATORY DRAIN SYSTEM	
US	99-08-19	APU FUEL BOOST PUMP ELECTRICAL MOTOR	747-2842200 04
		THE TOTAL BOOST FORM ELECTRICAL MOTUR	747-28A2209 R1
ATRO	RAFT/AFRONES		

BOEING

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

BOEII			
747	200 SERIES		
(CON	FINUED / SUITE)		
US	99-09-11 99-10-10	NACELLE STRUT DIOGNAL BRACE STEEL FITTINGS	
US	99-11-15	FUSE PINS	747-54-2155 R2
US	99-15-08	AILERION CABLE FRAYING	747-27-2367R1
US	99-20-09	FAIL SAFE FEATURES OF THE THRUST REVERSER SYSTEM	747-87A2130
US	99-24-16	TANGENTIAL LINK UPPER BOLT NUT ENG MOUNT CABLE GUARDS IN THE LATERAL CONTROL SYSTEM	747-71A2277 R 1,2,3
US	2000-01-05	INAVERTENT DEPLOYMENT OF THRUST REVERSER IN FLIGHT	/4/-2/A2364
747	233B ( 74	7 200 SERIES )	
747	238B ( 74	7 200 SERIES )	
7.47	400 SERVES		
0.5	<b>400 SERIES</b> CF-96-04	CORDOCTON PREMERTAL CONTROL	
US	89-04-05	CORROSION PREVENTION & CONTROL PROGRAMS	747 50 044007
US	89-05-04R1	NOSE GEAR WHEEL WELL AFM CHANGES - LANDING FLAPS	747-53-211287
US	89-06-03	HOSE ASSEMBLIES	747-37A2229R7
US	89-08-03R1	INSPECT BODY CREASE BEAM	747-53-2297
US	89-08-09		747-76A2074
US	89-12-07	LITAIO CALLETIA	
US	89-15-02	STABILIZER MOUNTING BRACKETS	747-27-2228R1
US	89-15-07	WING LANDING GEAR	141-51-2244KI
US	89-16-07	OUTBOARD STRUT SEAL	747-54A2129
US	89-19-07	THRUST CONTROL CABLES  OXYGEN GENERATOR ASSEMBLY	747-76A2O71R1
US	89-21-03 89-21-05	AFM CHANGES - MESSAGES	747-35A2065 M-7201-89-1141
US	89-21-09	TAISDECT FLIGHT AGE CIVIA	747 50 00000
US	89-23-07	STEEL BOLTS	747-51-2043 R5
US	89-23-19	STEEL BOLTS HORIZONTAL STABILIZER FASTENERS OVERHEAD STOWAGE BINS	747-53A2314
US	90-02-02	OVERHEAD STOWAGE BINS	747-53A2320R1
US	90-03-12	CONTROL CABLE BLOCK PLATES	747-25-2776
US	90-04-01	AFM CHANGES - APU	747-26-2135R1
US	90-06-06	FLAP TRACKS	747-57A2229R8
US	90-06-12		747-53-2299R1
US US	90-06-14R1	NOSE WHEEL WELL	747-53-2293 R6
US	90-06-18R1 90-09-06	WING LANDING GEAR CARGO DOORS	747-52A22O6R3/R4/R5
US	90-09-09	PRESSURE BULKHEAD CHORD	747-53-2064R4
US	90-10-03	ENTRY DOOR ROD-END BEARINGS	747-52A2217
US	90-11-02	APU FIREWALL	747-53A2317
US	90-11-06	FUEL VALVE BUNDING WIRE	141-20A2140
US	90-11-11	OXYGEN MODULE	747-35A2067
US	90-13-05	AFM CHANGES - BLEED RELIEF VALVES CRACKS / CORROSION IN FUSELAGE SKINS	747-35A2061
US US	90-15-06 90-15-51	NOSE WHEEL WELL BEAMS	747-53A2338
US	90-17-07	PSU RAILS	747-25-2853
US	90-17-19	FLAPS CARRIAGE SPINDLES	747-27-2280R3
US	90-19-05	STOWAGE BIN ESCAPE STRAP	747-25A2847
US	90-20-10	FLAP TRACK STRAPS	747-57-2187R4
US	90-20-20	THOUGHT DITTO! DEFINITE DITTO!	747-54-2123
US	90-21-09	CROSSOVER PNEUMATIC DUCTS	747-36-2078R2 747-29-2051R1
US	90-21-13	111011111111111111111111111111111111111	747-25-2031K1
US US	90-21-17	INSPECT FUSELAGE SKIN STRUT PNEUMATIC DUCT BRACKETS	747-SL-54-32
US	90-21-21 90-23-14		747-53-2253R2
US	90-23-16	GEAR SELECTOR VALVE	747-32-2361
US	90-24-09	FLAP TRACKS	747-57-2231R2
US	90-25-05	CORROSION CONTROL PROGRAM	D6-36022RA
US	90-25-08	CARGO COMPARTMENT LINER	-45 of 4005004
US	90-25-10	ELEVATOR CONTROL INSPECTION	747-27A2253R4
US	90-26-02	CARGO FIRE PROTECTION	747-26A2170 747-29A2063R5
US	90-26-04	ELEVATOR CONTROL SYSTEM PREVENT FAILURE OF FIRE DET WARNING SYSTEM	747-26A2171
US	90-26-08	FUSELAGE INSPECTION	747-53A2321 REV5
US US	90-26-10 90-26-54	ERROR IN LOGIC WIRING FOR T/REV AND FLAP CONT	
US	91-03-04	FLIGHT MANAGEMENT SYSTEM PLACARDS	
US	91-03-13	VERIFY APPLICATION OF FUEL TANK BARRIER	747-57-2253R1
US	91-03-16	PREVENT SMOKING MATERIAL DROPPING BEHIND WALL	747-25A2862
US	91-03-17	PREVENT FLAP TRACK FAILURES	747-57-2256 R2
US	91-05-01	PREVENT INADVERTENT AUTOPILOT DISCONNECT	120-28C 747-26-2138R1/2141R1
US	91-05-04	FIRE EXTINGUISHING WIRING HORIZONTAL STABILIZER - FUS STN 2598 BULKHEAD WEB	
US	91-05-17	HUNTZUNTAL STABILIZER - FOS STN 2550 BOLKHEAD WED	
20	JANUARY/JANVIER 2000		AIRCRAFT/AERONEFS

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

CIMOM	t Homeno de Contione	50001	BOLLETIN DE SENVICE DE REF.
BOEING			
747 4	400 SERIES		
(CONTI	NUED / SUITE)		
US	91-05-19	ELIMINATE POTENTIAL OF AN ENGINE FUEL FIRE	747-36A2O97 R2
US	NUED / SUITE) 91-05-19 91-06-03	PREVENT CABIN PRESSURE LOSS	
US	91-06-08	PREVENT DAMAGE TO WING PANELS AND WIRING PREVENT FAILURE OF EFIS CONTROL PANEL	747-36A2O74R4
US	91-06-17	PREVENT FAILURE OF EFIS CONTROL PANEL	DCP-7000-31-04
US	91-09-11	DRAIN MAST SHIELDES	747-38A2Q77
US	91-11-01	FORWARD FUSELAGE STRUCTURE	747-53A2265R8
US	91-11-01 91-12-03	DISCHARGE OF FIRE EXTINGUISHING AGENT	747-26A218O
US	91-12-08	COLLINS DME	
US	91-13-10R1	OVERSPEED OR UNCOMMANDED SHUTDOWN OF AN ENGINE	747-31-2151
US		PROTECTIVE SLEEVE ON WIRE BREAKOUT AND OXYGEN LINE	747-35-2059 PEV 2
US	91-13-11 91-14-23 91-15-24	DOOD E CREAM DEST STATION	747 22 2200 04
	91-15-24	AUXILIARY POWER UNIT PNEUMATIC DUCTS	747 35 2206 KT
US	91-18-04	FUSELAGE FRAMES	747-53-2302
US	91-18-05	REROUTING AND ADDING SHIELDED WIRING - PG PANEL	
US	91-21-12	RADIO CONTROL PANELS	141-24-2154
US	91-22-05		745 05 0504
US	01-22-05	OVERHEAD STOWAGE BINS	141-25-2134
	91-23-09	TERMILAL STRIPS	5159 REV F BAC
US	91-23-10	PREVENT OCCURENCE OF FIRE/SMOKE IN PASSENGER CABIN	
US	91-25-02	B F GOODRICH SINGLE-PIECE RAMP SLIDE	4A3416-25-233 BFG
US	91-25-02 91-26-05R1		747-23-2321
US	92-02-01	DOURSTOP SUPPORT FITTING NUMBER 5 MAIN ENTRY DOOR	
US	92-02-06	SUPPLEMENTAL OXYGEN TO FLIGHT CREW	747-35A2O75
US	92-02-13	DEPRESSION PANEL AND FLAPPER VALVE	747-21A2312, 2317
US	92-02-13 92-04-03	PASSENGER DXYGEN SYSTEM FLOW CONTROL UNITS	747-35-2074 R1
US	92-04-05	AUXILIARY POWER UNIT PNEUMATIC DUCT RESTRAINT	747-36A2087
US	92-06-01	FUEL TUBES - ENGINE STRUTS	747-28-2153 / 2154
US	92-06-03	EVFACUATION SYSTEM PACKBOARD AND COVER ASSEMBLIES	747-2542889
US	92-06-07	EMERGENCY DOOR POWER ASSIST SYSTEM	747-52A2237
US	92-08-12	CARGO COMPARTMENT / ENGINE FIRE PROTECTION	747-26-2168 R3
US	92-13-08 92-13-12		747-2042000
US	92-13-12	ESCAPE SLIDE/RAFTS LIFE RAFT MOORING LINE AND INFLATION RATE PREVENT INADEQUATE LEVELS OF FIRE AGENT ESCAPE SLIDES	25-232 REV 1 BEG
US	92-14-02	LIFE RAFT MOORING LINE AND INFLATION RATE	20 202,112 1 01 0
US	92-14-07	PREVENT INADEQUATE LEVELS OF FIRE AGENT	7/7-26/2170 D1 D2
US	92-16-08	ESCAPE SLIDES	747-25-2132
US	92-16-17	OFF WING ESCAPE RAMP & SLIDE	747-25-2951
	92-18-12	BRAKES - MAXIMUM WEAR LIMITS	
US	92-24-07	BODY STATION 860 AND 980 UPPER DECK FLOOR BEAMS	2602012-32-001R2 BEN
US	92-24-51	NACELLE STRUT MIDSPAR FUSE PINS	747-53-2327 R1
US	92-27-04	AGING AIRCRAFT	2063R9, A2155R1, 2168
US	92-27-12	WIRE BUNDLES	D6-35999
US	92-27-12	ENGINE STRUTS 2 AND 3	747 0410100 00
US	92-27-13 93-03-14	ENGINE STRUTS 2 AND 3 FORWARD AND AFT BOTTLE BORE FUSE PINS	747-24A2168 R3
US		FURWARD AND AFT BUTTLE BURE FUSE PINS	54-2066R2,2155,2168
	93-05-13	ELECTRICAL POWER FEEDER CONNECTOR AT ENG FIREWALL	
US	93-07-15	CLASS B CARGO COMPARTMENT	747-26-2227
US	93-08-12	FUSELAGE INTERNAL STRUCTURE	747-53-2349
US	93-09-01	FIRE EXTINGUISHER SYSTEM	747-26A2210
US	93-10-01	PORTAL LATCH PIN SUPPORT FITTINGS - CARGO DOOR	747-52-2186
	93-14-21	FULL PITOT HEAT AND TOTAL AIR TEMP IN GRND MODE	747-30A2069_REV 1
US	93-17-06	NO 1 STRUT IDLER PULLEY SUPPORT BRACKET ASSY	747-65A2083 R1 R2
US	93-17-07	NACELLE ATTACH FITTING	747-54A2152 REV 3
US	93-18-07	FIRE EXTINGUISHER DISCHARGE TUBES	747-26A2214 REV 3
US	94-01-15	FASCIA PANELS	747-25A3056
US	94-03-05	PASSENGER OXYGEN SYSTEM RESEVOIR MASK ASSEMBLIES	
US	94-09-13	DUCT COUPLINGS - WING LEADING EDGE	PUROLATOR -FSC-912
US	94-10-05	FORWARD LOWER ENGINE MOUNT BOLT	747-71A2269
US	94-12-04	LAP JOINTS	747-53-2367 R1
US	94-12-09	SKIN LAP JOINTS IN FUSELAGE UPPER LOBE	747-53-2307 R2
US	94-12-11	IN-FLIGHT FUEL LEAK	
US	94-13-06	RAPID DECOMPRESSION	747-53-2371
US	94-15-05	THRUST REVERSER SYSTEM	747-78A2113 R2
US	94-15-06	WING TO BODY FAIRING - LOWER LOBE LAP JOINTS	747-53A2312 OR R1
US	94-15-17	FUSELAGE LONGITUDINAL LAP JOINTS	747-53A2312 OR R1
US	94-15-18	DTR FOR EACH SSI IN BOEING D6-35022 REV D	
US	94-17-01	HIGH FREQUENCY CURRENT INSPECTION - LAP JOINTS	SSID D6-35022 REV D
US	94-17-09	BFGOODRICH EVACUATION RAMP/SLIDES	747-53A2267 OR REV 3
US	94-17-17		7A1418-25-253
US	94-20-11	INBD & OUTBD STRUT FWD SPAR CHORDS, STIFFENERS	747-54-2160 REV 1
US	94-22-08	PREVENT DEPLOYMENT THRUST REVERSER IN FLIGHT	747-78A2128 R1
US		PYLON SKIN	747-54-2091R5
US	95-02-07 95-04-08	STRUT DRAINAGE AREA	747-28-2160 REV 1
US		BFGOODRICH STRETCHER UPPER DECK EVACUATION SLIDES	7A1323-25-266 REV 1
	95-10-16	NACELLE STRUT AND WING STRUCTURE	747-54A2195R1
US	95-11-03	POTABLE WATER TANK	747-38A2103

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

			DOLLETIN DE CENTICE DE NET.
POETAL	C		
BOEIN			
	400 SERIES		
(CONT	INUED / SUITE)		
US	95-12-27	FLAP OPERATIONS	- Lagrange
US	95-13-05	NACELE CIDITA AND MINE CIDITAL	747-27A2346 R2
US	95-13-06	NACELLE STRUT AND WING STRUCTURE	747-54A2157
US	0F 40 07	NACELLE STRUT AND WING STRUCTURE	747-54A2156 R2
	95-13-07	NACELLE STRUT AND WING STRUCTURE	747-54A2158
US	95-16-02	REVERSIBLE GEARBOX PNEUMATIC DRIVE UNIT (PDU)	747-78A2131
US	96-03-14	ENGINE FUEL SHUTOFF VALVE	747-28A2130
US	96-06-06	AUTOLAND SYSTEM	
US	96-07-09	AIRPLANE FUEL SYSTEM	747-22A2213 R2
US	96-08-05	CIDIT FUEL TOPE	
US	96-11-03	STRUT FUEL TUBES AND COUPLINGS	747-28A2185 R1
		FUEL LINE IN 1 & 4 ENGINE STRUTS	747-35A2O97 R3
US	96-15-08	NO 5 DOOR EVACUATION SLIDE/RAFT DEPLOYMENT	747-25A3096
US	96-22-01	ELEVATOR SERVO ASSEMBLIES	747-27A2348 REV 1
US	96-23-02	DISBONDING AND CRACKING OF SKIN PANELS	747-53A2409, 53-2272
US	96-23-05 96-24-03	CORROSION ON GIRT BAR SUPPORT FITTINGG	747-53A2378 REV 1
US	96-24-03	DECOMPRESSION ("BLOW-OUT") PANELS	
US	96-26-04		747-25A3064
		NWW PRESSURE BULKHEAD	
US	96-26-06	BOOSTER PUMPS	747-28A22O4
US	96-26-52R1	ENGINE PYLON	747-54A2157
US	97-03-17	FUEL PUMP WIRING	747-28A2194 R1
US	97-05-01	EDDY CURRENT(HFEC)FRONT SPAR WEB CENTER WING	747-57A2298R1
US	97-09-13	FATIGUE CRACKING UPPER DECK FLOOR BEAM STN 980	747-53A2400
US	97-12-03	PYLON MIDSPAR FITTINGS	
US			747-54-2118R1
	97-14-06	CORROSION OR CRACKING OF FUSE PINS	747-52A2166 R1
US	97-20-01R1	ENGINE PYLON LOWER SPAR FITTING LUG	747-54-2062 R8
US	97-25-06	SCAVENGE PUMP	747-28A2206
US	97-26-07	TEFLON SLEEVING AND WIRE BUNDLES	747-28A22O4 R1
US	98-02-02	FORWARD ENGINE MOUNT	747-54A2069R9
US	98-03-10	PILOTS SEATS AND SEAT LOCKS	747-25-3132
US	98-06-29		
		GALLEY POWER FEEDER AND STATIC GROUND WIRING	747-25A3137
US	98-07-15	CRACKS OF THE SKIN AND INTERNAL DOUBLERS STA 460	747-53A2396 R1
US	98-08-23	ENGINE FLAMEOUT DUE TO JP-4/JET B FUEL	747-11A2O52
US	98-09-29	APU BATTERY GROUND	747-24A2214
US	98-10-10	ELECTRICAL WIRING IN FUEL TANKS	747-28A22O4
US	98-13-12R1		747-27A2368
US	98-14-17	SCAVENGE PUMP	747-28A2215
		CODIADO AND ACT TAINED CHODOS OF DS OFOR DILLICITAD	
US	98-16-13	FORWARD AND AFT INNER CHORDS OF BS 2598 BULKHEAD CENTER TANK OVERIDE/JETTISON FUEL PUMPS	747-53A2423
US	98-16-19	CENTER TANK OVERIDE/JETTISON FUEL PUMPS	747-28A2212 REV 2
US	98-17-13	ENGINE FIRE DETECTION SYSTEM	747-26A2250
US	98-18-23	CARGO DOOR - ALUMINUM LATCH SUPPORT FITTINGS	747-53A2377R2
US	98-20-20	AFT PRESSURE BULKHEAD	747-53-2275 R1 TO R4
US	98-21-17	MAIN LANDING GEAR SPRING BEAM	747-52A2171 R1
US	98-21-29	FUEL SHUTOFF VALVE PART NUMBERS	747-28A2199
		LEADING EDGE FLAPS	747-27A2356 R1
US	98-24-26		141-21A2356 KI
US	98-25-52	OVERRIDE/JETTISON FUEL PUMPS	
US	98-26-13	MAIN ENTRY DOOR STOP SUPPORT FITTINGS	747-53-2358
US	98-26-23	REAR SPAR WEB CENTER WING AREA	747-57-2263 R1
US	99-01-10	ENGINE STRUT DIAGONAL BRACE LUGS	747-54-2126
	99-04-01	CIDIT CVIN AND SPRING REAM FITTINGS	747-54A2172
US	99-05-02	OUTBOARD SEQUENCE CARRIAGE FITTING WING FOREFLAP	747-57A2302
		NUMBER 1 AND 4 NACELLE STRUTS	747-54A2184
US	99-05-06		ASB 747-21A2381
US	99-06-18	CABIN PRESSURIZATION	
US	99-07-03	MAIN DOOR EDGE FRAME WEB & DOUBLER FATIGUE CRACKS	747-53A2414
US	99-07-12	LOWER LOBE FUSELAGE FRAMES	747-53A2408
US	99-08-01	2 AND 3 ENGINE UPPER LINK ASSEMBLY	747-54A2187
US	99-08-02R1	CENTRE FUEL TANK INSPECTION	747-28A2210
US	99-08-10	LAVATORY DRAIN SYSTEM	
	99-08-10	APU FUEL BOOST PUMP ELECTRICAL MOTOR	747-28A2209 R1
US		NACELE CIDIT DIOGNAL PRACE CIEF FITTINGS	
US	99-09-11	NACELLE STRUT DIOGNAL BRACE STEEL FITTINGS	747-54-2155 R2
US	99-10-10	FUSE PINS	
US	99-10-14	ILS RECEIVERS	RIA-35B-34-6 R3
US	99-11-12	ENGINE THRUST LINKS	747-71A2283
US	99-11-15	AILERION CABLE FRAYING	747-27-2367R1
US	99-14-04	SATCOM RACK AND FUSE SUPPORT STRUCTURE	747-53A2428
		RUDDER PEDAL COVER	747-27A2378
US	99-16-08	SATCOM RACK AND FUSE SUPPORT STRUCTURE	
US	99-16-10	SAICUM RACK AND FUSE SUPPORT STRUCTURE	747-0542140 01
US	99-18-07	CEILING PANEL LATCH ASSEMBLIES	747-25A3142 R1
US	99-18-16	TO DETECT AND CORRECT FAILURE OF THE MAWEA OR WEU	747-31-2288 & REVI
US	99-20-09	TANGENTIAL LINK UPPER BOLT NUT ENG MOUNT	747-71A2277 R 1,2,3
US	99-22-09	CONTROL CABLES DEFLECTION OR INTERFERENCE	747-53A2430
		CABLE GUARDS IN THE LATERAL CONTROL SYSTEM	747-27A2364
US	99-24-16	THRUST REVERSER DEACTIVATION PINS	747-78A2165 R1
US	99-26-02	TINGST REVENSER DEAGTIVATION TING	

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

	INC. NOWIERO DE CONSTONE		_							
BOEII	v.c.									
1	4F6	( 7	747	400	SERI	ES	)			
	*** 0	` '								
747	433	( 7	747	400	SERI	ES	)			
1	,,,,	` '					•			
747	475	( 7	747	400	SERI	ES	)			
	95-02-13			DISTE	RIBUT1	ON	FIRE	E EXTINGUISHER AGENT		747-26A2226
757	200 SERIES									
US	83-15-05R2			FUEL	EXHAL	JSTI	ON			757-28A7
US	83-21-04							SEMBLIES		757-21-9/13/51R1
ÜS	84-14-51R1			AFM E	MER.	PRC	CEDL	JRE - GEAR LEVER		757-32-0033
US	85-07-02				BLOW					757-A0036R1
US	85-11-03				JATION			S		757-25-0040
US	85-12-08				ORY D			JCTS		757-38-0008
US	85-19-01			ROSEN	MOUNT	AOA	SEN	NSORS		757-34A0026
US	85-23-02			NO.4	DOOR	INS	PECT	TION		757-52A0017
US	85-25-05			SELF-	-LOCK I	NG	NUTS	S INSP.		757-27-0069
US	86-02-02			CARGO	COMP	ART	MENT	T BLOWOUT PANEL ASSEMBLI	ES	757-25-0047R1
US	86-05-06			ELEVA	TOR C	CONT	ROL	FORWARD OVERRIDE ASSEMB	LY CAM	757-27-0057R1
US	86-07-09R1			CARGO	COMP	ART	MENT	T SMOKE DETECTORS		2156204-26-01
US	86-07-11			PASSE	NGER	DOC	RS			757-52A0019
US	86-09-09			SLIDE	PACK	RE	LEAS	SE CABLE ASSEM.		757-25A0058
US	86-17-04							S - CATEGORY II		757-52A0019 757-25A0058 757-SL-27-24-B
US	86-19-03							ISHER DISCHARGE OUTLETS		757-26A0010
US	86-26-03							VALVES & PROX. SENSORS		757-7840006
US	87-01-01							CIRCUIT BREAKER		757-24A0032
US	87-07-06							MERGENCY RESERVOIRS		757-52A0022
US	87-08-04				MAL BL					757-78-0010
US	87-08-09			NITRO	GEN I	NFL	ATIC	DN A / C TIRES		
US	87-15-02			WEATH	IER RA	DAR	CAE	BLE		757-34A0042
US	87-24-08			HYDRA	ULIC	SYS	TEM			757-29A0035R1
US	88-01-03				ROYC					757-71A0026R1
UŞ	88-01-13			RAM A	IR TU	RBI	NE V	WIRING		757-29A0032
US	88-06-04			VERTI	CAL F	IN	& HC	ORIZONTAL STABILIZERS		757-53-0038
US	88-07-02				R ELC					
US	88-12-07			AILER	SON CC	NTR	OL S	SYSTEMS		757-27-0079R1
US	88-21-03R1			AFM C	CHANGE	S ~	FUE	EL CROSSFEED VALVE ION SYSTEM		
US	88-22-10			DUCT	LEAK	DET	ECT I	ION SYSTEM		757-26-0016
US	89-02-02			AINI 13	N TD A	ALV	E IAIC	JUULE		131-32A0061
US	89-03-05							ONTROL ACTUATOR		757-27A0086
US	89-03-10							MMAND UNITS		757-27-0076
US	89-03-51							OMPARTMENTS FIRE PROTECT		
US	89-13-04							ATION WARNING SYSTEM (TC	WS)	757-27A0063R1
US	89-13-08							ALVE ACTUATION SHAFT		757-32-0083
US	89-14-06							_ VALVE ACTUATORS		757-28A0018
US	89-15-04				RESSU					757-28A0018 757-79-0005
US	89-19-06				E SLI			KAFIS		105-25-28R2/29
US	89-22-13							CABLES		757-76-0006
US	89-23-02							GROUND CHECKOUT MODULE		757-29A0037R1
US	89-26-06R1			PREVE	NI FA	TLU	KL C	OF OXYGEN GENERATOR FOR POWER CONTROL ACTUATO	anc.	757-35A0006R1
US	89-26-12									757-SL-27-43
US	90-02-12							ASSEMBLY FLEXIBLE DEFLE	CIUKS	757-27-0072R1
US	90-11-10			DETEC	IND PL	LUC	r Or	ONTROL COMPUTER WING AND ENGINE ANTICE		FCC-701-22-10R2/16
US	90-12-04R1			PETEC	E PDC	LUK	L UI	CAPE SLIDE RELEASE		757-30A0013 R5,R6
US	90-12-11R1				I RAM					1211233-29-02 ARKWIN
US US	90-20-06 90-22-01							S VALVE FREEZING		757-28A0017R2
US	90-23-06							ON OF TRAILING EDGE WED	SES	757-28A0017R2 757-57A0038R6
US	90-23-06							F NUMBER 1 WINDOW HEAT S'		757-30-0015R2
	90-24-02									737 30 00 15K2
US	91-01-05							DOUBLE FLT ATTENDANT SEA		757-25-0061R2
US	91-02-01							C INTO ENGINE STRUT		757-29A0038R1
US	91-02-02							NECTION OF FIRE EX WIRI	NG	757-26-0020 R2
US	91-05-01							ENT AUTOPILOT DISCONNECT		
US	91-06-12							DOOR NO 4 LEFT AND RIGH		757-52A0049
US	91-07-01							OF EFIS DISPLAY		EFIP-701E-34-03
US	91-07-13							OF ALT GEAR EXTENTION SYS	STEM	757-29-0042
US	91-07-16							SYSTEMS, SMOKE OR FIRE	G , LI-1	757-24-0061
US	91-07-51							W DAMPER POGO ASSEMBLY		M-7272-91-1886
US	91-09-02							OF THRUST CONTROL CABLE		757-76-0008
US	91-12-03							EXTINGUISHING AGENT		757-26A0026/0027R1
US	91-12-15							OM ALL THREE HYDRAULIC S'	YSTEMS	757-29A0030 R3
US	91-14-21							OGE UPPER PANEL		757-57-0027 REV 1
US	91-18-17				DOOR					757-52-0052 R1
	DCDAET / AEDONEES									

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

US US	98-19-24 98-25-12		ESCAPE SLIDE SHELF ASSEMBLIES ACOUSTIC PANELS - ENGINE INLET FUEL FLOW FROM FUEL TANKS TO ENGINE NACELLE	757-25-0175 R1 RB211-71-B480 R1 757-28A0045 REV 1
US	98-19-05		STRUCTURAL CRACKS	757-57-0053 REV 1
US			RUDDER CONTROL SYSTEM CHAFING OF ELECTRICAL WIRE BUNDLES	757-27A0156
US US	98-03-20		CHAFING OF WIRE BUNDLES AT E1 RACK OF ELECT BAY	757-24A0025
US	97-18-05		MIDSPAR FUSE PINS PILOTS SEATS AND SEAT LOCKS	757-54A0019 R5 757-25-0183
US			MIDSPAR FUSE PINS	757-54A0020 R5
US	97-09-06		CHAFING OF THE TUBES OF THE FIRE EXTINGUISHING SYS BATTERY GROUND TERMINATIONS OF THE APU	757-26A0040
US	97-03-17		FATIGUE CRACKING OF LOWER SPAR CHORD CHAFING OF THE TUBES OF THE FIRE EXTINGUISHING SYS	757-54-0031 REV 2
US US			AUTOTHROTTLE FUEL PUMP WIRING	757-22A0052 757-28A0043 R1
US	96-19-17		MAIN BATTERY SHUNT	757-24A0079 REV 2
US US	96-07-09 96-09-07		AIRPLANE FUEL SYSTEM ABEX ELECTRO HYDRAULIC SERVO VALVES	
US	96-04-11R1		ENG RUNDDOWN DURING IDLE DESCENTS	MMEL
US	95-25-01		ENGINE FUEL SHUTOFF VALVE DOOR OPENING SYSTEM	757-76-1007 REV 2 757-52-0042R1
US	95-18-02		SUNDSTRAND RAM AIR TURBINE HYDRAULIC PUMP	757-29A0046
US US	95-10-13		FLAP TRACK STRUCTURE HYDRAULIC TUBING SUPPORT BRACKETS	757-27A0188 757-54A0030 R1
US	95-01-05		GROUND OPERATION DURING ICING CONDITIONS	
US	94-18-01	***************************************	COCKPIT WINDOWS	757-56-0007
US US	94-14-02		SYNC LOCK FEATURE ENGINE STRUT LOWER SPAR CORD	757-78-0035 757-54-0028
US	94-13-02R1		FLIGHT MANUAL COMPUTER DEPLOYMENT OF THRUST REVERSERS IN FLIGHT	757-78-0032 R2
US US			THRUST REVERSER	757-78A0027
US US			FIRE EXTINGUISHER SYSTEM FLAME OUT ENG START - STATIC INVERTER INSP	757-26A0032 757-24A0069 R1
US	93-07-15		CLASS B CARGO COMPARTMENT	757-26A0032
US US	93-05-08		DXYGEN MASKS REDUCED SENSIVITY TO THE SMOKE DETECTOR	757-35A0010 757-26A0028 R1
US	92-25-01		TE EDGE FLAP DRIVE TORQUE TUBE COUPLING SPLINES	757-SL-27-52R1
US	92-19-16		OVERHEAD STORAGE BIN ATTACHMENTS	757-27A0105 757-25A0121 R3
US	92-17-08		PASSENGED DOOD EMED ACCIET CUIDDONT DEADING	757-52-0055
US	92-17-04		SOFT BULKHEAD SUPPORT STRUCTURE AT BS 1640 BRAKES - MAXIMUM WEAR LIMITS	757-25A0112 REV 1 2-1457-32-13 OR R1
US			THRUST REVERSER - RESTRICTOR VALVE	757-78A0030
US	92-08-11		FLIGHT ATTENDS SEAT	757-57-0036 192 REV C TRANSAERC
US			SIDE-OF-BODY FLOOR PANELS FIXED INDOARD TRAILING EDGE UPPER PANEL	757-53A0060
US	92-01-06		FUEL CROSSFEED AND SHUTOFF VALVES	757-57A0045 R3 757-SL-28-8-A
	91-21-12 91-22-51		RADIO CONTROL PANELS WING LEADING EDGE SLAT T/E WEDGE INSPECTION	757-57A0045 R3

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

BOEING			
767 20	OO SERIES		
	NUED / SUITE)	FUEL EXHAUSTION	767-28A5
US US	83-15-05R2 83-19-06	ENGINE STALL CONDITIONS	767-73A7
US	83-21-04	OUTFLOW VALVE ASSEMBLIES SUPPORT FITTINGS INSPECTION	767-21-13/15R1
US	84-05-02	SUPPORT FITTINGS INSPECTION	767-53-2
US US	84-11-02R2 84-25-03 85-04-02 85-09-02	ENGINE FUEL FEED HOSE	767-73-11
US	84-25-03	RAT ACTUATOR MOTOR	767-29-17R2
US	85-04-02		767-28-14
US	85-09-02	PUEL BOOST PUMP PIVOT PINS  CARGO VENTILATION SYSTEM PRESSURE REGULATING/SHUTOFF VALVE WIRING AND TERMINALS	767-55-0005
US	85-13-02	CARGO VENTILATION SYSTEM	767-21-0041R1
US		PRESSURE REGULATING/SHUTOFF VALVE	36-2030
US	85-17-01 85-19-01 85-21-51 86-02-01		767-71A0019R3
US	85-19-01	ROSEMOUNT AOA SENSORS	767-34430
US	85-21-51	ROSEMOUNI ADA SENSORS AIRFRAME SELF-LOCKING NUTS ENTRY/SERVICE DOOR OPERATING MECHANISMS ENTRY/SERVICE DOOR COUNTERBALANCE GEARBOX PICO EMERGENCY EVACUATION SLIDES CARGO COMPARTMENT SMOKE DETECTORS SLIDE/RAFT PACKBOARD	767-52-0041
US	00 02 01	ENTRY/SERVICE DOOR OPERATING MECHANISMS	767-52-0041
US	86-04-08	ENTRY/SERVICE DOOR COUNTERBALANCE GEARDON	101623/30/51/54/
US	86-06-06	PICU EMERGENCY EVACUATION SLIDES	2156204-26-01
US	86-07-09R1 86-07-10	CLIDE PACT BACKBOARD	767-25-40071
US	86-07-10	STIDE/KAFT PACKBUAKD	767-26A0019/21
US	8h-19-03	HTL FIRE EXTINGUISHER DISCHARGE OUTLETS VERTICAL FIN - AFT PRESSURE BULKHEAD	767-52-0042RA
US	86-19-07	ENTRY/SERVICE DOOR ROLLERS	767-52-0032
US	96-25-02	FLIGHT CONTROL QUADRANTS	767-27A0062
US US	86-22-11 86-25-02 87-03-07 87-04-22	ENTRY/SERVICE DOOR ROLLERS FLIGHT CONTROL QUADRANTS AFM - BRAKING INFORMATION ENGINE STRUT RACEWAY	D6T11320/21
US	97-04-22	ENGINE STRUT RACEWAY	767-54A0024
US	87-08-09	ENGINE STRUT RACEWAY NITROGEN INFLATION A / C TIRES	
US	87-10-02	ELAD DOTTE VADOD CEALS	767-27A0074
us	87-17-02	AUXILIARY POWER UNIT	767-24A0039
US	87-18-05R1	ENGINE STRUT BRACKETS	767-29-0032
US	87-24-09 87-25-09 88-04-09 88-07-02	AUXILIARY POWER UNIT ENGINE STRUT BRACKETS WEATHER RADAR RECEIVER - TRANSMITTER ENTRY/SERVICE DOOR - MID LINER DUST COVER PNEUMATIC SYSTEM 8TH STAGE CHECK VALVE	767-34A0055R1/2286
US	87-25-09	ENTRY/SERVICE DOOR - MID LINER DUST COVER	767-25A0092
US	88-04-09	PNEUMATIC SYSTEM 8TH STAGE CHECK VALVE	767-36-0021
US	88-07-02	ELECTRONIC ENGINE CONTROL SWITCHES  VERTICAL FIN / AFT PRESSURE BULKHEAD  CARGO COMPARTMENT-FIRE EXTINGUISHANT SYSTEM	
0.5	88-12-06	VERTICAL FIN / AFT PRESSURE BULKHEAD	767-53-0025
US	88-13-04	CARGO COMPARTMENT-FIRE EXTINGUISHANI SYSTEM	767-26A0036
US	88-15-04 88-19-03R1	MAIN LANDING GEAR AFT PRESSURE BULKHEAD - BS 1582	767-32A0071 REV 2
US	88-19-03R1	AFT PRESSURE BULKHEAU - BS 1382	767-5440027,-28
US	88-19-05 88-21-03R1 89-03-51 89-07-10	ENGINE FIREWALL AFM CHANGES - FUEL CROSSFEED VALVE	767-28-0034R2
US	88-21-03R1	ENGINE & CARGO COMPARTMENTS FIRE PROTECTION SYSTEM	767-26-0045 R2
US US	89-03-51	OFF-WING ESCAPE SLIDE	767-25A0104R1
US	89-07-10	OFF-WING ESCAPE SLIDE MOTOR DRIVEN FUEL VALVE ACTUATORS UPPER DOOR LINER PIVOT BOLTS	767-28A0020
US	89-14-06 89-16-11 89-19-03 89-21-04R1	UPPER DOOR LINER PIVOT BOLTS	767-25A0109R1
US	89-19-03	MOUNTING BOLTS - FLIGHT ATTENDANT SEAT	767-25A0135
US	89-21-04R1	MOD - FLECTRICAL/FLECTRONIC ENGINE CONTROL WIRING	767-71-0041R2
ÜS	89-23-02 89-24-05 89-26-01 89-26-06R1	RAM AIR TURBINE GROUND CHECKOUT MODULE	767-29A0035R1
US	89-24-05	PILOT'S CONTROL WHEEL	767-31A0029
US	89-26-01	BRAKE METERING VALVE MODULE SHAFTS PREVENT FAILURE OF DXYGEN GENERATOR	767-32-0081 R1
US	89-26-06R1	PREVENT FAILURE OF OXYGEN GENERATOR	767-35A0014R1
US	90-01-03	EMERGENCY EVACOATION SEIDE MEGNATURE	767-25-0123
US	90-01-09	8TH STAGE BLEED SYSTEM CHECK VALVE	767-36A0030
US	90-01-09 90-05-05 90-08-13	KIDDE ENGINE FIRE & OVERHEAT DETECTION SYSTEM	767-26-0037 R3
US	90-08-13	VENTILATION FAN WIRE BUNDLE REROUTING RH & LH LEADING EDGE SLAT DRIVE SHAFT COUPLING	767-21A0074R1 767-27A0095 R5
US	90-09-51 90-10-07 90-10-09 90-11-10	RH & LH LEADING EDGE SLAT DRIVE SHAFT COUPLING	767~27~0095 R5
US	90-10-07	PREVENT UNCOMMMANDED EXTENTION OF SPOILERS	
US	90-10-09	ENSURE PROPER OPERATION OF OXYGEN GENERATOR COLLINS FLIGHT CONTROL COMPUTER	FCC-701-22-10 R2
US	90-11-10	8TH STAGE BLEED AIR SYS CHECK VALVE	36-2078R1 HAM STAND
0.5	90-12-02	PROVIDE RELIBILITY OF EVACUATION SYSTEM	767-25A0131R1/
US US	90-15-05 90-17-08	WING/ENGINE THERMAL ANTI ICE SYSTEM	767-30A0011 R6
US	90-17-08	PREVENT LOSS OF STABILIZER TRIM	767-29A0039 R4
US	90-18-05	PREVENT FAILURE OF VERTICAL STABILIZER	767-55A0007
US	90-22-04	MODIFICATION OF ESCAPE SLIDES	25-212 BFG
US	90-22-07	PREVENT ENGINE FIRE AND OIL LOSS	767-71A0057
US	90-25-08	PREVENT CARGO COMPARTMENT FIRE FROM MIGRATING	767-25-0193
US	90-26-02	CARGO FIRE PROTECTION	767-26A0068R1
US	90-26-51	FAILURE OF L/E SLAT TORQUE TUBE FITTING	767-27A0110
US	91-02-03	PREVENT FIRES CAUSED BY CHAFING OF WIRES	767-29A0054
US	91-05-01	PREVENT INADVERTANT AUTOPILOT DISCONNECTION	808 80 800
US	91-09-15	ENGINE OIL FILTER DIFFERENTIAL PRESSURE SWITCH	767-79-0008 R1
US	91-10-09	OVER PRESSURIZATION OF VERTICAL STABILIZER	767-55A0007 767-26A0075/0076
US			
us	91-12-03 91-12-16	DISCHARGE OF FIRE EXTINGUISHING AGENT LOSS OF FLUID FROM LEFT HYDRAULIC SYSTEM	767-29A0038 R1

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

			BULLETIN DE SERVICE DE REF.
BOEING			
767 2	OO SERIES		
(CONTIN	NUED / SUITE)		
US	91-13-10R1	OVERSPEED OR UNCOMMANDED SHUTDOWN OF AN ENGINE CENTER WING FUEL TANK OVERRIDE FUEL PUMP	767-31-0038
UŞ	91-15-11	CENTER WING FUEL TANK OVERRIDE FUEL PUMP	767-28A0036 REV 1
US	91-17-51	THRUST REVERSER SYSTEM BRAKES - MAXIMUM WEAR LINITS LEADING EDGE SLATS THRUST REVERSED - FAIL SAFE FEATURE	707 2040000 112 1
US		BRAKES - MAXIMUM WEAR LINITS	
US	91-21-10 91-22-02 92-02-12	LEADING EDGE SLATS	767-27A0095 R1,2,3
US	91-22-02		767-78-0047 R3
US	92-02-12	REMOVAL BULK CARGO VENTILATION FLAPPER VALVE	767-21A0098 R2
US	92-07-12 92-07-13	OFF WING ESCAPE SLIDE	767-25-0137 R3
	92-08-05	ESCAPE SYSTEM - GIRT BAR LOCKS AFT GALLEY TIE RODS	767-52A0061 R1
US	92-10-01	INBOARD EDGES OF RUB STRIP ON INBOARD SPOILERS	767-25-0160 OR REV 1
US	92-16-02	INBOARD EDGES OF RUB STRIP ON INBOARD SPOILERS WING-BODY & WING STRUT DISCONNECTS INBOARD LEADING EDGE SLAT POWER DRIVE UNIT	767-27-0104 R2 767-87A0052 R2
US	92-16-10	INBOARD LEADING EDGE SLAT POWER DRIVE UNIT	767-29A0064
US	92-16-16	FLAPS/STABILIZER POSITION MODULE	767-27A0118 R1
US	92-17-03	WING REAR SPAR	767-57A0038 R2
US	93-01-19	ENTRY/SERVICE DOORS - COUNTERBALANCE SPRING	767-52A0053 R2
US	93-05-08	REDUCED SENSIVITY TO THE SMOKE DETECTOR	767-26A0081
US	93-05-13	ELECTRICAL POWER FEEDER CONNECTOR AT ENG FIREWALL	767-24A0088
US	93-09-01	FIRE EXTINGUISHER SYSTEM	767-26A0089
US	93-13-01	FLAME OUT ENG START - STATIC INVERTER INSP	767-24A0085
US	93-14-11 93-14-19		767-36A0041 REV 4
US US	93-14-19	TRAILING EDGE WEDGES OF LEADING EDGE SLATS	767-57A0039 R2
US	93-19-05 94-01-02	SHOTOFF/ DYPASS VALVES - LEADING/ TRAILING EDGE FLPS	767-27A0094 R4
US	94-03-07	RAM AIR TURBINE WIRING CARBON BRAKES	767-29-0021
US	94-10-08	ENGINE BLEED AIR CROSSOVER DUCT	767-32A0116R1, 0132 767-36A0041 R4
US	94-10-08 94-11-02 94-11-05	MIDSPAR FUSE PIN	767-54A0062R3
US	94-11-05		767-28A0045 REV 2
US		FUEL TANK THRUST REVERSER FLOW RESTRICTOR	767-78-0064, 0065
US	94-15-03	IN-FLIGHT ENGINE FUEL LEAK	
US	94-14-01 94-15-03 94-16-03 94-16-05	CHK INTEGRITY FAIL SAFE OF THRUST REVERSERS	767-78-0054, 0061R3
US	94-16-05	BRAKE TORQUE ARM BUSHINGS	767-32-0128
US	94-17-03	THRUST REVERSER SYSTEM	767-78-0048 R1
US		COCKPIT WINDOWS	767-56-0002
US	95-08-11	ESCAPE SLIDE	3092100-25-002 DEB
US	95-13-12R1	THRUST REVERSER SYSTEM	767-78-0047 R1,2,3
US	95-15-01	OVER-WING ESCAPE SLIDES BFGOODRICH OFF-WING RAMP/SLIDES	767-57-0043 R3
US	95-18-03	MAIN LANDING GEAR OUTER CYLINDER AFT TRUNNION	767-25-0218 767-SL-32-067
US US	95-19-10 95-20-51	MAIN LANDING GEAR DOTER CYLINDER AFT TRUNNION MAIN LANDING GEAR - OUTER CYLINDER AFT TRUNNION	767-32-067 767-3340151 DEV 1
US	95-20-51	TRAILING EDGE FLAP DRIVE	767-27-0138
US	96-06-09 96-07-09	AIRPLANE FUEL SYSTEM	707 27 0100
US	96-14-02		767-71A0082
US	96-14-05	FUEL NOZZLE SECONDARY TRANSFER TUBE CRACKS IN OUTBOARD WING LE SLAT RODS CHAFING AILERON CABLES & GENERATOR CABLES	767-57-0021 R1, 2, 5
US	96-14-51	CHAFING AILERON CABLES & GENERATOR CABLES	767-24A0113 R2
us	96-19-10	MAIN BATTERY SHUNT	767-24A-119 R2
US	96-20-05	RAT ACTUATOR MOTOR	767-29A0080
US	96-21-06	MAIN LANDING GEAR AFT TRUNNION OUTER CYLINDER	767-32A-151 REV1
US	96-25-18	OUTBOARD LEADING EDGE SLATS	767-27A0137
US	97-02-19 97-08-51	AUTOTHROTTLE	767-22A0097
US		OUTBOARD TRAILING EDGE FLAP	767-27A0151 R2
US	97-15-09	BATTERY GROUND TERMINATIONS OF THE APU	767-32A0157
US	97-16-03	MLG RETAINING BOLT	707-32AU137
US	97-19-15	CENTER TANK FUEL PUMP	767-25-0244
US	98-03-10	PILOTS SEATS AND SEAT LOCKS WIRE BUNDLES ABOVE PASSNEGER DOOR	767-33-0052 NSC -
US	98-07-13	WIRE BUNDLES ABOVE PASSNEGER DOOR WIRE BUNDLES ADJACENT FORWARD GALLEY AIR CHILLER	
US US	98-07-26	ENGINE FLAMEOUT DUE TO JP-4/JET B FUEL	767-11A0031
US	98-08-23 98-10-10	ELECTRICAL WIRING IN FUEL TANKS	
US	98-10-10 98-13-12R1	RUDDER CONTROL SYSTEM	767-27A0029
US	98-16-07	MLG FORWARD TRUNNION PINS	767-57A0047 REV 1
US	98-17-13	ENGINE FIRE DETECTION SYSTEM	767-26A0103
US	98-22-12	INBOARD TRAILING EDGE FLAP COLLAR FITTING	767~57A0066R1
US	98-23-05	WIRE CHAFING AT PILOT OXYGEN MASK STOWAGE	767-35A0028 0029 R1
US	99-07-06	NACELLE STRUT DIAGONAL BRACING CRACKS	767-54A0094
US	99-10-14	ILS RECEIVERS	RIA-35B-34-6 R3
US	99-11-14	VC FOR CORROSION AND CRACKING OF FUSE PINS	767-57A0054R2/R3
US	99-18-16	TO DETECT AND CORRECT FAILURE OF THE MAWEA OR WEU	747-31-2288 & REV1
US	99-19-29	TENSION BOLT INSPECTION	767-57A0064R1
US	99-21-18	THRUST REVERSER CONTROL CABLE	7657-76-0100 767-32A0185
US	99-24-02	NLG LOWER DRAG STRUT	767-78A0080
US	99-26-02	THRUST REVERSER DEACTIVATION PINS	70. 70,0000
			ATRCRAFT / AFRONEES

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT
SUBJECT

ORIGII	NE NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
BOEIN	IG			
767	200 SERIES			
(CONT	INUED / SUITE)			
US	99-26-09		PRIMARY THRUST LINKAGE	767-71A0087
US	99-27-05		BRAKE HOUSING	767-32-0152
05	33 27 03			
767	209	( 767	200 SERIES )	
//		\		
767	233	( 767	200 SERIES )	
101	200	( , , , ,	,	
767	275	( 767	200 SERIES )	
/0/	213	\/9/	200 JENZES /	
707	300 SERIES			
US	83-06-01		ICE SHIELDS INSTALLATION	767-30-2
US			CARGO DRAIN VALVE INSPECTION	767-51-1
	83-07-24		PASSENGER OR SERVICE DOORS	767-52A7R1
US	83-09-04			767-28A5
US	83-15-05R2		ENGINE STALL CONDITIONS	767-73A7
US	83-19-06		OUTFLOW VALVE ASSEMBLIES	
US	83-21-04		DAT ACTUATOR MOTOR	767-29-17R2
US	84-25-03		RAT ACTUATOR MOTOR	767-21-0041R1
US	85-13-02		PROCESS ATTAIC (SHITGES VALVE	36-2030
US	85-16-01		PRESSURE REGULATING/SHUTOFF VALVE	767-34430
US	85-19-01		A IDEDAMS SELS LOCKING MUTS	767-27A0064
US	85-21-51		AIRPRINE SELF-LUCKING NUTS	767-52-0044
US	86-02-01		PRESSURE REGULATING SHOTOFF VALVE ROSEMOUNT ADA SENSORS AIRFRAME SELF-LOCKING NUTS ENTRY/SERVICE DOOR OPERATING MECHANISM FNTRY/SFRVICE DOOR COUNTERBALANCE GEARBOX	767-52-0041
US	86-04-08		ENTRY/SERVICE DOOR COUNTERBALANCE GEARBUX	101602/20/54/54/
US	86-06-06		ENTRY/SERVICE DOOR OPERATING MECHANISM ENTRY/SERVICE DOOR COUNTERBALANCE GEARBOX PICO EMERGENCY EVACUATION SLIDES PARGO COMPARTMENT SMOKE DETECTOR SYSTEM	101623/30/51/54/
US	86-07-09R1		CARGO COM ARTIMENT CONSINE DE LEGICION CONTROL	
US	86-07-10		SLIDE/RAFT PACKBOARD	767-25-A0071
US	86-19-03		HTL FIRE EXTINGUISHER DISCHARGE OUTLETS VERTICAL FIN - AFT PRESSURE BULKHEAD	767-26A0019/21
US	86-19-07		VERTICAL FIN - AFT PRESSURE BULKHEAD	767-52-0042RA
US	86-22-11		ENTRY/SERVICE DOOR ROLLERS	767-52-0032
UŞ	86-25-02		FLIGHT CONTROL QUADRANTS	767-27A0062
US	87-04-22		ENGINE STRUT RACEWAY	767-54A0024
US	87-08-09		NITROGEN INFLATION A / C TIRES	
US	87-10-02		FLAP DRIVE VAPOR SEALS	767-27A0074
US	87-17-02		AUXILIARY POWER UNIT	767-2440039
US	87-18-05R1		ENGINE STRUT BRACKETS	767-29-0032
US	87-24-09		WEATHER RADAR RECEIVER - TRANSMITTER	767-34A0055R1/2286
US	87-25-09		ENTRY/SERVICE DOOR - MID LINER DUST COVER	767-25A0092
US	88-04-09		PNEUMATIC SYSTEM 8TH STAGE CHECK VALVE	767-36-0021
US	88-07-02		ELECTRONIC ENGINE CONTROL SWITCHES	
US	88-12-06		VERTICAL FIN / AFT PRESSURE BULKHEAD	767-53-0025
US	88-13-04		CARGO COMPARTMENT-FIRE EXTINGUISHANT SYSTEM	767-26A0036
US	88-15-04		MAIN LANDING GEAR	767-32A0071 REV 2
US	88-19-03R1		AFT PRESSURE BULKHEAD - BS 1582	767-53-0026R1
US	88-19-05		ENGINE FIREWALL	767-5440027,-28
US	88-21-03R1		AFM CHANGES - FUEL CROSSFEED VALVE	767-28-0034 R1
US	89-03-51		ENGINE & CARGO COMPARTMENTS FIRE PROTECTION SYSTEM	767-26-0045 R2
US	89-07-10		OFF-WING ESCAPE SLIDE	767-25A0104R1
US	89-14-06		MOTOR DRIVEN FUEL VALVE ACTUATORS	767-28A0020
US	89-16-11			767-25A0109R1
US	89-19-03		MOUNTING BOLTS - FLIGHT ATTENDANT SEAT	767-25A0135
US	89-21-04R1		MOD - ELECTRICAL/ELECTRONIC ENGINE CONTROL WIRING	767-71-0041R2
US	89-23-02		RAM AIR TURBINE GROUND CHECKOUT MODULE	767-29A0035R1
US	89-24-05		PILOT'S CONTROL WHEEL	767-31A0029
US	89-26-01		BRAKE METERING VALVE MODULE SHAFTS	767-32-0081 R1
US	89-26-06R1		PREVENT FAILURE OF OXYGEN GENERATOR	767-35A0014R1
US	90-01-05		EMERGENCY EVACUATION SLIDE MECHANISM	
US	90-01-09		8TH STAGE BLEED SYSTEM CHECK VALVE	767-36A0030
US	90-05-05		KIDDE ENGINE FIRE & OVERHEAT DETECTION SYSTEM	767-26-0037 R3
US	90-08-13		VENTILATION FAN WIRE BUNDLE REROUTING	767-21A0074R1
US	90-08-13		RH & LH LEADING EDGE SLAT DRIVE SHAFT COUPLING	767-27A0095 R5
US	90-09-51		PREVENT UNCOMNMANDED EXTENTION OF SPOILERS	767-27-0085R1
US			OXYGEN GENERATOR	767-35A0015
	90-10-09		COLLINS FLIGHT CONTROL COMPUTER	FCC-701-22-10 R2
US			8TH STAGE BLEED AIR SYS CHECK VALVE	36-2078R1 HAM STAND
US	90-12-02		PROVIDE RELIBILITY OF EVACUATION_SYSTEM	767-25A0131R1/
US	90-15-05			767-30A0011 R6
US	90-17-08		WING/ENGINE THERMAL ANTI ICE SYSTEM	767-29A0039 R4
US	90-18-04		PREVENT LOSS OF STABILIZER TRIM	
US	90-18-05		PREVENT FAILURE OF VERTICAL STABILIZER	767-55A0007
US	90-22-04		EVACUATION SYSTEM	25-212 BFG
US	90-22-07		DRAIN SYSTEM	767-71A0057
US	90-25-08		PREVENT CARGO COMPARTMENT FIRE FROM MIGRATING	767-25-0193
US	90-26-02		CARGO FIRE PROTECTION	767-26A0068R1

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

POFTMO			
BOEING			
767 3	OO SERIES		
(CONTI	NUED / SUITE)		
US	90-26-51	EATLUDE OF 176 CONTINUES AND DESCRIPTION OF THE PROPERTY OF TH	
US	91-02-03	FAILURE OF L/E SLAT TORQUE TUBE FITTING	767-27A0110
		PREVENT FIRES CAUSED BY CHAFING OF WIRES	767-29A0054
UŞ	91-05-01	PREVENT INADVERTANT AUTOPTION DISCONNECTION	
US	91-05-06	PRECLUDE CROSS CONNECTION OF FIRE EXTINGUISHERS	707 00 0045/40
US	91-10-09	OVER DESCRIPTION OF THE EXTINGUISHERS	767-26-0045/48
US	91-12-03	OVER PRESSURIZATION OF VERTICAL STABILIZER	767-55A0007
		DISCHARGE OF FIRE EXTINGUISHING AGENT	767-26A0075/0076
US	91-12-16	LOSS OF FLUID FROM LEFT HYDRAULIC SYSTEM	767-29A0038 R1
US	91-13-10R1	OVERSPEED OR UNCOMMANDED SHUTDOWN OF AN ENGINE	767-21-0029
US	91-15-11	CENTER WING FUEL TANK OVERRIDE FUEL PUMP	707 01 0000
US	91-17-51	THRUST REVERSER SYSTEM	767-28A0036 REV 1
US	91-18-10		
	91-18-10	BRAKES - MAXIMUM WEAR LINITS	
US	91-21-10	LEADING EDGE SLATS	767-27A0095 R1,2,3
US	91-22-02	THRUST REVERSER - FAIL SAFE FEATURE	767-78-0047 R3
US	92-02-12 92-07-12	REMOVAL BULK CARGO VENTILATION FLAPPER VALVE	
US	92-07-12	DEF WIND COARD VENTILATION PLAPPER VALVE	767-21A0098 R2
	92 07 12	OFF WING ESCAPE SLIDE	767-25-0137 R3
US	92-07-13	ESCAPE SYSTEM - GIRT BAR LOCKS	767-52A0061 R1
US	92-08-05	AFT GALLEY TIE RODS	767-25-0160 OR REV 1
US	92-10-01	INBOARD EDGES OF RUB STRIP ON INBOARD SPOILERS	767-27-0104 R2
US	92-16-02	WING-BODY & WING STRUT DISCONNECTS	
US	92-16-10	TARRADO A SARANG SIRUT DISCUNNECTS	767-87A0052 R2
US	32-16-10	INBOARD LEADING EDGE SLAT POWER DRIVE UNIT	767-29A0064
US	92-16-16	FLAPS/STABILIZER POSITION MODULE	767-27A0118 R1
US	92-17-03	WING REAR SPAR	767-57A0038 R2
US	93-01-19	ENTRY/SERVICE DOORS - COUNTERBALANCE SPRING	767-52A0053 R2
US	93-05-08	DEDICED SENSIVITY TO THE CHOICE DETECTOR	
110	00 05 00	REDUCED SENSIVITY TO THE SMOKE DETECTOR	767-26A0081
US	93-05-13	ELECTRICAL POWER FEEDER CONNECTOR AT ENG FIREWALL	
US	93-09-01	FIRE EXTINGUISHER SYSTEM	767-26A0089
US	93-13-01	FLAME OUT ENG START - STATIC INVERTER INSP	767-24A0085
US	93-14-11	ENGINE BLEED AIR CROSSOVER DUCTS	
			767-36A0041 REV 4
US	93-14-19	TRAILING EDGE WEDGES OF LEADING EDGE SLATS	767-57A0039 R2
US	93-19-05	SHUTOFF/BYPASS VALVES - LEADING/TRAILING EDGE FLPS	767-27A0094 R4
US	94-01-02	RAM AIR TURBINE WIRING	767~29-0021
US	94-03-07	CARBON BRAKES	767-32A0116R1, 0132
US	94-10-08	ENGINE BLEED AIR CROSSOVER DUCT	767-36A0041 R4
US	94-11-02	MIDSPAR FUSE PIN	
			767-54A0062R3
US	94-11-05	FUEL TANK	767-28A0045 REV 2
US	94-12-10	THRUST REVERSERS	767-78-0046 REV 1
US	94-14-01	THRUST REVERSER FLOW RESTRICTOR	767-78-0064, 0065
US	94-15-03	IN-FLIGHT ENGINE FUEL LEAK	
US	94-16-03	CHK INTEGRITY FAIL SAFE OF THRUST REVERSERS	767-78-0053, 0061R3
US	94-16-05		767-32-0128
		BRAKE TORQUE ARM BUSHINGS	767-78-0048 R1
US	94-17-03	THRUST REVERSER SYSTEM	
US	94-18-01	COCKPIT WINDOWS	767-56-0002
US	95-08-11	ESCAPE SLIDE	3092100-25-002 DEB
US	95-13-12R1	THRUST REVERSER SYSTEM	767-78-0047 R1,2,3
US	95-15-01	DVER-WING ESCAPE SLIDES	767-57-0043 R3
US	95-18-03	BFGOODRICH OFF-WING RAMP/SLIDES	767-25-0218
			767-SL-32-067
US	95-19-10	MAIN LANDING GEAR OUTER CYLINDER AFT TRUNNION	
US	95-20-51	MAIN LANDING GEAR - OUTER CYLINDER AFT TRUNNION	767-32A0151 RREV 12
US	96-06-09	TRAILING EDGE FLAP DRIVE	767-27-0138
US	96-07-09	AIRPLANE FUEL SYSTEM	
US	96-14-02	FUEL NOZZLE SECONDARY TRANSFER TUBE	767-71A0082
			767-57-0021 R1, 2, 5
US	96-14-05	CRACKS IN OUTBOARD WING LE SLAT RODS	
US	96-14-51	CHAFING AILERON CABLES & GENERATOR CABLES	767-24A0113 R2
US	96-19-10	MAIN BATTERY SHUNT	767-24A-119 R2
US	96-20-05	RAT ACTUATOR MOTOR	767-29A0080
		MAIN LANDING GEAR AFT TRUNNION OUTER CYLINDER	767-32A-151
US	96-21-06	OUTDOARD LEADING EDGE CLATC	767-27A0137
US	96-25-18	OUTBOARD LEADING EDGE SLATS	
US	97-02-19	AUTOTHROTTLE	767-22A0097
US	97-08-51	OUTBOARD TRAILING EDGE FLAP	767-27A0151 R2
US	97-15-09	BATTERY GROUND TERMINATIONS OF THE APU	
US	97-16-03	MLG RETAINING BOLT	767-32A0157
		CENTER TANK FUEL PUMP	
US	97-19-15		767-25-0244
US	98-03-10	PILOTS SEATS AND SEAT LOCKS	
US	98-07-13	WIRE BUNDLES ABOVE PASSNEGER DOOR	767-33-0052 NSC -
US	98-07-26	WIRE BUNDLES ADJACENT FORWARD GALLEY AIR CHILLER	
US	98-08-23	ENGINE FLAMEOUT DUE TO JP-4/JET B FUEL	767-11A0031
US	98-10-10	ELECTRICAL WIRING IN FUEL TANKS	
	00-13-1001	RUDDER CONTROL SYSTEM	767-27A0029
us	96-13-12K1	MIC EDDWARD TRINNITON DING	767-57A0047 REV 1
US	98-16-07	MLG FORWARD TRUNNION PINS	767-26A0103
US	98-17-13	ENGINE FIRE DETECTION SYSTEM	
US	98-23-05	WIRE CHAFING AT PILOT DXYGEN MASK STOWAGE	767-35A0028, 0029 R1
US	99-07-06	NACELLE STRUT DIAGONAL BRACING CRACKS	767-5440094

MAKE / CONS MODEL / MODEL / MO			SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
BOEING	NOMERO DE CONSTONE			
767 30	OO SERIES UED / SUITE) 99-10-14 99-11-14 99-18-16 99-19-29 99-21-18 99-24-02 99-26-02 99-26-09 99-27-05		ILS RECEIVERS VC FOR CORROSION AND CRACKING OF FUSE PINS TO DETECT AND CORRECT FAILURE OF THE MAWEA OR WEU TENSION BOLT INSPECTION THRUST REVERSER CONTROL CABLE NLG LOWER DRAG STRUT THRUST REVERSER DEACTIVATION PINS PRIMARY THRUST LINKAGE BRAKE HOUSING	RIA-35B-34-6 R3 767-57A0054R2/R3 757-31-0066 REV1 767-57A0064R1 7657-76-0100 767-32A0185 767-78A0080 767-71A0087
767 33	13	( 767	300 SERIES )	
767 37	75	( 767	300 SERIES )	
767 38	BE	( 767	300 SERIES )	
BV 107  CF  US  US  US  US  US  US  US  US  US  U	CF-98-15 63-13-05 63-24-04 64-06-07 64-21-06R2 66-13-05 72-16-10 73-08-01 74-17-02 76-25-03 80-11-08 80-25-08 83-07-06 87-11-05 88-12-09 88-14-03		HELICOPTER RESCUE SYSTEMS AFT ROTOR VERTICAL DRIVE AFT TRANSMISSION ASSEMBLIES SERIOUS LURCHING CONDITION ROTOR PITCH HOUSING FIRE DETECTION SYSTEM AFT TRANSMISSION COLLECTOR GEAR DETECT SURFACE DEFECTS - AFT QUILL SHAFT ROTOR BLADES ROTOR BLADE SPARS CYCLIC STICK BOOT TENSION TORSION STRAP ASSEMBLIES SYNCHRONIZING SHAFT COMPONENT FATIGUE FAILURE MAIN ROTOR SHAFT MAIN ROTOR HUB	CAR 702.21 107-3 R3 107-113A / 107-182 107-118 A107-317 107-329 107-334
BD 700				
<b>305</b> US US	68-05-02 76-08-06		TAIL ROTOR DRIVE SHAFT MAIN ROTOR HUB CLEVIS BEARING	
BREGUET 905 S FR	60-010-005 60-012-006 60-015-007 62-005-011 62-021-012 64-012-016 65-017-018 66-023-020		WING ATTACHMENT FRAME WING ATTACHMENT FRAME WING ATTACHMENT FRAME WING ATTACHMENT FRAME MODIFICATION REAR FUSELAGE BULKHEAD / AIRSPEED LIMITATIONS REAR SPAR AT FRAME #9 ELEVATOR BELLCRANK VERTICAL FINS - MOUNTING BRACKETS CONTROL QUICK DISCONNECTS	
BREWSTE 2	R FLEET			
## I STOLE  170  CF  UK  UK  UK  UK  UK  UK  UK  UK  UK  U	CF-55-O8 2857 PRE 80 2858 PRE 80 2859 PRE 80 2860 PRE 80 2861 PRE 80 2862 PRE 80 2863 PRE 80 2864 PRE 80 2865 PRE 80 2866 PRE 80 2867 PRE 80 2867 PRE 80 2868 PRE 80		WAIVER - MOD 1278  RUDDER MASS BALANCE WEIGHT AUTO PITCH COARSENING MICRO SWITCHES LINES AUTO PITCH COARSENING 19 AMP CABLE BATTERY CIRCUIT BREAKER CIRCUIT AILERON, ELEVATOR AND RUDDER TRIMMER SCREW JACKS GUARD ACCESSORY COOLING DUCTS INLET ANTI-FLUTTER MOUNTINGS/WHIP TYPE AERIALS OUTER WING FRONT SPAR FRONT SPAR FITTINGS/CENTRE PLANE CADMIUM PLATED CLOSE TOLERANCE BOLTS CENTRE PLANE OUTER WING SPAR WEB JOINTS	1033 1087 1120 1075 1097 1119 1160 1169 1172 1192 1235 1247

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

			BULLETIN DE SERVICE DE REF
BRISTOL			
170			
	UED / SUITE)		
UK	2869 PRE 80	AILERON CENTRE HINGE SUPPORT EMERGENCY LIGHTING PASSENGER COMPARTMENT PROVISION/ILLUMINATION PORT WING LEADING EDGE INTRODUCTION/ILLUMINATION PORT WING LEADING EDGE	1244
UK	2870 PRE 80	EMERGENCY LIGHTING PASSENGER COMPARTMENT	1278
UK	2871 PRE 80	PROVISION/ILLUMINATION PORT WING LEADING EDGE	1276
UK	2872 PRE 80	INTRODUCTION/ILLUMINATION PORT WING LEADING EDGE	1277
UK UK	2873 PRE 80 2874 PRE 80	BOLTS CENTRE PLANE AND OUTER WING JOINTS WEB DOUBLERS OUTER WING FRONT REAR MAIN SPAR WEBS WEB DOUBLERS CENTRE PLANE FRONT/REAR MAIN SPAR WEB CENTRE SECTION HINGED NOSE PORTION "ENGINE SPEED" LABEL	1294
UK	2875 PRE 80	WEB DOUBLERS DUTER WING FRONT REAR MAIN SPAR WEBS	1295
	2876 PRE 80	CENTRE SECTION HINGED NOSE PORTION	1297
UK	2877 PRE 80	"ENGINE SPEED" LABEL  "ENGINE SPEED" LABEL  OUTER WING FRONT SPAR  BOTTOM INBOARD NACELLE STRUCTURE BRACKET  AILERON "FOLLOW UP" TAB CONTROL ROD  FLASHING NAVIGATION LIGHTS  ICE GUARD WHIP AERIAL POSITIONS	1281
UK	2878 PRE 80	OUTER WING FRONT SPAR	1300
UK	2879 PRE 80	BOTTOM INBOARD NACELLE STRUCTURE BRACKET	1304
UK	2880 PRE 80	AILERON "FOLLOW UP" TAB CONTROL ROD	1305
UK UK	2881 PRE 80	FLASHING NAVIGATION LIGHTS  ICE GUARD WHIP AERIAL POSITIONS  CENTRE PLANE REAR SPAR BOTTOM BOOM OUTER WING REAR SPAR BOTTOM BOOM OUTER WING REAR SPAR	1309
UK	2882 PRE 80 2883 PRE 80	ICE GUARD WHIP AERIAL POSITIONS	1335
UK	2884 PRE 80	OUTER WING BEAR SPAR BUTTOM BOOM	1374
UK	2885 PRE 80	OUTER WING REAK SPAR BUTTUM BOUNT	1392
UK	2886 PRE 80	OUTER WING REAR SPAR	1303
UK	2887 PRE 80	CENTRE PLANE FRONT SPAR	1394
UK	2888 PRE 80	OUTER WING FRONT SPAR OUTER WING FRONT SPAR OUTER WING REAR SPAR CENTRE PLANE FRONT SPAR CENTRE PLANE REAR SPAR FUEL AND OIL CUT-OFF CIRCUIT PRODUCTION DEEP BOTTOM BOOM BOTLS FUSELAGE TO CENTRE PLANE ATTACHMENT CENTRE PLANE TO FUSELAGE JOINTS PLATES GUARD AUTO-COARSENING SWITCH	1395
UK	2889 PRE 80	FUEL AND OIL CUT-OFF CIRCUIT	1405
UK	2890 PRE 80	PRODUCTION DEEP BOTTOM BOOM	1412
UK	2891 PRE 80	BUTLS FUSELAGE TO CENTRE PLANE ATTACHMENT	1420
UK UK	2892 PRE 80	CENTRE PLANE TO FUSELAGE JOINTS PLATES	1421
UK	2093 PKE 80	SIDE STRUTS UNDERCARRIAGE LOWER SITTING	1422
UK	2895 PRF 80	FIRST PILOTS CONTROL COLLIMN	1423
UK	2896 PRF 80	GUARD AUTO-COARSENING SWITCH SIDE STRUTS UNDERCARRIAGE LOWER FITTING FIRST PILOTS CONTROL COLUMN GENERATOR POWER FAILURE WARNING LIGHTS	1435
UK	2897 PRE 80	FIRE EXTINGUISHER CARTRIDGE  NACELLE STRUCTURE  CONSTANT SPEED UNIT  PROPELLER AUTO. COARSE PITCH AIR PRESSURE SWITCH	1436
UK	2898 PRE 80	NACELLE STRUCTURE	SRM NO.78
UK	2899 PRE 80	CONSTANT SPEED UNIT	SRM NO.79
UK	2900 PRE 80	PROPELLER AUTO. COARSE PITCH AIR PRESSURE SWITCH	SRM NO.80
UK	2901 PRE 80	MAIN UNDERCARRIAGE FITTINGS	SRM NO.81
UK	2902 PRE 80	DRAIN SUMPS	SRM NO.84
UK	2903 PRE 80	AILEKUN CUNIKUL CABLES	SRM NO.85
UK UK	2904 PRE 80 2905 PRE 80	AILERUN CUNTRUL CABLES FIRE EXTINGUISHER CARTRIDGE MANDATORY AIRCRAFT INFO SHEETS	PP 155 170/F/7, 9, 11
UK		FIRE EXTINGUISHER CARTRIDGE	PP 155 170/F/7, 9, 11
UK UK B <b>RITISH</b>	AEROSPACE		
UK UK BRITISH	AEROSPACE		
UK UK RITISH DH 125 CF UK	AEROSPACE		
UK UK RITISH DH 125 CF UK UK	AEROSPACE		
UK UK RITISH DH 125 CF UK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS FLAP CENTRE OPERATING CIRCUIT	251894 252174 PT A,B,C 252194
UK UK RITISH DH 125 CF UK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS FLAP CENTRE OPERATING CIRCUIT	251894 252174 PT A,B,C 252194
UK UK RITISH DH 125 CF UK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS FLAP CENTRE OPERATING CIRCUIT	251894 252174 PT A,B,C 252194 252300 PT D&E 252410
UK UK BRITISH DH 125 CF UK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LFADING FDGE	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442
UK UK RITISH DH 125 CF UK UK UK UK UK UK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1555 PRE 80 1555 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442
UK UK DH 125 CF UK UK UK UK UK UK UK UK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1555 PRE 80 1555 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442
UK UK DH 125 CF UK UK UK UK UK UK UK UK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1555 PRE 80 1555 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578
UK UK OK OH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1554 PRE 80 1554 PRE 80 1557 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C
UK UK OK OH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1554 PRE 80 1554 PRE 80 1557 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C
UK UK BRITISH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1554 PRE 80 1554 PRE 80 1557 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C
UK UK RITISH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1554 PRE 80 1554 PRE 80 1557 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C
UK UK OK OH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1565 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C
UK UK OK OF 171SH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1559 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1563 PRE 80 1564 PRE 80 1564 PRE 80 1565 PRE 80 1565 PRE 80 1569 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C 252675 252705 257705 257705 257583 SB 21-119
UK UK RITISH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1555 PRE 80 1557 PRE 80 1559 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1564 PRE 80 1564 PRE 80 1565 PRE 80 1565 PRE 80 1569 PRE 80 1569 PRE 80 1561 PRE 80 1563 PRE 80 1563 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C
UK UK DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1561 PRE 80 1563 PRE 80 1564 PRE 80 1569 PRE 80 1569 PRE 80 1569 PRE 80 1571 PRE 80 1573 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER FLECTRICAL POWER - BUS BAR PROTECTION UNIT	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C 252675 252675 252758 2527583 SB 21-119 SB 23-A20 SB 24-141
UK UK OK OK OK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1569 PRE 80 1569 PRE 80 1569 PRE 80 1569 PRE 80 1569 PRE 80 1569 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS F LAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252578 252626 PT A,B,C 252670 252675 252705 257583 SB 21-119 SB 23-A20 SB 24-141 SB 28-A23
UK UK DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1561 PRE 80 1563 PRE 80 1564 PRE 80 1569 PRE 80 1569 PRE 80 1569 PRE 80 1571 PRE 80 1573 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252636 PT A,B,C 252670 252675 252705 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-69
UK UK OK OK OK OK UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1569 PRE 80 1571 PRE 80 1571 PRE 80 1573 PRE 80 1574 PRE 80 1578 PRE 80 1585 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAIL IC POWER - FLOW INDICATOR UNITS	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C 252675 252705 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-A23 SB 28-69 SB 29-60
UK UK RITISH DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1560 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1565 PRE 80 1565 PRE 80 1567 PRE 80 1571 PRE 80 1573 PRE 80 1574 PRE 80 1574 PRE 80 1574 PRE 80 1574 PRE 80 1574 PRE 80 1575 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAIL IC POWER - FLOW INDICATOR UNITS	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C 252675 252705 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-A23 SB 28-69 SB 29-60
UK UK DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1555 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1559 PRE 80 1560 PRE 80 1560 PRE 80 1563 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1573 PRE 80 1574 PRE 80 1578 PRE 80 1578 PRE 80 1578 PRE 80 1578 PRE 80 1582 PRE 80 1585 PRE 80 1585 PRE 80 1587 PRE 80 1587 PRE 80 1587 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAULIC POWER - FLOW INDICATOR UNITS LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252580 252626 PT A,B,C 252675 252705 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-A23 SB 28-69 SB 29-60
UK UK UK DH 125 CF UK	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1558 PRE 80 1560 PRE 80 1561 PRE 80 1561 PRE 80 1562 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1565 PRE 80 1571 PRE 80 1571 PRE 80 1571 PRE 80 1573 PRE 80 1574 PRE 80 1578 PRE 80 1578 PRE 80 1589 PRE 80 1589 PRE 80 1589 PRE 80 1588 PRE 80 1589 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAULIC POWER - FLOW INDICATOR UNITS LANDING GEAR - EMERGENCY BRAKE REDUCING VALVE LANDING GEAR - REMERGENCY BRAKE REDUCING VALVE	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252626 PT A,B,C 252670 252675 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-A23 SB 28-A23 SB 29-60 SB 32-167 SB 32-167 SB 32-167 SB 32-18485
UK U	AEROSPACE SERIES CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1558 PRE 80 1558 PRE 80 1560 PRE 80 1560 PRE 80 1563 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1574 PRE 80 1574 PRE 80 1574 PRE 80 1578 PRE 80 1578 PRE 80 1578 PRE 80 1582 PRE 80 1585 PRE 80 1585 PRE 80 1586 PRE 80 1587 PRE 80 1588 PRE 80 1588 PRE 80 1589 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAULIC POWER - FLOW INDICATOR UNITS LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - ROSE CYLINDED	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252626 PT A,B,C 252670 252670 252675 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-69 SB 29-60 SB 32-166 SB 32-167 SB 32-184R5 SB 35-A22
UK U	AEROSPACE SERIES.  CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1555 PRE 80 1555 PRE 80 1557 PRE 80 1557 PRE 80 1558 PRE 80 1569 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1567 PRE 80 1568 PRE 80 1569 PRE 80 1571 PRE 80 1573 PRE 80 1574 PRE 80 1574 PRE 80 1578 PRE 80 1585 PRE 80 1586 PRE 80 1587 PRE 80 1588 PRE 80 1589 PRE 80 1593 PRE 80 1593 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAULIC POWER - FLOW INDICATOR UNITS LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - MERGENCY BRAKE REDUCING VALVE LANDING GEAR - MERGENCY BRAKE REDUCING VALVE LANDING GEAR - NOSE LEG DRAG STAY ASSEMBLY OXYGEN - MASTER VALVE	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252626 PT A,B,C 252670 252670 252675 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-69 SB 29-60 SB 32-166 SB 32-167 SB 32-184R5 SB 35-A22
UK UK UK DH 125 CF UK	AEROSPACE SERIES  CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1554 PRE 80 1555 PRE 80 1557 PRE 80 1557 PRE 80 1558 PRE 80 1559 PRE 80 1560 PRE 80 1561 PRE 80 1561 PRE 80 1561 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1564 PRE 80 1565 PRE 80 1565 PRE 80 1573 PRE 80 1573 PRE 80 1574 PRE 80 1574 PRE 80 1574 PRE 80 1578 PRE 80 1578 PRE 80 1578 PRE 80 1578 PRE 80 1589 PRE 80 1588 PRE 80 1589 PRE 80 1589 PRE 80 1589 PRE 80 1599 PRE 80 1599 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAULIC POWER - FLOW INDICATOR UNITS LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - MOSE LEG DRAG STAY ASSEMBLY OXYGEN - STORAGE CYLINDER OXYGEN - MASTER VALVE FUSELAGE - FRONT PRESSURE BULKHEAD	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252626 PT A,B,C 252670 252670 252675 257583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-69 SB 29-60 SB 32-166 SB 32-167 SB 32-184R5 SB 35-A22
UK UK UK DH 125 CF UK	AEROSPACE SERIES.  CF-90-04 1550 PRE 80 1551 PRE 80 1552 PRE 80 1553 PRE 80 1555 PRE 80 1555 PRE 80 1557 PRE 80 1557 PRE 80 1558 PRE 80 1569 PRE 80 1563 PRE 80 1563 PRE 80 1564 PRE 80 1565 PRE 80 1567 PRE 80 1568 PRE 80 1569 PRE 80 1571 PRE 80 1573 PRE 80 1574 PRE 80 1574 PRE 80 1578 PRE 80 1585 PRE 80 1586 PRE 80 1587 PRE 80 1588 PRE 80 1589 PRE 80 1593 PRE 80 1593 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAULIC POWER - FLOW INDICATOR UNITS LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE REDUCING VALVE LANDING GEAR - MOSE LEG DRAG STAY ASSEMBLY OXYGEN - STORAGE CYLINDER OXYGEN - MASTER VALVE FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - CANOPY POST A-B	251894 252174 PT A,B,C 252194 252300 PT D&E 252410 252426 252442 252454 252578 252626 PT A,B,C 252675 252675 2527583 SB 21-119 SB 23-A20 SB 24-141 SB 26-A18 SB 28-A23 SB 28-A23 SB 28-A23 SB 28-A25 SB 32-166 SB 32-167 SB 32-184R5 SB 35-A22 SB 35-A22 SB 35-A23 SB 35-A23

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER (SERIES / SERIE)

ORIGINE	NUMERO DE CONSIGNE	SUBJECT	BULLETIN DE SERVICE DE REF
	H AEROSPACE		
	SERIES		
UK	IUED / SUITE) 1601 PRE 80	WINDOWS - CABIN WINDOW PANELS WINDOWS - COCKPIT WINDOW PANEL 'C' WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - UPPER AIRBRAKE ASSEMBLY	SB 56-15
UK	1601 PRE 80	MINDOMS - CUCKBIL MINDOM BANET (C)	SB 56-15
UK	1603 PRE 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-44
UK	1604 PRE 80	WINGS - UPPER AIRBRAKE ASSEMBLY	SB 57-A49
UK	1605 PRE 80	WINGS - ALLERON INNER HINGE BRACKEL ASSEMBLY	SB 57-51
UK	1606 PRE 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-54
UK UK	1607 PRE 80	WINGS - FLAP DUTER HINGE ASSEMBLY	SB 57-55
UK	1608 PRE 80 1610 PRE 80	WINGS - FLAPS OUTBOARD HINGES  ELECTRICAL POWER GYROSCOPIC BANK/PITCH INDICATION	SB 57-58
UK	1611 PRE 80	MANDATORY LIFE LIMITATIONS	MAINT. SCHEDULE
UK	007-11-80	AIRBORNE AUXILIARY POWER	SB 49-23
UK	012-05-81	FUEL - RUBBER FLAP VALVE WING FILLER CAP	SB 28-60
UK	013-06-81	FLIGHT CONTROLS - AILERON, RUDDER & ELEVATOR TRIM	
UK	014-01-81	ELECTRICAL POWER - FUEL COMPUTERS	SB 24-225
UK	014-08-81 015-08-81	LANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT	SB 32-190
UK	001-12-82	STABILIZERS - ATTACHMENT FITTINGS	SB 55-33
UK	006-01-82	AIR CONDITIONING BAE DYNAMICS GROUP COLD-AIR UNIT	
UK	006-10-83	LANDING GEAR - WHEELS AND BRAKES	SB 32-193
UK	007-10-83	LANDING GEAR - JACK CYLINDER HEAD ATTACHMENT LUGS	SB 32-A197
UK	010-04-83	ELECTRICAL POWER - PANEL "ZL"	SB 24-220
UK	011-04-83	ELECTRICAL POWER FEEDER FUSES ON PANEL "ZL"	SB 24-239
UK UK	046-04-83 003-06-84	COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 23-21
UK	005-07-84	LANDING - MAIN GEAR DOORS  LANDING GEAR - MAIN WHEELS - WHEEL FLANGE POWER PLANT - ENGINE MOUNTINGS	SB 32-200
UK	004-08-85	POWER PLANT - ENGINE MOUNTINGS	SB 71-38
UK	005-10-85	ELECTRICAL POWER - CABLE INSTALLATION	SB 24-255
UK	005-11-85	ELECTRICAL POWER - CABLE INSTALLATION ENGINE - TURBINE INTERSTAGE TRANSITION DUCT	SB 72-3
UK	006-02-86	AIRBURNE AUXILIARY POWER	49-32-(9210A)
UK	007~02-86	AIRBORNE AUXILIARY POWER	49-31-(9286A)
UK UK	015-10-86 002-03-87	WINGS - AILERON MASS BALANCE	57-66
UK	010-03-87	ELECTRICAL POWER EMERG. CONTACTOR LOWER TERMINAL	24-A261R1
UK	017-01-87	FLIGHT CONTROLS - ELEVATOR MASS BALANCE ENGINE - REAR MOUNTING	SB 27-142R3 72-4
UK	003-09-88	TURBINE - REAR MOUNTING TURBINE INTERSTAGE TRANSITION DUCT MAIN LANDING GEAR SIDESTAY NOSE GEAR PLYOT PIN	72-1-2844AR2
UK	007-02-88	MAIN LANDING GEAR SIDESTAY	32-216R1
UK	008-02-88		32-217
UK	008-06-88	MAIN LANDING GEAR DOOR FORWARD HINGE FITTING	32-218
UK UK	012-05-88 001-01-89	ELECTRICAL POWER - DC BUS-TIE SYSTEM ELECTRICAL POWER - BATTERY POST LOCKNUTS	24-264R1
UK	004-06-89	FUSELAGE - FORWARD KEEL SKIN PANELS	51-4
UK	012-07-89	WARMING OVEN	25-54-9758A&BR1
UK	005-08-90	NOSE LANDING GEAR SIDEWALL CRACKS	53-73R2
UK	012-08-91	CORROSION - WINGS TOP SKIN BENEATH BOUNDRY FENCE	57-73R1
UK	013-08-91	WINGS - CRACKS TOP SKIN	57-75R2
UK	015-12-91	FUEL FEED PIPE JOINTS	28-87
UK UK	003-08-92	WARMING OVEN	25-64-9758C
UK	012-12-92 017-01-92	DIODES - BOTTLE GONE INDICATORS FUSELAGE - DRAIN MASTS	26-33R1 53-74-3193C&DR1
UK	029-05-92		29-89-3269A
UK	011-02-94	FAN VENTURI MOTOR	21-A150
US	89-18-13	SUNSTRAND TURBOMACH T-62T SERIES APU (STC'S)	
US	95-08-06	STATIC INVERTER	
US	97-03-07	INSPECT MLG SIDESTAY JACK PIVOT	32-233R2
DH 125	1A ( DH 1540 PRE 80	125 SEDIES )	
UK	1540 PRE 80	HYDRAULIC POWER HAND PUMP TANK	251252 DADT D
UK	1541 PRE 80	BATTERY HEATING	251252 PART B 251281
UK	1542 PRE 80	'ULTRA' JET PIPE TOP TEMPERATURE CONTROL SYSTEM	251318
UK	1543 PRE 80	WINGS/AILERON	251339
UK	1544 PRE 80	FUEL FILTER DIFFERENTIAL PRESSURE SWITCH	251393
	1545 PRE 80	HYDRAULIC EMERGENCY SYSTEM	251395
	1546 PRE 80	FLIGHT CONTROLS/AILERONS	251408
UK	1547 PRE 80 1548 PRE 80	INSTRUMENTS PLACARDS GUST LOCK ELEVATOR AND AILERON CONTROLS	251451
	1549 PRE 80	FUSELAGE - ENGINE MOUNTING BEAM	251716 251723
UK	1567 PRE 80	EQUIPMENT/FURNISHINGS - LIFFJACKET	257070
UK	1568 PRE 80	ELECTRICAL POWER - VOLTAGE SENSING UNIT	257355 EB 24 28
UK	1570 PRE 80	AIR CONDITIONING SAFETY INWARD RELIEF VALVE	3D 21-28
UK UK	13/2 PRE 80	AUTO-PILOT PLACARDS	SB 22-A1
UK	1575 PRE 80 1576 PRE 80	ELECTRICAL POWER CABIN PRESSURE SEAL BUNGS FIRE PROTECTION AUTO. FIRE EXTINGUISHER TOP CAP	SB 24-178
	AET /AEDONIES	THE EXTINGUISHER TOP CAP	3D 26-1

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

CHICH	E NOWERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF
	SH AEROSPACE			
	25 1A	( DH	125 SERIES )	
(CONT)	INUED / SUITE)		,	
UK	1577 PRE 80		FIRE PROTECTION FIRE EXTINGUISHING SYSTEM	CD OC-AE
UK	1579 PRE 80		FLIGHT CONTROL FLAP OPERATING MECHANISM	SP 27-140
UK	1580 PRE 80		FLIGHT CONTROL FLAD JACK ASSEMBLY	SD 27-A49
UK	1581 PRE 80		FUEL - FUEL ETLITED DE-TOTALS SYSTEM	SD 27-125
UK	1594 PRE 80		OXYGEN - SUPPLY VALVE	SD 28-56
UK	005-04-83		LANDING GEAR - EMERGENCY SELECTOR CHAFT ACCEMBLY	SB 35-A25
UK	004-03-86		FLIGHT CONTOOLS - FLAD CYCTEM	3B 32-39
UK	011-02-87		STRUCTURES ADDITIONAL INSPECTION DECULDEMENTS	27-A140, 27-140
UK	012-02-87		FUSELAGE - DUTED SKIN	3D 51-3
UK	013-02-87		WINGS - BOTTOM SKIN	5B 53-63
UK	003-11-89		FIRE PROTECTION FIRE EXTINGUISHING SYSTEM FLIGHT CONTROL FLAP OPERATING MECHANISM FLIGHT CONTROL FLAP JACK ASSEMBLY FUEL - FUEL FILTER DE-ICING SYSTEM  DXYGEN - SUPPLY VALVE LANDING GEAR - EMERGENCY SELECTOR SHAFT ASSEMBLY FLIGHT CONTROLS - FLAP SYSTEM STRUCTURES ADDITIONAL INSPECTION REQUIREMENTS FUSELAGE - OUTER SKIN WINGS - BOTTOM SKIN REAR EQUIPMENT BAY / REAR PRESSURE BULKHEAD REAR SPAR AND MLG SUPPORT BRACKET MAIN ENTRY DOOR FATIGUE CRACKING	50 5/-6/
UK	006-06-92		REAR SPAD AND MIC SUPPORT PRACTET	53-71
US	98-05-16		MAIN ENTRY DOOR FATIGUE CRACKING	52-48
00	30 00 10		MAIN ENTRY DOOR PATIGUE CRACKING	52-48
DH 12	25 3A	( DH	125 SEDIES )	
1.117	1544 PRE 80	( DII	125 SERIES ) FUEL FILTER DIFFERENTIAL PRESSURE SWITCH	051000
UK	1544 FRE 80		HYDDALII TO FAMEDOENION CHETTA	251393
UK	1545 FRE 80		CHET LOCK ELEVATOR AND ATTERON CONTROLS	251395
UK	15/10 PRE 00		ELICEL ACE - ENCINE MOUNTING DEAM	251/16
UK	1567 PDE 00		FOLITOMENT / FUDNICHING NOUNTING BEAM	251723
UK	1507 PKE 80		ELECTRICAL DOWER VOLTACE CENCENC LINET	257070
UK	1500 PKE 8U		ELECTRICAL POWER - VOLTAGE SENSING UNIT	207300
UK	1575 PRE 80		ELECTRICAL POWER CABIN PRESSURE SEAL BUNGS	SB 24-1/8
UK	15// PRE 80		FUEL FILTER DIFFERENTIAL PRESSURE SWITCH HYDRAULIC EMERGENCY SYSTEM GUST LOCK ELEVATOR AND AILERON CONTROLS FUSELAGE - ENGINE MOUNTING BEAM EQUIPMENT/FURNISHINGS - LIFELACKET ELECTRICAL POWER - VOLTAGE SENSING UNIT ELECTRICAL POWER CABIN PRESSURE SEAL BUNGS FIRE PROTECTION FIRE EXTINGUISHING SYSTEM FLIGHT CONTROL FLAP OPERATING MECHANISM FLIGHT CONTROL FLAP JACK ASSEMBLY	SB 26-A5
UK	15/9 PRE 80		FLIGHT CONTROL FLAP OPERATING MECHANISM FLIGHT CONTROL FLAP JACK ASSEMBLY FUEL - FUEL FILTER DE-ICING SYSTEM OXYGEN - SUPPLY VALVE LANDING GEAR - EMERGENCY SELECTOR SHAFT ASSEMBLY FLIGHT CONTROLS - FLAP SYSTEM FUSELAGE - OUTER SKIN WINGS - BOTTOM SKIN MAIN ENTRY DOOR FATIGUE CRACKING	SB 27-A49
UK	1580 PRE 80		FLIGHT CONTROL FLAP JACK ASSEMBLY	SB 27-125
UK	1581 PRE 80		FUEL - FUEL FILTER DE-ICING SYSTEM	SB 28-56
UK	1594 PRE 80		OXYGEN - SUPPLY VALVE	SB 35-A25
UK	005-04-83		LANDING GEAR - EMERGENCY SELECTOR SHAFT ASSEMBLY	SB 32-59
UK	004-03-86		FLIGHT CONTROLS - FLAP SYSTEM	27-A140, 27-140
UK	012-02-87		FUSELAGE - OUTER SKIN	SB 53-63
UK	013-02-87		WINGS - BOTTOM SKIN	SB 57-67
US	98-05-16		MAIN ENTRY DOOR FATIGUE CRACKING	52-48
DH 12	25 400A	( DH	125 SERIES )	
UK	1575 PRE 80		ELECTRICAL POWER CABIN PRESSURE SEAL BUNGS	SB 24-178
UK	1581 PRE 80		FUEL - FUEL FILTER DE-ICING SYSTEM	SB 28-56
UK	1592 PRE 80		NAVIGATION WEATHER RADAR SYSTEMS	SB 34-A134
UK	1594 PRE 80		OXYGEN - SUPPLY VALVE	SB 35-A25
UK	012-02-87		FUSELAGE - OUTER SKIN	SB 53-63
UK	013-02-87		WINGS - BOTTOM SKIN	SB 57-67
US	97-21-05		125 SERIES ) ELECTRICAL POWER CABIN PRESSURE SEAL BUNGS FUEL - FUEL FILTER DE-ICING SYSTEM NAVIGATION WEATHER RADAR SYSTEMS OXYGEN - SUPPLY VALVE FUSELAGE - DUTER SKIN WINGS - BOTTOM SKIN HIGH PRESSURE OXYGEN HOSE ASSEMBLIES	35-46
BH 12	SERIES			
CF	CF-90-04		AUXILIARY POWER UNIT T-62T SERIES	
UK	32-233		INSPECT MLG SIDESTAY JACK PIVOT	32-233R1
UK	1550 PRE 80		FLIGHT CONTROLS FLAP CENTRE HINGE	251894
UK	1551 PRE 80		AUXILIARY POWER UNIT T-62T SERIES INSPECT MLG SIDESTAY JACK PIVOT FLIGHT CONTROLS FLAP CENTRE HINGE FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY	252174 PT A,B,C
UK	1552 PRE 80		WINDSCREEN DE-ICING HAND PUMP	252194
UK	1553 PRE 80		FLAP OUTER HINGE ASSEMBLY	252300 PT D&E
UK	1554 PRE 80		COCKPIT WINDOW PANEL 'C'	252410
UK	1555 PRE 80		FLIGHT CONTROLS - FLAP INBOARD HINGE	252426
UK	1557 PRE 80		WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS - AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT	252442
UK	1558 PRE 80		WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT	252454
UK	1559 PRE 80		FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET	252578
UK	1560 PRE 80		ENGINE AIR - BLOW-OFF VALVE SWITCHES	25258U
UK	1561 PRE 80		WINGS - LEADING EUGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE	252626 PT A,B,C 252670
UK	1563 PRE 80		WINGS TEAT OF TEAT	
UK	1564 PRE 80			252675
UK	1565 PRE 80		FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH	252705
UK	1569 PRE 80		NAVIGATION - ALTITUDE ALERTING UNIT	257583
UK	1571 PRE 80		AIR CONDITIONING - MIXING VALVE	SB 21-119
UK	1573 PRE 80			SB 23-A20
UK	1574 PRE 80			SB 24-141
UK	1578 PRE 80		FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY	SB 26-A18
UK	1582 PRE 80		FUEL - FILTER DE-ICING SYSTEM	SB 28-A23
UK	1585 PRE 80		FUEL - DISTRIBUTION	SB 28-69
UK	1586 PRE 80		HYDRAULIC POWER - FLOW INDICATOR UNITS	SB 29-60
UK	1587 PRE 80		LANDING GEAR - EMERGENCY BRAKE	SB 32-166
UK	1588 PRE 80		LANDING GEAR - EMERGENCY BRAKE REDUCING VALVE	SB 32-167
UK	1589 PRE 80	*	LANDING GEAR - NOSE LEG DRAG STAY ASSEMBLY	SB 32-184R5
UK	1593 PRE 80		OXYGEN - STORAGE CYLINDER	SB 35-A22
UK	1596 PRE 80		DXYGEN - MASTER VALVE	SB 35-29
OK	1000 1112 00			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER SUBJECT
SUJET

REFERENCE SERVICE BULLETIN
BULLETIN DE SERVICE DE REF.

UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1610 F UK 07-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 015-08 UK 006-01 UK 006-10 UK 007-10 UK 007-10 UK 007-10 UK 005-10 UK 005-10 UK 005-10 UK 005-11 UK 005-11 UK 007-02 UK 008-06	ES SUITE) SUITE) PRE 80	FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - CANOPY POST A-B FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - FRONT PRESSURE BULKHEAD WINDOWS - CABIN WINDOW PANELS WINDOWS - COCKPIT WINDOW PANEL 'C' WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE BRACKET ASSEMB WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - TURBINE INTERSTAGE TRANSITION DUCT TO ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER FEEDER FUSES ON PANEL "ZL' COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS ANDING GEAR - MAIN WHEELS - WHEEL FLANGE OWER PLANT - ENGINE MOUNTINGS LECTRICAL POWER - CABLE INSTALLATION NGINE - TURBINE INTERSTAGE TRANSITION DUCT IRBORNE AUXILIARY POWER	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
BH 125 SERI (CONTINUED / SERI	ES SUITE) SUITE) PRE 80	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1610 F UK 07-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 015-08 UK 006-01 UK 006-10 UK 007-10 UK 007-10 UK 003-06 UK 005-10 UK 005-10 UK 005-10 UK 005-11 UK 005-11 UK 005-11 UK 007-02 UK 007-02 UK 015-10 UK 007-02 UK 017-02	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1610 F UK 07-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 015-08 UK 006-01 UK 006-10 UK 007-10 UK 010-04 UK 007-10 UK 005-10 UK 005-10 UK 005-10 UK 005-10 UK 005-10 UK 005-11 UK 005-11 UK 005-11 UK 005-11 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 017-01 UK 007-02 UK 017-01 UK 003-09 UK 017-01 UK 003-09 UK 017-02	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1610 F UK 07-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 015-08 UK 006-01 UK 006-10 UK 007-10 UK 010-04 UK 007-10 UK 005-10 UK 005-10 UK 005-10 UK 005-10 UK 005-10 UK 005-11 UK 005-11 UK 005-11 UK 005-11 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 017-01 UK 007-02 UK 017-01 UK 003-09 UK 017-01 UK 003-09 UK 017-02	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1610 F UK 07-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 015-08 UK 006-01 UK 006-10 UK 007-10 UK 010-04 UK 007-10 UK 005-10 UK 005-10 UK 005-10 UK 005-10 UK 005-10 UK 005-11 UK 005-11 UK 005-11 UK 005-11 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 017-01 UK 007-02 UK 017-01 UK 003-09 UK 017-01 UK 003-09 UK 017-02	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1610 F UK 07-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 006-01 UK 006-01 UK 007-10 UK 007-10 UK 007-10 UK 005-07 UK 005-07 UK 005-07 UK 005-07 UK 005-01	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1611 F UK 007-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 006-01 UK 006-01 UK 007-10 UK 007-10 UK 007-10 UK 007-10 UK 005-07	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1611 F UK 007-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 006-01 UK 006-01 UK 007-10 UK 007-10 UK 007-10 UK 007-10 UK 005-07 UK 005-05 UK 005-05 UK 005-05 UK 005-05 UK 008-06 UK 004-05	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1605 F UK 1606 F UK 1607 F UK 1608 F UK 1610 F UK 1611 F UK 007-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 014-01 UK 006-01 UK 006-01 UK 007-10 UK 007-10 UK 007-10 UK 007-10 UK 005-07 UK 005-05 UK 005-05 UK 005-05 UK 005-05 UK 008-06 UK 004-05	PRE 80 PR	WINGS - AILERON INNER HINGE BRACKET ASSEMB WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER EUEL - RUBBER FLAP VALVE WING FILLER CAP ELIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-51 SB 57-54 SB 57-55 SB 57-55 SB 57-58 SB 57-58 SB 57-58 SB 27-130 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 22-21
UK 1607 F UK 1608 F UK 1610 F UK 1611 F UK 013-06 UK 013-06 UK 013-06 UK 014-01 UK 001-12 UK 015-08 UK 005-10 UK 007-10 UK 003-06 UK 005-11 UK 005-11 UK 005-11 UK 005-10 UK 007-02 UK 015-08 UK 005-10 UK 005-11 UK 005-11 UK 005-10 UK 007-02 UK 015-10 UK 008-06 UK 008-06 UK 008-06 UK 008-06 UK 012-05 UK 008-06 UK 008-06 UK 008-06 UK 008-06 UK 008-06 UK 012-05 UK 008-06 UK 008-06	PRE 80 PRE 81 PRE 81 PRE 81 PRE 81 PRE 82 PRE 83 PRE 84 PRE 84 PRE 85 PRE 85 PRE 80 PR	VINGS - FLAPS OUTBOARD HINGES LECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILITARY POWER UEL - RUBBER FLAP VALVE WING FILLER CAP LIGHT CONTROLS - AILERON, RUDDER & ELEVATO LECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUC TABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-58  ICATION NOTICE NO.81 MAINT. SCHEDULE SB 49-23 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 23-21
UK 1607 F UK 1608 F UK 1610 F UK 1611 F UK 013-06 UK 013-06 UK 013-06 UK 014-01 UK 001-12 UK 015-08 UK 005-10 UK 007-10 UK 003-06 UK 005-11 UK 005-11 UK 005-11 UK 005-10 UK 007-02 UK 015-08 UK 005-10 UK 005-11 UK 005-11 UK 005-10 UK 007-02 UK 015-10 UK 008-06 UK 008-06 UK 008-06 UK 008-06 UK 012-05 UK 008-06 UK 008-06 UK 008-06 UK 008-06 UK 008-06 UK 012-05 UK 008-06 UK 008-06	PRE 80 PRE 81 PRE 81 PRE 81 PRE 81 PRE 82 PRE 83 PRE 84 PRE 84 PRE 85 PRE 85 PRE 80 PR	VINGS - FLAPS OUTBOARD HINGES LECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILITARY POWER UEL - RUBBER FLAP VALVE WING FILLER CAP LIGHT CONTROLS - AILERON, RUDDER & ELEVATO LECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUC TABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-58  ICATION NOTICE NO.81 MAINT. SCHEDULE SB 49-23 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 23-21
UK 1608 F UK 1610 F UK 007-11 UK 007-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 006-01 UK 006-01 UK 007-10 UK 007-10 UK 007-10 UK 005-07 UK 005-01 UK 005-02 UK 015-10 UK 005-02 UK 015-10 UK 005-03 UK 017-01 UK 003-09 UK 005-02 UK 008-06 UK 008-06 UK 012-05 UK 004-06	PRE 80 PRE 81 PRE 81 PRE 81 PRE 81 PRE 82 PRE 83 PRE 84 PRE 84 PRE 85 PRE 85 PRE 80 PR	VINGS - FLAPS OUTBOARD HINGES LECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS AIRBORNE AUXILITARY POWER UEL - RUBBER FLAP VALVE WING FILLER CAP LIGHT CONTROLS - AILERON, RUDDER & ELEVATO LECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUC TABILIZERS - ATTACHMENT FITTINGS ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 57-58  ICATION NOTICE NO.81 MAINT. SCHEDULE SB 49-23 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-220 SB 24-220 SB 23-21
UK 1610 F UK 07-11 UK 07-11 UK 012-05 UK 013-06 UK 014-01 UK 014-01 UK 015-08 UK 006-01 UK 006-10 UK 007-10 UK 007-10 UK 007-10 UK 005-07 UK 005-07 UK 005-07 UK 005-01 UK 005-02 UK 015-10 UK 005-02 UK 015-10 UK 005-02 UK 015-05	PRE 80   19   19   19   19   19   19   19   1	ELECTRICAL POWER GYROSCOPIC BANK/PITCH IND MANDATORY LIFE LIMITATIONS ALTRBORNE AUXILIARY POWER UEL - RUBBER FLAP VALVE WING FILLER CAP LIGHT CONTROLS - AILERON, RUDDER & ELEVATO ELECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUCTABILIZERS - ATTACHMENT FITTINGS AND ING GEAR - WHEELS AND BRAKES ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	ICATION NOTICE NO.81 MAINT. SCHEDULE SB 49-23 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 SB 24-220 SB 24-229 SB 22-21
UK 012-05 UK 013-06 UK 014-01 UK 014-05 UK 015-08 UK 001-12 UK 006-01 UK 007-10 UK 007-10 UK 011-04 UK 003-06 UK 003-06 UK 005-11 UK 006-02 UK 007-02 UK 011-04 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 017-01 UK 003-06	PRE 80	MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER UEL - RUBBER FLAP VALVE WING FILLER CAP LIGHT CONTROLS - AILERON, RUDDER & ELEVATO LECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUCTOR TABILIZERS - ATTACHMENT FITTINGS LIR CONDITIONING BAE DYNAMICS GROUP COLD-A: ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" OMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	MAINT. SCHEDULE SB 49-23 SB 28-60 OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-4197 " SB 24-220 " SB 24-220 " SB 24-220 " SB 24-239 SB 223-21
UK 012-05 UK 013-06 UK 014-01 UK 014-05 UK 015-08 UK 001-12 UK 006-01 UK 007-10 UK 007-10 UK 011-04 UK 003-06 UK 003-06 UK 005-11 UK 006-02 UK 007-02 UK 011-04 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 015-10 UK 007-02 UK 017-01 UK 003-06	15-81	UEL - RUBBER FLAP VALVE WING FILLER CAP LIGHT CONTROLS - AILERON, RUDDER & ELEVATO LECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUCT TABILIZERS - ATTACHMENT FITTINGS IR CONDITIONING BAE DYNAMICS GROUP COLD-A: ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 28-60  OR TRIM SB 27-130  SB 24-225  SB 32-190  T SB 72-1  SB 55-33  IR UNIT SB 21-123  SB 32-193  NT LUGS SB 32-A197  SB 24-220  "SB 24-220  "SB 24-229  SB 23-21
UK 013-06 UK 014-08 UK 014-08 UK 015-08 UK 006-01 UK 006-01 UK 007-10 UK 007-10 UK 011-04 UK 011-04 UK 011-04 UK 005-07 UK 005-07 UK 005-01 UK 005-11 UK 006-02 UK 007-02 UK 007-02 UK 015-10 UK 003-09 UK 015-10 UK 003-09 UK 015-10 UK 003-09 UK 015-05 UK 015-10 UK 003-09 UK 015-05	5-81 1-81 3-81 1-82 1-82 1-82 1-83 1-83 1-83 1-83 1-83 1-83 1-83 1-83 1-83 1-83 1-84 1-84 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85 1-85	LIGHT CONTROLS - AILERON, RUDDER & ELEVATO LECTRICAL POWER - FUEL COMPUTERS LANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUC TABILIZERS - ATTACHMENT FITTINGS IR CONDITIONING BAE DYNAMICS GROUP COLD-A: LANDING GEAR - WHEELS AND BRAKES LANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	OR TRIM SB 27-130 SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 "SB 24-229 SB 24-229 SB 23-21
UK 014-01 UK 015-08 UK 015-08 UK 001-12 UK 006-10 UK 007-10 UK 010-04 UK 011-04 UK 011-04 UK 003-06 UK 005-11 UK 006-02 UK 007-02 UK 015-10 UK 015-10 UK 007-02 UK 017-01 UK 007-02 UK 017-01 UK 003-08 UK 007-02 UK 017-01 UK 003-09 UK 017-01 UK 003-09 UK 017-01 UK 003-09 UK 017-01 UK 003-09 UK 007-02 UK 017-01 UK 003-09 UK 008-06 UK 008-06 UK 008-06 UK 004-08	1-81	LECTRICAL POWER - FUEL COMPUTERS ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUCTOR TABILIZERS - ATTACHMENT FITTINGS IR CONDITIONING BAE DYNAMICS GROUP COLD-A: ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" OMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 24-225 SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-4197 SB 24-220 SB 24-239 SB 24-239 SB 23-21
UK 006-01 UK 006-10 UK 007-10 UK 010-04 UK 011-04 UK 011-04 UK 03-06 UK 005-07 UK 005-07 UK 005-11 UK 006-02 UK 007-02 UK 007-02 UK 015-10 UK 003-09 UK 010-03 UK 010-03 UK 017-01 UK 003-09 UK 007-02 UK 017-02 UK 017-02	1-82	ANDING GEAR - LOWER MAIN GEAR NGINE - TURBINE INTERSTAGE TRANSITION DUCTOR TABILIZERS - ATTACHMENT FITTINGS IT CONDITIONING BAE DYNAMICS GROUP COLD-A: ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL' COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 32-190 T SB 72-1 SB 55-33 IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 " SB 24-229 SB 23-21
UK 006-01 UK 006-10 UK 010-04 UK 011-04 UK 011-04 UK 011-04 UK 003-06 UK 005-07 UK 005-11 UK 006-02 UK 005-11 UK 006-02 UK 007-02 UK 015-10 UK 002-03 UK 010-03 UK 010-03 UK 017-01 UK 003-09 UK 003-09 UK 003-09 UK 008-06 UK 008-06 UK 012-05 UK 012-05 UK 012-05	1-82	NGINE - TURBINE INTERSTAGE TRANSITION DUC- TABILIZERS - ATTACHMENT FITTINGS IR CONDITIONING BAE DYNAMICS GROUP COLD-A: ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 " SB 24-239 SB 23-21
UK 006-01 UK 006-10 UK 010-04 UK 011-04 UK 011-04 UK 011-04 UK 003-06 UK 005-07 UK 005-11 UK 006-02 UK 007-02 UK 007-02 UK 015-10 UK 002-03 UK 010-03 UK 010-03 UK 017-01 UK 003-09 UK 003-09 UK 003-09 UK 003-09 UK 008-06 UK 008-06 UK 012-05 UK 012-05 UK 012-05	1-82	ITR CONDITIONING BAE DYNAMICS GROUP COLD-A: ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL' COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 " SB 24-239 SB 23-21
UK 011-04 UK 046-04 UK 003-06 UK 005-07 UK 004-08 UK 005-10 UK 005-11 UK 006-02 UK 007-02 UK 010-03 UK 017-01 UK 003-09 UK 007-02 UK 007-02 UK 017-01 UK 008-02 UK 008-06 UK 012-05 UK 008-06	1-82	ITR CONDITIONING BAE DYNAMICS GROUP COLD-A: ANDING GEAR - WHEELS AND BRAKES ANDING GEAR - JACK CYLINDER HEAD ATTACHMEN LECTRICAL POWER - PANEL "ZL" LECTRICAL POWER FEEDER FUSES ON PANEL "ZL' COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	IR UNIT SB 21-123 SB 32-193 NT LUGS SB 32-A197 SB 24-220 " SB 24-239 SB 23-21
UK 011-04 UK 046-04 UK 003-06 UK 005-07 UK 004-08 UK 005-10 UK 005-11 UK 006-02 UK 007-02 UK 010-03 UK 017-01 UK 003-09 UK 007-02 UK 007-02 UK 017-01 UK 008-02 UK 008-06 UK 008-06 UK 004-06	1-83 E E E E E E E E E E E E E E E E E E E	LECTRICAL POWER FEEDER FUSES ON PANEL "ZL' COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	" SB 24-220 " SB 24-239 SB 23-21
UK 011-04 UK 046-04 UK 003-06 UK 005-07 UK 004-08 UK 005-10 UK 005-11 UK 006-02 UK 007-02 UK 010-03 UK 017-01 UK 003-09 UK 007-02 UK 007-02 UK 017-01 UK 008-02 UK 008-06 UK 008-06 UK 004-06	1-83 E E E E E E E E E E E E E E E E E E E	LECTRICAL POWER FEEDER FUSES ON PANEL "ZL' COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	" SB 24-220 " SB 24-239 SB 23-21
UK 006-02 UK 007-02 UK 015-10 UK 002-03 UK 010-03 UK 017-01 UK 003-09 UK 008-02 UK 008-02 UK 008-06 UK 012-05- UK 004-06	1-83 E 1-83 ( 1-84 L 1-85 P 1-85 E -85 F	LECTRICAL POWER FEEDER FUSES ON PANEL "ZL' OMMUNICATIONS - AUDIO INTEGRATING SYSTEMS ANDING - MAIN GEAR DOORS ANDING GEAR - MAIN WHEELS - WHEEL FLANGE OWER PLANT - ENGINE MOUNTINGS	" SB 24-239 SB 23-21
UK 006-02 UK 007-02 UK 015-10 UK 002-03 UK 017-01 UK 003-09 UK 007-02 UK 008-02 UK 008-06 UK 004-06 UK 004-06	1-83 ( -84 L -85 P -85 E	OMMUNICATIONS - AUDIO INTEGRATING SYSTEMS ANDING - MAIN GEAR DOORS ANDING GEAR - MAIN WHEELS - WHEEL FLANGE OWER PLANT - ENGINE MOUNTINGS	SB 23-21 SB 32-200
UK 006-02 UK 007-02 UK 015-10 UK 002-03 UK 010-03 UK 017-01 UK 003-09 UK 008-02 UK 008-02 UK 008-06 UK 012-05- UK 004-06	5-84 L -84 L -85 P -85 E -85 F	ANDING - MAIN GEAR DOORS ANDING GEAR - MAIN WHEELS - WHEEL FLANGE OWER PLANT - ENGINE MOUNTINGS	\$B 32-200
UK 006-02 UK 007-02 UK 015-10 UK 002-03 UK 010-03 UK 017-01 UK 003-09 UK 008-02 UK 008-02 UK 008-06 UK 012-05- UK 004-06	1-85 P 1-85 E	ANDING GEAR - MAIN WHEELS - WHEEL FLANGE OWER PLANT - ENGINE MOUNTINGS	
UK 006-02 UK 007-02 UK 015-10 UK 010-03 UK 017-01 UK 003-09 UK 007-02 UK 008-02 UK 008-06 UK 012-05- UK 004-06	)-85 -85	OWER PLANT - ENGINE MOUNTINGS	SB 32-201
UK 006-02 UK 007-02 UK 015-10 UK 002-03 UK 010-03 UK 017-01 UK 003-09 UK 008-02 UK 008-02 UK 008-06 UK 012-05- UK 004-06	-85 F	I ECTRICAL POWER - CARLE INSTALLATION	SB 71-38
UK 007-02 UK 015-10 UK 002-03 UK 010-03 UK 017-01 UK 003-09 UK 007-02 UK 008-02 UK 008-06 UK 012-05 UK 004-06		NGINE - TURBINE INTERSTAGE TRANSITION DUCT	SB 24-255 T SR 72-2
UK 003-09 UK 007-02 UK 008-02 UK 008-06 UK 012-05- UK 004-06	-86 A	NGINE - IDREINE INTERSTAGE TRANSITION DUCT IRBORNE AUXILIARY POWER IRBORNE AUXILIARY POWER INGS - AILERON MASS BALANCE LECTRICAL POWER EMERG. CONTACTOR LOWER TER LIGHT CONTROLS - ELEVATOR MASS BALANCE	49-32-(9210A)
UK 003-09 UK 007-02 UK 008-02 UK 008-06 UK 012-05 UK 004-06	-86 A	IRBORNE AUXILIARY POWER	49-31-(9286A)
UK 003-09 UK 007-02 UK 008-02 UK 008-06 UK 012-05 UK 004-06	-86 W	INGS - AILERON MASS BALANCE	57-66
UK 003-09 UK 007-02 UK 008-02 UK 008-06 UK 012-05 UK 004-06	-87 F	LEVIRICAL POWER EMERG. CONTACTOR LOWER TER LIGHT CONTROLS - ELEVATOR MASS BALANCE NGINE - REAR MOUNTING URBINE INTERSTAGE TRANSITION DUCT AIN LANDING GEAR SIDESTAY OSE GEAR PIVOT PIN	RMINAL 24-A261R1
UK 008-06- UK 012-05- UK 004-06-	-87 E	NGINE - REAR MOUNTING	SB 27-142R3
UK 008-06- UK 012-05- UK 004-06-	-88 T	URBINE INTERSTAGE TRANSITION DUCT	72-1-2844AR2
UK 008-06- UK 012-05- UK 004-06-	-88 M	AIN LANDING GEAR SIDESTAY	32-216R1
UK 012-05 UK 004-06 UK 012-07	-88 M		32-217
UK 004-06 UK 012-07	~88 F	AIN LANDING GEAR DOOR FORWARD HINGE FITTIN	IG 32-218
UK 012-07	-89 F	USELAGE - FORWARD KEEL SKIN PANELS	24-264R1
11K 005-08.	-89 W	ARMING OVEN	25-54-9758A&BR1
UK 012-08-	~90 . N	OSE LANDING GEAR SIDEWALL CRACKS	53-73R2
UK 012-08-	-91 C	DRRUSION - WINGS TOP SKIN BENEATH BOUNDRY	FENCE 57-73R1
UK 015-12-	-91 F	ARMING OVEN  DSE LANDING GEAR SIDEWALL CRACKS  DRROSION - WINGS TOP SKIN BENEATH BOUNDRY  INGS - CRACKS TOP SKIN  JEL FEED PIPE JOINTS	57-75R2
UK 003-08-	-92 W.	ARMING OVEN	25-64-07500
UK 012-12-	-92 D	JUSEL FEED PIPE JOINTS  ARMING OVEN  IODES - BOTTLE GONE INDICATORS  JSELAGE - DRAIN MASTS  YDRAULIC ACCUMULATORS	26-33R1
UK 017-01-	-92 FI	JSELAGE - DRAIN MASTS	53-74-3193C&DR1
			29-89-3269A
UK 011-02- US 89-18-1		AN VENTURI MOTOR JNSTRAND TURBOMACH T-62T SERIES APU (STC'S	21-A15()
3H 125 600A	( BH 12	5 SERIES )	
CF CF-94-0	03 SI	JNSTRAND TURBOMACH APU SEALANT	49-72-02
UK 1556 PF UK 1575 PF	RE 80 N/	AVIGATION - PITOT HEAD	252436
UK 1575 PF UK 1591 PF		ECTRICAL POWER CABIN PRESSURE SEAL BUNGS	SB 24-178
UK 1592 PR		IGHTS - INSTRUMENT PANEL LIGHTING AVIGATION WEATHER RADAR SYSTEMS	SB 33-A18
UK 012-02-	-87 FL	JSELAGE - OUTER SKIN	SB 34-A134 SB 53-63
UK 024-07- UK 010-02-	-90 L:	IGHTS PASSENGER COMPARTMENT	33-43R1
	_	VOLT LIGHTING-CIRCUIT BREAKER	24-310-3544A&B
TS 125 SERIES CF CF-90-0	5	IVII TARV DOUGD INIT TO THE	
UK 32-233		JXILIARY POWER UNIT T-62T SERIES USPECT MLG SIDESTAY JACK PIVOT	00 00-
UK 1550 PR	D4 AL	IGHT CONTROLS FLAP CENTRE HINGE	32-233R1
UK 1551 PR	04 AL	THE SERVICE STATES	251894
UK 1552 PR	04 AU IN RE 80 FL RE 80 FL	IGHT CONTROLS - AIRBRAKE OPERATING CIRCUI NDSCREEN DE-ICING HAND PUMP	T 252174 PT A,B,C

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN : AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

		3000	BULLETIN DE SERVICE DE REF
	H AEROSPACE		
HS 12	5 SERIES		
(CONTI	NUED / SUITE)		
UK	1553 PRE 80	FLAP OUTED HINGE ACCEMBLY	
UK	1554 PRE 80	COCKPIT WINDOW PANEL (C)	252300 PT D&E
UK	1555 PRE 80	ELICUT CONTODU C	252410
UK	1557 PRE 80	VINCE	252426
UK	1558 PRE 80	FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE WINGS ALBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME	252442
	1556 PRE 60	WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT	252454
UK	1559 PRE 80 1560 PRE 80	FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET	252578
UK	1560 PRE 80	ENGINE AIR - BLOW-OFF VALVE SWITCHES	252580
UK	1561 PRE 80	FUSELAGE - RADOME	252626 PT A.B.C
UK	1563 PRE 80	WINGS - FLAP OUTBOARD HINGE	252670
UK	1564 PRE 80	AIRBORNE AUXILIARY POWER	252675
UK	1565 PRE 80	FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE	252705
UK	1569 PRE 80	NAVIGATION - ALTITUDE ALERTING UNIT	257500
UK	1571 PRF 80	AIR CONDITIONING - MIXING VALVE	CD 04-440
UK	1573 PRF 80	FAIRCHILD A100 COCKRIT VOICE DECORDED	SD 21-119
UK	1574 PPE 90	ELECTRICAL DOWER BUS DAD PROTECTION LINES	SB 23-A20
UK	1574 FRE 80	ELECTRICAL POWER - BUS BAR PROTECTION UNIT	SB 24-141
UK	1578 PKE 80	FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY	SB 26-A18
UK	1582 PRE 80	FUEL - FILTER DE-ICING SYSTEM	SB 28-A23
UK	1585 PRE 80	FUEL - DISTRIBUTION	SB 28-69
UK	1586 PRE 80	HYDRAULIC POWER - FLOW INDICATOR UNITS	\$B 29-60
UK	1587 PRE 80	LANDING GEAR - EMERGENCY BRAKE	SB 32-166
UK	1588 PRE 80	LANDING GEAR - EMERGENCY BRAKE REDUCING VALVE	SB 32-167
UK	1589 PRE 80	LANDING GEAR - NOSE LEG DRAG STAY ASSEMBLY	SB 32-184R5
UK	1593 PRE 80	OXYGEN - STORAGE CYLINDER	SB 35-422
UK	1596 PRF 80	OXYGEN - MASTER VALVE	SB 35-29
UK	1597 PRF 80	FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - FILTER DE-ICING SYSTEM FUEL - DISTRIBUTION HYDRAULIC POWER - FLOW INDICATOR UNITS LANDING GEAR - EMERGENCY BRAKE LANDING GEAR - EMERGENCY BRAKE REDUCING VALVE LANDING GEAR - MOSE LEG DRAG STAY ASSEMBLY OXYGEN - STORAGE CYLINDER OXYGEN - STORAGE CYLINDER OXYGEN - MASTER VALVE FUSELAGE - FRONT PRESSURE BULKHEAD WINDOWS - CABIN WINDOW PANELS WINDOWS - COKPIT WINDOW PANEL 'C' WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - AILERON INNER HINGE ASSEMBLY WINGS - FLAP OUTER HINGE BANK/PITCH INDICATION	SR 53=43
UK	1500 DDE 00	FUSELAGE - CANODY DOCT A-P	SD 53-43
UK	1598 PRE 80	FUSELAGE - CANUPY PUST A-B	SB 53-46
UK	1599 PRE 80	FUSELAGE - FRUNT PRESSURE BULKHEAD	SB 53-46A TO Q
UK	1600 PRE 80	FUSELAGE - FRONT PRESSURE BULKHEAD	53-46Q TO S
UK	1601 PRE 80	WINDOWS - CABIN WINDOW PANELS	SB 56-15
UK	1602 PRE 80	WINDOWS - COCKPIT WINDOW PANEL 'C'	SB 56-A16
UK	1603 PRE 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-44
UK	1604 PRE 80	WINGS - UPPER AIRBRAKE ASSEMBLY	SB 57-A49
UK	1605 PRE 80	WINGS - AILERON INNER HINGE BRACKET ASSEMBLY	SB 57-51
UK	1606 PRF 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-54
UK	1607 PPF 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-55
UK	1609 PRE 80	WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - FLAPS OUTBOARD HINGES ELECTRICAL POWER GYROSCOPIC BANK/PITCH INDICATION MANDATORY LIFE LIMITATIONS AIRBORNE AUXILIARY POWER FUEL - RUBBER FLAP VALVE WING FILLER CAP FLIGHT CONTROLS - AILERON, RUDDER & ELEVATOR TRIM	SB 57-58
UK	1000 PRE 80	ELECTRICAL DOWER CYPOSCOPIC PANY PITCH INDICATION	NOTICE NO 91
UK	1610 PRE 80	ELECTRICAL POWER GYROSCOPIC DANK/PITCH INDICATION	MATAIT COUEDING
UK	1611 PRE 80	MANDATURY LIFE LIMITATIONS	MAINI. SCHEDULE
UK	007-11-80	AIRBURNE AUXILIARY POWER	SB 49-23
UK	012-05-81	FUEL - RUBBER FLAP VALVE WING FILLER CAP	SB 28-60
UK	013-06-81	FLIGHT CONTROLS - AILERON, RUDDER & ELEVATOR TRIM	SB 27-130
UK	014-01-81	ELECTRICAL POWER - FUEL COMPUTERS	SB 24-225
UK	014-08-81	LANDING GEAR - LOWER MAIN GEAR	SB 32-190
UK	015-08-81	ENGINE - TURBINE INTERSTAGE TRANSITION DUCT	SB 72-1
UK	001-12-82	STABILIZERS - ATTACHMENT FITTINGS	SB 55-33
UK	006-01-82	AIR CONDITIONING BAE DYNAMICS GROUP COLD-AIR UNIT	SB 21-123
UK	006-10-83	FLIGHT CONTROLS - AILERON, RUDDER & ELEVATOR TRIM ELECTRICAL POWER - FUEL COMPUTERS LANDING GEAR - LOWER MAIN GEAR ENGINE - TURBINE INTERSTAGE TRANSITION DUCT STABILIZERS - ATTACHMENT FITTINGS AIR CONDITIONING BAE DYNAMICS GROUP COLD-AIR UNIT LANDING GEAR - WHEELS AND BRAKES LANDING GEAR - JACK CYLINDER HEAD ATTACHMENT LUGS ELECTRICAL POWER - PANEL "ZL"	SB 32-193
UK	007-10-83	LANDING GEAR - JACK CYLINDER HEAD ATTACHMENT LUGS	SB 32-A197
	010-04-83	ELECTRICAL POWER - PANEL "ZL" ELECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS LANDING - MAIN GEAR DOORS	SB 24-220
UK	010-04-83	ELECTRICAL POWER FEEDER FUSES ON DANEL "71"	SB 24-239
UK	011 04 85	COMMUNICATIONS AUDIO INTECDATING SYSTEMS	CD 22-21
UK	046-04-83	LANDING MAIN CEAD DOODS	SB 32-200
UK	003-06-84	ELECTRICAL POWER - PANEL "ZL" ELECTRICAL POWER FEEDER FUSES ON PANEL "ZL" COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS LANDING - MAIN GEAR DOORS LANDING - MAIN WHEFI S - WHEFI FLANGE	SP 22-201
UK	005-07-84	LANDING GEAR - MAIN WHEELS - WHEEL FLANGE	SD 32-201
UK	004-08-85	POWER PLANT - ENGINE MOUNTINGS	SD /1-38
UK	005-10-85	ELECTRICAL POWER - CABLE INSTALLATION	SB 24-255
UK	005-11-85	LANDING - MAIN GEAR DOORS  LANDING GEAR - MAIN WHEELS - WHEEL FLANGE POWER PLANT - ENGINE MOUNTINGS ELECTRICAL POWER - CABLE INSTALLATION ENGINE - TURBINE INTERSTAGE TRANSITION DUCT AIRBORNE AUXILIARY POWER AIRBORNE AUXILIARY POWER	SB 72-3
UK	006-02-86	AIRBORNE AUXILIARY POWER	49~32-(9210A)
UK	007-02-86	AIRBORNE AUXILIARY POWER	49-31-(9286A)
UK			57-66
	015-10-86	ELECTRICAL POWER EMERG. CONTACTOR LOWER TERMINAL	
UK	002-03-87	FLIGHT CONTROLS - ELEVATOR MASS BALANCE	SB 27-142R3
UK	010-03-87	ENGINE - REAR MOUNTING	72-4
UK	017-01-87		72-1-2844AR2
UK	003-09-88	TONDING THE CONTROL TO THE CONTROL OF THE CONTROL O	
UK	007-02-88	THE STATE OF THE S	32-216R1
UK	008-02-88	NOSE GEAR PIVOI PIN	32-217
UK	008-06-88	MAIN LANDING GEAR DOOR FORWARD HINGE FITTING	32-218
UK	012-05-88	ELECTRICAL POWER - DC BUS-TIE SYSTEM	24-264R1
UK	004-06-89		51-4
UK	012-07-89	WARMING OVEN	25-54-9758A&BR1
		NOSE LANDING GEAR SIDEWALL CRACKS	53-73R2
UK	005-08-90	CORROSION - WINGS TOP SKIN BENEATH BOUNDRY FENCE	57-73R1
UK	012-08-91	WINGS - CRACKS TOP SKIN	57-75R2
UK	013-08-91	WINGS - CRACKS TOP SKIN	
			ATPODART / AFRONERS

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE) SUBJECT

ORIGINE ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
BRITIS	H AEROSPACE		
HS 12	5 SERIES		
UK	NUED / SUITE) 015-12-91	FUEL FEED PIPE JOINTS WARMING OVEN DIODES - BOTTLE GONE INDICATORS FUSELAGE - DRAIN MASTS HYDRAULIC ACCUMULATORS FAN VENTURI MOTOR	28-87
UK	003-08-92	WARMING OVEN	25-64-9758C
UK	012-12-92	DIODES - BOTTLE GONE INDICATORS	26-33R1
UK	017-01-92	HVDDALLI TO ACCUMULATORS	53-74-3193C&DR1
UK	011-02-94	FAN VENTURI MOTOR	21-A150
US	89-18-13	SUNSTRAND TURBOMACH T-62T SERIES APU (STC'S)	2. 4,00
HS 12	5 600A ( HS	S 125 SERIES )	
CF	CF-94-03	SUNSTRAND TURBOMACH APU SEALANT	49-72-02
UK	56-A12	DEDCORY DI LOTTO TOLLIONISTICO DI CONTROLLO	
UK	1556 PRE 80	NAVIGATION - PITOT HEAD	252436
UK UK	15/5 PRE 80	LIGHTS - INSTRUMENT DANE: LIGHTING	SB 24-178
UK	1592 PRE 80	NAVIGATION WEATHER RADAR SYSTEMS	SB 33-A18 SB 34-A134
UK	012-02-87	ELECTRICAL POWER CABIN PRESSURE SEAL BUNGS LIGHTS - INSTRUMENT PANEL LIGHTING NAVIGATION WEATHER RADAR SYSTEMS FUSELAGE - OUTER SKIN LIGHTS PASSENGER COMPARTMENT	SB 53-63
UK	024-07-90 010-02-94	LIGHTS PASSENGER COMPARTMENT	33-43R1
US	97-21-05	HIGH PRESSURE DAYGEN HOSE ASSEMBLIES	24-310-3544A&B
		PERSPEX PLASTIC TRANSPARENCIES INSPECTION NAVIGATION - PITOT HEAD  ELECTRICAL POWER CABIN PRESSURE SEAL BUNGS LIGHTS - INSTRUMENT PANEL LIGHTING NAVIGATION WEATHER RADAR SYSTEMS FUSELAGE - OUTER SKIN LIGHTS PASSENGER COMPARTMENT 6 VOLT LIGHTING-CIRCUIT BREAKER HIGH PRESSURE OXYGEN HOSE ASSEMBLIES	00 40
HS 12	5 <b>700A SERIES</b> CF-90-04		
UK	1550 PRE 80	AUXILIARY POWER UNIT T-62T SERIES FLIGHT CONTROLS FLAP CENTRE HINGE	251894
UK	1550 PRE 80 1551 PRE 80	FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT	OFO474 DT + D =
UK UK	1552 PRE 80	WINDSCREEN DE-ICING HAND PUMP	252194
UK	1553 PRE 80	COCKPIT WINDOW PANEL (C)	252300 PT D&E
UK	1555 PRE 80	WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE WINGS - LEADING EDGE	252410 252426
	1557 PRE 80	WINGS - LEADING EDGE	252442
UK	1558 PRE 80	WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT	252454
UK	1560 PRE 80	ENGINE AIR - BLOW-OFF VALVE SWITCHES	252578 252580
UK	1561 PRE 80	WINGS - LEADING EDGE WINGS ALBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME FLECTRICAL POWED - LIGHTS BEACON	252626 PT A,B,C
UK	1562 PRE 80 1563 PRE 80	ELECTRICAL TOWER LIGHTS BEACON	202603
	1564 PRE 80	WINGS - FLAP OUTBOARD HINGE AIRBORNE AUXILIARY POWER	252670 252675
UK	1565 PRE 80	AIRBORNE AUXILIARY POWER  FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH NAVIGATION - ALTITUDE ALERTING UNIT AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY FUEL - PRESSURE REFUEL / DEFUEL SYSTEM  FUEL - PRESSURE REFUEL / DEFUEL SYSTEM	252705
UK	1569 PRE 80 1571 PRE 80	NAVIGATION - ALTITUDE ALERTING UNIT	257583
	1573 PRE 80	FAIRCHILD A100 COCKPIT VOICE RECORDED	SB 21-119 SB 22-420
UK	1574 PRE 80	ELECTRICAL POWER - BUS BAR PROTECTION UNIT	SB 24-141
UK	1578 PRE 80 1582 PRE 80	FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY	SB 26-A18
	1583 PRE 80	FUEL - FILTER DE-ICING SYSTEM	SB 28-A23
UK	1584 PRE 80	FUEL - PRESSURE REFUEL / DEFUEL SYSTEM LANDING GEAR - EMERGENCY BRAKE	SB 28-67
UK UK	1587 PRE 80	LANDING GEAR - EMERGENCY PRAKE	22 20 400
	1588 PRE 80 1589 PRE 80	LANDING GEAR - EMERGENCY BRAKE REDUCING VALVE LANDING GEAR - NOSE LEG DRAG STAY ASSEMBLY LANDING GEAR - WHEELS AND BRAKES	SB 32-167
UK	1590 PRE 80	LANDING GEAR - WHEELS AND BRAKES	SB 32-184R5 SB 32-188
UK	1592 PRE 80	LANDING GEAR - WHEELS AND BRAKES NAVIGATION WEATHER RADAR SYSTEMS OXYGEN - STORAGE CYLINDER FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - CANDPY POST A-B FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - FRONT PRESSURE BULKHEAD WINDOWS - CABIN WINDOW PANELS	SB 34-A134
UK	1592 PRE 80 1593 PRE 80 1597 PRE 80	UXYGEN - STORAGE CYLINDER	SB 35-A22
UK	1597 PRE 80 1598 PRE 80 1599 PRE 80	FUSELAGE - CANOPY POST A-R	SB 53-46
UK	1599 PRE 80	FUSELAGE - FRONT PRESSURE BULKHEAD	SB 53-46A TD Q
UK	1600 PRE 80 1601 PRE 80	FUSELAGE - FRONT PRESSURE BULKHEAD	53-46Q TO S
UK	1602 PRE 80	WINDOWS - CABIN WINDOW PANELS WINDOWS - COCKPIT WINDOW PANEL 'C'	SB 56-15 SB 56-A16
UK	1603 PRE 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-44
UK UK	1604 PRE 80	WINGS - UPPER AIRBRAKE ASSEMBLY	SB 57-A49
UK	1605 PRE 80 1606 PRE 80	WINGS - AILERON INNER HINGE BRACKET ASSEMBLY WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-51
UK	1607 PRE 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-54 SB 57-55
UK	1608 PRE 80	WINGS - FLAPS OUTBOARD HINGES	SB 57-58
UK UK	1609 PRE 80 1610 PRE 80	POWER PLANT - STARTER / GENERATOR CABLES ELECTRICAL POWER GYROSCOPIC BANK/PITCH INDICATION	SB 71-A28
UK	1611 PRE 80		NOTICE NO.81 MAINT. SCHEDULE
UK	007-11-80	AIRBORNE AUXILIARY POWER	SB 49-23
UK UK	012-05-81 012-06-81	FUEL - RUBBER FLAP VALVE WING FILLER CAP	SB 28-60
UK	013-06-81	ELECTRICAL POWER FLIGHT CONTROLS - AILERON, RUDDER & ELEVATOR TRIM	SB 24-230 SB 27-120
UK	014-01-81	ELECTRICAL POWER - FUEL COMPUTERS	SB 24-225
UK	014-08-81	LANDING GEAR - LOWER MAIN GEAR	SB 32-190
	AET /AEDONIEEC		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

	NOMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
RRITIS	SH AEROSPACE		
	5 700A SERIES		
	NUED / SUITE)		
UK	015-08-81	ENGINE - TURBINE INTERSTAGE TRANSITION DUCT EQUIPMENT / FURNISHINGS - IPECO SEATS	SR 72-1
UK	016-12-81	EQUIPMENT / FURNISHINGS - IPECO SEATS	SB 25-45
UK	006-01-82	AIR CONDITIONING BAE DYNAMICS GROUP COLD-AIR UNIT	SB 21-123
UK UK	006-10-83	LANDING GEAR - WHEELS AND BRAKES	SB 32-193
UK	007-10-83 010-04-83	LANDING GEAR - JACK CYLINDER HEAD ATTACHMENT LUGS	
UK	011-04-83	ELECTRICAL POWER - PANEL "ZL" ELECTRICAL POWER FEEDER FUSES ON PANEL "ZL"	SB 24-220
UK	046-04-83	COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 24-239
UK	003-06-84	LANDING -MAIN GEAR DOORS	32 200
UK	005-07-84	LANDING GEAR - MAIN WHEELS - WHEEL FLANGE	SB 32-201
UK	004-08-85	POWER PLANT - ENGINE MOUNTINGS	SB 32-201 SB 71-38
UK	005-10-85	ELECTRICAL POWER - CABLE INSTALLATION ENGINE - TURBINE INTERSTAGE TRANSITION DUCT AIRBORNE AUXILIARY POWER	SB 24-255
UK UK	005-11-85	ENGINE - TURBINE INTERSTAGE TRANSITION DUCT	SB 72-3
UK	006-02-86 007-02-86	AIRBORNE AUXILIARY POWER AIRBORNE AUXILIARY POWER	49-32-(9210A)
UK	015-10-86	WINGS - AILERON MASS BALANCE	49-31-(9286A)
UK	002-12-87	FLECTRICAL POWER - CIDCUIT RDEAVED LARGES	57-66 24-263-9486R1
LIV	010-02-07	ELICHT CONTROLC ELEVATOR MASS CALANCE	SB 27-142R3
UK	012-02-87	FUSELAGE - OUTER SKIN	SB 53-63
UK	012-02-87 017-01-87	ENGINE - REAR MOUNTING	72-4
OK	003 03 66	ENGINE - TURBINE INTERSTAGE TRANSITION DUCT	72-1-2844A
UK	007-02-88	MAIN LANDING GEAR SIDESTAY	32-216R1
UK	007-06-88	ENGINE FIRE EXTINGUISHER	26-28
UK	008-02-88	NOSE GEAR PIVOT PIN	32-217
UK UK	008-06-88 012-05-88	MAIN LANDING GEAR DOOR FORWARD HINGE FITTING	32-218
UK	012-05-88	ELECTRICAL POWER - DC BUS-TIE SYSTEM WARMING OVEN	24-264R1
	005-08-90	NOSE LANDING GEAR SIDEWALL CRACKS	25-54-9758A&BR1 53-73R2
UK	025-02-91	ENGINE FIRE EXTINGUISHER ELECTRICAL CONNECTIONS	26-31
UK	012-12-92	DIODES - BOTTLE GONE INDICATORS	26-33R1
US	89-18-13	SUNSTRAND TURBOMACH T-62T SERIES APU (STC'S)	
US	95-08-06	STATIC INVERTER	
US	97-03-07	INSPECT MLG SIDESTAY JACK PIVOT	32-233R2
HS 12	5 700A ( HS	125 700A SERIES )	
CF		AILERON CONTROL CABLES	
CF	CF-94-03	SUNSTRAND TURBOMACH APU SEALANT	49-72-02
UK	014-08-90	GENERATOR CONTROL UNIT	24-A278
UK	014-11-90	STANDBY INVERTER COVER	24-279-3255A
UK	024-07-90	GENERATOR CONTROL UNIT STANDBY INVERTER COVER LIGHTS PASSENGER COMPARTMENT	33-43R1
UK	006-08-91	FUEL FEED FIFE OUTNIS	24-289-3267R1 A TO G
UK UK	009-12-91	CORPOSION - WINGS TOP SKIN BENEATH BOUNDRY FENCE	57-73R1
UK	012-08-91	CARIN AND TOTLET LIGHTING	33-45-25A027A&BR2
UK	008-10-92	BATTERY & CONTACTOR MOUNTING	24-293-3501ABCDEFR2
UK			53-74-3193C&DR1
UK	029-05-92	HYDRAULIC ACCUMULATORS	29-89-3269A
UK	010-02-94	HYDRAULIC ACCUMULATORS 6 VOLT LIGHTING-CIRCUIT BREAKER FAN VENTURI MOTOR	24-310-3544A&B
UK		FAN VENTURI MOTOR	21-A150
US	97-21-05	HIGH PRESSURE OXYGEN HOSE ASSEMBLIES	35-46
BAF 1	25 800A		
CF	CF-90-04	AUXILIARY POWER UNIT T-62T SERIES	
CF	CF-90-09	AILERON CONTROL CABLES	
CF	CF-94-03	SUNSTRAND TURBOMACH APU SEALANT	49-72-02
UK	30-25	ICE PROTECTION SYSTEM - METERING PUMPS	30-25
UK	32-227R1	MLG - INSP. OF SIDESTAY ARM AND TORQUE LINKS	32-227R1 49-45
UK	49-45	APU FUEL FEED HOSE FLIGHT CONTROLS FLAP CENTRE HINGE	251894
UK	1550 PRE 80	FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT	
UK	1551 PRE 80	FLIGHT CONTROLS - AIRBRAKE OPERATING CIRCUIT	252194
UK	1552 PRE 80	FLAP OUTER HINGE ASSEMBLY	252300 PT D&E
UK	1554 PRE 80	WINDSCREEN DE-ICING HAND PUMP FLAP OUTER HINGE ASSEMBLY COCKPIT WINDOW PANEL 'C' FLIGHT CONTROLS - FLAP INBOARD HINGE	252410
1.114	1555 PRE 80	FLIGHT CONTROLS - FLAP INBOARD HINGE	252426
UK	1557 PRE 80	WINGS - LEADING EDGE	252442
UK	1558 PRE 80	WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT	252454
UK	1559 PRE 80	FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET	252578
UK	1560 PRE 80	WINGS - LEADING EDGE WINGS AIRBRAKE OUTBOARD HINGE BRACKET ATTACH. BOLT FLIGHT CONTROLS - ELEVATOR CONTROL PULLEY BRACKET ENGINE AIR - BLOW-OFF VALVE SWITCHES FUSELAGE - RADOME WINGS - FLAP OUTBOARD HINGE	252626 PT A,B,C
UK	1561 PRE 80	HINGS - ELAD OUTROADD HINGS	252670
			252675
UK	1564 PRE 80	FLIGHT CONTROLS ELEVATOR PITCH TRIM SWITCH	252705
UK	1303 PKE OU	TEXALL SOMETHOUS ELECTRICAL FILE CONTROL OF THE CON	

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF SUBJECT SUJET

Г	DDITIC	1 AEDOCDACE		
		H AEROSPACE 25 800A		
		UED / SUITE)		
	UK	1569 PRE 80		257583
	UK UK	1571 PRE 80 1573 PRE 80	AIR CONDITIONING - MIXING VALVE FAIRCHILD A100 COCKPIT VOICE RECORDER ELECTRICAL POWER - BUS BAR PROTECTION UNIT FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY ELLE - ELLED DE-ICING SYSTEM	SB 21-119 SB 23-420
	UK	1574 PRE 80	FLECTRICAL POWER - BUS BAR PROTECTION UNIT	SB 24-141
1	UK	1578 PRE 80	FIRE PROTECTION WIRE CONTROL UNIT ASSEMBLY	SB 26-A18
	UK	1582 PRE 80	TOLL TILTER DE TOTAG STSTEM	3D 20 M20
	UK	1587 PRE 80	LANDING GEAR - EMERGENCY BRAKE	SB 32-166
-	UK	1588 PRE 80 1589 PRE 80	LANDING GEAR - EMERGENCY BRAKE REDUCING VALVE LANDING GEAR - NOSE LEG DRAG STAY ASSEMBLY	SB 32-184R5
	UK	1593 PRE 80	OXYGEN - STORAGE CYLINDER	SB 35-A22
	UK	1597 PRE 80	FUSELAGE - FRONT PRESSURE BULKHEAD	SB 53-43
1		1598 PRE 80	FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - CANDPY POST A-B FUSELAGE - FRONT PRESSURE BULKHEAD FUSELAGE - FRONT PRESSURE BULKHEAD WINDOWS - CABIN WINDOW PANELS WINDOWS - CABIN WINDOW PANELS	SB 53-46
	UK UK	1599 PRE 80 1600 PRE 80	FUSELAGE - FRONT PRESSURE BULKHEAD	58 53-46A TO Q
	UK	1601 PRE 80	WINDOWS - CABIN WINDOW PANELS	SB 56-15
	UK	1602 PRE 80	WINDOWS - CABIN WINDOW PANELS WINDOWS - COCKPIT WINDOW PANEL 'C' WINGS - FLAP OUTER HINGE ASSEMBLY WINGS - UPPER AIRBRAR ASSEMBLY WINGS - ALLEDON INNER HINGE BRACKET ASSEMBLY	SB 56-A16
	UK	1603 PRE 80	WINGS - FLAP OUTER HINGE ASSEMBLY	SB 57-44
	UK UK	1604 PRE 80 1605 PRE 80	WINGS - UPPER AIRBRAKE ASSEMBLY WINGS - AILERON INNER HINGE BRACKET ASSEMBLY	SB 57-A49
	UK	1610 PRE 80	ELECTRICAL POWER GYROSCOPIC BANK/PITCH INDICATION	NOTICE NO.81
-	UK	1611 PRE 80	MANDATORY LIFE LIMITATIONS	MAINT. SCHEDULE
	UK	007-11-80	AIRBORNE AUXILIARY POWER	SB 49-23
	UK UK	012-05-81 015-08-81	FUEL - RUBBER FLAP VALVE WING FILLER CAP ENGINE - TURBINE INTERSTAGE TRANSITION DUCT	SB 28-60 SB 72-1
	UK	006-01-82	AIR CONDITIONING BAE DYNAMICS GROUP COLD-AIR UNIT	
1	UK	046-04-83	COMMUNICATIONS - AUDIO INTEGRATING SYSTEMS	SB 23-21
	UK	002-10-84	LANDING GEAR - NOSE GEAR DOOR QUICK RELEASE STRUT	
ļ	UK	003-06-84 003-12-85	LANDING - MAIN GEAR DOORS WINGS - AILERON	SB 32-200 57-64-(3067)
	UK	004-04-85	ELECTRICAL POWER - EFIS POWER SUPPLY	24-248-(3024)
	UK	004-06-85	WINGS - FLAPS	57-61-(3072A)
ļ	UK	004-08-85	POWER PLANT - ENGINE MOUNTINGS FIRE PROTECTION - FIRE EXTINGUISHING SYSTEM ELECTRICAL POWER - WINDSCREEN HEAT CONTROLLERS ELECTRICAL POWER - CABLE INSTALLATION	SB 71-38
	UK UK	005-01-85 005-04-85	FIRE PROTECTION - FIRE EXTINGUISHING SYSTEM	SB 26-A25 24-249-(3029)
	UK	005-10-85	ELECTRICAL POWER - WINDSCREEN HEAT CONTROLLERS	SB 24-255
ļ	UK	006-04-85	ELECTRICAL POWER - PANEL DA ELECTRICAL CABLES	24-250-(3017D)
	UK	006-11-85	FUSELAGE - PIPE INSTALLATION	SB 53-60
	UK	007-04-85 011-05-85	ELECTRICAL POWER UNIT EARTH CONNECTIONS FLIGHT CONTROLS FLAP MICROSWITCH	24-251-(3014A) 27-136-(3059)
	UK	012-05-85	WINGS - AILFRON	27-137-(3056)
-	UK	001-09-86	ELECTRICAL POWER - CABLE INSTALLATION PANEL ZK	SB 24-A258
	UK	003-08-86	FUSELAGE - VENTRAL TANK AFT ATTACHMENT	53-62-(3127)
	UK	006-02-86 007-02-86	AIRBORNE AUXILIARY POWER AIRBORNE AUXILIARY POWER	49-32-(9210A) 49-31-(9286A)
	UK	007-05-86	FIRE PROTECTION - FIRE WARNING SYSTEM	SB 26-27
	UK	012-06-86	FUSELAGE - CANOPY UPPER RAIL	53-59-(3031B)
	UK	014-04-86	FLIGHT CONTROLS - AILERON CENTRE HINGE	27-138-(3128)
	UK	015-10-86 016-02-86	WINGS - AILERON MASS BALANCE FIRE PROTECTION SYSTEM - FIRE DETECTOR BOX CABLING	57-66 26-26-(3101)
	UK	025-11-86	ELECTRICAL POWER - PANEL ZK	24-259-(3171B)
	UK	001-05-87	AIR CONDITIONING FLIGHT DECK SIDE CONSOLE LOUVRES	SB 21-128-3182
	UK	002-12-87 003-12-87	ELECTRICAL POWER - CIRCUIT BREAKER LABELS	24-263-9486R1
	UK	003-12-87	WINDSCREEN CENTRE PILLAR ASSEMBLY COMMUNICATIONS - HF AERIAL SYSTEM	53-65-3168AR1 SB 23-23
	UK	009-03-87	EQUIPMENT/FURNISHING MULTI-BREWER COFFEE/TEA MAKER	
	UK	010-02-87	ELECTRICAL POWER - COMPONENT INSTALLATION	SB 24-260
	UK	003-09-88	ENGINE - TURBINE INTERSTAGE TRANSITION DUCT	72-1-28444
	UK UK	005-08-88 006-06-88	AC GENERATOR CONTROL UNITS POWER PLANT-COWLINGS-ENGINE EXHAUST DUCT	24-267-3221A 71-40-3213AR2
	UK	007-02-88	MAIN LANDING GEAR SIDESTAY	32-216R1
	UK	007-06-88	ENGINE FIRE EXTINGUISHER	26-28
	UK UK	008-02-88	NOSE GEAR PIVOT PIN	32-217 5B 32-218
	UK	008-06-88 012-05-88	MAIN LANDING GEAR DOOR FORWARD HINGE FITTING ELECTRICAL POWER - DC BUS-TIF SYSTEM	SB 32-218 24-264R1
-	UK	001-01-89	ELECTRICAL POWER - DC BUS-TIE SYSTEM ELECTRICAL POWER - BATTERY POST LOCKNUTS	24-268-3223A&BR
	UK	006-11-89	MLG TORQUE LINK PIVOTS	32-222
	UK UK	012-07-89 021-03-89	WARMING OVEN	25-54-9758A&BR1
	UK	021-03-89	STALL SYSTEM ANGLE SENSOR VANE INSERT ELECTRICAL CABLE LOOMS	27-149 24-270
	UK	004-08-90	LANDING GEAR WHEELS AND BRAKES	32-A228
	UK	005-08-90	NOSE LANDING GEAR SIDEWALL CRACKS	53-73R2
L	UK	007-02-90	MLG SIDESTAYS/WING PICK-UP FITTING	32-224R1
		AFT /AFDONESS		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

		30001	BULLETIN DE SERVICE DE REF
DDIT	ISH AEROSPACE		
	125 800A		
(CON	TINUED / SUITE)		
UK	008-02-90	the standard of many transfer and the standard of the standard	
UK		MLG SIDESTAY ATTACHMENT LUG	57-72R1
UK	014-08-90	MLG SIDESTAY PIVOT	32-225
UK	024-07-90	GENERATOR CONTROL UNIT LIGHTS PASSENGER COMPARTMENT MIG. STEEL TORQUE LIDNES	24-A278
UK	002-05-91	LIGHTS PASSENGER COMPARTMENT	33-43R1
UK	005-07-91	THE STEEL TOROUGH LINKS	32-226-325/A
UK	005-07-91	WASHBASIN DRAIN OUTLET	25-67-25A013AR4
UK	009-12-91	FUEL FEED PIPE JOINTS	28-86
UK	011-10-91	GENERATOR POWER  APU IGNITION/STARTING FUSE PROTECTION COLLINS FLIGHT CONTROL COMPUTER CABIN AND TOILET LIGHTING	24-289-3267R1 A TO G
UK	013-11-91	APU IGNITION/STARTING FUSE PROTECTION	49-37-25A253A&B
UK	013-12-91	COLLINS FLIGHT CONTROL COMPUTER	22-12-25A222A
UK	014-08-91		33-45-25A027A&BR2
UK	016-04-91	RUDDER PEDAL TORQUE TUBES	27-155
UK	025-02-91	INSTRUMENT INTEGRAL LIGHTING	33-447670AR1
UK	003-08-92	ENGINE FIRE EXTINGUISMER ELECTRICAL CONNECTIONS	26-31
UK		WARMING OVEN	25-64-9758C
UK	004-08-92	FORWARD CABIN DOOR RETAINER	25-68-25A440A
UK	008-10-92		
UK	012-12-92	DIODES-BOTTLE GONE INDICATORS THRUST REVERSERS WINDSCREEN HEAT CIRCUIT BREAKER FUSEI AGE - DRAIN MASTS	26-33R1
UK	013-01-92	IMRUSI REVERSERS	78-4-9949AR1
UK	016-02-92	WINDSCREEN HEAT CIRCUIT BREAKER	24-288-3284A
	017-01-92	TO SECTION AND ADDRESS OF THE SECTION ADDRESS OF THE SE	33 74-3133CQDK1
UK UK	029-05-92	FUSELAGE - DRAIN MASTS HYDRAULIC ACCUMULATORS CORROSION-WING LEADING FOGE	29-89-3269A
UK	016-05-93	CURRUSTON-WING LEADING EDGE	57-77R1
UK	003-12-94	HYDRAULIC ACCOMULATORS  CORROSION-WING LEADING EDGE  DIODE CONNECTIONS PANELS ZL	24-317
1	011-02-94	FAN VENTURI MOTOR	21-A150
UK US	009-03-95	IMPROVED FLUID DRAINAGE IN THE FUSELAGE	53-82-3566GR2
	89-18-13	SUNSTRAND TURBUMACH 1-621 SERIES APU (SIC'S)	
US	95-08-06	STATIC INVERTER	
US US	95-15-04	WING LEADING EDGE INTERFACE JOINT	57-77
US	96-12-16 96-12-17	MODIFICATION OF FUSELAGE AFT OF WING REAR SPAR	
		INSPECTION OF SOLDERED CONNECTIONS	24-317
US	96-18-09	INSPECTION OF SOLDERED CONNECTIONS REMOVAL OF SILVER PLATED WIRING FILLING OF TWO UNUSED TOOLING HOLES INSPECT MLG SIDESTAY JACK PIVOT RUDDER MODIFICATION APU FUEL FEED HOSES HIGH PRESSURE OXYGEN HOSE ASSEMBLIES	30-61-7676A
US	96-24-16	THEREOF MIC STREETAY LACK RIVET	54-1-3815B
US	97-03-07	INSPECT MEG SIDESTAY JACK PIVOT	32-233R2
US	97-18-07	RUDDER MODIFICATION	55-36-25F017A&B
US	97-21-03	APU FUEL FEED MUSES	49-47-25A825A
US	97-21-05	HIGH PRESSURE UNIGEN HUSE ASSEMBLIES	35-46
LIAME	ER 800XP		
US		FIDE EXTINGUISHED SYSTEM	26-2107
US	98-11-13 98-23-15	FIRE EXTINGUISHER SYSTEM APU FUEL FEED HOSE	49-3018
05	98-23-15	APO TOLL TELD HOSE	45 3018
DAE	146 SERIES		
UK	146 SEKIES	MANDATORY LIFE LIMITATIONS	
	008-04-83	MANDATORY LIFE LIMITATIONS AIRBORNE AUX. POWER FUEL SOLENOID VALVE FLIGHT CONTROLS SELECTOR LEVER OVERTRAVEL	49-A1 ASB
UK	010-11-83	FIGHT CONTROLS SELECTOR LEVER OVERTRAVEL	27-124
UK	001-09-84	LANDING GEAR - MAIN GEAR	32-18
UK UK	001-10-84	DOORS GIRT BAR STOP	52-A14
	002-07-84	DOORS GIRT BAR STOP FUSELAGE WING TO FUSELAGE FAIRINGS	53-5
UK UK	002-09-84		32-9 B
UK	004-04-84	AUTOPILOT SERVO ACTUATORS	22-A9
UK	005-08-84 006-01-84	LANDING GEAR BRAKE WEAR INDICATOR PINS	32-A4
UK		AIR CONDITIONING PRESSURIZATION CONTROLLER PANEL	21-10-70032A
UK	008-06-84	ENGINE CONTROLS - CABLE ASSEMBLY	76-A16
UK	004-10-85 005-09-85	FLIGHT CONTROLS FLEVATOR CONTROL SYSTEM	27-42-006714
		FUEL CENTRE TANK SEALING	28-3-00650A
UK UK	010-05-85 001-04-86	I ANDING GEAR - DRAKES	32-A33
		ELECTRICAL POWER ESSENTIAL DC & EMERG. DC BUSBARS	24-30-00757A
UK	002-08-86	AIR CONDITIONING HYDRAULIC BAY PASSENGER COMPART.	21-24-00543A
UK	003-02-86	FLIGHT CONTROLS FLAP TORQUE LIMITER UNITS	
UK	003-05-86	EQUIPMENT EVACUATION SLIDE	25-58-35069A
UK	004-02-86	EQUIPMENT EVACUATION SLIDE	25-A57
UK	005-01-86	FIGHT CONTROLS ELECTRO-PNEUMATIC SOLENOID VALVES	27-58
UK	005-09-86	DOORS LOCKING ARM	52-55-00830A
UK	009-11-86	DOORS LOCKING ARM  EQUIPMENT EVACUATION SLIDE LANDING GEAP - MAIN GEAP ASSEMBLY	25-13-70039A
UK	011-04-86	LANDING GEAR - MAIN GEAR ASSEMBLY	32-73
UK	011-11-86	FLIGHT CONTROLS ELECTRO-PNEUMATIC SOLENOID VALVES	
UK	012-04-86	CLICUIT CONTROL C CLAR CONTROL CYCTEM	27-A54
UK	013-04-86	LANDING GEAR - BRAKES	32-A75
UK	008-03-87	FUSELAGE WING TO FUSELAGE FAIRINGS	53-67R1
UK	009-12-87	FUSELAGE REAR FUSELAGE SKIN	53-70
UK	001-03-88	FLIGHT CONTROLS - AILERON DISCONNECT UNIT	27-75-70212A&B
UK	002-07-88		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			DOCE THE DE SERVICE DE REF.
RRT	TISH AEROSPACE		
	E 146 SERIES		
	NTINUED / SUITE)		
U		CDEW DAYCEN MATAL CUDDLY OVETABLE	
Ui		CREW OXYGEN - MAIN SUPPLY CYLINDER ELEVATOR 'G' WEIGHT DAMPER	35-8
U		POWER PLANT JET PIPE TO ENGINE	27-77-00955A&CR
U		FLIGHT CONTROLS AILERON & ELEVATOR TRIM SCREWJACK	71-32-00760A
Ü	C 005-10-88	AILERON DISCONNECT UNIT	5 27-74
UF		NLG STEERING CUFF RING NUT	27-87
Ur			32-95-70409A
Uk		WINGS PINS AT LOWER CARRIAGE ON FLAP TRACK	57-24-00911A R4
Uk	014-10-88	NOSE WHEEL STEERING CUFF RING NUT AILERON DISCONNECT UNIT	32-A95R1
Uk	001-10-89	NACELLES/PYLONS - BUSH - ENG FRONT MOUNT YOKE ASS	27-88-70212C
Uk		ELEVATORS CONTROL CABLES	
Uk		FUSELAGE - REAR SECTION RIVETS SEALED LEAD ACID RATTERIES	27-A105
Uk	006-07-89	FUSELAGE - KEAK SECTION KIVETS	53-84-00737D R3
UK	019-05-89	SEALED LEAD ACID BATTERIES  ELEVATORS - MASS BALANCE WEIGHTS  FLAP ELECTRONIC CONTROL UNIT  PLACARDS & MARKINGS - FLAP COMPUTER	24-57
UK		ELEVATURS - MASS BALANCE WEIGHTS	55-7-00955D R4
UK		FLAP ELECTRONIC CONTROL UNIT	27-95-70420A R1
UK	044-09-89	PLACARDS & MARKINGS - FLAP COMPUTER WINGS - REAR SPAR ROOT JOINT ATTACHMENT FITTING LANDING GEAR - COUPLING HYDRALLIC LINES/RPAKE UNIT	11-36-01104A&BR2
UK		WINGS TREAK SPAK ROOT OUTNI ATTACHMENT FITTING	57-33 REV 5
UK		THE THE PARTY OF T	32 A 10 1
UK		INSP OF VOI-SHAN EARTH STUDS	24-60
UK		INTRODUCE EATON CORP RCCB	24-69-70484AR1
UK		PITTING CORROSION OF FUSELAGE SKINS	53-98
		PREVENT INADVERTENT PARKING BRAKE APPLICATION	32-104-01159AR2
UK UK	008-01-90	FUSELAGE SKIN RIVETS	53-87
		FUSELAGE SKIN FOR CRACKS	53-88
UK		INTRODUCE SPRING STRUTS TO FREIGHT DOOR SHAFT	52-81-56012A
UK		L/G DOOR REAR HINGE BRACKET INSPECTION	32-A119 R1
UK			FO 00 0000011 110 0-
UK		INSPECTION OF BUTT STRAP AT RIB 2 LWR WING	57-36
UK		INSPECT OF IN-LINE SPLICES APU GEN CIRCUIT	24-83R1
UK		INSPECT OF IN-LINE SPLICES IDG CIRCUITS	24~84R1
UK		BRAKE CONTROLS AND INDICATION	32-124-70491A&B R4
UK		INSP POLYMER COATING CTR FUEL TANK	29_40
UK		INSPECTION OF NLG UPPER MAIN FITTING FOR CRACKS	32-131 R3
UK		GEC PLESSY GENERATOR CONTROL UNITS	24-A97 R1
UK		PITOT STATIC SYSTEM - TAS 2 UNIT	34-132-46042AR2
UK		PITOT STATIC SYSTEM - TAS 2 UNIT PITOT STATIC SYSTEM - TAS 1 UNIT PITOT STATIC SYSTEM - TAS 1 UNIT WHEELS AND BRAKES - DUNLOP HYDRAULIC FUSE FORWARD ATTENDENTS SEATS FIRE STATES	34-131-46041AR2
UK		WHEELS AND BRAKES - DUNLOP HYDRAULIC FUSE	32-130-70295CR2
UK		FORWARD ATTENDENTS SEATS - FIRE BLOCKING	25-277-65167A
UK	015-04-91	REAR ATTENDENTS SEATS - FIRE BLOCKING	25-278-65168A
UK		WING TOP SKINS AT RIB "O"	57-41
UK		WHEELS AND BRAKES - DUNLOP HYDRAULIC FUSE FORWARD ATTENDENTS SEATS - FIRE BLOCKING REAR ATTENDENTS SEATS - FIRE BLOCKING WING TOP SKINS AT RIB "O" INSPECT FIRE EXT PIPE ASSY ATTENDANTS SEAT CUSHION FIRE BLOCKING PITOT STATIC HOSES	26-A29
UK		ATTENDANTS SEAT CUSHION FIRE BLOCKING	25-247-36079A BCD&E
UK	022-02-91	PITOT STATIC HOSES	34-128-00950JR2
UK		AIR CRUISER EVACUATION SLIDE	25-328R3
UK	005-11-92	LIFT SPOILER UPLOCK	27-137
UK	009-04-92	PITCH SERVOMOTOR	27-126
UK	010-03-92R1	ALTITUDE LIMITATIONS / FORCAST ICING CONDITIONS SMOKE DETECTION - RESONATOR TO THE WARNING HORN	ALF502R-73-12
UK	010-04-92	SMOKE DETECTION - RESONATOR TO THE WARNING HORN	26-32-36128A
UK	014-01-92	N2 LIMITATIONS FOR ANTI-ICE SELECTIONS	11-97-01285A R1
UK	018-01-92	AIRBRAKE SYSTEM	27-133
UK	002-12-95	ELEVATOR - MASS BALANCE	55-014-01510A
UK	004-12-96	WING TOP SKIN PANELS	57-50R2
UK	005-12-96 006-09-97	MLG OUTER LINK CRACKS	32-144
UK	006-09-97	RETRACTION JACK, EYEBOLT AND PISTON CORROSION	32-145R1
UK	004-03-98	ALTITUDE ICING LIMITATIONS MLG UPLOCKS & DOOR LOCKS NLG RETRACTION JACK ATTACH, BOSS - CRACKING	11-137-30405A
UK	005-12-98	MLG UPLOCKS & DOOR LOCKS	32-150-70656A
UK	015-10-98	NLG RETRACTION JACK ATTACH. BOSS - CRACKING	53-152
UK	004-09-99	INSPECT FOR LOOSE JO-BOLT FASTENERS	57-56
UK	006-09-99	INSPECT PYLON TO WING FORWARD ATTACHMENT BOLTS	
			54-10
BAE	146 200	( BAE 146 SERIES )	
UK	003-04-85	CENTRE FUEL TANK LEAKING	38-4003
UK	004-01-85	FUSELAGE OUTBOARD SEAT RAIL	28-A003
UK	006-09-85		53-13-00503A
UK	009-08-89	PASSENGER COMPARTMENT - EQUIPMENT/FURNISHINGS	22-29-00671BR2
UK	008-05-90	EVACUATION SLIDE	25-A157
UK	009-06-90	DEDI ACE CASE STRONG COMMISSION C	25-198
UK	004-09-91	REPLACE SAFE FLIGHT SUMMING UNIT WITH A -3MOD	27-109-00503CR1
UK	006-12-91	CALL PANEL MOUNTINGS INTERIOR DECOR	25-294-36108B
UK	008-12-91	DOGE BANELS	25-299-60358D
UK	002-07-93	WINDSHEAD DETECTION AND DESCRIPTION	25-303-56061A
UK	015-05-93	WINDSHEAR DETECTION AND RECOVERY SYSTEM	34-A155R2
		FIRE RESISTANT QUICK RELEASE HYDRAULIC COUPLINGS	29-31-01339A R1

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			DOLLETTIN DE SERVICE DE REF.
BRITIS	H AEROSPACE		
BAE 1	46 200	GENERATOR CONTROL SYSTEM INSPECTION OF CABLE TERMINALS ON APU START CIRCUIT AMBER WARNING LIGHT - LIFT SPOILER NOT DEPLOYED PERI-SEAL HOUSING IN BLEED AIR SYSTEM FUSELAGE FRAME 29 BOLT HOLES FASTENER HOLES IN BUTT STRAP GENERATOR CONTROL UNITS HORIZONTAL STABILIZERS-DRAIN HOLES TERMINAL BLOCK ON D.C. PANEL NO 1 - TWO WAY LINK MLG LINK SUB ASSEMBLY AILERON SERVO AND TRIM TAB DRIVE BRACKETS APU FIREWALL CRACKING ALTITUDE LIMITATION FIRE PROTECTION-SMOKE DETECT FREIGHT COMPARTMENT WINGS-TOP SKIN STRESS CORPOSION CRACKING	
(CONT II	NUED / SUITE)		
UK	023-01-93	GENERATOR CONTROL SYSTEM	24-01-70400000 00
UK	007-02-94	INSPECTION OF CABLE TERMINALS ON APIL START CIRCUIT	19-10 P1
UK	008-02-94	AMBER WARNING LIGHT - LIFT SPOTTER NOT DEPLOYED	27-70-00913A&B D11
UK	008-09-94	PERI-SEAL HOUSING IN BLEED AIR SYSTEM	36-23
UK	012-05-94	FUSELAGE FRAME 29 BOLT HOLES	53-130
UK	013-03-94	FASTENER HOLES IN BUTT STRAP	57-40
UK	014-03-94	GENERATOR CONTROL UNITS	34-103
UK	003-07-95	HORIZONTAL STABILIZERS-DRAIN HOLES	55-13-01/190RP2
UK	005-01-95	TERMINAL BLOCK ON D. C. PANEL NO. 1 - TWO WAY LINK	24-107
UK	005-08-95	MLG LINK SUB ASSEMBLY	32-142
UK	006-06-95	AILERON SERVO AND TRIM TAR DRIVE BRACKETS	57-47
UK	007-05-95	APU FIREWALL CRACKING	26-2501
UK	003-06-96R1	ALTITUDE LIMITATION	71-72-30473A (INFO)
UK	004-08-96	FIRE PROTECTION-SMOKE DETECT ERRIGHT COMPARTMENT	26-A83D1
UK	005-06-96	WINGS-TOP SKIN STRESS CORROSION CRACKING	57-/QD1
UK	001-04-97	HORIZONTAL TO VERTICAL STAB, ATTACH BRACKETS	55-15R1
UK	010-07-97	ELEVATOR HINGE BRACKET RIB CRACKING	55-16
UK	005-04-98	SKIN CRACKING FRAME 29	53-14401
UK	009-02-99	FIRE DETECTION-CHAFING DAMAGE	26-11
		APO FIREWALL CRACKING ALTITUDE LIMITATION FIRE PROTECTION-SMOKE DETECT FREIGHT COMPARTMENT WINGS-TOP SKIN STRESS CORROSION CRACKING HORIZONTAL TO VERTICAL STAB. ATTACH BRACKETS ELEVATOR HINGE BRACKET RIB CRACKING SKIN CRACKING FRAME 29 FIRE DETECTION-CHAFING DAMAGE	20 44
HS 741	8 SERIES	ELECTRICAL POWER PORTABLE FIRE EXTENGUISHERS-BROKEN TRIGGERS INSTALLATION OF AILERON CABLE SUPPORT BLOCK PROPELLER CONTROL UNIT & AUTO FEATHERING SWITCH AUTO-PILOT ELEVATOR SERVO MOTOR MOUNTING CONTROL SURFACE LOCK CIRCUIT PROPELLER CONTROL UNIT PLUGS MAIN UNDERCARRIAGE CROSS BEAM & RADIUS ROD RUDDER SPRING TAB AND TAIL CONE WING STRUCTURE STABILIZERS TAILPLANE CONSTRUCTION JOINT PLATES STABILIZERS TAILPLANE CONSTRUCTION JOINT FUSELAGE - FORMER 18F NAVIGATORS WINDOW EMERGENCY LANDING GEAR SYSTEM WINGS - GLASS FIBRE FENCE TURN AND SLIP INDICATOR TURN AND SLIP INDICATOR RESTRICTING BRACKET ELEVATOR CONTROL LEVER OXYGEN HOSES DOORS - EMERGENCY EXIT ENGINE CONTROLS AUTO FEATHER RUDDER AND RUDDER TRIM CIRCUITS LANDING GEAR NOSE LEG AIR CONDITIONING HEAT EXCHANGER FAN CONTROL PANEL	
CF	CF-95-13	ELECTRICAL POWER	
UK	004-09-02	PORTABLE FIRE EXTENGUISHERS-BROKEN TRIGGERS	26/55
UK	27-63-4602	INSTALLATION OF AILERON CARLE SUPPORT BLOCK	748-27-63-4602
UK	0050 PRF 80	PROPELLER CONTROL UNIT & AUTO FEATHERING SWITCH	727 (SR 61-2)
UK	0051 PRE 80	AUTO-PILOT ELEVATOR SERVO MOTOR MOUNTING	729 (SR 22-1)
UK	0052 PRF 80	CONTROL SURFACE LOCK CIRCUIT	735 (SB 27-12)
UK	0053 PRF 80	PROPELLER CONTROL UNIT PLUGS	862 (SB 61-2)
UK	0054 PRF 80	MAIN UNDERCARRIAGE CROSS BEAM & RADIUS ROD	938 (SB 32-13)
UK	0055 PRF 80	RIDDER SPRING TAR AND TAIL CONE	956 (SB 32 13)
UK	0056 PRF 80	WING STRUCTURE	975 (SR 57-2)
LIK	0050 FRE 80	STABILIZERS TAILPLANE CONSTRUCTION JOINT PLATES	1061 (SR 55-2)
LIK	0057 TRE 80	STABILIZERS TAILPLANE CONSTRUCTION JOINT	1100 (SB 55-4)
UK	0050 PRE 80	FUSELAGE - FORMER 18F	1216 (SB 53-4)
LIK	0000 PRE 80	NAVIGATORS WINDOW	12/0 (SB 53-15)
UK	0060 FRE 80	EMEDGENCY LANDING GEAR SYSTEM	1242 (3B 33-13)
UK	0061 FRE 80	WINGS - GLASS FIRE FING	2250 (SB 57-12)
UK	0062 FRE 80	TIIDN AND SLIP INDICATOR	2272 & 2413 (31-5)
UK	0063 PRE 60	THEN AND SLIP INDICATOR	2/12 G 2413 (31-3)
UK	0004 PRE 80	DESTRICTING REACKET ELEVATOR CONTROL LEVER	2414 (30 31 0)
UK	0065 PRE 80	MYVGEN HOSES	2264 (SB 27-33)
UK	0000 PRE 80	DOODS - EMEDGENCY EXIT	3400 (SB 53-47)
UK	0067 PRE 80	ENGINE CONTROL S ALTO FEATHER	3741 (SR 76-14)
UK	0068 PRE 80	BUDGED AND BUDGED TOTAL CIPCLITS	3826 (SB 27-54)
UK	0069 PRE 80	LANDING GEAR NOSE LEG	4046 (SB 32-45)
UK	0070 PRE 80	A ID CONDITIONING HEAT EXCHANGED FAN CONTROL PANEL	4048 (SB 31-83)
011	0071 PRE 80	DDODELLER WARNING HORN CIPCLIT	4078 (SB 61-17)
UK	0072 PRE 80	FLIGHT CONTROLS RUDDER TRIM CONTROL SCREW JACK	4341 (SB 27-61)
UK	0073 PRE 80	POLLS-POVCE DART MK 531H FNGINES	4579 (SB 71-12)
UK	0074 PRE 80	PROPERTIES PITCH COARSENING SOLENOID	4609 (SB 61-18)
UK	0075 PRE 80	FLECTRICALLY OPERATED GYRO HORIZON	4630 (SB 24-60)
UK	0076 PRE 80	RUDDER AND RUDDER TRIM CIRCUITS  LANDING GEAR NOSE LEG  AIR CONDITIONING HEAT EXCHANGER FAN CONTROL PANEL PROPELLER WARNING HORN CIRCUIT  FLIGHT CONTROLS RUDDER TRIM CONTROL SCREW JACK ROLLS-ROYCE DART MK 531U ENGINES PROPELLERS PITCH COARSENING SOLENOID ELECTRICALLY OPERATED GYRO HORIZON ELECTRICALLY OPERATED GYRO HORIZON ELECTRICALLY OPERATED GRYO HORIZON ELECTRICALLY OPERATED GRYO HORIZON ELECTRICALLY OPERATED GYRO HORIZON STABILIZERS GUSSET PLATES TAILPLANE/ELEVATOR HINGE GUSSET PLATES AILERON OUTBOARD // CENTRE HINGE AILERON SPAR OUTBOARD HINGE POSITION	4631 (SB 24-61)
UK	0077 PRE 80	FLECTRICALLY OPERATED GRYD HORIZON	4693 (SB 24-68)
UK	0078 PRE 80	ELECTRICALLY OPERATED GVPO HORIZON	4852 (SB 24-67)
UK	0079 PRE 80	STABILITERS GUSSET PLATES TATLELANE/FLEVATOR HINGE	4872 (SR 55-12)
UK	0080 PRE 80	CHISSET PLATES ATTERON OUTROARD / CENTRE HINGE	4873 (SB 57-28)
UK	0081 PRE 80	GUSSET PLATES ATLERDIN DOI BOARD / CENTRE HINGE ATLERON SPAR OUTBOARD HINGE POSITION WINGS REINFORCING PLATES STARBOARD REAR DIAPHRAGM	4874 (SB 57-27)
UK		WINGS REINFORCING PLATES STARBOARD REAR DIAPHRAGM	4875 (SR 57-26)
UK		ROLLS-ROYCE DART MK 533-2 ENGINES	4934 (SB 71-15)
UK	0084 PRE 80	ROLLS-ROYCE DART MK 533-2 ENGINES ROLLS-ROYCE DART MK 534-2 ENGINES	4934 (SB 71-15) 4935 (SB 71-16)
UK	0085 PRE 80		
UK	0086 PRE 80	ROLLS-ROYCE DART MK 535-2 ENGINES ROLLS-ROYCE DART MK 534-2 ENGINES	4936 (SB /1-1/) 5342&4935,71-18
UK	0087 PRE 80	EARTH BONDING SPERRY FLIGHT DATA RECORDING UNIT	5730 (SR 31-30)
UK	0088 PRE 80	FARIH BUNDING SPERKY FLIGHT DATA RECORDING UNIT	3/30 (38 31-20)
UK		AILERON CONTROL QUADRANT ASSEMBLY	0112 (SB 2/-/5)
UK	0090 PRE 80	ELECTRICAL POWER CENTRE BUSBAR PANEL	6121 (SB 24-89)
UK	0091 PRE 80	FLIGHT DATA RECORDER 115 VOLT SUPPLY	0129 (5B 31-22)
UK	0092 PRE 80	AIR CUNDITIONING - AUTO PRESSURISATION	6318 (SB21-105)
UK	0093 PRE 80	AIR CONDITIONING - AUTO PRESSURISATION PLACARDS AIRSPEED LIMITATIONS LABEL PLACARDS AIRSPEED LIMITATIONS LABEL	6370 (SB 11-3)
UK	0094 PRE 80	PLACARDS AIRSPEED LIMITATIONS LABEL	63/1 (SB 11-2)
UK	0095 PRE 80		6519 (38 61-31)
UK	0096 PRE 80		23-37
UK	0097 PRE 80	CENTRE BUSBAR & PORT & STARBOARD GENERATOR PANELS	24-25

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT SUJET REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			COLLET THE BE CENTREDE BE REF.
DDITI	SIL AFROCRAGE		
	SH AEROSPACE		
HS 7	'48 SERIES		
(CONT	INUED / SUITE)	FLAP MOTOR SUPPLY FUSE FLOOR LASHING FITTINGS GRAVINER FIRE EXTINGUISHER ENGINE NACELLE ELEVATOR CONTROL LEVER ASSEMBLY FLIGHT CONTROLS TRIM CIRCUIT CHAINS RUDDER CENTRE HINGE POSITION CONTROL SYSTEM GUST LOCKS FUEL TANK VENT PIPE FUEL SYSTEM CROSS FEED PIPES INTERNAL REFUELLING RESTRICTOR VALVE MAIN HYDRAULIC PRESSURE MANIFOLD BLOCK	
UK	0098 PRE 80	FLAP MOTOR SUPPLY FUSE	····
l uk	0099 PRF 80	ELOOD LACUING FITTING	A24-26
UK	0100 PRF 80	FLOOR LASHING FITTINGS	25-157
UK	0100 PRE 80	GRAVINER FIRE EXTINGUISHER ENGINE NACELLE	A26-6
UK	0101 PRE 80	ELEVATOR CONTROL LEVER ASSEMBLY	A27-7
UK	0102 PRE 80	FLIGHT CONTROLS TRIM CIRCUIT CHAINS	07 45
UK	0103 PRF 80	PUDDED CENTRE HINCE DOCTTION	2/-15
UK	0104 PPE 90	CONTROL CENTRE FINGE POSITION	A27-62
UK	0104 116 80	RUDDER CENTRE HINGE POSITION CONTROL SYSTEM GUST LOCKS FUEL TANK VENT PIPE FUEL SYSTEM CROSS FEED PIPES INTERNAL REFUELLING RESTRICTOR VALVE MAIN HYDRAULIC PRESSURE MANIFOLD BLOCK NOSE LANDING GEAR AXLE ASSEMBLY MAIN UNDERCARRIAGE CROSS BEAM	27-76
UK	0105 PRE 80	FUEL TANK VENT PIPE	28-7
UK	0106 PRE 80	FUEL SYSTEM CROSS FEED PIPES	28-8
UK	0107 PRE 80	INTERNAL REFUELLING RESTRICTOR VALVE	20 0
UK	0108 PRF 80	MAIN HYDRAUL TO DESCRIPE MAILTON OF DESCRIP	28-23
UK	0109 PRE 80	MANIFOLD BLUCK	29-23
	0103 FRE 80	NOSE LANDING GEAR AXLE ASSEMBLY	A32-9
UK	0110 PRE 80	MAIN UNDERCARRIAGE CROSS BEAM	32-12
UK	0111 PRE 80	WEATHER RADAR INSTALLATION	21-10
UK	0112 PRE 80	PITOT PRESSURE PIDE	34-10
UK	0113 PRE 80	EMERCENCY EVIL BANG C TAL BURGE	34-57
UK	O114 DDF 80	EMERGENCY EXIL PANELS IN FUSELAGE	52-21
	0114 PRE 80	UVERWING EMERGENCY EXIT PANELS OPERATING MECHANIST	M A52-82
UK	0115 PRE 80	NOSE LANDING GEAR RETRACTION JACK MOUNTING BOLTS	53-16
UK	0116 PRE 80	NOSE LANDING GEAR RETRACTION JACK MOUNTING BOLTS	50 10
UK	0117 PRE 80	FIRST AGE LARGE EREIGHT DOOR AREDTURE	53-18
UK	0118 PRF 80	NOSE LANDING GEAR AXLE ASSEMBLY  MAIN UNDERCARRIAGE CROSS BEAM  WEATHER RADAR INSTALLATION PITOT PRESSURE PIPE EMERGENCY EXIT PANELS IN FUSELAGE OVERWING EMERGENCY EXIT PANELS OPERATING MECHANISI NOSE LANDING GEAR RETRACTION JACK MOUNTING BOLTS NOSE LANDING GEAR RETRACTION JACK MOUNTING BOLTS FUSELAGE LARGE FREIGHT DOOR APERTURE NACELLES JACK MOUNTING BRACKET	53-43
UK	0110 PRE 00	NACELLES JACK MOUNTING BRACKET	54-7
	0119 PKE 80	NACELLES ENGINE SUBFRAME	54-25 R6
UK	0120 PRE 80	ELEVATOR OUTER HINGE STRUCTURE	55-11
UK	0121 PRE 80	TAILPLANE CENTRE TORSION BOX & OUTED TATLOLANDS	55-11
UK	0122 PRE 80	NACELLES JACK MOUNTING BRACKET NACELLES ENGINE SUBFRAME ELEVATOR OUTER HINGE STRUCTURE TAILPLANE CENTRE TORSION BOX & OUTER TAILPLANES WINGS ADDITIONAL RIVETS ALLERON OUTER HINGE BRACKET STRUCTURE WINGS STRUCTURE RIB 70 TO RIB 134 WINGS RIB 134. 366, PORT & STARBOARD WINGS RIB 134. 366, PORT & STARBOARD WINGS RIB 134. 366, PORT & STARBOARD WINGS REVISED INSPECTION INBOARD MAIN UNDERCARRIAGE PIVOT BRACKET FORGINGS PROPELLER CONTROL ELECTRICAL CIRCUIT WIRING ENGINE MOUNT FRAME SUPPORT TUBES ENGINE CONTROLS CABLES AUTO FEATHER INHIBIT. MICRO-SWITCH OPERAT. LEVERS LANDING GEAR CROSSBEAM & RADIUS ROD NOSE UNDERCARRIAGE AXLE	55-19
UK	0123 PPE 90	ATI COM OUTTONAL RIVERS	57-6
UK	0120 TRE 80	AILERON DUTER HINGE BRACKET STRUCTURE	57-25
UK	0124 PRE 80	WINGS STRUCTURE RIB 70 TO RIB 134	57-34R7
UK	0125 PRE 80	WINGS RIB 134. 366, PORT & STARBOARD	57-46
UK	0126 PRE 80	WINGS RIB 134 366 PORT & STAPROARD	57 40
UK	0127 PRE 80	WINGS - REVISED INSPECTION	57-48
UK	0128 PRF 80	INROADD MAIN UNDERCARDIAGE DAVICE DELCARDO	57-55R5
UK	0129 PRF 80	PROPERTY ON ONDERCARRIAGE PIVOT BRACKET FORGINGS	57-59
UK	0120 PRE 80	PROPELLER CONTROL ELECTRICAL CIRCUIT WIRING	61-30
UK	0130 PRE 80	ENGINE MOUNT FRAME SUPPORT TUBES	71-2
UK	0131 PRE 80	ENGINE CONTROLS CABLES	76-1
UK	0132 PRE 80	AUTO FEATHER INHIBIT MICRO-SWITCH OPERAT LEVERS	70 1
UK	0133 PRE 80	LANDING GEAR CROSSREAM & BADTUS DOD	76-15 R4
UK	0134 PRE 80	NOSE UNDERCARRIAGE AXLE MAIN UNDERCARRIAGE CROSSBEAM & RADIUS ROD UNITS AXLE ASSEMBLY OF NOSE UNDERCARRIAGE MAIN UNDERCARRIAGE CROSSBEAM & RADIUS ROD NOSE UNDERCARRIAGE AXLES	32-8E
UK	0135 PRE 80	MA TALLIADERCARRIAGE AXLE	32-15E
UK	0137 PRE 80	MAIN UNDERCARRIAGE CROSSBEAM & RADIUS ROD UNITS	32-20E
	0107 FRE 80	AXLE ASSEMBLY OF NOSE UNDERCARRIAGE	32-43F
UK	0138 PRE 80	MAIN UNDERCARRIAGE CROSSBEAM & RADIUS ROD	32-49E
UK	0139 PRE 80	NOSE UNDERCARRIAGE AXLES	22-505
UK	0140 PRE 80	NOSE UNDERCARRIAGE AXLES	32-365
UK	0141 PRE 80	MAIN INDEPCARRIAGE LACK EVE FAIR FATTANCE	32-75E
UK	0142 PRE 80	MATALINDERCAPITACE DACK ETE-END FITTING	32-78E
UK	0143 DDE 90	MATIV UNDERCARRIAGE RETRACTION JACK	32-84E
UK	0144 PDF 80	MAIN UNDERCARRIAGE CROSS BEAM	32-85E
UK	0144 PRE 80	NOSE UNDERCARRIAGE JACK	32-91F
UK	0145 PRE 80	GYROSCOPIC BANK & PITCH INDICATORS	
UK	0146 PRE 80	MANDATORY LIFE LIMITATIONS	
UK	005-07-80	MAIN UNDERCARRIAGE CROSSBEAM & RADIUS ROD NOSE UNDERCARRIAGE AXLES NOSE UNDERCARRIAGE AXLES MAIN UNDERCARRIAGE AXLES MAIN UNDERCARRIAGE JACK EYE-END FITTING MAIN UNDERCARRIAGE CROSS BEAM NOSE UNDERCARRIAGE CROSS BEAM NOSE UNDERCARRIAGE JACK GYROSCOPIC BANK & PITCH INDICATORS MANDATORY LIFE LIMITATIONS WINGS STRINGER BRACKET FASTENERS WINGS STRINGER BRACKET FASTENERS PLACARDS AIRSPEED LIMITATIONS FLIGHT MANUAL AMENDMENT SPERRY HORIZONTAL SITUATION INDICATORS	
UK	006-07-80	WINGS STRINGER PRACKET FASTENERS	57-62
UK	012-09-80	PLACADOC AZORGER BRACKET FASTENERS	57-63
UK	042 40 80	PLACARDS AIRSPEED LIMITATIONS	11-4
UN	042-12-80	FLIGHT MANUAL AMENDMENT	71-22
UK	002-06-81	SPERRY HORIZONTAL SITUATION INDICATORS	24/102
UK	004-09-81	DOORS - LARGE EREIGHT DOOR	54/103
UK	005-09-81	DOORS - LARGE EREIGHT DOOR	52-79
UK	008-07-81	DOORS EARGE FREIGHT DOOR	52-84
UK	009-07-01	LANDING	A52-90
	040 40 84	LANDING GEAR BRAKE UNIT	32-A930
UK	010-10-81	PLACARDS AIRSPEED LIMITATIONS FLIGHT MANUAL AMENDMENT SPERRY HORIZONTAL SITUATION INDICATORS DOORS - LARGE FREIGHT DOOR DOORS - LARGE FREIGHT DOOR DOORS LANDING GEAR BRAKE UNIT FLIGHT CONTROLS - PLATE SEPARATORS FLIGHT CONTROLS GUST LOCK & H.P. COCK CIRCUITS FLIGHT CONTROLS AILEDON	27-01
UK	013-10-81	FLIGHT CONTROLS GUST LOCK & H.B. COCK CIRCUITS	2/-01 ALEBE THE - /-
UK	018-09-81	FLIGHT CONTROLS AILERON	ALERT TX 2/81
UK	052-04-81	AIR CONDITIONING AUTO PRESSURISATION	27-80
UK	053-04-81	CDERRY HORIZONING AUTO PRESSURISATION	21/106
UK	005-02-82	STERRY HORIZONTAL STIUATION INDICATOR	34/102
		ENGINE HYDRAULIC BY-PASS VALVE	29-34
UK	012-07-82	LARGE FREIGHT DOORS	
UK	001-01-83	DOORS SECONDARY LOCK MECHANISM MICRO SWITCHES	52-100
UK	001-03-83	ELEVATOR CONNECTING DOD DELL CONTROL	52-106
UK	001-10-83	ELEVATOR CONNECTING ROD BELL CRANK LEVERS	27-93
UK	002-01-83	GUST LOCKS	27-98
UK	002-02-03	FLIGHT CONTROLS GUST LOCKS	27-88
	002-03-83	REAR PRESSURE BULKHEAD	53-49R1
UK	002-10-83	WINGS - STRUCTURE - RIB 134,366	
UK	003-01-83	A H EPON TENSTON DECLI ATOD	57-75R3
UK	004-01-83	CREW / ERETGHT DOOR LOCKING MEGULANISM LEVILLE	27-92
		THE TOTAL BOOK LOCKING MECHANISM LEVERS	52-101
ATRON	DAET /AEDONIEEO		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

	H AEROSPACE		
CONT II	8 SERIES NUED / SUITE)		
UK	005-01-83	STANDARD DOOR UNSAFE AUDIBLE WARNING SYSTEM	
UK	008-01-83	PUWER SUPPLY DIODES FOR INTERCOM & V H F	52-109 23-44
UK	009-01-83	MIN. STANDARD DOOR UNSAFF AUDIR F WARNING SYSTEMS	52-110
UK	012-01-83 002-08-84	DOUR MICRO SWITCH MOUNTINGS & STRIKERS	52-96
UK	003-08-84	WINGS - CENTRAL REINFORCING STRAPS WINGS - CENTRAL REINFORCING STRAPS	57-81R2
UK	005-01-84	FLIGHT CONTROLS - CROSS SHAFT / CENTRE CONSOLE	57-82R2
UK	008-07-84	OVERWING ESCAPE HATCH	EO 11E
UK	008-10-84	D.C. GENERATOR CENTRE BUSBAR TO BATTERY BUSBAR	24-104
UK	014-05-84 004-12-85	EMERGENCY LIGHTING	33-29
UK UK	004-12-85	FLIGHT CONTROLS - RUDDER GUST LOCK STANDBY HORIZON NORMAL / EMERGENCY SWITCH NAVIGATION ELECTRICAL WIRING	27-109
ÜK	010-04-85	STANDBY HORIZON NORMAL / EMERGENCY SWITCH NAVIGATION ELECTRICAL WIRING SUPPLEMENTARY STRUCTURAL INSPECTION DOCUMENT EXHAUST - JET PIPE DOORS - OVERWING ESCAPE HATCH NACELLES - ENGINE SUB-FRAME	34-115
UK	010-09-85	SUPPLEMENTARY STRUCTURAL INSPECTION DOCUMENT	SR 12-11 DEV 2
UK	011-04-85	EXHAUST - JET PIPE	SB 78-9
UK	011-09-85	DOORS - OVERWING ESCAPE HATCH	52-127
UK UK	013-05-85	NACELLES - ENGINE SUB-FRAME PLACARDS FLOOR LOAD LIMITATION DUNLOP BRAKE ACCUMULATOR ASSEMBLY NOSE LANDING GEAR JACK SUPPORT BRACKET ENGINE SUBFRAME / WING ATTACHMENT ASSEMBLY	54-23
UK	002-03-86	PLACARDS FLOUR LUAD LIMITATION	11-6
UK	013-11-86	NOSE LANDING GEAR JACK SUPPORT REACKET	29-42 452-52
UK	026-11-86	NOSE LANDING GEAR JACK SUPPORT BRACKET ENGINE SUBFRAME / WING ATTACHMENT ASSEMBLY STABILIZERS - ELEVATORS	54-29
UK	003-04-87	STABILIZERS - ELEVATORS	55-24R1
UK	006-03-87	FLIGHT CONTROLS	
UK UK	007-02-87	ENGINE SUBFRAME / WING ATTACHMENT ASSEMBLY STABILIZERS - ELEVATORS FLIGHT CONTROLS PLACARDS LARGE FREIGHT DOOR INTERIOR TRIM LARGE FREIGHT DOOR LOCKING MECHANISM PLACARDS - BAGGAGE LOADING TOLLET WATER HEATER	11-7
UK	008-07-87	LARGE FREIGHT DOOR LOCKING MECHANISM PLACARDS - BAGGAGE LOADING	11-0
UK	023-05-87	TOILET WATER HEATER	25-183
UK	026-05-87	PLACARDS - BAGGAGE LOADING TOILET WATER HEATER UNDERVOLTAGE WARNING INDICATOR 115/26 VOLT STEP DOWN TRANSFORMER APU OIL FILLING WARNING LABELS	24-97 REV 8
UK	027-05-87	115/26 VOLT STEP DOWN TRANSFORMER	24-121
UK UK	005-03-88 008-08-88	STABILIZERS - TAILPLANE CENTRE SECTION TORSION BOX	49-6R1
UK	008-09-88	POWER PLANT - ROLLS ROYCE DART MOD 1857	73-18
UK	009-08-88	EYE BOLT - ENGINE SUBFRAME ASSEMBLIES	54-31
UK	010-08-88	LH & RH MAIN LANDING GEAR DOOR	A32-80
UK	011-11-88	POWER PLANT - ROLLS ROYCE DART MOD 1857  EYE BOLT - ENGINE SUBFRAME ASSEMBLIES  LH & RH MAIN LANDING GEAR DOOR  LABEL - OXYGEN CHARGE VALVE  FLIGHT CONTROLS - RUDDER SPRING TAB  ELECTRICAL POWER CABLE  FLIGHT CONTROLS	35-25R1
UK UK	015-11-88	FLIGHT CUNTRULS - RUDDER SPRING TAB	27-114 R3
UK	003-01-89	FLIGHT CONTROLS	27-101R1
UK	004-02-89	NLG JACK SUPPORT BEAM	53-55
UK	008-03-89	ELECTRICAL POWER CABLE FLIGHT CONTROLS NLG JACK SUPPORT BEAM POWER SUPPLY STARBOARD BUSBAR WATER SEPARATOR FILTER FLEMENTS	24-119R1
UK	008-07-89	WATER SUPPLY STANDARD BUSDAM WATER SEPARATOR FILTER ELEMENTS DOORS - OVERWING ESCAPE HATCH OPERATING LEVER FLIGHT CONTROLS - FLAPS LANDING GEAR SELECTOR LEVER ASSEMBLY FLIGHT CONTROLS - FLAPS INSPECT FOR CRACKS LG STEE4RING JACK INSPECT LG NORMAL SELECT LEVER ASSY	30-34
UK	017-07-89	FLIGHT CONTROLS - FLAPS	27-112R2
UK	028-01-89	LANDING GEAR SELECTOR LEVER ASSEMBLY	A32-81
UK	029-01-89 007-08-90 009-12-90 012-08-90	FLIGHT CONTROLS - FLAPS	27-111
UK	007-08-90	INSPECT FOR CRACKS LG STEE4RING JACK	32-11E R1
	009-12-90	INSPECT LG NORMAL SELECT LEVER ASSY REVISION OF MOD OF CROSSBEAM ATTACH PIN SECURITY OF RING NUT LOCKING NOSE LANDING GEAR	32-83 32-60F P2
UK UK	012-08-90	SECURITY OF RING NUT LOCKING NOSE LANDING GEAR	32-101E
UK	016-10-90 018-10-90 022-11-90 001-02-91	REVISION OF MOD OF CROSSBEAM ATTACH PIN SECURITY OF RING NUT LOCKING NOSE LANDING GEAR PORTABLE FIRE EXTINGUISHERS (SEE MISC. AD'S) ONE TIME INSPECTION OF FLAP TRACKS	FFE A26-106
UK	022-11-90	ONE TIME INSPECTION OF FLAP TRACKS	57-86R1
UK	001-02-91	INSPECT NOSE LANDING GEAR RETRACT JACK BRACKET INSPECT WING ROOT JOINT STRAPS	
UK	004-04-91	INSPECT WING ROUT OUTNI STRAPS	57-87
UK	004-04-91 017-04-91 018-04-91	ATTERON SPRING LOADING LEVER HALF CLIP	27-119
	009-02-93	INSPECT WING ROOM OOTH STRAFS INTRODUCE RETURN SPRING ON DOOR AILERON SPRING LOADING LEVER HALF CLIP LANDING GEAR - COMPONENT SAFE LIFE LIMITS IMPROVEMENTS TO HYD SYS HIGH PRESS FILTER MODIFIED BRAKE PRESSURE SWITCHES	32-104E
UK	010-12-93	IMPROVEMENTS TO HYD SYS HIGH PRESS FILTER	29-45R2
UK	011-12-93	MODIFIED BRAKE PRESSURE SWITCHES ENGINE MOUNT STRUCTURE "W" FRAME SOCKET FITTING	748-32-94 R1 HS748-71-33
UK	002-09-94	RETRACTION JACK MOUNTING BRACKET	748-53-59-INSP
UK	007-05-94		HS748-A-32-95
UK	007-07-94	AILERON CABLE SUPPORT BLOCK	748-27-63-4602 R4
1.112	000 OF-01	AILERON CABLE PULLEY GUARD	748-27-70-5244 REV 2
UK	007-11-95	AILERON OPERATING ARM BRACKET  CABLE TENSION REGULATORS, GUST LOCKS, PRESS SEALS	748-27-124
UK	005-02-96	CABLE TENSION REGISTATIONS, GOST EGGRS, TRESS SEAES	A27-128 R2
UK	008-12-96 005-02-97		HS748-29-49
UK			
HS 748	2A	( HS 748 SERIES )	
110 = 1	00	( HS 748 SERIES )	
HS 748	28	(110 / 110 0 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110 0 110	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			BULLETIN DE SERVICE DE REF.
BRIT	ISH AEROSPACE		
311			
CF		ALTERNATE MEANS OF COMPLIANCE FLAP TORQUE SHAFT	27 140000 1000
CF		FLAP LIMITS MODIFICATION	27-A-JA920340R2 27-A-JA910541R3
UK	0, 00	WINGS - ACCESS PANEL W33	57-A~JM-5220R1
UK		ELEVATOR	07 4 144700000
UK		PROPELLER BLADES	61~A-JA 841025
UK		PROPELLER BLADES PROPELLER DE-ICING SYSTEM PROPELLER ANTI-ICE CURRENT	30-JM 7453R2
UK		PROPELLER ANTI-ICE CURRENT	30-A-JM 7387
UK		POWERPLANT - REAR TURBINE BEARING OIL PIPE FUEL SYSTEM CROSSFEED PIPE	71-A-JM7418
UK		EMERGENCY LIGHTING POWER PACKS	28-JM 7161
UK		AIR CONDITIONING - BLEED AIR PRE-COOLER PIPE	33-A-JM7431R1
UK		WINGS - AILERON SHROUD	
UK			57-JA 831005R1
UK		FLYING CONTROLS FLAP LIFT DUMP SELECTORS	27-AJM 9002R1
UK	006-05-84 007-04-84	HYDRAULICS SHUT-OFF COCKS	29-JM-7226
UK	007-05-84	FUSELAGE STRINGERS	53-JM7297
UK	008-05-84	TAIL NAVIGATION LIGHTS FUSELAGE DRAIN HOLE	33-A-JA-840410
UK	009-05-84	WINGS - BONDING POINT	53-JM-7389
UK	001-11-85	DICHT UDDED CENTRE DAME.	57-JM-7298
UK	003-06-85		24-A-JM7490R1
UK	004-03-85	AILERON SERVO CABLES	24-UA850518R2
UK	005-02-85	WING SPIGOT HOUSING DIATE	27-A-JA841132R1
UK	006-12-85 009-10-85	NOSE GEAR - TORQUE TOP CAP BOLTS	32-1484082701
UK	012-04-85	NOSE GEAR - TORQUE TOP CAP BOLTS WINGS - SPIGOT FUSELAGE STATION 199 MAIN LANDING GEAR DOOR	57~A-JA850941
UK	012-09-85		32-A-JA840318R2
UK	012-11-85	WING FUEL TANK ACCESS PANELS AUTOPILOT AND ELECTRIC TRIM	57-JM5232D1
UK	013-04-85	AUIOPILOT AND ELECTRIC TRIM WINGS - BOTTOM SKIN AT LANDING GEAR BAY ENGINE MOUNTING STRUCTURE ATTACHMENT BOLTS FLYING CONTROL BOBBINS	22-A-JA851141
UK	013-09-85	ENGINE MOUNTING STRUCTURE ATTACHMENT BOLTS	57-JM-7314R1
UK	014-01-85	FLYING CONTROL BOBBINS	71-JA850625
UK	014-05-85	HYDRAULICS LEADING EDGE	27-JM9002
UK	014-09-85	WARNING SIGN MAIN ENTRANCE DOOR/TOLLET DOOR	29-JA-840508R1
UK	015-05-85 015-09-85		32-A-JA850127R2
UK	016-09-85	FUSELAGE - NOSE EQUIPMENT BAY	53-A-JA850610
UK	001-08-86	MAIN DC FLEXIBLE BUSBAR	24-A-JA850648
UK	003-01-86	NOSE LANDING GEAR CYLINDER MAIN LANDING GEAR PINTLE HOUSING ELEVATOR TRIM SERVO CABLE	32-A-JA860412R2
UK	004-12-86	ELEVATOR TRIM SERVO CABLE	32-A-JA851226R3
UK	005-06-86	AILERON DRIVE QUADRANT STUD SECURING NUT	22-A-JA861023R3 27-JM5257
UK	006-12-86 009-02-86	AUTUPILUI	22-A-JA861215
UK	010-04-86	FLAP TORQUE SHAFT ASSEMBLIES	27-JA840421
UK	011-06-86	AUTOPILOT ELEVATOR TRIM SERVO MOTOR	22-A-JA860413
UK	003-02-87	FUEL ACTUATED BALL VALVES	
UK	004-02-87	PRIMARY FLYING CONTROL CABLES BALL END FITTING MAIN LANDING GEAR CYLINDER	27-A-JA870210R1
UK	007-09-87	CABLE CLEARANCE ESSENTIAL BUSBAD	32-0A860812R1
UK	020-09-87	ENGINE CONTROLS GROUND IDLE	24-A-JM7631
UK	024-05-87 001-04-88	NLG RETRACTION JACK	76-A-JM7620R1 53-A-JA870510R1
UK	002-06-88	PROPELLER FEATHERING SYSTEM	76-A-JA880440R1
UK	003-03-88	ENGINE CONTROL - PROPELLER GOVERNOR	76-A-JA880442R1
UK	003-10-88	FLIGHT CONTROLS- GUST LOCKS	27-JM7561R1
UK	004-09-88	26V AC INVERTER CABLES - CIRCUIT BREAKERS LELAND ASH 674-3, -33 STATIC INVERTER	24-A-JA7672A R1
UK	004-10-88	FLAP TORQUE SHAFT UNIVERSAL JOINTS	24-A-JA-880640
UK UK	011-06-88	WINGS - INSPECTION WING DID OC	27-A-JA881041R2
UK	012-06-88	FLIGHT CONTROLS-BRAKE MSTP CVI TNDER /PURDER DEDALG	57-A-JA880144R2
UK	019-11-88 006-07-89		26-A-JA881142R1
UK	007-11-89	SEALED LEAD ACID BATTERIFS	MI-89 ISSUE 2
UK	010-03-89	BOLT - MAIN DOOR RESTRAINT CABLE	52-A-JM7704
UK	012-10-89	HYDRAULICS - EMERGENCY SELECTOR VALVE FLT COMP SMOKE - IND-300 WEATHER RADAR INDICATOR	29-A-JA881143
UK	027-01-89	ELECTRICAL POWER - TORQUE / STALL TEST	34-JA 890444
UK	002-03-90	ELECTRICAL - INVERTER SYNCHRONIZATION LINES	24-JM7657A R2
UK	003-03-90	SHURIENED CABLE LOOMS #'S 1 & 2 VERTICAL GYROSCORE	24-A-JM7708R1
UK	009-02-90 012-11-90	PADEN I COOKESCEN) LIGHTING & PHWED HATT WIDING	33-A-JA 891240R3
UK	031-04-90	INTRODUCTION OF INVERTER	24-JM 7740
UK	005-05-91	AC MAIN CONTROL SWITCH WIRES	04 4 44
UK	006-05-91	FUEL WATER DRAIN VALVE WHEEL RETAINING NUT	28-JM5354
UK	007-05-91	POWER LEVER CONTROL CABLES	32-A-JA910140
UK	007-12-91	ESCAPE HATCH FITTING	76-A-JA910542R3
UK	008-09-91	POWERPLANT-POWER LEVER	52-JM7752
AIRC	RAFT/AERONEFS		71-JM7755R1

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

			BOLLETIN DE SERVICE DE REF
	H AEROSPACE		
3112	NUED / CUITE)		
UK	NUED / SUITE) 009-10-91	ENGINE CONTRACTOR OF THE CONTR	
UK	012-06-91	ENGINE CONTROL-STOP CIRCUIT	80-A-JA911045R1
UK	014-01-91	HYD. POWER - EMERGENCY SELECTOR VALVE LANDING GEAR TOP CAP	29-JA901242R1
UK	017-01-91	HYDRAULIC POWER HANDLE STOWAGE	32-JA901040R3 29-JM7360R1
UK	017-03-91	FLYING CONTROLSICING CONDITIONS	27-A-JA910340R1
UK	006-10-92	FIRE PROTECTION-FIRE BOTTLE HOSES	26-A-JA920401
UK	009-10-92	PIPES AND HOSES IN TAIL UNIT DECING	30-A-JA920444R1
UK	015-02-92	DOORS-TAPER PIN INSPECTION	52-A-JA911140R2
UK	028-05-92	AUTO RELIGHT LATCHING RELAYS	74-JM7693AR3
UK	004-02-93	WINDOWS-INSPECTION OF LEFT AND RIGHT PILOTS W/S	56-JA920843R1ERRATUM
UK	007-02-93 008-02-93	WING/FUSELAGE FORWARD ATTACH SPIGOT BUSHES	57-A-JA920640
UK	008-02-93	AILERON CONTROL SYSTEM MOUNTING SPIGOTS	57-JA921140R1
UK	010-08-93	DOORS-INTERNAL DOOR HANDLE DOOR RIGGING	52-A-JA930901R1
UK	012-10-93	WINGS-INSPECTION OF SPIGOT HOUSING PLATE	52-JM7793R1 57-JA930941R2
UK	014-05-93	WING-LOWER SKIN AND LOWER FRONT SPAR	57-JA921203
UK	003-04-94	CORROSION PREVENTION AND CONTROL PROGRAMME	MANUAL REF. JS/CPCP/1
UK	002-10-96	NOSE LANDING GEAR-TOGGLE ATTACHMENTS	32-JA960601R1
UK	005-03-96	MLG PINTLE TO CYLINDER INTERFACE CRACKING	32-JA960142
UK	006-08-96	WINDSHIELD WIPER-ARM ASSY, SERVICE LIFE (ERRATUM)	30-JA 950641R2
UK	006-10-96	AUTO FLIGHT-TRIM RELAYS	22-JK 2628R2 ERR #1
UK	003-12-97	STALL WARING-REMOVAL OF GROUND INHIBIT	27-A-JM7847R1
UK UK	003-07-98	MLG BRAKE UNITS WEAR INDICATORS	32-A-JA980540
UK	003-09-98 006-10-98	NLG WHEEL STEERING JACK SEALS NOSE WHEEL STEERING-FEEDBACK SYSTEM	32-JA900942R6 & ERR1
UK	007-07-98	ELEVATOR BIAS SPRING ASSEMBLY BEARING	32-A-JA980840R3 ERR 27-A-JA980606R1
UK	007-10-98	NOSE WHEEL STEERING SELECTOR VALVE	32-JA980841R1
UK	11-A-JA880140	PLACARDS & MARKINGS - INDICATED AIRSPEED	CAN.CERT. AIRCRAFT
UK	012-03-99	NOSE LANDING GEAR-STEERING JACK	32-JA-981043
3212			
CF	CF-96-01	ALTERNATE MEANS OF COMPLIANCE FLAP TORQUE SHAFT	27-JA920340R2
UK	004-10-88	FLAP TORQUE SHAFT UNIVERSAL JOINTS	27-A-JA881041R2
UK	012-06-88	FLIGHT CONTROLS-BRAKE MASTER CYLINDER/RUDDER PEDAL	
UK	007-11-89	BOLT - MAIN DOOR RESTRAINT CABLE HYDRAULICS - EMERGENCY SELECTOR VALVE	52-A-JM7704 29-A-JA881143
UK UK	010-03-89 012-10-89	FLT COMP SMOKE - IND-300 WEATHER RADAR INDICATOR	34-JA 890444
UK	002-03-90	ELECTRICAL - INVERTER SYNCHRONIZATION LINES	24-A-JM7708R1
UK	009-02-90	CABIN FLUORESCENT LIGHTING & POWER UNIT WIRING	33-A-JA 891240R3
UK	012-11-90	INTRODUCTION OF INVERTER	24-JM 7740
UK	031-04-90	AC MAIN CONTROL SWITCH WIRES	24-A-JA900443R3
UK	005-05-91	FUEL WATER DRAIN VALVE	28-JM5354
UK	006-05-91	WHEEL RETAINING NUT	32-A-JA910140
UK	007-05-91	POWER LEVER CONTROL CABLES	76-A-JA910542R3 52-JM7752
UK	007-12-91	ESCAPE HATCH FITTING POWERPLANT-POWER LEVER	71-JM7755R1
UK	008-09-91	ENGINE CONTROL-STOP CIRCUIT	80-A-JA911045R1
UK UK	009-10-91 012-06-91	HYD. POWER - EMERGENCY SELECTOR VALVE	29-JA901242R1
UK	014-01-91	LANDING GEAR TOP CAP	32-JA901040R3
UK	024-06-91	WINGS-MAIN SPAR ACCESS	57-JM8160R2
UK	001-09-92	WINGS-JOGGLED DOUBLERS	57-A-JA920540
UK	006-10-92	FIRE PROTECTION-FIRE BOTTLE HOSES	26-A-JA920401
UK	007-10-92	INDICATING/RECORDING-FDR	31-A-JA921050
UK	009-10-92	PIPES AND HOSES IN TAIL UNIT DECING	30-A-JA920444R1
UK	014-02-92	RUDDER GUST LOCK	27-A-JM7771R1 57-JM8175R1
UK	015-01-92	COLD WORKED HOLES AT MAIN SPAR DOORS-TAPER PIN INSPECTION	52-A-JA911140R2
UK	015-02-92	AUTO RELIGHT LATCHING RELAYS	74-JM7693AR3
UK	028-05-92	WINDOWS-INSPECTION OF LEFT AND RIGHT PILOTS W/S	56-JA920843R1ERRATUM
UK	004-02-93	WINGS-BOTTOM SKIN INSPECTION	57-JA930640R1
UK UK	004-09-93 007-03 <b>-</b> 93	WINGS-INSPECTION OF SPIGOT HOUSING PLATE	57-JA921144R3
UK	008-02-93	AILERON CONTROL SYSTEM MOUNTING SPIGOTS	57-JA921140R1
UK	008-12-93	WINGS LOWER SKIN INSPECTION	57-JA930848R1
UK	009-12-93	DOORS-INTERNAL DOOR HANDLE	52-A-JA930901R1
UK	010-08-93	DOOR RIGGING	52~JM7793R1
UK	003-04-94	CORROSION PREVENTION AND CONTROL PROGRAMME	MANUAL REF. JS/CPCP/1
UK	002-10-96	NOSE LANDING GEAR-TOGGLE ATTACHMENTS MLG PINTLE TO CYLINDER INTERFACE CRACKING	32~JA960601R1 32~JA960142
UK	005-03-96	WINDSHIELD WIPER-ARM ASSY, SERVICE LIFE (ERRATUM)	
UK	006-08-96	STALL WARING-REMOVAL OF GROUND INHIBIT	27-A-JM7847R1
UK	003-12-97	HYDRAULIC POWER COMPONENTS CORROSION	29-A-JA970940R1
UK	001-02-98 001-04-98	MAIN LANDING GEAR BAY AUX. SPAR	57-A-JA980441R1
UK	001 04 30		

(SERIES / SERIE) MODEL / MODELE ORIGIN AD NUMBER
ORIGINE NUMBER DE CONSIGNE REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. BRITISH AEROSPACE 3212 (CONTINUED / SUITE) MLG BRAKE UNITS WEAR INDICATORS

NLG WHEEL STEERING JACK SEALS

NOSE WHEEL STEERING-FEEDBACK SYSTEM

ELEVATOR BIAS SPRING ASSEMBLY BEARING

27-A-JA980606R1 003-07-98 UK UK 003-09-98 006-10-98 HK 007-07-98 007-10-98 NOSE WHEEL STEERING SELECTOR VALVE
003-09-99 FUEL TANK WIRING
012-03-99 NOSE LANDING GEAR-STEERING JACK 32-JA980841R1 UK 28-A-JA990841R1 HK 32~JA-981043 4112 EARTH POST FAILURE UK O01-09-93 EARTH POST FAILURE

O03-10-93 REAR CABIN ATTENDANT SEAT

O05-06-93 BULKHEAD DECOMPRESSION VENTS

O05-12-93 AILERON QUADRANT BEARING

O06-04-93 AFT DOORS HINGE BRACKET

O07-04-93 ELEVATOR LOOSE RIVETS

O07-11-93 ELEV CONTROLS STRUCTURE REINFORCING 001-09-93 J41-A24-012R2 UK J41-A25-034R2 J41-25-006 LIK UK J41-A27-026R2 UK J41-A-32-004R1 HK J41-A-55-003 J41-53-012R1 UK O07-11-93 ELEV CUNTRULS STRUCTURE REIT
010-03-93 FIRE EXTINGUISHER CONTROL
010-10-93 WING REAR SPAR HARNESS
011-10-93 AILERON DRIVE QUADRANT
013-05-93 MAIN BAGGAGE DOOR SEAL
013-08-93 AILERON TAB-HINGE WIRE UK J41-A26-002 LIK J41-57-003 J41-53-011 J41-A52-016 UK UK 
 013-05-93
 MMAIN BAGGAGE DUCK JUNE
 J41-A27-020

 013-08-93
 AILERON TAB-HINGE WIRE
 J41-A27-020

 013-10-93
 BATTERY SERVICING
 J41-A52-021

 014-08-93
 MAIN DOOR WIRING LOOM
 J41-A52-021

 002-01-94
 PLACARD-ELEVATOR DECOUPLE CONTROL
 J41-32-017

 003-06-94
 MAIN LANDING GEAR TRUNNION PINS
 J41-32-017

 003-06-94
 SPOILER ACTUATORS
 J41-A27-034

 003-11-94
 ENGINE FUEL AND CONTROL
 J41-73-007

 004-06-94
 MAIN DOOR HANDRAIL ASSEMBLY
 J41-A27-036

 005-09-94
 AILERON AND ELEVATOR DISCONNECT
 J41-27-036

 006-09-94
 FLEXURAL CRACKS-OVERWING FAIRING
 J41-23-028R

 007-08-94
 HYDRAULIC CASE DRAINS
 J41-29-005

 008-08-94
 HYDRAULIC SPOILER SYSTEM
 J41-29-001

 WARDRORF DECOMPRESSION VENTS
 J41-25-018
 HK J41-A27-020 UK J41-A24-013R1 PLACARD-ELEVATOR DECOUPLE CONTROL J41-A52-O21
PLACARD-ELEVATOR DECOUPLE CONTROL J41-11-004R1 ERATUM
MAIN LANDING GEAR TRUNNION PINS J41-32-O17 ADDENDUM
SPOILER ACTUATORS ЦK UK UK ЦK J41-A27-034R2& ERRAT UK UK IJK UK J41-53-028R2 
 007-08-94
 HYDRAULIC SPOILER SYSTEM
 041-25-018

 008-08-94
 HYDRAULIC SPOILER SYSTEM
 041-25-018

 012-03-94
 WARDROBE DECOMPRESSION VENTS
 J41-25-018

 001-02-95
 STANDBY COMPASS
 J41-A34-026F

 002-05-95
 ENGINE POWER & CONDITION CONTROLS
 J41-76-013R

 002-06-95
 SEAT BELT SHACKLES
 J41-A25-061

 003-04-95
 LANDING GEAR CONTROL UNIT
 J41-A32-042

 003-05-95
 PLACARDS - MAIN ENTRANCE DOOR
 J41-11-007

 003-09-95
 LANDING GEAR CONTROL UNIT
 J41-32-044

 004-09-95
 REAR PRESSURE BULKHEAD REPAIR
 J41-53-020R

 004-11-95
 DECOMPRESSION PANEL
 J41-25-063R

 004-11-95
 DECOMPRESSION EIDERLOCK COVERS
 J41-25-063R
 UK J41-29-005 REV 2 IJK LIK UK J41-A34-026R2 UK J41-76-013R1 UK ÜK UK HK J41-53-020R4 UK 004-11-95 DECOMPRESSION PANEL
007-07-95 SEAT BASE CUSHION FIREBLOCK COVERS
008-07-95 TYPE II EXIT
009-11-95 MLG UPPER LINK DRAG BRACE ЦK J41-25-068R1 UK IJK J41-53-014R1 008-11-95 J41-32-049 UK OU1-05-96 AILERON DISCONNECT UNIT O01-12-96 FIRE PROTECTION-ENGINE & NACEL O02-02-96 DC STARTER-GENERATOR BEARINGS O02-07-96 AUTO FLIGHT-OVERHEAT OF ELICIPATION LIK J41-A27-042R1 FIRE PROTECTION-ENGINE & NACELLE FIRE EXT. UK J41-A26-007R1 IJК J41-A24-036 UK UK ЦK UK UK UK LIK UK 005-08-96 006-01-96 UK O06-01-96 FLOOR-INCORRECT INTERCOSTAL
O06-05-96 FLAP NACELLE FAIRING ATTACHMENT
O06-12-96 AILERON CONTROL - CHAIN LINKS
O07-01-96 DC GENERATION EARTH POSTS
O07-12-96 FUSELAGE - DIAPHRAGM CRACKS
O01-09-97 PAX DOOR-INCREASED DIA. 'G' LOCK ROLLERS
O02-05-97 MAIN WHEEL TIE BOLTS
O03-03-97 PAX DOOR - ROLLER GUIDE SHEAR CLEATS FLOOR-INCORRECT INTERCOSTAL HK J41-A53-030R2 UK J41-A57-015R2 UK J41-27-045 J41-24-033R3 UK UK J41-A53-023R1 POSELAGE - DIAPHRAGM CRACKS
PAX DOOR-INCREASED DIA. 'G' LOCK ROLLERS
MAIN WHEEL TIE BOLTS UK J41-A-52-059R2 UK J41-32-058R1 003-03-97 J41-A52-043R2 UK PAX DOOR - ROLLER GUIDE SHEAR CLEATS MLG DRAG BRACE LOWER LINK LOOSE BEARINGS J41-A32-O61R1
PAX DOOR - LOCK LUBRICATION J41-52-058P1 UK 003-07-97 003-07-97 UK 004-07-97 UK ELECTRICAL CONNECTORS SEALING J41-24-027 ERRATUM#1 UK MAIN BAGGAGE-REDUCED LOAD LIMITATIONS J41-11-010 004-08-97 005-03-97 UK WING UPPER SPLICE PLATE J41-57-020 UK 009-07-97 NOSE BAY SIDE PLATES J41-53-041 REAR BAGGAGE FIRE EXTINGUISHER UK 015-11-97 J41-11-020R1 005-08-98 CARGO DOOR INSPECTION J41-52-060

MAKE / CONSTRUCTEUR

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			COLLETTI DE CENTROL DE MEI.
RRITIS	H AEROSPACE		
4112	ALKOST ACL		
	NUED / SUITE)		
UK	006-09-98	FI EVATOR AND DURBER OF	
UK	007-08-98	PASSENCED LIFAR TARRACT BROWNS	J41-27-052 R1
UK	004-05-99	ELEVATOR AND RUDDER CONTROL STRENGTHENING PASSENGER HEAD IMPACT REQUIREMENTS PLACARDS AND MARKINGS-PROHIBITING PUSHBACK STANDBY FUEL BOOST PUMP - CABLE ASSY	J41-25-075
UK	005-04-99	STANDRY FUEL POOCT DUMP CARLE ACCY	J41-11-024
UK	005-04-99 005-09-99	STANDBY FUEL BOOST PUMP - CABLE ASSY ELEVATOR CONTROL CABLE TENSION REGULATOR LEVER LANDING GEAR ACTUATOR LOCKWASHER	J41-28-010R1
UK	007-09-99	LANDING GEAR ACTUATOR LOCKWASHER	J41-A-27-053
0.1	007 03 33	LANDING GEAR ACTUATUR LUCKWASHER	J41-32-068
BRITTE	N NORMAN		
	SERIES		
CF	CF-81-01	MLG TORQUE LINK PIN	105
CF	CF-94-16	CARB HEAT LABEL	135
UK	0601 PRE 80	ELICHT CONTROLS-ELEVATOR TRIM TAR ANGLE	211
UK	0602 PRE 80	FLIGHT CONTROLS-ELEVATOR TRIM TAB ANGLE	BN-2/NB/M/1/9
UK	0604 PRE 80	EQUIPMENT/FURNISHINGS SEAT WEBBING FLAP CENTRE OPERATING LEVER ELEVATOR TRIM JACK PILOT/PASSENGER SEAT CUSHION SUPPORTS FUEL PIECE FINGING - DRIVEN DIMO	DN-2/ND/M/238
UK	0605 PRE 80	FLEVATOR TRIM JACK	DIN-2/ IND/ IVI/ 4 1 /
UK	0607 PRE 80	DILOT/DASSENCED SEAT CHICHTON CURRORTS	DN-2/ND/N/468
UK	0608 PRF 80	PILOT/PASSENGER SEAT CUSHION SUPPORTS FUEL PIPE ENGINE-DRIVEN PUMP FLIGHT CONTROLS/LANDING GEAR RUDDER BAR BFAM	BN-2/SB11
UK	0609 PRE 80	FI TOUT CONTROL OF AND	DIN-2/3D11
UK	0610 PRE 80	PUDDED RAD REAM	BN-2/5B15
UK	0611 PRE 80	FUEL PIPE ENGINE-DRIVEN PUMP FLIGHT CONTROLS/LANDING GEAR RUDDER BAR BEAM ELEVATOR TRIM SYSTEM	BN-2/SD20
UK			DN 2/3D24
UK	0613 PRF 80	WING ATTACHMENT SPINDLES TAILPLANE FRONT SPAR ATTACHMENTS	BN-2/SB25 BN-2/SB27
UK	0614 PRE 80	CARRIETTOR ATR BOXES	BN-2/SB2/ BN-2/SB28
UK	0615 PRF 80	WING ATTACHMENT SPINDLES TAILPLANE FRONT SPAR ATTACHMENTS CARBURETTOR AIR BOXES FLAP OPERATING LEVER & FLAP ATTACHMENTS	RN-2/SR36
UK	0616 PRF 80	JO-BOLTS ENGINE MOUNTING FRAME ATTACHMENT BRACKETS	RN-2/SR44
UK	0617 PRE 80	JO-BOLTS ENGINE MOUNTING FRAME ATTACHMENT BRACKETS FLIGHT CONTROLS FLIGHT CONTROLS - RUDDER BAR ENGINE MOUNTING BRACKETS FRONT WING SPAR	BN-2/SB44
UK	0618 PPF 80	FLIGHT CONTROLS - PLIDDED BAD	BN-2/5045
UK	0619 PPE 80	FNGINE MOUNTING ROACKETS FRONT WING SDAD	BN-2/5B56
UK	0620 PRF 80	FLAP MICRO-SWITCH SETTING	BN-2/SB66
UK	0621 PPF 80	ATTERON MASS RALANCE ATTACHMENT	BN-2/SB67
UK	0627 PRE 80	ENGINE INDICATING SANGAMO WESTON TACHOMETERS	BN-2/SB68
UK	0623 PRE 80	FLIGHT COMPARTMENT SEAT BACKS	BN-2/SB69
UK	0624 PRE 80	SEAT LOCKING MECHANISM FLIGHT COMPARTMENT SEATS	BN-2/SB71
UK	0625 PRE 80	ENGINE MOUNTING FRAME	BN-2/SB72
UK			BN-2/SB74
UK	0625 PRE 80	FLIGHT CONTROLS - RUDDER BAR RUDDER HINGE BRACKET ELECTRICAL POWER AUDIO SYSTEM AIR INTAKE HOSE FLIGHT CONTROLS ENGINE TACHOMETER CALIBRATION	BN-2/SB76
UK	0627 PRE 80	ELECTRICAL DOWED AUDIO SYSTEM	BN-2/SB85
UK	0630 PRE 80	ATD INTAKE HOSE	DNI-0/CDOE TCC /
UK	0630 PRE 80	FLIGHT CONTROLS	BN-2/SB101
UK	0632 PRE 80	ENGINE TACHOMETER CALIBRATION	BN-2/SB103
UK	0633 PRE 80 0634 PRE 80 0635 PRE 80 0636 PRE 80 0637 PRE 80	FLIGHT CONTROLS ENGINE TACHOMETER CALIBRATION HARTZELL PROPELLER SERVICE BULLETIN 118 PROPELLER AND ENGINE CONTROLS RUDDER BAR PILLAR/SLIDER TUBE ASSEMBLY SINGLE BUCKLE SAFETY HARNESS	BN-2/SB104
UK	0635 PRE 80	PROPELLER AND ENGINE CONTROLS	BN-2/SB109
UK	0635 PRE 80	PUDDER BAR PILLAR/SLIDER TUBE ASSEMBLY	BN-2/SB111
	0636 PRE 80	SINGLE BLICKLE SAFETY HARNESS	BN-2/SB114
UK	0637 PRE 80	CLEVATOR TRIM TAR	BN-2/SB142
UK	0638 PRE 80	MAIN LINDEPCAPPIAGE LEGS	BN-2/SB134
UK	0640 BBE 80	ELEVATOR TRIM TAB MAIN UNDERCARRIAGE LEGS ELEVATOR TRIM TAB ELECTRICAL GENERATION SYSTEM CARBURETTOR AIR BOX	BN-2/SB142 ISS 4
UK	0040 PKE 80	FLECTRICAL GENERATION SYSTEM	CAA AW NOTICE NO. 82
UK	0041 FKE 80	CARBURETTOR AIR BOX	BN-2/SB144
UK UK	009-07-80	MAIN UNDERCARRIAGE SHOCK ABSORBER UNITS	BN-2/SB135 ISSUE 3
UK	010-07-80	R.F.D. LIFEJACKETS	
UK	005-09-80 009-07-80 010-07-80 018-02-82	R.F.D. LIFEJACKETS OXYGEN BREATHING SYSTEMS	BN-2/SB145
UK	013-02-82	TIP TANK FLOATS	154
UK	015-02-83	COLLINS AUTO PILOT	156
UK	019-02-82 015-04-83 016-04-83 001-05-84	WING TIP FUEL TANK CONTROLS	157
UK	001-05-84	ENGINE TACHOMETER	BN-2/NB/M/1090
UK	001-05-84	MAXIMUM ENGINE OIL PRESSURE	BN-2/NB/M/1022 ISS 3
UK	002-05-84	PILOT'S INDIVIDUAL SLIDING SEATS	BN-2/SB163
	007-06-84	TAILPLANE SKIN/STRUCTURE	131 ISS.2
UK	005-06-85	MAIN UNDERCARRIAGE UPPER TORQUE LINK ATTACH. LUGS	
UK	004-07-86	ELEVATOR MASS BALANCE	113 ISSUE 3
UK	009-08-86	HARTZELL PROPELLER - PUBL. ENTRY IN CAA CAP 473	SSID BY 001-07-94
UK	019-09-87	CENTURY AUTOPILOT	SL NO.23
		AGEING AIRCRAFT - CORROSION AFFECTING PRIMARY STRU	BN-2/SB 190 ISS 3
UK	020-02-90	UNDERVOLTAGE SENSOR	BN-2/SB 187
UK	021-02-90	MARVEL SCHEBLER CARBURETOR FLOAT	BN-2/SB.203
UK	010-10-91	PILOTS SWITCH PANEL	BN-2/SB.202
UK	020-06-91 005-09-93	NOSE WHEEL STEERING DRIVE RING CRACKS	214 ISS.2
UK	005-09-93	AUTOPILOT ELEVATOR TRIM CABLE	217
UK	007-09-94	RUDDER CONTROL CABLES	BN-2/SB.223 ISS.1
UK	009-05-95	CONTROL CABLE SWIVEL NUT BRACKET	218
UK	004-01-96	70 AMP DC GENERATION SYSTEM	228 ISS. 2
UK	00-4 01 30		

MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE) ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. BRITTEN NORMAN BN2A SERIES (CONTINUED / SUITE) WING TIP FUEL TANK MOD 004-05-96 HK BN-2/2B232 UK 007-10-96 50 A GENERATOR SYSTEM BN-2/SB.229 1116 008-10-96 MLG TORQUE LOADING OF ATTACHMENT BOLTS BN-2/SB.231 ISS.2 HK 009-10-97 WING SPAR CAPS BN2/SB.237 UK 011-10-97 NACELLE BOX STRUCTURE BN2/SB.235 UK 004-12-98 NOSE LANDING GEAR CHROME PLATING 249 LIK 005-03-99 RUDDER LOWER HINGE DOUBLER 240 UK 006-03-99 CONTROL COLUMN SLIDING TUBE 243 RN2A ( BN2A SERIES ) UK 0601 PRE 80 FLIGHT CONTROLS-ELEVATOR TRIM TAB ANGLE BN-2/NB/M/179 RN2A 6 ( BN2A SERIES ) BN2A 8 ( BN2A SERIES ) BN2A 9 ( BN2A SERIES ) BN2A 20 ( BN2A SERIES ) BN2A 21 ( BN2A SERIES ) BN2A 26 ( BN2A SERIES ) BN24 27 ( BN2A SERIES ) BN2A MK III 0630 PRE 80 UK AIR INTAKE HOSE BN-2/SB95 ISS 4 RUDDER TRIM JACK BRACKET LIK 0643 PRE 80 BN-2/NB/M/596 0645 PRE 80 RUDDER BAR BN-2/SB56 0646 PRE 80 UK RUDDER TRIM JACK LOWER MOUNTING BRACKET BN-2/SB62 UK 0647 PRE 80 FLAP HINGE ATTACHMENTS BN-2/SB63 AILERON MASS BALANCE ATTACHMENT UK 0648 PRE 80 BN-2/SB67 0649 PRE 80 UK FLIGHT COMPARTMENT SEAT BACKS BN-2/SB69 LIK 0650 PRE 80 SEAT LOCKING MECHANISM FLIGHT COMPARTMENT SEATS BN-2/SB71 0651 PRE 80 UK ENGINE MOUNTING FRAME BN-2/SB72 IJK 0653 PRE 80 ELEVATOR TRIM CABLES BN-2/SB75 LIK 0654 PRE 80 WING BOTTOM SURFACE LAMINATIONS BN-2/SB77 UK 0655 PRE 80 ELECTRICAL POWER SUPPLY AUDIO SYSTEM BN-2/SB85 UK 0656 PRE 80 DRAIN HOLES REAR FUSELAGE
REAR ENGINE FIRE DETECTION SYSTEM BN-2/SB86 HK 0657 PRE 80 BN-2/SB88 BN-2/SB89 UK 0658 PRE 80 BOLTS UNDERCARRIAGE LOWER BRACKET 0660 PRE 80 IJK PROPELLER BLADE SHANK BN-2/SB93 UK 0662 PRE 80 FLIGHT CONTROL RODS BN-2/SB101 BN-2/SB102 1 JK 0663 PRE 80 RUDDER STOP STRUCTURE 0664 PRE 80 UK ENGINE TACHOMETER BN-2/SB103 HK 0665 PRE 80 HARTZELL PROPELLER SERVICE BULLETIN 118C BN-2/SB104 0666 PRE 80 UK PROPELLER AND ENGINE CONTROLS BN-2/SB109 0667 PRE UK RUDDER BAR PILLAR/SLIDER TUBE ASSEMBLY 80 BN-2/SB111 UK 0668 PRE 80 SINGLE BUCKLE SAFETY HARNESS BN-2/SB114 UK 0670 PRE 80 MAIN UNDERCARRIAGE LEG TUBE BN-2/SB118 UK 0671 PRE 80 TAILPLANE ATTACHMENT BRACKET BN-2/SB120 UK 0672 PRE 80 RUDDER BAR PILLAR/SLIDES TUBE ASSEMBLIES BN-2/SB128 UK 0673 PRE 80 RUDDER DRIVE LEVER BN-2/SB132 UK 0674 PRE 80 MAIN UNDERCARRIAGE SHOCK ABSORBER BN-2/SB139 0675 PRE 80 ELECTRICAL GENERATION SYSTEM UK CAA AW NOTICE NO. 82 UK 006-09-80 CARBURETTOR AIR BOX BN-2/SB144 UK 012-07-80 MAIN UNDERCARRIAGE SHOCK ABSORBERS BN-2/SB133 UK 013-07-80 R.F.D. LIFEJACKETS BN-2/SB137 021-06-80 UK MOUNTING BRACKETS WING MOUNTED ENGINES BN-2/SB61 UK 006-11-81 WING/FUSELAGE ATTACHMENT PINS BN-2/146 UK 010-08-81 MANDATORY LIFE LIMITATIONS BN-2/150 UK 011-08-81 WING ENGINE NACELLE STRUCTURE BN-2/151 WING TIP TANK FUEL TRANSMITTER FLOATS
MAIN UNDERCARRIAGE UPPER TORQUE LINK ATTACH. LUGS
HARTZELL PROPELLER - PUBL. ENTRY IN CAA CAP 473 UK 019-02-82 BN-2/SB154 HK 005-03-86 BN-2/SB173 ISS 3 UK 009-08-86 SSID BY 001-07-94 UK 014-06-88 ELEVATOR TRIM TAB OPERATING ROD BN-2/SB179 UК 020-02-90 AGEING AIRCRAFT - CORROSION AFFECTING PRIMARY STRU BN-2/SB 190 ISS 3 UK 021-02-90 UNDERVOLTAGE SENSOR BN-2/SB 187 UK 010-10-91 MARVEL SCHEBLER CARBURETOR FLOAT BN-2/SB.203 UK 016-06-91 TAILPLANE ATTACHMENT BRACKETS BN2/SB.199 HK 017-06-91 UNDERCARRIAGE TOP BLOCK SUPPORT BN2/SB.200

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT

ORIG	INE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
	TEN NORMAN		
BN2	A MK III		
ÜK	TINUED / SUITE)	PILOTS SWITCH PANEL TORQUE LINK ASSEMBLIES	
UK	020-06-91 006-11-92	PILOTS SWITCH PANEL	BN-2/SB.202
UK	005-09-93	TORQUE LINK ASSEMBLIES  NOSE WHEEL STEERING DRIVE-RING CRACKS  CONTROL CABLE SWIVEL NUT BRACKET  50 A GENERATOR SYSTEM	BN-2/SB.209
UK	009-05-95	CONTROL CARLE STEERING DRIVE-RING CRACKS	214 ISS.2
UK	007-10-96	CONTROL CABLE SWIVEL NUT BRACKET	218
UK	007 10 30	SU A GENERATUR SYSTEM	BN-2/SB.229
UK	004-12-98	MING SPAK CAPS	BN2/SB.237
UK	006-03-99	CONTROL COLUMN SETEMBE THEE	249
		50 A GENERATOR SYSTEM WING SPAR CAPS NOSE LANDING GEAR CHROME PLATING CONTROL COLUMN SLIDING TUBE	243
BN2E	3 SERIES		
UK	0601 PRE 80	FLIGHT CONTROLS-ELEVATOR TRIM TAB ANGLE ENGINE MOUNTING BRACKETS FRONT WING SPAR	BN-2/NB/M/179
UK	0619 PRE 80	ENGINE MOUNTING BRACKETS FRONT WING SPAR	DN-2/ND/M/1/9
UK	0630 PRE 80	AIR INTAKE HOSE	BN-2/SB95 ISS 4
UK	015-04-83	COLLINS AUTO PILOT	450
UK	005-06-85	TAILPLANE SKIN/STRUCTURES	131 TSS 2
UK	005-12-85	MLG UPPER TORQUE LINK ATTACH LUGS	170
UK	010-10-91	MARVEL SCHEBER CARBURETOR FLOAT	BN-2/SB 203
UK	005-09-93	NOSE WHEEL STEERING DRIVE RING CRACKS	214 ISS 2
UK	005-06-95	TAILPLANE SKIN/STRUCTURES MLG UPPER TORQUE LINK ATTACH LUGS MARVEL SCHEBER CARBURETOR FLOAT NOSE WHEEL STEERING DRIVE RING CRACKS RUDDER CONTROL CABLES	BN-2/SB.223 ISS.1
UK	004-01-96	MARVEL SCHEBER CARBURETOR FLOAT NOSE WHEEL STEERING DRIVE RING CRACKS RUDDER CONTROL CABLES 70 AMP DC GENERALDN SYSTEM WING TIP FIEL TANK MOD	228 ISS. 2
UK	004-05-96	WING TIP FUEL TANK MOD	BN-2/2B232
UK	007-10-96	50 A GENERATOR SYSTEM	BN-2/SB.229
UK	008-10-96	WING TIP FUEL TANK MOD 50 A GENERATOR SYSTEM MLG TORQUE LOADING OF ATTACHMENT BOLTS WING SPAR CAPS	BN-2/SB.231 ISS.2
UK	009-10-97	WING SPAR CAPS	BN2/SB.237
UK	011-10-97	RUDDER CONTROL CABLES  70 AMP DC GENERATION SYSTEM  WING TIP FUEL TANK MOD  50 A GENERATOR SYSTEM  MLG TORQUE LOADING OF ATTACHMENT BOLTS  WING SPAR CAPS  NACELLE BOX STRUCTURE  NOSE LANDING GEAR CHROME PLATING  RUDDER LOWER HINGE DOUBLER  CONTROL COLUMN SLIDING TUBE	BN2/SB.235
UK	004-12-98	NOSE LANDING GEAR CHROME PLATING	249
UK	005-03-99	RUDDER LOWER HINGE DOUBLER	240
UK	006-03-99	CONTROL COLUMN SLIDING TUBE	243
	21	( BN2B SERIES )	
UK	0607 PRE 80	PILOTS AND PAX SEAT CUSHIONS FUEL PIPE-PUMP TO CARB	BN-2/SB 5 ISS 4
UK	0608 PRE 80	FUEL PIPE-PUMP TO CARB	11
UK	0609 PRE 80	TURNBUCKLES	15
UK	0610 PRE 80	RUDDER BAR	20
UK	0611 PRE 80	ELEVATOR TRIM WING ATTACH	24
UK	0612 PRE 80	WING ATTACH	25
UK	0613 PRE 80	CARR AIR BOY FIRE	27
UK	0614 PRE 80	CARD AIR DUX FIRE	28
UK	0615 PRE 80	TAIL PLANE SPAR CARB AIR BOX FIRE FLAP LEVER AND ATTACHMENTS ENGINE MOUNT/JO-BOLTS	36 44
UK	0616 PRE 80	ELEV AND ELEV. TRIM DRIVE CIRCUITS	49
UK	0617 PRE 80 0620 PRE 80	FLAP MICRO SWITCH	66
UK	0634 PRE 80	HADTZELL PROP	101
UK	0640 PRE 80	HARTZELL PROP ELEVATOR TRIM TAB CARB AIR BOX SHUTTER	BN-2/SB142 ISS 4
UK	005-09-90	CARB AIR BOX SHUTTER	144
UK	018-02-82	OXYGEN SYSTEM	145
UK	005-09-80 018-02-82 019-02-82 016-04-83	TIP TANK FLOATS	154
UK	016-04-83	TIP TANK CONTROLS	157
UK	007-06-84	TIP TANK CONTROLS PILOTS SEAT	163
UK	005-12-85	MLG UPPER TORQUE LINK ATTACH LUGS	170
UK	004-07-86	ELEVATOR MASS BALANCE	113 ISSUE 3
UK	020-02-90	PILOTS SEAT MLG UPPER TORQUE LINK ATTACH LUGS ELEVATOR MASS BALANCE CORROSION /AGEING AIRCRAFT UNDERVOLTAGE SENSOR	BN-2/SB.190 ISS 3
UK	021-02-90	UNDERVOLTAGE SENSOR	187
UK	020-06-91	PILOTS SWITCH PANEL	202
UK	007-09-94	AUTOPILOT ELEVATOR TRIM CABLE	217
UK	009-05-95	CONTROL CABLE SWIVEL NUT BRACKET	218
	***************************************		
BN2B	27	( BN2B SERIES )	
CF	CF-94-16	CARB HEAT LABEL	211
UK	020-06-91	PILOTS SWITCH PANEL	BN-2/SB.202
UK	007-09-94	AUTOPILOT ELEVATOR TRIM CABLE	217
UK	009-05-95	CONTROL CABLE SWIVEL NUT BRACKET	218
	ART GROB		
	SERIES	C OF C COURLING	102-2
GΥ	76-226	C OF G COUPLING	102-3
GY	89-209/2	ELEVATOR HINGES SPAR SPIGOT ASSEMBLIES	306-27 306-29
GΥ	91-5/2	SPAR SPIGOT ASSEMBLIES	300 25
_		( G102 SERIES )	
	ASTIR CS	ELEVATOR CONTROL COCKPIT AREA	102-4
GY	76-273	CABLE RELEASE PULLEYS	102-6
GY	77-235	CADEL HELLING FOLLETS	102 0

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
RIIRKHA	RT GROB		
G102	ASTIR CS ( G1	102 SERIES )	
(CONTIN	NUED / SUITE)		
			102-7
GY	78-30	AILERON DEFLECTION DURING GROUND HANDLING RUDDER CONTROL INSPECTION COVER CONTROL & ELEVATOR SYSTEM	102-8
GY	80-96	INSPECTION COVER	306-13
GV	81-126	CONTROL & ELEVATOR SYSTEM	306-16
GY	81-267	SERVICE LIFE	306-17
GY	85-98	AIRBRAKE LOCKING LEVERS IN WINGS	306-26
GΥ	92-356	INSPECTION OF THE AIRBRAKE STOPS	306-31
GY	93-041	EXTENSION OF SERVICE LIFE	306-30
GY	94-317/2	ELEVATOR SYSTEM  ELEVATOR BOLTS SERVICE LIFE AIRBRAKE LOCKING LEVERS IN WINGS INSPECTION OF THE AIRBRAKE STOPS EXTENSION OF SERVICE LIFE ELEVATOR LEVER CRACKS A/C S/NS 1001-1536	306-33
G102 A	STIR CS 77 ( C4	A2 SERIES )	
GY	76-273	ELEVATOR CONTROL COCKPIT AREA RUDDER CONTROL INSPECTION COVER CONTROL & ELEVATOR SYSTEM SERVICE LIFE	100 4
GY	78-30	RUDDER CONTROL	102-4
GY	80-96	INSPECTION COVER	306-13
GΥ	81-125/2	ELEVATOR CONTROL COCKPIT AREA RUDDER CONTROL INSPECTION COVER CONTROL & ELEVATOR SYSTEM SERVICE LIFE	306-16
GY GY	81-267	SERVICE LIFE	306-18
GY	92-356	AIRBRAKE LOCKING LEVERS IN WINGS	306-26
GΥ	93-041	EXTENSION OF SERVICE LIFE	306-31
GY	94-317/2	SERVICE LIFE AIRBRAKE LOCKING LEVERS IN WINGS INSPECTION OF THE AIRBRAKE STOPS EXTENSION OF SERVICE LIFE ELEVATOR LEVER CRACKS A/C S/NS 1601-1844	306-30
			306-33
G102 C	LUB ASTIR III ( G1	O2 SERIES )	
GY	83-91	PEDAL UNIT	306-22
GY GY	84-57	SERVICE LIFE	306-24
GY	93-041	SERVICE LIFE INSPECTION OF THE AIRBRAKE STOPS EXTENSION OF SERVICE LIFE	306-31
		EXTENSION OF SERVICE LIFE	306-30
G102 C	LUB ASTIR IIIB( G10	O2 SERIES )	
GY	83-91	PEDAL UNIT	306-22
GY	84-57	SERVICE LIFE	306-24
GY	93-041	PEDAL UNIT SERVICE LIFE INSPECTION OF THE AIRBRAKE STOPS EXTENSION OF SERVICE LIFE	306-31
			306-30
G102 S	TND ASTIR III ( G10	D2 SERIES )	
GY	83-91	PEDAL UNIT	306-22
GY GY	84-57	SERVICE LIFE	306-24
GY	84-57 92-356 93-041	INSPECTION OF THE AIRBRAKE STOPS	306-31
			306-30
G103 SI	ERIES		
GY	87-140	AFT ACTUATOR KNOB - TOW HOOK	315-32
GY	88-176	SPAR SPIGOT ASSEMBLIES	315-36
GV	89-5/2	AILERONS - MOUNTING BOLTS / NUTS	315-38
G1	32-150/2	AFT ACTUATOR KNOB - TOW HOOK SPAR SPIGOT ASSEMBLIES AILERONS - MOUNTING BOLTS / NUTS INCREASE IN SERVICE LIFE_SUPERSEDES 92-190	315-45/2
G103 TV	VIN ASTIR ( G10	)3 SERIES )	
GY	VIN ASTIR ( G10 79-258	AIR BRAKE CONTROL	400 =
GY	79-331	MAIN CONTROL UNIT FUSELAGE CENTER SECTION	103-5
GY	81-125/2	CONTROL & ELEVATOR SYSTEM	315-12
GY	81-268	SERVICE LIFE	315-15
GV	92-309/2	AIR BRAKE CONTROL  MAIN CONTROL UNIT FUSELAGE CENTER SECTION CONTROL & ELEVATOR SYSTEM SERVICE LIFE RUDDER CONTROL - PARALLEL LEVER/PEDAL SUPPORT AIRBRAKE OVER CENTRE LEVER INSPECTION OF THE AIRBRAKE STOPS	315-30
GY	92-356	INSPECTION OF THE AIRPRAKE GRODE	111 010 40
			315-49
G103 TW	/IN II (G10	3 SERIES )	
GY 8	81-53	ELEVATOR INSTALLATION	315-11
GY 8	82-132 .	SLIDE - FRONT PEDAL UNIT	315-20
GY {	84-58	SERVICE LIFE	245-20
GY 8	85-222 85-236	FRONT COCKPIT AIRBRAKE OPERATING LEVER	315-29
		OOTER ATRORAGE PIVUT LEVERS	315-31
GY 8		RUDDER LEVER / AFT STICK BULKHEAD CONTROL SYSTEM	315-33
GY 9	92-356	INSPECTION OF THE AIRBRAKE STOPS	315-37 315-49
GY .	1999-216/2	FLIGHT CONTROLS-INS/REP NUT AT REAR CONTROL STICK	TECH NOTE 315-61/0
G1024 T	WIN IT ACRO (		23/1/10/12/3/3-6/1/2
GY 8	WIN II ACRO ( G10	ELEVATOR INCIDENCE	
GY 8	32-132	ELEVATOR INSTALLATION	315-11
	34-58	SLIDE - FRONT PEDAL UNIT SERVICE LIFE	315-20
	35-222	FRONT COCKPIT AIRBRAKE OPERATING LEVER	315~26
GY 8	35-236	OUTER AIRBRAKE PIVOT LEVERS	315-29 315-31
ATDODA	ET /AEDONIEEC		313-31

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

	SUJET SUJET	BULLETIN DE SERVICE DE REF.
(CONTINUED / SUITE)	RO ( G103 SERIES )	
GY 87-168 GY 88-1 GY 88-175 GY 92-356	RUDDER LEVER / AFT STICK BULKHEAD ELEVATOR PUSH-ROD CONTROL SYSTEM INSPECTION OF THE AIRBRAKE STOPS	TM 315-33 315-34 315-37 315-49
G 109 SERIES	FLIGHT CONTROL-INS/REP NUT AT REAR CONTROL STICK	TECH NOTE 315-61/2
GY 83-6 GY 85-132 GY 86-219 GY 87-142/2 GY 92-198 GY 92-359	FLIGHT MANUAL  MAIN LANDING GEAR FLIGHT/MAINT MANUAL AMENDMENTS FUEL SHUT-OFF VALVE EXTENSION OF SERVICE LIFE INSPECTION OF EXHAUST SYSTEM	TM 817-8 817-19 817-22 TN 817-23/1 TM 819-28/1 817-32
G 109 GY 92-356 GY 94-004	( G 109 SERIES )  INSPECTION OF THE AIRBRAKE STOPS  MAIN UNDERCARRIAGE LEGS INSPECTION	817-36 TM 817-39
GY 88-50 GY 90-315 GY 92-189	( G 109 SERIES ) AILERON FLUTTER INNER ELEVATOR HINGES REPLACEMENT OF NUTS IN ROOT RIB STUD PLATE MAGNETO FLYWEIGHTS AND STOP PIN INSPECT ELEVATOR DRAIN HOLES INSPECTION OF THE AIRBRAKE STOPS MAIN UNDERCARRIAGE LEGS INSPECTION ENGINE MOUNT FRAME	817-20 TM 817-25 TM 817-29 817-34/2 TM817-35 817-36 TM 817-39 TM817-45
CALLAIR S1B1		
A3		
A9A CF CF-75-05 US 73-22-02 US 78-20-06	FLIGHT CHARACTERISTICS WATER ACCUMULATION - WING LIFT STRUTS WING STRUTS	A-23
CAMAIR 480 US 63-21-05	LANDING GEAR RETRACTION LINKS	
CAMERON		
UK 001-07-96 UK 002-11-98 UK 003-11-98	THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS	2 ISSUE 1 REV C 4 7 ISSUE "B"
DRAGON UK 002-11-98 UK 003-11-98	PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS	4 7 ISSUE "B"
IGC PROPANE BOTTL UK 001-07-96 UK 002-11-98 UK 003-11-98	THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES	2 ISSUE 1 REV C 4 7 ISSUE "B"
<b>0 56</b> UK 001-07-96 UK 002-11-98 UK 003-11-98	THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS	2 ISSUE 1 REV C 4
TRUCK 56 UK 001-07-96 UK 002-11-98 UK 003-11-98	THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS	2 ISSUE 1 REV C 4 7 ISSUE "B"
V 56 UK 001-07-96 UK 002-11-98 UK 003-11-98	THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS	2 ISSUE 1 REV C 4 7 ISSUE "B"

MAKE / CONSTRUCTEUR MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT REFERENCE SERVICE BULLETIN CAMERON C 60 UK 002-11-98 PRESSURE RELIEF VALVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" N 65 001-07-96 THUNDER AND COLT TURNING VENTS
PRESSURE RELIEF VALVES UK 2 ISSUE 1 REV C UK 002-11-98 HK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" 0 65 001-07-96 THUNDER AND COLT TURNING VENTS HK 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES UК 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" V 65 UК 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C LIK 002-11-98 PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS UK 003-11-98 7 ISSUE "B" GOLF 76 001-07-96 UK THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C PRESSURE RELIEF VALVES UK 002-11-98 003-11-98 HK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" **ELEPHANT 77** 001-07-96 THUNDER AND COLT TURNING VENTS
PRESSURE RELIEF VALVES UK 2 ISSUE 1 REV C LIK 002-11-98 UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" N 77 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C 002-11-98 HIK PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS UK 003-11-98 7 ISSUE "B" 0 77 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" RAINDROP 77 001-07-96 BIK THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS ISSUE "B" TIGER 77 UK 001-07-96 THUNDER AND COLT TURNING VENTS
PRESSURE RELIEF VALVES 2 ISSUE 1 REV C 002-11-98 LIK BURNER FRAME CROSS BAR WELDS UK 003-11-98 7 ISSUE "B" V 77 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" C 80 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES 003-11-98 UK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" DINOSAUR 80 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK PRESSURE RELIEF VALVES 002-11-98 BURNER FRAME CROSS BAR WELDS 003-11-98 UK 7 ISSUE "B" 0.84 UK 001-07-96 THUNDER AND COLT TURNING VENTS
PRESSURE RELIEF VALVES 2 ISSUE 1 REV C UK 002-11-98 UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" N 90 001-07-96 LIK THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES 2 ISSUE 1 REV C UK 002-11-98 UK 003-11-98 BURNER FRAME CROSS BAR WELDS

7 ISSUE "B"

MAKE / CONSTRUCTEUR MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT CAMERON 0 90 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C 002-11-98 ÜK PRESSURE RELIEF VALVES 003-11-98 HK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" WAVING FLAG 90 HK 001-07-96 THUNDER AND COLT 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES 003-11-98 UK BURNER FRAME CROSS BAR WELDS ISSUE "B" MAPLE LEAF 95 001-07-96 UK THUNDER AND COLT 2 ISSUE 1 REV C LIK PRESSURE RELIEF VALVES 002-11-98 003-11-98 BURNER FRAME CROSS BAR WELDS UK ISSUE "B" A 105 UК 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES ÜK 003-11-98 BURNER FRAME CROSS BAR WELDS ISSUE "B" N 105 UK 001-07-96 THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES 2 ISSUE 1 REV C UK 002-11-98 003-11-98 HK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" 0 105 THUNDER AND COLT TURNING VENTS UK 001-07-96 2 ISSUE 1 REV C UK 002-11-98 PRESSURE RELIEF VALVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" COW 106 THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES 001-07-96 UK 2 ISSUE 1 REV C UK 002-11-98 4 003-11-98 BURNER FRAME CROSS BAR WELDS UK 7 ISSUE "B" CALLING CARD 110 A 120 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C PRESSURE RELIEF VALVES UK 002-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" UK 003-11-98 0 120 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 001-07-96 PRESSURE RELIEF VALVES UK 002-11-98 003-11-98 UK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" A 140 PRESSURE RELIEF VALVES 4 002-11-98 HK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" UK 003-11-98 A 160 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 001-07-96 PRESSURE RELIEF VALVES UK 002-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" 003-11-98 UK D 160 THUNDER AND COLT TURNING VENTS
PRESSURE RELIEF VALVES 2 ISSUE 1 REV C UK 001-07-96 UK 002-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" 003-11-98 UK A 180 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C UK 001-07-96 PRESSURE RELIEF VALVES 002-11-98 UK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" UK 003-11-98 A 210 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV C 001-07-96 UK PRESSURE RELIEF VALVES 002-11-98 UK BURNER FRAME CROSS BAR WELDS 7 ISSUE "B" 003-11-98 UK A 250 THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES 2 ISSUE 1 REV C ŲΚ 001-07-96

002-11-98

UK

Δ

		DEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN O	
MAKELOO		X DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU	CANADA
MODEL / I ORIGIN ORIGINE	AD NUMBER	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CAMERO			BOLLETIN DE SERVICE DE REF.
CAMERO A 250			
	NUED / SUITE)		
UK	003-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
A 300	1		
UK	001-07-96	THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
UK UK	002-11-98	PRESSURE RELIEF VALVES	4
UK	003-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
CANADA			
CL44 CF	SERIES	0-1	
CF	CF-69-03 CF-69-11	STABILIZER INTERSPAR RIBS INTERSPAR RIBS	CL-44D4-286
CF	CF-72-04	MLG ACTUATOR ATTACHMENT BRACKETS	CL-44D4-475
CF	CF-73-07	REAR SPAR ATTACHMENT FITTINGS	
CF CF	CF-73-08 CF-74-10	REAR SPAR ATTACHMENT FITTINGS	CL-44-478
CF	CF-75-08	NLG UPPER AND LOWER TOGGLE PINS FUSELAGE SKINS	CL44-381
CF	CF-76-14	MAIN LANDING GEAR ATTACHMENT BOLTS	CL-44-385 CL44-478
CF	CF-76-23	NOSE LANDING GEAR RADIUS ROD	CL-44-151
CF CF	CF-77-01 CF-77-02	OIL LEAKS	CL-44-386
CF	CF-77-04	NOSE LANDING GEAR ACTUATOR LEVER BOLTS LANDING GEAR MICRO SWITCHES	CL-44-387
CF	CF-77-07	BRAKE CONTROL UNIT	CL-44-402 CL-44-405
CF	CF-78-02	ELEVATOR RESILIENT STOP MECHANISM	CL-44-406
CF CF	CF-78-07 CF-78-08	MAIN LANDING GEAR ACTUATOR END CAP	
CF	CF-78-10	FIRE EXTINGUISHING SYSTEM JOINTS FUELING PILOT VALVE	CL-44D4-480
CF	CF-78-11	ENGINE COWLING FLUID FIRES	CL-44D4-485 CL-44D4-486
CF	CF-78-12	BRAKE PRESSURE REDUCING VALVE	CL-44-412
CF. CF	CF-79-09 CF-79-23	HORIZONTAL STABILIZER FRONT SPAR	CL-44-377
CF	CF-80-09	OXYGEN SAFETY OUTLET FIRE SAFETY	CL-44-487
CF	CF-80-19	NOSE LANDING GEAR CROSS BEAM	CL-44-488 CL-44-431
CF CF	CF-81-33	MAIN LANDING GEAR ATTACHMENT PINS	CL-44-441
CF	CF-81-41 CF-82-09	AUXILIARY FUEL TANKS	CL-44-432
	CF-82-10	MAIN LANDING GEAR UPLOCK ACTUATING CYLINDER HORIZONTAL STAB REAR ATTACHMENT FITTINGS	CL-44D4-381
CF	CF-82-14	ENGINE OIL BREATHER DUCT ASSEMBLY	CL-44-379 CL-44-443
CF CF	CF-85-09 CF-88-21	LANDING GEAR UPPER FORGING	CL-44-419
CF	CF-90-02	UPPER WING SKIN CORROSION SUPPLEMENTAL INSPECTION	CL44T-1340/2431
*****************		SOFF LEMENTAL TRISPECTION	
CL44 D		( CL44 SERIES )	
CL44 J		( CL44 SERIES )	
CC106			
CF	CF-74-10	NLG UPPER AND LOWER TOGGLE PINS	CL44-381
CF CF	CF-75-08 CF-76-14	FUSELAGE SKIN	385-CL44
CF	CF-76-23	MAIN LANDING GEAR ATTACHMENT BOLTS NOSE LANDING GEAR RADIUS ROD	CL44-478
CF	CF-77-01	OIL LEAKS	CL-44-151 CL-44-386
CF CF	CF-77-02	NOSE LANDING GEAR ACTUATOR LEVER BOLTS	CL-44-387
CF	CF-77-04 CF-77-07	LANDING GEAR MICRO SWITCHES	CL-44-402
CF	CF-78-02	BRAKE CONTROL UNIT ELEVATOR RESILIENT STOP MECHANISM	CL-44-405
CF	CF-78-07	MAIN LANDING GEAR ACTUATOR FAID CAR	CL-44-406
CF CF	CF-78-08	FIRE EXTINGUISHING SYSTEM JOINTS	CL44D4-480
CF	CF-78-10 CF-78-11	, occined , ILO; VALVE	CL-44D4-485
CF	CF-79-09	ENGINE COWLING FLUID FIRES HORIZONTAL STABLIZER FRONT SPAR	CL-44D4-486
CF	CF-80-09	FIRE SAFETY	CL-44-377 CL44-488
CF CF	CF-80-19 CF-81-33	NOSE LANDING GEAR CROSS BEAM	CL-44-431
01	0, 01 33	MAIN LANDING GEAR ATTACHMENT PINS	CI -41-111

CL215 SERIES

CF-81-41

CF-82-09

CF-82-10

CF-82-14

CF-86-12 CF-87-08R1

CF

CF

CF

CF

CF

CF

CL-44-441

379-CL44

215-227

215-A363

SBA215-339

CL-44-443

CL-44-432 CL-44D4-381

AUXILIARY FUEL TANKS
MAIN LANDING GEAR UPLOCK ACTUATING CYLINDER

HORIZONTAL STABILIZER REAR ATTACHMENT FITTINGS ENGINE OIL BREATHER DUCT ASSEMBLY

MAIN LANDING GEAR ATTACHMENT PINS

FUEL BOOST PUMPS

PROP GOVERNOR NUTS

WATER DOORS MICROSWITCHES

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

1			BOLLETIN DE SERVICE DE REF.
CANADA	ATD		
	SERIES		
(CONTI	NUED / SUITE)		
CF	CF-89-05	DC GENERATORS	
CF	CF-90-11R2	DUDGE ALCON TATEROOM	215-414
CF	CF-91-23	RUDDER-AILERON INTERCONNECT TAB FLUTTERS MAIN ELECT DIST CENTER LOOSE/MISSING HARDWARE CHAFING OF RADIO MAGNETIC WIRE BUNDLE - MOD	215-A435
		MAIN ELECT DIST CENTER LOOSE/MISSING HARDWARE	TA215-439-010
CF	CF-91-36	CHAFING OF RADIO MAGNETIC WIRE BUNDLE - MOD	215 405
CF	CF-97-07R1	WING-TO-FUSELAGE FRAME ANGLE CRACKS	215-A476R2
		The state of the s	215-A476R2
CI 215	5 1A10	( CL215 SERIES )	
CF			
	CF-70-04	CHINE SPRAY STRIPS	CF215-51
CF	CF-70-06	WATER DOOR TENSION ROD	
CF	CF-71-03	NLG WHEELS	23-CL-215
CF	CF-71-04	ELEVATOR HINGE FITTINGS	
CF	CF-71-06	AILERON ASSEMBLIES	26-CL-215
CF	CF-71-08	AILLON ASSEMBLIES	19-CL-215
		EXTIAUST STACKS	TLX TMS 71-482
CF	CF-71-10	OIL & HYDRAULIC SYSTEM HOSES	CL215-138, -140
CF	CF-71-15	FUEL LEAKS	CI 215-165 27
CF	CF-72-02	FEATHERING PUMP	CL 215-166, 40
CF	CF-72-08	FRONT AND REAR DOORS	CL215-166,40
CF	CF-73-14	FRONT AND REAR DOORS NLG HYDRAULIC SYSTEM	CL215-173,51
		NLG HYDRAULIC SYSTEM	CL-215-176
CF	CF-75-13	PROPELLER COMPONANT SEIZURE	CL-215-198
CF	CF-75-16	PROPELLER COMPONANT SEIZURE NLG HYDRAULIC SYSTEM	CL-215-200
CF	CF-76-01	NLG DOOR	101-CL-215
CF	CF-76-05	ELEVATOR TORQUE TUBE	
CF	CF-76-07		115-CL-215
		MLG WHEEL WELL ANGLES	104-CL-215
CF	CF-76-11	LOWER RUDDER BEARINGS PROPELLER GOVERNOR SUPPORT BRACKETS WINDOW SILL	110-CL-215
CF	CF-76-12	PROPELLER GOVERNOR SUPPORT BRACKETS	119-CL-215
CF	CF-76-19	WINDOW SILL	129-CL-215
CF	CF-76-20	MLG ACTUATOR ATTACHMENT FITTING	136-CL-215
	CI 70 20	MEG ACTORION ATTACHMENT FITTING	136-CL-215
CF	CF-77-12	WATER DOOR HINGE PLATES	143-CL-215
CF	CF-79-10	LINK CONNECTING RODS	
CF	CF-92-26	CRACKS LH & RH WING REAR SPAR - INSP/NDT .	215-A454
CF	CF-93-07	CRACKS FRONT SPAR LOWER CAP WING STN 51 - NDT INSP	ALERT WIRE 215-AA63
CF	CF-93-08R2	MAIN LANDING GEAR CRACKED AXLES - NDT INSPECTION	
	CF-93-08K2	MAIN LANDING GEAR CRACKED AXLES - NOT INSPECTION	ALERI WIRE 215-A462
CL215	6B11(CL215T)	( CL215 SERIES )	
CF	CF-92-10R1	ENGINE FIRE WIRE DETECTION LOOP - MODIFICATION	21113 & 21314
CF	CF-92-22		215-12010
CF	CE-02-26	CRACKS LH & RH WING REAR SPAR - INSP/NDT	215-1464
	05 00 07	CRACKS LH & RH WING REAR SPAR - INSP/NDT CRACKS FRONT SPAR LOWER CAP WING STN 51 - NDT INSP MAIN LANDING GEAR CRACKED AXLES - NDT INSPECTION	ALERT WIRE DAE A460
CF	CF-93-07	CRACKS FRONT SPAR LOWER CAP WING SIN ST - NOT INSP	ALERI WIRE 215-A463
CF	CF-93-08R2	MAIN LANDING GEAR CRACKED AXLES - NOT INSPECTION	ALERT WIRE 215-A462
CL215	6B11(CL415)		
CF	CF-90-11R2	RUDDER-AILERON INTERCONNECT TAB FLUTTERS	215-A435
CI	CI SO TIRZ	Nobbett Attended 1111 Englished 1111 Television	
	0		
CL600	SERIES		
CL 600	1A11(600)	( CL600 SERIES )	
	CF-81-14	RUDDER CONTROL BEARING HOUSINGS	A600-0013
		BRAKE ASSEMBLY	A600-0045
CF	CF-81-15	FACT/CLOW INDICATORS	A600=0053
CF	CF-81-16	FAST/SLOW INDICATORS	A600-0053
CF	CF-81-17		A600-0029
CF	CF-81-18 CF-81-19	FUSELAGE FRAME FS235 WINDSHIELD SILL MEMBER	A600-0010
CF	CF-81-19	WINDSHIELD SILL MEMBER	A600-0035
CF	CF-81-22	INNER MAIN DOOR HANDLE	
			A600-00770074
CF	CF-81-23	Always to the second se	A600-0077, -0074
CF	CF-81-26		
CF	CF-81-30		A600-0062
CF	CF-81-34	FLIGHT SPOILER CONTROL	A600-0024
		ANTI-SKID SYSTEM	A600-0094
CF	CF-81-36	LG MANUAL RELEASE CONTROL	A600-0076
CF	CF-81-37		
CF		STALL PROTECTION STICK PUSHER	A600-0090
	CF-81-40		
CF		RUDDER ANTIJAM MECHANISMS	A600-0030
CF CF	CF-81-42	FLAP DRIVE SHAFTS	A600-0037
CF	CF-81-42 CF-82-03	FLAP DRIVE SHAFTS	A600-0037
CF CF	CF-81-42 CF-82-03 CF-82-04	FLAP DRIVE SHAFTS ADG CONTROL CABLE ASSEMBLY	A600-0037 A600-0063
CF	CF-81-42 CF-82-03	FLAP DRIVE SHAFTS ADG CONTROL CABLE ASSEMBLY	A600-0037 A600-0063 A600-0084
CF CF	CF-81-42 CF-82-03 CF-82-04	FLAP DRIVE SHAFTS ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR AIR DRIVEN GENERATOR EJECTION JACK	A600-0037 A600-0063
CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07	FLAP DRIVE SHAFTS ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR AIR DRIVEN GENERATOR EJECTION JACK ANTI-SKID SYSTEM	A600-0037 A600-0063 A600-0084 A600-0066
CF CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07 CF-82-08	FLAP DRIVE SHAFTS ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR AIR DRIVEN GENERATOR EJECTION JACK ANTI-SKID SYSTEM FLAP DRIVE SHAFTS	A600-0037 A600-0063 A600-0084 A600-0066
CF CF CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07 CF-82-08 CF-82-11	FLAP DRIVE SHAFTS  ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR  AIR DRIVEN GENERATOR EJECTION JACK  ANTI-SKID SYSTEM FLAP DRIVE SHAFTS	A600-0037 A600-0063 A600-0084 A600-0066
CF CF CF CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07 CF-82-08 CF-82-11 CF-82-12R1	FLAP DRIVE SHAFTS  ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR  AIR DRIVEN GENERATOR EJECTION JACK ANTI-SKID SYSTEM FLAP DRIVE SHAFTS GENERATOR AND APU FEEDER WIRES	A600-0037 A600-0063 A600-0084 A600-0066
CF CF CF CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07 CF-82-08 CF-82-11 CF-82-12R1 CF-82-13R1	FLAP DRIVE SHAFTS  ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR  AIR DRIVEN GENERATOR EJECTION JACK ANTI-SKID SYSTEM FLAP DRIVE SHAFTS GENERATOR AND APU FEEDER WIRES  MLG SIDESTAY ATTACHMENT PIN - DOWTY CMM 32-10-00	A600-0037 A600-0063 A600-0084 A600-0066 A600-0059 DWG 600-58001,-58031
CF CF CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07 CF-82-08 CF-82-11 CF-82-12R1	FLAP DRIVE SHAFTS  ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR  AIR DRIVEN GENERATOR EJECTION JACK ANTI-SKID SYSTEM FLAP DRIVE SHAFTS GENERATOR AND APU FEEDER WIRES MLG SIDESTAY ATTACHMENT PIN - DOWTY CMM 32-10-00 VHF TRANSMITTER	A600-0037 A600-0063 A600-0084 A600-0066 A600-0059 DWG 600-58001,-58031
CF CF CF CF CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07 CF-82-08 CF-82-11 CF-82-12R1 CF-82-13R1 CF-82-16R1	FLAP DRIVE SHAFTS ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR AIR DRIVEN GENERATOR EJECTION JACK ANTI-SKID SYSTEM FLAP DRIVE SHAFTS GENERATOR AND APU FEEDER WIRES MLG SIDESTAY ATTACHMENT PIN - DOWTY CMM 32-10-00 VHF TRANSMITTER MLG BRAKE ASSEMBLY	A600-0037 A600-0063 A600-0084 A600-0066 A600-0059 DWG 600-58001,-58031
CF CF CF CF CF CF	CF-81-42 CF-82-03 CF-82-04 CF-82-05 CF-82-07 CF-82-08 CF-82-11 CF-82-12R1 CF-82-13R1	FLAP DRIVE SHAFTS  ADG CONTROL CABLE ASSEMBLY PITCH TRIM ACTUATOR  AIR DRIVEN GENERATOR EJECTION JACK ANTI-SKID SYSTEM FLAP DRIVE SHAFTS GENERATOR AND APU FEEDER WIRES MLG SIDESTAY ATTACHMENT PIN - DOWTY CMM 32-10-00 VHF TRANSMITTER	A600-0037 A600-0063 A600-0084 A600-0066 A600-0059 DWG 600-58001,-58031

MAKE / CONSTRUCTEUR MODEL (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJET REFERENCE SERVICE BUILLETIN CANADAIR CL600 1A11(600) ( CL600 SERIES )

(CONTINUED / SUITE)

CF CF-82-27 BULKHEAD FATIGUE CRACKING FS 409.00 600-0124

CF CF-82-30 DOOR LATCH MECHANISM A600-0203

CF CF-82-32R1 ELECTRICAL CABLES AND INSULATION BARRIERS A600-0250

CF CF-83-01 FUEL SPILL A600-0245 CF CF-83-01 FUEL SPILL A600-0245

CF CF-83-02 FLAP ASYMMETRY DETECTORS A600-0284

CF CF-83-13 INBOARD FLAP VANE SUPPORT A600-0357

CF CF-83-33 CABIN PRESSURE 600-0317

CF CF-83-36R1 PRECIPITATION STATIC DISCHARGE A600-0332

CF CF-83-37 LIGHTNING PROTECTION A600-0372

CF CF-84-04R2 FREZING OF BRAKES A600-0369

CF CF-84-06R1 LOWER WING TANK SKIN A600-0416

CF CF-84-09R4 ELECTRICAL GENERATOR HOUSING

CF CF-86-04R1 AILERON / ELEVATOR FLUTTER DAMPERS A600-0612

CF CF-91-21R1 ADG ELECTRICAL DUTTER DAMPERS A600-0581

CF CF-91-24 ENGINE FIRE EXTINGUISHER WIRING HARNESS A600-0612

CF CF-92-23R1 ENGINE SHUT-DOWN IN FLIGHT A600-0615

CF CF-94-13 ADG MANUAL DEPLOYMENT SYSTEM 600-0638

CF CF-94-23 DETECT CRACKING OF RUDDER QUAD - NDT 600-0637

CF CF-95-02R1 OVERSPEED OF HORIZ. STAB. TRIM ACTUATOR A600-0644

CF CF-97-16R1 PRESSURE BULKHEAD FRAME CRACKING 600-0679

CF CF-99-14 HYDRAULIC AND FUEL LINE MODS 600-0671 A600-0245 CF-83-01 CF-83-02 FUEL SPILL
FLAP ASYMMETRY DETECTORS CF CF-99-14 HYDRAULIC AND FUEL LINE MODS 600-0671

CL600 2A12(601) ( CL600 SERIES )

CF CF-82-12R1 GENERATOR AND APU FEEDER WIRES DWG 600-58001,-58031

CF CF-82-16R1 VHF TRANSMITTER 601-0091

CF CF-83-36R1 PRECIPITATION STATIC DISCHARGE A601-0008

CF CF-83-36R1 PRECIPITATION STATIC DISCHARGE A601-0026

CF CF-83-37 LIGHTNING PROTECTION A601-0026

CF CF-84-04R2 FREEZING OF BRAKES A601-0024

CF CF-84-06R1 LOWER WING TANK SKIN - DWGS A601-0069

CF CF-84-09R4 ELECTRICAL GENERATOR HOUSING

CF CF-91-21R1 ADG ELECTRICAL - OUTPUT HARNESS A601-0370

CF CF-91-22R3 TAIL CONE FUEL TANK A601-0381

CF CF-91-24 ENGINE FIRE EXTINGUISHER WIRING HARNESS 600-0309

CF CF-92-23R1 ENGINE SHUT-DOWN IN FLIGHT A601-0374

CF CF-93-18 FLAP ACTUATOR INCORRECTLY INSTALLED SHOULDER BOLT ASB A601-0430

CF CF-94-13 ADG MANUAL DEPLOYMENT SYSTEM 601-0430

CF CF-94-23 DETECT CRACK ING OF RUDDER QUAD - NDT 601-0426

CF CF-97-02 PREVENT FUEL TANK ACTUATOR A601-0441

CF CF-97-16R1 PRESSURE BULKHEAD FRAME CRACKING A601-0441

CF CF-99-14 HYDRAULIC AND FUEL LINE MODS 601-0442

CL600 2B16(601 3A) (CL600 SERIES) 
 CL600
 2B16(601 3A)
 ( CL600 SERIES )

 CF
 CF-84-09R4
 ELECTRICAL GENERATOR HOUSING

 CF
 CF-86-04R1
 AIRLERON / ELEVATOR FLUTTER DAMPERS
 600-000-32/194

 CF
 CF-91-21R1
 ADG ELECTRICAL - DUTPUT HARNESS
 A601-0370

 CF
 CF-91-22R3
 TAIL CONE FUEL TANK
 A601-0381

 CF
 CF-91-24
 ENGINE FIRE EXTINGUISHER WIRING HARNESS
 601-0309

 CF
 CF-92-23R1
 ENGINE SHUT-DOWN IN FLIGHT
 A601-0374

 CF
 CF-93-18
 FLAP ACTUATOR INCORRECTLY INSTALLED SHOULDER BOLT AS RAGOL-0415
 CF-95-10 NLG SPRING BUNGEE ASSY
CF-97-16R1 PRESSURE BULKHEAD FRAME CRACKING
CF-99-09R1 IDG CABLE HARNESS
CF-99-14 HYDRAULIC AND FUEL LINE MODS CF 601-0454 CE 601-0501 CF 4601-0524 CF 601-0482 
 CL600
 2B16(601 3R)
 ( CL600 SERIES )

 CF
 CF-86-04R1
 AIRLERON / ELEVATOR FLUTTER DAMPERS
 600-000-32/

 CF
 CF-91-21R1
 ADG ELECTRICAL - OUTPUT HARNESS
 A601-0370

 CF
 CF-91-22R3
 TAIL CONE FUEL TANK
 A601-0381

 A601-0374
 A601-0374
 600-000-32/194 
 CF-91-22R3
 TAIL CONE FUEL TANK
 A601-0370

 CF-92-23R1
 ENGINE SHUT DOWN IN FLIGHT
 A601-0374

 CF-94-13
 ADG MANUAL DEPLOYMENT SYSTEM
 601-0430

 CF-94-23
 DETECT CRACKING OF PURPLE CHARLAND
 ADT

 CF
 CF-94-23
 DETECT CRACKING DF RUDDER QUAD - NDT
 601-0430

 CF
 CF-95-02R1
 OVERSPEED OF HORIZ. STAB. TRIM ACTUATOR
 601-0426

 CF
 CF-95-10
 NLG SPRING BUNGEE ASSY.
 601-0454

 CF
 CF-97-16R1
 PRESSURE BULKHEAD FRAME CRACKING
 601-0501

 CF
 CF-99-09R1
 IDG CABLE HARNESS
 4601-0524
 CF

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
CANADA	T 0		
CANADA:	2B16(601 3B)	( CL600 SERIES )	
(CONTIN	NUED / SUITE)	( CLOOD SEKIES )	
CF	CF-99-14	HYDRAULIC AND FUEL LINE MODS	601-0482
CL 600	2B16(604)	( CL600 SERIES )	
CF	CF-97-16R1	PRESCRIES BULKHEAD FRAME CRACKING	604-53-007
CF	CF-99-09R1	IDG CABLE MARNESS	A601-0524
CF CF	CF-99-14 CF-2000-01	HYDRAULIC AND FUEL LINE MODS	604-29-001
Cr	CF-2000-01	FUEL SERVICE PANEL MAINTENANCE LIGHT WIRING	N/A
	2B19(RJ)		
CF	CF-93-02R1	PASSENGER DOOR DE-ICING AGENT & LUBRICATION	A601R-52-002
CF CF	CF-93-26R2 CF-93-27R1	PREVENT - LOSS OF BRAKING FUNCTION STALL PROTECTION SYSTEM	601R-32-017
CF	CF-93-29	INTEGRATED DRIVE GENERATOR	601R-27-038 A601R-24-015, 016
CF	CF-94-14	ADG MANUAL DEPLOYMENT SYSTEM	A601R-24-019
CF CF	CF-94-21R1 CF-94-23	ELEVATOR DAMPER SHEAR PINS	601R-27-040
CF	CF-95-08R2	DETECT CRACKING OF RUDDER QUAD - NDT HORIZONTAL STAB TRIM CONTROL / AFM RESTRICTION	A601R-27-011 REV A 601R-27-053 & 054
CF	CF-95-10	NLG SPRING BUNGEE ASSY	A601R-32-037
CF	CF-95-14R1	AILERON FLUTTER DAMPER SHEAR PIN	A601R-27-058
CF CF	CF-96-12R1 CF-96-16R1	MLG SHOCK STRUT PINS PLATING	M-DT 17002-32-10
CF	CF-96-18	COPILOT'S AIR DATA SYSTEM DC POWER FUSE HOLDER	601R-34-094 A601R-24-056
CF	CF-97-11R2	PRESSURE BULKHEAD FRAME CRACKING	A601R-53-045 &046
CF	CF-98-14R1	FLAP TWIST	601R-11-071
CF CF	CF-98-35 CF-98-40	ELECTRICAL CONDUITS IN FUEL TANKS MAIN AND APU BATTERY CONNECTOR	A601R-28-036 A601R-24-085 REV C
CF	CF-99-01	OVERWING EXIT INSULATION REMOVAL	A601R-25-152
CF	CF-99-09R1	IDG CABLE HARNESS	A601R-24-095
CF	CF-99-32	INSPECTION OF MAIN LANDING GEAR FITTING	A601R-32-079
CASA			
212 SE	RIES		
SP	212-11-07	ZONE A LOAD PLACARD FOLD UP SEAT	MSB 212-11-07
SP SP	212-25-32 212-27-17R1	RUDDER CONTROL CABLE IMPROVEMENT	MSB 212-25-32 MSB 212-27-17R1
SP	212-27-22R3	FLAP SAFETYING IMPROVEMENT	MSB 212-27-22R3
SP	212-28-19R3	FUEL FILTER REPLACEMENT	MSB 212-28-19R3
SP SP	212-29-10 212-52-16	HYDRAULIC PIPE REPLACEMENT CREW DOOR HANDLE PROTECTION	MSB 212-29-10 MSB 212-52-16
SP	212-76-04	PROPELLER FEATHERING SAFETY	MSB 212-76-04
SP	212-76-05R1	CONTROL QUADRANT SLOTS	MSB 212-76-05R1
SP	212-79-03R2	ENGINE OIL REPLACEMENT STRUCTURAL INTEGRITY PROGRAM	MSB 212-79-03R2 C-212-PV-01-CPC
SP SP	02-88R2 88-001	ARTIFICIAL STALL WARNING SYSTEM	212-31-12R1
SP	01-89	RUDDER, ELEVATOR & AILERON TRIM & SERVO COMPONENT	212-27-25R6
SP	02-89	ENGINE OVERTORQUE - AUTOMATIC POWER RESERVE	212-72-05
SP	6/91	FUEL MANIFOLD INSPECT FUEL HOSE FOR CRACKS	TPE331-A73-0190 TP331-A73-0198
SP SP	02-92	RUDDER DEFLECTION	212-27-47
SP	07/94	MAIN LANDING GEAR SHOCK ABSORBER	212-32-38
SP	01/96	PERFORMANCE OF CORROSION TASKS INSPECTION OF FALSE SPAR	C-212-PV-01-SID
SP SP	02/96	INSPECTION OF FALSE SPAR INSPECTION OF INNER FLAP FITTINGS	212-224
SP	04/96	CONTROL LEVER SLOT PROTECTION	212-76-08
SP	05/96	AILERON COMMAND BAR HINGES RUDDER TORSION TUBE CORROSION	212-27-48
SP	06/96	RUDDER TORSION TUBE CORROSION INSPECTION OF FUEL PUMP COVER	212-27-34
SP	10/96	11131 201 1314 31 1 322 1 3111 33121	
C 212	CC40	( 212 SERIES )	212-76-07R1
CF	CF-93-28	POWER LEVERS 26 VOLT DOUBLE BUS BAR	MSB 212-24-33R2
SP SP	212-24-33R2 212-26-06R2	ADDITIONAL SMOKE DETECTOR	MSB 212-26-06R2
SP	212-27-12R3	RUDDER AND ELEVATOR ATTACHMENT	MSB 212-27-12R3
SP	212-27-19	FLAP HINGE BEARING REPLACEMENT TRIM CONTROL BOX INDICATOR	MSB 212-27-19 MSB 212-27-30
SP	212-27-30 212-55-07	RUDDER HINGE SUPPORT REPLACEMENT	MSB 212-27-30 MSB 212-55-07
SP SP	212-55-07	FLAP ATTACHMENT TORQUE	MSB 212-57-12
		( 212 SERIES )	
C 212	CC50 212-26-06R2	ADDITIONAL SMOKE DETECTOR	MSB 212-26-06R2
SP	212-26-0612	TRIM CONTROL BOX INDICATOR	MSB 212-27-30

MODEL /		(SERIES / SERIE)	
ORIGIN ORIGINE		SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CENTRA	NT R		
ASW20	)F		
FR FR	85-001(A) 85-019(A)	TOW HOOK RELEASE	8
FR	85-020(A)	LATERAL CONTROL & AILERON BALANCING FUSELAGE FRAME	6 9
FR	86-132(A)R1	FLIGHT CONTROL BRACKET	10
FR	87-139(A)	AILERON GAP SEALS	11
FR FR	88-010(A) 91-073(A)	OSCILLATIONS RUDDER PEDALS	12
FR	91-113(A)	AIRBRAKE HANDLE	13 20/14
FR	92-223(A)R1	WING EXTENSION LIMITATIONS	20-16R1
FR FR	93-004(A) 1995-260(A)R2	FLIGHT IN ROUGH AIR SPEED BRAKES	20-17
FR	97-048(A)	SWIVEL JOINTS AND BALL JOINTS CONTROLS	20-18 REV4 20-19;101-18,201-15
CESSNA C37			
T50			
CF	CF-47-01	LG SCREW YOKE BOLTS	TO 01-125-Z
CF US	CF-50-09 46-01-01	WOOD AND FABRIC DETERIORATION	
US	46-01-02	FLAP CHAIN WING COVERING	
US	46-12-01	FABRIC INSPECTION	
US US	46-46-03 47-05-01	AILERON AND FLAP HINGE BRACKETS	
US	47-30-02	FUEL SHUTOFF VALVE HANDLE BRAKE PEDAL LINKS	
US	47-30-03	WING INSPECTION FOR I D	
US	47-30-04	LANDING GEAR CHAINS	
US US	51-18-01 51-25-01	RUDDER TORQUE TUBE	
ÜS	53-06-01	HORIZONTAL STABILIZER LANDING LIGHT MOTOR CIRCUIT	
US	53-18-01	GOODRICH WHEEL BEARING	
US	56-21-02	SPAR DETERIORATION	
120	***************************************		
CF	CF-50-02	TOP RUDDER HINGE RIVETS	
CF US	CF-54-05 46-44-01	FIN ASSEMBLY SECURITY RUDDER STOP BOLTS	
US	46-44-02	SAFETY BELT BRACKET REINFORCEMENT	
US	46-44-03	WINDSHIELD RETAINING CHANNEL	
US US	46-44-04 46-44-05	CARBURETOR HOT AIR DUCTS	
US	47-06-10	ENGINE MOUNTING BOLTS AILERON CARRY-THROUGH BAR	
US	47-06-11	FORWARD DOORPOST CRACKS	
US	47-26-02	WING LEADING EDGE REWORK	
US US	47-43-01 47-43-02	PRIMER LINE RELOCATION FUEL SELECTOR VALVE HANDLE	
US	47-43-03	SEAPLANE SPREADER STRUTS	
US	47-43-04	RUDDER CONTROL CABLE HORNS	
US	47-43-05 47-43-06	ELEVATOR SPAR WEB REINFORCEMENT	
US	47-43-08	AILERON SUPPORT RIBS BEECH ROO3-201 PROPELLER BLADES	
US	47-50-02	FUSELAGE BULKHEAD	
US	48-05-04	OPERATOR LIMITATIONS PLACARD	
US US	48-07-01 48-25-02	STABILIZER ATTACHING BOLTS	
US	48-25-03	WELDED EXHAUST MUFFLER WING DRAG WIRE SYSTEM	
US	50-31-01	FIN SPAR REINFORCEMENT	
US US	51-21-01 61-25-01	RUDDER RIB FLANGES	
US	62-24-03	MET-CO-AIRE LANDING GEAR CABIN HEAT SYSTEM	
US	79-08-03	ELECTRICAL SYSTEM	
US US	86-26-04 96-12-22	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
	30-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
140 CF	CF-50-02	TOO DUDDED LIVED	
CF	CF-54-05	TOP RUDDER HINGE RIVETS FIN ASSEMBLY SECURITY	
CF	CF-63-07	SKI AXLE ASSEMBLY	
US	46-44-01	RUDDER STOP BOLTS	
US US	46-44-02 46-44-03	SAFETY BELT BRACKET REINFORCEMENT	
US	46-44-04	WINDSHIELD RETAINING CHANNEL CARBURETOR HOT AIR DUCTS	
US	46-44-05	ENGINE MOUNTING BOLTS	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE

(SERIES / SERIE) SUBJECT

ORIGINE	NUMERO DE CONSIGNE		SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CESSNA				
140				
(CONTIN	NUED / SUITE)			
US	47-06-10 47-06-11		AILERON CARRY-THROUGH BAR FORWARD DOORPOST CRACKS	
US	47-26-02		WING LEADING EDGE REWORK	
US	47-43-01		PRIMER LINE RELOCATION	
US US	47-43-02 47-43-03		FUEL SELECTOR VALVE HANDLE	
US	47-43-04		SEAPLANE SPREADER STRUTS RUDDER CONTROL CABLE HORNS	
US	47~43-05		ELEVATOR SPAR WEB REINFORCEMENT	
US US	47-43-06 47-43-08		AILERON SUPPORT RIBS	
US	47-50-02		BEECH ROO3-201 PROPELLER BLADES FUSELAGE BULKHEAD	
US	48-05-04		OPERATOR LIMITATIONS PLACARD	
US	48-07-01		STABILIZER ATTACHING BOLTS	
US US	48-25-02 48-25-03		WELDED EXHAUST MUFFLER WING DRAG WIRE SYSTEM	
US	50-31-01		FIN SPAR REINFORCEMENT	
US	51-21-01		RUDDER RIB FLANGES	
US US	61-25-01		MET-CO-AIRE LANDING GEAR	
US	62-24-03 86-26-04		CABIN HEAT SYSTEM PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
1404				
140A CF	CF-50-02		TOP RUDDER HINGE RIVETS	
CF	CF-54-05		FIN ASSEMBLY SECURITY	
CF	CF-63-07		SKI AXLE ASSEMBLY	
US US	61-25-01 62-24-03		MET-CO-AIRE LANDING GEAR CABIN HEAT SYSTEM	
US	79-08-03		ELECTRICAL SYSTEM	
US	79-10-14R1		FUEL TANK VENTING	_
US US	86-26-04 96-12-22		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER ENGINE OIL FILTER ADAPTERS ASSEMBLIES	SEB86-8 ATTACHED SKETCH
03	30-12-22		ENGINE OIL TIETER ADATTERS ASSEMBLIES	ATTACHED SKETCH
150 SE				
CF CF	CF-66-02		NOSE GEAR SEAT LOCKING MECHANISM	66-13 SIL SE 83-6
US	CF-87-15R2 62-22-01		VACUUM PUMP MODIFICATION	312 32 33 0
US	67-03-01		EXHAUST GAS HEAT EXCHANGERS	
US	68-17-04		STALL WARNING SYSTEM CRACKS IN NOSE GEAR FORK	
US US	71-22-02 74-06-02		AVCON MUFFLERS	
US	79-08-03		ELECTRICAL SYSTEM	
US	79-10-14R1		FUEL TANK VENTING	
US US	87-21-05 88-15-06		PLACARD - SPINS BATTERY CABLE / ELEVATOR CABLE	
US	93-05-06		IGNITION SWITCHES	SEB91-5
US	96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	96-12-23		WING STALL FENCE HEIGHT COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH 96-15,96-21,96-3
US	97-01-13			21,00
150		( 150	SERIES )	\$1 150-21
CF	CF-61-02		INTERNATIONAL SPINNING RIB AND SPAR RIVETS	SL 150-21
CF US	CF-62-09 73-23-07		DEFECTIVE SPAR ATTACH FITTINGS	
US	75-15-08		ENGINE LUBRICATION .	
US	77-02-09		WING FLAP SYSTEM APPROVED C OF G LIMITS	
US US	86-15-07 86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
03				
150A		150	SERIES ) ENGINE LUBRICATION	
US US	75-15-08 86-15-07		APPROVED C OF G LIMITS	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
		150	SERIES )	
<b>150B</b> US	75-15-08		ENGINE LUBRICATION	
US	86-15-07		APPROVED C OF G LIMITS	SEDOC O
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
1500	(	150	SERIES )	
150C US	75-15-08		ENGINE LUBRICATION	
US	86-15-07		APPROVED C OF G LIMITS	

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER SUBJECT

ORIGINE		SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CESSNA			
150C		( 150 SERIES )	
US US	NUED / SUITE) 86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
150D			32000 0
US	75-15-08	( 150 SERIES ) ENGINE LUBRICATION	
US	83-17-06	AILERON BALANCE WEIGHTS	
US US	86-24-07 86-26-04	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
	00 20 04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
150E US	75~15-08	( 150 SERIES )	
US	83-17-06	ENGINE LUBRICATION AILERON BALANCE WEIGHTS	
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
150F		( 150 SERIES )	
US US	72-03-03R3	WING FLAP JACK SCREW	
US	75-15-08 80-11-04	ENGINE LUBRICATION CRACKED NUTPLATES	
US	83-17-06	AILERON BALANCE WEIGHTS	
US US	86-24-07 86-26-04	ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
US	93-24-15	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB86-8
150G			SEB92-33R1
US	67-31-04	( 150 SERIES ) REMOVAL OF GLOVE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US US	75-15-08 80-11-04	ENGINE LUBRICATION	
US	83-17-06	CRACKED NUTPLATES AILERON BALANCE WEIGHTS	
US	86-24-07	ENGINE CONTROLS - BALL TYPE POD ENDS	SE79-6
US	86-26-04 93-24-15	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB86-8
			SEB92-33R1
150H US	67-31-04	( 150 SERIES )	
US	72-03-03R3	REMOVAL OF GLOVE COMPARTMENT WING FLAP JACK SCREW	
US US	75-15-08	ENGINE LUBRICATION	
US	80-11-04 83-17-06	CRACKED NUTPLATES AILERON BALANCE WEIGHTS	
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US US	86-26-04 93-24-15	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
		INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB92-33R1
150J US	72-02-0202	( 150 SERIES )	
US	72-03-03R3 75-15-08	WING FLAP JACK SCREW ENGINE LUBRICATION	
US	80-11-04	CRACKED NUTPLATES	
US US	83-17-06 86-24-07	AILERON BALANCE WEIGHTS	
US	86-26-04	ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
US	93-24-15	INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB92-33R1
150K		( 150 SERIES )	
	72-03-03R3	WING FLAP JACK SCREW	
US US	75-15-08 80-11-04	ENGINE LUBRICATION	
US	83-17-06	CRACKED NUTPLATES AILERON BALANCE WEIGHTS	
	86-24-07	ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
50L		( 150 SERIES )	
US	72-03-03R3	WING FLAP JACK SCREW	
		ENGINE LUBRICATION	
US US	75-15-08 80-11-04	CRACKED NUTPLATES	
US US US	80-11-04 83-17-06	CRACKED NUTPLATES AILERON BALANCE WEIGHTS	
US US US US	80-11-04	AILERON BALANCE WEIGHTS ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US US US US US	80-11-04 83-17-06 86-24-07	AILERON BALANCE WEIGHTS ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
US US US US US	80-11-04 83-17-06 86-24-07	AILERON BALANCE WEIGHTS ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6 SEB86-8

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGN	(SERIES / SERIE) SUBJECT	ANADA  REFERENCE SERVICE BULLETIN
Chicke Nowero de Collsion	E SUJET	BULLETIN DE SERVICE DE REF.
CESSNA		
150M (CONTINUED / SUITE)	( 150 SERIES )	
US 86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
A150 SERIES		02,0
CF CF-87-15R2	SEAT LOCKING MECHANISM	SIL SE 83-6
US 79-08-03 US 79-10-14R1	ELECTRICAL SYSTEM	011 01 00 0
US 80-11-04	FUEL TANK VENTING CRACKED NUTPLATES	
US 86-24-07 US 87-21-05	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US 88-15-06	PLACARD - SPINS BATTERY CABLE / ELEVATOR CABLE	
US 93-05-06 US 96-12-22	IGNITION SWITCHES	SEB91-5
US 96-12-22 US 96-12-23	ENGINE DIL FILTER ADAPTERS ASSEMBLIES WING STALL FENCE HEIGHT	ATTACHED SKETCH
US 97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH 96-15,96-21,96-3
A150K	( A150 SERIES )	
US 72-03-03R3	WING FLAP JACK SCREW	
US 75-15-08 US 76-01-01	ENGINE LUBRICATION HIGH SPEED FLUTTER	
US 79-08-03	ELECTRICAL SYSTEM	
A150L	( A150 SERIES )	
US 72-03-03R3	WING FLAP JACK SCREW	
US 73-23-07 US 75-15-08	SPAR ATTACHMENT	
US 76-01-01	ENGINE LUBRICATION HIGH SPEED FLUTTER	
4.4.F.OM	( AAFO CERTEC )	
<b>A150M</b> US 77-02-09	( A150 SERIES ) WING FLAP ACTUATOR	
US 78-25-07	VERTICAL FIN ATTACH BRACKETS	
US 80-06-03	WING FLAP CABLE CLAMP	SIL 79-16
152	OCIT LOCATION MEDITALIZA	
CF CF-87-15R2 US 79-02-06	SEAT LOCKING MECHANISM EXHAUST SYSTEM	SIL SE 83-6
US 80-01-06	FLAP ACTUATOR ASSEMBLY	
US 80-06-03 US 80-11-04	WING FLAP CABLE CLAMP CRACKED NUTPLATES	
US 81-05-01	FUEL TANK CAPACITY	
US 83-22-06 US 86-24-07	AILERON HINGE PIN ENGINE CONTROLS- BALL TYPE ROD ENDS	
US 93-05-06	IGNITION SWITCHES	SEB91-5
US 96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES WING STALL FENCE HEIGHT	ATTACHED SKETCH ATTACHED SKETCH
US 96-12-23 US 97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
A152 CF CF-87-15R2	SEAT LOCKING MECHANISM	SIL SE 83-6
US 78-25-07	VERTICAL FIN ATTACH BRACKETS	
US 79-02-06 US 80-01-06	EXHAUST SYSTEM FLAP ACTUATOR ASSEMBLY	
US 80-06-03	WING FLAP CABLE CLAMP	
US 80-11-04 US 81-05-01	CRACKED NUTPLATES FUEL TANK CAPACITY	
US 83-22-06	AILERON HINGE PIN	
US 86-24-07 US 93-05-06	ENGINE CONTROLS~ BALL TYPE ROD ENDS  IGNITION SWITCHES	SEB91-5
US 93-05-06 US 96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US 96-12-23	WING STALL FENCE HEIGHT COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH 96-15,96-21,96-3
US 97-01-13		
170 SERIES	SKI AXLE ASSEMBLY	
CF CF-63-07 CF CF-87-15R2	SEAT LOCKING MECHANISM	SIL SE 83-6
US 48-43-02	CONTINENTAL C-145-2 ENGINES MUFFLER ASSEMBLY	
US 69-15-03 US 73-17-01	FUEL TRANSFER PUMP PLACARD	
US 74-06-02	AVCON MUFFLERS  ELECTRICAL SYSTEM	
US 79-08-03 US 79-10-14R1	FUEL TANK VENTING	
US 86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER ENGINE OIL FILTER ADAPTERS ASSEMBLIES	SEB86-8 ATTACHED SKETCH
US 96-12-22	ENGINE OTE TIETER ADMITTERS ASSEMBLIES	ATTACHED SKETCH

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER OF (

(SERIES / SERIE) SUBJECT

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF
CECCNA				
CESSNA 170 S	ERTES			
	NUED / SUITE)			
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
US	98-21-21		BOB FIELDS AEROCESSORIES STC	
170		( 170	SERIES )	
		<b>1</b> 1 T.		
170A	00 07 00	( 170	SERIES )	
US	82-07-02		ENGINE CRANKCASE BREATHER	
170B		( 170	SERIES )	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
172 SE	RIES			
CF	CF-87-15R2		SEAT LOCKING MECHANISM	SIL SE 83-6
US	68-17-04		STALL WARNING SYSTEM	
US	69-15-03 71-18 <b>-</b> 01		MUFFLER ASSEMBLY FUEL SELECTOR VALVE PLACARD	
US	71-22-02		CRACKS IN NOSE GEAR FORK	
US	73-17-01		FUEL TRANSFER PUMP PLACARD	
US	74-04-01		AFT FUSELAGE BULKHEAD ASSY	
US US	74-06-02 79-08-03		AVCON MUFFLERS ELECTRICAL SYSTEM	
US	79-10-14R1		FUEL TANK VENTING	
US	90-06-03R1		EXHAUST HEATER/MUFFLER	170/172-11, -13
US	93-05-06		IGNITION SWITCHES	SEB91-5
US US	96-12-22 97-01-13		ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH
US	98-21-21		BOB FIELDS AEROCESSORIES STC	96-15,96-21,96-3
4				
172 US	FO10-00	( 172	SERIES )	
US	59-10-03 72-07-02		FLASHER SWITCH SELECTOR VALVE PLACARD	
US	73-23-07		DEFECTIVE SPAR ATTACH FITTINGS	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US US	83-17-06		AILERON BALANCE WEIGHTS	
US	86-26-04 99-27-02		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB86-8 SEB99-7
	00 2. 02		THE EASEMENT OF FOCE SELECTOR VALVE CAN	35099-7
172A		( 172	SERIES )	
US US	72-07-02 82-07-02		SELECTOR VALVE PLACARD ENGINE CRANKCASE BREATHER	
US	83-17-06		AILERON BALANCE WEIGHTS	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
172B		( 172	SERIES )	
US	68-19-05		UTILITY CATEGORY PLACARD	
US	72-07-02		SELECTOR VALVE PLACARD	
US US	82-07-02 83-17-06		ENGINE CRANKCASE BREATHER AILERON BALANCE WEIGHTS	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
4700				
172C US	68-19-05		SERIES ) UTILITY CATEGORY PLACARD	
US	72-07-02		SELECTOR VALVE PLACARD	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US	83-17-06		AILERON BALANCE WEIGHTS	
US US	86-26-04 99-27-02		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
	00 21 02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	25899-1
172D			SERIES )	
US	68-19-05		UTILITY CATEGORY PLACARD	
US US	72-07-02 82-07-02		SELECTOR VALVE PLACARD ENGINE CRANKCASE BREATHER	
US	83-17-06		AILERON BALANCE WEIGHTS	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US US	86-26-04 99-27-02		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
0.3	55-21-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
172E			SERIES )	
US	68-19-05		UTILITY CATEGORY PLACARD	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT

SUBJECT REFERENCE SERVICE BULLETIN

	NOWELLO DE CONSTONE		SUJET	BULLETIN DE SERVICE DE REF.
CESSNA	1			
172E		( 172	SERIES )	
	NUED / SUITE)		ounted )	
US	72-07-02		SELECTOR VALVE PLACARD	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US	83-17-06 86-24-07		AILERON BALANCE WEIGHTS	
US	86-26-04		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	93-24-15		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB86-8
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB92-33R1
				SEB99-7
172F	60 40 05	( 172	SERIES )	
US US	68-19-05 72-03-03R3		UTILITY CATEGORY PLACARD	
US	72-03-0383		WING FLAP JACK SCREW SELECTOR VALVE PLACARD	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US	83-17-06		AILERON BALANCE WEIGHTS	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US US	93-24-15 99-27 <b>-</b> 02		INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB92-33R1
00	33 21 02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
172G		( 172	SERIES )	
US	68-19-05	······································	UTILITY CATEGORY PLACARD	
US	72-03-03R3		WING FLAP JACK SCREW	
US	72-07-02		SELECTOR VALVE PLACARD	
US US	82-07-02 83-17-06		ENGINE CRANKCASE BREATHER AILERON BALANCE WEIGHTS	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS	\$570-6
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTED	SE79-6 SEB86-8
US	93-24-15		INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB92-33R1
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
1704		( 470	CEDIEC )	
172H US	72-03-03R3		SERIES ) WING FLAP JACK SCREW	
US	72-03-0383		SELECTOR VALVE PLACARD	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US	83-17-06		AILERON BALANCE WEIGHTS	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US US	93-24-15 99-27-02		INSTRUMENT PANEL LIGHTING RHEOSTAT REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB92-33R1 SEB99-7
03	33 21 02		THE ENGLISHED OF THE SELECTOR VALVE CAN	35033-7
172I	•••••••••••••••••••••••••••••••		SERIES )	
US	70-10-06		OIL PRESSURE INSTRUMENT LINE	
US	72-03-03R3		WING FLAP JACK SCREW	
US	72-07-02		SELECTOR VALVE PLACARD ENGINE CRANKCASE BREATHER	
US	82-07-02 83-17-06		AILERON BALANCE WEIGHTS	
US	86-24-07		FNGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	93-24-15		INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB92-33R1
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
172K		( 172	SERIES )	
US	70-10-06		DIL PRESSURE INSTRUMENT LINE	
US	72-03-03R3	1	WING FLAP JACK SCREW	
US	72-07-02		SELECTOR VALVE PLACARD	
US	82-07-02		ENGINE CRANKCASE BREATHER AILERON BALANCE WEIGHTS	
US	83-17-06		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US US	86-24-07 86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	93-24-15		INSTRUMENT PANEL LIGHTING RHEOSTAT	SEB92-33R1
UŞ	99-27-02	F	REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
		4	ornier )	
172L			SERIES ) VING FLAP JACK SCREW	
US	72-03-03R3		ARC PA-500A ACTUATORS	
US US	76-04-03 82-07-02		NGINE CRANKCASE BREATHER	
US	83-17-06	4	ILERON BALANCE WEIGHT	
US	86-24-07		NGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	99-27-02	F	REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
4.00.00		( 172 (	SERIES )	
172M	76-04-03	172	RC PA-500A ACTUATORS	
US	78-04-03			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE

(SERIES / SERIE) SUBJECT

CESSNA	
172M	
CONTINUED	
US 77-12-08 EXTERNAL ELEC GROUND POWER RECEP US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-1 US 99-27-02 REPLACEMENT OF FUEL SELECTOR VALVE CAM SEB99  172N (172 SERIES ) US 76-21-06 LOSS OF ENGINE OIL US 77-02-09 WING FLAP SYSTEM US 77-12-08 EXTERNAL ELEC GROUND POWER RECEP US 80-04-08 FUEL LINES US 80-06-03 WING FLAP CABLE CLAMP US 81-05-01 FUEL TANK CAPACITY US 81-05-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PIN US 81-05-01 ENGINE CONTROLS - BALL TYPE ROD ENDS US 83-22-06 SILERON HINGE PIN US 81-05-01 ENGINE CONTROLS - BALL TYPE ROD ENDS US 83-22-06 AILERON HINGE PIN US 81-05-01 ENGINE CONTROLS - BALL TYPE ROD ENDS US 83-17-06 AILERON BALANCE WEIGHTS US 81-05-01 ENGINE CONTROLS - BALL TYPE ROD ENDS US 82-07-02 ENGINE CONTROL SYSTEM US 81-05-01 ENGINE CONTROLS - BALL TYPE ROD ENDS US 83-10-03 CONTROL SYSTEM US 81-05-01 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL SYSTEM US 83-10-04 CONTROL SYSTEM US 83-10-05 CONTROL SYSTEM US 83-10-05 CONTROL SYSTEM US 83-10-06 AILERON BALANCE WEIGHTS US 83-10-06 AILERON BALANCE WEIGHTS US 83-10-06 AILERON BALANCE WEIGHTS	
US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD  US 83-17-06 AILERON BALANCE WEIGHTS US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-09-27-02 REPLACEMENT OF FUEL SELECTOR VALVE CAM SEB99  172N US 76-21-06 LOSS OF ENGINE OIL US 77-02-09 WING FLAP SYSTEM US 77-12-08 EXTERNAL ELEC GROUND POWER RECEP US 80-04-08 FUEL LINES US 80-06-03 WING FLAP CABLE CLAMP US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PIN  172P US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-6  172P US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ENGINE CONTROLS - BALL TYPE ROD ENDS US 83-10-03 CONTROL SYSTEM US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ENGINE CONTROLS - BALL TYPE ROD ENDS US 83-10-03 CONTROL SYSTEM US 82-07-02 ENGINE CONTROLS - BALL TYPE ROD ENDS US 83-10-03 CONTROL SYSTEM US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CONTROLS SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-17-06 AILERON BALANCE WEIGHTS	
US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD  US 83-17-06 A LLERON BALANCE WEIGHTS US 99-27-02 REPLACEMENT OF FUEL SELECTOR VALVE CAM SEB99  172N  US 76-21-06 LOSS OF ENGINE OIL US 77-02-09 WING FLAP SYSTEM US 80-04-08 FUEL LINES US 80-04-08 FUEL LINES US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-17-06 ALLERON HINGE PIN US 83-22-06 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD ALLERON HINGE PIN US 86-24-07 ENGINE CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD ALLERON BALANCE WEIGHTS US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROLS - BALL TYPE ROD ENDS  172P US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CONTROL SYSTEM US 82-07-02 ENGINE CONTROLS SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD ALLERON BALANCE WEIGHTS US 83-10-04 ALLERON BALANCE WEIGHTS US 83-10-05 CONTROL SYSTEM US 83-10-05 ENGINE CRANKCASE BREATHER US 83-10-05 CONTROL SYSTEM US 83-10-05 CONTROL SYSTEM US 83-10-05 ALLERON BALANCE WEIGHTS US 83-17-06 ALLERON BALANCE WEIGHTS US 83-17-06 ALLERON BALANCE WEIGHTS US 83-22-06 ALLERON BALANCE WEIGHTS	
US 83-17-06	
US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-09-27-02 REPLACEMENT OF FUEL SELECTOR VALVE CAM SEB99  172N US 76-21-06 LOSS OF ENGINE OIL US 77-02-09 WING FLAP SYSTEM US 80-04-08 FUEL LINES US 80-06-03 WING FLAP CABLE CLAMP US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 83-10-03 CONTROL SYSTEM US 83-22-06 AILERON BALANCE WEIGHTS US 83-22-06 TOTAL TO ENGINE CONTROL SYSTEM US 83-22-06 AILERON ENGINE CONTROL SYSTEM US 83-10-03 CONTROL SYSTEM US 83-10-03 CONTROL SYSTEM US 83-22-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON BALANCE WEIGHTS US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROLS - BALL TYPE ROD ENDS  172P US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD AILERON BALANCE WEIGHTS US 83-10-03 CONTROL SYSTEM US 83-10-04 ENGINE CRANKCASE BREATHER US 83-10-05 ENGINE CRANKCASE BREATHER US 83-10-05 AILERON BALANCE WEIGHTS US 83-10-06 AILERON BALANCE WEIGHTS US 83-10-06 AILERON BALANCE WEIGHTS	
US   99-27-02   REPLACEMENT OF FUEL SELECTOR VALVE CAM   SEB99	
172N	
US 76-21-06	
US 77-02-09 WING FLAP SYSTEM US 77-12-08 EXTERNAL ELEC GROUND POWER RECEP US 80-04-08 FUEL LINES US 80-06-03 WING FLAP CABLE CLAMP US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON FINE POWER FROM END US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-6 US 82-07-02 ENGINE CONTROL SYSTEM US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CONTROL SYSTEM US 82-07-02 ENGINE CONTROL SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-17-06 AILERON BALANCE WEIGHTS US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS	
US 77-12-08 EXTERNAL ELEC GROUND POWER RECEP  US 80-04-08 FUEL LINES  US 80-06-03 WING FLAP CABLE CLAMP  US 81-05-01 FUEL TANK CAPACITY  US 81-16-09 ELEVATOR CONTROL SYSTEM  US 82-07-02 ENGINE CRANKCASE BREATHER  US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD  US 83-17-06 AILERON BALANCE WEIGHTS  US 83-22-06 AILERON HINGE PIN  US 81-05-01 FUEL TANK CAPACITY  US 81-16-09 ELEVATOR CONTROLS - BALL TYPE ROD ENDS SE79-6  172P  US 81-16-09 ELEVATOR CONTROLS SYSTEM  US 81-16-09 ELEVATOR CONTROLS SYSTEM  US 82-07-02 ENGINE CRANKCASE BREATHER  US 83-10-03 CONTROL SYSTEM  US 83-10-03 CONTROL SYSTEM  US 83-17-06 ENGINE CRANKCASE BREATHER  CONTROL WHEEL YOKE GUIDE MOD  AILERON BALANCE WEIGHTS  US 83-17-06 AILERON BALANCE WEIGHTS  US 83-22-06 AILERON HINGE PINS	
US 80-04-08 US 80-06-03 US 81-05-01 US 81-16-09 US 82-07-02 US 83-10-03 US 83-17-06 US 83-22-06 US 83-22-06 US 81-05-01 US 81-05-01 US 81-05-01 US 81-05-01 US 83-22-06 US 83-22-06 US 83-22-06 US 83-22-06 US 83-22-06 US 81-05-01 US 81-16-09 US 81-05-01 US 81-	
US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON HINGE PIN US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-6  172P ( 172 SERIES ) US 81-05-01 FUEL TANK CAPACITY US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROLS SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS	
US 81-16-09 ELEVATOR CONTROL SYSTEM  US 82-07-02 ENGINE CRANKCASE BREATHER  US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD  US 83-17-06 AILERON BALANCE WEIGHTS  US 83-22-06 AILERON HINGE PIN  US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-6  172P  US 81-05-01 FUEL TANK CAPACITY  US 81-16-09 ELEVATOR CONTROL SYSTEM  US 82-07-02 ENGINE CRANKCASE BREATHER  US 83-10-03 CONTROL SYSTEM  US 83-10-03 CONTROL SYSTEM  US 83-17-06 AILERON BALANCE WEIGHTS  US 83-22-06 AILERON BALANCE WEIGHTS  US 83-22-06 AILERON HINGE PINS	
US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PIN US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-6  172P US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL SYSTEM US 83-17-06 AILERON BALANCE WEIGHTS US 83-17-06 AILERON BALANCE WEIGHTS  172Q (172 SERIES)	
US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-6  172P US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS	
US 83-17-06	
US 83-22-06 AILERON HINGE PIN US 86-24-07 ENGINE CONTROLS - BALL TYPE ROD ENDS SE79-6  172P US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS  172Q (172 SERIES)	
172P ( 172 SERIES )  US 81-05-01 FUEL TANK CAPACITY  US 81-16-09 ELEVATOR CONTROL SYSTEM  US 82-07-02 ENGINE CRANKCASE BREATHER  US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD  US 83-17-06 AILERON BALANCE WEIGHTS  US 83-22-06 AILERON HINGE PINS  172Q ( 172 SERIES )	
US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS  172Q (172 SERIES )	
US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS  172Q (172 SERIES )	
US 81-16-09 ELEVATOR CONTROL SYSTEM US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS  172Q (172 SERIES)	
US 82-07-02 ENGINE CRANKCASE BREATHER US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS  172Q ( 172 SERIES )	
US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD US 83-17-06 AILERON BALANCE WEIGHTS US 83-22-06 AILERON HINGE PINS  172Q ( 172 SERIES )	
US 83-22-06 AILERON HINGE PINS  172Q ( 172 SERIES )	
172Q ( 172 SERIES )	
110	
172R ( 172 SERIES )	
US 97-12-06 FUEL LOSS GASCOLATOR DRAIN VALVE 97-28- US 98-01-01 ALTERNATE STATIC ALD SOURCE 97-28-	01
US 98-01-01 ALTERNATE STATIC AIR SOURCE 97-34- US 98-02-05 EXHAUST MUFFLERS	02R1
IIC 00-13-44	00 00 05 00
US 98-14-07 LOWER FORWARD DOORPOST BULKHEAD SR97-5	02,03,05,06
US 98-25-03 AILERON CONTROL CABLE SB98-2	
US 99-18-14 CONTROL COLUMN PIVOT BOLT 99-27-	01
172RG ( 172 SERIES )	
US 80-01-06 FLAP ACTUATOR ASSEMBLY	
US 80-19-08 FUEL/AIR MIXTURE	
US 81-05-01 FUEL TANK CAPACITY	
US 81-14-06 RUDDER TRIM/NOSE GEAR STEERING BUNGEE US 81-16-09 FLEVATOR CONTROL SYSTEM	
ELEVATOR CONTROL 3131EM	
US 83-14-04 CABIN HEATER SHROUD MOD US 83-22-06 AILERON HINGE PIN	
US 85-20-01 CABIN HEAT DEACTIVATED	
172S ( 172 SERIES )	
P172D	
US 79-08-03 ELECTRICAL SYSTEM	
US 82-07-02 ENGINE CRANKCASE BREATHER	
US 86-26-04 PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER SEB86-8	
US 96-12-22 ENGINE OIL FILTER ADAPTERS ASSEMBLIES ATTACHE	ED SKETCH
US 97-01-13 COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM 96-15,	96-21,96-3
R172K	
US 77-02-09 WING FLAP ACTUATOR	
US 77-12-08 EXTERNAL FLEC GROUND POWER RECEP	
US 79-08-03 ELECTRICAL SYSTEM	
US 80-04-08 · FUEL LINES	
US 80-06-03 WING FLAP CABLE CLAMP  US 80-07-03 DIL PRESSURF	
JIE TRESSORE	
US 81-05-01 FUEL TANK CAPACITY US 81-16-09 ELEVATOR CONTROL SYSTEM	
US 83-10-03 CONTROL WHEEL YOKE GUIDE MOD	
US 83-22-06 AILERON HINGE PIN	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
CESSNA				
R172K				
	NUED / SUITE)			
US	86-19-11		FUEL RESERVOIRS	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US US	93-05-06 96-12-22		IGNITION SWITCHES	SEB91-5
US	97-01-13		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	99-27-02		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM REPLACEMENT OF FUEL SELECTOR VALVE CAM	96-15,96-21,96-3
			No. EROSMENT OF TOLL SELECTOR VALVE CAM	SEB99-7
	ERIES			
CF US	CF-87-15R2 69-15-03		SEAT LOCKING MECHANISM	SIL SE 83-6
US	71-22-02		MUFFLER ASSEMBLY CRACKS IN NOSE GEAR FORK	
US	73-17-01		FUEL TRANSFER PUMP PLACARD	
US	74-06-02		AVCON MUFFLERS	
US	79-08-03		ELECTRICAL SYSTEM	
US US	79-10-14R1 86-26-04		FUEL TANK VENTING	
US	96-12-22		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER ENGINE OIL FILTER ADAPTERS ASSEMBLIES	SEB86-8
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH 96-15,96-21,96-3
US	98-21-21		BOB FIELDS AEROCESSORIES STC	13 10,00 21,00 0
475		/	CEOTEC	
175 US	62-22-01	( 175	SERIES ) VACUUM PUMP MODIFICATION	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
175A	60 00 01	( 175	SERIES )	
US US	62-22-01 82-07-02		VACUUM PUMP MODIFICATION ENGINE CRANKCASE BREATHER	
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
	33 27 02		THE ENGLISH OF THE DEED TON THE TONIN	32033 /
175B		( 175	SERIES )	
US	62-22-01		VACUUM PUMP MODIFICATION	
US	82-07-02		ENGINE CRANKCASE BREATHER	
175C		( 175	SERIES )	
US	62-22-01		VACUUM PUMP MODIFICATION	
US	82-07-02		ENGINE CRANKCASE BREATHER	
US	99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
177 SI	FRIES			
CF	CF-87-15R2		SEAT LOCKING MECHANISM	SIL SE 83-6
US	68-17-04		STALL WARNING SYSTEM	
US	70-24-04		FUEL SHUT-OFF VALVE	
US	71-01-03 79-08-03		CRACKS IN STABILIZER ATTACHMENT ANGLE ELECTRICAL SYSTEM	
US	79-08-03 79-10-14R1		FUEL TANK VENTING	
US	86-19-11		FUEL RESERVOIRS	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	93-05-06		IGNITION SWITCHES ENGINE OIL FILTER ADAPTERS ASSEMBLIES	SEB91-5 ATTACHED SKETCH
US US	96-12-22 97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	
05				,
177		( 177	SERIES )	
US	68-07-09		LONGITUDINAL CONTROL SYSTEM	
US	68-18-02		OIL PRESSURE LINE FUEL QUANTITY TRANSMITTER FLOAT	
US US	70-01-02		FIFXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3		WING FLAP JACK SCREW	
US	74-16-06		OIL PRESSURE GAGE LINE	
US	75-07-02		AIR FILTER SEAL PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEROG-0
US	86-26-04		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB86-8 SEB99-7
US	99-27-02		THE CHOCKER OF THE STATE OF THE	
177A		( 177	SERIES )	
US	70-01-02		FUEL QUANTITY TRANSMITTER FLOAT	
US	71-01-03		CRACKS IN STABILIZER ATTACHMENT ANGLE WING FLAP JACK SCREW	
US	72-03-03R3			SEB86-8
US US	86-26-04 99-27-02		REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
05				
177B			SERIES )	
US	72-03-03R3		WING FLAP JACK SCREW	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER ODE CONSIGNE
SUBJECT
SUBJECT
SUBJECT

ORIGINE	NUMERO DE CONSIGNE			SUJET	BULLETIN DE SERVICE DE REF.
CESSNA		-	477	centec )	
177B	UED / SUITE)	(	1//	SERIES )	
US	76-04-03			ARC PA-500A ACTUATORS	
US	76-14-08			TRIM TAB ACTUATOR	
US	76-21-06			LOSS OF ENGINE DIL	
US	77-12-08			EXTERNAL ELEC GROUND POWER RECEP	
US	86-26-04			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	99-27-02			REPLACEMENT OF FUEL SELECTOR VALVE CAM	SEB99-7
		,			
177RG			177	SERIES )	
US US	72-03-03R3			WING FLAP JACK SCREW OIL PRESSURE GAGE LINE	
US	74-16-06 75-07-02			AIR FILTER SEAL	
US	76-04-03			ARC PA-500A ACTUATORS	
ÜS	76-14-08			TRIM TAB ACTUATOR	
US	76-21-06			LOSS OF ENGINE DIL	
US	77-12-08			EXTERNAL ELEC GROUND POWER RECEP	
US	79-08-03			ELECTRICAL SYSTEM	
US	88-12-12			FUEL SYSTEM	
400 0	DIEC				
180 SE				SKI AXLE ASSEMBLY	
CF CF	CF-63-07 CF-73-05			RUDDER PEDAL TORQUE TUBE	SIL SE 72-36
CF	CF-87-15R2			SEAT LOCKING MECHANISM	SIL SE 83-6
CF	CF-96-17			WING EXTENSIONS	SB-1-96
	68-17-04			STALL WARNING SYSTEM	
US	73-17-01			FUEL TRANSFER PUMP PLACARD	
US	75-16-01			WING FUEL TANKS	
US	77-04-05			CARBURETOR AIR INTAKE	
US	79-08-03			ELECTRICAL SYSTEM	
US US	79-10-14R1 79-25-07			FUEL TANK VENTING ALTERNATOR GROUND	
US	83-17-06			AILERON BALANCE WEIGHTS	
us	84-10-01R1			FUEL TANK DRAINS / FUEL BLADDER CELLS	
US	93-05-06			IGNITION SWITCHES	SEB91-5
US	96-12-22			ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13			COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
US	98-21-21			BOB FIELDS AEROCESSORIES STC	
US	98-23-02			AIRGLAS ENGRG SKI INSTALLATION	
180		-	100	SERIES )	
CF	CF-58-16	,	180	BALL CHECK AND VENT TUBE	SI 180-2 180-11
US	59-10-03			FLASHER SWITCH	
US	86-26-04				SEB86-8
US	90-21-08			UNDETECTED FUEL LOSS	
180A		(	180	SERIES )	
US	59-10-03			FLASHER SWITCH	0.000
US	86-26-04			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
180B			190	SERIES )	
US	86-26-04	,	130	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
	00 20 07			. LEGI, CE I VEGI GIOGEDEN ANNICES ADDOCTEN	
180C		(	180	SERIES )	
US	86-26-04			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
		,			
180D		(	180	SERIES )	055000
US	86-26-04			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
1905		(	190	SERIES )	
180E US	86-26-04	,	180	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
03	55 20 04				
180F		(	180	SERIES )	
US	86-24-07			ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-26-04			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
		,			
180G	00 04 07	(	180	SERIES )	5570 6
US US	86-24-07			ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-26-04			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
180H		(	180	SERIES )	
US	76-04-03	•		ARC PA-500A ACTUATORS	
US	86-24-07			ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-26-04			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
CESSNA 180H (CONTI	NUED / SUITE) 93-24-15	(	O SERIES )	
180J US	73~23-07	(	INSTRUMENT PANEL LIGHTING RHEOSTAT  D SERIES )	SEB92-33R1
UŞ	76-04-03		DEFECTIVE SPAR ATTACHMENT FITTING ARC PA-500A ACTUATORS	
US US	77-12-08 86-24-07		EXTERNAL ELEC GROUND POWER RECEP	
US	93-24-15		ENGINE CONTROLS - BALL TYPE ROD END INSTRUMENT PANEL LIGHTING RHEOSTAT	SE79-6 SEB92-33R1
180K		(	SERIES )	
US US	77-12-08 83-22-06		EXTERNAL ELEC GROUND POWER RECEP	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD END	S SE79-6
182 S				
CF CF	CF-87-15R2 CF-96-17		SEAT LOCKING MECHANISM WING EXTENSIONS	SIL SE 83-6 SB-1-96
US	71-22-02		CRACKS IN NOSE GEAR FORK	
US US	72-07-09 73-17-01		CRACKS AND LOOSE BOLTS IN FIN & RUD FUEL TRANSFER PUMP PLACARD	DE
US US	75-16-01 77-04-05		WING FUEL TANKS	
US	77-23-11		CARBURETOR AIR INTAKE ELT INSTALLATION	
US US	78-01-14 79-08-03		ELT INSTALLATION ELECTRICAL SYSTEM	
US	79-10-14R1		FUEL TANK VENTING	
US US	79-25-07 83-17-06		ALTERNATOR GROUND AILERON BALANCE WEIGHTS	
US	84-10-01R1		FUEL TANK DRAINS / FUEL BLADDER CEL	LS
US US	93-05-06 96-12-22		IGNITION SWITCHES ENGINE OIL FILTER ADAPTERS ASSEMBLI	SEB91-5 ES ATTACHED SKETCH
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRA	
US	98-21-21		BOB FIELDS AEROCESSORIES STC	
<b>182</b> US	59-10-03	( 1	P SERIES ) FLASHER SWITCH	
US	73-23-07		DEFECTIVE SPAR ATTACHMENT FITTING	
US US	75-05-02 83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJ	
182A		( 1	SERIES )	
US US	59-10-03 75-05-02		FLASHER SWITCH ENGINE OIL	
US	83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJ	JSTER SEB86-8
182B	75 05 00	( 1	SERIES ) FNGINE OIL	
US US	75-05-02 83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJ	JSTER SEB86-8
182C		( 1	SERIES )	
US US	75-05-02 83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJ	JSTER SEB86-8
182D		( 1	SERIES )	
US	75-05-02		ENGINE OIL PLACARD - IMPROPER FUEL CAP SEALING	
US US	83-13-01 86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJ	JSTER SEB86-8
182E		( 1	SERIES )	
US	72-03-03R3		WING FLAP JACK SCREW ENGINE OIL	
US US	75-05-02 83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
us	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJ	JSTER SEB86-8
182F		( 1	SERIES )	
US	72-03-03R3 75-05-02		WING FLAP JACK SCREW ENGINE OIL	
US US	83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
CESSNA				
182F		( 182	SERIES )	
	NUED / SUITE)			
US	86-24-07 86-26-04		ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
182G		( 185	SERIES )	
US	72-03-03R3	\!.0.2	WING FLAP JACK SCREW	
US	75-05-02		ENGINE OIL	
US	83-13-01 86-24-07		PLACARD - IMPROPER FUEL CAP SEALING ENGINE CONTROLS - BALL TYPE ROD ENDS	
US	86-26-04		ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
182H		( 400		32860 8
US	72-03-03R3	( 102	SERIES ) WING FLAP JACK SCREW	
US	75-05-02		ENGINE OIL	
US	83-13-01, 86-24-07		PLACARD - IMPROPER FUEL CAP SEALING	
US	86-26-04		ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6
182ป		(		35880-8
US	72-03-03R3	( 182	SERIES ) WING FLAP JACK SCREW	
US	75-05-02		ENGINE OIL	
US US	83-13-01 86-24-07	,	PLACARD - IMPROPER FUEL CAP SEALING	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6
				SEB86-8
182K US	72-03-03R3	( 182	SERIES )	
US	75-05-02		WING FLAP JACK SCREW ENGINE OIL	
US	83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US US	86-24-07 86-26-04		ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
	00 20 04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
<b>182L</b> US	72-03-03R3	( 182	SERIES )	
US	75-05-02		WING FLAP JACK SCREW ENGINE OIL	
US	83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US US	86-24-07 86-26 <b>-</b> 04		ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
00	00 20 04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
182M	70.00.000	( 182	SERIES )	
US US	72-03-03R3 75-05-02		WING FLAP JACK SCREW ENGINE OIL	
US	83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
182N			SERIES )	
US US	72-03-03R3 75-05-02		WING FLAP JACK SCREW	
US	76-04-03		ENGINE OIL ARC PA-500A ACTUATORS	
US	83-13-01		PLACARD - IMPROPER FUEL CAP SEALING	
US US	86-24-07 86-26-04		ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6
			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
182P US	75-05-00		SERIES )	
US	75-05-02 76-04-03		ENGINE DIL ARC PA-500A ACTUATORS	
US	77-02-09		WING FLAP SYSTEM	
US US	77-12-08 77-14-09		EXTERNAL ELEC GROUND POWER RECEP	
US	83-13-01		AIRCRAFT CONTROLABILITY PLACARD - IMPROPER FUEL CAP SEALING	
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
1820			SERIES )	
us	77-02-09		WING FLAP ACTUATOR	
US US	77-12-08	1	EXTERNAL ELEC GROUND POWER RECEP	
	77-14-09 83-13-01		AIRCRAFT CONTROLABILITY	
US	83-22-06		PLACARD - IMPROPER FUEL CAP SEALING ALLERON HINGE PIN	
US	86-24-07	E	NGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
182R			SERIES )	
US	83-22-06		AILERON HINGE PIN	
ATROD	AET /AEDONIESS			

MODEL / N	AD NUMBER	(SERIES / SERIE) SUBJECT	
ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CESSNA 182S US US US	98-01-01 98-01-14 98-13-10	ALTERNATE AIR STATIC SOURCE EXHAUST MUFFLER EXHAUST MUFFLER CRACKING	97-34-02R1 SB97-78-01 98-78-02
R182 US US US US	83-13-01 83-22-06 86-24-07 93-05-06	( 182 SERIES )  PLACARD - IMPROPER FUEL CAP SEALING  AILERON HINGE PIN  ENGINE CONTROLS - BALL TYPE ROD ENDS  IGNITION SWITCHES	SE79-6 SEB91-5
TR182 US	83-22-06	( 182 SERIES ) AILERON HINGE PIN	
185 S	ERIES		
CF CF CF US US US US	CF-73-05 CF-87-15R2 CF-96-17 68-17-04 75-09-06 75-16-01 77-04-05 79-08-03	RUDDER PEDAL TORQUE TUBE SEAT LOCKING MECHANISM WING EXTENSIONS STALL WARNING SYSTEM ENGINE INDUCTION AIR DUCT WING FUEL TANKS CARBURETOR AIR INTAKE ELECTRICAL SYSTEM	SIL SE 72-36 SIL SE 83-6 SB-1-96
US US US US US US US	79-10-14R1 79-25-07 83-17-06 84-10-01R1 86-19-11 87-20-04 93-05-06	FUEL TANK VENTING ALTERNATOR GROUND AILERON BALANCE WEIGHTS FUEL TANK DRAINS / FUEL BLADDER CELLS FUEL RESERVOIRS FUEL SYSTEM - QUICK DRAINS IGNITION SWITCHES	SEB91-5
US US US US	96-12-22 97-01-13 98-21-21 98-23-02	ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM BOB FIELDS AEROCESSORIES STC AIRGLAS ENGRG SKI INSTALLATION	ATTACHED SKETCH
185 US US	73-23-07 86-26-04	( 185 SERIES )  DEFECTIVE SPAR ATTACH FITTINGS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
185A US	86-26-04	( 185 SERIES ) PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
185B US US	86-24-07 86-26-04	( 185 SERIES )  ENGINE CONTROLS - BALL TYPE ROD ENDS  PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
185C US US	86-24-07 86-26-04	(185 SERIES )  ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
1850 US US US	86-24-07 86-26-04 93-24-15	( 185 SERIES ) ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER INSTRUMENT PANEL LIGHTING RHEOSTAT	SE79-6 SEB86-8 SEB92-33R1
185E US US US	86-24-07 86-26-04 93-24-15	( 185 SERIES )  ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER INSTRUMENT PANEL LIGHTING RHEOSTAT	SE79-6 SEB86-8 SEB92-33R1
A185E US US US	76-04-03 86-24-07 86-26-04	( 185 SERIES )  ARC PA-500A ACTUATORS  ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
A185F US US US US	76-04-03 77-12-08 83-22-06 86-24-07	( 185 SERIES )  ARC PA-500A ACTUATORS  EXTERNAL ELEC GROUND POWER RECEP  AILERON HINGE PIN  ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
188 SE CF US		SEAT LOCKING MECHANISM STRANDS ON CONTROL CABLES	SIL SE 83-6

MAKE / CONSTRUCTEUR

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. SUBJECT SUJET

ONIGINE	NOWERO DE CONSTGILE		30001	BOLLETIN DE SERVICE DE REF.
CESSNA				
	ERIES			
	NUED / SUITE)		CHOTHE TAIDLIGTTON AND DUGT	
US	75-09-06		ENGINE INDUCTION AIR DUCT	
US	75-16-01		WING FUEL TANKS	
US	77-04-05		CARBURETOR AIR INTAKE	
US	79-08-03		ELECTRICAL SYSTEM	
US	79-10-14R1		FUEL TANK VENTING	
US	79-25-07		ALTERNATOR GROUND	
US	84-10-01R1		FUEL TANK DRAINS / FUEL BLADDER CELLS	
US	86-19-11		FUEL RESERVOIRS	0000
US	86-24-07		ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
188			SERIES )	
CF	CF-67-01	( 188		
US	68-07-07		REQUIRED MODIFICATION RUDDER PEDAL ASSEMBLY	
] 03	00-07-07		RODDER PEDAL ASSEMBLY	
188B		( 100	SERIES )	
1000		( 100	SEKIES )	
A188		( 100	SERIES )	
CF	CF-61-01	( 188	FIRE PROTECTION	
US	68-07-07	•••••		
US	69-04-02		RUDDER PEDAL ASSEMBLY THROTTLE BELLCRANK BRACKET	
	00 04 02		THOTTEE BLECKANK BRACKET	
A188A		( 189	SERIES )	
A TOOA		(108	JERILU /	
A188B		( 188	SERIES )	
US	74-23-07	( 100	AIR INLET DUCT	
	, , 20 0,		AIN INCE! BOO!	
190				
CF	CF-63-07		SKI AXLE ASSEMBLY	
CF	CF-87-15R2		SEAT LOCKING MECHANISM	SİL SE 83-6
us.	50-39-01		RUDDER CABLE INSPECTION	21F 2E 83-6
ÜS	51-10-04		COWL MOUNTING CHANNELS	
US	51-11-02		ELEVATOR SPAR	
US	63-20-02		WING SPAR INSPECTION	
US	79-08-03		ELECTRICAL SYSTEM	
US	84-10-01R1		FUEL TANK DRAINS / FUEL BLADDER CELLS	
US	86-26-04	*	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEBSC S
US	96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	SEB86-8
	97-01-13		COLLARGED HOSE OIL FUEL OF LIVERALL TO CHOTEM	ATTACHED SKETCH
			COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
195 SE	ERIES			
CF	CF-87-15R2		SEAT LOCKING MECHANISM	STI SE 88 8
US	50-39-01		RUDDER CABLE INSPECTION	SIL SE 83-6
US	51-11-02	• • • • • • • • • • • • • • • • • • • •	ELEVATOR SPAR	
US	63-20-02		WING SPAR INSPECTION	
US	79-08-03		ELECTRICAL SYSTEM	
US	84-10-01R1		FUEL TANK DRAIN / FUEL BLADDER CELLS	
US	86-26-04		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	
	_ ,		TELEST OF THE TOTAL OF HIDRAULIC SYSTEM	96-15,96-21,96-3
195		( 195	SERIES )	
		, ,,,,,		
195A		( 195	SERIES )	
		( 155		
195B		( 195	SERIES )	
		, , , , ,	ounced /	
206				
CF	CF-83-38R1		AUX WING TIP TANKS	AEDO SR EA4 DA
CF	CF-87-15R2		AUX WING TIP TANKS SEAT LOCKING MECHANISM	ALKO 3D FAT KA
US	69-08-11		FUEL BOOST PUMP	SIL SE 83-6
US	71-24-04		FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3		WING FLAP JACK SCREW	
US	72-07-09	• • • • • • • • • • • • • • • • • • • •	CRACKS AND LOOSE BOLTS IN FIN & RUDDE	
US	77-16-05		FUEL SELECTOR VALVE	
US	79-08-03		ELECTRICAL SYSTEM	
US			FUEL TANK VENTING	
US	79-15-01		FUEL FLOW DISTRIBUTION	
us	84-10-01R1		FUEL TANK DRAIN / FUEL BLADDER CELLS	
US	85-02-07		FUEL SELECTOR	
US	85-03-01		THROTTLE AND MIXTURE CONTROLS	
			THE THE MINISTER CONTROLS	
ATDOD	PART / AEDONIEEC			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN

	NOMENO DE CONSIGNE	20151	BULLETIN DE SERVICE DE REF.
CESSNA			
206			
	NUED / SUITE)		
US	85-10-02	ENCINE TARRESTED	
US	86-19-11	ENGINE INDUCTION AIRBOX	
US	86-24-07	FUEL RESERVOIRS	
	86-26-04	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	96-12-22	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	97-01-13	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
03	5/ 01 13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
206H			
US	99-13-04	LOCCE ATTERON CONTROL OF LOCAL CONTROL	
03	33-13-04	LOOSE AILERON CONTROL BELLCRANK STOP BOLTS	S.S.P. 99-27-02
P206	SERIES		
	CF-83-38R1	ALIV LITAIC TID TANKS	
CF	CF-87-15R2	AUX WING TIP TANKS	AERO SB FA1 RA
US	72-03-03R3	SEAT LOCKING MECHANISM WING FLAP JACK SCREW	SIL SE 83-6
US	72-03-0383		
US	75-16-01	CRACKS AND LOOSE BOLTS IN FIN & RUDDE	
US	77-16-05	WING FUEL TANKS	
US	79-08-03	FUEL SELECTOR VALVE	
US	79-08-03 79-10-14R1	ELECTRICAL SYSTEM	
US	84-10-01R1	FUEL TANK VENTING	
US	85-00-07	FUEL TANK DRAIN / FUEL BLADDER CELLS	
US	85-02-07	FUEL SELECTOR	
	85-03-01 85-10-02	THROTTLE AND MIXTURE CONTROLS ENGINE INDUCTION AIRBOX	
US			
US	86-19-11	FUEL RESERVOIRS	
	86-24-07 86-26-04	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
	97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM BOB FIELDS AEROCESSORIES STC	96-15,96-21,96-3
US	98-21-21	BUB FIELDS AEROCESSURIES SIC	
P206		( P206 SERIES )	
	00 00 11	FUEL BOOST PUMP	
US	69-08-11	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	71-24-04	FUEL FLOW DISTRIBUTION	
US	79-15-01	ALTERNATOR GROUND	
US	79-25-07	ALTERNATUR GROUND	
P206A		( P206 SERIES )	
	71 04 04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	71-24-04	FLEXIBLE FIOSES IN ENGINE COMPARIMENT	
DOOGD		( P206 SERIES )	
P206B	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	/1-24-04	LEVIPLE 110252 III ENGINE COM MUMERI	
BOOCC		( P206 SERIES )	
P206C	74 04 04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	71-24-04	TENTOLE ROSES IN CHARLE SOM MITTER	***************************************
P206D		( P206 SERIES )	
F 206D		( 1200 04.1220 )	
TP200	SERIES		
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
CF	CF-83-38R1 CF-87-15R2	SEAT LOCKING MECHANISM	SIL SE 83-6
US	71-09-07R1	EXHAUST MANIFOLD HEAT EXCHANGER	
US	72-07-09	CRACKS IN FIN AND RUDDER	
US	75-16-01	WING FUEL TANK PLACARDS	
US	78-07-01	ENGINE OIL PUMP	
US	79-08-03	ELECTRICAL SYSTEM	
		FUEL TANK VENTING	
US	79-10-14R1	FUEL SYSTEM VAPOUR BLOCKAGE	
US	79-15-01	OIL PRESSURE	
US	80-07-01 84-10-0181	FUEL TANK DRAIN / FUEL BLADDER CELLS	
US	84-10-01R1	FUEL SELECTOR	
US	85-02-07	FUEL RESERVOIRS	
US	86-19-11	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-24-07	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
US	86-26-04	ACDOULTD COL HOSE ASSEMBLIES	SEB88-5
US		ENGINE III EILIEK ADAPIEKS ASSEMBLIES	ATTACHED SKETCH I
US	96-12-22	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
US	97-01-13	BOB FIELDS AEROCESSORIES STC	.,
US	98-21-21		
70000		( TP206 SERIES )	
TP206B		FLEXIBLE HOSES IN ENGINE COMPARTMENT	
us	71-24-04	WING FLAP JACK SCREW	
US	72-03-03R3	THROTTLE AND MIXTURE CONTROLS	
US	85-03-01		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

CESSNA			
<b>TP206</b> US	72-03-03R3	( TP206 SERIES ) WING FLAP JACK SCREW	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
U206	SERIES CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
CF	CF-87-15R2	SEAT LOCKING MECHANISM	SIL SE 83-6
US	72-07-09	CRACKS AND LOOSE BOLTS IN FIN & RUDDE	
US	75-16-01	WING FUEL TANKS	
US	77-16-05 79-08-03	FUEL SELECTOR VALVE ELECTRICAL SYSTEM	
US	79-08-03 79-10-14R1	FUEL TANK VENTING	
US	79-15-01	FUEL FLOW DISTRIBUTION	
US	79-25-07	ALTERNATOR GROUND	
US	84~10-01R1	FUEL TANK DRAIN / FUEL BLADDER CELLS	
US	85-02-07 85-10-02	FUEL SELECTOR ENGINE INDUCTION AIRBOX	
	86-19-11	FUEL RESERVOIRS	
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	93-05-06	IGNITION SWITCHES	SEB91-5
US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13 98-21-21	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM BOB FIELDS AEROCESSORIES STC	96-15,96-21,96-3
U206	00 00 44	( U206 SERIES )	
US	69-08-11 71-24-04	FUEL BOOST PUMP FLEXIBLE HOSES IN ENGINE COMPARTMENT	· · · · · · · · · · · · · · · · · · ·
US	72-03-03R3	WING FLAP JACK SCREW	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
U206A		( U206 SERIES )	
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US US	85-03-01 86-26-04	THROTTLE AND MIXTURE CONTROLS	05000
05	00-20-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
T206H US	99-13-04	LOOSE AILERON CONTROL BELLCRANK STOP BOLTS	S S D 90-27-02
	30 10 01		3.3.7. 99 27 02
U206B	E	( U206 SERIES )	
US	71-24-04 72-03-03R3	FLEXIBLE HOSES IN ENGINE COMPARTMENT WING FLAP JACK SCREW	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	86-26-04		SEB86-8
110000		( Hood CERTEC )	
U206C US	71-24-04	( U206 SERIES ) FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
U206D		( U206 SERIES )	
US	72-03-03R3	WING FLAP JACK SCREW	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
U206E		( U206 SERIES )	
US	72-03-03R3	WING FLAP JACK SCREW	
US	76-04-03	ARC PA-500A ACTUATORS	05555
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
U206F		( U206 SERIES )	
US	76-04-03	ARC PA-500A ACTUATORS	
US US	77-02-09 77-12-08	WING FLAP SYSTEM	
US	85-17-07	EXTERNAL ELEC GROUND POWER RECEP WING REAR SPAR	
<b>U206G</b> US	77-02-00	( U206 SERIES )	
US	77-02-09 77-12-08	WING FLAP ACTUATOR  EXTERNAL ELEC GROUND POWER RECEP	
US	85-17-07	WING REAR SPAR	
US	86-11-07	STC SA2353NM - VOLTAGE REG & ELEC SY	

MAKE / CONS MODEL / MODEL / MO		(SERIES / SERIE)	
ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CESSNA			
	SERIES		
CF	CF-83-38R1	AUX WING TIP TANKS	AFRO SR FA1 DA
CF	CF-87-15R2	SEAT LOCKING MECHANISM	SIL SE 83-6
US	71-09-07R1	EXHAUST MANIFOLD HEAT EXCHANGER	315 35 00 0
US	72-07-09 .	CRACKS AND LOOSE BOLTS IN FIN & RUDDE	
US	75-16-01	WING FUEL TANKS	
US	77-16-05	FUEL SELECTOR VALVE	
US	78-07-01	ENGINE OIL PUMP	
US	79-08-03	ELECTRICAL SYSTEM	
US	79-10-14R1	FUEL TANK VENTING	
US	79-15-01	FUEL FLOW DISTRIBUTION	
US	79-25-07	ALTERNATOR GROUND	
US	80-07-01	OIL PRESSURE	
US	84-10-01R1	FUEL TANK DRAIN / FUEL BLADDER CELLS	
US	85-02-07	FUEL SELECTOR	
US	86-19-11	FUEL RESERVOIRS	
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	88-22-07	AEROQUIP 601 HOSE ASSEMBLIES	SEB88-5
US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
TU206A		( TU206 SERIES )	
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
TU206B		( TU206 SERIES )	
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US	85-03-01	THROTTLE AND MIXTURE CONTROL	SE69-16
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
TU206C		( TU206 SERIES )	
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US	85-03-01	THEOTIE AND MIXTHEE CONTENTS	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
TU206F		( TU206 SERIES )	
US	76-04-03	ARC PA-500A ACTUATORS	
US	77-12-08	EXTERNAL ELEC GROUND POWER RECEP WING REAR SPAR	
US	85-17-07	WING KEAN SPAN	
TU206G		( TU206 SERIES )	
US	77-12-08	EXTERNAL ELEC GROUND POWER RECEP	
US	79-03-03	ENGINE OIL PRESSURE	
US	85-17-07	WING REAR SPAR	
US	86-11-07	STC SA2353NM - VOLTAGE REG & ELEC SY	
207 SE	RIES		
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
US	72-07-09	CRACKS AND LOOSE BOLTS IN FIN & RUDDE	
US	75-16-01	WING FUEL TANKS	
US	77-02-09	WING FLAP SYSTEM	
US	77-16-05	FUEL SELECTOR VALVE	
US	70-00-03	ELECTRICAL SYSTEM	
US	79-10-14R1	FUEL TANK VENTING	
US	79-15-01	FUEL FLOW DISTRIBUTION	
US	79-25-07	ALTERNATOR GROUND	
US	84-10-01R1	FUEL TANK DRAIN / FUEL BLADDER CELLS	
IIS	96-19-11	FUEL RESERVOIRS	

76-04-03 US 77-12-08 US 85-02-07 US

ARC PA-500A ACTUATORS EXTERNAL ELEC GROUND POWER RECEP FUEL SELECTOR THROTTLE AND MIXTURE CONTROLS

ENGINE CONTROLS - BALL TYPE ROD ENDS

IGNITION SWITCHES ENGINE OIL FILTER ADAPTERS ASSEMBLIES

COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM

WING FLAP JACK SCREW

( 207 SERIES )

86-19-11

86-24-07

93-05-06

96-12-22

97-01-13

85-03-01

72-03-03R3

US

US

US

US

US

US

US

207

ATTACHED SKETCH

96-15,96-21,96-3

SE79-6

SEB91-5

# INDEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN CANADA

	INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA			
MAKE / CON MODEL / N	ISTRUCTEUR	( CEDIEC	(CEDIE)	
ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGN		(/SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN
			30001	BULLETIN DE SERVICE DE REF
CESSNA 207		( 00	7 050770	
	NUED / SUITE)	( 20	7 SERIES )	
US	85-10-02		ENGINE INDUCTION AIRBOX	
US US	85-17-07 86-26-04		WING REAR SPAR	
			PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
207A US	77-12-00	( 20	7 SERIES )	
US	77-12-08 85-02-07		EXTERNAL ELEC GROUND POWER RECEP FUEL SELECTOR	
US	85-10-02	******************	ENGINE INDUCTION AIRBOX	
US	85-17-07		WING REAR SPAR	
T207 S	SERIES			
CF CF	CF-83-38R1		AUX WING TIP TANKS	AERO SB FA1 RA
US	CF-87-15R2 71-09-07R1		SEAT LOCKING MECHANISM EXHAUST MANIFOLD HEAT EXCHANGER	SIL SE 83-6
US	72-07-09		CRACKS AND LOOSE BOLTS IN FIN & RUDDE	
US	75-16-01		WING FUEL TANKS	
US	77-16-05 78-07-01		FUEL SELECTOR VALVE ENGINE OIL PUMP	
US	79-10-14R1		FUEL TANK VENTING	
US US	79-15-01 79-25-07		FUEL FLOW DISTRIBUTION	
US	80-07-01		ALTERNATOR GROUND OIL PRESSURE	
US	84-10-01R1		FUEL TANK DRAIN / FUEL BLADDER CELLS	
US US	86-19-11 86-24-07		FUEL RESERVOIRS	
US	88-22-07		ENGINE CONTROLS - BALL TYPE ROD ENDS AEROQUIP 601 HOSE ASSEMBLIES	SE79-6
US	96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	SEB88-5 ATTACHED SKETCH
US	97-01-13		COLLAPSED HOSE, DIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
T207		( T20	7 SERIES )	
US US	72-03-03R3 76-04-03		WING FLAP JACK SCREW	
US	77-12-08		ARC PA-500A ACTUATORS EXTERNAL ELEC GROUND POWER RECEP	
US	85-02-07		FUEL SELECTOR	
US US	85-03-01 85-17-07		THROTTLE AND MIXTURE CONTROLS WING REAR SPAR	
US	86-26-04	• • • • • • • • • • • • • • • • • • • •	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
T207A		( T00		31000-0
US	77-12-08	( 120	7 SERIES ) EXTERNAL ELEC GROUND POWER RECEP	
US	79-03-03		ENGINE OIL PRESSURE	
US US	85-02-07 <b>8</b> 5-17-07		FUEL SELECTOR WING REAR SPAR	
			TING ILAN SPAN	
208 SEI	90-05-01		DICHT FLAD BELLODANIK	
US	90-05-04		RIGHT FLAP BELLCRANK NLG SHIMMY DAMPER / ENGINE MOUNT RING	CAB89-34
	96-09-15		SEVERE ICING	
	96-12-22 97-01-13		ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH
	97-25-04		POWER LEVER POSITIONING BELOW FLIGHT IDLE	96-15,96-21,96-3
208		( 200		
	86-22-06	( 208	SERIES ) FUEL TANK SELECTOR SYSTEM	CAR96-9 - 00
208B		( 000		CAB86-8, -26
	88-19-06	( 208	SERIES ) ELEVATOR BALANCE LIMITS	
			THE TATE OF THE TA	CAB 88-27
210 SER	RIES CF-87-15R2		SEAT LOCKING MEGHANITON	
US	72-07-09		SEAT LOCKING MECHANISM CRACKS AND LOOSE BOLTS IN FIN & RUDDE	SIL SE 83-6
	77-16-05		FUEL SELECTOR VALVE	
	79-08-03 79-10-14R1		ELECTRICAL SYSTEM FUEL TANK VENTING	
US	79-15-01		FUEL FLOW DISTRIBUTION	
	79-25-07 84-10-01R1		ALTERNATOR GROUND	
	91-22-01		FUEL TANK DRAIN / FUEL BLADDER CELLS FUEL LEAKAGE	65.00.00
US 9	93-05-06		IGNITION SWITCHES	SE 82-32 SEB91-5
	94-12-08 96-12-22		FUEL QTY SYSTEM	SEB91-10
	97-01-13		ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH
ATRCRA	FT/AERONEFS		THE ON THE MADE TO STATE OF	96-15,96-21,96-3

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CECCNA			
CESSNA 210 S			
	NUED / SUITE)		
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
040			
210 CF	CF-83-38R1	( 210 SERIES )	
US	66-19-02	AUX WING TIP TANKS FUEL SYSTEM	AERO SB FA1 RA
US	69-08-11	FUEL BOOST PUMP	
US	76-04-01	MAIN GEAR EXTENSION	
US US	76-14-07R2 86-26-04	LANDING GEAR SADDLES	
05	80 20 04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
210 5		( 210 SERIES )	
US	69-08-11	FUEL BOOST PUMP	
US US	77-16-05 79-08-03	FUEL SELECTOR VALVE	
US	79-15-01	ELECTRICAL SYSTEM FUEL FLOW DISTRIBUTION	
US	84-10-01R1	FUEL TANK DRAIN / FUEL BLADDER CELLS	
US	85-02-07	FUEL SELECTOR	
US US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	86-19-11 86-26-04	FUEL RESERVOIR	
		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	
210 5/		( 210 SERIES )	
US	79-08-03	ELECTRICAL SYSTEM	
US US	85-02-07 86-19-11	FUEL SELECTOR FUEL RESERVOIR	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	
210A		( 210 SERIES )	
US US	66-19-02 76-04-01	FUEL SYSTEM MAIN GEAR EXTENSION	
US	76-14-07R2	LANDING GEAR SADDLES	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
0.4.0.0			
210B US	76-04-01	( 210 SERIES ) MAIN GEAR EXTENSION	
US	76-14-07R2	LANDING GEAR SADDLES	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	86-19-11	FUEL RESERVOIRS	SEROC O
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
210C		( 210 SERIES )	
US	76-04-01	MAIN GEAR EXTENSION	
US	76-14-07R2	LANDING GEAR SADDLES THROTTLE AND MIXTURE CONTROLS	
US US	85-03-01 86-19-11	FUEL RESERVOIRS	
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
0400		( 210 SERIES )	
210D CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US	76-04-01	MAIN GEAR EXTENSION LANDING GEAR SADDLES	
US US	76-14-07R2 85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	85-10-02	ENGINE INDUCTION AIRBOX	
US	86-19-11	FUEL RESERVOIRS	6570.0
	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
US	86-26-04		32500 0
210E		( 210 SERIES )	
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT WING FLAP JACK SCREW	
US US	72-03-03R3 76-14-07R2	LANDING GEAR SADDLES	
	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US	85-10-02	ENGINE INDUCTION AIRBOX	
		FUEL RESERVOIRS  ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US US	86-24-07 86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
03	20 04		

MAKE / CON MODEL / N	STRUCTEUR	(SERIES / SERIE)		
ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.	
CESSNA				
210F		( 210 SERIES )		
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA	
US	86-24-07	ENGINE CONTROL - BALL TYPE ROD ENDS	SE79-6	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8	
210G		( 210 SERIES )		
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA	
US US	71-24-04 72-03-03R3	FLEXIBLE HOSES IN ENGINE COMPARTMENT		
US	76-14-07R2	WING FLAP JACK SCREW LANDING GEAR SADDLES		
US	78-26-12	FUEL QUANTITY SYSTEM		
US US	85-02-07	FUEL SELECTOR		
US	85-03-01 85-10-02	THROTTLE AND MIXTURE CONTROLS ENGINE INDUCTION AIRBOX		
UŞ	86-19-11	FUEL RESERVOIRS		
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8	
210H		( 210 SERIES )		
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA	
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT		
US US	72-03-03R3 76-14-07R2	WING FLAP JACK SCREW LANDING GEAR SADDLES		
US	78-26-12	FUEL QUANTITY SYSTEM		
US	85-02-07	FUEL SELECTOR		
US US	85-03-01	THROTTLE AND MIXTURE CONTROLS		
US	85-10-02 86-19-11	ENGINE INDUCTION AIRBOX FUEL RESERVOIRS		
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD FNDS	SE79-6	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8	
210J		( 210 SERIES )	***************************************	
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA	
US	72-03-03R3	WING FLAP JACK SCREW	ALKO 36 FAT KA	
US US	76-14-07R2 78-26-12	LANDING GEAR SADDLES		
US	85-02-07	FUEL QUANTITY SYSTEM FUEL SELECTOR		
US	85-03-01	THROTTLE AND MIXTURE CONTROLS		
US	85-10-02	ENGINE INDUCTION AIRBOX		
US US	86-19-11 86-24-07	FUEL RESERVOIRS		
US	86-26-04	ENGINE CONTROLS - BALL TYPE ROD ENDS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	\$E79-6 \$EB86-8	
0.1.01/			3000 8	
210K CF	CF-83-38R1	( 210 SERIES )		
US	72-03-03R3	AUX WING TIP TANKS WING FLAP JACK SCREW	· AERO SB FA1 RA	
US	76-04-03	ARC PA-500A ACTUATORS		
US	80-21-03	ROLL AXIS FLIGHT CONTROL		
US ·	85-02-07 85-10-02	FUEL SELECTOR		
US	86-19-11	ENGINE INDUCTION AIRBOX FUEL RESERVOIRS		
	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8	
210L		( 210 SERIES )		
	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA	
US	76-04-03	ARC PA-500A ACTUATORS	,	
	77-12-08 79-19-06	EXTERNAL ELEC GROUND POWER RECEP	***************************************	
	80-21-03	FUEL FLOW SYSTEM PER STC SA3835WE ROLL AXIS FLIGHT CONTROL		
US	82-06-10	VACUUM-DRIVEN-ATTITUDE INSTRUMENTS		
	85-02-07 85-10-03	FUEL SELECTOR		
	85-10-02 86-19-11	ENGINE INDUCTION AIRBOX FUEL RESERVOIRS		
	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6	
210M				
	CF-83-38R1	( 210 SERIES ) AUX WING TIP TANKS		
US	78-11-05	AUTOPILOT ACTUATOR	AERO SB FA1 RA	
	78-26-12	FUEL QUANTITY SYSTEM		
	79-19-06 80-21-03	FUEL FLOW SYSTEM PER STC SA3835WE		
US	82-06-10	ROLL AXIS FLIGHT CONTROL VACUUM-DRIVEN-ATTITUDE INSTRUMENTS		
US	85-02-07	FUEL SELECTOR		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT SUJET

		BULLETIN DE SERVICE DE REF.
CESSNA		
(CONTINUED / SUITE)	( 210 SERIES )	
US 85-10-02	ENGINE INDUCTION AIRBOX	
US 86-19-11	FUEL RESERVOIRS	
US 86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
210N	( 210 SERIES )	
CF CF-83-38R1 US 78-26-12	AUX WING TIP TANKS	AERO SB FA1 RA
US 78-26-12 US 80-21-03	FUEL QUANTITY SYSTEM ROLL AXIS FLIGHT CONTROL	
US 82-06-10	VACUUM-DRIVEN-ATTITUDE INSTRUMENTS	
US 85-02-07 US 85-10-02	FUEL SELECTOR	
US 86-19-11	ENGINE INDUCTION AIRBOX FUEL RESERVOIRS	
0.105		
210R US 86-19-11	( 210 SERIES ) FUEL RESERVOIRS	
	TOLL RESERVOIRS	
P210 SERIES US 88-22-07	AFRONIUS COLUMNIA COL	
US 88-22-07 US 93-05-06	AEROQUIP 601 HOSE ASSEMBLIES IGNITION SWITCHES	SEB88-5
US 94-12-08	FUEL OTY SYSTEM	SEB91-5 SEB91-10
US 96-12-22 US 97-01-13	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US 98-21-21	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM BOB FIELDS AEROCESSORIES STC	96-15,96-21,96-3
<b>P210N</b> CF CF-83-38R1	( P210 SERIES )  AUX WING TIP TANKS	4500 CD 544 D4
US 78-11-05	AUTOPILOT ACTUATOR	AERO SB FA1 RA
US 78-26-12	FUEL QUANTITY SYSTEM	
US 79-15-01 US 79-19-06	FUEL FLOW DISTRIBUTION FUEL FLOW SYSTEM PER STC SA3835WE	
US 79-25-07	ALTERNATOR GROUND	
US 80-21-03 US 81-15-05	ROLL AXIS FLIGHT CONTROL ENGINE AND AIRPLANE MODIFICATIONS	
US 81-15-05 US 81-23-03R2	ENGINE AND AIRPLANE MODIFICATIONS ENGINE EXHAUST SYSTEM	
US 82-06-10	VACUUM-DRIVEN-ATTITUDE INSTRUMENTS	
US 85-02-07 US 85-11-07R1	FUEL SELECTOR TURBOCHARGER OIL RESERVOIR	
US 86-19-11	FUEL RESERVOIRS	
US 86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US 88-25-04 US 98-05-14R1	SLICK MODEL 6220 & 6224 PRESSURIZED MAGNETOS OPERATING IN SEVERE ICING CONDITIONS	1-88 AWD
T210 SERIES US 72-07-09	CRACKS AND LOOSE BOLTS IN FIN & RUDDE	E company
US 77-16-05	FUEL SELECTOR VALVE	
US 78-07-01	ENGINE OIL PUMP	
US 79-08-03 US 79-10-14R1	ELECTRICAL SYSTEM FUEL TANK VENTING	
US 79-15-01	FUEL FLOW DISTRIBUTION	
US 79-25-07	ALTERNATOR GROUND OIL PRESSURE	
US 80-07-01 US 84-10-01R1	FUEL TANK DRAIN / FUEL BLADDER CELLS	
US 86-19-11	FUEL RESERVOIRS	CEROO E
US 88-22-07 US 94-12-08	AEROQUIP 601 HOSE ASSEMBLIES FUEL QTY SYSTEM	SEB88-5 SEB91-10
US 96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US 97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM BOB FIELDS AEROCESSORIES STC	96-15,96-21,96-3
US 98-21-21	DOD FILLDS ALKOGESSONIES SIC	
T210	( T210 SERIES )	CTL CS DO C
CF CF-87-15R1	SEAT LOCKING MECHANISM FUEL BOOST PUMP	SIL SE 83-6
US 69-08-11		
T210F	( T210 SERIES ) AUX WING TIP TANKS	AERO SB FA1 RA
CF CF-83-38R1 US 71-09-07R1	EXHAUSI MANIFULU HEAT EXCHANGER	ALKO SD FAT KA
US 71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US 72-03-03R3	WING FLAP JACK SCREW LANDING GEAR SADDLES	
US 76-14-07R2 US 85-03-01	THROTTLE AND ENGINE MIXTURE	
US 86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6

MAKE / COM MODEL / I ORIGINE ORIGINE	AD NUMBER	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CESSNA			
T210G		( T210 SERIES )	
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
US US	71-09-07R1 71-24-04	EXHAUST MANIFOLD HEAT EXCHANGER FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US	72-03-03R3	WING FLAP JACK SCREW	
US	76-14-07R2	LANDING GEAR SADDLES	
US	78-26-12	FUEL QUANTITY SYSTEM	
US	85-02-07 85-03-01	FUEL SELECTOR THROTTLE AND MIXTURE CONTROLS	
US	86-24-07	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
T210H		( T210 SERIES )	
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
US	71-09-07R1	EXHAUST MANIFOLD HEAT EXCHANGER	
US	71-24-04	FLEXIBLE HOSES IN ENGINE COMPARTMENT	
US US	72-03-03R3 76-14-07R2	WING FLAP JACK SCREW	
US	78-26-12	LANDING GEAR SADDLES FUEL QUANTITY SYSTEM	
US	85-02-07	FUEL SELECTOR	
US	85-03-01	THROTTLE AND MIXTURE CONTROLS	
US US	86-24-07 86-26-04	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
03	06-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SEB86-8
T210J		( T210 SERIES )	
CF US	CF-83-38R1 71-09-07R1	AUX WING TIP TANKS	AERO SB FA1 RA
US	72-03-03R3	EXHAUST MANIFOLD HEAT EXCHANGER WING FLAP JACK SCREW	
US	76-14-07R2	LANDING GEAR SADDLES	
US	78-26-12	FUEL QUANTITY SYSTEM	
US	85-02-07	FUEL SELECTOR	
US US	85-03-01 86-24-07	THROTTLE AND MIXTURE CONTROLS ENGINE CONTROLS - BALL TYPE ROD ENDS	6570.0
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
T210K			
CF	CF-83-38R1	( T210 SERIES ) AUX WING TIP TANKS	AEDO CO EAA DA
US	71-09-07R1	EXHAUST MANIFOLD HEAT EXCHANGER	AERO SB FA1 RA
US	76-04-03	ARC PA-500A ACTUATORS	
US US	80-21-03	ROLL AXIS FLIGHT CONTROL	
US	85-02-07 86-24-07	FUEL SELECTOR ENGINE CONTROLS - BALL TYPE ROD ENDS	5570.0
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	SE79-6 SEB86-8
US	93-13-09	AIR INDUCTION HOSE	32300
T210L		( T210 SERIES )	
CF	CF-83-38R1	AUX WING TIP TANKS	AERO SB FA1 RA
US	71-09-07R1	EXHAUST MANIFOLD HEAT EXCHANGER	ALICE SE FAT IX
US US	76-04-03	ARC PA-500A ACTUATORS	
US	77-12-08 79-19 <b>-</b> 06	EXTERNAL ELEC GROUND POWER RECEP FUEL FLOW SYSTEM PER STC SA3835WE	
US	80-21-03	ROLL AXIS FLIGHT CONTROL	
US	82-06-10	VACUUM-DRIVEN-ATTITUDE INSTRUMENTS	
US	85-02-07	FUEL SELECTOR	
US US	86-24-07 88-25-04	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	93-13-09	SLICK MODEL 6220 & 6224 PRESSURIZED MAGNETOS AIR INDUCTION HOSE	1-88
T0101			
T210M CF	CF-83-38R1	( T210 SERIES )  AUX WING TIP TANKS	AFDO CD CA4 DA
US	71-09-07R1	EXHAUST MANIFOLD HEAT EXCHANGER	AERO SB FA1 RA
US	78-11-05	AUTOPILOT ACTUATOR	
US US	78-26-12	FUEL QUANTITY SYSTEM	
US	79-03-03 <b>79-19-0</b> 6	ENGINE OIL PRESSURE	
US	80-21-03	FUEL FLOW SYSTEM PER STC SA3835WE ROLL AXIS FLIGHT CONTROL	
US	82-06-10	VACUUM-DRIVEN-ATTITUDE INSTRUMENTS	
US	85-02-07	FUEL SELECTOR	
US US	86-24-07 88-25-04	ENGINE CONTROLS - BALL TYPE ROD ENDS	SE79-6
US	93-13-09	SLICK MODEL 6220 & 6224 PRESSURIZED MAGNETOS AIR INDUCTION HOSE	1-88
T210N			
CF	CF-83-38R1	( T210 SERIES ) AUX WING TIP TANKS	1500 CD 511 51
	00 0bk1	AUX WING ITP TANKS	AERO SB FA1 RA

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
CESSNA				
T210N		( T21	O SERIES )	
(CONT II	NUED / SUITE)			
US	71-09-07R1 78-26-12		EXHAUST MANIFOLD HEAT EXCHANGER FUEL QUANTITY SYSTEM	
US	80-21-03		ROLL AXIS FLIGHT CONTROL	
US	82-06-10		VACUUM-DRIVEN-ATTITUDE INSTRUMENTS	
US	85-02-07 86-24-07		FUEL SELECTOR	
US	88-25-04		ENGINE CONTROLS - BALL TYPE ROD ENDS SLICK MODEL 6220 & 6224 PRESSURIZED MAGNETOS	SE79-6 1-88
US	93-13-09		AIR INDUCTION HOSE	1-00
US	98-05-14R1		OPERATING IN SEVERE ICING CONDITIONS	AWD
T303				ĺ
CF	CF-87-15R2		SEAT LOCKING MECHANISM	SIL SE 83-6
US	85-11-05R1 85-23-06		AFM PLACARD - ICING CONDITION FUEL METERING UNITS INSP	
US	86-01-01R2		PLACARD- ICING CONDITIONS	
US	87-21-02R1		FUEL FILLER OPENINGS	SIL ME84-31
US	88-25-04 91-11-09		SLICK MODEL 6220 & 6224 PRESSURIZED MAGNETOS NOSE GEAR ACTUATOR ATTACH FITTING	1-88 MEB88-4
US	95-09-13		FUEL INLET FLOAT VALVE	MEB93-10R1
US	96-12-22 97-01-13		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	98-04-28		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM OPERATING IN SEVERE ICING CONDITIONS	96-15,96-21,96-3 AWD
			7-1./4 00/102/120/10	
305 SI	ERIES 96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED CHETCH
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH 96-15,96-21,96-3
2054		/ 225	CEDIEC )	
<b>305A</b> US	75-04-04	1 305	SERIES ) OIL LINE SYSTEM	
305C		( 305	SERIES )	
310 SI	ERIES			
CF US	CF-81-38 57-04-01		LG WELDED STRUT ASSEMBLY AILERON HINGE	
US	72-03-07		LANDING GEAR FAILURE	
US	72-14-08R1		FLEXIBLE HOSE ASSEMBLIES	
US US	73-07-07 76-08-02R2		FUEL HOSES & ELECTRICAL WIRING CHAFIN WING TIP NOSE CAP	
US	87-21-02R1		FUEL FILLER OPENINGS	SIL ME84-31
US	90-02-13		MLG STRUT BARREL LOCK RINGS & BEARINGS ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED CVETCH
US US	96-12-22 97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	ATTACHED SKETCH 96-15,96-21,96-3
US	98-21-21		BOB FIELDS AEROCESSORIES STC	
310		( 310	SERIES )	
US	69-12-03	( 5,0	FUEL CROSSFEED LINE	
US	69-15-09		FUEL STARVATION FIRE PROCEDURES CHECKLIST	
US	74-20-08		TINE PROCEDURES CHECKETS!	
310B		( 310	SERIES )	
US US	69-12-03 69-15-09		FUEL CROSSFEED LINE FUEL STARVATION	
US	74-20-08		FIRE PROCEDURES CHECKLIST	
		( 040	CEDIES )	
310C US	69-12-03	( 310	SERIES ) FUEL CROSSFEED LINE	
US	69-15-09		FUEL STARVATION	
3100		( 310	SERIES )	
310D US	69-12-03		FUEL CROSSFEED LINE	
US	69-15-09		FUEL STARVATION	
310E			SERIES )	
US	69-12-03		FUEL CROSSFEED LINE	
US	69-15-09		FUEL STARVATION WING TIP NOSE CAP	
US	76-08-02R2			
310F			SERIES ) FUEL CROSSFEED LINE	
US	69-12-03 69-15-09		FUEL STARVATION	
US	03-13-03			

MAKE / CON MODEL / M ORIGIN ORIGINE	STRUCTEUR ODELE AD NUMBER NUMERO DE CONSIGNE	(SERIES /	SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
CESSNA 310H US	69-14-01	( 310	SERIES ) FUEL STARVATION	
<b>310</b> I US US	69-14-01 73-25-01	( 310	SERIES ) FUEL STARVATION HEATER FUEL PUMP RELAY RELOCATION	
310J US	69-14-01	( 310	SERIES ) FUEL STARVATION	
<b>310K</b> US	69-14-01	( 310	SERIES ) FUEL STARVATION	
<b>310</b> L US	69-14-01	( 310	SERIES ) FUEL STARVATION	
310N US US	69-14-01 73-01-02	( 310	SERIES ) FUEL STARVATION ALTERNATE AIR SYSTEM	
310P US US	69-14-01 73-01-02	( 310	SERIES ) FUEL STARVATION ALTERNATE AIR SYSTEM	
310Q US US US US	73-01-02 74-20-01 75-23-07 76-04-03	( 310	SERIES ) ALTERNATE AIR SYSTEM MAIN LANDING GEAR TRUNNION EMERGENCY EXIT WINDOW ARC PA-500A ACTUATORS	
310R US US US	75-23-07 76-04-03 78-11-05 80-13-14	( 310	SERIES ) EMERGENCY EXIT WINDOW ARC PA-500A ACTUATORS AUTOPILOT ACTUATOR FUEL FLOW TRANSDUCER	
US <b>T310 S</b>	98-04-28 ERIES		OPERATING IN SEVERE ICING CONDITIONS	AWD
US US US US	75-23-08R5 76-08-02R2 96-12-22 97-01-13 98-21-21		ENGINE EXHUAST SYSTEM WING TIP NOSE CAP ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM BOB FIELDS AEROCESSORIES STC	ATTACHED SKETCH 96-15,96-21,96-3
T310P US US	69-14-01 70-03-04R1	( T31	O SERIES ) FUEL STARVATION TURBO SUPERCHARGER TURBINE HOUSING	ME70-3, ME72-4
T310Q US US US	70-03-04R1 75-23-07 76-04-03	( T31	O SERIES ) TURBO SUPERCHARGER TURBINE HOUSING EMERGENCY EXIT WINDOW ARC PA-500A ACTUATORS	ME70-3, ME72-4
T310R US US US US	75-23-07 76-04-03 78-11-05 98-04-28	( T310	D SERIES ) EMERGENCY EXIT WINDOW ARC PA-500A ACTUATORS AUTOPILOT ACTUATOR OPERATING IN SEVERE ICING CONDITIONS	AWD
	RIES CF-81-38 71-09-01 72-14-08R1 73-07-07 75-11-01 75-23-08R5 76-08-02R2		LG WELDED STRUT ASSEMBLY NACELLE ELECTRICAL FAILURES FLEXIBLE FUEL HOSE ASSEMBLIES FUEL HOSES & ELECTRICAL WIRING CHAFFI G FUEL LINES ENGINE EXHAUST SYSTEM	
US US US US US	76-08-02R2 87-21-02R1 90-02-13 96-12-22 97-01-13 98-21-21	•••••••	WING TIP NOSE CAP FUEL FILLER OPENINGS MLG STRUT BARREL LOCK RINGS & BEARINGS ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM BOB FIELDS AEROCESSORIES STC	SIL ME84-31 ATTACHED SKETCH 96-15,96-21,96-3

MAKE / CON MODEL / M ORIGINE ORIGINE		(SERIES	/ SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
CESSNA 320	CO-15 CO		O SERIES )	JOSEPH DE GENVIOL DE REF
320 1	69-15-09		FUEL STARVATION  O SERIES )	
US 320A	69-15-09	( 32	FUEL STARVATION  O SERIES )	
US 320B	69-14-01	( 22	FUEL STARVATION	
US	69-14-01	( 3 4	O SERIES ) FUEL STARVATION	
<b>320C</b> US	69-14-01		O SERIES ) FUEL STARVATION	
320E US US	69-14-01 70-03-04R1	( 32	D SERIES ) FUEL STARVATION TURBO SUPERCHARGER TURBINE HOUSING	ME70-3, ME72-4
335 US US US US US US US	80-13-14 80-19-10 81-07-11R1 82-26-05 87-21-02R1 96-12-22 97-01-13 98-04-28		FUEL FLOW TRANSDUCER DEICER SYSTEMS IN ADVERSE WEATHER BALANCE WEIGHT SUPPORT STRUCTURE RUDDER BALANCE WEIGHT RIB FUEL FILLER OPENINGS ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM OPERATING IN SEVERE ICING CONDITIONS	SIL ME84-31 ATTACHED SKETCH 96-15,96-21,96-3 AWD
336 CF US US US US US	CF-87-15R2 70-15-02 71-24-04 72-23-03 78-09-05 78-16-04 79-10-14R1		SEAT LOCKING MECHANISM FUEL QUANTITY INDICATORS FLEXIBLE HOSE IN ENGINE COMPARTMENT WING FLAP ACTUATOR WING SPAR CAPS AND WEB DOUBLERS WEIGHT AND BALANCE DATA FUEL TANK VENTING	SIL SE 83-6
US US US	86-26-04 96-12-22 97-01-13		PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	MEB86-22 ATTACHED SKETCH 96-15,96-21,96-3
CF US US US US US US	RIES CF-87-15R2 75-09-05 77-08-05 78-09-05 79-10-14R1 96-12-22 97-01-13		SEAT LOCKING MECHANISM PITOT SYSTEM SINGLE ENGINE TAKEOFFS WING SPAR CAPS AND WEB DOUBLERS FUEL TANK VENTING ENGINE OIL FILTER ADAPTERS ASSEMBLIES COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	SIL SE 83-6  ATTACHED SKETCH 96-15,96-21,96-3
337 US US US US US	70-15-02 71-17-08 71-24-04 72-23-03 86-26-04	( 337	SERIES ) FUEL QUANTITY INDICATORS REAR ENGINE STOPPAGE ON TAKE OFF FLEXIBLE HOSE IN ENGINE COMPARTMENT WING FLAPS PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
US US US US	70-15-02 71-24-04 86-26-04	( 337	FUEL QUANTITY INDICATORS FLEXIBLE HOSE IN ENGINE COMPARTMENT PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
<b>337</b> B US US US	70-15-02 71-24-04 86-26-04	( 337	SERIES ) FUEL QUANTITY INDICATORS FLEXIBLE HOSE IN ENGINE COMPARTMENT PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
337C US US US	70-15-02 71-24-04 86-26-04	( 337	SERIES ) FUEL QUANTITY INDICATORS FLEXIBLE HOSE IN ENGINE COMPARTMENT PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
<b>337</b> D US	70-15-02	( 337	SERIES ) FUEL QUANTITY INDICATORS	
	ANUADY / JANUTED	0000		AIRCRAFT/AERONEFS

MAKE / CONSTRUCTEUR

MAKE / CON MODEL / M ORIGIN ORIGINE	STRUCTEUR  ODELE  AD NUMBER  NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJECT	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
OHIOINE	NOMENO DE CONSTONE	30001	BOLLETIN DE SERVICE DE REF.
CESSNA 337D		( 337 SERIES )	
(CONTIN	UED / SUITE)		
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
<b>337</b> E US	76-04-03	( 337 SERIES ) ARC PA-500A ACTUATORS	
ÜS	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
337F		( 337 SERIES )	
US	76-04-03	ARC PA-500A ACTUATORS	
<b>337G</b> US	76-04-03	( 337 SERIES ) ARC PA-500A ACTUATORS	
US	77-12-08	EXTERNAL ELEC GROUND POWER RECEP	
337H		( 337 SERIES )	
M337B			
CF US	CF-87-15R2 70-15-02	SEAT LOCKING MECHANISM FUEL QUANTITY INDICATORS	SIL SE 83-6
US	71-17-08	REAR ENGINE STOPPAGE ON TAKEOFF	
US US	71-24-04 72-23-03	FLEXIBLE HOSE IN ENGINE COMPARTMENT WING FLAPS	
US US	75-09-05 76-04-03	PITOT SYSTEM ARC PA-500A ACTUATORS	
US US	77-08-05	SINGLE ENGINE TAKEOFFS	
US	78-09-05 79-10-14R1	WING SPAR CAPS AND WEB DOUBLERS FUEL TANK VENTING	
US US	86-26-04 96-12-22	PILOT/COPILOT SHOULDER HARNESS ENGINE OIL FILTER ADAPTER ASSEMBLIES	MEB86-22
US	97-01-13	COLAPSED HOSE, DIL, FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
Р337Н	50 00 05		
US US	78-09-05 96-12-22	WING SPAR CAPS AND WEB DOUBLERS ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
T337 S	ERIES CF-70-03	DOUTD DI ANT MOUNT TUDOTNE DOLOS	
CF	CF-87-15R2	POWER PLANT MOUNT - TURBINE BRACE SEAT LOCKING MECHANISM	CSL ME 68-24 SIL SE 83-6
US US	77-08-05 78-09-05	SINGLE ENGINE TAKEOFFS WING SPAR CAPS AND WEB DOUBLERS	
US US	79~10~14R1 96~12~22	FUEL TANK VENTING ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
Т337В		( T337 SERIES )	
US US	70-15-02 71-24-04	FUEL QUANTITY INDICATORS FLEXIBLE HOSE IN ENGINE COMPARTMENT	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
T337C US	70 4F 00	( T337 SERIES )	
US	70-15-02 71-24-04	FUEL QUANTITY INDICATORS FLEXIBLE HOSE IN ENGINE COMPARTMENT	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
T337D US	70-15-02	( T337 SERIES ) FUEL QUANTITY INDICATORS	
T337E			
US	76-04-03	( T337 SERIES )  ARC PA-500A ACTUATORS	
US	86-26-04	PILOT/CO-PILOT SHOULDER HARNESS ADJUSTER	MEB86-22
T337G US	76-04-03	( T337 SERIES )  ARC PA-500A ACTUATORS	
US	77-12-08	EXTERNAL ELEC GROUND POWER RECEP	
Т337Н		( T337 SERIES )	
US	78-09-05	WING SPAR CAPS AND WEB DOUBLERS	
340 SE US	RIES 72-03-07	LANDING GEAR FAILURE	
US	75-23-08R5	ENGINE EXHAUST SYSTEM	
03	87-21-02R1	FUEL FILLER OPENINGS	SIL ME84-31

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

				BULLETIN DE SERVICE DE REF
CESSNA				
	SERIES (NUED / SUITE)			
US	88-03-07		FUEL LINES - FIREWALL	MED 07 704
US	90-02-13		MLG STRUT BARREL LOCK RINGS & BEARINGS	MEB 87-7R1
US	96-12-22 97-01-13		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
			COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15, 96-21, 96-3
340 US	73-22-01	( 340	SERIES )	
US	74-20-01		FUEL IN WING LEADING EDGE MAIN LANDING GEAR TRUNNION	
US	76-04-03		ARC PA-500A ACTUATORS	
US US	76-08-02R2 78-13-05		WING TIP NOSE CAP IMPROPERLY INSTALLED SEATS	
US	78-14-01		OPTIONAL STORAGE/REFRESHMENT	
US US	81-07-11R1 82-26-05		BALANCE WEIGHT SUPPORT STRUCTURE RUDDER BALANCE WEIGHT RIB	
	02 20 00		RODDER BALANCE WEIGHT RIB	
340A US	77-06-05	( 340	SERIES )	
US	78-11-05		FIRE HAZARD IN OXYGEN SYSTEM AUTOPILOT ACTUATOR	
US	78-13-05		IMPROPERLY INSTALLED SEATS	
US US	78-14-01 80-13-14		OPTIONAL STORAGE/REFRESHMENT FUEL FLOW TRANSDUCER	
US	80-19-10		DEICER SYSTEMS IN ADVERSE WEATHER	
US US	81-07-11R1 82-26-05		BALANCE WEIGHT SUPPORT STRUCTURE RUDDER BALANCE WEIGHT RIB	
US	98-04-28		OPERATING IN SEVERE ICING CONDITIONS	AWD
US	98-24-14		ENGINE EXHAUST WYE TUBE	
401 S	ERIES			
US	72-03-07		LANDING GEAR FAILURE	
US US	72-12-04 72-14-08R1		SUPPORT OF FUEL LINES FLEXIBLE FUEL HOSE ASSEMBLIES	
US	75-23-08R5		ENGINE EXHAUST SYSTEM	
US US	76-08-02R2 76-13-07		WING TIP NOSE CAP FORK BOLTS	
US	76-16-07		ENGINE ATTACHMENT TANGS	
US	87-21-02R1		FUEL FILLER OPENINGS MLG STRUT BARREL LOCK RINGS & BEARINGS	SIL ME84-31
US US	90-02-13 96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
401		( 401	SERIES )	
US	69-14-01		FUEL STARVATION	84570 2 84570 4
US US	70-03-04R1 71-07-04		TURBO SUPERCHARGER TURBINE HOUSING EMERGENCY EXIT WINDOW	ME70-3, ME72-4
US	73-22-01		FUEL IN WING LEADING EDGE	
US	79-10-15		CRACKS IN WING STRUCTURE	
401A		( 401	SERIES )	
US	69-14-01		FUEL STARVATION TURBO SUPERCHARGER TURBINE HOUSING	ME70-3, ME72-4
US US	70-03-04R1 71-07-04		EMERGENCY EXIT WINDOW	, , , , , ,
US	73-22-01		FUEL IN WING LEADING EDGE CRACKS IN WING STRUCTURE	
US	79-10-15			
401B	TO 00 5151	( 401	SERIES ) TURBO SUPERCHARGER TURBINE HOUSING	ME70-3, ME72-4
US US	70-03-04R1 71-07-04		EMERGENCY EXIT WINDOW	
US	73-22-01		FUEL IN WING LEADING EDGE	
US	76-04-03 79-10-15		ARC PA-500A ACTUATORS CRACKS IN WING STRUCTURE	
US	79-10-15			
402 SI			LANDING GEAR FAILURE	
US US	72-03-07 72-12-04		SUPPORT OF FUEL LINES	
US	72-14-08R1		FLEXIBLE FUEL HOSE ASSEMBLIES FORK BOLTS	
US US	76-13-07 76-16-07		ENGINE ATTACHMENT TANGS	
US	87-21-02R1		FUEL FILLER OPENINGS MLG STRUT BARREL LOCK RINGS & BEARINGS	SIL ME84-31
US US	90-02-13 96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3

MAKE / CON: MODEL / M	STRUCTEUR ODELE	(SERIES / SERIE)	
ORIGIN	AD NUMBER	SUBJECT	REFERENCE SERVICE BULLETIN
ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
CESSNA		( 400 CERTEC )	
402	00 44 04	( 402 SERIES )	
US	69-14-01	FUEL STARVATION	14550
US	70-03-04R1	TURBO SUPERCHARGER TURBINE HOUSING	ME70-3, ME72-4
US	71-07-04	EMERGENCY EXIT WINDOW	
US	73-22-01	FUEL IN WING LEADING EDGE	
US	75-23-08R5	ENGINE EXHAUST SYSTEM	
US	76-08-02R2	WING TIP NOSE CAP	
US	79-10-15	CRACKS IN WING STRUCTURE	
402B		( 402 SERIES )	
US	70-03-04R1	TURBO SUPERCHARGER TURBINE HOUSING	ME70-3, ME72-4
US	71-07-04	EMERGENCY EXIT WINDOW	, , , , , , , , , , , , , , , , , , , ,
US	73-22-01	FUEL IN WING LEADING EDGE	
US	74-20-01	MAIN LANDING GEAR TRUNNION	
US	75-23-08R5	ENGINE EXHAUST SYSTEM	
US	76-04-03	ARC PA-500A ACTUATORS	
US	76-08-02R2	WING TIP NOSE CAP	
US	78-11-05	AUTOPILOT ACTUATOR	
US	78-13-05	IMPROPERLY INSTALLED SEATS	
US	79-10-15	CRACKS IN WING STRUCTURE	
US	92-16-18	ENVIROFORM SEAT STRUCTRUAL ASSEMBLY	
US	98-04-28	OPERATING IN SEVERE ICING CONDITIONS	AWD
402C		( 402 SERIES )	
US	80-13-14	FUEL FLOW TRANSDUCER	
US	84-20-02	NOSE LANDING GEAR	
US	85-13-03R2	ENGINE MOUNT BEAMS	•••• •••••••••••• •••• ••••
US	92-16-18	ENVIROFORM SEAT STRUCTURAL ASSEMBLY	
US	95-09-13	FUEL INLET FLOAT VALVE	MED02-1001
US	97-26-16		MEB93-10R1
US	98-04-28	ENGINE MOUNT BEAMS (SUPERSEDES 85-13-03R2)	AND
US		OPERATING IN SEVERE ICING CONDITIONS	AWD
US	99-11-13	TO DETECT CRACKS IN FWD, AFT AND AUX WING SPARS.	CSB MEB99-3
40.4			
404		AUTODILOT ACTUATOR	
US	78-11-05	AUTOPILOT ACTUATOR	
US	78-13-05	IMPROPERLY INSTALLED SEATS	
US	80~13-14	FUEL FLOW TRANSDUCER	
US	80-15-06	ELEVATOR TRIM TAB ASSY	
US	84-20-02	NOSE LANDING GEAR	
US	86-20-12	ENGINE MOUNT BEAMS	MEB 86-7
US	87-21-02R1	FUEL FILLER OPENINGS	SIL ME84-31
US	92-16-18	ENVIROFORM SEAT STRUCTURAL ASSEMBLY	
US	95-09-13	FUEL INLET FLOAT VALVE	MEB93-10R1
US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
US	98-04-28	OPERATING IN SEVERE ICING CONDITIONS	AWD
		OF EXAMINATIVE SEVERE TOTAL CONDITIONS	AWD
411 SE	DIEC		
US	72-11-05	ALIYTI TADV ELIEL CELL LEAVE	
US		AUXILIARY FUEL CELL LEAKS	
	72-14-08R1	FLEXIBLE FUEL HOSE ASSEMBLIES	
US	75-23-08R5	ENGINE EXHAUST SYSTEM	
US	76-08-02R2	WING TIP NOSE CAP	
US	76-13-07	FORK BOLTS	
US	87-21-02R1	FUEL FILLER OPENINGS	SIL ME84-31
US	90-02-13	MLG STRUT BARREL LOCK RINGS & BEARINGS	
US	91-02-07	TAKEOFF PERFORMANCE INFO	
US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	
411		( 411 SERIES )	
US	69-14-01	FUEL STARVATION	
US	71-07-04	EMERGENCY EXIT WINDOW	
US	72-02-01	PROPELLER ATTACHMENT NUTS	
US	73-22-01	FUEL IN WING LEADING EDGE	
US	79-10-15		
us	75 10 15	CRACKS IN WING STRUCTURE	
414 SE	DIEC		
		LANDING OF AD FAILURG	
US	72-03-07	LANDING GEAR FAILURE	
US	76-13-07	FORK BOLTS	
US	87-21-02R1	FUEL FILLER OPENINGS	SIL ME84-31
US	90-02-13	MLG STRUT BARREL LOCK RINGS & BEARINGS	
US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13	COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3

MAKE / CONSTRUCTEUR

CESSNA 414 US	73-22-01 74-20-01 75-23-08R5	( 4	SUJET	BULLETIN DE SERVICE DE REF.
414 US US US US US US US US US	74-20-01	( 4		
US US US US US US US US	74-20-01	( 4		
US US US US US US	74-20-01		4 SERIES )	
US US US US US			FUEL IN WING LEADING EDGE	
US US US US US	70 20 00110		MAIN LANDING GEAR TRUNNION ENGINE EXHAUST SYSTEM	
US US US	76-04-03		ARC PA-500A ACTUATORS	
US US	76-08-02R2		WING TIP NOSE CAP	
US	76-16-07		ENGINE ATTACHMENT TANGS	
	78-11-05		AUTOPILOT ACTUATOR	
US	78-13-05		IMPROPERLY INSTALLED SEATS	
116	88-03-07 98-04-28		FUEL LINES - FIREWALL	MEB 87-7R1
US	98-04-28		OPERATING IN SEVERE ICING CONDITIONS	AWD
414A		( 4	4 SERIES )	
US	78-11-05		AUTOPILOT ACTUATOR	
	78-13-05		IMPROPERLY INSTALLED SEATS	
	80-13-14		FUEL FLOW TRANSDUCER	
	84-03-04		WINDSHIELD INSTLN INSP	
	84-20-02		NOSE LANDING GEAR	
	85-13-03R2 95-09-13		ENGINE MOUNT BEAMS FUEL INLET FLOAT VALVE	MERCO 1001
	97-26-16		ENGINE MOUNT BEAMS (SUPERSEDES 85-13-03R2)	MEB93-10R1
	98-04-28		OPERATING IN SEVERE ICING CONDITIONS	AWD
	98-24-14		ENGINE EXHAUST WYE TUBE	
421 SEF			LANDING CEAD CATHLING	
	72-03-07 72-11-05		LANDING GEAR FAILURE	
	72-14-08R1		AUXILIARY FUEL CELL LEAKS FLEXIBLE FUEL HOSE ASSEMBLIES	
	75-23-08R5		ENGINE EXHAUST SYSTEM	
	76-13-07		FORK BOLTS	
US	87-21-02R1		FUEL FILLER OPENINGS	SIL ME84-31
	90-02-13		MLG STRUT BARREL LOCK RINGS & BEARINGS	
	96-12-22		ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US	97-01-13		COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM	96-15,96-21,96-3
421		( 4:	1 SERIES )	
	69-14-01		FUEL STARVATION	
US	72-02-01		PROPELLER ATTACHMENT NUTS	
	73-22-01		FUEL IN WING LEADING EDGE	
	76-08-02R2		WING TIP NOSE CAP	
US	78-13-05		IMPROPERLY INSTALLED SEATS	
421A	•••••	( 42	1 SERIES )	
	69-14-01	,	FUEL STARVATION	
US	72-02-01		PROPELLER ATTACHMENT NUTS	
	73-22-01		FUEL IN WING LEADING EDGE	
	76-08-02R2		WING TIP NOSE CAP	
US	78-13-05		IMPROPERLY INSTALLED SEATS	
421B		( 42	1 SERIES )	
	72-02-01		PROPELLER ATTACHMENT NUTS	
	72-03-04		CRANKCASE VENT LINE ICE	
US	73-13-08		TURBOCHARGERS	
	73-22-01		FUEL IN WING LEADING EDGE	
	74-20-01		MAIN LANDING GEAR TRUNNION	
	76-04-03		ARC PA-500A ACTUATURS	
	76~08~02R2		WING TIP NOSE CAP WINDSHIELD INSPECTION AND REPAIR	
	77-09-02 78-13-05		IMPROPERLY INSTALLED SEATS	
	98-04-28		OPERATING IN SEVERE ICING CONDITIONS	AWD
421C		( 42	1 SERIES )	
	76-07-07		FUEL LEAKAGE WINDSHIELD INSPECTION AND REPAIR	
	77-09-02 78-11-05		AUTOPILOT ACTUATOR	
	78-11-05 78-13-05		IMPROPERLY INSTALLED SEATS	
	80-13-14		FUEL FLOW TRANSDUCER	
	80-20-06		KFC-200 FCS MOD UNDER STC SA1246CE	
	84-03-04		WINDSHIELD INSTLN INSP	
	84-20-02		NOSE LANDING GEAR	00001 001
	91-25-08R1		WING SPAR UPPER CAP	CQB91-8R1
	92~16-18		ENVIROFORM SEAT STRUCTURAL ASSEMBLY	MEB93-10R1
US !	95-09-13 98-04-28		FUEL INLET FLOAT VALVE OPERATING IN SEVERE ICING CONDITIONS	AWD

MODEL / MODELE ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN CESSNA 425 84-03-04 WINDSHIELD INSTLM INSP 84-20-02 NOSE LANDING GEAR NUTS - CESSNA P/N NAS1291-8 US 85-25-11 115 91-25-08R1 WING SPAR UPPER CAP CQB91-8R1 96-12-22 ENGINE OIL FILTER ADAPTERS ASSEMBLIES
COLLAPSED HOSE, OIL , FUEL OR HYDRAULIC SYSTEM ATTACHED SKETCH 97-01-13 96-15,96-21,96-3 97-25-04 POWER LEVER POSITIONING BELOW FLIGHT IDLE 98-04-28 OPERATING IN SEVERE ICING CONDITIONS AWD 441 CF-80-04 ACTUATOR JACK SCREWS STI PJ 79-15 US 79-08-07 ANTI-ICING PROPELLER WIRING 79-09-02 AILERON CONTROL SURFACES DRAINAGE 79-19-12 ENGINE STOPPAGE ELEVATOR TRIM TAB 79-19-13 115 80-02-17 FLIGHT MANUAL PERFORMANCE DATA BATTERY SWITCH WIRING 83-12-03 84-20-02 NOSE LANDING GEAR 115 85-25-11 NUTS - CESSNA P/N NAS1291-8 FLIGHT MANUAL - LIMITATIONS / ICING ENVIRONMENT 86-24-13 HORIZONTAL STAB FRONT SPAR ENVIROFORM SEAT STRUCTURAL ASSEMBLY 92-16-07 CQB91-1R1 92-16-18 95-25-10 OUTFLOW SAFETY VALVES 103576-21-4054 ENGINE OIL FILTER ADAPTERS ASSEMBLIES 96-12-22 US ATTACHED SKETCH 97-25-04 POWER LEVER POSITIONING BELOW FLIGHT IDLE 98-04-28 OPERATING IN SEVERE ICING CONDITIONS AWD 500 73-26-09 CRACKS IN FLT COMPT SIDE WINDOWS
UPPER & LOWER SPAR CAP STEMS 79-12-06 80-09-09 DUAL FLIGHT DIRECTOR INSTALLATION THRUST REVERSER THROTTLE LOAD LIMITER US 93-05-15 500-78-11 95-25-10 OUTFLOW SAFETY VALVES
AFM REVISION - ICING CONDITIONS US 103576-21-4056 98-04-38 501 US 79-12-06 UPPER & LOWER SPAR CAP STEMS 80-09-09 DUAL FLIGHT DIRECTOR INSTALLATION THRUST REVERSER THROTTLE LOAD LIMITER US 93-05-15 500-78-11 US 98-04-38 AFM REVISION - ICING CONDITIONS 525 115 97-01-02 MLG TRUNNION BEARING FAILURE SLA 525-32-11 550 79-12-06 US UPPER AND LOWER SPAR CAP STEMS US 80-09-09 DUAL FLIGHT DIRECTOR INSTALLATION US 88-06-02 OVERHEAD FLOURESCENT LIGHTING SYSTEM SLA550-33-02 FITTINGS - FUEL FLOW TRANSMITTER
RUDDER/ELEVATOR CONTROL CABLES - STC SA2698SW US 89-16-10 550-73-1R1, 2 US 90-07-10R1 US 93-05-15 THRUST REVERSER THROTTLE LOAD LIMITER 550-78-03 95-25-10 US OUTFLOW SAFETY VALVES 103576-21-4056 US 98-04-38 AFM REVISION - ICING CONDITIONS \$550 AFM REV PLACARD - ICING PLACARD - ICING CONDITIONS US 85-24-04 US 85-25-10 OVERHEAD FLOURESCENT LIGHTING SYSTEM 88-06-02 SLA550-33-01 FLAP PANELS - DRAIN/VENT HOLES UŞ 88-11-07 SLAS550-57-01 US 88-13-03R1 MAIN LANDING GEAR TORQUE LINK \$550-32-5 US 88-24-16 ELECTRICAL WIRING SBAS550-25-02R4 90-07-10R1 RUDDER/ELEVATOR CONTROL CABLES - STC SA2698SW US 93-05-15 THRUST REVERSER THROTTLE LOAD LIMITER \$550-78-04 560 US 95-25-10 OUTFLOW SAFETY VALVES 103648-21-4055 US 96-24-06 REVISE LIMITATIONS OF AFM A560-30-07 US 98-04-38 AFM REVISION - ICING CONDITIONS 560XL 650 US 84-08-02R1 PLACARD - USABLE FUEL

MAKE / CONSTRUCTEUR

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

			BOLLETIN DE SERVICE DE REF.
CESSNA 650 (CONTINUED / SUITE) US 85-03-51 US 88-23-04 US 88-24-16 US 89-03-16 US 90-25-06 US 92-27-08 US 93-05-15 US 97-12-01		C BALANCE ING ELAYS TAL AFCS	SLA650-27-20 SBA650-25-12 SLA650-24-14 A650-34-68 ASL A650-27-30 650-78-05R1 SB650-24-57
<b>750</b> US 98-16-17	HORIZONTAL STAE	BILIZER TRIM ACTUATOR	ASB750-27-22
CHAMPION 7 SERIES		SEE/VOIR: BELLANCA	
7AC	( 7 SERIES )	SEE/VOIR: BELLANCA	
7BCM	( 7 SERIES )	SEE/VOIR: BELLANCA	
7CCM	( 7 SERIES )	SEE/VOIR: BELLANCA	
7EC	( 7 SERIES )	SEE/VOIR: BELLANCA	
S7EC	( 7 SERIES )	SEE/VOIR: BELLANCA	
7ECA	( 7 SERIES )	SEE/VOIR: BELLANCA	
7FC	( 7 SERIES )	SEE/VOIR: BELLANCA	
7GC SERIES		SEE/VOIR: BELLANCA	
7GC	( 7GC SERIES )	SEE/VOIR: BELLANCA	,
7GCA	( 7GC SERIES )	SEE/VOIR: BELLANCA	
7GCAA	( 7GC SERIES )	SEE/VOIR: BELLANCA	
7GCB	( 7GC SERIES )	SEE/VOIR: BELLANCA	
7GCBC	( 7GC SERIES )	SEE/VOIR: BELLANCA	
7KC SERIES		SEE/VOIR: BELLANCA	
7KC	( 7KC SERIES )	SEE/VOIR: BELLANCA	
7KCAB	( 7KC SERIES )	SEE/VOIR: BELLANCA	
402	EVILANCE CVCTEMO		
US 64-17-04	EXHAUST SYSTEMS		
CHRISTEN A 1 HUSKY	FORWARD SEAT BA	01/	
US 90-20-05 US 91-23-02	CARB INTAKE		2
COLONIAL			
C 1 US 57-06-01 US 57-13-01 US 59-12-05 US 59-15-02 US 59-17-04 US 67-11-01 US 72-07-11 US 74-25-08 US 74-26-02 US 79-21-09R1		TTINGS SURFACE LOCKS RIVETS HING BOLTS AGE INSTRUMENT LINE D BEARINGS FITTINGS	
C 2 US 59-12-05 US 59-15-02 US 59-17-04	PLASTIC CONTROL THROTTLE HANDLE WING SPAR ATTAC	RIVETS	AIRCRAFT/AERONEFS
20 JANUARY/JANVI	ER 2000		AZRORAL I / ALRUNEL 3

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

( SERIES / SERIE)
SUBJECT
SUJET

OHIGINE	NUMERO DE CONSIGNE	SUJET	BOLLETIN DE SERVICE DE REF.
COLONIA	IL.		
C 2	/		
US	UED / SUITE) 60-22-01	ENGINE MOUNT	
US	67-11-01	FUEL PRESSURE GAGE INSTRUMENT LINE	
US	72-07-11	FLAP PUSHROD END BEARINGS	
US	74-25-08	WING REAR SPAR FITTINGS	
US	74-26-02	RUDDER CONTROL	
US US	79-21-09R1 98-10-12	ELECTRICAL SYSTEM HORIZONTAL AND VERT STABILIZER ATTACHMENT FITTING	8-78
US	98-10-12	MURIZUNTAL AND VERT STABILIZER ATTACHMENT FITTING	D-76
COLT			
	LYING HAT	THE PARTY OF THE P	0 700115 4 8514 0
	001-07-96	THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES	2 ISSUE 1 REV C
UK	002-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
OIX	000 11 30	BONNEN THANK ONOSS SAN WEEDS	
	PEN BOOK		
UK	013-02-92	INTRO OF TWO RIP STOPPERS	SB 4
UK	001-07-96 002-11-98	THUNDER AND COLT TURNING VENTS PRESSURE RELIEF VALVES	2 ISSUE 1 REV C
	002-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
OIX	000 11 30	BONNEN THANK GROSS BAN WEEDS	, 10000
56A			0. 700115
UK	001-07-96	THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
UK UK	002-11-98 003-11-98	PRESSURE RELIEF VALVES BURNER FRAME CROSS BAR WELDS	4 7 ISSUE "B"
		DOMACK I KAMIL GROSS DAN WEEDS	, 13302 0
77A			
UK	001-07-96	THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
UK	002-11-98	PRESSURE RELIEF VALVES	4 7 ISSUE "B"
UK	003-11-98	BURNER FRAME CROSS BAR WELDS	\ 1220F "B"
77B BU	LLIT		
	001-07-96	THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
UK	002-11-98	PRESSURE RELIEF VALVES	4
UK	003-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
105 A			
UK	001-07-96	THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
UK	002-11-98	PRESSURE RELIEF VALVES	4
UK	003-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
160 A			
	001-07-96	THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
UK	002-11-98	PRESSURE RELIEF VALVES	4
UK	003-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
240 A			
UK	001-07-96	THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
UK	002-11-98	PRESSURE RELIEF VALVES	
UK	003-11-98	BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
CONAIR			
FIRECA	Т		
	CF-88-20R1	RUDDER TRIM CRANK ASSEMBLY	447-002-R4
CF	CF-90-14	STALL WARNING SYSTEM	
CF	CF-90-15	AIRSPEED AND ALTIMETER	
CF	CF-94-20	SUPPLEMENTAL STRUCTURAL INSPECTION PROGRAM	SSID-1314R2
TURBO	FIRECAT		
CF	CF-90-15	ERRONEOUS AIRSPEED AND ALTIMETER READINGS	
004601	0.47.50		
CONSOLI. PBY5A	DATED		
CF	CF-56-02	FIRE PROTECTION	
CF	CF-61-01	FIRE PROTECTION	
CF	CF-67-02	WATER DROPPING DOORS	AT-67-1
	05 00 00	TRIPOD ASSEMBLY TURNBUCKLES	AT-68-2,68-3
CF	CF-68-03		
	CF-68-11	WATER DOOR LATCHING JACK	AT-68-1
CF		WATER DOOR LATCHING JACK	AT-68-1
CF CF		WATER DOOR LATCHING JACK FIRE PROTECTION	AT-68-1
CF CF 285ACF	CF-68-11		AT-68-1 AT-67-1 AT-68-2,68-3

MAKE / CONSTRUCTEUR

(SERIES / SERIE)

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

SUBJECT SUJET

166	JΝ	5	U	L	1	$\nu$	A	1	EU	
2	28	5	Α	C	F					

(CONTINUED / SUITE)

WATER DOOR LATCHING JACK

AT-68-1

#### CONSOLIDATED VULTEE

240 SERIES

240

( 240 SERIES )

SEE/VOIR: CONVAIR SEE/VOIR: CONVAIR

		SELY VOIN. CONVAIN	
CONVA			
	SERIES		
US	48-41-01	WING BULKHEAD - FUEL TANK AREA	
US	48-50-04	NOSE GEAR REWORK	
US	48-51-02	HORIZONTAL TAIL SURFACE INSPECTION	
US	49-30-01	PROPELLER HUB CRACKS	
US	49-30-02	AUGMENTER VANE REWORK	
US	49-34-01	COCKPIT CHECKLIST	
US	49-38-01	NOSE GEAR STRUT INSPECTION	
US	49-43-01	AUGMENTER TUBE INSPECTION	
US	49-44-02	HORIZONTAL STABILIZER REWORK	
US	50-13-01	AILERON HINGE BRACKET	
US	50-19-02	RUDDER TAB BRACKET	
US	50-36-01	NOSE STRUT CYLINDER	
US	51-28-01	FIRE PROTECTION MODIFICATION	
US	52-11-02	ENGINE NACELLE STEEL FACING	
US	52-14-02	PROPELLER REVERSING REWORK	240-381 ITEM IV
US	53-23-01	NOSE LANDING GEAR CLUTCH PLATE	2.50 .007
US	55-15-02	FIRE RESISTANT PROP FEATHERING LINES	
US	55-18-01	PROPELLER REVERSE PROTECTIVE DEVICE	240-460A
US	56-04-02		240-467, -468
US	56-18-01	ELECTRIC POWER SYSTEM REWORK	240 467, 466
US	56-20-04		240-470472
US			
	56-24-01	PROPELLER FEATHERING LINE REROUTING	240-479
US	56-24-02		P&W 1602, 1604
US	57-03-01	LANDING GEAR FITTING INSPECTION	
US	57-14-01	LANDING GEAR PIVOT SHAFT SLEEVE	
US	58-06-01	LANDING GEAR AXLE	
US	58-25-01	ELEVATOR TORQUE TUBE RIVETS	
US	59-01-01	FIRE DETECTOR SYSTEM REWORK	
US	59-02-01	FIRE PROTECTION MODIFICATIONS	240-466
US	59-04-02	DV WINDOW STOP	
US	64-18-04	NOSE LANDING GEAR RETRACT FORKS	
US	64-19-04	CABIN PRESSURIZATION / FIRE PROTECTION SYSTEM	
US	67-07-05	PROPELLER GUST LOCK	640(340D)A61-4
US	67-33-03	PRESSURE FUELING VALVES	
US	68-16-04	EXHAUST DUCTS	
US	70-10-03	ENGINE BREATHER OIL FUMES	71-2B
US	74-03-04	PILOT & CO-PILOT WINDOW FRAME CASTINGS	
US	77-10-11	CORROSION OF LANDING GEAR LUG	32-2
US	79-21-06	THE PARTY OF THE P	
US	80-08-03	AIRCRAFT WINDOWS	53-4B
US	81-18-05	WING STRUCTURE INSPECTION	
US	83-01-01	NLG AXLE FRACTURE	
US	83-23-04	DOOR WARNING SWITCH	
US	83-23-05	MAIN ENTRANCE DOOR & STAIRS - MECHANISM INSTALLATN	53-6
US	91-12-04	ELEVATOR HINGE PINS	
US		CORROSION & PREVENTION CONTROL	ZS-340-2000
	92-25-13	ELEVATOR & RUDDER HINGE PINS & BUSHINGS INSP	
US	93-21-02	ELEVATOR & RODDER HIMSE THOSE STORES	1
240		( 240 SERIES )	
	00 00 04	FLAP LIMITATIONS IN ICING CONDITIONS	AFM
US	96-03-04		BI III
US	98-08-17	POWER LEVERS	
0.40			
340	E0 14 05	PROPELLER REVERSING REWORK	240-381 ITEM IV
US	52-14-02		240 301 11111111
US	55-03-01	ELEVATOR SERVO TAB INSPECTION	
US	55-15-02	FIRE RESISTANT PROP FEATHERING LINES	340-141A
US	55-18-01	PROPELLER REVERSE PROTECTIVE DEVICE	
US	56-04-02	NACELLE FIRE PROTECTION	340-166, -167
US	56-18-02	HOT WEATHER OIL FLOW	P&W 1513, 1524
US	56-20-04	FIRE PROTECTION REWORK	340-177, -209, -210A
US	56-24-01	PROPELLER FEATHERING LINE REROUTING	340-205
US	56-24-02	FUEL MIXTURE CONTROL	P&W 1602, 1604

56-27-01

US

ELEVATOR TAB RODS

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUJJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
CONVAII	₹		*
340			
	UED / SUITE)		***************************************
US	57-12-05	ELEVATOR SPAR CRACKS	
US US	57-14-01 58-01-03	LANDING GEAR PIVOT SHAFT SLEEVE	040 4444
110	FO 01 01	FUEL MIXTURE CONTROL FIRE DETECTOR SYSTEM REWORK	340-1444
US	59-02-01	FIRE PROTECTION MODIFICATIONS	340-170
US	59-04-02	DV WINDOW STOP	340-170
US	60-14-01	LANDING GEAR ACTUATING CYLINDER ROD	
	63-06-03	ELECTRICAL FAULT DETECTION PANELS	BENDIX SB R-47
US	63-10-03	WING LOWER SKIN CRACKS	
US	63-11-02	MAIN LANDING GEAR	
US	63-15-04	NOSE LANDING GEAR ROD END EYE-BOLTS	
US	64-18-04	NOSE LANDING GEAR RETRACT FORKS	
US	65-12-01	MAIN LANDING GEAR GLAND NUT	
US	67-02-03	REAR SERVICE DOOR	340-174A, -213, -232
US	67-07-05	PROPELLER GUST LOCK	640(340D)A61-4
US	67-33-03	PRESSURE FUELING VALVES	
US	68-07-01	DIRECT VISION WINDOW FRAME CASTING	
US	68-10-04	FRONT SPAR LOWER RAIL	
US	68-16-04	EXHAUST DUCTS .	
US	70-10-03	ENGINE BREATHER OIL FUMES	71-2B
US	70-12-01	MLG BEAM WEB INSPECTION	57-3
US US	70-12-05	MLG TRUNION FITTING INSPECTION	57-4
US	70-12-07 70-13-02	MLG PISTON AXLE INSPECTION	32-3
US	71-02-03	WINDSHIELD LONGERON CRACKS MAIN LANDING GEAR FAILURE	53-3
US	71-21-04	MLG PISTON BEARING LOCK PINS	20 5
US	73-07-01	WING FRONT SPAR LOWER CAP CRACKS	32-5
US	73-18-01	NOSE LANDING GEAR FATIGUE CRACKS	32-7
ÜS	73-19-11	NOSE LANDING GEAR DRAG STRUT	32-8
US	74-16-01	STRINGER INSPECTION	32 8
US	77-10-11	CORROSION OF LANDING GEAR LUG	32-2
US	78-17-04	EMERGENCY WINDOW RELEASE HANDLE	ASB 25-A10
US	78-22-04	EMERGENCY EXIT WINDOW	
US	80-08-03	AIRCRAFT WINDOWS	53-5B
US	81-22-02	ELEVATOR OUTER TORQUE TUBE	27-6
US	82-19-02	HORIZONTAL STABILIZER ATTACH	55-3A, -4R1
US	83-01-02	NLG AXLE FRACTURE	32-13
US	87-17-10	MLG DRAG STRUT PIVOT BOLT	32-14
US	90-13-13	VISUAL INSPECTION OF FUSELAGE FRAMES	53-15 R1
US	91-12-05	VISUAL INSPECTION OF FUSELAGE FRAMES ELEVATOR HINGE PIN PRINCIPAL STRUCTURAL ELEMENTS	55-5, -A5
US	92-06-06	PRINCIPAL STRUCTURAL ELEMENTS	SID ZS-340-1000R1
US US	.92-25-13 93-04-03	CORROSION & PREVENTION CONTROL	ZS-340-2000
US	93-04-03	HORZ & VERT STAB ATTACH FITTINGS - INSPECT ELEV & RUDDER HINGE PINS - INSP UNAPROVED PARTS	55-6
US	96-03-04	FLAP LIMITATIONS IN ICING CONDITIONS	
US	98-08-17	POWER LEVERS	AFM
00	30 00 17	FOWER CLVERS	
440			
US	56-20-04	FIRE PROTECTION REWORK	440-30, -32A
US	56-24-01	PROPELLER FEATHERING LINE REPOUTING	440-23
US	56-24-02	FUEL MIXTURE CONTROL	P&W 1602, 1604
US	56-27-01	ELEVATOR TAB RODS	440-27A
US	58-01-03	FUEL MIXTURE CONTROL	440-58
US	59-01-01	FIRE DETECTOR SYSTEM REWORK	
US	59-04-02	DV WINDOW STOP	
US	60-14-01	DV WINDOW STOP LANDING GEAR ACTUATING CYLINDER ROD ELECTRICAL FAULT DETECTION PANELS WING LOWER SKIN CRACKS	
US	63-06-03	ELECTRICAL FAULT DETECTION PANELS	BENDIX SB R-47
US	63-10-03	WING COURT SKIN CRACKS	
US	63-11-02	MAIN LANDING GEAR	
US	63-15-04	NOSE LANDING GEAR ROD END EYE-BOLTS	
US	64-18-04	NOSE LANDING GEAR RETRACT FORKS	
US US	65-12-01 67-07-05	MAIN LANDING GEAR GLAND NUT	
	67-33-03	PROPELLER GUST LOCK	
US	68-07-01	PRESSURE FUELING VALVES	
US	68-10-04	DIRECT VISION WINDOW FRAME CASTING FRONT SPAR LOWER RAIL	
US	68-16-04	EXHAUST DUCTS	
US	70-10-03		71-20
US	70-12-01	ENGINE BREATHER OIL FUMES MLG BEAM WEB INSPECTION	/ 1-2B
US	70-12-05	MLG TRUNION FITTING INSPECTION	57-3 57-4
US	70-12-07	MLG PISTON AXLE INSPECTION	32-3
US	70-13-02	WINDSHIELD LONGERON CRACKS	53-3
ATRCP	AFT/AFRONEES		

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

CONVA	I R		
440	2 //		
(CONT	INUED / SUITE		
US	71-02-03	MAIN LANDING GEAR FAILURE	
US	71-21-04	MLG PISTON BEARING LOCK PINS	32-5
US	73-07-01	WING FRONT SPAR LOWER CAP CRACKS	
US	73-18-01	NOSE LANDING GEAR FATIGUE CRACKS	32-7
US	73-19-11	NOSE LANDING GEAR DRAG STRUT	32-8
US	74-16-01	STRINGER INSPECTION	
US	77-10-11	CORROSION OF LANDING GEAR LUG	32-2
US	78-17-04 78-22-04	EMERGENCY WINDOW RELEASE HANDLE	ASB 25-A10
US	80-08-03	EMERGENCY EXIT WINDOW AIRCRAFT WINDOWS	
US	81-22-02	ELEVATOR OUTER TOROUT TURE	53-5B
US	82-19-02	HORIZONTAL STABILIZER ATTACH	27-6
US	83-01-02	NLG AXLE FRACTURE	32-13
US	87-17-10	MLG DRAG STRUT PIVOT BOLT	32-14
US	90-13-13	VISUAL INSPECTION OF FUSELAGE FRAMES	53-15 R1
US	91-12-05		55-5, -A5
US	92-06-06	PRINCIPAL STRUCTURAL ELEMENTS	SID ZS-340-1000R1
US	92-25-13	CORROSION & PREVENTION CONTROL	75-340-2000
US	93-04-03	HORZ & VERT STAB ATTACH FITTINGS - INSPECT	55-6
US	93-24-06	ELEV & RUDDER HINGE PINS - INSP UNAPROVED PARTS	A55-7, -5
US	96-03-04	FLAP LIMITATIONS IN ICING CONDITIONS	AFM
US	98-08-17	POWER LEVERS	
580			
US	52-14-02	PROPELLER REVERSING REWORK	240-381 ITEM IV
US	55-03-01	ELEVATOR SERVO TAB INSPECTION	
US	55-15-02	FIRE RESISTANT PROP FEATHERING LINES	The state of the s
US	55-18-01	PROPELLER REVERSE PROTECTIVE DEVICE	340-141A
US	56-04-02	NACELLE FIRE PROTECTION	340-166, -167
US	56-20-04	FIRE PROTECTION REWORK	340-177, -209, -210A
US	56-27-01	ELEVATOR TAB RODS	340-150A, -207
US US	57-12-05 57-14-01	ELEVATOR SPAR CRACKS	
US	59-01-01	LANDING GEAR PIVOT SHAFT SLEEVE FIRE DETECTOR SYSTEM REWORK	
US	59-02-01	FIRE PROTECTION MODIFICATIONS	340-170
US	59-04-02	DV WINDOW STOP	340 170
US	60-14-01	LANDING GEAR ACTUATING CYLINDER ROD	
US	63-06-03		BENDIX SB R-47
US	63-10-03	WING LOWER SKIN CRACKS	
	63-11-02	MAIN LANDING GEAR	
US	63-15-04	NOSE LANDING GEAR ROD END EYE-BOLTS	
US	64-18-04	NOSE LANDING GEAR RETRACT FORKS	
US	65-12-01	MAIN LANDING GEAR GLAND NUT	
US	67-02-03		340-1744, -213, -232
US	67-07-05	PROPELLER GUST LOCK	
US	67-33-03	PRESSURE FUELING VALVES	
US	68-07-01	DIRECT VISION WINDOW FRAME CASTING	
US	68-10-04	FRONT SPAR LOWER RAIL	
US	68-16-04	EXHAUST DUCTS ENGINE BREATHER OIL FUMES	71-2B
US US	70-10-03		
US	70-12-01	MLG BEAM WEB INSPECTION MLG TRUNION FITTING INSPECTION	57-4
US	70-12-05 70-12-07	MLG TRONION FITTING THAT THE MEDITION	32-3
US	70-12-07	WINDSHIELD LONGERON CRACKS	53-3
US	71-02-03	MAIN LANDING GEAR FAILURE	
US	71-21-04	MLG PISTON BEARING LOCK PINS	32-5
US	73-07-01	WING FRONT SPAR LOWER CAP CRACKS	
US	73-18-01	NOSE LANDING GEAR FATIGUE CRACKS	32-7
US	73-19-11	NOSE LANDING GEAR DRAG STRUT	32-8
US	74-16-01	STRINGER INSPECTION	
US	77-10-11	CORROSION OF LANDING GEAR LUG	32-2
US	78-17-04	EMERGENCY WINDOW RELEASE HANDLE	ASB 25~A10
US	78-22-04	EMERGENCY EXIT WINDOW	50 FD
US	80-08-03	AIRCRAFT WINDOWS	53-5B
US	81-22-02	ELEVATOR OUTER TORQUE TUBE	27-6
US	82-19-02	HORIZONTAL STABILIZER ATTACH	55-3A, -4R1
US	83-01-02	NLG AXLE FRACTURE	32-13
US	87-17-10	MLG DRAG STRUT PIVOT BOLT	32-14 53-15 R1
US	90-13-13	VISUAL INSPECTION OF FUSELAGE FRAMES	55-5, -A5
US	91-12-05	ELEVATOR HINGE PIN PRINCIPAL STRUCTURAL ELEMENTS	SID ZS-340-1000R1
US	92-06-06	CORROSION & PREVENTION CONTROL	ZS-340-2000
US	92-25-13	CORROSTOR & TREVERSION CONTROL	

MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE) ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF CONVAIR 580 (CONTINUED / SUITE) 93-04-03 HORZ & VERT STAB ATTACH FITTINGS - INSPECT 55-6 115 US 93-24-06 ELEV & RUDDER HINGE PINS - INSP UNAPROVED PARTS A55-7, -5 115 96-03-04 FLAP LIMITATIONS IN ICING CONDITIONS AFM US 98-08-17 POWER LEVERS CORCORAN B TG1A CUB AIRCRAFT J3C SERIES SEE/VOIR: PIPER ( J3C SERIES ) SEE/VOIR - PIPER CURTISS WRIGHT ROBIN C 1 C46 SERTES US 47-51-02 ELEVATOR HINGE BOLTS 47-51-03 AILERON RIB REWORK 47-51-04 PROPELLER ANTIHEAT SHIELD US 47-51-05 AILERON HORN 47-51-07 US LANDING GEAR DRAG STRUT 48-03-05 HYDRAULIC LINES US 48-44-02 WING ATTACH BOLTS 49-12-01 AILERON TRIM TAB US 49-18-01 COMBUSTION HEATER FIRE PROTECTION US 49-25-01 CARGO COMPARTMENT FIRE PROTECTION 50-26-01 LANDING GEAR SIDE BRACES 50-29-01 WING CENTER SECTION RIVETS US 51-10-06 CONTROL SURFACE FITTINGS COCKPIT LIGHT REWORK 51-20-01 US 51-29-02 MAIN LANDING GEAR SIDE BRACE 52-10-01 AMMETER CIRCUIT PROTECTION CABIN DOOR LOCK US 52-12-02 52-17-02 TAILWHEEL REWORK 52-18-01 CARBURETOR GASKET MODIFICATION 52-19-01 POWERPLANT FIRE PROTECTION 53-10-01 VACUUM SYSTEM DISCHARGE LINE 54-05-01 LANDING GEAR CYLINDER HEAD 54-14-01 HORIZONTAL STABILIZER RIBS US 55-09-02 CONTROL COLUMN INSPECTION HYDRAULIC VENT LINE 57-05-01 57-11-01 ELEVATOR SPRING TAB CARTRIDGE 57-15-02 GOODRICH WHEEL INSPECTION US 58-17-02 HORIZONTAL TAIL INSPECTION US 58-17-03 PROPELLER FEATHERING LINE REROUTING US 58-20-01 TAIL WHEEL RETRACT YOKE US 60-03-02 CARGO FIRE PROTECTION US 60-23-02 UNAPPROVED INSPECTION OPENINGS US 60-25-01 WING BOLTS 62-10-02 FIRE PROTECTION MODIFICATION 62-27-03 US RUDDER SPRING TAB ROD TERMINAL 65-17-02 LANDING GEAR LIGHT SYSTEM 66-02-02 MAIN HYDRAULIC ACCUMULATOR US 66-05-01 MAIN LANDING GEAR DRAG STRUTS 74-18-03 MAIN LANDING GEAR AXLE ELBOW 79-05-10 ENGINE FIRE FROM WHEEL WELL C46A(AIRLIFT INTL) ( C46 SERIES ) C46D ( C46 SERIES ) C46F ( C46 SERIES ) DART G

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
	_		
DASSAUL FALCON			
FR	75-138-001	DITOT PRODES CERVISE	
FR	76-224-002(B)	PITOT PROBES SERVICE LIFE ENGINE TAILPLANES	
FR	77-215-005(B)	FIRE EXTINGUISHING SYSTEM	F10-0129
FR	77-216-006(B)	AIR CONDITIONING COOLING SYSTEM	F10-0141 F10-0162
FR	78-004-007(B)	OXYGEN SUPPLY PRESSURE REDUCING VALVE	F10-0135
FR	78-081-008(B)	PASSENGER DOOR MICROSWITCH	F10-0163
FR FR	78-126-009(B)	LANDING GEAR LATCHING BOXES	F10-0164,-0157
FR	78-202-010(B) 78-215-011(B)	AILERON / ELEVATOR ARTHUR Q UNIT	F10-1065
FR	78-224-012(B)	EMERGENCY / STANDARD LANDING GEAR CONTROLS FREON COMPRESSOR TIMER	F10-0149, -0168
FR	79-203-013(B)	PASSENGER ACCESS DOOR	F10-1077
FR	79-230-014(B)	SICMA PILOT / COPILOT SEATS	F10-0190 F10-0093
FR	81-225-015(B)	ENGINE AFT MOUNT AUXILIARY BRACKET	F10-0225
FR	83-104-017(B)	RUDDER POWER CONTROL UNIT	F10-0237
FR	83-155-018(B)	WING ANTI-ICING SUPPLY SYSTEM	F10-0239
FR	84-041-019(B)	WING TO FUSELAGE JUNCTION	F10-0205
FR	84-105-020(B)	AUTOMATIC OPERATION - LEADING EDGE SLATS	F10-0247
FR	86-188-021(B)	FREUN COMPRESSER MOTOR GROUND	F10-0262
FR FR	98-547-022(B) 1999-211-023(B)	TAKEOFF CONFIGURATION WARNING OVERWING EMERGENCY EXIT	F10-280
FR	1999-269-024(B)		SEE AD EOD DEFENDA
FR	1999-450(B)R1	YEAR 2000 COMPLIANCE	SEE AD FOR REFERENCE
		Tana 2000 dani ETANOL	
	20 SERIES		
FR	67-001-001	HORIZONTAL STABILIZER	27-12R2
FR	67-038-004	EMERGENCY HYDRAULIC CONTROL	29-17
FR	68-024-005	FUEL HEATER	73-4,73-5
FR FR	68-034-006	LANDING GEAR SWITCHES	333R1
FR	69-020-007 72-025-008	LANDING GEAR SWITCHES AIR CONDITIONING PIPES	374R1 442
FR	76-015-009(B)	LANDING GEAR ACTUATING CYLINDERS	5228R2.529
FR	76-050-010(B)	FUEL SYSTEM	554.555
FR	76-064-011(B)	FUEL SYSTEM - SHUT OFF VALVE	550,551
FR	76-219-013(B)	ELEVATOR TRIM ELECTRICAL CONTROL CIRCUIT	568R1
FR	78-080-012(B)	PASSENGER DOOR	605,615,616
FR	79-132-15(B)	FLEXIBLE LINES - ENGINE FIRE EXTINGUISHING	632
FR	87-077-018(B)	MLG - LATERAL DOOR REAR LOCK CONTROL	FJF 502R1
FR	90-089-020(B)R1	SUPPLEMENTAL STRUCTURAL INSPECTION PROGRAM(SSIP)	FJF 730
FR	90-090-019(B)R1	MAJOR CORROSION INSPECTION OVERWING EMERGENCY EXIT	
FR FR	1999-212-024(B) 1999-270-025(B)	PASSENGER DXYGEN MASKS	SEE AD FOR REFERENCE
FR	1999-467-026(B)	SPEED LIMITATIONS ASSOCIATED WITH ARTHUR Q FAILURE	
	1333 407 020(37		,
FALCON		ALCON 20 SERIES )	
CF	CF-67-04	THROTTLE DRIVING - PULLEY MICROSWITCH	76-4
CF	CF-67-05	CORROSION OF HONEYCOMB SKINS	
FR	96-092-021(B)	WING TO FUSELAGE UPPER FAIRINGS	
FR FR	98-114-023(B)R1 1999-450(B)R1	FIRE EXTINCTION YEAR 2000 COMPLIANCE	
F.IX	1999-430(b)K1	TEAN 2000 OOM ESTATO	
FALCON	20D ( F	ALCON 20 SERIES )	
FR	1999-450(B)R1	YEAR 2000 COMPLIANCE	
FALCON		SIDE ENGINE AFT MOUNT BRACKET	F50-0113
	81-226-001(B)	SIDE ENGINE FRONT MOUNT FORWARD BOLT	F50-0132
FR FR	82-174-002(B) 83-010-003(B)	FUEL SYSTEM REFUELING CONNECTOR	F50-0137
FR	86-055-004(B)	CUEL SYSTEM COOSSEED VALVE ACTUATORS	F50-0182
	86-074-005(B)	BAGGAGE COMPARTMENT FLOOR - FUSELAGE REINFORCEMENT	
	88-140-006(B)R2	MLG DOOR EMERGENCY UNLOCKING PIN	
FR	89-041-007(B)R1	LEVER/SPLINED PIN - MLG DOORS	F50-208
FR	93-113-013(B)	ENGINE TAIL PIPE CLAMPS	F50-229R1
	94-238-015(B)R1	ELECTRICAL WIRING	A243, 244
	96-094-017(B)R1	WIRING PROTECTION	F50-256 F 50-274
	1997-370-020(B)R2	HORIZONTAL STABILIZER HINGE ENGINE COMPUTER DEEC - MODIFICATION	F 50-274 F .50-276
	98-228-021(B)	TAKE-OFF CONFIGURATION WARNING	F50-240
	98-300-022(B) 1999-213-025(B)	OVERWING EMERGENCY EXIT	
FR FR	1999-213-025(B)	PASSENGER DXYGEN MASKS	SEE AD FOR REFERENCE
FR	1999-450(B)R1	YEAR 2000 COMPLIANCE	
FR	1999-464-029(B)	SPEED LIMITATIONS ASSOCIATED WITH ARTHUR Q FAILURE	N/A

	NSTRUCTEUR MODELE (SE	ERIES / SERIE)	
ORIGIN	AD NUMBER	SUBJECT SUJET .	REFERENCE SERVICE BULLETIN
	NOME TO BE CONTINUE	30021	BULLETIN DE SERVICE DE REF.
DASSAL			
	ON 200		
FR FR	84-080-016(B) 86-037-017(B)	FUEL FLOW TRANSMITTER	***************************************
FR	91-197-018(B)	FUEL DISTRIBUTOR BLOCK ACTUATOR COWLING FASTNERS	F200-64
FR	96-078-021(B)	FUSELAGE TANKS POLYURETHANE FOAM REPLACEMENT	F200-0059,0078,0087
FR	96-246-022(B)	WING TO FUSELAGE UPPER FAIRINGS	
FR	1999-212-024(B)	OVERWING EMERGENCY EXIT	
FR	1999-270-025(B)	PASSENGER OXYGEN MASKS	SEE AD FOR REFERENCE
FR	1999-450(B)R1	YEAR 2000 COMPLIANCE	
FR	1999-467-026(B)	SPEED LIMITATIONS ASSOCIATED WITH ARTHUR Q FAIL	URE N/A
FALCO	N 900		
FR	88-140-006(B)R2	MLG DOOR EMERGENCY UNLOCKING PIN	
FR	89-041-007(B)R1	LEVER/SPLINED PIN - MLG DOORS	F900-52
FR FR	89-106-008(B)R1	THRUST REVERSER	F900-54R2, -61
FR	90-170-009(B)R1 92-067-010(B)	WATER DRAINAGE AT FRAME 25 WATER FREEZING-FLIGHT CONTROL AREA FR25	F900-82, F900-83
FR	92-139-011(B)	WINDSHIELD SUPPORT	F900-113 & 115
FR	92-140-012(B)	STRUCTURAL REINFORCEMENT-FRAME 30	F900-91
FR	94-098-014(B)R1	NLG - SHOCK ABSORBER	F900-93 ASB F900-A150
FR	95-204-016(B)R1	OVERHEAD PANEL WIRING HARNESS	F900-A172
FR	96-279-018(B)	WATER HEATER	F.900-181
FR	1997-370-020(B)R2		F 900-203
FR FR	98-429-023(B)	ELEVATOR AUX. ARTIFICIAL FEEL UNIT	MF900-235
FR	1999-082-024(B)R1 1999-213-025(B)	FLAP SCREWJACK	
FR	1999-271-026(B)	OVERWING EMERGENCY EXIT PASSENGER OXYGEN MASKS	
FR	1999-446-028(B)	FRAME 25 WATER DRAINAGE	SEE AD FOR REFERENCE
FR	1999-450(B)R1	YEAR 2000 COMPLIANCE	MF900-232,F900EX-093
FR	1999-464-029(B)	SPEED LIMITATIONS ASSOCIATED WITH ARTHUR Q FAILU	JRE N/A
DE CUA	TILLON		
DE CHA			
	75-062	HORIZONTAL STABILIZER MOUNTING BRACKET	
		THORIZONIAL STABILIZER MOUNTING BRACKET	
DEHAVI			
CS2F			
CF CF	CF-83-23 CF-90-14	HINGE TANGS AND SPAR CAPS	
Cr	CF-90-14	STALL WARNING SYSTEM	
CS2F	2		
	CF-83-23	HINGE TANGS AND SPAR CAPS	
CF	CF-88-20R1	RUDDER TRIM	724-001-R3
CF	CF-90-14	STALL WARNING SYSTEM	724 001 KG
DH60G			
UK	006-10-97	COCVETT LATERAL THE BODS	
UK	002-03-98	COCKPIT LATERAL TIE RODS FLIGHT LIMITATIONS	TNS 29 ISSUE 3
UK	007-03-99	COCKPIT SAFETY HARNESS	TNS 32 ISSUE 2 TNS 33 ISS. 1
			110 00 100. 1
DH60GN			
UK	006-10-97	COCKPIT LATERAL TIE RODS	TNS 29 ISSUE 3
UK	002-03-98	FLIGHT LIMITATIONS	TNS 32 ISSUE 2
DH82 S	ERIES		
DH82A		DH82 SERIES )	
UK	2731 PRE 80	ATTERON SPROCKET CHAIN GUIDES	MOD 125-TNS 5 ISS.1
UK UK	2732 PRE 80	AILERON GEAR BOX	MOD 134-TNS 5 ISS.1
UK	2734 PPF 90	AILERON GEAR BOX AILERON CONTROL BOX UNIVERSAL JOINT UNDERCARRIAGE COMPRESSION LEG ANTI-SPINNING STRAKES FUSELAGE JOINTS E AND L	MOD 138-TNS 5 ISS.1
UK	002-04-83	ANTI-SPINNING STRAVES	TNS 19 ISS. 1
UK	002-10-97	FUSELAGE JOINTS F AND I	AD/ IL/ 0139
UK	006-10-97	COCKPIT LATERAL TIE RODS	TNS 28 ISSUE 2 TNS 29 ISSUE 3
UK	002-03-98	FLIGHT LIMITATIONS	TNS 32 ISSUE 2
UK	007-03-99	ANTISPINNING STRAKES FUSELAGE JOINTS E AND L COCKPIT LATERAL TIE RODS FLIGHT LIMITATIONS COCKPIT SAFETY HARNESS FUEL ON/OFF COCK LEVER LOCKING DEVICE	TNS 33 ISS. 1
UK	008-03-99	COCKPIT SAFETY HARNESS FUEL ON/OFF COCK LEVER LOCKING DEVICE	TNS 34 ISS. 1
DH82C		DH82 SERIES )	
		DIIOZ SEKIES /	
DH83C			
UK	006-10-97	COCKPIT LATERAL TIE RODS	TNS 29 ISSUE 3
UK UK	002-03-98 007-03-99	FLIGHT LIMITATIONS	TNS 32 ISSUE 2
	007 00 33	COCKPIT SAFETY HARNESS	TNS 33 ISS. 1

MAKE / CONS MODEL / MO		(SERIES / SERIE)	
ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
DEHAVIL	LAND		
DH85	000 00 00	51 7017	
UK	002-03-98	FLIGHT LIMITATIONS	TNS 32 ISSUE 2
DH87A			
UK	002-03-98	FLIGHT LIMITATIONS	TNS 32 ISSUE 2
DH87B			
UK	002-03-98	FLIGHT LIMITATIONS	TNS 32 ISSUE 2
			1113 32 1330L 2
DH89A	0725 DDE 00	CODERN MAND CODERN MADE	
UK UK	2735 PRE 80 2736 PRE 80	SCREEN WIND-SCREEN WIPER ANTI-VIBRATION STRUT	RAPIDE MOD. 1
UK	2737 PRE 80	FUEL DRAIN PIPE	RAPIDE MOD. 2 RAPIDE MOD. 5
UK	2738 PRE 80	BATTERY MASTER SWITCH	RAPIDE MOD. 9
UK UK	2739 PRE 80 2740 PRE 80	FUSE NEGATIVE LEAD TO RADIO	RAPIDE MOD. 10
UK	2/40 PRE 80	REAR DIAGONAL STRUTS/UNDERCARRIAGE RADIUS RODS	RAPIDE MOD. 15
DH104			
CF	CF-55-07	WING CENTRE SECTION	TN'S 18,119
UK	002-11-88	FLAP JACK TO FLAP ATTACHMENT PIN	TNS 246
DHC 1			
CF	CF-49-05	MODIFICATIONS	C-3,C-4,C-6 TNS
CF	CF-51-05	MODIFICATIONS	C-20, C(R)1 TNS
CF CF	CF-52-04 CF-52-06	MODIFICATIONS FUSELAGE REAR BULKHEAD	C-30 TNS C-33 TNS
CF	CF-91-38	FATIGUE CRACKS FUSELAGE REAR BULKHEAD - INSP	TNS 183 ISSUE 4
DHC 1A		2140774004	0.0.0.4.0.0.7115
CF CF	CF-49-05 CF-51-05	MODIFICATIONS MODIFICATIONS	C-3,C-4,C-6 TNS C-20,C(R)1 TNS
CF	CF-52-04	MODIFICATIONS	C-30 TNS
CF	CF-52-06	FUSELAGE REAR BULKHEAD	C-33 TNS
CF	CF-91-38	FATIAGUE CRACKS FUSELAGE REAR BULKHEAD - INSP	TNS 183 ISSUE 4
DHC 1B	SERIES		
	CF-49-05	MODIFICATIONS	C-3,C-4,C-6 TNS C-20,C(R)1 TNS
CF CF	CF-51-05 CF-52-04	MODIFICATIONS MODIFICATIONS	C-30 TNS
CF	CF-52-06	FUSELAGE REAR BULKHEAD	C-33 TNS
CF	CF-53-11	MODIFICATION	C-38 TNS
CF CF	CF-54-02 CF-91-38	CANOPY LOCK FATIAGUE CRACKS FUSELAGE REAR BULKHEAD - INSP	TNS 183 ISSUE 4
CF	Cr-91-30	ALLAGE ONKONS FOSCEAGE NEW SOLUTION	
DHC 1B	1	( DHC 1B SERIES )	
DHC 1B	2	( DHC 1B SERIES )	
DHC 1B	253	( DHC 1B SERIES )	
DHC 1B	255	( DHC 1B SERIES )	
DHC 2	CF-50-03	MODIFICATIONS	
CF	CF-50-08	FUEL LINE, FUEL PIPE	B42
CF	CF-51-03	WOBBLE PUMP BRACKET WING SKIN AND FUSELAGE SIDE INSP / REPAIR	B43 B59, ISS-2
	CF-53-05	ELEVATOR OUTBOARD HINGE ATTACHMENT	B60
CF CF	CF-53-06 CF-53-09	FLAP HYDRAULIC HAND PUMP	B63
CF	CF-53-10	ENGINE OIL SUMP	B64
CF	CF-53-12	REAR WING SPAR TO FUSE ATTTACHMENT REAR TANK FILLER NECK RECESS BOX	B67 B68
CF CF	CF-53-14 CF-54-10	CONTROL CABLE TERMINALS	B76
CF	CF-55-04	SKI AXLE BOLT	
CF	CF-56-01	SKI CHANNEL INSPECTION	B22
CF	CF-60-02	FRONT PICKUP CASTING SKI AXLE PINS AND BUSHINGS	B24
CF CF	CF-61-03 CF-61-12	AILERON MASS BALANCE WEIGHT ARM	B17
CF	CF-64-01	ELEVATOR TRIM TAB FIBER END BLOCK	B30
CF	CF-66-03	WING RIBS AILERON / WING FLUTTER	B35,T.B.3 2/27,B28
		AILEKUN / WING FLOTTER	-/-/, 020
CF	CF-80-05R1		2/30
CF CF	CF-80-05R1 CF-80-25 CF-83-07	ELEVATOR ROOT RIB WING LIFT STRUT UPPER FITTING HORIZONTAL TORQUE TUBE	2/30 2/3 2/28

MAKE / CONSTRUCTEUR

	ONSTRUCTEUR / MODELE N AD NUMBER	(SERIES / SERIE)	
ORIGII	NE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
DEHAV	'ILLAND		
	2 SERIES INUED / SUITE)		
CF	CF-84-02R1	AILERON CENTER HINGE BRACKET	2/37 REV C
CF	CF-85-08R3	WING STRUT LOWER FITTING	2/41 REV. B
CF CF	CF-91-42 CF-93-21	TAILPLANE SPAR CRACKS	2/47 REV C
CF	CF-93-22	WING STRUTS - STEEL END FITTINGS DOOR OPERATING INSTRUCTIONS	A2/48 2/45 REV A
CF	CF-97-06	ELEVATOR TIP RIBS	SB 2/50 & TB/58
CF CF	CF-98-37R1 CF-98-38	FRONT FUSELAGE STRUT ASSEMBLIES	- / /
		BULKHEAD CRACKS STA. 228	2/52 OR TB 2/60
DHC		( DHC 2 SERIES )	
CF	2 MKI CF-54-08R1	( DHC 2 SERIES ) TAILPLANE FRONT ATTACHMENT	2/42 REV A
CF CF	CF-65-03 CF-83-09R2	PREVENTION OF CARBURATOR FIRE ON START	
		EDO FLOATS / FIN	2/35 REV A
	2 MKII	( DHC 2 SERIES )	
CF CF	CF-54-08R1 CF-83-09R2	TAILPLANE FRONT ATTACHMENT EDO FLOATS / FIN	2/42 REV A
		LOG TEGATS / TIN	2/35 REV A
DHC :	2 MKIII	( DHC 2 SERIES )	
CF	CF-66-04 CF-68-10	FUEL SYSTEM RUDDER HORN SKIN	5 TB
CF	CF-71-01	FLOAT OR AMPHIBIOUS FLOAT EQUIPMENT	19 TB
CF	CF-80-22	PROP REVERSING LINKAGE INTERCONNECT	
DHC :			
CF CF	CF-53-16 CF-54-03	MODIFICATIONS	3,4,6,9 TNS
CF	CF-54-03 CF-54-04	MODIFICATIONS COMPRESSION STRUT	17 TNS
CF	CF-54-07	CARGO DOORS	23 TNS 21 TNS
CF CF	CF-54-09	MODIFICATIONS	22,24,25 TNS
CF	CF-55-03 CF-55-06	MODIFICATIONS ENGINE BREATHER PIPE ASSEMBLY	1,3 TNS
CF	CF-56-03	REQUIRED MODIFICATIONS	5 EB 017,018 EB
CF CF	CF-56-08	TAILPLANE TRIM	021 EB
CF	CF-56-11 CF-56-12	FLAP HYDRAULIC CIRCUIT CHECK VALVE EXHAUST SYSTEM SUPPORT	3/731 MOD
CF	CF-56-13	PROPELLER COUNTERWEIGHT BEARING SHAFT	019 EB 55 TNS
CF CF	CF-57-06 CF-57-08	MODIFICATIONS	
CF	CF-58-04	SINTERED METAL FILTER ASSY CLINCH NUTS	038 EB
CF	CF-58-15	FLAP CONTROL RODS	O47 EB O49 EB
CF	CF-59-03	MODIFICATION	057 EB
CF CF	CF-59-07 CF-60-03	BELLCRANK ASSEMBLIES WING STRUT SPAR	003 ED
CF	CF-61-04	MAIN SKI AXLE PINS AND BUSHINGS	066 EB 070 EB
CF	CF-61-05	OIL DELIVERY LINES	O68 EB
CF CF	CF-62-05 CF-68-13	FIREWALL ASSEMBLIES ELEVATOR TAB FLUTTER	072 EB
CF	CF-69-12	SKIS OR WHEEL-SKIS	3/4, 3/6 3/12 ISSUE 2
CF	CF-82-26R1	TIE BAR ASSEMBLIES	3/12 1330E 2
CF CF	CF-82-34 CF-85-03R1	CONTROL COLUMN ASSEMBLIES	3/39
CF	CF-85-04	CABIN UTILITY SEATS ELEVATOR PUSHROD	3/42
CF	CF-89-20R1	TAILPLANE RIB CRACKING	3/35, 3/43 3/46 REV B
CF CF	CF-91-16 CF-99-05	FUEL CONTROL DETENT	
CF	CF-99-05 CF-99-06	ELECTRICAL SYSTEM . FIRE DETECTION	SA-SIL-98-11-03
US	98-18-08	A SA LLITON CTO MOD	ML 066 SA-SIL-98-11-03
DHC 4	SERIES		
CF	CF-61-10	INCORRECT RIVETS	11 EM
CF CF	CF-61-11	RUDDER RIB FLANGES	4/1101 MB
CF	CF-61-14 CF-61-15	ELECTROFILM BEARINGS ROOT FORE FLAPS	4/1099 MB
CF	CF-62-01	MICRO SWITCH ACTUATING ARM LOCK SCREW	4/1150 MB 12 EB
CF	CF-62-03	FUEL SIPHONING	
CF CF	CF-62-04 CF-62-06	LATCH ROD PISTON	4/1182 MB
CF	CF-62-08	ALUMINUM ELECTRICAL CABLE ASSYS FEATHERING WELL	18 EB 4/1203 <b>M</b> B
CF	CF-79-05	MAGNETO DRIVE MECHANISM	1756

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

		50361	BULLETIN DE SERVICE DE REF.
DELLA	ATT LAND		
DHC	VILLAND	( DUO 4 CERTER )	
DITC	4	( DHC 4 SERIES )	
DHC	41	( DHC 4 SERIES )	
Dile	70	( DIIC 4 SERIES )	
DHC	54		
	CF-82-22	FLAP TOPOLE THE ASSEMBLY	15/005
CF	CF-83-12R1	FLAP TORQUE TUBE ASSEMBLY ROOT TRAILING FLAP	A5/307
CF	CF-83-35	FLYING CONTROL RODS	5/321
CF	CF-84-07	FLAP HINGE ARM	5/268
		A THE PROPERTY PROPERTY AND A STATE OF THE PROPERTY OF THE PRO	5/322
DHC	5E		
CF	CF-82-22	FLAP TORQUE TUBE ASSEMBLY	A5/307
CF	CF-83-12R1	ROOT TRAILING FLAP, HINGES AND BEARINGS	5/1732
CF	CF-83-35	FLYING CONTROL RODS - STRESS CORROSION/CRACKING	5/268 REV. D
CF	CF-84-07	ROOT FLAP OUTBOARD HINGE ARM ATTACHMENT BRACKETS	5/322
			-,
DHC	6 SERIES		
CF	CF-68-05	AILERON MASS BALANCE	6/100
CF	CF-68-09	LH ELEVATOR TRIM TAB	6/65,6/68,6/69
CF	CF-69-20	WING STRUT JO-BOLTS	6/166
CF	CF-70-10	CIRCUIT WIRES	6/245
CF	CF-71-07	FUEL STARVATION	6/269
CF	CF-71-11	O.D. STOTENS ATK CONDITIONER	0/200,0 0 011
CF	CF-71-12	A.C. POWER	6/263
CF	CF-72-06R4	LOWER CONTROL COLUM ELEV / RUDDER PULLEY BRACKET	6/180, 6/181
CF	CF-73-03R1		6/295 REV B
CF	CF-73-04	PROP AUTO-FEATHER SYS	2/297 REV B
CF	CF-73-06R2	CRACKING OF OVERHEAD CONTROL CONSOLE QUADRANTS	6/519
CF CF	CF-73-09	AUTO-FEATHERING SYS	0/000
CF	CF-73-11	FLOAT TO CHASSIS BOLTS SIDE SEAT RAIL ATTACHMENT	2/296
CF	CF-73-12 CF-74-04	HORIZ STAB REAR SPAR	6/302 6/310
CF	CF-74-07	AILERON CONTROL CABLE	6/304 REV B
CF	CF-75-06	SLOW BLOW FUSES	6/263 REV D
CF	CF-75-11	REVERSE CURRENT RELAYS - HARTMAN	0/200 NEV D
CF	CF-75-14	FLOAT WATER COMPARTMENT	
CF	CF-76-21	WING TIP LIGHTNING PROTECTION	6/318 REV A
CF	CF-77-05R1	CRACKING OF ELEVATOR CONTROL HOUSING ASSY	6/348
CF	CF-77-08	REVERSE CURRENT RELAYS	6/353
CF	CF-78-17R1	CRACKING OF FUSELAGE SIDE FRAMES	6/371
CF	CF-79-02	ELEVATOR CONTROL SYSTEM	6/379
CF	CF-79-22R2	FLAP SYS CONTROL RODS	6/388, 6/502
CF	CF-79-24	BEIA RANGE IHRUITLE ARMING SWITCH	6/309 REV C
CF	CF-80-01	FLOAT STRUT FAILURE	6/330, 6/357 REVS B
CF	CF-80-03R4	ELEV, FLAP AND AILERONS CONTROL ROD MLG Y-JOINT WELD	6/390 REV A
CF	CF-80-06	MLG Y-JOINT WELD PROP REVERSING LINKAGE INTERCONNECT	6/380
CF	CF-80-22	ELECTRICAL FIRE PREVENTION	6/401 REV A
CF	CF-81-05	ENGINE NACELLE LOWER LONGERONS	6/509
CF	CF-81-07R4	WINDSCREEN WASHER / DE-ICER SYS	6/422
CF CF	CF-82-20	CRACKING OF ELEVATOR ROOT RIBS	6/399 REV E
CF	CF-82-21R1 CF-83-11R1	ELEVATOR HINGE ARM ASSEMBLY	6/421, 6/228
CF	CF-83-11K1	CARIN LITH ITY SEATS	6/447 REV B
CF	CF-83-25K2	FUEL VENT FLAME ARRESTOR	6/211 REV. A
CF	CF-84-03	NOSE GEAR STEERING CABLES	6/453 ISS 2
CF	CF-85-12R3	CRACKING OF WING TO FUSELAGE ADAPTOR FITTINGS	A6/476,6/500
CF	CF-85-14	CORROSION OF WING STRUTS	6/474
CF	CF-87-02R1	CORROSION OF WING SPAR LOWER CAP ANGLES	6/492
CF	CF-90-01	FLIGHT CONTROL GUST LOCKS	6/508
CF	CF-90-10	ELEVATOR PUSHROD END	0 /
CF	CF-91-30	WING STRUTS	6/342
CF	CF-92-04	LOOSE HORZ STAB FWD ATTACH FITTINGS	6/438REVD & 6/513
CF	CF-92-05	HORZ STAB CENTER HINGE FLANGE BRACKET - INSPECT	6/512
CF	CF-93-25	CORROSION - RIVETS ATTACH LWR & LDG EDGE SKINS	SECT 3 6/517
CF	CF-94-12R1	CORROSION PREVENTION AND CONTROL PROGRAM	6/521
CF	CF-95-12	SKIN CRACKING FS 239 SERVICE LIFE LIMITS	0/ 321
CF	CF-96-15	SERVICE LIFE LIMITS	
CF	CF-99-11	CORROSION TASKS	
DILIC	0	( DHC 6 SERIES )	
DHC	ь	( ) 110 3 02	
DHC	6 100	( DHC 6 SERIES )	
DITO	0 100		

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMBER ODE CONSIGNE SUBJECT
SUBJECT

ORIG	146	NUMERO DE CONSIGNE			SUJET	
		LLAND				
DHC	6	200	(	DHC	6 SERIES )	
DHC	6	300	(	DHC	6 SERIES )	
DUC	-	310	(	DHC	6 SERIES )	
DHC	6	310	,	DHC	6 SERIES /	
	7	SERIES			AND DELICE ATTACKMENT BOLTS	7-54-4
CF CF		CF-79-14 CF-80-02			MLG FRAME ATTACHMENT BOLTS MLG UPPER DRAG STRUT	A7-32-18
CF		CF-80-16R1			MLG LOCK STRUT	7-32-21 REV B
CF		CF-80-17			NLG STOP PLATE RETAINING SPRING PIN	7-32-25
CF CF		CF-80-20R1 CF-81-02			FATIGUE CRACKS / FUSELAGE FLAP SCREWJACKS	7-53-9 7-27-29
CF		CF-81-02			FLAP OPERATION FAILURE OF BARREL NUTS	7-27-29
CF		CF-81-10R1			CRACKS / WING SPOILER SPIGOT FITTINGS	7-27-25
CF		CF-81-11			400 HZ INVERTORS  OXYGEN SUPPLY	7-24-13
CF CF		CF-81-27 CF-81-32			NOSE GEAR DOOR	7-32-13
CF		CF-82-25			GROUND SPUILER SELECTOR VALVE	A7-27-46
CF		CF-82-29			ELEVATOR TRIM MECHANISM	7-55-6 A7-27-47
CF CF		CF-82+31 CF-83-19R2			ELEVATOR GUST LOCK PILOT VALVE - GROUND SPOILERS	A7-27-56 REV A
CF		CF-83-20			FLAPS-UP SELECTOR CABLE	7-27-20
CF		CF-83-29R1			FUEL TANK COVERS	7-57-17 REV A 7-71-18
CF CF		CF-83-39 CF-83-40			FIRE PROTECTION PITOT TUBES	
CF		CF-84-10			LOWER WASTE DISPOSAL DOORS	7-25-44
CF		CF-84-13R2			REVISION OF FLIGHT MANUAL	7 57 05 051/ 4
CF CF		CF-85-15 CF-86-03			HEAT DAMAGE - UPPER WING SURFACE ELEVATOR TRIM ACTUATOR DRAIN HOLES	7-57-25 REV A 7-27-76
CF		CF-86-08			REAR CARGO COMPARTMENT LINER	7-25-49
CF		CF-86-14			FUEL LEAKING INTO LANDING LIGHT	7-28-18
CF		CF-87-04			FUEL LEAKING IN LANDING LIGHT AREA UPPER WING SKIN HEAT SHIELDS	7-57-30 7-57-29
CF CF		CF-87-11 CF-89-04			RELOCATION OF EXTERNAL POWER GROUND STUDS	7-24-66 REV A
CF		CF-89-07			FUSELAGE SKIN DOUBLER DISBONDING	7-53-33 REV A
CF		CF-89-10R1			WING SKIN CORROSION	7-57-33 REV A 7-57-14
CF CF		CF-91-05 CF-91-08R1			CRACKING AND RIVET FAILURE OF WING LEADING EDGE FLAP TRACK REINFORCEMENT	7-53-15 REV A
CF		CF-91-09R1			UNDERWING FAIRING FOULING	7-57-11
CF		CF-91-10			NACELLE LONGERON RIVETS	7-54-9
CF CF		CF-91-11 CF-91-12R1			WING FLAP TRACK FITTINGS WING REAR MOUNTING PLATES	7-27-37 7-57-19
CF		CF-91-13			SPOILER ACTUATOR ATTACHMENT BRACKET	7-57-12
CF		CF-91-20			UPPER DRAG STRUR	32-18 REV 1
CF CF		CF-91-31 CF-92-02			NOSE LANDING GEAR DRAG STRUT ATTACHMENT FITTING EMERGENCY DOWN RELEASE CABLES	7-53-32 A7-32-94
CF		CF-92-08			HYD SYS PRESS - QUANTITY LIMITING VALVE (QLV)	7-29-20
CF		CF-92-11			UNCOMMANDED PITCH EXCURSION DURING FLIGHT	7-55-10
CF CF		CF-92-13 CF-93-11			FLAP INDICATOR PROBLEM MAIN LANDING GEAR - UPPER LOCK STRUT	A7-27-86 ASB A7-32-100
CF		CF-93-30			ALUMINUM WASHERS IN DC FIREWALL TERMINAL BLOCK	7-24-69
CF		CF-94-04			LANDING GEAR SELECTOR VALVE	A7-32-97
CF CF		CF-94-15 CF-94-19R1			DISBONDING OF SKIN DOUBLERS INSPECTIONS	7-51-1
CF		CF-94-19R1			THERMAL INSULATION BLANKETS	7-21-30
CF		CF-95-03R1			EMERGENCY LIGHTS POWER CONTROL RELAY INSTALLATION	
CF		CF-95-04			EMERGENCY LIGHT CIRCUITRY	7-33-7
CF CF		CF-98-03 CF-98-05			CORROSION TASKS WHEEL BRAKE SHUTTLE VALVES	A7-32-102 REV.A
CF		CF-98-12			WING-TO-FUSELAGE ATTACH BOLTS	7-57-37R2
CF		CF-98-32R1			WEIGHT AND BALANCE	
CF CF		CF-99-03 CF-99-07			BAGGAGE DOOR STOP FITTINGS NACELLE LONGERON CORROSION	7-54-19
CF		CF-99-29			GROUND SPOILERS - UNCOMMANDED DEPLOYMENT	7-27-90
CF		CF-99-31			INSPECT/REPLACE LANDING GEAR SELECTOR VALVE	A7-32-103
DHC	7	102	(	DHC	7 SERIES )	
DHC	7	103	(	DHC	7 SERIES )	
DHC	7	150	(	DHC	7 SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

DEHAV I	I L L AND B	( DHC 8 100 SERIES )	
	3 100 SERIES		
CF CF	CF-85-06R3 CF-85-07R1	ENGINE ELEC. FUEL CONTROL UNIT	
CF	CF-86-01R1	LIMITATION OF FLAP OPERATION ELEVATOR MASS BALANCE	8-27-7
CF	CF-86-02	ELEVATOR TRIM ACTUATOR - DRAIN HOLES	8/0468 MOD 8-27-15
CF	CF-86-11R2	ELEVATOR TRIM ACTUATOR - DRAIN HOLES GROUND AND ROLL CONTROL SPOILERS	8-27-15 A8-27-25
CF CF	CF-86-13R1 CF-86-15	MAIN LANDING GEAR - COLLAPSING	A8-32-20
CF	CF-87-07R1	MAIN LANDING GEAR – COLLAPSING RUDDER HINGE BRACKET LAVATORY DOOR LABELLING	8-55-7
CF	CF-87-09	ALC VOICE FOR CABLELING	8-11-14 8-32-56
CF	CF-88-02R2	ELDEC PSEU	8-32-70
CF	CF-88-05 CF-88-12R3	DIGITAL AIR DATA COMPUTER	8-34-45
CF CF	CF-88-12R3	PROPELLER UNFEATHERING ALTERNATE FEATHER SWITCHES	8/0909 MOD
CF	CF-88-15	STARTER - GENERATOR - LUCAS	8-61-10 23088-00X,04 SIL
CF	CF-88-24	WARDROBE ASSY  ELEVATOR CONTROL QUADRANT LEVER ENGINE FIRE EXTINGUISHING SYSTEM FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASSYMMETRIC FLAP	8-25-35 REV A
CF	CF-88-25	ELEVATOR CONTROL QUADRANT LEVER	A8-27-45
CF CF	CF-89-01R1 CF-89-02	ENGINE FIRE EXTINGUISHING SYSTEM	A8-26-7
CF	CF-89-03	MAIN LANDING GEAR LIPLOCK ACTUATOR	8-57-10 8-22-79 PEV A
CF	CF-89-09R4	ASYMMETRIC FLAP	8-54-16,8-27-47
CF	CF-89-13R1	MAXIMUM / REDUCED POWER SWITCH	8-73-10
CF CF	CF-89-15R1	ADDED ENGINE COWL DOOR RETENTION / PRESSURE RELIEF MICROWAVE LANDING SYSTEM	
CF	CF-89-18R1 CF-90-08		8-34-60 REV A 8-33-17 REV B
CF	CF-91-07R1	FLIGHT CREW DXYGEN	A8-35-5 REV A
CF	CF-91-25R2	MAIN LANDING GEAR RETRACTION ACTUATOR BRACKETS	8-54-27RB & 8-54-34A
CF CF	CF-91-32R1	ENGINE BLEEDS ON TAKE OFF	8-21-29,8-21-53
CF	CF-91-34 CF-92-09	FLAP BALLSCREWS HYD SYS PRESS - QUANTITY LIMITING VALVE (QLV)	8-29-21
CF	CF-92-14	ENGINE MOUNT STRUT	8-71-17
CF	CF-92-16R1	CABIN/BAGGAGE COMPARTMENT BULKHEAD SEALS	
CF	CF-92-18R3	NLG DRAG STRUT FITTING	A8-53-40RA & 8-53-49
CF CF	CF-92-20 CF-93-01R1		A8-24-44 A8-33-30RA, 8-33-34
CF	CF-93-20	POWER SUPPLY - WHITE ANTI-COLLISION LIGHTS	8-33-19
CF	CF-93-24	NOSE WHEEL STEERING	8-32-99
CF	CF-94-05	LANDING GEAR SELECTOR VALVE THERMAL INSULATION BLANKETS	A8-32-117
CF CF	CF-94-08R1 CF-94-10R1	ENGINE NACELLE AREA SEALING	8-54-12 8-71-19
CF	CF-95-15	NLG DRAG STRUT PIVOT TUBE	8-32-131
CF	CF-96-14	FUEL/DEFUEL TUBE ASSEMBLIES	A8-28-20
CF	CF-96-20R2	FUEL/DEFUEL TUBE ASSEMBLIES COCKPIT DOOR ALTERNATE RELEASE HYDRAULIC SYSTEMS MODIFICATIONS	8-52-39
CF CF	CF-96-25R2 CF-97-14	WIRE CHAFING-LAVATORY SIDEWALL	8-24-50
CF	CF-98-05		10.00
CF	CF-98-24	WHEEL BRAKE SHUTTLE VALVES HORIZONTAL STABILIZER SKIN PANELS MLG UPLOCK ACTUATOR MOD BONDING INTEGRITY INSPECTIONS	
CF	CF-98-26	MLG UPLOCK ACTUATOR MOD  BONDING INTEGRITY INSPECTIONS	8-32-98 8-51-2
CF CF	CF-98-31 CF-98-32R1	WEIGHT AND BALANCE	8-31-2
CF	CF-99-10R1	FLAP CARRIAGE HOOK ROLLER SHAFTS CORROSION	PSM 1-8-7 TR AWL 72,
CF	CF-99-15R1		RD8-55-669 ISSUE 3
CF	CF-99-18	POWER LEVER FLT IDLE GATE RECONFIGURATION WING- FUEL TANK ACCESS PANEL SEAL CHANGE	REFER TO AD 8-57-41
CF CF	CF-99-20 CF-99-21		8-24-69
CF	CF-99-22	LANDING GEAR SELECTOR VALVE	A8-32-145
2110 0		( DHC 8 100 SERIES )	
DHC 8	102 CF-92-12	LOW PRESSURE FUEL SWITCH ADAPTOR	A8-73-14 R3
CF	CF-93-05R1	HORIZONTAL STABILIZER MIDDLE SPAR ATTACH BOLT	A8-55-18
CF	CF-93-31	ALUMINUM WASHERS IN DC FIREWALL TERMINAL BLOCK	8-24-47 REV A 8-73-18
CF	CF-94-09	EEC LIGHTNING STRIKES INSPECTION OF FUSELAGE FRAMES	8-53-48
CF CF	CF-94-17 CF-94-22R1	TITEDY TEMPERATURE MONITOR	8-24-53
CF	CF-94-25R1	THERMAL INSULATION BLANKETS	8-21-68
CF	CF-94-26R1		8-21-66 REV B A8-27-73
CF	CF-95-06	• · · · · · · · · · · · · · · · · · · ·	8-33-35
CF CF	CF-95-18R1 CF-97-01R2	AHRS	A8-34-117 REV. C
CF	CF-98-01	HORIZONTAL STABILIZER DISBOND	
CF	CF-98-04		8-27-79 REV A
CF	CF-98-08R1	UNDERFLOOR WIRING	8-53-66

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

DEHAVI	NOWERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF
	I I AND			
DHC 8	LLAND	( 5116	0.400 050750 )	
(CONIT IN	NUED / SUITE)	( DHC	8 100 SERIES )	
CF	CF-98-30		LADDED DIATES	
CF	CF-98-33		LADDER PLATES	
CF			EMERGENCY LIGHT SWITCH AUTHORITY RUDDER FEEL ASSEMBLY SPRING	8-33-40
CF			RODDER FEEL ASSEMBLY SPRING	A8-27-82
'	CI . 23 . 30		BETA BACK-UP TEST SWITCH WRONG PART NUMBER	A8-61-30RB
DHC 8	103	( DHC	8 100 SERIES )	
	CF-92-12	( )	LOW PRESSURE FUEL SWITCH ADAPTER	40 70 44 00
CF	CF-93-05R1		HORIZONTAL STABILIZED MIDDLE SDAD ATTACH DOLT	A8-73-14 R3
CF	CF-93-31		HORIZONTAL STABILIZER MIDDLE SPAR ATTACH BOLT ALUMINUM WASHERS IN DC FIREWALL TERMINAL BLOCK	8-24-47 REV A
CF	CF-94-09		EEC LIGHTNING STRIKES	8-73-18
CF	CF-94-09 CF-94-17		INSPECTION OF FUSELAGE FRAMES	8-53-48
CF	CF-94-22R1		BATTERY TEMPERATURE MONITOR	
CF	CF-94-25R1		THERMAL INSULATION BLANKETS	8-21-68
CF	CF-94-26R1		THERMAL INSULATION BLANKETS - REAR FUSELAGE	8-21-66 REV B
CF	CF-95-06		STALL WARNING SYSTEM	A8-27-73
CF	CF-95-18R1		CEILING LIGHTING SYSTEM	
CF	CF-97-01R2		AHRS	A8-34-117 REV C
CF	CF-98-01		HORIZONTAL STABILIZER DISBOND	
CF	CF-98-04		LINCOMMUNICED DOLL DECOMPLETE	8-27-79 REV A
CF	CF-98-08R1		UNDERFLOOR WIRING	8-53-66
CF	CF-98-30		LADDER PLATES	
CF	CF-98-33		EMERGENCY LIGHT SWITCH AUTHORITY	8-33-40
CF	CF-98-39R1		RUDDER FEEL ASSEMBLY SPRING	A8-27-82
CF	CF-99-30		BETA BACK-UP TEST SWITCH WRONG PART NUMBER	A8-61-30RB
DIIIO O	400			
DHC 8		( DHC	8 100 SERIES )	
	CF-93-05R1		HORIZONTAL STABILIZER MIDDLE SPAR ATTACH BOLT	A8-55-18
CF	CF-93-31		ALUMINUM WASHERS IN DC FIREWALL TERMINAL BLOCK	8-24-47 REV A
CF	CF-94-09		EEC LIGHTNING STRIKES	8-73-18
CF	CF-94-22R1		BATTERY TEMPERATURE MONITOR	8-24-53
CF CF	CF-94-25R1		THERMAL INSULATION BLANKETS	8-21-68
CF	CF-95-06		STALL WARNING SYSTEM	A8-27-73
	CF-97-01R2 CF-98-04		AUKS	A8-34-117 REV C
	CF-98-04 CF-98-08R1		UNCOMMANDED ROLL DISCONNECTS	8-27-79 REV A
CF	CF-08-30		UNDERFLOOR WIRING	8-53-66
CF	CF-98-30 CF-98-33		LADDER PLATES	
	CF-98-33 CF-98-39R1		EMERGENCY LIGHT SWITCH AUTHORITY	8-33-40
	CF-98-39K1 CF-99-30		RODDER FEEL ASSEMBLY SPRING	A8-27-82
	. 55 50		BETA BACK-UP TEST SWITCH WRONG PART NUMBER	A8-61-30RB
DHC 8	200 SERIES			
	CF-85-07R1		LIMITATION OF FLAP OPERATION	8-27-7
CF	CF-86-01R1		ELEVATOR MASS BALANCE	9/04C9 MOD
CF	CF-86-02		ELEVATOR TRIM ACTUATOR - DRAIN HOLES	9-27-45
CF	CF-86-11R2		GROUND AND ROLL CONTROL SPOILERS	8-27-15 A8-27-25
CF	CF-86-13R1		MAIN LANDING GEAR -COLLAPING	A8-32-20
CF	CF-86-15			8-55-7
CF	CF-87-07R1		RUDDER HINGE BRACKET LAVATORY DOOR LABELLING	8-11-14
	CF-87-09		MLG YOKE FUSE PINS	0 11-14
CF				
CF	CF-88-05		DIGITAL AIR DATA COMPUTER	8-32-56 8-34-45
CF CF	CF-88-13		DIGITAL AIR DATA COMPUTER ALTERNATE FEATHER SWITCHES	8-34-45
CF CF	CF-88-13 CF-88-15		ALTERNATE SEATURE SUFFICIES	8-34-45
CF CF CF	CF-88-13			8-34-45 8-61-10 23088-00X,04 SIL
CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFF STRAPS	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A
CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFF STRAPS	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A
CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A
CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-89-18R1		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47
CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-89-18R1 CF-91-34	ľ	ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFF STRAPS	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A
CF CF CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-91-34 CF-91-34 CF-93-01R1	, , , , , , , , , , , , , , , , , , ,	ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY LAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP MICROWAVE LANDING SYSTEM LAP BALLSCREWS	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A
CF CF CF CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-89-18R1 CF-91-34		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS VALUE - LUCAS VAL	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47
CF CF CF CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-91-34 CF-91-34 CF-93-01R1		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP MICROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD CHERMAL INSULATION BLANKETS	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34
CF CF CF CF CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-91-34 CF-91-34 CF-93-01R1 CF-94-08R1 CF-96-14		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS VALUE - LUCAS VAL	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34
CF CF CF CF CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-18R1 CF-91-34 CF-93-01R1 CF-94-08R1 CF-95-15 CF-96-14 CF-96-20R2	P	ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP MICROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD PHERMAL INSULATION BLANKETS NLG DRAG STRUT PIVOT TUBE FUEL/DEFUEL TUBE ASSEMBLIES DOCKPIT DOOR ALTERNATE RELEASF	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20
CF CF CF CF CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-18R1 CF-91-34 CF-93-01R1 CF-94-08R1 CF-95-15 CF-96-14 CF-96-20R2 CF-97-14	P	ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP MICROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD PHERMAL INSULATION BLANKETS NLG DRAG STRUT PIVOT TUBE FUEL/DEFUEL TUBE ASSEMBLIES DOCKPIT DOOR ALTERNATE RELEASF	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39
CF CF CF CF CF CF CF CF CF CF CF CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-91-34 CF-93-01R1 CF-94-08R1 CF-95-15 CF-96-14 CF-96-20R2 CF-98-05		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP AICROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD PHERMAL INSULATION BLANKETS NLG DRAG STRUT PIVOT TUBE UUEL/DEFUEL TUBE ASSEMBLIES COCKPIT DOOR ALTERNATE RELEASE VIRE CHAFING-LAVATORY SIDEWALL	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39 8-24-50
CF C	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-91-34 CF-93-01R1 CF-94-08R1 CF-95-15 CF-96-14 CF-96-14 CF-96-20R2 CF-97-14 CF-98-05 CF-98-26		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP MICROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD PHERMAL INSULATION BLANKETS NLG DRAG STRUT PIVOT TUBE FUEL/DEFUEL TUBE ASSEMBLIES DOCKPIT DOOR ALTERNATE RELEASF	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39 8-24-50 A8-32-139
CF C	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-89-18R1 CF-91-34 CF-93-01R1 CF-94-08R1 CF-96-14 CF-96-14 CF-96-20R2 CF-97-14 CF-98-05 CF-98-05 CF-98-05 CF-98-26 CF-98-32R1		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP MICROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD IHERMAL INSULATION BLANKETS WLG DRAG STRUT PIVOT TUBE FUEL/DEFUEL TUBE ASSEMBLIES COCKPIT DOOR ALTERNATE RELEASE WIRE CHAFING-LAVATORY SIDEWALL WHEEL BRAKE SHUTTLE VALVES	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39 8-24-50
CF C	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-91-34 CF-93-01R1 CF-94-08R1 CF-95-15 CF-96-14 CF-96-14 CF-96-20R2 CF-97-14 CF-98-05 CF-98-26		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP AICROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD THERMAL INSULATION BLANKETS NLG DRAG STRUT PIVOT TUBE UUL/DEFUEL TUBE ASSEMBLIES TOCKPIT DOOR ALTERNATE RELEASE AIRE CHAFING-LAVATORY SIDEWALL WHEEL BRAKE SHUTTLE VALVES MLG UPLOCK ACTUATOR MOD WEIGHT AND BALANCE	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39 8-24-50 A8-32-139 8-32-139 8-32-98
CF C	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-99-18R1 CF-91-34 CF-93-01R1 CF-94-08R1 CF-95-15 CF-96-14 CF-96-20R2 CF-97-14 CF-98-26 CF-98-32R1 CF-98-32R1 CF-99-10R1		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP ATCROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD HERMAL INSULATION BLANKETS WILL DEFULL TUBE ASSEMBLIES COCKPIT DOOR ALTERNATE RELEASE WIRE CHAFING-LAVATORY SIDEWALL WHEEL BRAKE SHUTTLE VALVES WILL UPLOCK ACTUATOR MOD WEIGHT AND BALANCE WILL OF ARRIAGE HOOK ROLLER SHAFTS CORROSION	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39 8-24-50 A8-32-139 8-32-139 8-32-98 1-82-7 TR AWL 2-16
CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-99-18R1 CF-91-34 CF-93-01R1 CF-94-08R1 CF-96-15 CF-96-14 CF-96-20R2 CF-97-14 CF-98-05 CF-98-26 CF-98-32R1 CF-99-10R1 CF-99-15R1 CF-99-18		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY **LAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP MICROWAVE LANDING SYSTEM **FLAP BALLSCREWS **SU PRINTED CIRCUIT BOARD IHERMAL INSULATION BLANKETS **WLG DRAG STRUT PIVOT TUBE **FUEL/DEFUEL TUBE ASSEMBLIES **SUCKPIT DOOR ALTERNATE RELEASE **VIRE CHAFING-LAVATORY SIDEWALL **WHEEL BRAKE SHUTTLE VALVES **MLG UPLOCK ACTUATOR MOD **VIEIGHT AND BALANCE** **LAP CARRIAGE HOOK ROLLER SHAFTS CORROSION **WORLDON'AL STABILIZER SKIN DISBONDING	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39 8-24-50 A8-32-139 8-32-139 8-32-139 8-32-98
CF	CF-88-13 CF-88-15 CF-88-24 CF-89-02 CF-89-03 CF-89-09R4 CF-99-18R1 CF-91-34 CF-93-01R1 CF-94-08R1 CF-95-15 CF-96-14 CF-96-20R2 CF-97-14 CF-98-26 CF-98-32R1 CF-98-32R1 CF-99-10R1		ALTERNATE FEATHER SWITCHES STARTER - GENERATOR - LUCAS WARDROBE ASSY FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR ASYMMETRIC FLAP ATCROWAVE LANDING SYSTEM FLAP BALLSCREWS PSU PRINTED CIRCUIT BOARD HERMAL INSULATION BLANKETS WILL DEFULL TUBE ASSEMBLIES COCKPIT DOOR ALTERNATE RELEASE WIRE CHAFING-LAVATORY SIDEWALL WHEEL BRAKE SHUTTLE VALVES WILL UPLOCK ACTUATOR MOD WEIGHT AND BALANCE WILL OF ARRIAGE HOOK ROLLER SHAFTS CORROSION	8-34-45 8-61-10 23088-00X,04 SIL 8-25-35 REV A 8-57-10 8-32-79 REV A 8-54-16,8-27-47 8-34-60 REV A A8-33-30RA, 8-33-34 8-32-131 A8-28-20 8-52-39 8-24-50 A8-32-139 8-32-139 8-32-98 1-82-7 TR AWL 2-16

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

			BULLETIN DE SERVICE DE REF
05//4//	T 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		
	ILLAND		
DHC 8	3 200 SERIES		
(CONT I	NUED / SUITE)		
CF	CF-99-30	BETA BACK-UP TEST SWITCH WRONG PART NUMBER	A8 C4 2000
		SWITCH WICHAIT AND NOMBER	A8-61-30RB
DHC 8	3 201	( DHC 8 200 SERIES )	
	CF-97-01R2		
CF	CF-98-04		A8-34-117 REV C
CF	CF-98-08R1	THE THE PERSON NAME OF STREET	8-27-79 REV A
CF	CF-98-30	UNDERFLOOR WIRING	8-53-66
Cr	CF -98-30	LADDER PLATES	
CF	CF-98-33	EMERGENCY LIGHT SWITCH AUTHORITY	8-33-40
CF	CF-98-39R1	RUDDER FEEL ASSEMBLY SPRING	A8-27-82
	3 202	( DHC 8 200 SERIES )	
CF	CF-97-01R2		A8-34-117 REV C
CF	CF-98-04	UNCOMMANDED ROLL DISCONNECTS	8-27-79 REV A
CF	CF-98-08R1	UNDERFLOOR WIRING	8-53-66
CF	CF-98-30	LADDER PLATES	8-53-66
CF	CF-98-33		
CF	CF-98-39R1	EMERGENCY LIGHT SWITCH AUTHORITY	8-33-40
CI	CF - 96 - 39R I	RUDDER FEEL ASSEMBLY SPRING	A8-27-82
Dura	000 055555		
	300 SERIES		
CF	CF-85-06R3		
CF	CF-85-07R1	LIMITATION OF FLAP OPERATION	8-27-7
CF	CF-86-01R1	ELEVATOR MASS RALANCE	0/0400 MOD
CF	CF-86-02	ELEVATOR TRIM ACTUATOR - DRAIN HOLES	8-27-15
CF	CF-86-11R2	ELEVATOR TRIM ACTUATOR - DRAIN HOLES GROUND AND ROLL CONTROL SPOILERS	18-27-25
CF	CF-86-13R1	MAIN LANDING GEAR -COLLAPING	A8-27-25 A8-32-20
CF	CF-86-15		
CF	CF-86-15 CF-87-07R1	RUDDER HINGE BRACKET LAVATORY DOOR LABELLING	8-55-7
			8-11-14
CF	CF-87-09	MLG YOKE FUSE PINS	8-32-56
CF	CF-88-05	DIGITAL AIR DATA COMPUTER	8-34-45
CF	CF-88-13	ALTERNATE FEATHER SWITCHES	8-61-10
CF	CF-88-15	STARTER - GENERATOR - LUCAS	23088-00X,04 SIL
CF	CF-88-24	WARDROBE ASSY	8-25-35 REV A
CF	CF-89-01R1	ENGINE FIRE EXTINGUISHING SYSTEM	A8-26-7
CF	CF-89-02	FLAP TRACK NO 5 FAIL SAFE STRAPS	8-57-10
CF	CF-89-03	FLAP TRACK NO 5 FAIL SAFE STRAPS MAIN LANDING GEAR UPLOCK ACTUATOR	8-32-79 REV A
CF	CF-89-09R4	ASYMMETRIC FLAP	0-E4-10 0-07-47
CF	CF-09-09R4	ASYMMETRIC FLAP PRECOOLER LUG FAILURE	0-34-10,0-27-47
	CF-89-16		A8-21-32
CF	CF-89-18R1	MICROWAVE LANDING SYSTEM	8-34-60 REV A
CF	CF-91-07R1	FLIGHT CREW OXYGEN	A8-35-5 REV A
CF	CF-91-25R2	MAIN LANDING GEAR RETRACTION ACTUATOR BRACKETS	8-54-27RB & 8-54-34A
CF	CF-91-34	FLAP BALLSCREWS	
CF	CF-92-09	HYD SYS PRESS - QUANTITY LIMITING VALVE (QLV)	8-29-21
CF	CF-92-14	ENGINE MOUNT STRUT	8-71-17
CF	CF-92-18R3	NLG DRAG STRUT FITTING	A8-53-40RA & 8-53-49
CF	CF-92-20	DC POWER CABLES	A8-24-44
CF	CF-93-01R1	PSU PRINTED CIRCUIT BOARD	A8-33-30RA, 8-33-34
CF		POWER SUPPLY - WHITE ANTI-COLLISION LIGHTS	8-33-19
	CF-93-20	THERMAL INSULATION BLANKETS	0 00 10
CF	CF-94-08R1		9-54-10 6 74 10
CF	CF-94-10R1	ENGINE NACELLE AREA SEALING	8-54-12, 8-71-19
CF	CF-95-15	NLG DRAG STRUT PIVOT TUBE	8-32-131
CF	CF-96-14	FUEL/DEFUEL TUBE ASSEMBLIES	A8-28-20
CF	CF-96-20R2	COCKPIT DOOR ALTERNATE RELEASE	8-52-39
CF	CF-96-25R2	HYDRAULIC SYSTEMS MODIFICATIONS	8-32-128, 8-29-23
CF	CF-97-14	WIRE CHAFING-LAVATORY SIDEWALL	8-24-50
CF	CF-98-05	WHEEL BRAKE SHUTTLE VALVES	A8-32-139
CF	CF-98-24	HORIZONTAL STABILIZER SKIN PANELS	
CF	CF-98-26	MLG UPLOCK ACTUATOR MOD	8-32-98
		BONDING INTEGRITY INSPECTIONS	8-51-2
CF	CF-98-31	WEIGHT AND BALANCE	- 0 - 2
CF	CF-98-32R1		1-83-7 TR AWL 3-77
CF	CF-99-10R1	FLAP CARRIAGE HOOK ROLLER SHAFTS CORROSION	RD8-55-669 ISSUE 3
CF	CF-99-15R1	HORIZONTAL STABILIZER SKIN DISBONDING	
CF	CF-99-18	POWER LEVER FLT IDLE GATE RECONFIGURATION	REFER TO AD
CF	CF-99-20	WING- FUEL TANK ACCESS PANEL SEAL CHANGE	8-57-41
CF	CF-99-22	LANDING GEAR SELECTOR VALVE	A8-32-145
CF	CF-99-30	BETA BACK-UP TEST SWITCH WRONG PART NUMBER	A8-61-30RB
CF	CL-99-30		
Dillo	224	( DHC 8 300 SERIES )	
	301	PREVENTION OF SUDDEN CABIN DECOMPRESSION	8-25-53
CF	CF-90-26	INTERNAL ENGINE FIRE	8-26-14 & PWC 21113
CF	CF-91-33R3	INTERNAL ENGINE TIME	
CF	CF-92-06R2	FIRE WIRE DETECTION LOOP MODIFICATION	SB 8-26-14 P&W 21113
CF	CF-92-12	LOW PRESSURE FUEL SWITCH ADAPTER	A8-73-14 R3
CF	CF-93-05R1	HORIZONTAL STABILIZER MIDDLE SPAR ATTACH BOLT	A8-55-18
	00 00111		

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER SUBJECT
ORIGINE NUMERO DE CONSIGNE SUJET

ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF
DEHAVIL				
DHC 8	301	( DHC	8 300 SERIES )	
(CONTIN	UED / SUITE)			
CF CF	CF-93-31		ALUMINUM WASHERS IN DC FIREWALL TERMINAL BLOCK	
CF	CF-94-09 CF-94-11		EEC LIGHTNING STRIKES 7.5 AMP CIRCUIT BREAKER	8-73-18
CF	CF-94-22R1			8-74-1
CF	CF-94-25R1		BATTERY TEMPERATURE MONITOR THERMAL INSULATION BLANKETS	8-24-53
CF	CF-94-26R1		THERMAL INJULATION BLANKETS	0-21-68
CF	CF-95-05R1		THERMAL INSULATION BLANKETS - REAR FUSELAGE FLAP RIVETS	8-57-24 REV B
CF			CEILING LIGHTING SYSTEM	8-37-24 REV B
CF	CF-97-01R2			
CF	CF-97-17		OVERHEAD BIN CONNECTOR OVERHEATING	A8-34-117 REV C 8-33-39REV. A 8-27-79 REV A
CF	CF-98-04		UNCOMMANDED ROLL DISCONNECTS	8-27-79 REV A
CF	CF-98-08R1		UNDERFLOOR WIRING	
CF	CF-98-30		LADDER PLATES	
CF	CF 30-33		EMERGENCY LIGHT SWITCH AUTHORITY	8-33-40
CF	CF-98-39R1		RUDDER FEEL ASSEMBLY SPRING	A8-27-82
CF	CF-99-27		UPPER WING ACCESS PANELS	
DHC 8		( DHC	8 300 SERIES )	
	CF-91-15R2		FUEL LEAKS	A8-28-16
CF	CF-91-33R3		INTERNAL ENGINE FIRE FIRE WIRE DETECTION LOOP MODIFICATION LOW PRESSURE FUEL SWITCH ADAPTER	8-26-14 & PWC 21113
CF	CF-92-06R2		FIRE WIRE DETECTION LOOP MODIFICATION	SB 8-26-14 P&W 21113
CF	CF-92-12		LOW PRESSURE FUEL SWITCH ADAPTER	A8-73-14 R3
CF CF	CF-93-05R1		HURIZUNIAL STABILIZER MIDDLE SPAR ATTACH BOLT	A8-55-18
CF	CF-93-10R1		ALLMANUM FAIRING ANGLES	A8-53-46 REV A
0.5			ALUMINUM WASHERS IN DC FIREWALL TERMINAL BLOCK EEC LIGHTNING STRIKES	8-24-47 REV A
CF	CF-94-11		7.5 AMP CIRCUIT BREAKER BATTERY TEMPERATURE MONITOR	8-73-18
CF	CF-94-22R1		RATTERV TEMPERATURE MONITOR	8-74-1
CF	CF-94-25R1		THERMAL INSULATION BLANKETS	8-24-53
CF	CF-94-26R1		THERMAL INSULATION BLANKETS - REAR FUSELAGE	9-21-66 DEV D
CF	CF-95-05R1		FLAP RIVETS	8-57-24 REV B
	CF-97-01R2			19-31-117 DEV C
CF	CF-97-17		AHRS OVERHEAD BIN CONNECTOR OVERHEATING	8-33-30DEN V
CF	CF-97-21R1		DITCHING DAMS	8-25-122
CF	CF-98-04		UNCOMMANDED ROLL DISCONNECTS	8-27-79 REV A
CF	CF-98-08R1		UNDERFLOOR WIRING	
CF	CF-98-30		LADDER PLATES	
CF	CF-98-33		EMERGENCY LIGHT SWITCH AUTHORITY	8-33-40
CF	CF-98-39R1		RUDDER FEEL ASSEMBLY SPRING	A8-27-82
DHC 8		( DHC	8 300 SERIES )	
CF	CF-93-05R1		HORIZONTAL STABILIZER MIDDLE SPAR ATTACH BOLT	
CF	CF-93-31		ALUMINUM WASHERS IN DC FIREWALL TERMINAL BLOCK	8-24-47 REV A
CF CF	CF-94-09 CF-94-11		EEC LIGHTNING STRIKES	8-73-18
CF	CF-94-22R1		7.5 AMP CIRCUIT BREAKER	8-74-1
	CF-94-25R1		BATTERY TEMPERATURE MONITOR THERMAL INSULATION BLANKETS	8-24-53
	CF-94-26R1		THERMAL INSULATION BLANKETS - REAR FUSELAGE	8-21-68
CF	CF-95-05R1		FLAP RIVETS	8-21-66 REV B 8-57-24 REV B
	CF-97~01R2		AHRS	A8-34-117 REV C
CF	CF-97-17		OVERHEAD BIN CONNECTOR OVERHEATING	8-33-39REV. A
	CF-97-21R1		DITCHING DAMS	8-25-122
CF	CF-98-04		UNCOMMANDED ROLL DISCONNECTS	8-27-79 REV A
	CF-98-08R1		UNDERFLOOR WIRING	8-53-66
CF	CF-98-30		LADDER PLATES	
	CF-98-33		EMERGENCY LIGHT SWITCH AUTHORITY	8-33-40
CF	CF-98-39R1		RUDDER FEEL ASSEMBLY SPRING	A8-27-82
		,		
DHC 8 :			8 300 SERIES )	
	CF-93-10R1		TITANIUM FAIRING ANGLES	A8-53-46 REV A
	CF-94-22R1		BATTERY TEMPERATURE MONITOR	8-24-53
	CF-94-25R1		THERMAL INSULATION BLANKETS	8-21-68
	CF-94-26R1		THERMAL INSULATION BLANKETS - REAR FUSELAGE	8-21-66 REV B
CF	CF-95-05R1 CF-97-01R2		FLAP RIVETS	8-57-24 REV B
	CF-97-01K2		AHRS	A8-34-117 REV C
	CF-97-17 CF-97-21R1		OVERHEAD BIN CONNECTOR OVERHEATING	8-33-39REV. A
	CF-98-04		DITCHING DAMS	8-25-122
	CF-98-08R1		UNCOMMANDED ROLL DISCONNECTS	
	CF-98-30		UNDERFLOOR WIRING LADDER PLATES	8-53-66
	CF-98-33		EMERGENCY LIGHT SWITCH AUTHORITY	9-22-40
	CF-98-39R1		RUDDER FEEL ASSEMBLY SPRING	8-33-40
			TOTAL TEEL ASSEMBLY SEATING	A8-27-82

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

REFERENCE SERVICE BULLETIN

	NE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
	ILLAND 8 400		
	8 401		
DHC	8 402		
DI AM A			
DIAMO			
DA 20 CF	CF-96-07	INSPECT FOR AILERON CONTROL ROD BLOCKAGE	DAGO E7 00
CF	CF-97-09	RUDDER PEDAL JAMMING	DA20-57-02 DA20-53-01A
DA 20	O C1		
DV20	77		
AS AS	77 86	ALTERATIONS TO EXHAUST ENDPIPE CRACKS IN NOSE WHEEL LEG	20-7/1
CF	CF-97-10	RUDDER PEDAL JAMMING	20-32
DORNIE			
<b>DO27</b> GY	<b>Q6</b> 63~079	ELEVATOR	TB 27-1 & 27-13
GY	64-011	FLAPS-UNINTENTIONAL DEPLOY	TB 27-18
GY GY	64-024 65-008	FRAME # 3 CRACKS OF WEB PLATE WIRE ARMOURED HOSES	TB 27-24
GY	65-085	FUEL AND OIL HOSES	TB 27-27 TB 27-29
GY	68-126	FUEL TANK	TB 27-31
GY GY	69-011/2	ELEVATOR OUTBOARD HINGE BEARINGS	TB 27-28C
GY	69-012 75-233	FUSELAGE FRAME 5 CRACKS FUEL AND OIL HOSES INSP.	TB 27-33 1059-0000
GY	79-249	TACHOMETER	KL 12/L/1067
GY	88-109/2	FLIGHT CONTROL WING FLAP POSITION	1116-0000 &1123-0000
GY	96-271	RIVET INSPECTION-HORIZ TAIL BEARING-FITTING	1140-0000
DO28 CF	B1 CF-79-25	HORIZONTAL STABILIZER TRIM	2068-0000
GΥ	63-021	ELECTRICAL HARNESS	TM 28-6
GY	63-078/2	ELECTRICAL HARNESS	TM 28/1A & 28/8
GY GY	64-011 65-085	FLIGHT CONTROLS/FLAP CONTROL LEVER FUEL AND OIL HOSES	TM 28/1A & 28/8 TM 28-28
GY	66-93	HINGE BRACKETS - HORIZONTAL STABILIZER FRONT SPAR	
GY	68-120	HORIZONTAL STABILIZER HINGE FITTING	28-44A
GY	68-132	ELEVATOR OUTBOARD HINGE FITTING	28-56 28-46
GY GY	68-2 68-3	HORIZONTAL STABILIZER CORRISION - WING SKIN, SLAT, SPAR, SPAR CAP	28-46
GY	68-4	STABILIZER TRIM CABLE DRUM GUARD	28-38A
GY	68-5	HORIZONTAL STABILIZER CONTROL CABLE DRUM	28-33
GY GY	68-6	FUEL TANK - CURTIS VALVE & DRAIN PLUG ELEVATOR TRIM CONTROL CABLE DRUM	28-32
GY	68-7 75-233	HOSES - FUEL & OIL SYSTEM	1059-0000
228 2	202		
GY	89-107	ELECTRICAL-ESSENTIAL BUS MOD	228-143 228-148
GY GY	89-156 90-181/2	NOSE WHEEL STEERING TRIM RELAYS	228-148
GY	90-181/2	GROUND CONNECTION WING/FUSELAGE	228-162
GY	90-294	STARTER GENERATOR	228-173
GY	92-188	WIRING HARNESS HORIZONTAL STABILIZER RIB CRACKING	228-192 228-211R3
GY GY	95-175/2 95-246	LANDING GEAR WARNING	
GY	1998-141/2	LANDING GEAR ACTUATOR	228-226R1
GY	1999-030/2	WINDSHIELD SPRAY NOZZLE	AOT228-30-022
DOUGLA			
26 SE US	RIES 47-36-01	WING FITTING REWORK	
US	47-36-01	OIL SCREEN REPLACEMENT	
US	55-26-01	FUSELAGE FUEL TANK MODIFICATION	
US	56-18-03	NOSE WHEEL CROSS BEAM WING STRUCTURE CORROSION	
US US	61-11-05 64-12-03	WING SPAR CAPS	
US	84-15-02	WING INFLIGHT STRUCTURE	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

ORIGINE NUMERO DE CONSIGNE		SUJET	DOCCETION DE GENTION DE MAIN
			1
DOUGLAS			
A26B	( 26	SERIES )	
		CENTEC )	
A26C	( 26	SERIES )	
BACB	( 26	SERIES )	
B26B	( 26	SERIES /	
B26C	( 26	SERIES )	
BZGC	( 20		}
DC3 SERIES			
CF CF-50-06		FUEL COCK SELECTOR	
CF CF-55-05		ENGINE AND TRIM CABLES	
CF CF-83-17		SHUT-OFF VALVES	250,252,258,259
CF CF-92-15		CRACKING WING ATTACHMENT	229 OR 263
US 41-47-01		CONTROL SURFACE REBALANCE	207
US 43-12-01		ELEVATOR HINGE BRACKETS	
US 46-12-02		ENGINE MOUNT FITTINGS	238
US 46-13-04		LANDING GEAR BRACE STRUT FITTINGS	233
US 46-13-05		CANVAS CONTROL BOOT	231
US 46-43-02		RUDDER PEDAL SLIDE TUBE SUPPORT BOLT	C-47-101
US 47-06-07		FIRE EXTINGUISHER TRIGGER	246
US 47-33-02		COWL FLAP HYDRAULIC LINES	054
US 47-51-12		CARBURETOR AIRSCOOP	251
US 48-05-01		OIL SHUTOFF VALVE "O" RINGS	256
US 48-17-01		FIRE PREVENTION MODIFICATIONS	250, 252, 258, 259
US 50-46-01		OIL TANK STANDPIPE RAMP TYPE DOOR REWORK	MAP-4A, 5A, -6A
US 51-02-01		VACUUM SYSTEM REWORK	A-129-T-1271/WB-11Q4
US 52-25-01		LANDING GEAR AXLE	A 125 1 12/1/WD 11Q4
US 56-14-02 US 56-20-05		PROPELLER OPERATING LIMITS	
US 58-04-01		"AIRSTAIR" DOOR SAFETYING	
US 58-08-03		CB FIRE EXTINGUISHER SYSTEM	
US 60-16-03		GEARED RUDDER TAB	
US 63-23-01		WING ATTACH ANGLES AND DOUBLERS	262 R1 14/6/63
US 66-18-02		WING ATTACH ANGLES AND DOUBLERS	262 R1 14/6/63
US 68-07-05		ELEVATOR RIBS	244
US 77-10-02		FIRE RESISTANT PROP FEATHERING SYSTEM	
US 78-18-02		ELEVATOR CONTROL SYSTEM	
US 90-05-08		PRINCIPAL STRUCTURAL ELEMENTS	DC 3 (SID) R1 JAN 90
US 98-04-35		OPERATING IN SEVERE ICING CONDITIONS - LIMITATIONS	
US 98-14-14		POSITIONING OF POWER LEVERS BELOW FLT IDLE STOP	AFM
DC3A	( DC3	SERIES )	
DC3AS1C3G	( DC3	SERIES )	
DC3C	( DC3	SERIES )	
DC3CR1830	( DC3	SERIES )	
DC3CS1C3G	( DC3	SERIES )	
DC3CS4C4G	( DC3	SERIES )	
DC3G202A	( DC3	SERIES )	
CAT CERTES			
C47 SERIES		CONTROL SUBSACE REPAI ANCE	207
US 41-47-01		CONTROL SURFACE REBALANCE ELEVATOR HINGE BRACKETS	201
US 43-12-01		ENGINE MOUNT FITTINGS	238
US 46-12-02		LANDING GEAR BRACE STRUT FITTINGS	233
US 46-13-04 US 46-13-05		CANVAS CONTROL BOOT	231
US 46-43-02		RUDDER PEDAL SLIDE TUBE SUPPORT BOLT	C-47-101
US 47-06-07		FIRE EXTINGUISHER TRIGGER	246
US 47-33-02		COWL FLAP HYDRAULIC LINES	
US 47-51-12		CARBURETOR AIRSCOOP	251
US 48-05-01		OIL SHUTOFF VALVE "O" RINGS	256
US 48-17-01	************************	FIRE PREVENTION MODIFICATIONS	250, 252, 258, 259
US 50-46-01		OIL TANK STANDPIPE	
US 51-02-01		RAMP TYPE DOOR REWORK	MAP-4A, -5A, -6A
US 52-25-01			A-129-T-1271/WB-11Q4
US 56-14-02		LANDING GEAR AXLE	
US 56-20-05		PROPELLER OPERATING LIMITS	
US 58-04-01		"AIRSTAIR" DOOR SAFETYING	
US 58-08-03		CB FIRE EXTINGUISHER SYSTEM	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)

ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
DOUGLAS		
C47 SERIES		
(CONTINUED / SUITE) US 60-16-03	CEADED DUODED TAD	
US 63-23-01	GEARED RUDDER TAB WING ATTACH ANGLES AND DOUBLERS	200 24 44/0/00
US 66-18-02	WING ATTACH ANGLES AND DOUBLERS	262 R1 14/6/63 262 R1 14/6/63
US 68-07-05	ELEVATOR RIBS	244
US 77~10-02 US 78-18-02	FIRE RESISTANT PROP FEATHERING SYSTEM	
US 90-05-08	ELEVATOR CONTROL SYSTEM PRINCIPAL STRUCTURAL ELEMENTS	20 0 (212) 21 111 00
		DC 3 (SID) R1 JAN 90
C47A	( C47 SERIES )	
R4D SERIES	CONTROL CURRENT TO THE CONTROL	
US 41-47-01 US 43-12-01	CONTROL SURFACE REBALANCE ELEVATOR HINGE BRACKETS	207
US 46-12-02	ENGINE MOUNT FITTINGS	238
US 46-13-04	LANDING GEAR BRACE STRUT FITTINGS	233
US 46-13-05	CANVAS CONTROL BOOT	231
US 46-43-02 US 47-06-07	RUDDER PEDAL SLIDE TUBE SUPPORT BOLT FIRE EXTINGUISHER TRIGGER	C-47-101
US 47-33-02	COWL FLAP HYDRAULIC LINES	246
US 47-51-12	CARBURETOR AIRSCOOP	251
US 48-05-01	OIL SHUTOFF VALVE "O" RINGS	256
US 48-17-01 US 50-46-01	FIRE PREVENTION MODIFICATIONS	250, 252, 258, 259
US 51-02-01	OIL TANK STANDPIPE RAMP TYPE DOOR REWORK	MAP-4A, -5A, -6A
US 52-25-01	VACUUM SYSTEM REWORK	A-129-T-1271/WB-11Q4
US 56-14-02	LANDING GEAR AXLE	
US 56-20-05	PROPELLER OPERATING LIMITS	
US 58-04-01 US 58-08-03	"AIRSTAIR" DOOR SAFETYING CB FIRE EXTINGUISHER SYSTEM	
US 60-16-03	GEARED RUDDER TAB	
US 63-23-01	WING ATTACH ANGLES AND DOUBLERS	262 R1 14/6/63
US 66-18-02	WING ATTACH ANGLES AND DOUBLERS	262 R1 14/6/63
US 68-07-05 US 77-10-02	ELEVATOR RIBS FIRE RESISTANT PROP FEATHERING SYSTEM	244
US 78-18-02	ELEVATOR CONTROL SYSTEM	
US 90-05-08	PRINCIPAL STRUCTURE ELEMENTS	DC 3 (SID) R1 JAN 90
R4D 8	( R4D SERIES )	
C54 SERIES		
US 46-11-02	OXYGEN REGULATOR RELOCATION	C-54-247
US 46-11-03	LANDING GEAR DOOR STUD	C-54-275
US 46-24-02 US 46-27-01	REVISION OF MAGNETO WIRES SPAR WEB REINFORCEMENTS	C-54-283 C-54-205
US 46-27-01 US 46-27-02	NOSE WHEEL BRACE STRUT COLLAR	C-54-209S
US 46-39-03	MAGNETO WIRES INSPECTION	
US 46-39-04	FUEL TANK VALVE REWORK	20 4 5
US 46-39-05	FUEL LINE SUPPORTING BRACKETS FXHAUST COLLECTOR RING BOLTS	DC-4-5 DC-4 ND.10
US 47-02-01 US 47-02-02	STABILIZER ATTACH FITTINGS AND BOLTS	DC-4 NO.11
US 47-02-03	ACCUMULATOR REPLACEMENT	DC-4 NO.9
US 47-02-04	ENGINE PRIMER SOLENOID	C-54-266
US 47-02-05	ELECTRICAL SYSTEM INSPECTION	DC-4 ND.3
US 47-02-06 US 47-12-01	HYDRAULIC HAND PUMP SHUTOFF VALVE SEAL FUSELAGE OPENINGS	DC-4 NO.32
US 47-12-01	CENTER MAIN BEARINGS	
US 47-16-01	CIRCUIT BREAKERS	
US 47-16-02	18-GAGE WIRE IN OIL DILUTION SOLENOID	
US 47-27-02	SPAR WEB INSPECTION - TANK AREA EXHAUST COLLECTOR RING "Y"	DC-4 NO.68
US 47-27-04 US 47-33-01	STABILIZER HINGE BRACKETS	DC-4 NO.73
US 47-42-01	GUST LOCK REWORK	DC-4 NO.79
US 47-42-02	COWLING FIRE SEAL	DC-4 NO.19
US 47-42-03	FIRE PREVENTION CHANGES	GOODYEAR NO.1
US 48-01-01 US 48-02-02	GOODYEAR WHEEL REWORK FIRE DETECTOR CLAMP	DC-4 NO.75
US 48-03-02	EMERGENCY AIR BRAKE	
US 48-06-05	CONTROL SURFACE ATTACHMENT REWORK	DC-4 NO.83
US 48-09-01	FUEL TRANSFER PLACARD	
US 48-09-02	ELECTRICAL DISTRIBUTION BUS FIRE PREVENTION REQUIREMENTS	
US 48-12-01 US 48-12-02	NOSE AND CABIN HEATER REWORK	DC-4 NO.47
30 10 12 02		

MAKE / CONSTRUCTEUR MODEL / MODELE	(SERIES / SERIE)	
ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
DOUGLAS		
C54 SERIES (CONTINUED / SUITE)		
US 48-14-04	TAILPIPE SHROUD DEFLECTOR	C-54-289
US 48-15-03	HYDRAULIC PRESSURE REGULATOR REWORK	C-54-239
US 48-17-04	PESCO VACUUM PUMPS	DC-4 NO.85
US 48-25-01	FIRE WARNING SYSTEM	DC-4 NO.67
US 48-28-02 US 48-44-01	CABIN HEATER COMBUSTION DUCTS NOSE GEAR ORFICE FITTING	DC-4 NO.78
US 49-27-03	NOSE GEAR YOKE END FITTINGS	55 , ,,,,,,,
US 49-38-02	BOLT REPLACEMENT	
US 49-46-01	VACUUM SYSTEM FUSIBLE PLUG	A-129-T-1271/WB-11Q4
US 51-09-02	HINGE BRACKETS AND BOLTS GENERATOR COOLING FAN	ECLIPSE-PIONEER 505
US 53-19-01 US 56-20-05	PROPELLER OPERATING LIMITS	ECETPSE / TONEER 303
US 57-16-01	NOSE GEAR PISTON TUBE	DC-4 NO.111
US 62-26-01	ENGINE-PROP OPERATING RESTRICTIONS	
US 77-10-01	FIRE RESISTANT PROP FEATHERING SYSTEM	
US 85-23-04	LH/RH ELEVATOR TRIM TAB INSP	
C54A	( C54 SERIES )	
C54BDC	( C54 SERIES )	
C54DDC	( C54 SERIES )	
C54EDC	( C54 SERIES )	
C54GDC	( C54 SERIES )	
DC6 SERIES		
US 47-42-05	CURTAIN HOOK REPLACEMENTS	15
US 47-42-06 US 47-42-07	FIRE EXTINGUISHER PLACARD WINDSHIELD HANDLE SPRING	18 19
US 47-42-08	HORIZONTAL STABILIZER RIVETS	A-214-529.010/RLT
US 47-42-09	OVERSIDE AILERON HINGE PLATES	A-214-529.004/RLT
US 47-42-10	LDG GEAR ANTI RETRACT MECHANISM	DWG 7354206 PG 28
US 47-42-11	HORIZONTAL STABILIZER FRONT SPAR CAPS ASTRODROME REINFORCEMENT	45
US 47-42-12 US 47-42-13	GUST LOCK REWORK	75
US 47-42-14	VOLTAGE REGULATOR BEARINGS	43
US 47-42-16	COMBUSTION CHAMBER INSPECTION	
US 47-42-17	WING CENTER SPAR WEB CRACKS	29
US 47-42-19 US 47-51-15	HORIZONTAL STABILIZER FRONT SPAR CAP BRAKE RELINING	1
US 47-51-16	FLAP SUPPORT REWORK	66
US 48-02-04	BRAKE ADJUSTING PIN REPLACEMENT	90
US 48-02-05	OUTBOARD ACCESSORY COWLING REWORK	30
US 48-02-06	INBOARD NACELLE COVER PLATES	92
US 48-07-02 US 48-07-03	ENGINE SUPERCHARGER CONTROL ACTUATOR DOOR REWORK	127
US 48-10-01	UNGROUNDING MODIFICATION - CLASS A	
US 48-11-01	UNGROUNDING MODIFICATION - CLASS B	
US 48-11-02	UNGROUNDING MODIFICATIONS - CLASS C	13, 257, 258
US 48-19-03	ELEVATOR TRIM TAB OPERATING MECHANISM  VACUUM PUMP LINE REPLACEMENT	123 401
US 48-48-02 US 48-49-03	ELECTRICAL CIRCUIT INSPECTION	329
US 48-52-01	ADDITIONAL MODIFICATION ITEMS	220, 259, 255, 256, 272
US 49-06-02	ATTACHMENT BOLT REPLACEMENT	410
US 49-33-01	HAMILTON STANDARD PROPELLER BLADES	A 400 T 1071 (UD1121
US 49-46-01	VACUUM SYSTEM FUSIBLE PLUG PROPELLER REVERSE MECHANISM	A-129-T-1271/WB11Q4 GEN SERV LET 19,23
US 50-16-01 US 50-18-02	ENGINE OPERATION PLACARD	
US 50-23-02	NOSE GEAR YOKE END FITTING	GEN SERV LET 26
US 50-43-01	GOODYEAR L20HBMF WHEEL INSPECTION	
US 51-01-01	INSPECT SPAR FITTINGS	GEN SERV LET 61
US 51-10-01 US 52-14-01	WING FLAP OPERATING LINK PROPELLER REVERSING REWORK	GEN SERV LET 60
US 52-14-01 US 52-18-02	SPAR CAP REWORK	
US 52-20-01	OVERVOLTAGE PROTECTION	470
US 52-27-02	OUTBOARD FRONT SPAR SPLICE PLATE	SERV LET 123
US 52-28-05	CENTER WING LOWER ACCESS HOLE	SERV LET 130
US 53-08-02 US 53-25-01	CENTER WING SKIN & STRINGERS AILERON CONTROL SYSTEM	521 SEV LET 153
US 54-06-01	KIDDIE CO2 DISCHARGE VALVE	GEN SERV LET 176

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT SUJET

			BULLETIN DE SERVICE DE REF.
DOUGLA			
DOUGLA			
	ERIES		
	NUED / SUITE)		
US	54-23-01	FUSELAGE CRACKS	
US	55-09-03	PROP CIRCUIT BREAKER REPLACEMENT	SERV LET 171
US	55-11-01	NOSE GEAR YOKE FND FITTING	607
US	55-15-04	FIRE RESISTANT PROP FEATHERING LINES	
US	55-18-02	PROPELLER REVERSE PROTECTIVE DEVICE WING SKIN AND STRINGER INSPECTION	GEN SERV LET 206
US	56-13-01	WING SKIN AND STRINGED INCOMESTICAL	557
US	58-11-01	MOCE WHEEL DETDACT LAND	A-673
US	58-15-01	NOSE WHEEL RETRACT LINK	A-677
US	58-15-01	SAFETY BELT HOOK ASSEMBLY	A-779
US	58-23-02	STABILIZER SPAR FITTINGS	A-796
US	59-13-06	LOWER FRONT SPAR CAP	A-821
US	60-02-05	SPAR CAP	A-845
US	61-04-02	SPAR CAPS	A-678
US	61-05-02	EMERGENCY EXIT DOOR HINGES	848
US	61-08-01	FUEL TRANSFER	294
US	61-23-04	SPAR CAPS	
US	62-25-02		802
US	63-20-03	MAIN LANDING GEAR SHOCK STRUT CYLINDER	C1-78-140/D0W
US	65-09-02	LOWER CENTER SPAR CAPS	A-849 R1
		MAIN GEAR TORQUE LINKS	C1-78-1311/DJW
US	67-13-02	FUSELAGE INSPECTION	616,617,622,636
US	80-12-02R1	WING FITTINGS, STRINGER, SKIN CRACKS	
US	80-22-07	NOSE GEAR TORQUE LINK	
US	83-20-04	HORIZONTAL STABILIZER REAR SPAR CAPS	
US	88-04-01	VERTICAL STABILIZER REAR SPAR ATTACH FITTINGS	723
US	89-11-07	WING CENTRE SPAR LANDING GEAR FITTING	, 23
US	93-11-07	PRINCIPAL STRUCTURE ELEMENT - NDT	SID L26-014
		THE STREET STREET STREET	310 120-014
DC6A	(	DC6 SERIES )	
DCGA	(	DCO SEKIES )	
0000		200 200 200	
DC6B	(	DC6 SERIES )	
DC9 S	ERIES		
CF	CF-79-17	AFT PRESSURE BULKHEAD	27-251
CF	CF-79-19	AFT PRESSURE BULKHEAD	53-137
CF	CF-85-01	REAR PRESSURE BULKHEAD	
US	67-05-01	DOOR ASSEMBLIES	57-40
US	67-05-02	ENGINE MOUNT	54-4
US	67-07-03	SPERRY SP-50 AUTOPILOT	
		SPERRY SP-50 AUTOFILLS	C1-78-2016/DBA
US	67-25-05	THRUST REVERSER AUTOTHROTTLE SYSTEM	76-15
US	67-27-05	REAR SPAR CAP INSPECTION PYLON AREA	A54-15
US	67-30-05	BATTERY CHARGER	A24-26
US	68-02-05	NOSE GEAR SHOCK STRUT	
US	69-17-01	AUXILIARY POWER UNIT	
US	69-26-06	HEAT DAMAGE TO HE COAXIAL CABLE	A23-24
US	70-09-04	FUEL INTERRUPTION FROM TIRE TREAD	28-16R1
US .	71-01-05	EMERGENCY EVACUATION SLIDE	AOL 9-370
US	71-02-06	EVACUATION SLIDE BAR LATCH	25-150R1
			25-118
US	71-08-01	AFT EVACUATION SLIDE	
US	71-08-02	CONTROL OF SPEED BRAKE	32-120
US	71-11-08	INSTRUMENT PANEL SLIDING AFT	05 110
US	71-15-01	FORWARD CABIN ATTENDANT'S SEAT	25-146
US	71-24-01	CABIN CEILING LIGHT SWITCH	33-56
US	72-03-05	PREVENT JAMMING OF ELEVATOR	55-4, 27-146R1
US	72-09-01	ENGINE MOUNT PYLON FAILURE	
US	72-17-03	RUDDER PEDAL ARM CASTING	27-148
US	74-22-01	ENGINE MOUNTS	AOL 9-786B
			78-36R1
US	75-14-06	THRUST REVERSERS	53-91
US	75-16-03	LANDING GEAR RELEASE SYSTEM	
US	76-01-04	LONGITUDINAL PORPOISING	A27-176
US	76-22-07	FLIGHT ATTENDANT'S SEAT	25-210
US	77-14-19	ENGINE PYLON	54-30
US	78-01-11	EMERGENCY EXIT RELEASE HANDLE	53-134R1
US	78-01-16	ENGINE PYLON SPAR STRAPS	54-31
US	78-04-03	AILERON SPOILER MIXER CAM	A27-189
US		WHEELWELL FRAME FITTINGS	
	78-07-05	STALL WARNING SYSTEM	
US	78-23-06	STALL WARNING STOLEN	57-118
US	79-03-01R1	FLAPS - SUPPORT FITTING ATTACH STUDS	
US	79-10-13	DOOR LOCK CRANK ASSY PARTS	52-111R1
US	79-19-02	ELEVATOR SPARS	55-28R4
US	79-24-01R3	AFT PRESSURE BULKHEAD	A53-127R1
US	80-02-04	AFT PRESSURE BULKHEAD DOOR	
US	80-02-16R1	AUXILIARY EMERGENCY EXIT DOOR	A52-116, -117R1
US	80-03-04	FUEL ACCUMULATION	
	00 00 07		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

			BOLLETIN DE SERVICE DE REF.
DOUGL			
	SERIES		
	INUED / SUITE)		
US	80-05-03	ELEVATOR CONTROL CABLE	25-222R1
US	80-06-04R1	MLG ATTACH FITTINGS	57-125R4
US	80-08-09R1	HORIZONTAL STABILIZER REAR SPARS	A55-31R1
US	81-02-06	CARGO DOOR ATTACH BOLTS	52-119
US	81-10-10R1	GALLEY SERVICE DOORS	52-125, -127
US	81-16-51	CARGO DOORS	A52-130
US	81-25-03	WINDSHIELD HEAT GENERATION	
US	82-03-06	TAIL CONE LOCK HOUSING MOD	53-158
US	82-04-02	RUDDER PEDAL ARM ASSEMBLIES	27-209
US	82-06-02R1	HOR STAB SECTION FITTINGS	
US	82-10-04	LONGITUDINAL TRIM SYSTEM	A27-234
US	82-24-04	DE-ICING SYSTEM	A30-50
US	83-06-03	MLG SUPPORT STRUCTURE	32-186
US	83-15-51	INSULATION MATERIAL	A53-144
US	84-03-06	LG ASSY COMPONENTS	
US	84-03-52R1	MLG DOORS, LATCHES, SHIELDS	27-247
US	84-07-04R1	AFT PRESSURE BULKHEAD	53-174
US	84-21-03	FITTING ASSY (ROD END) INSPECTION	ASB27-266
US	84-22-03	WING HINGE STUDS INSP	A57-162
US	84-26-01	MLG ATTACH FITTINGS	57-148R1
US	85-01-02R1	FUSELAGE CABIN AFT VENTRAL PRESSURE BULKHEAD	53-137R3
US	85-01-03	SPOILER DRIVE LINK AND FITTINGS	27-228, -229
US	85-03-08R1	FUSELAGE SKIN INSP	A53-188
US	85-06-05	BATTERY CHARGERS	24-73
US	85-07-10	FLUSH POWER MOTOR IN LAVATORIES	24-73
US	85-11-02R1	ELEVATOR SURFACE INSPECTION	
US	85-16-07	FIRE PREVENTION - WASTE CONTAINERS	27-262
US	85-25-06		25-259
US	86-10-09	EMERGENCY ENGINE FIRE SHUTOFF SWITCH CAMS	24-78
US	87-08-02	RUDDER RIBS & SKIN	A76-43
US	87-08-09		55-23R4
US	87-13-09	NITROGEN INFLATION A / C TIRES	
US		TAILCONE	
US	87-13-10	RUDDER DRIVE CRANK ASSEMBLY	27-261R1
	88-01-04	WING REAR SPAR - UPPER AND LOWER TEE CAPS	A57-146R1
US	88-12-05	AUTO BRAKE SYSTEM	32-216
	88-24-04R1	FUEL - APU EXHAUST DUCTING	A49-40R1, 53-229
US	88-24-06	NOTS - DOOR ASSIST HANDLES	A25-302
US	88-24-08R2	FUSELAGE SKIN & LONGERONS	A53-230R3
US	89-06-03	AEROQUIP 601 TYPE HOSE ASSEMBLIES	A73-10R1
US	89-06-04	AFT PRESSURE BULKHEAD	A53-231
US	89-07-08	AC CROSS TIE RELAY	24-57R1
US	89-07-17	CENTER TANK FUEL PUMP	
US	89-08-04	SPOILER POSITION SENSING SYSTEM	27-173R1,-257R1
US	89-08-10	EMPENNAGE SECTION	A53-154R4,-223
US	89-10-10	EVACUATION SLIDE GIRT BAR FORWARD STOWAGE CLIP	A25-299R3
US	89-11-02R1	MAIN CARGO DOOR LATCHING	52-91R2,52-92R2
US	89-14-02	RUDDER PEDAL BRACKET	A27-307
US	89-14-10	ENGINE MOUNT CONE BOLTS	71-46
US	89-25-03	LH & RH WINDOW BELT PANELS/STRUCTURES	A53-142R8
US	89-26-02	RUDDER CONTROL SECTOR	A27-302
US	90-01-12	CONTROL COLUMNS	A27-288R3
US	90-07-06	PLACARD - AFT PRESSURE BULKHEAD EMERGENCY EXIT	52-167
US	90-16-51R1	BROKEN CARGO DOOR LATCH SPOOL FITTING ATTACH BOLT	52-119R1
US	91-13-06	AFM AMENDMENT - AC BUS X-TIE SWITCH	24-119
US	91-21-03	INSP ELECT WIRING - ARCING/CHAFING STOWAGE COMP	ESCI-25-A1
US	91-21-07	SHORTING/BURNING PRIMARY LONGITUDINAL RELAY	
US	91-22-03	TAIL CONE DEPLOYMENT VISUAL INDICATION	A27-316 53-199
US	91-22-07	PREVENT LOSS OF LH OR RH MLG OUTBOARD DOOR	
US	91-24-05		A32-244
US	91-25-03R1	FWD CABIN ATTENDANT DUAL SEAT LAP BELT SYS - MOD AIRCRAFT BRAKING SYS WEAR LIMITS	A25-311
US	91-26-09	OPERATION AND MAINTENANCE TAIL CONE RELEASE SYS	450 040
US	92-02-04	RUDDER ACTUATOR	
US	92-11-10		A27-301
US		SLAT DRIVE MECHANISM/STRUCTURE	27-196R2, 27-250R3
US	92-22-0804	BF GOODRICH AIRCRAFT EVACUATION SYSTEM	11331-25-248
US	92-22-08R1	CORROSION & PREVENTION CONTROL	MDC K4606
	93-05-16R1	FLT CONTROLS INSPECT RUDDER POWER CNTRL VALVE	A27-327 REV 1
US	93-07-15	CLASS B CARGO COMPARTMENT	
US	93-13-07	INST OF WATER DRAIN SYS IN SLANT PRESS PANEL	53-179 CN2
US	93-23-03	EVACUATION SLIDE	4A3153-25-258
US	94-01-08	CRACKS IN THE VENTRAL AFT PRESSURE BULKHEAD	53-26, A53-144
US	94-08-04	UPPER ANTI-COLLISION LIGHT CUTOUT - INSP/NDT	53-186
US	95-02-02	PREVENT INABILITY OF TAIL CONE TO DEPLOY	53-269

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

		40027	BULLETIN DE SERVICE DE REF.
DOUGLA	ıç		
	SERIES		
	NUED / SUITE)		
US	95-06-06	ELIZATE AT L	
US	95-16-03	ENGINE STARTER	24-121
US	96-01-05	THRUST REVERSER DOORS	A78-67
US	96-02-05	MLG ATTACH FITTINGS RH & LH	57-125R5, -148R5
US	96-07-15	RUDDER PEDALS ADJUSTER HUB ASSY - INSP/NDT	A27-325 REV 1
US	96-10-11	ELECTRICAL WIRING ROUTING COCKKPIT	DC9-24-157 REV 1
US	96-11-04	AGING AIRCRAFT INSPECTION AND STRUCTURE MODS	MDC K1572 REV A
US	96-11-11	INSULATION MAIN LDG GEAR SLANT PRESS PANEL	53-268
US	96-13-03	FATIGUE CRACKING FUSELAGE NOSE SKIN - NDT INSP	53-262
US	96-16-04	PRINCIPAL STRUCTURAL ELEMENTS - NDT VENTRAL AFT PRESSURE BULKHEAD	DC9-53-280
US	97-02-08R1	FILE   EARAGE DEDUCED STOUGHDAY INTEGRATY WANGE	A53-232 R2
us	97-02-10	FUEL LEAKAGE-REDUCED STRUCTURAL INTEGRITY WINGS NOSE LANDING GEAR UPPER LOCK LINK ASSY - INSPECT	27-300R2
US	97-03-05	CRACKING OF FUSELAGE FRAME AT FS 275 & ADF ANTENNA	32A298
US	97-03-15	EVACUATION SLIDE GIRT & LANYARD STOWAGE - MOD	
US	98-04-07	FUSELAGE INSPECTION	BFGOODRICH 25-280R2
US	98-08-24	FUS SKIN DOUBLERS FWD LWR CARGO DOORJAMB CRACKS	53A147 REV 5
US	98-09-19	UNCONTAINED FAILURE OF ENGINE STARTER	53-277
us	98-11-10	JAMMED SPEED BRAKE HANDLE PIN	DC9-80-010, -014
US	98-13-35R1	FUSELAGE SKIN CRACK DETECTION	27-346 REV 1
US	98-15-15	FIREX SUPPLY PIPE	53-235 26-25 DEV 5
US	98-18-22	FUSELAGE SKIN - UPPER CARGO DOOR CORNER DOORJAM	26-25 REV 5
US	98-20-08	FRAME TO SKIN SHEAR CLIPS	DC9-53-276
US	98-26-08	FORWARD SERVICE DOOR DOORJAM CORNERS	DC9-53-140 DC9-53-279 R1
US	98-26-09	FORWARD PASSENGER DOOR CORNERS	
US	99-08-05R1	FUSELAGE FRAMES AND LONGERONS 16R AND 17R	DC9-53-280R1 DC9-53-267
US	99-13-13	FLIGHT SPOILER ACTUATOR	DC9-33-267
35		TERMIN STOLEN MOTORION	DC3-21-355
DC9 3	2 ( DC9	SERIES )	
US	93-23-11	NOSE WHEEL ASSEMBLIES - INSPECTION	DC9-30-SL-16
US	94-09-12	CENTER & SIDE WINDSHIELDS - VISUAL INSPECTION	A56-15R2
US	95-02-14	ENGINE NOSE COWL	A71-63R1
US	95-11-12	EMERGENCY POWER SWITCHES	24-150
US	96-02-06	WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	24-150
US	96-22-10	BLUE ICE LAVATORY LEAKAGE	38-41R3
US	97-22-05	EMERGENCY INTERNAL RELEASE SYSTEM TAILCONE	53-257 REV 1
US	98-22-13		38-27 R1
US	98-24-33	LONGERONS 22 THROUGH 26	DC-9-87
US	99-15-05	AFT LOWER CARGO DOORJAM MOD	DC9-53-278 R1
US	99-21-07	MAIN LANDING GEAR HYDRAULIC DAMPER ASSEMBLY	DC9-32-289
US	99-22-08	PNEUMATIC AUGMENTATION VALVE	DC9-36-012 R3
US	99-23-08	FUEL QUANTITY INDICATING SYSTEM WIRING	DC9-28-077
	35 20 00	TOLE COMMITTE THE STATE OF STA	200 20 0.,
DC10 9	SERIES		
CF	CF-79-12	STATUS OF AD CF-79-11	
US	73-10-05	RUDDER HYDRAULIC SYSTEM	29-40, -46
US	73-26-04	NOSE COWL ATTACH BOLTS	
US	74-07-04	FWD PASSENGER DOOR AIR BOTTLE ASSY	52-95
US	74-08-04	CARGO DOOR LATCH	A52-35
US	74-08-06	LANDING GEAR SYSTEM	A32-76, -82
US	74-08-07	AUTO LANDING SYSTEM	22~56
US	74-10-02	OXYGEN GENERATORS	25-326
US	74-12-07	LOWER CARGO DOOR	52-98, -99, -102, -106
US	74-15-04	AIRCRAFT SEATS	25-314, -330
US	74-18-01	INERTIAL NAVIGATION SYSTEM	
US	74-18-17R1	ENGINE MAIN FUEL HOSE	71-57, 71-141
US	75-04-03	OXYGEN	AOL 10-742
US	75-06-07	FORWARD PASSENGER DOORS	52-132R1
US	75-07-09	ELECTRICAL SHOCK	24-45R2, -62
US	75-07-12	AUTOTHROTTLE/SPEED CONTROL	22-67
US	75-08-08	OPENING OF PASSENGER DOORS	52-74 R1
US	75-08-13	WING ENGINE NOSE COWL	71-53
US	75-11-10	DOORS	AOL 10-814
US	75-12-03	AFT ENGINE	71-73 R1
US	75-13-03	PASSENGER DOORS	A52-145
US	75-15-05	FLOOR CAPABILITY	
US	75-16-21	FLAP VANE ASSEMBLY	A57-48
US	75-18-08	AIRPLANE MISALIGNMENT	34-66
US	76-01-10	INBOARD ELEVATOR SURFACES	27-141
US	76-03-03	SPOILER CONTROL ASSEMBLY	27-119
US	76-07-06	SPOILERS	27-147
US	76-13-04	PORTABLE OXYGEN UNITS	
US	76-22-05	ATTENDANT'S SEAT BELTS	

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

( SERIES / SERIE) SUBJECT SUJET

ORIGINE	NUMERO DE CONSIGNE	50321	
DOUGLAS			
	SERIES		
(CONTIN	UED / SUITE)		
US	77-12-04	UPPER CARGO DOOR	52-137
US	77-17-02	AUTOPILOT ACTUATORS	A22-96
US	77-24-05	AIR CONDITIONING COMPARTMENT DOOR	
	78-05-04	AUTOMATIC LANDING SYSTEM	
US	78-08-05	LITTON INS OR ISS SYSTEMS	25-251
US	78-08-11	FALSE STALL WARNING	22-94
US	78-20-02	HORIZONTAL STABILIZER	A27-163 R1
	78-20-04	SLAT DRIVE ARM AND DRIVE SHAFT	A27-160 R2
US	78-20-10	POWERED FLIGHT CONTROLS	A29-113
US	78-25-09	SEATS	25-494
US	79-05-01	AUTOMATIC LANDING SYSTEM	A24-99
US	79-15-04	SLAT MECHANICAL DRIVE SYSTEM	
US	79-15-05	ASYMMETRIC WING SLAT CONDITION	30-47
US	79-18-03	WING/ANTENNA ANTI-ICE SYSTEM	30-47
US	79-19-11	DUAL BRAKE CONTROL VALVES	A32-169
US	79-25-01	PRESSURE RELIEF VALVES	21-87
US	80-02-18	PICO PASSENGER EVACUATION SYSTEM	DC-10-25-78R2
US	80-03-10	STALL WARNING FUNCTION	
US	80-11-05R1 80-13-09	WING ENGINE PYLON STRUCTURE	54-78
US	80-13-09	EMERGENCY EVACUATION SYSTEM	25-75
US	80-17-12	FIRE FIGHTING SAFEGUARDS	76-27
US	80-21-01	ENGINE FUEL SHUT-OFF VALVE	
US	80-22-02	AIDS SPOILER HANDLE POSITION SENSOR	A27-178
US	80-22-51	FIRE EXTINGUISHER SYSTEMS	
US	81-02-07	CARGO DOOR ATTACH BOLTS	52-183
US	81-10-05	ELECTRICAL SYSTEM	28-17
US	81-10-06	SLIDE/RAFT ASSEMBLIES	25-278
US	81-16-06R1	GENERATOR OPERATION	
US	82-03-03	WING SLATS MODIFICATIONS	27-187
US	82-27-11R1	GALLEY LIFT ELECTRICAL SYSTEM	25-266
US	83-13-09R1	INTERPHONE AUDIO SYSTEM MOD	23-46
US	84-02-06	FUEL TANK PUMP CONDUITS	24-123
US	84-03-02		A32-202
US	84-03-06	LG ASSY COMPONENTS	
US	84-03-07	HOR STAB DRIVE ASSY MOD	27-192R1
US	84-11-04	AILERON ACTUATOR CONTROLS	A27-196
US	84-15-06	WIRING	AOL 10-1759
	85-10-03		
US	85-10-03 85-14-09 85-16-02	LAVATORY WASTE CONTAINERS	25-330
US	85-16-02	ELECTRIC WIRING	A24-131
US	85-16-06	FUEL FLOWMETER TUBE ASSEMBLY	A73-20
US	85-17-02	OUTBOARD SLATS MODIFICATION	27-195R1
US	85-22-01	ENGINE MOUNT BOLTS INSP	A71-133
	85-22-03	ENGINE MOUNT BOLTS INSP FIRE EXTINGUISHING CONTAINERS BRAKE - ANTI-SKID SYSTEM	A26-41
US	86-04-03	BRAKE - ANTI-SKID SYSTEM	32-155, 32-198
US	86-05-10	ANTI-SKID VALVE ASSEMBLIES	32-209
US	86-19-08	FORWARD DOOR ASSEMBLY	25-339
US	86-19-09	FUEL SYSTEM	28-140R1,-163R1
US	87-04-17	FUEL/FIRE SHUT-OFF VALVES	28-168
US	87-05-51	STC - FLOOR PROXIMITY LIGHTING SYSTEM	
US	87-06-05	CREW SEATS LIFE VESTS	
US	87-07-04	ENGINE CORE COWL DOOR	71-142
US	87-08-09	NITROGEN INFLATION A / C TIRES	
US	87-11-10	BOLTS - PYLON AFT CLEVIS FITTING ATTACH	A57-106
US	87-21-04	INBOARD SLAT DRIVE ARM	A27-203R1
US	88-01-05R1	INBOARD AND OUTBOARD FLAP VANE NUTS AND BOLTS	A57-107
US	88-03-08	HORIZONTAL STABILIZER	A55-16, -17
US	88-06-06	ENGINE CORE COWL DOOR LATCHES	A71-150R1
US	88-10-03	DC POWER FEEDER CABLE	A24-140
US	88-15-05	MAIN BATTERY GROUND CABLE BRACKET	
US	88-24-11R1	PASSENGER EMERGENCY OXYGEN SYSTEM	JEPSON 25-20-618
US		WET CENTER WING FUEL TANKS	A25-356
US	89-01-03	AEROQUIP 601 TYPE HOSE ASSEMBLIES	A73-21
	89-06-03 89-19-08	OUTBOARD FLAP VANE	A57-110R1
US		AUX HYDRAULIC PUMPS - ELECTRICAL CONNECTORS	A29-127
US	89-20-09R1		NES 121
US	90-01-01	AIRCRAFT BRAKING SYSTEM	25-357
US	90-04-03	LAVATORY OVERHEAD LITE ASSEMBLIES	29-129
US	90-13-07	INSTALL NO 3 HYD SYS FLOW RATE SENSOR	52-129 52-129R1
US	90-18-01	CARGO DOOR "VENT DOOR-OPEN" INDICATING SYSTEM	
US	90-19-12	TORQUE TEST ON CARGO DOOR LATCH SPOOL FITTING BOLT	
US	90-22-03 91-07-15	FUEL TANK MANIFOLD DRAIN/OUTBOARD FILL VALVES	A28-196 A54-99, -103
	31 07 13	ENGINE FORWARD MOUNT TRUSS ASSEMBLY	AU- 33, 103

	ONSTRUCTEUR / MODELE	(SERIES / SERIE)	
ORIGII ORIGII	N AD NUMBER	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
DOUGL	45		
	SERIES		
	INUED / SUITE)		
US	91-10-07 91-23-14	PREVENT_INADVERTENT OPENING OF CARGO DOOR IN FLT	
US	92-16-03	NO. 3 HYDRAULIC SYS CLOSED MASTER CAUTION WARNING SPOILER MIXER BRACKETS - NDT EDDY CURRENT INSP	29-132R1 A27-220
US	92-22-06	AFM LIMITATIONS SECT FUEL DUMP REVISION	A27-220
US	92-22-09R1	CORROSION & PREVENTION CONTROL	MDC K4607
US US	92-22-10 93-01-28	HORIZONTAL STABILIZER REAR SPAR CAP	A55-18 OR R1,2,3,4,
US	93-07-15	INSPECTION (DPI) WING-TO-FUSELAGE ATTACH TEE CLASS B CARGO COMPARTMENT	A53-164
US	94-03-08	AGING AIRCRAFT INSPECTION & STRUCTURAL MODS	MDC-K1571 REV A
US	94-22-01	INGESTION OF ICE OR SNOW	ADL 10-673 7 AUG 74
US US	94-23-01 95-11 <b>-</b> 02	WING REAR SPAR LOWER CAP AFT TANG - NDT INSP	A57-123
US	95-23-09	NLG - UPPER & LOWER LOCK LINKS VISUAL INSPECTION PRINCIPAL STRUCTURAL ELEMENTS - NDT	A32-237, -238 DC10-57A137
US	96-10-17	ENG PYLON THRUST FITTING - NDT INSPECTION	54-108
US	96-12-18	LAVATORY DRAIN SYSTEM LEAKAGE CHECK	
US	96-14-04	NOSE LANDING GEAR LOCK LINK BOLT	DC10-32-242
US US	96-17-08 96-19-03	AC GENERATOR CONTROL UNIT - MODIFICATION STEEL HI-LOK FASTENERS, INBD FLAP, INBD TRACK	-24-111RO1 DC-10-57-134
US	97-07-12	ENGINE DRIVEN GEN CORRECT INSTALLATION	A26-46, 6/12/93
US	98-21-37	FUEL TANK BOOSTER PUMP HOUSINGS	28-97 R1
US	98-26-22	WING REAR SPAR LOWER CAP	DC10-57A137 R1
US	99-08-22	REAR SPAR CAP HORIZONTAL STABILIZER	DC10-55A028
DC10	30	( DC10 SERIES )	
US	92-17-13	WING PYLON AFT BULKHEAD INSPECTION	A54-106
US	92-27-18	MAIN LANDING GEAR PISTON - MOD	SB 32-227 REV 1
US US	93-07-09 94-04-08	FUS STN Y=595.000 PRESS BULKHEAD - VISUAL/NDT INSP NO. 2 ENG PYLON LOWER SPAR FWD MOUNT BOLTS - NDT	A53-158 REV 1 54-100 REV 1
US	94-07-02	CAVITY VENT DRAIN TUBE	28-204
US	94-12-05	OUTER WING STRINGER NO. 41 - NDT INSPECTION	57-114 REV 1
US	94-20-10	FATIGUE-CRACKING UPPER FWD SKIN HORZ STAB - INSP	55-25 R1 3 AUG 93
US US	94-23-02 94-24-03	H-11 CARGO DOOR LATCH SPOOL FITT ATTACH BOLTS PREVENT INADVERTENT ASYMMETERIC DEPLOY OF SPOILER	A52-212 R4 3/11/93 27-222, 1 NOV 93
US	95-04-07R2	LOCK WIRE ENGINE MOUNT BOLTS - INSPECTION	71-133R6, 71A159R1
US	95-11-07	ATTACH BOLTS VERT STAB	55-20R2
US	95-11-11R1	WING PYLON AFT BULKHEAD	A54-106
US US	95-14-06 95-21-11	SYS REVIEW TASK FORCE APPLICABLE MODS WING PYLON AFT BULKHEAD	A54-106 R2
US	95-24-03	HORIZONTAL STABILIZER LOWER FRONT SPAR CAP	55-14R5
US	96-03-05	MAIN LANDING GEAR TRUNNION BOLTS	32-239R1
US	96-06-08	WING ATTACH BOLTS (6) FRONT SPAR FOR CRACKS	57-126 REV 1
US US	96-07-01 96-24-15	VERTICAL STABLILIZER CRACKING ATTACHMENTS SECONDARY PIVOT SUPPORT HORZ STAB - NDT HFEC	55-23 REV 1 53-167R1
US	96-24-15	NO. 4 BANJO FITTING REAR SPAR VERT STAB - NDT	54-096R3
US	98-24-17	MLG ATTACH FITTING ASSEMBLIES	57-78
US	99-06-08	MLG FORWARD TRUNNION BOLT	DC10-32-248
EDGAR	PERCIVAL		
EP9			
	EINO RIIHELA	/	
PIK	20E	SEE/VOIR: EIRIAVION OY	
EIRIA	VION OY		
	20 SERIES	TOU HOOK DADY DELEACE	14
FD FD	735/77	TOW HOOK BACK RELEASE PILOT-LEKO 1 SAFETY HARNESS	M15
FD	746/77 M 1232/84R1	RUDDER BOTTOM HINGE BRACKET	M2O-26
PIK		( PIK 20 SERIES )  OPERATING LIMITATIONS & FLIGHT SPEEDS	,
CF FD	CF-76-22 736/77	FLAP OPERATING MECHANISM	16
FD	779/78	RUDDER CABLE / LANDING GEAR	M18
FD	M 851/79	LANDING GEAR	22
FD	M 1479/87R1	FLAP AND AILERON BALANCE WEIGHTS	
PIK :	20B	( PIK 20 SERIES )	
CF	CF-76-22	OPERATING LIMITATIONS & FLIGHT SPEEDS	16
FD	736/77	FLAP OPERATING MECHANISM RUDDER CABLE / LANDING GEAR	16 M18
FD FD	779/78 M 851/79	· LANDING GEAR	22
FD	M 1479/87R1	FLAP AND AILERON BALANCE WEIGHTS	

MAKE / CONSTRUCTEUR

INDEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN CANADA INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJET REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. EIRIAVION OY PIK 20D ( PIK 20 SERIES )
FD 733 SHEAR WEB / WING UPPER PANEL SPAR CAB M 17

PIK	20E			
FD	746/77		PILOT-LEKO 1 / SAFETY HARNESS FUEL SYSTEM INLETS / HOSE CONNECTIONS PROP HUB MOUNTING NUT LOCKPLATE ROTAX ENGINE - PISTON PIN BEARINGS	M15
FD.	M 1200/83		FUEL SYSTEM INLEIS / HOSE CONNECTIONS	
FD	M 1/3//90K1		PROP HOS MOUNTING NOT LOCKPLATE	ROTAX SB 505-05
''	14 1631/31		ROTAL ENGINE FISTON FIN DEARINGS	NOTAX 30 303 03
CMOD	AFD			
EMB	110 SERIES		LANDING GEAR WARNING HORN MICROSWITCHES HOT MIKE - PILOTS / PASSENGERS CABIN COMMUNICATION GOODYEAR 6.50 - 8X8PR - TL TYPE TIRES FRONT DOOR LOCKING PIN	
BZ	78-06-02		LANDING GEAR WARNING HORN MICROSWITCHES	110-32-031
BZ	78-07-03		HOT MIKE - PILOTS / PASSENGERS CABIN COMMUNICATION	110-23-011
BZ.	78-10-01		EDONT DOOD LOCKING DIN	110-32-032
BZ BZ	79-03-04		FRONT DOOR LOCKING PIN FLAP ASYMMETRY DETECTOR SYSTEM MS 21232 BEARING - FLT CONTROL TRIM TAB ASSEMBLIES FLAP SUPPORTS PROPELLER - SPINNER BULKHEAD	110-27-029
BZ	79-04-02		MS 21232 BEARING - FLT CONTROL TRIM TAB ASSEMBLIES	110-27-036
BZ	79-05-01		FLAP SUPPORTS	
BZ	79-08-01		FLAP SUPPORTS PROPELLER - SPINNER BULKHEAD LITHIUM SULFUR DIOXIDE (LI SO2) BATTERIES / ELT'S MAIN LANDING GEAR TORQUE LINK FITTING ELEVATOR TRIM TAB / TAIL CONE MAIN LANDING GEAR PISTON TUBE BENDIX AUTO PILOT - MAGNETIC CLUTCH HARTZELL PROPELLER SLIP RING RUDDER UPPER HINGE SUPPORT COVERS - OVERWING EMERGENCY EXIT HANDLES	110-61-008R1
BZ	79-11-01		LITHIUM SULFUR DIOXIDE (LI SO2) BATTERIES / ELT'S	
BZ	80-06-03		MAIN LANDING GEAR TORQUE LINK FITTING	
BZ.	80-07-03		MAIN LANDING GEAR RISTON TURE	110-32-034
BZ BZ	80-11-04		RENDIX AUTO PILOT - MAGNETIC CLUTCH	110-32-034
B7	80-12-03R1		HARTZELL PROPELLER SLIP RING	110-61-014
BZ	80-12-04R2		RUDDER UPPER HINGE SUPPORT	110-055-0017
BZ	81-06-02R1		COVERS - OVERWING EMERGENCY EXIT HANDLES	110-52-021R2
BZ	81-07-01		HARTZELL PROPELLER SLIP RING RUDDER UPPER HINGE SUPPORT COVERS - OVERWING EMERGENCY EXIT HANDLES FLAP LINEAR ACTUATOR BALL NUT FIRE DETECTOR CABLE TERMINALS FIRE DETECTOR BRACKET ASSEMBLY DE-ICING SYSTEM HOSES FLT CONTROL TRIM TAB ASSEMBLIES BEARINGS FLAP LINEAR ACTUATOR OPERATIONAL PROCEDURES / DE-ICING SYSTEM HOSES COLLINS ADF-60 FLAP CONTROL - LANDING GEAR SOLENOID PRIMARY FLIGHT CONTROL CABLES FUEL FILTER DRAIN LINE MAIN & NOSE LANDING GEAR WIRING FLT CONTROL - PEDAL ASSY MAIN BEARING ATTACHMENT	110-27-A54
BZ	82-02-01		FIRE DETECTOR CABLE TERMINALS	110-26-002R2
BZ.	82-02-02		PEREDETECTOR BRACKET ASSEMBLY	110-26-003
BZ BZ	82-05-03R2 82-06-01P8		ELT CONTDOL TOTM TAR ASSEMBLITES BEADINGS	110-30-01381
BZ	82-07-04R3		FLAP LINEAR ACTUATOR	110-27-043
BZ	82-07-06		OPERATIONAL PROCEDURES / DE-ICING SYSTEM HOSES	110 27 040
BZ	82-09-06R1		COLLINS ADF-60	
BZ	82-09-07R1		FLAP CONTROL - LANDING GEAR SOLENOID	110-32-054
BZ	82-09-08R2		PRIMARY FLIGHT CONTROL CABLES	110-27-064R2
BZ	82-10-01		MAIN & NOSE LANDING SEAR WILLIAM	110-28-024
BZ BZ	82-10-02R2 82-11-02		FIT CONTROL DEDAY ASSV MAIN BEADING ATTACHMENT	110-32-0052R3
B7	82-11-03		NUT - ROD FND FLEVATOR TRIM TAR	110-27-062
BZ	82-11-04		CONTROL COLUMN .	110-27-059
BZ	82-12-02R5		KEY - MAIN LANDING GEAR TORQUE LINK	110-032-0056
BZ	83-02-01R3		CONTROL WHEEL SPINDLE	110-27-A70
BZ	83-03-03R6		BULKHEAD - HORIZONTAL STABILIZER FRONT FITTING	110-53-019R4
BZ	83-05-03R2		STATIC BALANCE - ATLERONS, RUDDER & ELEVATORS	110-55-021
BZ BZ	83-11-01R2 83-12-01		HADTZELL DOODELLED BLADE DOOT BEADING DACES	110-55-0023
BZ BZ	84-01-01R2		MULTIPOSITION FLAP CONTROL SWITCH	110-27-073/01
BZ	84-04-01R6		HORIZONTAL STABILIZER SUPPORT FITTINGS	110-053-0022R3
BZ	85-01-02R2		FUEL FILTER DRAIN LINE MAIN & NOSE LANDING GEAR WIRING FLT CONTROL - PEDAL ASSY MAIN BEARING ATTACHMENT NUT - ROD END ELEVATOR TRIM TAB CONTROL COLUMN KEY - MAIN LANDING GEAR TORQUE LINK CONTROL WHEEL SPINDLE BULKHEAD - HORIZONTAL STABILIZER FRONT FITTING STATIC BALANCE - AILERONS, RUDDER & ELEVATORS ELEVATOR TRIM TAB HINGE PIN HARTZELL PROPELLER BLADE ROOT BEARING RACES MULTIPOSITION FLAP CONTROL SWITCH HORIZONTAL STABILIZER SUPPORT FITTINGS ELEVATOR CONTROL ROD TUBE	110-27-076,-077
BZ	86-01-01R1		WHEEL AXLE / PISTON TUBE SUPPORT	110-032-0068
BZ	87-07-05R4		ELEVATOR TRIM TAB ACTUATOR - SPRING PINS	110-027-0083R3
BZ	88-09-01R2		PEAR INCLUDING CONTROL SWITCH	110-027-0084R1
BZ BZ	90-05-0391		FLEVATOR WEIGHT ARM	110-071-0023
BZ BZ	T91-11-01		RUDDER TRIM TAB ROD	110-27-0091
BZ	91-07-01		HORIZONTAL STABILIZER SUPPORT FITTINGS ELEVATOR CONTROL ROD TUBE WHEEL AXLE / PISTON TUBE SUPPORT ELEVATOR TRIM TAB ACTUATOR - SPRING PINS FLAP POSITION CONTROL SWITCH REAR INSULATOR - ENGINE "C" FLANGE CONNECTOR ELEVATOR WEIGHT ARM RUDDER TRIM TAB ROD EMB 110 RUDDER SYSTEM REAR DOOR LOCKING	110-027-0089
BZ	92-10-01R1		REAR DOOR LOCKING	110-52-0045R1
BZ	93-02-01		ELEVATOR TRIM TAB ACTUATOR FITTING SUPPORT - INSP	110-027-A090
BZ	94-01-01		EMB TO RUDDER SYSTEM REAR DOOR LOCKING ELEVATOR TRIM TAB ACTUATOR FITTING SUPPORT - INSP DOWN LOCK ASSEMBLY NOSE LANDING GEAR AUTO FEATHERING GCU OVERVOLTAGE GYRO HORIZON DOOR LOCKING ROD ARMS ICING OPERATION	110-32-0084
BZ	95-10-01		AUTO FEATHERING	110-061-0032
BZ BZ	95-11-02K1		GVPO HODIZON	SNI 110-34-0002
BZ	97-05-01		DOOR LOCKING ROD ARMS	110-52-0044
BZ	97-06-02 ERRATA		ICING OPERATION	
EMB	110P1 (	EMB	110 SERIES )	
CF	110P1 ( CF-90-20		FORWARD EMERGENCY EXIT	110-52-030
EMP	110P2	EMD	110 CEDIEC )	
CF	110P2 ( CF-90-20	CMD	FORWARD EMERGENCY EXIT	110-52-030
			TOTAL BALL	52 000

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

		- 30151	BULLETIN DE SERVICE DE REF.
E4400	450		
EMBR			
	120 SERIES		
BZ	86-10-01R1	OIL COOLER	120-079-0006
BZ	87-03-01	EFIS	120-34-A012
BZ	87-03-02	2B VDC BUSS BAR OVERVOLTAGE	
BZ	87-05-01R2	FLAP ASYMMETRY	120-049-0003
BZ		EDEC-EAL ACTUATING LEVED	
BZ	88-08-05	FREE-FALL ACTUATING LEVER	120-032-0042
BZ		FIRE DETECTION SYSTEM	120-049-0010
		RUDDER PEDALS	120-027-0043
BZ		AUX. GENERATOR VOLTAGE SENSOR	120-024-0031
BZ		HMU SOLENOID	120-073-0007
BZ		GLIDESLOPE ANTENNA	120-034-0035
BZ	90-07-04R4	FLIGHT IDLE POSITION ELECTRICAL LOCK	120-076-0018R1
BZ	90-09-02R1	ELECTRONIC CONTROL UNIT	120-053-0049
BZ		GENERATOR CONTROL UNIT	120 033-0049
BZ	90-10-01	FLAP ANNUNICATOR	120-024-0021
BZ			120-027-0064
BZ		ESCAPE HATCH	120-025-0169
		ELEVATOR TRIM RUNAWAY PLUG-IN TABLE STOWAGE ENGINE FIRE DETECTOR	120-022-0016_& 0013
BZ		PLUG-IN TABLE STOWAGE	120-025-0163
BZ		ENGINE FIRE DETECTOR	120-26-0019&PW 2111:
BZ	92-08-04R1	PROPELLER OVERSPEED	120-076-0009/18
BZ	93-03-01	EMERGENCY LIGHTING	120-033-0033
BZ		ELECTRICAL CONNECTIONS	120-24-0047
BZ	93-12-01R1		120 24 005104
BZ		ELECTRICAL POWER LOSS ELECTRICAL SYSTEM AND AHRS	120-24-0051R1
BZ			120-24-0008R3
		AILERON CONTROL	120-57-0021R2
BZ	95-05-01R1	WING RIB SKIN ANGLES	120-57-0031
BZ		DRAIN INSTALLATION	120-53-0064
BZ	96-12-01	HYDRAULIC PUMP HOSES	120-29-0047 CHANGE
BZ	96-12-02	LEFTHAND DC RELY BOX	12-24-A057
BZ	97-05-03R2	ABNORMAL LANDING GEAR EXTENSION	
BZ	97-06-01	COMBUSTION CHAMBER DRAIN VALVE CAP	120-72-A005
BZ		ICING OPERATION	120-30-0027
BZ			
	97-08-01	FDR AND FLIGHT CONTROLS	120-31-0028
BZ		WING LEADING EDGE EROSION ELEVATOR PITCH TRIM TAB REVERSION CIRCUIT BREAKER, TAT-PITOT/STATIC HEATING	120-51-A004
BZ	97-09-08R1	ELEVATOR PITCH TRIM TAB REVERSION	120-27-A081R1
BZ	97-11-01	CIRCUIT BREAKER, TAT-PITOT/STATIC HEATING	120-30-0028
BZ	97-11-03R1	NACELLE STAINLESS STEEL PLATE	120-54-0035R2
BZ	98-01-02	NACELLE STAINLESS STEEL PLATE AILERON MASS BALANCE WEIGHT	120-27-0077R1
BZ		WING TO FUSELAGE FITTINGS	120-57-0034R1
CF	CF-90-27	LANDING GEAR AURAL WARNING SYSTEM	120-032-0052, -55
01	0, 50 27	CANDING GEAR ABRAE WARRING STOLER	120 002 0002, 00
CMD	400EB	( EMB 120 SERIES )	
		( LPID 120 SERTES /	
LMD	120EK		
		( EMB 120 SERIES )	
ЕМВ	120RT		
EMB NST	120RT ROM		
EMB NSTF F28	120RT	( EMB 120 SERIES )	
EMB NST	120RT ROM		0076
EMB NSTF F28	120RT ROM SERIES	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE	SIL 136
EMB NSTF F28 CF CF	120RT ROM SERIES CF-88-16 CF-89-17	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE	SIL 136
NSTF F28 CF CF CF	120RT ROM SERIES CF-88-16 CF-89-17 CF-98-15	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS	SIL 136 CAR 702.21
F28 CF CF CF US	12ORT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY	SIL 136
NSTE F28 CF CF CF US US	120RT ROM SERIES CF-88-16 CF-89-17 CF-98-15 89-04-09 90-01-06	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX	SIL 136 CAR 702.21 0027
EMB  NSTIF F28 CF CF CF US US US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX	SIL 136 CAR 702.21 0027
EMB F28 CF CF CF US US US US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS	SIL 136 CAR 702.21 0027 0083 0082 REV A
EMB  F28  CF  CF  US  US  US  US  US	12ORT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE	SIL 136 CAR 702,21 0027 0083 0082 REV A 0077 REV B
EMB  NSTF F28 CF CF US US US US US US US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B
EMB  F28  CF  CF  US  US  US  US  US	12ORT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTF F28 CF CF US US US US US US US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02	( EMB 120 SERIES )  HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB ENST! F28 CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTF F28 CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  ( F28 SERIES )	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTF F28 CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-17-15  96-06-02  96-06-03  72-11-04	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
NSTF F28 CF CF CF US US US US US US US US US US US US US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINOLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  ( F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTF F28 CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-17-15  96-06-02  96-06-03  72-11-04	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTF F28 CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINOLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  ( F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
RST F 28 CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-01	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  ( F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTF F28 CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-01	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  **NSTF** F28 CF CF CF CF US	120RT  ROM SERIES  CF-88-16 CF-89-17 CF-98-15 89-04-09 90-01-06 93-15-10 93-24-13 94-13-03 94-17-15 96-06-02 96-06-03  72-11-04 74-12-01 74-17-07 75-22-01 76-05-11	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  ENSTIF F28 CF CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-01  76-05-11  76-06-11	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS SWASHPLATE BEARING	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTIF F28 CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-10  76-05-11  76-06-11  76-17-08	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS SWASHPLATE BEARING MAIN ROTOR SHAFT	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTIF F28 CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-01  75-22-10  76-05-11  76-06-11  76-17-08  77-20-02	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS SWASHPLATE BEARING MAIN ROTOR SHAFT TAIL ROTOR SPINDLE	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  NSTIF F28 CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-10  76-05-11  76-06-11  76-17-08	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS SWASHPLATE BEARING MAIN ROTOR SHAFT TAIL ROTOR SPINDLE MAIN ROTOR SPINDLE MAIN ROTOR SPINDLE	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB  F 28 CF  CF  CF  US  US  US  US  US  US  US  US  US  U	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-01  75-22-10  76-05-11  76-06-11  76-17-08  77-20-02	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS SWASHPLATE BEARING MAIN ROTOR SHAFT TAIL ROTOR SPINDLE MAIN ROTOR SHAFT TAIL ROTOR BLADE GRIPS DRIVEBELT CLUTCH MECHANISM	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB ENSTIF F28 CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-01  75-22-10  76-05-11  76-05-11  76-05-11  76-07-20-02  82-16-09	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS  MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS SWASHPLATE BEARING MAIN ROTOR SPINDLE MAIN ROTOR SPINDLE MAIN ROTOR BLADE GRIPS DRIVEBELT CLUTCH MECHANISM MAIN ROTOR GEARBOXES	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B
EMB ENSTIF F28 CF CF CF US	120RT  ROM  SERIES  CF-88-16  CF-89-17  CF-98-15  89-04-09  90-01-06  93-15-10  93-24-13  94-13-03  94-17-15  96-06-02  96-06-03  A  72-11-04  74-12-01  74-17-07  75-22-01  75-22-10  76-05-11  76-06-11  76-17-08  77-20-02  82-16-09  82-24-01	HORIZONTAL STABILIZER SPAR GREASE HELICOPTER RESCUE SYSTEMS MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY TAIL ROTOR GEARBOX REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS TRIM SYSTEM FAILURE DUE TO STICKING RELAYS PREVENT TAIL ROTOR SPINDLE FAILURE LAMIFLEX BEARING FAILURE UPPER AND LOWER SWASHPLATE BEARINGS FAILURE MAIN ROTOR TRANSMISSION CLUTCH ASSY  (F28 SERIES ) FAILURE TAIL ROTOR DRIVE PINS FORGED IDLER YOKE MAIN ROTOR GEAR BOX MAIN ROTOR SYSTEM HUB LOCK WASHER TAIL CONE ATTACH BOLTS SWASHPLATE BEARING MAIN ROTOR SHAFT TAIL ROTOR SPINDLE MAIN ROTOR SHAFT TAIL ROTOR BLADE GRIPS DRIVEBELT CLUTCH MECHANISM	SIL 136 CAR 702.21 0027 0083 0082 REV A 0077 REV B 0081 S/L 0110 REV B

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

ENSTRO	W	/		
F28A		( F28	SERIES )	
	NUED / SUITE)			
US	90-17-03		TAIL ROTOR DRIVESHAFT COUPLINGS	0065 REV A
US	97-20-04		PRESTOLITE VOLTAGE REGULATOR/ OVER VOLTAGE RELAY	SDB 0086
F28C		( F28	SERIES )	
US	76-06-11		SWASHPLATE BEARING	
US	77-06-04		TAIL ROTOR ASSEMBLY	
US	77-15-04		TAIL ROTOR PITCH LINK ASSY	
US	77-20-02		TAIL ROTOR SPINDLE	
US	77-25-05		IDLE MIXTURE	
US	79-02-01		TURBOCHARGERS	
US	79-10-06R1		TAIL ROTOR BLADE GRIPS	
	82-16-09		MAIN ROTOR BLADE GRIPS	
US	82-24-01		DRIVEBELT CLUTCH MECHANISM	
US	90-17-02		TAIL ROTOR DRIVESHAFT COUPLINGS	0080
US	90-17-03		TAIL ROTOR DRIVESHAFT COUPLINGS	0065 REV A
			PRESTOLITE VOLTAGE REGULATOR/ OVER VOLTAGE RELAY	
US	97-20-04		PRESTULTTE VULTAGE REGULATUR/ UVER VULTAGE RELAY	3DB 0006
		( 500	centre \	
F28C2	00 47 60	( F28	SERIES )	0080
US	90-17-02		TAIL ROTOR DRIVESHAFT COUPLINGS	0080
US	90-17-03		TAIL ROTOR DRIVESHAFT COUPLINGS	0065 REV A
		,		
F28F		( F28	SERIES )	
US	90-17-02		TAIL ROTOR DRIVESHAFT COUPLINGS	0080
US	90-17-03		TAIL ROTOR DRIVESHAFT COUPLINGS	0065 REV A
280 SE	ERIES			
CF	CF-89-17		GREASE	SIL 136
CF	CF-98-15		HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	83-04-04		MAIN ROTOR GEARBOXES	
US	89-04-09		MAIN ROTOR TRANSMISSION CLUTCH ASSEMBLY	0027
US	90-01-06		TAIL ROTOR GEARBOX	
US	93-15-10		REMOVAL OF COMPOSITE WRAPPED ROTOR SHAFTS	0083
US	93-24-13		TRIM SYSTEM FAILURE DUE TO STICKING RELAYS	OO82 REV A
US	94-13-03		PREVENT TAIL ROTOR SPINDLE FAILURE	0077 REV B
US	94-17-15		LAMIFLEX BEARING FAILURE	0081
US	96-06-02		UPPER AND LOWER SWASHPLATE BEARINGS FAILURE	S/L 0110 REV B
			MAIN ROTOR TRANSMISSION CLUTCH ASSY	SUPERCEDES 89-04-09
US	96-06-03		MAIN KOTOK TRANSMISSION CEUTCH ASSY	SUPERCEDES 89-04-09
280		( 200	SERIES )	
	75 00 40	( 200		
US	75-22-10		HUB LOCK WASHER	
US	76-05-11		TAIL CONE ATTACH BOLTS	
US	76-06-11		SWASHPLATE BEARING	
US	76-17-08		MAIN ROTOR SHAFT	
US	77-20-02		TAIL ROTOR SPINDLE	
US	82-16-09		MAIN ROTOR BLADE GRIPS	
US	82-24-01		DRIVEBELT CLUTCH MECHANISM	
US	90-17-02		TAIL ROTOR DRIVESHAFT COUPLINGS	080
US	90-17-03		TAIL ROTOR DRIVESHAFT COUPLINGS	0065 REV A
US	97-20-04		PRESTOLITE VOLTAGE REGULATOR/ OVER VOLTAGE RELAY	SDB 0086
		,		
280C		( 280	SERIES )	
US	76-06-11		SWASHPLATE BEARING	
US	77-06-04		TAIL ROTOR ASSEMBLY	
US	77-15-04		TAIL ROTOR PITCH LINK ASSY	
US	77-20-02		TAIL ROTOR SPINDLE	
US	77-25-05		IDLE MIXTURE	
US	79-02-01		TURBOCHARGERS	
US	79-10-06R1		TAIL ROTOR BLADE GRIPS	
US	82-16-09		MAIN ROTOR BLADE GRIPS	
US	82-24-01		DRIVEBELT CLUTCH MECHANISM	
US	90-17-02		TAIL ROTOR DRIVESHAFT COUPLINGS	0800
US	90-17-03		TAIL ROTOR DRIVESHAFT COUPLINGS	0065 REV A
US	97-20-04		PRESTOLITE VOLTAGE REGULATOR/ OVER VOLTAGE RELAY	
		( 280		
280F			SERIES )	
280FX		( 280	SERIES )	
480		***************************************		
CF	CF-98-15		HELICOPTER RESCUE SYSTEMS	CAR 702.21

MODEL / M ORIGIN ORIGINE	STRUCTEUR ODELE AD NUMBER NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
RCO			
E			
US	86-22-09	FUEL LINE NIPPLE	244
G			
US	86-22-09	FUEL LINE NIPPLE	24A
415 SE	RIFS		
US	46-49-01	NOSE WHEEL REPLACEMENT	
US	47-20-03	FUEL PUMP LINE ALTERATION	
US US	52-02-02 54-26-02	AILERON INSPECTION	
US	60-09-02	CONTROL CABLE FRAYING NOSE GEAR BOLTS	
US	86-22-09	FUEL LINE NIPPLE	24A
US	94-18-04R1	WING STRUCTURE	29 REV B
415C		( 415 SERIES )	
US	46-23-01	MUFFLER REPLACEMENT	
US US	46-23-02 46-23-03	ENGINE BREATHER LINE HOSE	
US	46-38-02	AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP	
US	46-38-03	FUEL SYSTEM ELBOW FITTING	
US	46-46-01	FUSELAGE GAS TANK OVERFLOW LINE	
US US	47-20-04 47-20-05	BAGGAGE COMPARTMENT ZIPPER BELLY SKIN REINFORCEMENT	
US	47-20-06	AILERON REINFORCEMENT	
US	47-20-08	BATTERY BOX DRAIN	
US US	47-20-09 47-42-20	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT	
US	50-07-01	ELEVATOR TRIM TAB STOP	
US	52-25-02	FEDERAL NOSE SKI	
US US	55-22-02 57-02-01	TERNEPLATE FUEL TANK	
US	59-05-04	RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT	
US	59-25-05	RUDDER REINFORCEMENT	
US	67-06-03	RUDDER BELLCRANK	
415CD		( 415 SERIES )	
US	46-23-01	MUFFLER REPLACEMENT	
US US	46-23-02 46-23-03	ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING	
US	46-38-02	AILERON CONTROL STOP	
US	46-38-03	FUEL SYSTEM ELBOW FITTING	
US US	46-46-01 47-20-04	FUSELAGE GAS TANK OVERFLOW LINE BAGGAGE COMPARTMENT ZIPPER	
US	47-20-05	BELLY SKIN REINFORCEMENT	
US	47-20-06	AILERON REINFORCEMENT	
	******************************		
US	47-20-08	BATTERY BOX DRAIN	
	47-20-08 47-20-09	BATTERY BOX DRAIN VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT	
US US US US	47-20-08 47-20-09 47-42-20 50-07-01	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP	
US US US US	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI	
US US US US	47-20-08 47-20-09 47-42-20 50-07-01	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP	
US US US US US US US US	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT	
US	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER REINFORCEMENT	
US US US US US US US US	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT	
US US US US US US US US US US US US US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES ) MUFFLER REPLACEMENT	
US US US US US US US US US US US US US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES ) MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE ATLERON CONTROL COLUMN FITTING	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-01 46-23-03 46-38-02	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING ALERON CONTROL STOP	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-02 46-23-03 46-38-03	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES ) MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP FUEL SYSTEM ELBOW FITTING	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-02 46-23-03 46-38-02 46-38-03 46-46-01	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING ALERON CONTROL STOP	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-02 46-23-03 46-38-03	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP FUEL SYSTEM ELBOW FITTING FUSELAGE GAS TANK OVERFLOW LINE BAGGAGE COMPARTMENT ZIPPER BELLY SKIN REINFORCEMENT	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-03 46-38-03 46-38-03 46-46-01 47-20-04 47-20-05 47-20-06	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP FUEL SYSTEM ELBOW FITTING FUSELAGE GAS TANK OVERFLOW LINE BAGGAGE COMPARTMENT ZIPPER BELLY SKIN REINFORCEMENT AILERON REINFORCEMENT	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-02 46-38-02 46-38-03 46-46-01 47-20-04 47-20-06 47-20-08	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP FUEL SYSTEM ELBOW FITTING FUSELAGE GAS TANK OVERFLOW LINE BAGGAGE COMPARTMENT ZIPPER BELLY SKIN REINFORCEMENT AILERON REINFORCEMENT BATTERY BOX DRAIN	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-03 46-38-03 46-38-03 46-46-01 47-20-04 47-20-05 47-20-06	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP FUEL SYSTEM ELBOW FITTING FUSELAGE GAS TANK OVERFLOW LINE BAGGAGE COMPARTMENT ZIPPER BELLY SKIN REINFORCEMENT AILERON REINFORCEMENT	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-02 46-23-02 46-23-03 46-38-02 46-38-03 46-46-01 47-20-04 47-20-05 47-20-08 47-20-09 47-42-00 50-07-01	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP FUEL SYSTEM ELBOW FITTING FUSELAGE GAS TANK OVERFLOW LINE BAGGAGE COMPARTMENT ZIPPER BELLY SKIN REINFORCEMENT AILERON REINFORCEMENT BATTERY BOX DRAIN VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP	
US U	47-20-08 47-20-09 47-42-20 50-07-01 52-25-02 55-22-02 57-02-01 59-05-04 59-25-05 67-06-03 46-23-01 46-23-03 46-38-03 46-38-03 46-46-01 47-20-05 47-20-08 47-20-09 47-42-20	VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT ELEVATOR TRIM TAB STOP FEDERAL NOSE SKI TERNEPLATE FUEL TANK RUDDER HORN ATTACHMENT REAR SPAR REINFORCEMENT RUDDER BELLCRANK  ( 415 SERIES )  MUFFLER REPLACEMENT ENGINE BREATHER LINE HOSE AILERON CONTROL COLUMN FITTING AILERON CONTROL STOP FUEL SYSTEM ELBOW FITTING FUSELAGE GAS TANK OVERFLOW LINE BAGGAGE COMPARTMENT ZIPPER BELLY SKIN REINFORCEMENT AILERON REINFORCEMENT BATTERY BOX DRAIN VOLTAGE REGULATOR CHECK CONTROL COLUMN SHAFT	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN

ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE		SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
ERCO 415D		( 445	SERIES )	
	JED / SUITE)	( 415	SERIES )	
US	59-25-05		RUDDER REINFORCEMENT	
US	67-06-03		RUDDER BELLCRANK	
EUROCOP				
EC 120 FR	B 1999-151-001(A)		T/R PITCH CHANGE CONTROL ROD	01.001
FR	1999-349-002(A)		MAIN GEAR BOX/ENGINE COUPLING TUBE	TELEX 05-001
EXTRA				
	SERIES			
GY	93-081		RUDDER CONTROL CABLE COMPRESSION SLEEVE	300-1-93
GY GY	93-145/2 94-043		WING ROOT RIB-AUX SPAR ATTACHMENT UPPER LONGERON CUTOUT BRIDGE	300-2-93 300-3-93
GY	95-125		AIR INLET SCREEN	300-5-94 ISSUE 1
GY GY	95-126 95-443		FIRE PROTECTION COWLING AREA AND FIREWALL RUDDER PEDAL SAFETY CONTROL STOP	300-6-94 ISSUE 1 300-3-5
GY	1998-001		TAIL WHEEL SUPPORT INSPECTION	300-2-97
EA 300	1	( FA	300 SERIES )	
EA 300	<b>S</b> 94-258	( EA	300 SERIES ) CANOPY LATCHES FOR THE LOCK AND HINGE SLEEVES	300-3-94 ISSUE A
			STATES FOR THE EDOK AND HENGE SEELVES	500 0 54 1550E A
FAIRCHI F11	LD			
F11 2				
FAIRCH	ILD 24 SERIES		······	
	46-21-01		LANDING GEAR UNIVERSAL JOINTS	
US US	46-40-01 46-40-02		FUEL TANK SELECTOR VALVE PLACARD OLEO TUBE REINFORCEMENT	
		/		
24H		( FAI	RCHILD 24 SERIES )	
24K		( FAI	RCHILD 24 SERIES )	
24R46		( FAI	RCHILD 24 SERIES )	
	47-21-01		STARTER RELAY TERMINAL WIRE	
US US	47-21-02 47-21-03		20-AMPERE LANDING LIGHT FUSE RUDDER CABLE TURNBUCKLES	
US	47-50-09		LANDING GEAR FITTINGS	
24R46A		( FAI	RCHILD 24 SERIES )	
US	47-21-03		RUDDER CABLE TURNBUCKLES	
US	47-50-09		LANDING GEAR FITTINGS	
24W41A		( FAI	RCHILD 24 SERIES )	
	47-21-03 47-50-09		RUDDER CABLE TURNBUCKLES LANDING GEAR FITTINGS	
	-, 50 03			
24W46	47-21-01	( FAI	RCHILD 24 SERIES )	
	47-21-01 47-21-02		STARTER RELAY TERMINAL WIRE 20-AMPERE LANDING LIGHT FUSE	
US	47-21-03		RUDDER CABLE TURNBUCKLES	
US	47-50-09		LANDING GEAR FITTINGS	
F27 SEI				
US US	58-26-03 59-05-03		WESTINGHOUSE DEICING GENERATOR DEICER VALVES	
US	59-12-01		COMBUSTION HEATER INSPECTION	
	59-18-05 59-23-03		COMBUSTION HEATER MODIFICATION	
	60-01-04		FIRE EXTINGUISHER CARTRIDGE RUDDER BALANCE TAB	
US	60-03-03		ELEVATOR RIVETS	
	60-05-01 61-15-02		RUDDER TORQUE TUBE RIVETS FLAP GIMBAL NUTS	
US	62-01-01		CHEMICAL DRIER HOUSING	
	62-04-01 62-27-05		LANDING GEAR BOLTS ELECTRICAL DISTRIBUTION SYSTEM	
US	63-17-02		NOSE LANDING GEAR BOLTS	
US	64-13-02		MAIN LANDING GEAR ATTACH LUGS	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

	NOWIEND BE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
EATRO	ITID		
FAIRCH			
	SERIES ( CHITE)		
	NUED / SUITE)		
US	64-16-03	RUDDER BALANCE WEIGHTS	
US	64-21-04	VERTICAL STABILIZER	
US	65-05-04	RUDDER TRIM TAB	
US	65-10-01	FLAP ASYMMETRY WARNING SYSTEM	
US	65-13-02	FLAP ASYMMETRY SYSTEM	
US	65-13-03	FLAP UNIVERSAL JOINTS	
US	65-24-03	STRUCTURAL INSPECTIONS	
US	65-26-01	AILERON CONTROL SECTORS	
US	65-28-02	ENGINE MOUNT FITTINGS	
US	66-13-03	INVERTER GROUND SYSTEM	
US	66-16-04	FLAP ASYMMETRY SWITCHES	
US	66-30-04	FIREWALL SUPPORT TUBE BRACKET	
US	67-08-04	ELEVATOR TORQUE TUBES AND RINGS	
US	67-08-05	STEWARDESS SEAT ASSEMBLY	
US	67-11-02	CRACKS IN LOWER FUSELAGE EXTERIOR	
US	67-12-02	NOSE LANDING GEAR	
US	67-12-04	RUDDER HORN ASSEMBLY	
US	67-15-02	ELECTRICAL SYSTEM MODIFICATION	
US	67-17-03	CRACKS IN SKIN OF STABILIZER	
US	67-23-04	ENGINE GENERATOR ELECTRICAL SYSTEM	
US	67-25-04	ELONGATED RIVET HOLES	
US	67-29-02	LOSS OF ELECTRICAL POWER	
US	67-29-03	APU FIRE DETECTION SYSTEM	
US	67-30-03	CRACKS IN THE RUDDER SKIN	
US	68-01-05	FLAP DRIVE SYSTEM FAILURE	
US	68-08-03	COMBUSTION HEATER SYSTEM	
US	69-01-01	ENGINE FIRE EXTINGUISHER	
US	69-01-03	WING CRACKS LOWER WING	
US	69-06-01	FLAP DRIVE SYSTEM	
US	69-06-05	INVERTER OVERVOLTAGE	
US	69-08-01	CRACKS IN HORIZONTAL STABILIZER	
US	69-08-06	LANDING GEAR RETRACTION SYSTEM	
US	69-13-06	WING FUEL ACCESS DOOR BOLTS	
US	69-16-04	LANDING GEAR DOOR TROLLEY LEVER	
US	69-20-04	DOOR LOCKING MECHANISM	
US	69-20-04		
US		FLAP OPERATING SYSTEM	
US	69-25-04	FLAP SCREW JACK END	
	70-12-03	FLAP JACKSCREW OVERTRAVEL STOPS	
US	71-08-05	MAIN GEAR DRAG STRUT	
US	72-07-12	STEWARDESS JUMP SEAT	
US	73-12-05	VERTICAL STABILIZER FITTINGS	
US	73-20-01	FRONT AND REAR SPAR FITTINGS	
US	76-07-01	LOOSE STUDS	
US	76-10-07	CARGO DOOR	
US	76-13-08	ENGINE MOUNT BOLTS	
US	80-18-11	HORIZONTAL STABILIZERS	
US	82-22-51	MOISTURE SEPARATOR ASSY	
US	85-21-04	ROD ASSEMBLY	
US	86-05-09	UPPER MAIN UNDERCARRIAGE DRAG STAY	
US	87-05-51	STC - FLOOR PROXIMITY LIGHTING SYSTEM	F07 F0 004
US	87-07-05	WING TO FUSELAGE FAIRING	F27~53~9R1
US	90-08-10	WING - STRUCTURAL CAPABILITY	F27-51-8
US	97-23-15	POWER LEVERS	
US	98-04-31	OPERATION IN ICING CONDITIONS	21/4
US	99-19-09	AFM REVISION FOR DEICE BOOT OPERATION	N/A
F27F		( F27 SERIES )	
F27J		( F27 SERIES )	
F270		( IZ/ JERILS )	
KR34C			
***			
M62 SI		LITTIC OFFITED CECTION COADC	
US	43-07-01	WING CENTER SECTION SPARS	
US	47-07-02	ELEVATOR HINGE ATTACHMENTS	
US	47-07-03	WING INSPECTION	
US	47-07-04	CONTROL STICK SAFETYING	
US	47-07-05	TORQUE TUBE COVER	
US	47-07-06	VERTICAL FIN ATTACHMENT	
US	48-45-01	WING SPAR INSPECTION	

MAKE / CON MODEL / N ORIGIN ORIGINE	ISTRUCTEUR	(SERIES /	SERIE) SUBJECT SUBJECT	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
ORIGINE	NONERO DE CONSTONE		SUJET	BULLETIN DE SERVICE DE REF
FAIRCH M62A3 CF CF CF CF US		( M62	SERIES )  MODIFICATIONS FOR CERTIFICATION  FLAP ACTUATION MECHANISM  GLUE DETERIORATION  COCKPIT HEAT CONTROL VALVE	
M62C CF US	CF-58-10 46-14-01	( M62	SERIES ) GLUE DETERIORATION PROPELLER INDEXING	······································
SA227	cc		SEE/VOIR: SWEARINGEN	
SA227	DC		SEE/VOIR: SWEARINGEN	
FANTAS FANTAS				
	CF-89-12		PREMATURE DETERIORATION OF GONDOLA CABLES	A-1
FANTA:	SY 7 65 SY 8 CF-89-12		DDEMATURE DETERMINATION OF CONDOLAR CARLES	
	SY 8 90		PREMATURE DETERIORATION OF GONDOLA CABLES	A-1
	SY 9 122			
FAUVEL AV36				
FR FLEET	59-003-001		RUDDER TRAVEL	
7B 7C				
16B				
80 CF	CF-47-03		FUEL STRAINER	_13
CF CF	CF-49-01 CF-51-09		LANDING GEAR HINGE BOLTS REAR FLOAT STRUT ATTACHMENT	
CF CF	CF-56-04 CF-69-10		FUEL SHUT-OFF UNIVERSAL JOINT REAR LIFT STRUTS	L-1 SUPP.1
FOKKER				
F27 MK	(300 59-04-30/72(A)		CAM ON CTA 1400 TO DETAIN SUPPLY ADSORDED	ND 12 22 22 (2)
ND	59-05-01/71(A)		CAM ON STA 1400 TO RETAIN SHOCK ABSORBER MAIN JUNCTION BOX	ND AD 70-024/6(A) ND AD 70-024/6(A)
ND ND	59-07-23/86(A) 59-08-06/J-14(	Δ)	NOSEWHEEL STEERING CIRCUIT FOLLOW-UP VALVE BYPASS DC GENERATOR MASTER SWITCH GROUNDING	ND AD 70-024/6(A) ND AD 70-024/6(A)
ND	59-09-18/J-19(	Δ)	ADDITIONAL GROUNDING OF GENERATOR CONTROL PANELS	NA AD 70-024/6(A)
ND ND	59-10-21/B-22() 59-11-30/B-23()	4) 4)	EMERGENCY DOOR - GUIDANCE IMPROVED CABLE GUIDE ASSEMBLIES - IMPROVED ATTACHMENT	ND AD 70-024/6(A) NA AD 7-024/6(A)
ND ND	59-12-28/F-5(A 59-3-30	)	ENGINE CONTROLS - LEVERS STRENGHTENED NOSEWHEEL SHOCK ABSORBER	NA AD 70-024/6(A)
ND	60-01-11/C-17(/	4)	FLAP SYSTEM - LIMIT SWITCHES RELOCATED	NA AD 70-024/6(A)
ND ND	60-01-19/74(B) 60-02-03/C-18(A	۵)	FLAP SYSTEM - NEW ASYMETRIC SAFE GUARD AILERON CONTROL WHEEL RETAINING NUT WASHERS	NA AD 70-024/6(A) NA AD 70-024/6(A)
ND ND	60-02-13/B-28(/	4)	ELECTRICAL CONNECTORS	NA AD 70-024/6(A)
ND	60-02-18/B-28() 60-02-19/B-27()	4)	REPLACEMENT OF ELEVATOR HINGE BRACKETS REINFORCEMENT OF ELEVATOR MAIN SPAR STA 2460	NA AD 70-024/6(A) NA AD 70-024/6(A)
ND ND	60-04-11/N-3(A 60-04-26/B-32(A		ENGINE R.P.M. INDICATOR - DIAL MARKINGS ALTERED AILERON HINGE BRACKETS	NA AD 70-024/6(A) NA AD 70-024/6(A)
ND	60-07-26/J-26(/	4)	LANDING GEAR ELECTRICAL CONTROL CIRCUIT	NA AD 70-024/6(A)
ND ND	60-09-12/F-9(A 61-03-02/N-7(A	)	RPM CONTROL GUST-LOCK INTERFERENCE SYSTEM PITOT-STATIC SYSTEM WATER TRAPS AND DRAINS	NA AD 70-024/6(A) NA AD 70-024/6(A)
ND ND	61-10-16/F-11() 62-10-29/H-24()	4)	HPC CONTROL LEVER RUB PLATE	NA AD 70-024/6(A)
ND	62-12-20/N-19()	4)	WATER/METHANOL CROSSFEED NON-RETURN VALVE PITOT STATIC SYSTEM TUBE INSPECTION	NA AD 70-024/6(A) NA AD 70-024/6(A)
ND ND	63-05-01/J-71() 63-07-26/B-146		ELECTRICAL CONNECTOR AT NACELLE BULKHEAD STEEL TUBULAR STRUCTURE - X-RAY INSPECTION	NA AD 70-024/6(A) NA AD 70-024/6(A)

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT

FOKKER	?		
F27 N			
	NUED / SUITE)		
ND	63-07-26/C-61(A)	CONTROL BOOK	
ND	64-06-18/B-150(A)	CONTROL RODS - CORROSION PREVENTION	NA AD 70-024/6(A)
ND	65-04-28/B-169(A)	HORIZONTAL STAB - FRONT AND REAR SPARS	NA AD 70-024/6(A)
ND	65-07-30/I-30(A)	RUDDER TRIM TAB CONTROL BRACKET & ATTACHMENT PNEUMATIC LINES CONNECTED TO ISOLATION VALVE	NA AD 70-024/6(A)
		PNEUMATIC LINES CONNECTED TO ISOLATION VALVE	NA AD 70-024/6(A)
ND	65-12-24/B-185(A)	NOSE GLAN DOOR AND REBAIL	NA AD 70-024/6(A)
ND	67-01-09/53-39(A)	HORIZONTAL STABILIZER NOSE SECTIONS	NA AD 70-024/6(A)
ND	67-01-24/D-79(A)	NOSE GEAR RAM MAIN PISTON	NA AD 70-024/6(A)
	67-10-02/I-33	PNEUMATIC SYSTEM - LINE REPLACEMENT	NA AD 70-024/6(A)
ND	67-5-15/E-35	ACCESSORY GEARBOX	E-35
ND	70-024/6(A)	MANDATORY AIRCRAFT MODS & INSPECTION SUMMARY	
ND	71-20-72(A)	REDUCTION GEAR	F27/72-1
ND	71-35-61(A)	BLADE GROUP - NEW LOCKING SEGMENTS	
ND	73-46-55/2(A)	ELEVATOR - TORQUE TUBE AND TUBE SUPPORTS	F27/55-38
ND	73-66-27(A)	BLEVATOR - TORQUE TUBE AND TUBE SUPPORTS RH AILERON TRIM TAB ACTUATOR	F27/27-105
ND	74-60-25(A)	IMPROVEMENT OF HATRACK PANEL LOCKING	F27/71-25 R1
ND	75-27-71(A)	ENGINE MOUNT - CRACKS IN UPPER TUBES	F27/71-25 R1
ND	75-68-61(A)	HUB - DRIVING CENTRE FOR INCORRECT MACHINING	F27/61-28
ND	75-72-27(A)	AILERON CONTROL SYSTEM - CABLE DRUM IN CONTROL SYS	F27/01 28
ND	75-73-27(A)	ATI FRON CONTROL SYSTEM	E07/07 110
ND	75-78-52(A)	ENLARGED CARGO DOOR - IMPROPER LOCKPIN	F27/52-55
ND	76-04-73(A)	AEROQUIP TYPE FUEL HOSES	F27/73-4
ND	76-103-24(A)	AC LIGHTING POWER CONVERSION SYSTEM	F27/24-G2
ND	76-104-27(A)	ATTERON ATTACHMENT	F27/24-63
ND	76-88-25(A)	PILOT AND CO-PILOT SEATS	F27/27-112
ND	77-113-61/2(A)	AC LIGHTING POWER CONVERSION SYSTEM AILERON ATTACHMENT PILOT AND CO-PILOT SEATS PROPELLER CONTROL SYSTEM CRACKS IN MAIN GEAR DRAG STRUT OUTER WING LOWER SKIN STRUCTURE PROPELLER FEATHERING CIRCUIT PROPELLER FEATHERING CIRCUIT	F27/25-43
ND	77-121-32(A)	CDACKS IN MAIN GEAD DDAG CIDUIT	F27/61-10
ND	77-39-57/2(A)	DUTED WING LOWED SKIN STRUCTURE	F27/32-126
ND	77-79-61(A)	DOOR WING LOWER SKIN STRUCTURE	F27/57-50
		PROPELLER FEATHERING CIRCUIT	F27/61-26
ND	77-80-36(A)	PROPELLER FEATHERING CIRCUIT	
ND	77-81-61(A)	INSPECTION - HUB AND DRIVE CENTRE ASSEMBLIES	F27/61-31
ND	78-30-33(A)	MAIN INSTRUMENT PANEL LIGHTING	F27/33-24
ND	78-40-34(A)	MAIN INSTRUMENT PANEL LIGHTING PITOT STATIC SYSTEM	F27/31-41
ND	78-57-30(A)	ICE AND RAIN PROTECTION	F27/30-34
ND	78-58-76(A)	POWER CONTROLS	F27/76-31
ND	78-66-32(A)	NOSE GEAR AND DOORS	F27/32-129
ND	79-04-25(A)	FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM	F27/25-47
ND	79-06-52/2(A)	CARGO DOOR - HOOK LATCH MECHANISM	F27/52-60
ND	79-106-52(A)	DOORS - ENTERANCE DOOR-CHECK EMERGENCY OPERATION	F27/52-47
ND	79-27-24(A)	BATTERY REVERSE CURRENT CIRCUIT BREAKERS	
ND	79-38-61(A)	PROPELLER - SHIELDED WIRES MLG ACTUATING RAM RETENTION RING GEARBOX ACCESS DOOR SPRING CABLE LOOMS IN COCKPIT FUEL TANK VENTILATION	F27/61-35
ND	80-15-32(A)	MLG ACTUATING RAM RETENTION RING	F27/32-136
ND	80-39-71(A)	GEARBOX ACCESS DOOR SPRING	F27/51-29
ND	81-07-24/2(A)	CABLE LOOMS IN COCKPIT	F27/24-68
ND	81-19-28/2(A)	FUEL TANK VENTILATION	F27/28-55
ND	81-26-32/2(A)	LANDING GEAR - ACTUATING RAMS	F27/32-134
ND	81-50-32(A)	I ANDING GEAR	F27/32-126
ND	81-53-30(A)	PITOT HEATING INDICATION CIRCUIT	F27/30-36
ND	81-56-26	PORTABLE FIRE EXTINGUISHERS	F27/26-18
ND	81-64-11(A)	NEW SPEED LIMITATION PLACARDS	F27/11-3
ND	82-04-55(A)	NEW SPEED LIMITATION PLACARDS ELEVATOR TRIM TAB INBOARD HINGE AEROQUIP FUEL HOSES INTRODUCTION OF NEW PROPELLER	F27/55-31
ND	82-13-73(A)	AEROQUIP FUEL HOSES	F27/73-05
ND	83-02-61/2(A)	INTRODUCTION OF NEW PROPELLER	F27/61-36 R1
ND	83-11-34(A)	PREESTALL WARNING SYSTEM	F27/27-26
ND	83-20-57(A)	AILERON - INBOARD HINGE CONNECTION	F27/57-58
ND	84-44-32(A)	MATNICEAD AND DOORS	F27/32-152
ND	85-31(A)	RUDDER TRIM TAB CONTROL BRACKET	F27/55-30
ND	85-46/2(A)	ELEVATOR TRIM TAB	F27/55-31
ND	85-71(A)	WHEELS AND BRAKES	F27/32-156
ND	86-04(A)	DOOR HINGES AT FORWARD CABIN PARTITION BLKH	F27/25-58
ND		TORQUE PRESSURE TRANSMITTER	F27/77-12
	86-33(A)	VERTICAL STABILIZER	F27/55-62
ND	86-53(A)	COMBUSTION EQUIPMENT	F27/72-14
ND	86-60(A)	SMOKE DETECTOR FOR TOILET COMPARTMENT	F27/26-21
ND	86-65(A)		F27/32-157
ND	87-88(A)	UPPER FUSELAGE CABLELOOM	F27/24-77
ND	88-40(A)		F27/54-26 R2
ND	88-44/2(A)	UPPER NACELLE BRACE STRUTS	121/34 20 KZ
ND	88-55/3(A)	SKIN SPLICE AT STA 7915N	F27/53-109
ND	89-125(A)	FLIGHT COMPARTMENT WINDOW FRAMES	
ND	89-20(A)	EXTERNAL SKIN INSPECTION	F27/21-30 F27/27-132
ND	90-067(A)	CABLE TENSION REGULATOR BRAKE UNIT ASSYS	F27/27-130
ND	90-106(A)	ELEVATOR TRIM SYSTEM	
ND	90-109	COFFEEMAKER CAN PROTECTOR	DA27-25-001
			TDCDAET / AEDONIEES

MAKE | CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN FOKKER F27 MK300 (CONTINUED / SUITE)
ND 1991-113/4(A) CORROSION CONTROL PROGRAM SE-291 R2 91-038(A) BRAKE CONTROL VALVE ACTUATING LEVERS F27/32-161 91-041(A) MLG ASSEMBLY UPPER MEMBER ND F27/32-162 91-049(A) ND STRUCTURAL INTEGRITY PROGRAM 91-067(A) AGING AIRCRAFT MODIFICATIONS ND SE-278 F27/53-60 ND WING ATTACHMENT FITTING BOLTS ND 91-110(A) TRUSS MEMBER/RIB ATTACHMENT BOLTS F27/57-25 91-111/2(A) AN BOLTS REPLACEMENT F27/51-10 R2 91-112(A) FUSELAGE BRACKET HINGE
OUTER FLAP CENTRE HINGE
FLAP ACTUATOR NOISE FILTER CAPACITORS
MAIN WING TANK/COLLECTOR TANK FUEL LINE
MLG SLIDING MEMBER OUT-STOP ASSEMBLY ND FUSELAGE BRACKET ATTACHMENT FASTENERS F27/57-23 91-129(A) ND F27/57-22 F27/27-135 ND 92-076(A) ND 92-102/2(A) 92-121/3(A) F27/28-61 MLG SLIDING MEMBER OUT-STOP ASSEMBLY
LOWER SKIN AT STRINGERS 4 THROUGH 7
NOSE WHEEL STEERING MECHANISM
MLG DRAG STAY TUBES
OUTER SKIN LAPJOINTS BELOW FLOOR LEVEL
RUDDER HORN ASSEMBLY AND CONTROL ROD
OUTER WING RIB-TO-STRINGER CONNECTIONS
LH ELEVATOR TORQUE LINKS

AEM - PROCEDURES ND F27/32-165 93-094(A) F27/57-70 ND 93-132(A) ND F27/32-166 93-169/2(A) ND F27/32-167 F27/53-68 94-092(A) 94-105(A) ND F27/27-131 94-148(A) ND F27/57-68 94-148(A) OUTER WING RIB-TO-STRINGER CONNECTIONS
1995-007(A) LH ELEVATOR TORQUE LINKS
1996-130(A) AFM - PROCEDURES
1996-142(A) MLG ACTUATING RAM
1996-159/2(A) MLG SLIDING MEMBER PISTON ROD LOCKING
1997-094(A) NACELLE FUEL LINES
1999-053(A) FUSELAGE ATTACHMENT FITTINGS ND F27/55-66 ND ND F27/32-168 F27/32-165 ND ND F27/28-62 FUSELAGE ATTACHMENT FITTINGS ND FUSELAGE ATTACHMENT FITTINGS DC GENERATOR SYSTEM CONTROL PANEL SHOULDER HARNESS F27/57-54 ND 1999-093(A) F27/24-79 1999-139(A) ND F27/25-65 1970-024/6 MANDATORY AIRCRAFT MODIFICATIONS AND INSPECTIONS
1975-073 AILERON CONTROL CABLE DRUM INSPECTION/AD MODIFICATION CONTROL CABLE DRUM INSPECTION CABLE DRUM INSPECTION CABLE DRUM INSPECTION CABLE DRUM CABLE DR F27 MK400 ND 1970-024/6 AILERON CONTROL CABLE DRUM INSPECTION/ADJUSTMENT ND F27/27-109 R1 AILERON CONTROL ROD/LH DIFFERENTIAL CONNECTION ND F27/27-110 R1 ENLARGED CARGO CO...

AC LIGHTING POWER CONVERTERS
PROPELLER FEATHERING SYSTEM
PROPELLER CONTROL SYSTEM WIR
MATN INSTRUMENT PANEL FLUORE 1975-078 ND ENLARGED CARGO DOOR AND CREW DOOR INSPECTION F27/53-55 R1 ND 1976-103 AC LIGHTING POWER CONVERTERS MODIFICATION F27/24-63 F27/61-26 R1 1977-079 ND 1977-113/2 PROPELLER CONTROL SYSTEM WIRING MODIFICATION ND F27/61-29 R2 F27/33-34 F27/34-41 MAIN INSTRUMENT PANEL FLUORESCENT LAMP ND 1978-030 1978-040 PITOT STATIC TUBE REPLACEMENT ND ND 1978-057 DE-ICING RELAY PANEL & CABLE LOOM F27/30-34 NOSE LANDING GEAR WHEEL AXLE INSPECTION
CARGO DOOR HOOK LATCH MECHANISMSPECTION 1978-066 ND F27/32-129 F27/52-60 R1 1979-006/2 CARGO DOOR HOOK LATCH MECHANISMSPECTION
PROPELLER CONTROL WIRE SHIELDING INSTALLATION
MAIL ENTRANCE DOOR EMERGENCY OPERATION
GFARBOX ACCESS COWING DOOP MODIFICATION ND 1979-038 F27/61-35 R1 ND 1979-106 F27/52-61 1980-039 GEARBOX ACCESS COWLING DOOR MODIFICATION ND F27/71-27 F27/24-68 R1 1981-007/2 ND 2 COCKPIT & NACELLE CABLE LOOMS
2 FUEL TANK VENT DRAIN TUBINGMS
PITOT HEATING INDICATION CIRCUIT COCKPIT & NACELLE CABLE LOOMS ND 1981-019/2 F27/28-55 1981-053 ND F27/30-36 R1 1987-088 MLG TORQUE LINK ND F27/32-157 ND 1988-044/2 UPPER NACELLE BRACE STRUTS F27/54-44 1988-044/2 UPPER NACELLE BRACE STRUTS
1991-041 MLG ASSEMBLY UPPER MEMBER INSPECTION
1991-067 WING ATTACHMENT FITTING BOLTS
1991-112 FUSELAGE BRACKET ATTACHMENT FASTENERS REPLACE ND F27/32-162 ND F27/53-115 FUSELAGE BRACKET ATTACHMENT FASTENERS REPLACEMENT F27/57-23 R6
OUTER FLAP CENTRE HINGE INSPECTION/REPAIR F27/57-66 ND 1991-112 1991-129
1993-169/2
1994-092
1996-130
OUTER FLAP CENTRE HINGE INSPECTION
OUTER FUSELAGE SKIN LAPJOINTS MODIFICATION
AFM CHANGE - CRUISE LOCK HPC LEVER IN LOCKOUT POS 1991-129 ND ND F27/32-167 ND F27/53-116 ND F27/61-40 ND 1999-053(A) 1999-093(A) 1999-139(A) STABILIZER DE-ICE MONITORING SYSTEM F27/30-44 ND FUSELAGE ATTACHMENT FITTINGS F27/57-77 DC GENERATOR SYSTEM CONTROL PANEL ND F27/24-79 ND 1999-139(A) SHOULDER HARNESS F27/25-65 F28 MK 1000 CF CF-93-04 EMERGENCY LIGHTING - MODIFICATION F28/33-26, -35 FUEL SUPPLY LINE WING FLAPS - VANE DRIVE MECHANISM ND 70-01-28 F28/28-8 ND 70-119-27 F28/27-41 PRESSURE FUELLING SYSTEM CHECK VALVE 70-12-28 ND F28/28-3 ND 70-121-29 FLUID QUANTITY INDICATING SYSTEM - CIRCUIT WIRING F28/29-18 70-15-76 HYDRAULIC SYSTEM FIRE SHUT-UFF VALVE ND F28/76-2 70-18-26 ND ENGINE FIRE EXTINGUISHING SYSTEM F28/26-2 OIL TEMPERATURE INDICATION SYSTEM ND 70-19-24 F28/24-4 ND 70-25-32 LANDING GEAR DOOR CABLE GUIDE & PULLEY F28/32-31 ND 70-36-29 HYD RESERVOIR LOW AIR PRESSURE INDICATING SYSTEM F28/29-13

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

	5		
FOKKE	<i>R</i> MK 1000		
(CONT	INUED / SUITE)		
ND	70-37-27	· · · · · · · · · · · · · · · · · · ·	
ND	70-50-27/3	AILERON TAB DRIVE	F28/27-22
ND	70-54-53	WING FLAP MECHANICAL ACTUATORS	F28/27-27
ND	70-55-25	SPEEDBRAKE ACCUMULATOR BRACKETS ANTISLIP ESCAPE ROUTE	F28/53-4
ND	70-60-54	NACELLES (STURWING EIDEWALL LOLE DIANKED OFF	F28/25-10
ND	70-61-76/4	NACELLES/STUBWING FIREWALL HOLE BLANKED OFF FLUID FIRE SHUT-OFF VALVES HORIZONTAL STABILIZER CONTROL LANDING GEAR DOOR RETRACTION SYSTEM APU - FUEL SOLENOID VALVE	F28/54-2
ND	70-69-27	HORIZONTAL STABILIZED CONTROL	F28/76-A3
ND	70-70-32	LANDING GEAR DOOR RETRACTION SYSTEM	F28/2/-30 F28/22-4F
ND	70-86-49/2	LANDING GEAR DOOR RETRACTION SYSTEM  APU - FUEL SOLENOID VALVE  FLAP SUPPORT STRUCTURE / RAIL BOX  AC POWER SUPPLY VERTICAL GYRO  AILERON CONTROL UNIT  ENGINE DRIVEN HYDRAULIC PUMPS  HORIZONTAL STABILIZER CONTROL UNIT  OUTER WING STRUCTURE - REAR SPAR  LIFT DUMPER SYSTEM - ELECT CONTROL CIRCUIT  ALTERNATE CONTROL & RELEASE SYSTEM	F28/49-9R1
ND	70-94-57	FLAP SUPPORT STRUCTURE / RAIL BOX	F28/57-5
ND	70-96-24	AC POWER SUPPLY VERTICAL GYRO	F28/24~5
ND	70-99-27	AILERON CONTROL UNIT	F28/27-32
ND	71-02-29 71-11-27 71-17-57 71-18-27	ENGINE DRIVEN HYDRAULIC PUMPS	F28/29-7
ND	71-11-27	HORIZONTAL STABILIZER CONTROL UNIT	F28/27-31
ND	71-17-57	OUTER WING STRUCTURE - REAR SPAR	F28/57-3
ND	71-18-27 71-21-32	LIFT DUMPER SYSTEM - ELECT CONTROL CIRCUIT	F28/27-14
ND	71-21-32 71-29-27 71-42-34	ALTERNATE CONTROL & RELEASE SYSTEM	F28/32-60
ND ND	71-29-27	AILERON CONTROL SYSTEM - ANTI ROTATION DEVICE	F28/27-47
ND ND	71-42-34 71-47-76	FLIGHT SYSTEM - WIRING COMPASS MONITOR	F28/34-14R1
ND	/1-4/-/0	FIRE SHUT-OFF SYSTEM - FLIGHT REFUELLING VALVES	F28/76-10
ND	71-48-28	FLIGHT REFUELLING VALVES	F28/28-18
ND	71-48-28 71-55-32/2 71-62-27 71-63-29	MAIN GEAR ACTUATOR BEARING AILERON TAB DRIVE MECHANISM	F28/32-72
ND	71-63-29	HYDRAULIC ACCUMULATORS DRAIN LINE	F28/27-55
ND	71-72-53	AUX STRUCTURE - MAIN JUNCTION BOX & OXYGEN BOTTLE	F28/29-21
ND	71-84-57	AILERON SERVO TABS	
ND	72-04-27	HORIZONTAL STABILIZER CONTROL SYSTEM	F28/57-33 F28/27-28
ND	72-18-55	HODIZONIAI STADILIZED	F28/55-8
ND	72-20-53	ATTACH FITTING SPEEDBRAKE SUPPORT STRUCTURE	F28/53-26
ND	72-33-25	PILOT SEAT INSTALLATION ~ BACK REST	F28/25-38
ND	72-39-27	FLAP ASSEMETRY PROTECTION SYSTEM	F28/27-68
ND	72-55-27	AILERON TAB LOCK OUT ACTUATOR ASSEMBLY	F28/27-78
ND	72-56-25 72-57-27	ESCAPE CHUTE – LOCK PIN LOCKING WIRE ELEVATOR BOOST CONTROL UNIT – STICK SWITCH	F28/25-41
ND	72-57-27	ELEVATOR BOOST CONTROL UNIT - STICK SWITCH	F28/27-A82
ND	72-69-28	FUEL LINES WING FAIRINGS APU CHECK VALVE - BLEED AIR SUPPLY INSTRUMENT LIGHTING - BUS CONNECTIONS BLEED AIR SYSTEM -FIRE SEAL IN NACELLE HORIZONTAL STABILIZER HINGE - BEARING MOUNTING	F28/28-22
ND	73-11-36	APU CHECK VALVE - BLEED AIR SUPPLY	F28/36-9
ND	73-26-33	INSTRUMENT LIGHTING - BUS CONNECTIONS	F28/33-11
ND	73-57-36	BLEED AIR SYSTEM -FIRE SEAL IN NACELLE	F28/36-10
ND	73-59-55	HORIZONTAL STABILIZER HINGE - BEARING MOUNTING	F28/55-14
ND	73-64-11	3RD CREW MEMBER DXYGEN INSTALLATION	F28/11-20
ND ND	73-67-24	AC GENERATOR SUPPLY CABLES	F28/24-17
ND	74-13-24	ELECTRICAL POWER - CABLE LOOM ELEVATOR BOOST UNIT	F28/24-22 F28/27-98
ND	73-64-11 73-67-24 74-13-24 74-14-27 74-16-52	DACCENCED DOOD - CLIDING DING	F20/27-90 F20/E2-44
ND	74-18-76	POWER CONTROLS - HPC & RPM CONTROL CARLES	F28/76-16
ND	74-20-52	PASSENGER DOOR LOCKING MECHANISM	F28/52-43
ND	74-21-49	APIL - FUEL CONTROL UNIT	F28/49-16
ND	74-34-52	PASSENGER DOOR - SLIDING PINS  POWER CONTROLS - HPC & RPM CONTROL CABLES  PASSENGER DOOR LOCKING MECHANISM  APU - FUEL CONTROL UNIT  CARGO DOORS - LOCK MECHANISM  REAR CARGO DOOR LOCK  CARGO DOORS - LATCH MECHANISM	F28/52-53
ND	74-41-52	REAR CARGO DOOR LOCK	F28/52-54
ND	74-57-52		F28/52-56
ND	74-58-25	PASSENGER COMPARTMENT - HATRACK PANELS	F28/25-35
ND	74-59-25	PASSENGER COMPARTMENT - HATRACK PANEL LOCKING	F28/25-56
ND	74-63-52	CARGO DOORS - LOCK WARNING SWITCH	F28/52-49
ND	74-64-52	CARGO DOORS - SAFETY CATCH & STOP ASSEMBLY	F28/52-51
ND	74-73-55	MORIZONIAL STABILIZER CONTROL UNIT	F28/27-103
ND	75-11-22	AUTOPILOT	F28/22-9
ND	75-28-27	LIFTDUMPER SYSTEM	F28/27-109
ND	75-52-52	REAR CARGO DOOR SAFETY CATCH	F28/52-61
ND	75-56-51	CARGO DOOR WASHERS	F28/51-10 F28/53-54
ND ND	75-57-53	CARGO DOOR INSP &/OR WASHER REPLACEMENT HORIZONTAL STABILIZER	F28/55-17
ND ND	75-88-55 76-112-27	WING FLAP MECHANICAL ACTUATORS	F28/27-126
ND	76-112-27	NOSE GEAR STRUT	F28/32-119
ND	76-12-32	AILERON TRIM & MECHANICAL CONTROL SYSTEM	F28/27-92
ND	76-23-49	APU EXHAUST SILENCER ASSEMBLY	F28/49-24
ND	76-24-32	ANTI SKID SYSTEM - WHEEL SPEED GENERATORS	F28/32-117
ND	76-27-52/2	SERVICE EMERGENCY DOOR GUIDE RAILS	F28/52-66
ND	76-30-27	AILERON TRIM / MECHANICAL CONTROL SYSTEM	F28/27-92
ND	76-43-27/2	FLAP CONTROL SYSTEM AUTOMATIC RESET	F28/27-112R2
ND	76-89-25	PILOT/CO-PILOT SEATS LOCKING MECHANISM	F28/25-71
ND	77-40-24	ELECTRICAL POWER CABLES	F28/24-29
ND	77-82-11	PLACARDS DOORS - PASSENGERS / EMERGENCY	F28/11-34
			ATDODAET /AEDONESS

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

	R MK1000 INUED / SUITE) 77-83-25/2 77-84-49 77-96-52 78-13-52 78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-27 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2 84-38-27	OBSERVER SEAT BELT / SHOULDER HARNESS  APU - ENCLOSURE DRAIN  CARGO DOOR LOCKING HANDLE  CARGO DOOR - LOCK WARNING SWITCH  SMITH AUTOPILOT PITCH MONITOR COMPUTER  EVACUATION LIGHTS / CABIN ENTRANCE  ENGINE FIRE SHUT-OFF SYSTEM  FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM  WING FLAP MECHANICAL ACTUATORS  ELECTRICAL POWER - TIME DELAY RELAY  LANDING GEAR - ANTI SKID SYSTEM  APU FUEL TUBE - ELECTRICAL WIRING  ELECTRICAL CABLE LOOMS  WING FLAP MECHANICAL ACTUATORS  HORIZONTAL STABILIZER HINGE BOLT LOCKING  AUTO PILOT  FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER  HYDRAULIC RESËRVÖIR MANIFOLD GASKET  STRUCTURAL INTEGRITY PROGRAM  AUTOFLIGHT - PITCH / ROLL COMPUTER	F28/27-136 F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
F 28 ( CONT	MK 1000 INUED / SUITE) 77-83-25/2 77-84-49 77-96-52 78-13-52 78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	APU - ENCLOSURE DRAIN CARGO DOOR LOCKING HANDLE CARGO DOOR - LOCK WARNING SWITCH SMITH AUTOPILOT PITCH MONITOR COMPUTER EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/49-25 F28/52-81 F28/52-80 SMITH 22-1002 F28/33-24 F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/24-27 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/22-13 F28/29-36
(CONT ND	INUED / SUITE) 77-83-25/2 77-84-49 77-96-52 78-13-52 78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	APU - ENCLOSURE DRAIN CARGO DOOR LOCKING HANDLE CARGO DOOR - LOCK WARNING SWITCH SMITH AUTOPILOT PITCH MONITOR COMPUTER EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/49-25 F28/52-81 F28/52-80 SMITH 22-1002 F28/33-24 F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/24-27 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/22-13 F28/29-36
ND N	77-83-25/2 77-84-49 77-96-52 78-13-52 78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	APU - ENCLOSURE DRAIN CARGO DOOR LOCKING HANDLE CARGO DOOR - LOCK WARNING SWITCH SMITH AUTOPILOT PITCH MONITOR COMPUTER EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/49-25 F28/52-81 F28/52-80 SMITH 22-1002 F28/33-24 F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/24-27 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/22-13 F28/29-36
ND N	77-84-49 77-96-52 78-13-52 78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	APU - ENCLOSURE DRAIN CARGO DOOR LOCKING HANDLE CARGO DOOR - LOCK WARNING SWITCH SMITH AUTOPILOT PITCH MONITOR COMPUTER EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/49-25 F28/52-81 F28/52-80 SMITH 22-1002 F28/33-24 F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/24-27 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/22-13 F28/29-36
ND N	78-13-52 78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	CARGO DOOR LOCKING HANDLE CARGO DOOR - LOCK WARNING SWITCH SMITH AUTOPILOT PITCH MONITOR COMPUTER EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESÉRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/52-81 F28/52-80 SMITH 22-1002 F28/33-24 F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/24-31 F28/25-137 F28/25-21 F28/22-13 F28/26-12 F28/26-12 F28/29-36
ND N	78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	SMITH AUTOPILOT PITCH MONITOR COMPUTER EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	SMITH 22-1002 F28/33-24 F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/22-13 F28/29-36
ND N	78-26-22 78-96-33 1979-007/2(A) 79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	SMITH AUTOPILOT PITCH MONITOR COMPUTER EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/33-24 F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/24-31 F28/25-21 F28/25-21 F28/26-12 F28/29-36
ND N	1979-007/2(A) 79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	EVACUATION LIGHTS / CABIN ENTRANCE ENGINE FIRE SHUT-OFF SYSTEM FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESERVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/76-20 F28/25-82 F28/27-136 F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/26-12 F28/29-36
ND ND ND ND ND ND ND ND ND ND ND ND ND	79-05-25 79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	FLIGHT COMPARTMENT - SEAT LOCKING MECHANISM WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/25-82 F28/27-136 F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND N	79-34-27 79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	WING FLAP MECHANICAL ACTUATORS ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESERVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/27-136 F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND N	79-36-24 79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	ELECTRICAL POWER - TIME DELAY RELAY LANDING GEAR - ANTI SKID SYSTEM APU FUEL TUBE - ELECTRICAL WIRING ELECTRICAL CABLE LOOMS WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESERVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/24-27 F28/32-127 F28/28-32R1 F28/24-31 F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND N	79-37-32 79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESERVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND N	79-80-28/2 79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESERVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND N	79-94-24 80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESERVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND ND ND ND ND ND ND	80-08-27 80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	WING FLAP MECHANICAL ACTUATORS HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESÉRÝOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/27-137 F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND ND ND ND ND ND	80-37-55/2 80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	HORIZONTAL STABILIZER HINGE BOLT LOCKING AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/55-21 F28/22-13 F28/26-12 F28/29-36
ND ND ND ND ND	80-60-22/3 81-55-26/2 81-68-29 82-026/2 83-35-22/2	AUTO PILOT FIRE PROTECTION – PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/22-13 F28/26-12 F28/29-36
ND ND ND ND ND	81-55-26/2 81-68-29 82-026/2 83-35-22/2	FIRE PROTECTION – PORTABLE FIRE EXTINGUISHER HYDRAULIC RESËRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/26-12 F28/29-36
ND ND ND	81-68-29 82-026/2 83-35-22/2	HYDRAULIC RESÉRVOIR MANIFOLD GASKET STRUCTURAL INTEGRITY PROGRAM	F28/29-36
ND ND ND	82-026/2 83-35-22/2	STRUCTURAL INTEGRITY PROGRAM	
ND ND	83-35-22/2	AUTOFI TOUT DITCH / DOLL COMPUTED	SIP DOC 28438
ND	84-38-27	AUTUELIGHT - PITCH / RULL COMPULER	F28/22-17, -18
		HORIZONTAL STABILIZER HYD CONTROL SYSTEM	F28/27-156
	84-45-33	EMERGENCY LIGHTING SYSTEM	F28/33-32
ND	85-087/2	MLG BAY CUTOUT LOWER OUTBOARD EDGE INSPECTION	57-76 R1
ND	85-36	MODIZONIAL STABILIZED - CONTROL LINIT	F28/27-161
ND	85-78/2	STOPS - RUDDER FLIGHT CONTROL PEDAL	F28/27-158R1
ND	85-87/2		F28/57-76R1
ND	86-08/2	HORIZONTAL STABILIZER - CONTROL UNIT SMOKE DETECTOR TOILET COMPARTMENT	F28/27-168R1
ND	86-64	SMOKE DETECTOR TOILET COMPARTMENT	F28/26-15
ND	87-16	ENGINE EXHAUSI COLLECTOR	F28/78-1
ND	88-30	WINGS - FLAP TRACK BEAM SUPPORT BRACKET LIGHTING BALLAST TRANSFORMER FUSELAGE LAP JOINT AT STRINGER 73	F28/57-81
ND	88-31	LIGHTING BALLAST TRANSFORMER	F28/33-34
ND	1990-006/3(A)	FUSELAGE LAP JOINT AT STRINGER 73	F28/53-A93R1
ND	90-063/2(A)	AGING AIRCRAFT MODIFICATIONS	SE 243
ND	90-097	AILERON DUAL QUADRANT MOUNTING BRACKET	F28/27-177
ND	90-126	COLD-BONDED LONGITUDINAL FUSELAGE LAPJOINTS	53-109
ND	1991-051/4(A)	CORROSION CONTROL PROGRAM	SE-253 REV 4
ND	91-003	INSP HORIZONTAL STAB ATTACH FITTINGS	F28/55-28
ND ND	91-022/2 91-055	LAPJOINT BETWEEN STA. 13345 & 14285	SBF28/21-16
ND	91-080/2	CENTRE WING-TO-FUSELAGE SKIN CONNECTION - MOD MLG MAIN FITTING SUB-ASSY - INSPECTION	F28/53-101
ND	1992-077/2(A)	FLIGHT CNTRL HORZ STAB ACTUATOR SERVO VALVE INSP	DOWTY 32-161R REV 2 F28/27-180, -183
ND	1992-117/3(A)	PASSENGER DOOR LOCK WARNING SYSTEM	F.28/52-101R1, -112
ND	92-101/4	STAB - ELEV GUST LOCK & SUPPORT STRUCT INSP/REP	F28/55-30
ND	92-119	HORIZONTAL STABILIZER ATTACHMENT FITTINGS	F.28/55-29
ND	93-004(A)	CONTROL COLUMN AILERON CHAIN REPLACEMENT	F28/27-181
ND	93-055(A)	CARGO DOOR HINGES	F28/52-110
ND	94-095(A)	LDG - MLG HYDRAULIC CONTROL SYS FLEX LINE	F.28/32-123 R1
ND	94~163(A)	MLG DOWNLOCK ACTUATOR - PRE-LOAD ADJUSTMENT	F28/32-153
ND	1995-126(A)	REAR CARGO DOOR & AUXILIARY STRUCTURE	F28/52-111
ND	1996-081(A)	1 10 10 11 17 17 17 17 17 17 17 17 17 17 17 17	/
ND	1996-103(A)	MLG TORQUE LINK DAMPERS - INSTALLATION FRAME STA. 10790 COUPLING FITTING BOLTS	F28/32-151
ND	1996-119(A)	FRAME STA. 10790 COUPLING FITTING BOLTS	F28/53-125
ND	1999-028/2(A)	MAIN DECK LARGE CARGO DOOR HINGE	F28/52-114
ND	1999-045(A)	MAIN LANDING GEAR ATTACHMENT BRACKET	F28/57-90
ND	1999-114(A)	FUEL BOOST PUMP WIRING	F28/28-46
ND	1999-117(A)	ANTI-SKID SYSTEM & LIFTDUMPERS	F28/32-116 R2
ND	1999-138(A)	MLG TORQUE LINK SERIES	F28/32-157
ND	1999-139(A)	SHOULDER HARNESS	F28/25-103
F00 *	41/4/0000		
r 28	MK1000C		
F20 P	MK3000		
ND N		ENGINE FIRE SHUT-OFF SYSTEM	F00/70 00
ND	1979-007/2(A) 80-60-22/3		F28/76-20
ND	81-55-26/2	AUTO PILOT FIRE PROTECTION - PORTABLE FIRE EXTINGUISHER	F28/22-13 F28/26-12
ND	81-68-29	HYDRAULIC RESERVOIR MANIFOLD GASKET	F28/29-36
ND	82-026/2	STRUCTURAL INTEGRITY PROGRAM	SIP 28438
ND	83-35-22/2	AUTOFLIGHT - PITCH / ROLL COMPUTER	F28/22-17, -18
ND	84-38-27	HORIZONTAL STABILIZER HYD CONTROL SYSTEM	F28/27-156
ND	84-45-33	EMERGENCY LIGHTING SYSTEM	F28/33-32
ND	85-087/2	MLG BAY CUTOUT LOWER OUTBOARD EDGE INSPECTION	57-76 R1
ND	85-36	HORIZONTAL STABILIZER - CONTROL UNIT	F28/27-161
	CDAFT / AFDONESS		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NOWERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
FOKKER				
F28 M				
	NUED / SUITE)			
ND	85-44		WINGS - BUTT SPLICES - RESEALING	F28/57-70
ND	85-45/2		MODIFIED BOUNDRY LAYER FENCE	F28/57-75
ND	85-78/2		STOPS - RUDDER FLIGHT CONTROL PEDAL	F28/27-158 REV 1
ND	86-08/2		HORIZONTAL STABILIZER - CONTROL UNIT	F28/27-168 R1
ND ND	86-64 87-16		SMOKE DETECTOR TOILET COMPARTMENT	F28/26-15
ND	88-30		ENGINE EXHAUST COLLECTOR	F28/78-1
ND	88-31		WINGS - FLAP TRACK BEAM SUPPORT BRACKET	F28/57-81
ND	89-50		LIGHTING BALLAST TRANSFORMER LAP JOINT AT STRINGER 73	F28/33-34
ND	1990-006/3(A)		FUSELAGE LAP JOINT AT STRINGER 73	F28/53-A93 F28/53-A93R1
ND	90-063/2(A)		AGING AIRCRAFT MODIFICATIONS	SE-243
ND	90-097		AILERON DUAL QUADRANT MOUNTING BRACKET	F28/27-177
ND	1991-051/4(A)		CORROSION CONTROL PROGRAM	SE-253 REV 4
ND	91-022/2		LAPJOINT BETWEEN STA.13345 & 14285	SBF28/21-16
ND	91-080/2		MLG MAIN FITTING SUB-ASSY - INSPECTION	DOWTY 32-161R REV :
ND ND	1992-077/2(A)		FLIGHT CNTRL HORZ STAB ACTUATOR SERVO VALVE INSP	F28/27-180, -181
ND	1992-117/3(A) 92-101/4		PASSENGER DOOR LOCK WARNING SYSTEM	F28/52-72
ND	92-119		STAB - ELEV GUST LOCK & SUPPORT STRUCT INSP/REP HORIZONTAL STABILIZER ATTACHMENT FITTINGS	F28/55-30
ND	93-004(A)		CONTROL COLUMN AILERON CHAIN REPLACEMENT	F28/55-29
ND	93-055(A)	***************************************	CARGO DOOR HINGES	F28/27-181 F28/52-110
ND	94-095(A)		LDG - MLG HYDRAULIC CONTROL SYS FLEX LINE	F28/32-123 R1
ND	94-163(A)		MLG DOWNLOCK ACTUATOR - PRE-LOAD ADJUSTMENT	F28/32-153
ND	1995-126(A)		REAR CARGO DOOR & AUXILIARY STRUCTURE	F28/52-111
ND	1996-081(A)		LAPJOINT AT STRINGER 16/17 AND 58/59	F28/53-121
ND	1996-103(A)		MLG TORQUE LINK DAMPERS - INSTALLATION	F28-32-151
ND	1996-119(A)		FRAME STA. 10790 COUPLING FITTING BOLTS	F28/53-125
ND	1999-028/2(A)		MAIN DECK LARGE CARGO DOOR HINGE	F28/52-114
ND	1999-045(A)		MAIN LANDING GEAR ATTACHMENT BRACKET	F28/57-90
ND ND	1999-114(A)		FUEL BOOST PUMP WIRING	F28/28-46
ND ND	1999-117(A) 1999-138(A)		ANTI-SKID SYSTEM & LIFTDUMPERS	F28/32-116 R2
ND	1999-139(A)		MLG TORQUE LINK SERIES SHOULDER HARNESS	F28/32-157 F28/25-103
			on boose in the management of the second of	120,20 100
ORNEY F 1 SE	RIFS			
US	86-22-09		FUEL LINE NIPPLE	24A
F 1		( F 1	SERIES )	
US	57-02-01	, , ,	RUDDER HORN ATTACHMENT	
US	59-25-05		RUDDER REINFORCEMENT	
US	60-09-02		NOSE GEAR BOLTS	
US	67-06-03		RUDDER BELLCRANK	
US	94-18-04R1		WING STRUCTURE	29 REV B
F 4.4		( = 4	CEDIEC )	
F 1A US	EQ-2E-0F	( F 1	SERIES ) RUDDER REINFORCEMENT	
US	59-25-05 67-06-03		RUDDER BELLCRANK	
US	94-18-04R1		WING STRUCTURE	29 REV B
			THE STRUCTURE	
DUND B				
FBA 20	CF-65-02		TAILPLANE BOX ATTACH FITTINGS	
CF	CF-65-04		TAILPLANE BOX	
CF	CF-66-06		FORWARD WING / FUSELAGE ATTACHMENT	
	00 00			
100			- /	
CF	CF-69-13		MLG / WHEEL AXLE BLOCK WELDED JOINT	
UNK				
B85C				
ALAXY	BALLOON			
GALAXY				
ARDAN				
GY 80	160			
FR	63-020-001		PROP CONE BRACKET PLATE	
FR	64-001-002		FUEL SHUT OFF	
FR	64-006-003		MODIFICATIONS	
FR	64-007-004		ELEVATOR CONTROL	
FR	64-023-005		NON-RETURN VALVE	

MODEL /		(SERIES / SERIE)	
ORIGIN ORIGINE		SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
GARDAN	1		
GY 80	160		
	NUED / SUITE)		
FR	65-007-006	OIL COOLER	
FR FR	65-023-007	OIL TEMP SENSOR	
FR	66-032-008 66-040-009	RH MUFFLER AIR INLET BOX	
FR	67-005-010	OIL COOLER	
FR	67-006-011	MLG ACTUATOR	
FR	67-033-012	MUFFLER	
FR	67-040-012	FUEL DISTRIBUTION	
FR FR	72-016(A) 89-105(A)R3	FRONT SEAT ELECTRIC FUEL PUMP DIAPHRAGM	113/2
GENERA G1 80	L AIRCRAFT		
GLASER	DIRKS		
DG 10			
GY	75-262	UPPER RUDDER HINGE	301-3
GY	76-261	WHEEL BRAKE CABLE / CONTROL STICK	301-2
GY	77-123	AILERON CONTROL COCKPIT AREA	301-4
GY	78-164	ELEVATOR CONTROL BRACKET	301-6
GY GY	78-61 85-126	TAILPLANE ASSEMBLY	301-5
GY	86-136	SERVICE LIFE CANOPY EMERGENCY RELEASE	301-11 301-14
GY	89-131	MAIN FITTING L4	301-14
GΥ	97-011	AIRBRAKE TORQUE TUBES AND AIRBRAKES	TECH NOTE 301/18
DG 20			
GΥ	79-313	WING SPAR REINFORCEMENT	323-1
GY GY	85-80 86-136	FLIGHT & MAINT MANUALS	323/5
GY	97-011	CANOPY EMERGENCY RELEASE AIRBRAKE TORQUE TUBES AND AIRBRAKES	323-6 TECH NOTE 323/9
DG 20	0/17		
GY	85-80	FLIGHT & MAINT MANUALS	323/5
GY	86-136	CANOPY EMERGENCY RELEASE	323-6
DG 30	0		
GY	86-136	CANOPY EMERGENCY RELEASE	359-9
GY	87-14	MASS BALANCE OF AILERONS	359-11, 12
GY GY	88-59	C OF G - PILOTS POSITION	359-13
GY	89-22	AIRBRAKE/WING ROOT	359-14
DG 40			
GY	84-157	POWER PLANT VIBRATION CRACKS	TN 826/11
GY	88-99	FOUR ITEMS SEE TECH NOTE	T.N. 826/20
GY GY	90-43 91-149	PROPELLER REAR MOUNTING HOLES MANUALS REV-INSP. PROPSHAFT-REPL. FUEL HOSES	TN 826/22
GY	96-242	ELECTRICAL SYSTEM REGULATOR	826/24 & 826/25 826/33
GY	96-243	POWER PLANT PROPELLER SHAFT	826/32
GY	97-011	AIRBRAKE TORQUE TUBES AND AIRBRAKES	TECH NOTE 826/34
DG 60	0		
GLASFL	UGEL		
MOSQU	ITO		
GY	79-322	CANOPY EMERGENCY JETTISONING SYSTEM	303-9
GY	84-11	WING STRUCTURE - WATER BALLAST BAGS	304-2
GY GY	88-28 88-281	ELEVATOR DRIVE BRACKET SERVICE LIFE EXTENSION	303-12
GY	95-102	CARBON FIBRE AILERONS	303-13 303-21
MOSQU	ІТО В		
GY	79-322	CANOPY EMERGENCY JETTISONING SYSTEM	303-9
GY	84-11	WING STRUCTURE - WATER BALLAST BAGS	304-2
GY	88-28	ELEVATOR DRIVE BRACKET	304-3
GY	88-281	SERVICE LIFE EXTENSION	304-4
GY	91-111	CANOPY MOUNTING STUDS	303-18
GY	95-102	CARBON FIBRE AILERONS	303-21
	LIBELLE 201		
GY GY	67-3	TOST COUPLING 53 - TOWING CABLE DEFLECTORS	23
GY	68-82	HORIZONTAL TAIL SURFACES - ELEVATOR ASSEMBLY	25

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

			BULLETIN DE SERVICE DE REF.
CLASEL	HCEL		
GLASFL			
SIND	LIBELLE 201		
(CONTI	NUED / SUITE)		
GY	71-10	RUDDER CABLES	201-6
GY	73-80	RUDDER CONTROL STOP FLIGHT CONTROL CABLE CONNECTIONS TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72,SH72	201-6
GY	74-323/2	FLIGHT CONTROL CARLE CONNECTIONS	201-15
GY	74-5	TOWING FOULDMENT NICES COUNTY THE	
GY	75-168/2	ELEVATOR GUIDE ASSEMBLY ELEVATOR LINKAGE SERVICE LIFE RUDDER CONTROL CABLES	
GY	75 108/ 2	ELEVATOR GUIDE ASSEMBLY	201-20
	80-207	ELEVATOR LINKAGE	201-22
GY	83-207	SERVICE LIFE	201-24
GY	87-83	RUDDER CONTROL CABLES	201-26
GY	94~265	EXTENSION OF SERVICE LIFE GLASS FIBER LAMINATE COVERING THE SPAR STUB FITTIN WEIGHT AND STATIC MOMENT OF CONTROL SURFACES	201.20
GY	96-131	GLASS FIRED LAMINATE COVEDING THE CDAR CTUR FITTING	001 01
GY	96-137	WEIGHT AND CTATTO MOMENT OF CONTROL SHARE STUB FILLIN	201-31
	30 107	WEIGHT AND STATIC MOMENT OF CONTROL SURFACES	201-32
CTND	LIBELLE COLO		
	LIBELLE 201B		
GY	67-3	TOST COUPLING 53 - TOWING CABLE DEFLECTORS	23
GY	68-82	HORIZONTAL TAIL SURFACES - ELEVATOR ASSEMBLY	25
GY	68-82 71-10	RUDDER CABLES	201-0
GY	73-80	RUDDER CABLES RUDDER CONTROL STOP	201-6
GY	74-323/2	ELICUT CONTROL GADIE CONNECTIONS	201-15
GY	74-5	TOWING FOUNDATION AND TOWING TOWING	
	75 100/0	RUDDER CONTROL STOP FLIGHT CONTROL CABLE CONNECTIONS TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72,SH72 ELEVATOR GUIDE ASSEMBLY	
GY	75-168/2	ELEVATUR GUIDE ASSEMBLY	201-20
GY	80-207	ELEVATOR LINKAGE	201-22
GY	83-207	SERVICE LIFE	201-24
GY	84-11	WING STRUCTURE - WATER BALLAST BAGS	201-25
GY	87-83	RUDDER CONTROL CABLES	
GY	94-265 96-116 96-131	RUDDER CONTROL CABLES  EXTENSION OF SERVICE LIFE	
GY	06-110	ATTERON ACTUATION CHART	TECH NOTE 201-29
	96-116	AILERON ACTUATING SHAFT	TECH NOTE 201-33
GY			201-31
GY	96-137	WEIGHT AND STATIC MOMENT OF CONTROL SURFACES	201-32
CLUB I	LIBELLE 205		
GY	74-5	TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72,SH72 ELEVATOR GUIDE ASSEMBLY ELEVATOR DRIVE BRACKET	
	75-160/0	ELEVATOR CUITE ACCEMBLY	005 0
GV	75-168/2	ELEVATOR GOIDE ASSEMBLY	205-6
GY	88-28	ELEVATOR DRIVE BRACKET	205-16
GY	88-280/2	EXTENSION OF SERVICE LIFE	206-12
GY	96-132	GLASS FIBER LAMINATE COVERING THE SPAR STUB FITTIN	205-19
GΥ	96-138	ELEVATOR GUIDE ASSEMBLY ELEVATOR DRIVE BRACKET EXTENSION OF SERVICE LIFE GLASS FIBER LAMINATE COVERING THE SPAR STUB FITTIN WEIGHT AND STATIC MOMENT OF CONTROL SURFACES ELEVATOR MASS AND RESIDUAL MOVEMENT	205-20
GY	1997-311/2	ELEVATOR MASS AND RESTRIAL MOVEMENT	206-19
	1001 011/2	CELTATION PROGRAMO RESTRONE PROVENERY	200 13
HORNET	7 206		
	206	TOUTNO FOULTBURNT NOOF COURT THE ED. FEG. OFF CHIEF	
	74-5	TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72,SH72 AILERON MASS BALANCE WING STRUCTURE - WATER BALLAST BAGS ELEVATOR DRIVE BRACKET EXTENSION OF SERVICE LIFE CANDRY MOUNTING STUDS	
GY	80-221	AILERON MASS BALANCE	206-9
GY	84-11	WING STRUCTURE - WATER BALLAST BAGS	206-11
GY	88-28	ELEVATOR DRIVE BRACKET	206-12
GY	88-280/2	EXTENSION OF SERVICE LIFE	TN 206-12
GY	91-111	CANOPY MOUNTING STUDS	206-16
GY	91-111 96-132	GLASS FIBER LAMINATE COVERING THE SPAR STUB FITTIN	
ur	30 132	GENSS FIDER EMPIRATE COVERTING THE SPAR STOR FITTIN	200 17
LEDGII	F 11001		
	E H301		
GY	67-3	TOST COUPLING 53 - TOWING CABLE DEFLECTORS HORIZONTAL TAIL SURFACES - ELEVATOR ASSEMBLY RUDDER CABLES RUDDER CABLE STOP	23
GY	68-82	HORIZONTAL TAIL SURFACES - ELEVATOR ASSEMBLY	25
GY	71-10	RUDDER CABLES	301-27
GY	73-80	RUDDER CABLE STOP	201-15
GY	74-323/2	FLIGHT CONTROL CABLE CONNECTIONS	
GY	74-5	TOWING FOLLIPMENT - NOSE COURLING 72 F72 S72 SH72	
CV	75 100/0	ELEVATOR CUITRE ACCEMBLY	301-30
GY	/5-168/2	TELINION GOIDE NOOTHER	
GY	80-207	ELEVATOR LINKAGE	301-31
GT	03-201	SERVICE LIFE	301-32
GY	87-83	RUDDER CONTROL CABLES	301-33
GY	96-131	GLASS FIBER LAMINATE COVERING THE SPAR STUB FITTIN	301-36
GY	96-137	WEIGHT AND STATIC MOMENT OF CONTROL SURFACES	301-37
······			
LIBELL	E H301B		
		TOST COUPLING 53 - TOWING CABLE DEFLECTORS	23
GY	67-3		
GY	68-82	HORIZONTAL TAIL SURFACES - ELEVATOR ASSEMBLY	25
GY	71-10	RUDDER CABLES	301-27
GY	73-80	RUDDER CABLE STOP	201-15
GY	74-323/2	FLIGHT CONTROL CABLE CONNECTIONS	
GY	74-5	TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72, SH72	
		ELEVATOR GUIDE ASSEMBLY	301-30
GY	75-168/2		301-30
GY	80-207	ELEVATOR LINKAGE	
GY	83-207	SERVICE LIFE	301-32
GY	87-83	RUDDER CONTROL CABLES	301-33

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT
SUBJECT
SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET		BULLETIN DE SERVICE DE REF.
GLASFLI	UGEL			
	LE H301B			
	NUED / SUITE)	CLACC ETDED LAMITA	ATE COVERING THE SPAR STU	D FITTIN 204 2C
GY GY	96-131 96-137		MOMENT OF CONTROL SURFAC	
CLACELI	ucei /unu			
	<i>UGEL/HPH</i> LUGEL 304 CZ			
GLOBE GC 1A				
US	46-23-04	ADDITION OF RIVET		
US US	46-33-02 46-42-01	FUSELAGE BULKHEAD CABIN HEATER VALV	FLANGE STIFFENER	
US	47-06-01	LANDING GEAR RETR	ACTION ADJUSTMENT	
US US	47-06-02 47-06-03	LANDING GEAR RETR ELEVATOR CABLE CO		
US	47-06-04	LANDING GEAR WASH		
US	47-06-05	BATTERY VENT PLUG		
US US	47-06-06 47-25-06	ENGINE BREATHER L CARBURETOR FLEXIB		
LIS	47-25-07	OIL RADIATOR OUTL	ET SLEEVE	
US US	48-28-01 51-02-02	FUSELAGE BULKHEAD ASBESTOS CLOTH RE		
US	51-08-03	STABILIZER SPAR A		
US US	51-10-05 51-11-04	FUSELAGE REINFORC LANDING GEAR REWO		
US	56-16-04	LANDING GEAR TORQ		
US	58-10-03	LANDING GEAR STOP	RING	
GC 1B				
US	46-23-04	ADDITION OF RIVET		
US US	46-33-02 46-42-01	FUSELAGE BULKHEAD CABIN HEATER VALV	FLANGE STIFFENER	
US	47-06-01	LANDING GEAR RETR	ACTION ADJUSTMENT	
US US	47-06-02 47-06-03	LANDING GEAR RETR ELEVATOR CABLE CO		
US	47-06-03	LANDING GEAR WASH	== - · · · · · <del>-</del>	
US	47-06-05	BATTERY VENT PLUG		
US US	47-06-06 47-25-06	ENGINE BREATHER L CARBURETOR FLEXIB		
US	47-25-07	OIL RADIATOR OUTL	ET SLEEVE	
US US	48-28-01 51-02-02	FUSELAGE BULKHEAD ASBESTOS CLOTH RE		
US	51-08-03	STABILIZER SPAR A		
US US	51-10-05 51-11-04	FUSELAGE REINFORC		
US	56-16-04	LANDING GEAR REWO		
US	58-10-03	LANDING GEAR STOP	RING	
US	64-05-06	ENGINE MOUNT		
GREAT L	AKES			
2T1A2 US	78-26-10R1	COCKPIT HEATER SY	STEM	
US	79-20-08	INDUCTION SYSTEM		
US	80-21-12R1	ENGINE OIL SYSTEM		
GROB	0		(	
G 109	SERIES		SEE/VOIR: BURKHAR	T GROB
G 109		( G 109 SERIES )	SEE/VOIR: BURKHAR	T GROB
G 109B	3	( G 109 SERIES )	SEE/VOIR: BURKHAR	T GROB
G 1150				
GY	94-217	MODIFICATION TO S		SB 1078-41
GY GY	96-025 96-270/3	REDUCTION OF NEVEL REMOVAL OF VNE RE	R EXCEED SPEED (VNE)	SB 1078-59/2 1078-69
GY	97-143	ELEVATOR HINGES		1078-59/3,1078-64
GY	1998-299	INSPECTION OF TRI	M TAB HINGES	1078-75
GRUMMAN				
TBM SE	RIES 58-19-01	FIRE RESISTANT HOS	E	
US	64-26-03	ELEVATOR PUSH ROD		

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJETT
SUJET

REFERENCE SERVICE BULLETIN

TBM 3	ORIGINE NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
TBM 9E			
AA 5 SERIES  ( AA 5 SERIES ) SEE/VOIR: AMERICAN AVN  AA 5 B  ( AA 5 SERIES ) SEE/VOIR: AMERICAN AVN  AA 5 SERIES  US 89-18-08  FUEL SYSTEM & COMPONENTS  176, 22  US 92-06-08  ELEVATOR BINDING  ME-1A	( TBM SERIES )		
AA 5B  (AA 5 SERIES)  SEE/VOIR: AMERICAN AVN  6A 7 SERIES  US 89-18-08  FUEL SYSTEM & COMPONENTS  (A 7 SERIES)  (A 8 SERIES)  (A 7 SERIES)  (A 8 SERIES)  (A 9 SERIES)  (A 9 SERIES)  (A 9 SERIES)  (A 9 SERIES)  (A 10 SERIES)  (A	TBM 3E	( TBM SERIES )	
GA 7 SERIES  US 92-06-08  FUEL SYSTEM & COMPONENTS  FUEL SYSTEM FUEL SYSTEM  F	AA 5 SERIES	SEE/VOIR: AMERICAN	AVN
Line	AA 5B	( AA 5 SERIES ) SEE/VOIR: AMERICAN /	
Section   Color   Co			
GA 7   SERIES   FUEL SELECTOR VALVES	US 89-18-08 US 92-06-08	FUEL SYSTEM & COMPONENTS ELEVATOR BINDING	176, 22
US	GA 7		WE-TA
US 79-03-06 US 79-05-06 US 79-05-07 CHAFING AND LEAKAGE OF MAIN FUEL LINE US 79-05-07 FUEL LEAKAGE IN TANK RIBS  G 21A CF CF-49-03 US 46-38-01 US 46-38-01 US 49-16-01 FUEL TANK BAFFLES US 50-15-01 MIXTURE CONTROL REWORK US 50-15-01 MIXTURE CONTROL REWORK US 53-24-01 US 63-27-02 RDDDER CONTROL PUSH ROD END FITTINGS US 73-12-06 FLEX DRIVE ELEVATOR TORDOL FOLDER US 54-26-01 US 54-26-01 LANDING GEAR VALVE PLACARD  G 44A US 48-31-01 US 54-26-01 LANDING GEAR VALVE PLACARD  G 164 SERIES US 62-08-07 ALLERON CONTROL CABLE BRACKETS US 63-22-01 US 63-22-03 US 78-23-11	US 78-20-09	FUEL SELECTOR VALVES	
US 79-05-06 US 79-05-07 FUEL LEAKAGE IN TANK RIBS  85-26-06 RUDDER TORQUE TUBE  CF CF-49-03 WING CENTRE SECTION RIBS US 46-38-01 VACUUM SYSTEM TUBING US 49-16-01 FUEL TANK BAFFLES US 50-15-01 MIXTURE CONTROL FEWDRE US 53-21-02 HORIZONTAL STABILIZER STRUT US 53-21-02 RUDDER TORQUE TUBE FAILURE US 63-27-02 RUDDER CONTROL PUSH RID END FITTINGS US 73-12-06 RUDDER CONTROL PUSH RID END FITTINGS US 73-12-06 RUDDER CONTROL PUSH RID END FITTINGS US 73-12-06 RUDDER CONTROL PUSH RID END FITTINGS US 79-02-03 RUDDER CONTROL PUSH RID END FITTINGS US 54-26-01 LANDING GEAR VALVE PLACARD  G. 444 US 48-31-01 US 54-26-01 LANDING GEAR VALVE PLACARD  G. 159 SEE/VOIR: GULFSTREAM  G. 164 SERIES US 63-029-07 ALLERON CONTROL CABLE BRACKETS 20 US 63-029-07 LOS GO-01-01 LOS GO-01-02 RUDDER CONTROL PUSH BOIL US 63-02-01 US 63-01-01 RUDDER CONTROL PUSH BOIL US 67-29-04 RUDDER CONTROL PUSH BOIL US 67-29-04 RUDDER CONTROL SURFACE LOCK US 67-09-04 CONTROL SURFACE LOCK US 67-09-04 RUDDER CONTROL PUSH BOIL US 99-05-06 RUDDER CABLES US 77-19-05 FLYING WIRE FERMINALS US 99-05-06 RUDDER CONTROL PUSH BOIL US 75-14-04 RUDDER CONTROL PUSH BOIL US 75-14-04 RUDDER CONTROL PUSH BOIL US 77-19-05 FLYING WIRE FERMINALS FUEL PUSH ROTHER FUEL SHITTOR PUSH BOIL US 77-19-05 FLYING WIRE FERMINALS FUEL PUSH ROTHER FUEL SHITTOR PUSH BOIL US 77-19-05 FLYING WIRE FERMINALS FUEL PUSH ROTHER FUEL PUSH ROTH			
US   85-26-05   RUDDER TORQUE TUBE		CHAFING AND LEAKAGE OF MAIN FUEL I INF	
CF	US 85-26-05	RUDDER TORQUE TUBE	
US 46-38-01	G 21A		
US	CF CF-49-03	WING CENTRE SECTION RIBS	
US 50-15-01 US 53-21-02 US 63-24-01 US 63-24-01 US 63-27-02 US 71-112-03 US 71-12-03 US 71-12-03 US 71-12-03 US 71-12-06 US 73-12-06 US 79-02-03 US 72-102 US 78-11-03 US 63-24-01 US 64-31-01 US 78-12-06 US 79-02-03 ENGINE FUEL STARVATION US 78-12-06 US 79-02-03 ENGINE FUEL STARVATION US 78-12-06 US 79-02-03 ENGINE FUEL STARVATION US 48-31-01 US 54-26-01 LANDING GEAR VALVE PLACARD  G 44A US 48-31-01 US 54-26-01 LANDING GEAR VALVE PLACARD  G 159  SEE/VOIR: GULFSTREAM  G 164 SERIES US 62-08-07 US 63-09-07 US 63-09-01 US 63-09-01 US 63-09-04 US 66-20-01 US 67-09-04 US 67-09-04 US 67-29-04 US 67-29-04 US 67-29-04 US 67-29-04 US 68-28-11 US 78-23-11 AILERON GEAR VALVE BLACARD US 78-23-11 AILERON GEAR VALVE BLACARD US 68-29-04 US 68-29-06 US 67-29-04 US 68-29-06 US 67-29-04 US 68-29-06 US 67-29-04 US 68-29-06 US 67-29-04 US 68-29-06 US 78-29-11 US 68-29-06 US 78-29-11 US 68-29-11 US 78-29-11 US 78-29			
US   53-24-01		MIXTURE CONTROL REWORK	
US   63-27-02			
US   72-11-03		RUDDER CONTROL PUSH ROD END FITTINGS	
US 73-12-06 US 79-02-03 ENGINE RESTART  G 44  US 48-31-01 US 48-31-01 US 54-26-01 LANDING GEAR VALVE PLACARD  G 44A  US 48-31-01 US 54-26-01 LANDING GEAR VALVE PLACARD  G 44A  US 54-26-01  US 54-26-01  LANDING GEAR VALVE PLACARD  G 159  SEE/VOIR: GULFSTREAM  G 164 SERIES US 62-08-07 US 63-01-01 ENGINE MOUNT WASHERS 21 US 63-22-01 US 63-22-01 US 63-22-02 US 66-01-02 US 66-01-02 US 66-01-02 US 67-29-04 CONTROL SUFFACE LOCK US 67-29-04 US 67-29-04 US 76-21-03 WAIN LANDING GEAR STRUT FAILURES US 78-23-11 US 78-23-11 US 82-07-04 US 78-23-11 US 82-07-04 US 83-07-06 FUEL SHUTOFF VALVE MODIFICATION US 89-18-02R1 US 93-05-06  G 164A  G 164 SERIES US 71-02-02 FUEL SHUTOFF VALVE MODIFICATION US 89-18-02R1 US 93-05-06 US 71-90-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 71-90-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 71-90-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 71-90-05 FUEL INTERITY LANDING US 75-14-04 RUDDER CABLES US 77-13-04 PLACARD-BRAKE WARNING 60 US 78-08-09 RUDDER ASSEMBLY US 78-08-09 RUDDER ASSEMBLY US 78-08-09 RUDDER ASSEMBLY US 77-13-04 PLACARD-BRAKE WARNING 56 US 77-			
STABILIZER STRUT	US 73-12-06	ELEVATOR & RUDDER TORQUE TUBE FAILURE	
US		ENGINE RESTART	
US   54-26-01		STARTI IZER STRIIT	
US			
S   S4-26-01			
G 164 SERIES US 62-08-07 AILERON CONTROL CABLE BRACKETS 20 US 63-01-01 ENGINE MOUNT WASHERS 21 US 63-01-01 OIL LINES FROM SPRAY PUMP FAN BLADES 23 US 63-22-02 THROTTLE CONTROL PIVOT BOLT 25 US 66-01-02 PROPELLER CONE AND SPACER SETS 32 US 67-09-04 CONTROL SURFACE LOCK 32 US 67-09-04 ELEVATOR FORWARD PUSHROD ASSEMBLY 32 US 76-21-03 MAIN LANDING GEAR STRUT FAILURES 33 US 78-23-11 AILERON BALANCE CABLES 63 US 82-07-04 FUEL SHUTOFF VALVE MODIFICATION 35 US 93-05-06 IGNITION SWITCHES ACS 5B 92-01  G 164A ( G 164 SERIES ) US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 72-02-02 FUEL LINE FITTING LEAKAGE 46 US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 76-13-10 LANDING GEAR STRUT 13 SN US 78-08-09 RUDDER ASSEMBLY 61 US 78-08-09 RUDDER ASSEMBLY 61 US 75-14-04 RUDDER CABLES 56A US 73-19-10 ELEVATOR CONTROL HORN 51 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B ( G 164 SERIES ) US 78-14-04 RUDDER ASSEMBLY 61 US 78-14-04 RUDDER CABLES 56A US 77-13-05 FLYING WIRE TERMINALS 556A US 77-13-06 PLACARD-BRAKE WARNING 60 US 77-13-07 FLYING WIRE TERMINALS 56A			
G 164 SERIES	G 159		4
US   62-08-07		SEE/VOIK. GOEF STREAM	•
US 63-22-02	US 62-08-07	AILERON CONTROL CABLE BRACKETS	20
US 63-22-02 THROTTLE CONTROL PIVOT BOLT 25 US 66-01-02 PROPELLER CONE AND SPACER SETS 32 US 67-09-04 CONTROL SURFACE LOCK  US 67-29-04 ELEVATOR FORWARD PUSHROD ASSEMBLY US 76-21-03 MAIN LANDING GEAR STRUT FAILURES US 78-23-11 AILERON BALANCE CABLES 63 US 82-07-04 FUEL SHUTOFF VALVE MODIFICATION US 89-18-02R1 FWD & AFT ELEVATOR PUSH-PULL RODS 85 US 93-05-06 IGNITION SWITCHES ACS SB 92-01  G 164A (G 164 SERIES)  US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 72-02-02 FUEL LINE FITTING LEAKAGE 46 US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 76-13-10 LANDING GEAR STRUT 13 SN US 77-19-05 FLYING WIRE TERMINALS US 78-08-09 RUDDER ASSEMBLY 61 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 PLACARD-BRAKE WARNING 60 US 77-13-04 PLACARD-BRAKE WARNING 55 US 78-08-09 RUDDER ASSEMBLY 51 US 78-26-03 WING FITTINGS CORROSION DETECTION 65	US 63-01-01	ENGINE MOUNT WASHERS	
US 67-09-04 CONTROL SURFACE LOCK  US 67-29-04 ELEVATOR FORWARD PUSHROD ASSEMBLY  US 76-21-03 MAIN LANDING GEAR STRUT FAILURES  US 78-23-11 AILERON BALANCE CABLES  US 82-07-04 FUEL SHUTOFF VALVE MODIFICATION  US 89-18-02R1 FWD & AFT ELEVATOR PUSH-PULL RODS  US 93-05-06 IGNITION SWITCHES  G164A (G 164 SERIES)  US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES  US 72-02-02 FUEL LINE FITTING LEAKAGE  US 73-19-10 ELEVATOR CONTROL HORN  US 75-14-04 RUDDER CABLES  US 77-13-04 PLACARD-BRAKE WARNING  US 77-19-05 FLYING WIRE TERMINALS  US 78-08-09 RUDDER ASSEMBLY  US 78-26-03 WING FITTINGS CORROSION DETECTION  G164B (G 164 SERIES)  US 73-19-10 ELEVATOR CONTROL HORN  US 77-13-04 PLACARD-BRAKE WARNING  US 78-08-09 RUDDER ASSEMBLY  US 78-08-09 RUDDER ASSEMBLY  O1 10 10 10 10 10 10 10 10 10 10 10 10 10			
US 67-29-04 ELEVATOR FORWARD PUSHROD ASSEMBLY US 76-21-03 MAIN LANDING GEAR STRUT FAILURES US 78-23-11 AILERON BALANCE CABLES 63 US 82-07-04 FUEL SHUTOFF VALVE MODIFICATION US 89-18-02R1 FWD & AFT ELEVATOR PUSH-PULL RODS 85 US 93-05-06 IGNITION SWITCHES ACS SB 92-01  G 164A (G 164 SERIES)  US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 72-02-02 FUEL LINE FITTING LEAKAGE 46 US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 73-19-10 FLYING WIRE TERMINALS US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 FLEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 56 US 77-13-04 PLACARD-BRAKE WARNING 56A US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-13-05 FLYING WIRE TERMINALS			32
US 78-23-11			
US 82-07-04 FUEL SHUTOFF VALVE MODIFICATION  US 89-18-02R1 FWD & AFT ELEVATOR PUSH-PULL RODS 85  US 93-05-06 IGNITION SWITCHES ACS SB 92-01  G 164A (G 164 SERIES)  US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33  US 72-02-02 FUEL LINE FITTING LEAKAGE 46  US 73-19-10 ELEVATOR CONTROL HORN 51  US 76-13-10 LANDING GEAR STRUT 13 SN  US 77-13-04 PLACARD-BRAKE WARNING 60  US 77-19-05 FLYING WIRE TERMINALS  US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES)  US 73-19-10 ELEVATOR CONTROL HORN 51  US 73-19-10 ELEVATOR CONTROL HORN 51  US 73-19-10 FLYING WIRE TERMINALS  US 75-14-04 RUDDER CABLES 56A  US 77-13-04 PLACARD-BRAKE WARNING 56  G 164B (G 164 SERIES)  US 73-19-10 FLYING WIRE TERMINALS			63
US 93-05-06 IGNITION SWITCHES ACS SB 92-01  G 164A (G 164 SERIES)  US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 72-02-02 FUEL LINE FITTING LEAKAGE 46 US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS US 78-08-09 RUDDER ASSEMBLY 61 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 55A US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS			63
G 164A (G 164 SERIES)  US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33  US 72-02-02 FUEL LINE FITTING LEAKAGE 46  US 73-19-10 ELEVATOR CONTROL HORN 51  US 75-14-04 RUDDER CABLES 56A  US 77-13-04 PLACARD-BRAKE WARNING 60  US 77-19-05 FLYING WIRE TERMINALS  US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES)  US 73-19-10 ELEVATOR CONTROL HORN 51  US 73-19-10 ELEVATOR CONTROL HORN 51  US 75-14-04 RUDDER CABLES 56A  US 77-13-04 PLACARD-BRAKE WARNING 560  US 77-13-04 PLACARD-BRAKE WARNING 560  US 77-13-05 FLYING WIRE TERMINALS			
US 66-27-06 RIGHT-HAND ELEVATOR TORQUE TUBES 33 US 72-02-02 FUEL LINE FITTING LEAKAGE 46 US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS US 78-08-09 RUDDER ASSEMBLY 61 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS			A03 30 32 01
US 72-02-02 FUEL LINE FITTING LEAKAGE 46 US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 76-13-10 LANDING GEAR STRUT 13 SN US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS US 78-08-09 RUDDER ASSEMBLY 61 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS	US 66-27-06	RIGHT-HAND ELEVATOR TORQUE TUBES	33
US 75-14-04 RUDDER CABLES 56A  US 76-13-10 LANDING GEAR STRUT 13 SN  US 77-13-04 PLACARD-BRAKE WARNING 60  US 77-19-05 FLYING WIRE TERMINALS  US 78-08-09 RUDDER ASSEMBLY 61  US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES)  US 73-19-10 ELEVATOR CONTROL HORN 51  US 75-14-04 RUDDER CABLES 56A  US 77-13-04 PLACARD-BRAKE WARNING 60  US 77-19-05 FLYING WIRE TERMINALS	US 72-02-02	FUEL LINE FITTING LEAKAGE	
US 76-13-10 LANDING GEAR STRUT 13 SN US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS US 78-08-09 RUDDER ASSEMBLY 61 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS			
US 77-19-05 FLYING WIRE TERMINALS US 78-08-09 RUDDER ASSEMBLY 61 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS	US 76-13-10	LANDING GEAR STRUT	
US 78-09 RUDDER ASSEMBLY 61 US 78-26-03 WING FITTINGS CORROSION DETECTION 65  G 164B (G 164 SERIES) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS		·	
G 164B ( G 164 SERIES ) US 73-19-10 ELEVATOR CONTROL HORN 51 US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS	US 78-08-09	RUDDER ASSEMBLY	
US 73-19-10 ELEVATOR CONTROL HORN 51  US 75-14-04 RUDDER CABLES 56A  US 77-13-04 PLACARD-BRAKE WARNING 60  US 77-19-05 FLYING WIRE TERMINALS			
US 75-14-04 RUDDER CABLES 56A US 77-13-04 PLACARD-BRAKE WARNING 60 US 77-19-05 FLYING WIRE TERMINALS			51
US 77-19-05 FLYING WIRE TERMINALS	US 75-14-04	RUDDER CABLES	
			60
			61

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET		REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
GRUMMAN			
G 164B (CONTINUED / SUITE)	( G 164 SERIES )		
US 78-26-03 US 82-13-06	WING FITTINGS CORF AILERON BELLCRANK		65
GRUMMAN SCAN			
GULFSTREAM AA 5 SERIES		SEE/VOIR: AMERICAN AVN	
AA 5A	( AA 5 SERIES )	SEE/VOIR: AMERICAN AVN	
AA 5B	( AA 5 SERIES )	SEE/VOIR: AMERICAN AVN	
GA 7 SERIES	,,,,,	SEE/VOIR: GRUMMAN	
GA 7	( CA 7 CEDIEC )		
	( GA / SERIES )	SEE/VOIR: GRUMMAN	
690 SERIES		SEE/VOIR: AERO COMMANDE	ER
690D	( 690 SERIES )	SEE/VOIR: AERO COMMANDE	ER
695 SERIES		SEE/VOIR: AERO COMMANDE	ER
695A	( 695 SERIES )	SEE/VOIR: AERO COMMANDE	R
G 159			
US 62-26-02 US 65-09-03	WING STRUCTURE DAM APU TURBINEEL AND		
US 65-13-04	NOSE GEAR STRUT AS		
US 67-33-04	AILERON CONTROL ID		
US 69-20-03	FUEL FILTER BLOCKA		
US 71-23-02 US 72-07-08	CRACKS IN WING TO MAIN LANDING GEAR		
US 73-14-07	PRESSURE DOME CRAC		
US 74-23-08	FIRE EXTINGUISHERS		
US 77-13-01	JUMPSEAT		
US 79-06-03 US 81-04-02	ELECTRICAL SHUNTS INCORPORATION OF A	EM DEVICTORS	
US 84-20-08	FORWARD/AFT ENG M		
US 87-05-51		NITY LIGHTING SYSTEM	
US 97-14-08	MAIN GEAR UPLOCK B	RACKET	179, 179A
US 97-14-09 US 97-14-10		TRIM TAB MOUNTING LUGS	208A
US 97-14-10 US 97-14-13	MAIN LANDING GEAR ENGINE MOUNT TUBE	CHAFE WEAD	172 SCN 180
US 97-16-05	WING CENTER SECTIO	N SKIN	3011 100
US 98-04-36		R SEVERE ICING CONDITIONS	
US 98-13-30	POWER LEVER POSITI	ONING	
G 1159 SERIES US 90-02-05	TAVEDEE WARNING CV	CTEM	400
US 93-01-18	TAKEOFF WARNING SY WING - INSPECTION		106 114A, 400A, 403A
		NE FIRE EXTINGUISHING SYSTEM	20, 4
G 1159	( G 1159 SERIES )		
US 73-14-05	AUTOPILOT DISCONNE		
US 73-14-07 US 74-11-05	PRESSURE DOME CRAC FIRE EXTINGUISHER		
US 74-11-05	AUTOMATIC FLIGHT C		
US 74-17-05	GROUND SPOILERS		
US 74-25-03	FLIGHT POWER SHUT-	OFF VALVE	
US 75-06-08 US 75-11-07	DC AND AC POWER ELEVATOR TRIM		
US 75-15-03	OPERATING PROCEDUR	ES	
US 76-18-12	GENERATOR TERMINAL		
US 77-13-01	JUMPSEAT		
US 78-03-02 US 78-14-06	MAIN LANDING GEAR		
US 79-06-03	CABIN WINDOW PANES ELECTRICAL SHUNTS		
US 81-06-07	LANDING GEAR SYSTE	M	
US 81-24-02	HYDRAULIC SYSTEM F	LUID FLOW	
US 82-11-02 US 90-13-02	ELEVATOR AND/OR TR WING STRUCTURE COR		CD 40
30 00 02	WING STRUCTURE COR	ROSTON AND CRACKS	CB 42

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT SUJET

		00001		BULLETIN DE SERVICE DE REF.
GULFSTREAM G 1159A US 91-	(	G 1159 SERIES ) ELECTRICAL FEEDER CAB	<u>L</u> E	6A
HARVARD HARVARD I				
CF CF-	82-23	HORIZONTAL STAB REAR	SPAR CONNECTOR FITTINGS	
CF CF-	82-23	HORIZONTAL STAB REAR	SPAR CONNECTOR FITTINGS	
HAWKER SID DH 125 SE	DELEY RIES		SEE/VOIR: BRITISH AERO	DSPACE
DH 125 1A	( )	OH 125 SERIES )	SEE/VOIR: BRITISH AERO	SPACE
DH 125 3A			SEE/VOIR: BRITISH AERO	
DH 125 40			SEE/VOIR: BRITISH AERO	
BH 125 SE	RIES		SEE/VOIR: BRITISH AERO	SPACE
BH 125 600		BH 125 SERIES )	SEE/VOIR: BRITISH AERO	
HS 125 SEI	RIES		SEE/VOIR: BRITISH AERO	SPACE
HS 125 600	A ( )		SEE/VOIR: BRITISH AERO	
HS 748 SEI			SEE/VOIR: BRITISH AERO	
HS 748 2A	( )		SEE/VOIR: BRITISH AERO	
HS 748 2B			SEE/VOIR: BRITISH AERO	
HELIO				
H250 US 82-	16-08	L AND R MAIN SPAR CARE	RV-THRU ASSV	
H295				
US 82-	16-08	L AND R MAIN SPAR CARE	RY-THRU ASSY	
	22-02	UPPER WING ATTACHMENT		13
	25-02	FRONT SPAR CRACKS		17
	01-04 25-04	AILERON BELLCRANK FIN UPPER HINGE ATTACH	JMENT	16 18
	17-05	FRONT SPAR	(I-1C1-0)	21
	17-06	PULLEY GUARDS		20
	18-02	VACUUM OIL SEPARATOR		30A
	16-08	L & R MAIN SPAR CARRY	THROUGH ASSY	
H395 US 58-2	25-04	FIN HINGE ATTACHMENT		
	25-04 17-05	HORIZONTAL TAIL SPAR F	ITTING	
	17-06	PULLEY GUARDS		
	18-02	ENGINE BREATHER		
US 82-1	16-08	L AND R MAIN SPAR CARR	RY-THRU ASSY	
H395A US 63-1	18-02	ENGINE BREATHER		
	6-08	L AND R MAIN SPAR CARR	Y-THRU ASSY	
<b>H800</b> US 87-0	04-09	MAIN LANDING GEAR COMP	POSITE LEGS	
HILLER				
UH12 SERIE		UEL TOORTER DECOUE OVER	FAAC	CAR 700 04
	98-15	HELICOPTER RESCUE SYST		CAR 702.21
	9-01 2-03	CARBURETOR MIXTURE CON		
05 59-0	5-05	CYCLIC CONTROL SCISSOR	CASTING	
US 59-2	25-05 25-03 25-08	WOBBLE PLATE SCREWS MAIN ROTOR BLADE - DYE		

MAKE / CONS MODEL / M ORIGINE ORIGINE		(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HILLER			
UH12 9	SERIES		
	UED / SUITE)		
US	73-20-03	MAIN ROTOR HUB	
US	77-07-05 77-24-03	SUPERCEDED BY AD 97-10-16 FUEL CONTROL VALVE	
US	81-17-03	MAIN TRANSMISSION	
US	81-18-02	TAIL ROTOR SKIN CRACKS	
US	97-10-16	SEPERATION OF THE CONTROL ROTOR BLADE ASSY	36-1 REV 3
UH12C		( UH12 SERIES )	
US	63-04-02	TAIL ROTOR BLADE	54 0 0 54 0
US	97-20-15	MAIN ROTOR OUTBOARD TENSION-TORSION BAR	51-2 & 51-9
UH12D		( UH12 SERIES )	
UH12E		( UH12 SERIES )	
US	61-05-04	MAIN TRANSMISSION	
US	62-06-03	TRANSMISSION & LUBRICATION SYSTEM MOD	
US US	63-21-03	MAIN ROTOR BLADES TAIL ROTOR PINION GEARS	
US	64-11-02 66-22-04	MERCURY CLUTCHES	
US	67-08-03	CYCLIC CONTROL BRACKET	
US	69-08-08	TAIL ROTOR YOKE	
US	69-13-07	COLLECTIVE YOKE SUPPORT BRACKETS	
US	72-13-08	MAIN ROTOR BLADES	
US	74-04-03	MAIN ROTOR DRAG STRUTS	
US US	75-10-01 76-20-06	ROTOR DRIVE SYSTEM  CABLE FREEZING CONTROL	
US	78-18-03	DRIVE SHAFT	
US	78-22-02	ROTOR BLADE RETENTION SYSTEM	
US	78-22-08	FLIGHT/ENGINE CONTROL	
US	78-23-07	FINITE LIFE COMPONENTS LISTED IN AD	
US	79-03-07	MAIN ROTOR TACH GENERATOR	
US	80-07-04	MAIN ROTOR BLADE ANTI-NODE BARS	
US US	80-19-02 81-04-01	TURBINE POWER - SOLOY CONVERSIONS RUDDER CABLE ASSEMBLY	
US	81-09-08	MAIN ROTOR BLADE	
US	82-13-04R1	TORSIONAL COUPLINGS	
US	82-15-02	MAIN AND TAIL ROTORS	
US	82-16-07	TORSIONAL COUPLING ASSYS	
US	83-25-02	MAIN ROTOR BLADE DOUBLERS	
US US	84-19-08 86-17-02	ENGINE MOUNT MAIN ROTOR BLADE FORK	
US	86-22-04	MAIN ROTOR BLADES	UH12-51-6
US	90-15-01	TAIL ROTOR BLADES	0.112 0 1 0
US	97-20-15	MAIN ROTOR OUTBOARD TENSION-TORSION BAR	51-2 & 51-9
UH12ET		( UH12 SERIES )	
FH1100			
CF	CF-69-19	MAIN ROTOR CUFF	
CF	CF-70-09	REGULATED PRESSURE LINE	
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	66-30-05	MAIN ENGINE DRIVE SHAFT	
US	68-02-04	CYCLIC INPUT SWASHPLATE RING	
US	68-06-05	FAILURE OF COUPLING SHAFT	
US US	68-08-09 70-18-04	COUPLING SHAFT TRANSMISSION VERTICAL STATUS	
US	71-11-03	VNE PLACARD	
US	71-22-03	TAIL ROTOR BEAR297 BLOCK	
US	71-24-02	FAILURE OF TRANSMISSION MOUNT STRUT	
US	71-24-06	ATTACH LUG ENGINE MOUNT STRUT	
US	71-24-08	LANDING GEAR TORQUE TUBE	
US US	72-13-07 75-03-04	DRIVE SHAFT ASSEMBLIES TAIL FIN SPAR	
US	77-07-08	TAIL ROTOR TENSION TORSION BARS	
US	79-11-04	LOWER HOUSING TRANSMISSIONS	
US	81-10-02	SUPPORT COLUMN	
ноас			
DV20		SEE/VOIR: DIAMOND	
<b>HK 36</b> AS	R SUPER DIMON		27
73		ATTACHMENT OF THE WHEEL AXLE ON SUPPORT ANGLE	27

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUJET
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HOAC			
	R SUPER DIMON	NA	
(CONTI	NUED / SUITE)	NA .	
AS	74	EXHAUST SYSTEM & AIRBRAKE SYSTEM	
AS	85	ELEVATOR RIB	33 & 34
			51
HK 36	TTC		
HOWARD			
DGA 15			
Dunis	•		
HUGHES			
	ERIES		
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	67-21-01	AIR SCOOP	N-76.1 SIN
US	69-21-01 70-17-03	FAILURE OF INPUT PINION SHAFT FLAPPING HINGE BOLTS	N-7.1
US	74-21-04	CONOPY SLATS	N-78 SIN
US	75-08-12	ACTUATOR AND COLUMN	N-126 SIN
US	76-10-02	LATERAL CONTROL	N-138 SIN
UŞ	76-18-01	TAIL BOOM SUPPORT STRUT	N-109.2
US	77-07-01	CLUTCH ACTUATOR	N-141.1
US US	78-02-02 78-25-04	TAIL ROTOR CONTROL PEDALS	N-121.1 SIN
US	78-25-04	PINION ASSEMBLIES TAIL ROTOR HUB ASSEMBLY	N-151.2 SIN
US	79-23-03R1	TAIL ROTOR HOB ASSEMBLY	N-130,N-162 SIN
US	80-18-07	MAIN TRANSMISSION ASSEMBLY	N-130,N-162 31N
US	81-17-04	DRIVE SHAFT ASSEMBLIES	N-142.1 SIC
US	82-15-01R1	MAIN TRANSMISSION	N-181 SIC
US	82-15-03	ROTOR SYSTEM	N-182 SIN
US US	88-17-04 89-20-03	TAIL ROTOR SUPPORT STRUT TAIL ROTOR BLADES	N-221 SCHWEIZER
US	89-20-03R1	TAIL ROTOR BLADE	N-183.2 N-183.3 SIN
US	90-06-10	THROTTLE CABLES	11-165.5 5111
US	92-25-14	CRACKS IN MAIN ROTOR SHAFT	B-255
US	93-03-01	CLUTCH CONTROL SPRING ASSEMBLY	B-256.1
US	93-17-13	LOWER COUPLING DRIVESHAFT FAILURE	B-257.1
US US	94-12-06 94-13-04	LOWER PULLEY BEARINGS	SUPERCEDES 80-02-14
US	94-16-04	BELT DRIVE CLUTCH CONTROL SPRING ASSY SEPERATION TAIL ROTOR PEDAL SUPPORT STRUCTURE	B-247
US	95-03-12		B-256.2(SUP 93-03-01
US	95-21-02	MAIN RUIDE DRIVESHAFT (SUPERSEDES 93-14-06)	B 255.1
US	97-23-06	TRANSMISSION RING GEAR	B-244.2
269A		( 000 SEBIES )	
US	62-11-04	( 269 SERIES ) OPERATING LIMITATIONS	
US	62-14-03	TAIL ROTOR BLADE	
US	62-21-03	MODIFICATION	N-2A7 SIN
US	64-06-04	LOWER COUPLING DRIVE SHAFT	N-2A-33 SIN
US	64-28-02		N-2A-38 SIN
US	66-03-02	TAIL POSITION LIGHTS	N-29 SIN
US US	67-11-03 68-26-01	MAIN ROTOR GEAR DRIVE LOWER COUPLING DRIVE SHAFT	N-29 SIN N-55.1 SIN
US	69-04-03	ROTOR BLADE	
US	70-01-06	LATERAL PITCH IDLER BELL CRANK	
US	70-08-01	FLAPPING HINGE BOLTS	N-75.1 SIN
US	71-20-05	IDLER PULLEY BEARINGS	N-1.4 SIN
US	75-15-02	THROTTLE AND ENGINE POWER CONTROL	NI-O 4 CINI
US US	77-23-08 93-05-11	CRACKS IN MAIN ROTOR BLADES  ENGINE DRIVEN FUEL PUMP DRAIN TUBE	N-9.1 SIN B-235.1
US	93-21-03		B-238.1
US	97-05-06	MAIN ROTOR THRUST BEARINGS	SUPERCEDES 68-21-05
US	98-18-11	M/R BLADE ABRASION STRIPS	
US	99-17-10	TAIL ROTOR SWASHPLATE SHAFT	B-271
2000		( aco centee )	
<b>269</b> B US	64-06-04	( 269 SERIES ) LOWER COUPLING DRIVE SHAFT	N-2A-33
US	64-06-04	MAIN ROTOR BLADE FLAPPING HINGE BEARI G	N-2A-38 SIN
US	66-03-02	TAIL POSITION LIGHTS	N-2A-54 SIN
US	67-11-03	MAIN ROTOR GEAR DRIVE	N-29 SIN
US	68-26-01	LOWER COUPLING DRIVE SHAFT	N-55.1 SIN
US	69-04-03	ROTOR BLADE	
US	70-01-06	LATERAL PITCH IDLER BELL CRANK	N-75.1 SIN
US	70-08-01	FLAPPING HINGE BOLTS	N-4 / CTN

71-20-05

US

N-1.4 SIN

IDLER PULLEY BEARINGS

MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE) ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE REFERENCE SERVICE BULLETIN HUGHES 269B ( 269 SERIES ) (CONTINUED / SUITE) 75-15-02 THROTTLE AND ENGINE POWER CONTROL US US 77-23-08 CRACKS IN MAIN ROTOR BLADES N-9.2 SIN 115 93-05-11 ENGINE DRIVEN FUEL PUMP DRAIN TUBE B-235.1 93-21-03 TAILBOOM CENTER ATTACHMENT FITTING (MAGNESIUM) US B-238 1 97-05-06 MAIN ROTOR THRUST BEARING SUPERCEDES 68-21-05 US 98-18-11 M/R BLADE ABRASION STRIPS 99-17-10 LIS TAIL ROTOR SWASHPLATE SHAFT B-271 2690 ( 269 SERIES ) CF-88-14 CF TAIL ROTOR CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 US 73-11-01 IDLER PULLEY BEARING FAILURE 88-12-02 TAIL ROTOR RETENTION STRAP ASSEMBLIES B237 SCHWEIZER B-239 US 90-09-07 CYCLIC CONTROL ROD SPRING CLAMP 91-05-18 MAGNESIUM TAILBOON CENTER ATTACHMENT FITTINGS 91-05 .\_ 93-05-11 US ENGINE DRIVEN FUEL PUMP DRAIN TUBE B-235.1 US 95-21-02 MAIN ROTOR DRIVESHAFT (SUPERSEDES 93-14-06) 97-23-06 B 255.1 TRANSMISSION RING GEAR R-244 2 US 98-18-11 M/R BLADE ABRASION STRIPS 99-17-10 US TAIL ROTOR SWASHPLATE SHAFT 269C 1 CF CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 99-04-14 MAIN ROTOR BLADE ABRASION STRIP US 99-17-10 TAIL ROTOR SWASHPLATE SHAFT B-271 2690 CF-98-15 HELICOPTER RESCUE SYSTEMS CAR 702.21 98-18-11 M/R BLADE ABRASION STRIPS HUB ATTACH BOLT HOLE AREA CRACKS 98-26-06 115 US 99-17-10 TAIL ROTOR SWASHPLATE SHAFT B-271 369 SERIES CF-88-09 CF TRANSMISSION RING GEAR CARRIER DN-148.1, EN-36.1 CF CF-92-17 FLIGHT LIMITATIONS WITH CARGO POD INSTALLED CF-98-15 HELICOPTER RESCUE SYSTEMS CF CAR 702.21 115 81-26-01R1 MAIN ROTOR DRIVE SHAFT DN-99, EN-4, FN-4 US 84-01-02R1 M/R SWASHPLATE BEARING EN-12, DN-125 115 84-11-01 CONTROL ROD EN-13 SIC 84-12-01R1 APPROVED ROTOR BLADES DL-57, EL-5 86-01-04 TAIL ROTOR BLADES EN-18&21, DN129&132 US 86-20-07 TAIL ROTOR DRIVE SHAFT EN-31.1, DN=143.1 US 87-18-11 M/R TRANSMISSION T/R OUTPUT PINION EN-35, DN-147, FN-24 TAIL ROTOR TRANSMISSION MOUNTING STUDS
MAIN ROTOR HUB RETENTION STRAPS US 88-17-09R1 EN-39, DN-151, FN-28 89-02-01R1 115 DN-154, EN-44, FN-33 DN-160, EN-50 89-20-02 LIS FOUR BLADED TAIL ROTOR HUB US 89-23-14 MAIN ROTOR COLLECTIVE TUBE EN-48.1, DN-158.1 90-01-08 US DRIVESHAFT COUPLING - ENGINE TO TRANSMISSION
TAIL ROTOR SWASHPLATE BEARING DN-157, EN-47, 90-12-03 DN-167, EN-58, FN-46 OVERRUNNING CLUTCH ASSY US 90-19-02 DN-164, EN-54, FN-44 US 90-24-07 MAIN ROTOR TRANSMISSION DRIVE ASSEMBLY EN-57, DN-166.1, FN-45 CRACKS - TAIL ROTOR BLADE ROOT FITTING 91-08-02 DN-177, EN-68, FN-55 US 93-07-10 YAW OSCILLATIONS DURING DESCENT WITH BAGGAGE POD FUEL LINE EMERGENCY SHUTOFF VALVE BLOCKAGE US 93-18-05 SIN DN-181 LOSS OF TAIL ROTOR BLADE ABRASION STRIPS 94-18-08 94-24-04 US PITCH CONTROL ASSEMBLY LOCKWASHER DN185 EN78 FN64 95-03-11 TAIL ROTOR BLADE ABRASION STRIPS H238, D187, E80, F66 FAILURE OF M/R ASSY OR HUB LEAD-LAG LINK ASSY 115 95-03-13 SUPERCEDES 91-17-04 MAIN ROTOR BLADE CHECK - ROOT END CRACKING US 96-10-09 HN239DN188EN81FN67 98-01-13 US MAIN ROTOR BLADE SEPARATION
SUPERCEDED BY 98-15-26 369D-194, 369E-087 98-03-15 243R1,088R1,195R1 US 98-09-02 OVERRUNNING CLUTCH ASSEMBLY OUTER RACE FAILURE DN-156.2 HN-215.2 98-15-26 US MAIN BLADE CRACKING ENGINE CONTROL RELAYS US 99-08-07 SB369E-090 369D ( 369 SERIES ) US 77-05-03 TAIL ROTOR CONTROL SYSTEM DN-1 US 77-19-03 MAIN ROTOR RETENTION STRAPS DN-154 77-21-04 US CLUTCH AND SHAFT ASSEMBLY DN-9.2 78-20-03 US FIRE SUPPRESION SYSTEM US 78-26-04 TAIL ROTOR HUB ASSEMBLY DN-27.1 79-10-09

DN-37 SIC

TAIL ROTOR PITCH CONTROL ASSY

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

	NOWERO DE CONSIGNE		BOJET	BULLETIN DE SERVICE DE REF
HUGHES				
1		( 000	CCD	
369D	NUED / CUITTE)	( 369	SERIES )	
US	NUED / SUITE) 80-24-04		AUTO DESCRIPTION	
US	80-25-01		AUTO-REIGNITION PLACARD RELOCATION	DN-100
US	82-01-08		T/R DRIVESHAFT COUPLING	
	82-14-01		LEVER CONTROL ROD	DN-87
US	82-17-01		CHADWICK AUX FUEL SYSTEM	VENDOR
US	96-08-03		OUTPUT GEARSHAFT ASSEMBLY	DN-148.1
US	97-15-08		FLIGHT TRAILS HELI. STC # SHGOBONM HARDPOINT ASSY	
US	98-21-12		MAIN ROTOR TRANSMISSION OUTPUT GEAR OVERRUNNING CLUTCH RETAINER	DN189, EN82, FN69
US	99-04-12		INPUT SHAFT COUPLING ASSEMBLY	
US	99-13-09		TAIL ROTOR FORK ASSY P/N 369D21701-21	200000 100
US	99-20-12		TO PREVENT FAILURE OF BRACKET P/N 369F55190-1	SB369D-198
			THE TENE OF BRACKET FIN 303F33130-1	
369E		( 369	SERIES )	
US	96-08-03		FLIGHT TRAILS HELI. STC # SH6080NM HARDPOINT ASSY	
US	97-15-08	1	MAIN ROTOR TRANSMISSION OUTPUT GEAR	DN189, EN82, FN69
US	98-21-12	(	OVERRUNNING CLUTCH RETAINER	DIV103, LIV02, 1 1V03
US	99-04-12		INPUT SHAFT COUPLING ASSEMBLY	
US	99-13-09		TAIL ROTOR FORK ASSY P/N 369D21701-21	SB369E-092
US	99-20-12		TO PREVENT FAILURE OF BRACKET P/N 369F55190-1	
369FF				
CF	CF-98-15		HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	96-08-03	i	FLIGHT TRAILS HELI. STC # SH6080NM HARDPOINT ASSY	
US	97-15-08		MAIN ROTOR TRANSMISSION OUTPUT GEAR	DN189, EN82, FN69
US	98-01-13	1	MAIN ROTOR BLADE SEPARATION	369F 074
US	98-03-15		SUPERCEDED BY 98-15-26	369F-075R1
US	98-07-19		TAIL ROTOR CONTROL ROD ASSEMBLY BUCKLING	
US	98-09-02		OVERRUNNING CLUTCH ASSEMBLY OUTER RACE FAILURE	FN-34.2
US	98-15-26		MAIN BLADE CRACKING	
US	98-21-12		DVERRUNNING CLUTCH RETAINER	
US	99-04-12		INPUT SHAFT COUPLING ASSEMBLY	
US	99-08-07		ENGINE CONTROL RELAYS	SB369F-077
US	99-20-12	1	TO PREVENT FAILURE OF BRACKET P/N 369F55190-1	
2601 6	SERIES			
CF	CF-92-17		TITCHT LIMITATIONS WITH CARCO DOD INSTALLED	
CF	CF-98-15		LIGHT LIMITATIONS WITH CARGO POD INSTALLED HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	69-21-01		FAILURE OF INPUT PINION SHAFT	HN-1.1
US	70-16-07		MAIN ROTOR BLADE	HN-8
US	72-16-09		TAIL ROTOR INPUT GEAR SHAFT ASSYS	HN-53.1
US	72-18-04		/NE LIMITATIONS	HN-45 SIN
US	74-07-02		ALUMINUM TAIL ROTOR BLADES	HN~65
US	74-20-04		MAIN ROTOR BLADE	HN-73
US	75-06-02		CARGO CARRIERS	
US	75-09-17		PROTECTION OF PASSENGERS	HN-91
US	75-10-04		AIL ROTOR BLADES	HN-83 SIN
US	75-22-03		AIL ROTOR DRIVE SHAFT	HN-86
US	75-22-04		AIL ROTOR BLADES	HN-88 SIN
US	76-19-03		DAMPER PLUNGER	HN-102.1 SIN
US	77-09-01		MERGENCY FLOAT ASSEMBLIES	HN-114 BSIN
US	77-21-04		CLUTCH AND SHAFT ASSEMBLY	HN-118 SIN
US	78-20-03		IRE SUPPRESION SYSTEM	VENDOR
US	78-26-04		AIL ROTOR HUB ASSEMBLY	HN-128.1
US	80-24-04		PLACARD - FRONT SEAT OCCUPANCY	HN-160
US	80-25-01		AIL ROTOR DRIVE SHAFT	
US	82-01-08		PM GOVERNOR CONTROL ROD REPLACEMENT	HN-169
US	82-14-01		CHADWICK AUX FUEL SYSTEM	VENDOR
US	84-01-02R1		1/R SWASHPLATE BEARING INSPECTION	HN-191
US	86-01-04		AIL ROTOR BLADES	HN-195&199
US	86-20-07	Ţ	AIL ROTOR DRIVE SHAFT	HN-206
US	89-02-01R1		I/R HUB STRAP PACK INSP & TRI-FLOW WASH PROCEDURE	HN-214
US	89-11-05		AIL ROTOR STRAP PACK ASSEMBLY	HN-219 HN-217.1
US	89-23-14	ĮV.	MAIN ROTOR COLLECTIVE TUBE	HN-217.1 HN-216
US	90-01-08	<u>D</u>	RIVESHAFT COUPLING - ENGINE TO TRANSMISSION	
US	91-08-02		/R BLADE ROOT FITTING	HN-230.1
US	93-07-10		AW OSCILLATIONS DURING DESCENT WITH BAGGAGE POD	SIN HN-234
US	93-18-05	F	UEL LINE EMERGENCY SHUTOFF VALVE BLOCKAGE	
US	98-01-13	IV	NAIN ROTOR BLADE SEPARATION	369H-242 369H-243R1
US	98-03-15		UPERCEDED BY 98-15-26	HN-215.2
US	98-09-02		VERRUNNING CLUTCH ASSEMBLY DUTER RACE FAILURE IAIN BLADE CRACKING	1114 213.2
US	98-15-26	IV	MAIN DEADE CRACKING	

MODEL / M ORIGIN	AD NUMBER	ERIES / SERIE) SUBJECT		REFERENCE SERVICE BULLETIN
ORIGINE	NUMERO DE CONSIGNE	SUJET		BULLETIN DE SERVICE DE REF.
HUGHES				
369HE		369H SERIES )		
369HS		369H SERIES )		
005115		, 30311 3211223 /		
CA BRA				
IS 28E	IS-28B2/CO-18	LANDING GEAR ATTACHMENT R	EINFORCEMENT	804/30.XI.1981
RO	IS-28B2/E0-10	LIFE EXTENSION FROM 4,000		IS-28B2/ED-10
RO	IS-28B2/E0-12	FLYING CONTROLS CHECK		IS-28B2/EO-12
RO	IS-28B2/EO-13	SAFE LIFE & SERVICE LIFE AILERON CONTROL LEVER	INCREASE	IS-28B2/EO-13 IS-28B2/EO-14
RO RO	IS-28B2/E0-14 IS-28B2/E0-2	DUEL CONTROL BALLAST		600/16.05.1978
RO	IS-28B2/ED-3	SPECIAL REQUIREMENTS FOR	CANADIAN CERTIFICATION	IS-28B2/ED-3
RO	IS-28B2/EO-6	SECURING FRONT SEAT BACK		IS-28B2/ED-6
RO	IS-28B2/EO-7	PLACARD - WING LOCKING		IS-28B2/EO-7
RO	IS-28B2/EO-9	ACCELERATOMETER - AEROBAT	IC FLIGHTS	IS-28B2/EO-9
IS 28M	12			
RO	IS-28M2/CO-14	BRAKE PEDAL STOP INSTALLA	TION	419/26.12.1984
RO	IS-28M2/CO-2	MODIFICATIONS, 145, 147, 149	, 153, 154, 155, 156, 165, 167	
RO	IS-28M2/CO-4	ADDING A GREEN UNDERCARRIA		REV RECORD CARD 2
RO	IS-28M2/EO-10 IS-28M2/EO-11	CONTROL CABLE TURNBUCKLE		412/13.11.1982
RO RO	IS-28M2/EU-11	SPEED LIMITATION PLACARD ( SAFE AND SERVICE LIFE INC		417/18.09.1984
RO	IS-28M2/EO-13	RUDDER BAR AXLE FIXING R		250/31
RO	IS-28M2/EO-3	LANDING GEAR LOCK WARNING		MOD 198
RO	IS-28M2/EO-5	LANDING GEAR MAINTENANCE		AMENDMENT 22
RO	IS-28M2/EO-8	TBO BETWEEN MAJOR OVERHAUI		
RO RO	IS-28M2/80HP/E			HOFFMAN SB E4C RE LIMBACH TC 9.3
	13 20M2/00MF/L	2 INCREASE SERVICE EITE AND	SALE LIVE FOR ENGINES	LIMBACH IC 9.3
IS 290				
RO	IS-29D2/ED-1	SPECIAL REQUIREMENTS FOR (		IS-29D2/ED-1
RO RO	IS-29D2/EO-4 IS-29D2/EO-6	CONTROL CABLES TURNBUCKLE SAFE LIFE & SERVICE LIFE		IS-29D2/EO-4 IS-29D2/EO-6
RU	13-2902/60-6	SAFE LIFE & SERVICE LIFE	INCREASE	12-5305/50-0
SRAEL				
1124 S		LITAIC CDAD		NOT 04 45
IL IL	1007 1009	WING SPAR GALLEY - HOT LIQUID CONTA:	INED	WW-24-17
IL	1011	INTERCOM SYSTEM AUDIO LOAI		WW-24-23
IL	85-001R2	HORIZONTAL STABILIZER AFT		1124-55-020R2
IL	87-01	SPEED LIMITATION - WINDSH:		
ΙŁ	91-01	STRUCTURAL INSPECTION PROC		
IL.	91-02	AILERON CONTROL ROD ASSEMB	BLIES	1124-27-100R2
IL IL	92-02 95-28R1	ACCESSIBILITY TO LIFE PRES INSPECTION OF AILERON TUBE	SERVERS	FAR 25.1411(F) 1124-27-129
IL	96-92	HORIZONTAL STABILIZER TRIM		1124-27-129
IL	25-97-08-14	LIFE RAFTS		N/A
IL	27-97-09-02	REPLACEMENT OF HORIZONTAL		1124-27-136
IL	29-97-03-10	HYDRAULIC FUSES - TEST AND		1124-29-132
IL	29-98-09-01	HYD. LOW PRESSURE WARNING	CIRCUIT	1124-29A-140
1124		1124 SERIES )		
1124A		1124 SERIES )		
1125 W	ESTWIND ASTRA			
IL.	91-03	HORIZONTAL TRIM RUNAWAY		REV 3 ASTRA AFM
IL	91-04	AILERON SERVO ACTUATORS		1125-11-062, -57-
IL	92-01	OXYGEN TUBE CRACKING		1125-35-071
ΪL	92-02	ACCESSIBILITY TO LIFE PRES	SERVERS	
IL	93-01	HORIZONTAL STABILIZER	CCATTON	1125-55-017
IL IL	93-02 95-34	SLAT DRIVE MOTOR CABLE REL SUPPORT BEAM, STA.452	LUCATION	1125-27-110 1125-53-135
IL	96-19	HYDRAULIC LINES STA. 388.00	PROTECTION	
ÎĹ	25-97-08-14	LIFE RAFTS	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	N/A
IL	29-97-03-10	HYDRAULIC FUSES - TEST AND	REPLACEMENT	1125-29-154
IL	25-98-02-07R1	BAGGAGE COMP. HEATING BLAN	KETS - DISCONNECTION	1125-25-177
IL	27-99-10-06R1	AILERON A/P SERVO STOPPER		

29-97-03-10

ASTRA SPX IL 25-97-08-14

1125-29-154

N/A

HYDRAULIC FUSES - TEST AND REPLACEMENT

LIFE RAFTS

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

		SUJET	BULLETIN DE SERVICE DE REF.
ISRAEL			
ASTRA			
	NUED / SUITE)		
IL	25-98-02-07R1	DACCACE CONTRACTOR OF THE PROPERTY OF THE PROP	
IL	27-99-10-06R1	BAGGAGE COMP. HEATING BLANKETS - DISCONNECTION	1125-25-177
IL	55-99-04-02R2	AILERON A/P SERVO STOPPER INSTALLATION	1125-27A-157
	73-99-07-05	HORIZ. STAB. LOWER SCISSORS ATTACHMENT BOLT HOLES	1125-55A-192R1
	75 35 07 05	INSP ENGINE MAIN FUEL TUBE ASSEMBLIES.	1125-73A-191
KAMAN			
K 120	10		
	CF-98-15	HEL ICODIED BECOME CHOTES	
US	99-26-04	HELICOPTER RESCUE SYSTEMS ENGINE ADAPTER FLANGE	CAR 702.21
	03 20 04	CNGINE ADAPTER FLANGE	MM (TR) NO. 284/289
KAMOV			
KA32A	11BC		
RU	98-001-065	EIDCT HODER ROTOR BLADE	
RU	99-002-065	FIRST UPPER ROTOR BLADE UPPER ROTOR BLADES	
1	33 002 003	OFFER ROTUR BLADES	
LAIRD			
LCB20	0		
LAISTE	R		
LP 49			
LAISTE	R KAUFFMANN		
LK10A			
	CF-58-14	PLACARDS	
		1 EACARD3	
LAKE			
LA 4			
US	64-17-05	ENGINE BREATHER TUBE	
US	65-15-03	NOSE GEAR DRAG STRUT BOLT	
US	67-11-01	FUEL PRESSURE GAGE INSTRUMENT LINE	
US	72-07-11	FLAP PUSHROD END BEARINGS	
US	74-26-02	RUDDER CONTROL	
US	76-02-01	ENGINE POWER	
US	79-21-09R1	ELECTRICAL SYSTEM	
US	98-10-12	HORIZONTAL AND VERT STABILIZER ATTACHMENT FITTING	D 70
05	38 10 12	HORIZONIAL AND VERT STABILIZER ATTACHMENT FITTING	B-78
LA 4 2	200		
US	72-07-11	FLAP PUSHROD END BEARINGS	
US	74-09-06	FUEL RESTRICTOR FITTING	
US	74-26-02	RUDDER CONTROL	
US	76-02-01	ENGINE POWER	
US	76-12-11	ENGINE POWER LOSS	
US	76-24-02	ENGINE OIL COOLERS	
US	78-14-05	MAIN BEAM FITTINGS	
US	79-06-01	ENGINE MOUNTS WITH CRACKED STRAPS	
US	79-21-09R1	ELECTRICAL SYSTEM	
US	98-10-12	HORIZONTAL AND VERT STABILIZER ATTACHMENT FITTING	R-79
03	30-10-12	HONTZONTAL AND VERT STABILIZER ATTACHMENT FITTING	D 70
250			
US	86-23-05	FUEL SHUTOFF VALVE MOUNTING PLATE	B-66
US	94-22-02	AUTOPILOT ELEVATOR AUTO TRIM	5 00
03	J-7 22 UZ	AUTOLIEGI EELVATOR AUTO TRIPI	
LEARJET	Ť		
	24 SERIES		
US	66-13-04	PRESSURE CONTROL TRAFFIC SYSTEM	
US	66-14-02	WINDSHIELD DE-ICING SYSTEMS	
US	69-15-06	ENGINE THROTTLE CABLE	
US	71-16-04	BATTERY INSPECTION	
US	72-15-03	SPOILER ACTUATOR BOLTS	
US	74-23-01	EXTERNAL POWER RECEPTACLE	
US	75-15-06	LANDING GEAR STRUTS	
US	76-18-07	INVERTER INPUT POWER	
US	77-19-02	CABIN DOOR LOCKING MECHANISM	
US	78-16-03	REFRIGERATION CONDENSER FAN	
US	79-12-05	STALL WARNING SYSTEMS	
US	80-07-09	MAIN CABIN ENTRANCE DOOR	
US	80-19-09R1	JET PUMPS	
US	80-19-09R1 80-19-11R1	AFM REVISIONS	
US	80-26-02	AFCS/AFC-SS PITCH FUNCTION	
US	81-13-07	CHANGES IN AFM	
US	82-01-05R2	STALL WARNING ACCELEROMETER	23/24/25~301B
US	84-17-02	HOR STAB TRIM ACTUATOR	,,
	U4 17 U2	TION OTAD TIVIN ACTORION	
			TDCDAET /AEDONEES

	MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE)					
ORIGINE ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.			
1.5.40.453						
LEARJET	4 SERIES					
(CONTIN	UED / SUITE)					
US	84-19-06	TAB CONTROL SYSTEM	24-334B			
US US	86-05-05R1 86-22-05	BATTERY INLET VENT FLAP SECTOR UPPER MOUNTING BRACKET	24-3346			
US	89-12-01	DRAG CHUTE RISER	24/25-342A			
US	92-19-12	OXYGEN PLUMBING AND MAP LIGHT WIRE	MOD KIT 90-5			
US	95-20-03	OUTFLOW/SAFETY VALVES (ALLIED SIGNAL)	130406-21-A4011R3			
US US	95-25-03 99-16-03	TIP TANK FLAPPER VALVE INSPECTION TO PREVENT UNDETECTED ACCRETION OF ICE	23/24/25-82-2 24-30-03			
24D		( LEAR 24 SERIES )				
	SERIES	ENGINE THROTTLE CABLE				
US US	69-15~06 71-16-04	BATTERY INSPECTION				
US	72-15-03	SPOILER ACTUATOR BOLTS				
US	75-15-06	LANDING GEAR STRUTS				
US	76-18-07	INVERTER INPUT POWER				
US US	77-19-02 78-16-03	CABIN DOOR LOCKING MECHANISM REFRIGERATION CONDENSER FAN				
US	79-12-05	STALL WARNING SYSTEMS				
US	80-07-09	MAIN CABIN ENTRANCE DOOR				
US	80-19-09R1	JET PUMPS				
US US	80-19-11R1 80-26-02	AFM REVISIONS AFCS/AFC-SS PITCH FUNCTION				
US	81-13-07	CHANGES IN AFM				
US	84-19-06	TAB CONTROL SYSTEM				
US	86-05-05R1	BATTERY INLET VENT	25-334B			
US US	86-22-05 89-12 <b>-</b> 01	FLAP SECTOR UPPER MOUNTING BRACKET DRAG CHUTE RISER	24/25-342A			
US	92-19-12	OXYGEN PLUMBING AND MAP LIGHT WIRE	MOD KIT 90-5			
US	95-20-03	OUTFLOW/SAFETY VALVES (ALLIED SIGNAL)	130406-21-A4011R3			
US	95-25-03	TIP TANK FLAPPER VALVE INSPECTION	23/24/25-82-2			
US	99-16-03	TO PREVENT UNDETECTED ACCRETION OF ICE	25-30-03			
<b>25B</b> US	82-01-04R2	( LEAR 25 SERIES ) HORIZONTAL STABILIZER TRIM ACTUATOR	23/24/25-301B			
	02 01 04112	TONIZONIAL STABILIZEN INTER ACTUATON	20/24/23 0010			
31A						
US	92-19-12	OXYGEN PLUMBING AND MAP LIGHT WIRE	MOD KIT 90-5			
US US	95-20-03 95-21-03	OUTFLOW/SAFETY VALVES (ALLIED SIGNAL) INSPECTION OF ENGINE FIRE PULL SWITCH ASSEMBLIES	130406-21-A4011R3 A31-26-3			
US	98-06-28	REPLACEMENT OF TWO WIRING SEGMENTS	31-21-10			
US	99-16-03	TO PREVENT UNDETECTED ACCRETION OF ICE	31-30-5			
US	99-23-19	INSPECTION OF SPOILER ACTUATORS FOR SPECIFIC SN	31-27-19			
	5 SERIES					
US US	76-18-07 78-16-03	INVERTER INPUT POWER REFRIGERATION CONDENSER FAN				
US	78-25-02	DOOR MECHANISM				
US	79-08-01R1	THRUST REVERSERS				
US	80-06-02	ELECTRICAL SYSTEMS				
US US	80-07-09	MAIN CABIN ENTRANCE DOOR				
US	80-17-11 80-19-09R1	AIRSPEED WARNING PLACARD JET PUMPS				
US	80-19-11R1	AFM REVISIONS				
US	81-13-07	CHANGES IN AFM				
US	82-01-05R2	STALL WARNING ACCELEROMETER	35/36-27-12B			
US US	83-08-03 84-19-06	HYDRAULIC PRESSURE LINE TAB CONTROL SYSTEM				
US	85-16-04	DATORGOV OTO CAROCANIA				
US	86-05-05R1	BATTERY VENT SYSTEM	35-24-10			
US US	86-22-05 87-02-06	FLAP SECTOR UPPER MOUNTING BRACKET FORWARD ENGINE MOUNTS	35/36-71-3			
US		AFM LIMITATIONS - AUTOPILOT/FLIGHT DIRECTOR				
US	89-12-01	DRAG CHUTE RISER	35/36-25-7A			
US	91-03-08	ELECTROMAGNETIC INTERFERENCE	35/36-33-5A			
US US	92-19-12	OXYGEN PLUMBING AND MAP LIGHT WIRE	MOD KIT 90-5			
US	95-19-04 95-20-03	INSTALLATION OF GNS GENERATOR BAND REJECT FILTER OUTFLOW/SAFETY VALVES (ALLIED SIGNAL)	130406-21-A4011R3			
US	95-25-03	TIP TANK FLAPPER VALVE INSPECTION	35/36-28-10			
US	96-19-13	AIRCRAFT MACH NUMBER REDUCTION				
US	99-23-19	INSPECTION OF SPOILER ACTUATORS FOR SPECIFIC SN	35-27-36			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

		30321	BULLETIN DE SERVICE DE REF.
LEAR	IET		
35		( LEAR 35 SERIES )	
35A	00 00 00	( LEAR 35 SERIES )	
US	98-06-28	REPLACEMENT OF TWO WIRING SEGMENTS	35-21-24
45			
55			
US	84-19-06	TAB CONTROL SYSTEM	
US	85-22-08R2	AFM - INCORRECT LANDING DISTANCES	55-27-7
US	86-22-05	FLAP SECTOR UPPER MOUNTING BRACKET	
US	87-02-06	FORWARD ENGINE MOUNTS	55-71-2
US	87-04-06 89-12-01	AFM LIMITATIONS - AUTOPILOT/FLIGHT DIRECTOR	55-22-2
US	91-03-08	DRAG CHUTE RISER	55~25-4A
US	93-24-10	ELECTROMAGNETIC INTERFERENCE GENERATOR INTERFACE WIRING	55-33-3A
US	95-19-04	INSTALLATION OF GNS GENERATOR BAND REJECT FILTER	55-24-4
US	95-20-03	OUTFLOW/SAFETY VALVES (ALLIED SIGNAL)	130406-21-A4011R3
US	99-16-03	TO PREVENT UNDETECTED ACCRETION OF ICE	55-30-3
60	02-02-40	CARTAL AND COOKET LIE	
US US	93-23-12 95-14-09	CABIN AND COCKPIT HEAT	A60-21-1
US	95-14-09	INSPECTION OF FUEL CROSSFLOW TUBE	A60-28-3
US	96-18-01	INSPECTION OF ENGINE FIRE PULL SWITCH ASSEMBLIES EMERGENCY FUEL SHUTOFF INTERFERENCE	A60-26-1 60-71-2
US	98-16-18	BRAKE WEAR	LEAR60-32-03
US	99-16-03	TO PREVENT UNDETECTED ACCRETION OF ICE	60-30-4
US	99-23-19	INSPECTION OF SPOILER ACTUATORS FOR SPECIFIC SN	60-27-21
LET	BLANIK		
СК	L 13/001	AILERON CONTROL ROD	L 13/001
CK	L 13/002	RUDDER CONTROL CABLE	L 13/001
CK	L 13/003	RUDDER CONTROL PEDALS	L 13/003
CK	L 13/004	FUSELAGE REAR SECTION	L 13/004
CK	L 13/005	BRAKE FLAP CONTROL ROD	L 13/005
CK	L 13/006	AMENDMENTS TO TECHNICAL LITERATURE	L 13/006
CK	L 13/007	FUSELAGE REAR SECTION	L 13/007
CK	L 13/010 L 13/014	TURN & BANK INDICATOR COMMUTATOR	L 13/010 L 13/014
CK	L 13/017	WING MAIN SPAR MOUNT EXPANDING PIN TOWING CABLE LOCK - REAR CONTROL HANDLE	L 13/014
CK	L 13/018	HORIZONTAL TAIL SURFACES - CONNECTING PIN SLEEVE	
CK	L 13/019	REAR RUDDER PEDAL LEVERS	L 13/019
CK	L 13/021	CANOPY HINGE PROTECTORS	L 13/021
CK	L 13/023	MAIN SPAR WEB	L 13/023
CK	L 13/024	PILOTS NOTES - LIMITATIONS	L 13/024
CK CK	L 13/025 L 13/031	CONTROL STICK - CONTROL ROD EYES WING BOLTS	L 13/025 L 13/031
CK	L 13/035	CORRECTION - PILOTS NOTES	L 13/035
CK	L 13/038	CORRECTION - PILOTS NOTES (ENGLISH)	L 13/038
CK	L 13/039	UNDERCARRIAGE - BOTTOM HINGE MOUNTS	L 13/039
CK	L 13/040	VERTICAL STABILIZER	L 13/040
CK	L 13/042	SERVICE INSPECTION PROGRAM	L 13/042
CK	L 13/045	INCREASE OF SERVICE LIFE	L 13/045
CK	L 13/046	ELEVATOR DEFLECTION TOW-ROPE HINGE CONTROL COUNTERSHAFT BRACKET	L 13/046 L 13/047
CK CK	L 13/047 L 13/048	LAP/SPACER - WING MAIN SPAR	L 13/04/
CK	L 13/052	STABILIZER END RIB	
CK	L 13/053	EXTENSION OF MSB L 13/048	L 13/052 L 13/053
CK	L 13/056	FLIGHT MANUAL AMENDMENT	L 13/056
CK	L 13/059	GENERAL OVERHAUL & SERVICE LIFE	L 13/059
CK	L 13/062	WING MAIN SPAR	L 13/062
CK	4-099/98	ELEVATOR DRIVE COLOUR MARKING	L13/082A L13/085A
CK	T-112/1999R1	TAIL/FUSELAGE ATTACHMENT FITTINGS	L13/003A
L 23	SUPER BLANIK		
CK	L 23/010A	TAIL LANDING GEAR MODIFICATION	L 23/010A
CK	L 23/011A	FLIGHT MANUAL REVISION	L 23/011A
CK	L 23/022A	WING TIP EXTENSIONS S/N 938101 & SUBSEQUENT	
1 00	501.0		
L 33	L 33/003A	FLIGHT MANUAL AMENDMENT	L33/003A
CK	L 33/003A	FLIGHT MANNUAL AMENDMENT	L33/004A
CK	L 33/006A	FLIGHT MANNUAL AMENDMENT	L33/006A
			ATDCDAET / AEDONEES

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
			,
LET			
L 33			
(CONTI	NUED / SUITE)		
CK	1-024/98	WING HINGE REPLACEMENT	L-33/008A
LOCKHE	ED		
10A			
12A			
18			
CF	CF-48-03	STATUS OF FAA AD 48-42-2	
CF	CF-50-10	GROSS WEIGHT	
US	46-13-01	LANDING GEAR HOSE FERRULES	
US	46-13-02	DUAL FUEL SYSTEM	
US	46~13-03	HOPPER OIL TANKS	
US	47-43-10	FIRE EXTINGUISHER BOTTLE REWORK	
US	47-43-11	ELEVATOR PUSH-PULL ROD BOLTS	
US	48-42-02	FIRE PREVENTION MODIFICATION	
US	52-08-01	FUEL TANK SEAL	
US	57-23-01	VACUUM SYSTEM FUSIBLE PLUG	
US	58-08-03	CB FIRE EXTINGUISHER SYSTEM	
US	58-11-02	LANDING GEAR DRAG STRUT YOKE	
US	58-11-03	RUDDER CABLE ATTACHMENT	
US	59-16-02	STABILIZER SPAR	
US	60-21-02	CARBURETOR PREHEAT MODIFICATION	
US	61-22-06	ELEVATOR CONTROL MAST CASTINGS	
US	63-03-03	MAIN LANDING GEAR DRAG STRUT	
US	63-21-04	ELEVATOR TRIM TABS	
UŞ	77-10-03	FIRE RESISTANT PROP FEATHERING SYSTEM	
	SERIES		
US	59-21-02	WING LEADING EDGE SCREWS	
US	59-25-04	GENERATOR FEEDER WIRES	
US	60-01-05	PROPELLER DEICING	
US	60-01-06	WING SURFACE PLANKS	
US	60-03-05	TAIL PIPE COWL	
US	60-04-03	LORD ENGINE MOUNTS	
US	60-09-03	OPERATING RESTRICTIONS	
US	60-10-05	FUEL PRESSURE RELIEF VALVE	
US US	60-11-03	COWL LONGERONS	
	60-13-03	FUELING PROCEDURE CHECK	
US US	60-20-03	ELECTRICAL SYSTEM	
US	60-20-04	LAVATORY DRAINS	
US	60-24-01	FUEL PRESSURE RELIEF VALVE	
US	60-25-02	AILERON COUNTERWEIGHT	
US	60-26-04	SWIRL STRAIGHTENER SCOOP	
US	60-26-05 61-09-01	ELEVATOR AND BOOST CONTROL VALVE	
US		ELEVATOR HYDRAULIC DAMPER HOUSING	
US	61-15 <b>-</b> 04 61-21-05	SAFETY BELT GROMMETS	
US	62-26-04	COMPASS CIRCUIT BREAKERS	
US	63-08-03	ELEVATOR BALANCE WEIGHT ARMS	
US		DEBOOST CONTROL SYSTEM	
US	63-17-03 63-18-03	HORIZONTAL STABILIZER SPAR WEB	
US	64-11-03	FUSELAGE STRINGERS	
US		UPPER WING PLANKS	
US	64-12-05	LANDING GEAR CAM FOLLOWER	
US	64-14-05	MAIN LANDING GEAR SUPPORT FITTING	
US	64-16-04	AILERON PUSH-PULL TUBES	
	65-09-04	UPPER WING PLANKS	
US US	65-15-04	NO 4 WING PLANK DRAIN HOLES	
	65-16-01	NOSE LANDING GEAR SUPPORT LINK	
US	65-21-05	VERTICAL STABILIZER ATTACH CHANNEL	
US	66-04-02	WING PLANK SPLICE AREAS	
US	66-05-03	OUTER WING CAP FITTINGS	
US	66-11-02	LOWER WING PLANK SPLICE AREAS	
US	66-28-04	NOSE LANDING GEAR STEERING HOUSING	
US	67-03-06	LANDING GEAR DOOR CYLINDERS	
US	67-11-04	FUSELAGE MAIN FRAMES FORGING	
US	68-11-02	CRACKS IN UPPER & LOWER WING PLANKS	
US	68-23-05	UPPER WING PLANK CRACKS	
US	69-08-07	CRACKS IN LOWER WING SURFACE	
US	69-26-08	TAKEOFF WARNING SYSTEM	
US US	74-25-04	HORIZONTAL STABILIZER	
03	77-21-09	AILERON/RUDDER JAMMING	

MAKE / CONSTRUCTEUR

(SERIES / SERIE)

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

		BULLETIN DE SERVICE DE REF
LOCKHEED		
L 188 SERIES (CONTINUED / SUITE)		•
US 80~10~05	WING FRONT SPAR CAPS	20.750
US 80-12-01	CARGO DOOR MODIFICATIONS	88/SB-699B 88/LAS-1B
US 81-03-53R1 US 81-24-09	FUEL LEAKAGE	88/SB-707A
US 87-08-03	FAA APP REV AFM PERFORMANCE REDUCTION AIR START DOOR	
US 87-16-05	STRUCTURAL INTEGRITY	
US 89-14-03 US 97-20-02	FLAP UNIVERSAL JOINTS POWER LEVERS	
L. 188A	( L 188 SERIES )	
L 188C	( L 188 SERIES )	
382 SERIES		
US 67-18-03	ENGINE MOUNT TRUSS	
US 68-03-03	WING STA 181 LEFT & 181 RIGHT	
US 74-12-06 US 74-24-04	OUTER WING BEAM CAP LOWER CENTER WING	
US 74-24-08	ENGINE THROTTLE CABLES	
US 75-17-04 US 75-17-35	MAIN FRAMES	
US 75-17-35	PROPELLER TORQUE CHECK OUTER WING SPAR CAP	
US 75-18-04	OUTER WING LOWER PANELS	
US 75-19-02 US 76-09-11	WING BEAM CAPS	
US 79-03-04	CRANK ARM INSPECTION BALLSCREW ASSEMBLY IN MLG	
US 79-05-05	THROTTLE CABLES	
US 79~25-06 US 81-12-02	WINDOW LATCH CATCHES LONGERONS	A200 F2 00D4
US 85-23-03	FIRE EXTINGUISHER SQUIB INSP	A382-53-29R1 A382-26-4
US 87-18-04	PILOTS / CO-PILOTS CIRCUIT BREAKER PANEL	A382-24-19
US 88-09-03 US 88-10-05	LH & RH CONTROL COLUMNS OUTER WINGS - LOWER SURFACE PANELS	A382-57-71, -73
US 88-10-06	OUTER WING LOWER SURFACE PANELS	382-57-69,-70
US 89-16-09	NOSE LANDING GEAR STRUT ASSEMBLY	382-32-23,-31
US 92-10-14 US 94-26-15	AFM REVISION - A/C CABIN OPERATING PRESSURE OUTER WING ASSEMBLY OUTBOARD FASTENERS NOT INSP	382-53-50R1 382-57-74 APPEND A
US 96-12-20	ENGINE MOUNT STRUCTURE	A382-71-19/A82-687
US 96-24-14 US 97-21-13	MAIN LANDING GEAR BRAKES	A382-32-47
US 97-21-13 US 99-25-04	TO PREVENT LOSS OF AIRPLANE CNTRL/ENG OVERSPEED RING FITTING FASTENERS	A382-53-57
2225	( 000 557750 )	
<b>382G</b> US 90-04-02	( 382 SERIES ) ENGINE FIRE EXTINGUISHER SQUIB	A382-26-7
US 97-05-07	LIMITATIONS & PERFORMANCE DATA	AFM SUPP 382-16
L 1011 SERIES		
CF CF-90-28	AFT PRESSURE BULKHEAD	
US 74-16-07	CARGO DOORS	
US 74-18-11 US 74-24-11	GROUND SPEED BRAKE MAIN LANDING GEAR	
US 74-25-11	FIRE PULL HANDLE MODULE ASSEMBLY	
US 74-26-06	FIRE PULL HANDLE ASSEMBLY	İ
US 75-03-07 US 75-04-10	PASSENGER EVACUATION SYSTEM HEATER OVERHEAT CONDITIONS	
US 75-07-03	PLACARD FOR MACH TRIM SYSTEM	
US 75-08-04 US 75-08-14	FIRE HAZARD IN CARGO COMPARTMENT CARGO DOOR HOOKS	İ
US 75-08-14 US 75-08-19	RUDDER PEDALS	
US 75-09-01	UNDER FLOOR LOUNGE	
US 75-09-12 US 75-09-16	AUTOPILOTS ELEVATORS, AILERONS, RUDDER CONTROL	
US 75-10-02R2	GALLEY SERVICE AREA	
US 75-11-09	COUNTERBALANCE	
US 75-12-11 US 75-15-05	UNWANTED PITCH UP IN AUTOLAND MODE FLOOR CAPABILITY	
US 75-17-17	FLIGHT ATTENDANT REST SEAT	
US 75-24-05	FIRE HAZARD	
US 76-01-07 US 76-09-03	SLIDE RAFT EVACUATION SYSTEM INFLIGHT DEPRESSURIZATION	
US 76-09-07	. S-DUCT ASSEMBLY	
US 76-14-04	MAIN LANDING GEAR MODIFICATION	

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMBER SUBJECT
ORIGINE NUMBERO DE CONSIGNE SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
1004115	5 D		
LOCKHE	1 SERIES		
	NUED / SUITE)		
US	76-16-06	PUMP PRESSURE SYSTEM	
US	76-17-05	DAMAGED ELECTRICAL WIRES	
US	76-20-08	MAIN LANDING GEAR ASSY	
US	76-21-01	L-1011 WITH C-1A CARGO DOORS	
US	76-22-06	ATTENDANT'S SEAT BELTS	
US	77-18-07	JAMMED ELEVATOR DRIVE	
US	78-18-06	"S" DUCT FIRE SEAL	
US	79-08-04R2	MLF TRUCK PIVOT PINS	
US	79-14-03	HYDRAULIC SYSTEM	
US	79-17-03	MAIN LANDING BRAKES INPUT STRAPS	
US	79-18-09	ENGINE GENERATOR FEEDER CABLES	
US	79-19-08 79-20-04	PRESSURE RELIEF DOOR	
US	79-20-04	ELEVATOR DRIVE SYSTEM	
US	79-25-02R1	CABIN PRESSURIZATION	
US	80-02-03R1	MAIN LANDING GEAR PISTONS	
US	80-15-01	MLG FWD/AFT TRUNNION PINS LG ALTERNATE BRAKE/LG ACCUMULATOR	093-32-A167
US	80-19-04	FUSELAGE STRUCTURE	093-32-A121
US	80-19-18	FIRE DAMAGE TO SERVICE CENTER	093-53-A190
US	80-25-04	FUEL SHUT-OFF VALVES	093-21-A180
US	81-01-03	OUTBOARD AILERON SUPPORT FITTINGS	093-28-062 093-57-143
US	81-01-07	RUDDER SERVO PLATES	093-27-231
US	81-02-08	OXYGEN GENERATORS	093-35-030
US	81-07-04	MLG WHEEL ASSEMBLIES	093-32-184
US	81-08-01R1	BRAKE SYSTEM CHECK	093-32-145
US US	81-18-51R4	FUSELAGE DECOMPRESSION	093-53-207
US	81-21-51R1	REVISION TO AFM LR-25	093-77-052
U\$	81-26-06 81-26-51R3	ELECTRICAL SYSTEM MODIFICATION	093-23-83
US	82-03-04R1	FUSELAGE STATIONS INSPECTION	093-53-208
US	82-04-07	FLAMMABLE FLUID LEAKAGE VOR/DME RADIO SYSTEMS	093-49-058
US	82-10-52R1	MLG STRUT CYLINDERS	093-34-146
US	82-15-05	APU FEEDER CABLE INSP	093-32-131
US	82-27-12	ELECTRICAL SYSTEM	093-25-254
UŞ	83-08-06	AIRCRAFT WIRING	093-24-080 093-22-147
US	83-09-51R1		093-28-060
US	84-03-05	ELECTRICAL WIRING INSPECTION	093-27-285
US	84-04-01	AIRCRAFT WIRING INSP AND MOD	093-30-055
US	84-09-51R1	RELIEF VALVE MOUNT ADAP	
US	84-13-51R1	FUEL SYSTEM LIMITATIONS	093-28-072
US US	85-05-04 85-07-0504	HYDRAULIC SYSTEM MOD	093-29-065, -085
US	85-07-05R1 85-09-03	AC/DC ELECTRICAL POWER	093-21-214R1
US	85-18-04	AFM REVISION - FIRE HAZARD	
US	85-20-02	WIRE HARNESS	093-30-056
US	85-22-13	ELEVATOR TRAILING EDGE PANELS PITCH CONTROL	093-55-026
US	85-22-51	APU CABLES AND FEEDER CABLE INSPECTION	093-27-290
US	85-23-01		093-24-A127
US	86-01-03	CONTROL SYSTEM BRAKE ASSY PASSENGER DOORS	093-27-216
US	86-01-05	OXYGEN INITIATOR TIMER SWITCHES	093-35-041
US	86-07-03	FAN COWL SUPPORT STRUT	033 33 041
	86-23-52R2	WING REAR SPAR	093-57-A181R3
US	87-04-16	FAN COWL SUPPORT STRUT	
	87-05-51	STC - FLOOR PROXIMITY LIGHTING SYSTEM	
	87-06-06	PYLON ATTACHMENT BOLTS	093-54-049
US	87-08-06	PASSENGER OXYGEN SYSTEM	093-35-04R3
US	87-08-09	NITROGEN INFLATION A / C TIRES	
	87-15-51	MLG SHOCK STRUT CYLINDER	093-32-A211R1
	88-07-51R1 88-17-08	AC ELECTRIC-DRIVEN HYDRAULIC PUMP	093-29-AD88
	89-18-11	FLT ATTENDANTS SEAT BELTS & SHOULDER HARNESSES	093-25-517
	89-20-07	APU - STARTER GROUND CABLE STUDS/BRACKET	093-49-062
	90-03-15	FUEL FEED LINE - PYLONS 1 & 3	000 55 000
	90-15-10	L & R #3 FLAP VANE OUTBOARD CARRIAGE LINK ASSY BLEED AIR DUCT COMPENSATORS	093-57-209
	91-07-03	AFT PRESSURE BULKHEAD	093-36-064
	91-23-12	PREVENT LOSS OF MLG BRAKING EFFECTIVENESS	093-53-263
US	92-16-19	AIRPLANE PITCH CONTROL ACTUATORS - INSPECTION	093-32-253 093-27-304
	93-20-03	CORROSION PREVENTION & CONTROL	LR31889
	93-24-12	CARGO BOOK LATCHING MECHANISM	093-52-155 REV 1
	94-03-09	INBRD & OUTBRD LUG EACH FLAP VANE - INSPECT	093-57-199
	94-05-01	AGING AIRCRAFT - INSPECTION AND STRUCTURAL MODS	093-51-035
05	94-23-07	FLIGHT CONTROLS - MODS & INSPECTIONS	093-27-301
	AFT / AFRONEES		

MAKE / CONSTRUCTEUR

(SERIES / SERIE)

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

SUBJECT SUJET

		SUJET	BULLETIN DE SERVICE DE REF
LOCKHEE	D		
	SERIES		
	JED / SUITE)		
US	94-26-09	RAM AIR TURBINE - SEPARATION OF TURBINE BLADES	000 00 000
US	95-06-51	BRAIDED FUEL LINF	093-29-098
US	95-10-17	STRUCTURAL INTEGRITY OF THE FUSELAGE SHELL	093-28-A091
US	95-17-03	AFT PRESSURE BULKHEAD	093-53-A271 093-53-258
US	95-20-04R1	PRINCIPAL STRUCTURAL FLEMENTS - NOT	CID LG92ER0060
US	95-21-07	FLUID DRAINAGE AREA OF THE FUSELAGE	093-53-095 REV 2
US	95-21-16	MAIN LANDING GEAR ATTACH PINS	002-22-250
US	95-26-11	FITTINGS - AFT PRESSURE BULKHEAD TO FUSE STRINGERS	000 02 200
US US	96-20-10	CANTED PRESSURE BULKHEAD	092-52-277
	97-14-07	RB211-524 ENGINES - HIGH SPEED GEAR BOX FIRE WARN	093-26-039
	98-09-23 98-10-14	FIRE DETECTOR SYSTEM / GEARBOX RREATHER DUCT	093-26-036
	99-07-05	CRACKING UPPER & LOWER REAR SPAR CAPS - NDT INSP	093-57-203 REV 4/6
	99-08-20	DIAGONAL TRUSS WEB JOINT OF ELEVATOR	093-55-031
	99-09-14	PRESSURE BULKHEAD (FS) 1363	093-53-268
	99-13-08	AIRFRAME STRUCTUAL - FS 983 MAIN FRAME LH/RH INSP FATIGUE CRACKING REAR SPAR OF WING	
	99-17-13	HORIZONTAL STAB PINS/BUSHES	093-57-218R1
	99-24-12	WING FUEL TANK BOOSTER PUMPS	SB 093-27-306 SB 093-28-093
			30 033-20-033
L 1011		( L 1011 SERIES )	
	96-02-06	WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	
US	99-02-05	GALLEY LIFT PRIMARY AND SECONDARY DRIVE SHAFTS	093-25-294 R2
L 1011	385 1 14	( L 1011 SERIES )	
	96-02-06	WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	
	99-02-05	GALLEY LIFT PRIMARY AND SECONDARY DRIVE SHAFTS	003-2E-304 D0
		AND SECONDARY DRIVE SHAFIS	093-25-394 R2
	385 1 15	( L 1011 SERIES )	
	96-02-06	WINDSHEAR DETECTION AND RECOVERY GUIDANCE SYS	
US	99-02-05	GALLEY LIFT PRIMARY AND SECONDARY DRIVE SHAFTS .	093-25-394 R2
L 1011	385 3	( L 1011 SERIES )	
8 SERIE			
US	47-10-40 47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1	STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION	4-46 3-47 1-51
US	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES )	3-47 1-51
US	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 51-03-05 94-16-02	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( B SERIES )	3-47
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES )	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( B SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 55-24-01 61-03-05 94-16-02 96-24-17R1	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES )	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 55-24-01 61-03-05 94-16-02 96-24-17R1	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES )	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( B SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( B SERIES ) FUEL SYSTEM MODIFICATIONS  ( B SERIES )	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 55-24-01 61-03-05 94-16-02 96-24-17R1	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( B SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( B SERIES ) FUEL SYSTEM MODIFICATIONS  ( B SERIES ) CABIN HEAT SYSTEM  ( 8 SERIES )	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51
US	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-09-03 48-49-01 49-43-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01 50-37-01 52-24-03	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-49-01 49-43-02 51-10-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-09-03 48-49-01 49-43-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01 50-37-01 52-24-03	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-09-03 48-49-01 49-43-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01 50-37-01 52-24-03 62-24-03	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51
US US US US US US US US US US US US US U	47-22-01 48-08-02 48-09-03 48-09-03 48-49-01 49-43-02 55-24-01 61-03-05 94-16-02 96-24-17R1 46-30-01 50-37-01 52-24-03	BULKHEAD REINFORCEMENT FOR SEAPLANES CLEVELAND 6:00 DMB WHEELS KOLLSMAN AIRSPEED BAFFLE VERTICAL STABILIZER SPAR FITTING STABILIZER SPAR INSPECTION CONTROL CABLE INSPECTION CORROSION INSPECTION FUEL LINE INTERFERENCE STABILIZER FORWARD ATTACH FITTING WING SPAR FAILURE CORROSION  ( 8 SERIES ) CONTROL STICK HORN ADJUSTMENT SCREW  ( 8 SERIES ) FUEL SYSTEM MODIFICATIONS  ( 8 SERIES ) CABIN HEAT SYSTEM  ( 8 SERIES ) CABIN HEAT SYSTEM	3-47 1-51

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

ONTOINE	NUMERO DE CONSIGNE		2015 (	BOLLETIN DE SERVICE DE HEF
MARTIN JRM 3				
MAULE				
M 4 SI			TATE TO SUCCE ACT ATTACK TUDE	
US	79-12-01		TAIL-TO-FUSELAGE ATTACH TUBE	
US	81-14-02		RUDDER PEDAL V-BAR	
US	84-09-07		PLUG TYPE DRAIN FITTINGS REPL	
US	98-15-18		WING LIFT STRUT CORROSION SUPERSEDES 95-26-18	SB 11
M 4		( M 4	SERIES )	
US	65-18-01		UPPER FUSELAGE FABRIC	
US	68-07-08		RUDDER TRIM TAB CONTROL	
US	69-20-02		AILERON CONTROL SYSTEM PULLEY	
	00 00			
M 4 T		( M 4	SERIES )	***************************************
us	68-07-08	( 14 4	RUDDER TRIM TAB CONTROL	
US	69-20-02			
03	69-20-02		AILERON CONTROL SYSTEM PULLEY	
			CEDIES	
M 4 18		( M 4	SERIES )	
	71-06-06		SEAT TRACK AND GUIDE	
US	73-11-06		ENGINE OVERHEAT	
		,		***************************************
M 4 21		( M 4	SERIES )	
US	65-18-01		UPPER FUSELAGE FABRIC	
US	65-28-04		FUEL SYSTEM MODIFICATIONS	
US	68-07-08		RUDDER TRIM TAB CONTROL	
US	69-20-02		AILERON CONTROL SYSTEM PULLEY	•••••
US	75-11-02		FUEL LINES	
US	96-10-05		ENGINE FIRE DUE TO GASCOLATOR AND EXHAUST PROX.	SB 10
			THE PER TO GROUP AND EXTENDED FROM	35 10
M 4 21	IOC	( M 4	SERIES )	
US	68-07-08	( 111 -4	RUDDER TRIM TAB CONTROL	
us	69-20-02		AILERON CONTROL SYSTEM PULLEY	
US				
	75-11-02		FUEL LINES	
US	96-10-05		ENGINE FIRE DUE TO GASCOLATOR AND EXHAUST PROX.	SB 10
M 4 22		( M 4	SERIES )	
	68-07-08		RUDDER TRIM TAB CONTROL	
US	69-20-02		AILERON CONTROL SYSTEM PULLEY	
US	71-06-06		SEAT TRACK AND GUIDE	
US	71-17-01		FUEL LINE BLOCKAGE	
US	73~11-06		ENGINE OVERHEAT	
M 5 SE	RIES			
US	79-12-01		TAIL-TO-FUSELAGE ATTACH TUBE	
US	81-14-02		RUDDER PEDAL V-BAR	
US	84-09-07		PLUG TYPE DRAIN FITTINGS REPL	***************************************
	86-17-11		FUEL CROSSFEED LINE	7
US	98-15-18			
US	30-13-18		WING LIFT STRUT CORROSION SUPERSEDES 95-26-18	SB 11
M E 40	000	7 34 5	CENTEC \	***************************************
M 5 18		c m >	SERIES )	
	00	/ **	CEDIEC )	
M 5 21	75 11 00	( M 5	SERIES )	
US	75-11-02		FUEL LINES	
US	78-13-08		ENGINE FUEL SUPPLY	
		,		
M 5 22	20C	( M 5	SERIES )	
M 5 23	15C	( M 5	SERIES )	
US	78-13-08		ENGINE FUEL SUPPLY	
US			ENGINE STOPPAGE PREVENTION	
M 6 23	5			***************************************
IIS	82-03-05		ENGINE STOPPAGE PREVENTION	3
US	98-15-18		WING LIFT STRUT CORROSION SUPERSEDES 95-26-18	SP 11
03	30 13 10		WING ETLI SIKO: COMMOSTON SONEKSEDES 30-50-18	SB 11
M 7 22	E CEDIES			
	S SERIES		WITHOU I SET CIPILIT CORPORATOR CONTRACTOR OF THE	00
US	98-15-18		WING LIFT STRUT CORROSION SUPERSEDES 95-26-18	SB 11
			\	
M 7 23	5	( M 7	235 SERIES )	
US	97-26-14		POWER LEVER POSITIONING BELOW FLIGHT IDLE STOP	
M 7 23	15B	( M 7	235 SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

ORIGINE	NOWERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
MAULE			
M 7 2	35C	( M 7 235 SERIES )	
MX 7			
US	98-15-18	WING LIFT STRUT CORROSION SUPERSEDES 95-26-18	SB 11
MY 7	225		
MX 7	98-15-18	WING LIET CIDUT CORROCTOR	
00	30 13 18	WING LIFT STRUT CORROSION SUPERSEDES 95-26-18	SB 11
MCDONN	ELL DOUGLAS HC		
500N			
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	96-08-03	FLIGHT TRAILS HELI. STC # SH6080NM HARDPOINT ASSY	OAIC 702.21
US US	96-10-09 97-15-08	MAIN ROTOR BLADE CHECK - ROOT FND CRACKING	NN-008
US	98-01-13	MAIN ROTOR TRANSMISSION OUTPUT GEAR	NN-009
US	98-03-15	MAIN ROTOR BLADE SEPARATION SUPERCEDED BY 98-15-26	500N-014
US	98-15-26	MAIN BLADE CRACKING	500N-015R1
US	98-21-12	OVERRUNNING CLUTCH RETAINER	SB 500-015R3
US	99-04-12	INPUT SHAFT COUPLING ASSEMBLY	SB500N-013
US	99-08-07	ENGINE CONTROL RELAYS	500N-017
US	99-20-12	TO PREVENT FAILURE OF BRACKET P/N 369F55190-1	
US	99-25-08	FORWARD & CENTER THRUSTER CONTROL CABLES	021/028
600N			
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAD 700 01
US	98-03-15	SUPERCEDED BY 98-15-26	CAR 702.21 600N-007
US	98-15-26	MAIN BLADE CRACKING	SB 600-007R2
US	99-04-12	INPUT SHAFT COUPLING ASSEMBLY	SB600N-003
US	99-08-07	ENGINE CONTROL RELAYS	600N-014
US	99-17-18	COLLECTIVE CONTROLS - REVISED/NEW LIFE LIMITS TO PREVENT FAILURE OF BRACKET P/N 369F55190-1	MDHS SB 600N-009
US US	99-20-12	TO PREVENT FAILURE OF BRACKET P/N 369F55190-1	
03	99-25-08	FORWARD & CENTER THRUSTER CONTROL CABLES	021/028
MESSER	SCHMITT		
	SERIES		
CF	CF-88-07R2	MAIN ROTOR PITCH LINK ROD END	
CF	CF-88-18	SAFETYING OF BLADE BOLTS	BK105-10-101 REV 3
CF	CF-89-11	CONTINUOUS IGNITION SYSTEM	
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
GY GY	74-162 75-103	TAIL ROTOR BLADES / END CAPS	30-8
GY	75-103	QUADRUPLE NUTS - MAIN ROTOR HEAD HOSE ASSEMBLIES	9
GY	75-170/2	QUADRUPLE NUTS & BOLTS - MAIN ROTOR HEAD	11, 12 10-18
GY	75-171	ELECTRICAL PLUG/CONNECTOR - ENGINE FLOOR	90~11
GY	75-172/2	PISTON RODS - TANDEMHYDRAULIC UNITS	40-19, 40-21
	75-191/2	ELECTRICAL SYSTEM - LOAD HOOK RELEASE	80-21
GY	75-238	FLANGE RIGHT OUTBOARD ENGINE MOUNT	60-25R1
GY	76-136/2	GEARBOX SUPPORTS - SERVICE LIFE	10.00 10.10
GY GY	76-206	OIL PUMP MAIN ROTOR GEARBOX	10-20, 10-16
GY	76-255/2 76-256/3	DUAL HYDRAULIC BOOSTER ROTOR BRAKE	40-15, 40-29 13R2
GY	76-317/2	TAIL BOOM ASSEMBLY	15
GY	77-306	INPUT SHAFT & RAM AIR VENT	10-7R1, 60-37
GY	78-257	DUAL HYDRAULIC SYSTEM	40-15
GY	78-295/2	TAIL ROTOR BLADES/HEADS	16R2
GY	78-339	TAIL ROTOR BLADE GRIPS	30-24
GY	79-135	BEARINGS MAIN ROTOR TRANSMISSION	10-34
GΥ	79-136	EXHAUST PIPE CLAMPS	17
GY	79-137	ENGINE - ASBESTOS CLOTH INGESTION	60-43
GY GY	79-144 79-234	TAIL ROTOR BLADE GRIPS TAIL ROTOR CONTROL LINKAGE	18 20-10R2
GY	79-234	DUAL HYDRAULIC BOOST SYSTEM	40-38
GY	79-443	BENDIX SHAFTS & CLUTCHES	60-45
GY	79-444	ENGINE COWLINGS	60-46
GY	80-208	MAIN GEARBOX	60-54, 10-37
GY	80-95/2	BENDIX DRIVE SHAFT	19R1
GY	82-99	HOIST CABLE	21
	83-124/2	TANDEM HYDRAULIC UNITS	22 R1
GY		TAIL ROTOR BLADES	23
GY GY	84-128		00 0404
GY GY GY	84-177/2	CARGO HOOK RELEASE MECHANISM	
GY GY GY	84-177/2 84-178	CARGO HOOK RELEASE MECHANISM  VERTICAL FIN	30-18R2
GY GY GY	84-177/2	CARGO HOOK RELEASE MECHANISM	

MAKE / CONSTRUCTEUR MODEL / MODELE	(SERIES / SERIE)	
ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
MECCEDCOUNTTY		DOUBLE THE DE GETTING BE NET
MESSERSCHMITT BO105 SERIES		
(CONTINUED / SUITE)	·	
GY 86-148 GY 87-106/2	FUEL SYSTEM DRAIN VALVE **SUPERCEDED BY CF-88-18**	B0105-60-101,65
GY 89-123/2	TANDEMHYDRAULIC UNIT - VALVE BODY MANIFOLDS	B010101R2 B0105-40-102
GY 91-204 GY 92-273	CLEARANCES - PC AIRTUBE	ASB 105-60-105
GY 97-275	MAIN TRANSMISSION, INTERMEDIATE & TR GB FLANGES MAIN TRANSMISSION CRACKS ON ROTOR MAST FLANGE	105-30-104 ASB B0105-10-110
BO105 C CDN		702 20100 10 110
GY 95-458	( BO105 SERIES )  INSTALLATION OF VOLTAGE CONTROLLER	105-80-118 REV1
GY 1999-300/3	MAIN ROTOR TENSION/TORSION STRAPS	ASB BO 105-10-114R2
B0105 LS A3	( BO105 SERIES )	
CF CF-91-41 CF CF-97-18	TORQUE IND. HOSE ASSEMBLIES	ASB 105 LS-60-4
CF CF-99-24R1	MAIN ROTOR MAST FLANGE CRACKING MAIN ROTOR HEAD TENSION STRAP	ASB BO 105LS-10-9 BO 105 LS-10-10
BO105 S CDN BS		BC 103 E3-10-10
GY 95-458	( BO105 SERIES )  INSTALLATION OF VOLTAGE CONTROLLER	105-80-118 REV1
GY 1999-300/3	MAIN ROTOR TENSION/TORSION STRAPS	BO 105-10-114R2
B0105 S CDN BS 4	( BO105 SERIES )	
GY 95-458	INSTALLATION OF VOLTAGE CONTROLLER	105-80-118 REV1
GY 1999-300/3	MAIN ROTOR TENSION/TORSION STRAPS	ASB BO 105-10-114R2
BK117 SERIES		
CF CF-88-07R2 CF CF-88-18	MAIN ROTOR PITCH LINK ROD ENDS SAFETYING OF BLADE BOLTS	BK117-10-103
CF CF-98-15	HELICOPTER RESCUE SYSTEMS	BK117-10-101 REV 3 CAR 702.21
GY 84-177/2 GY 85-208	CARGO HOOK RELEASE MECHANISM	80-4R1
GY 85-50	MAIN TRANSMISSION ASSEMBLY - FREEWHEEL CONTROL ROD DIMENSIONS	AB-MBB-BK-117-1
GY 86-1/2 GY 86-149	STICK POSITION AUGMENTATION SYSTEM (SPAS)	
GY 86-190	TAIL ROTOR GEARBOX ATTACHMENT BOLTS FIRE EXTINGUISHING SYSTEM TEE VALVE	BK117-4 BK117-70-100
GY 87-106/2 GY 87-147	**SUPERCEDED BY CF-88-18** CHIP_DETECTION - ENGINE OIL SYSTEM	BD10101R2
GY 88-122	VNE-SCHEDULE PLACARD	BK117-70-101
GY 94-280/2 GY 95-242	INSPECTION OF MAIN ROTOR BLADES (AD REV 14-12-94)	ASB BK117-10-108
GY 1997-144/3	RECALCULATING LIFE LIMITS OF VARIOUS PARTS TAIL BOOM VERTICAL FIN INSPECTION	BK-117-106R1,109,110 BK117-30-106 REV4
GY 97-276 GY 97-350	MAIN TRANSMISSION CRACKS ON ROTOR MAST FLANGE	
GY 1999-284/2	LIFE LIMIT ON BEVEL GEAR - A/C S/N SPECIFIC AD INSP AND REPL OF TENSION-TORSION STRAP	ASB MBB 117-10-113 MBB BK 117-10-120 R1
GY 1999-302	TRANSMISSION/ENGINE COWLING DOORS	MBB-BK 117-20-109 R2
BK117 A 4D	( BK117 SERIES )	
GY 90-212/2	DISPERSION OF STATIC ELECTRICITY	90-104,-105, 60-107,
BK117 B 1D	( BK117 SERIES )	
MEYERS		
MAC145		
MILES HAWK MAJ M2W		
MITCHELL		
CENTAUR 101E US 65-22-01	CHANDEL DAY AND ADDRESS OF	
	CHANNEL P/N 105-1011321-14 - WING TO LIFT STRUT	
MITSUBISHI MU 2B SERIES		
CF CF-89-06	ELECTRICAL PITCH TRIM SYSTEM	
JN 518 JN 785B-73	ELEVATOR HINGE FITTING / STABILIZER RIB	079
JN 948A-74	NICKEL-CADMIUM BATTERY REPLACEMENT WINDSHIELD/DEFOG AIR WARNING INSPECTION	163A
JN 1188-75 JN 1209-75	PROPELLER PITCH CONTROL LEVER	168
JN 1284-75	NOSE LANDING GEAR SHIMMY DAMPER MLG DRAG STRUT	169
JN 1328-76 JN 1520A-77	HEATPROOF ENGINE BLEED AIR TUBING	070C
JN 948A-1-78	LATCH LINK - ENGINE NACELLE UPPER DOOR WINDSHIELD/DEFOG AIR WARNING INSPECTION	180A
	TOTAL DE ATT WARNING INSPECTION	163B

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

			BULLETIN DE SERVICE DE REF.
MITSH	BISHI		
	B SERIES		
	INUED / SUITE)		
JN	1768-79	NOCE LANGTIC	
JN	1001B-81	NOSE LANDING GEAR STRUT ASSEMBLY	181
JN	2070-81	ELEVATOR TRIM TAB BRACKET	176C
JN	2113-82	NLG DOWN LOCK MECHANISM	188
JN	1001B-2-84	ENGINE ELECTRICAL HARNESS	191
JN	2342-1-84	ELEVATOR TRIM TAB BRACKET	176E
JN	1768-1-85	RETORQUE COUPLING NUT - ENGINE BLEED TUBE	196A
JN	2451-85	NOSE LANDING GEAR STRUT ASSEMBLY	181B
JN		FLAP FLEXIBLE SHAFT	198
JN	2450A-87	ALM REVISION - ANTI-ICE/DEICE CIRCUITS	SR 053A
JN	2451-1-87	LUAP FLEXIBLE SHAF!	198
	2252-2-88	FLAP TORQUE TUBE JOINT	189B
JN	3901-93	FUEL LEAK AT NAV LIGHT	
JN	3942-1-94	EMERGENCY GEARDOWN GEARBOX	219A
JN	3942-94	PIN - EMERGENCY GEARDOWN GEARBOX HOUSING	219
JN	3393A-96	ANTIICE/DEICE	212A
JN	4310-96	WING TIP TANK ATTACH BOLTS	225
JN	4379-96	PROPELLER FEATHERING LINKEAGE	229
JN	4552-96	OPERATION IN SEVERE TOTALS CONDITIONS	108 (063/30-009)
JN	2679A-97	AUTO IGNITION SYSTEM (AUTO RE-LIGHT)	226A, 210A
JN	4529-97	ICE DETECTION SYSTEM	220A, 210A
JN	4625-97	ICING CONDITIONS AND AUTO PILOT	217B 231
JN	4626-97	ICING CONDITIONS AND AUTO PILOT DE-ICING SYSTEM PROPER FUNCTIONING	232
JN	4684-97	LANDING GEAR EXTENSION	
JN	3740A-98	AUTOD TO OT AUGO	230
JN	4753-98	FLIGHT IN KNOWN ICING CONDITIONS	216 & 228
		TOTAL THE MACHINE TOTAL CONDITIONS	
MU 28	326A		
CF	CF-89-06	ELECTRICAL PITCH TRIM SYSTEM	
US	79-24-02	OUTER FUEL TANK WIRING	
US	81-25-04 R1	ELECTRICAL WIRING INSPECTION	
US	84-12-04	TEMP PLACARD ANTI-ICE SYSTEM	
US	84-25-02	TRIM TAB BRACKETS	
US	85-04-03 R1		
US			
	86-20-01	PITOT TUBE - ANTI-ICE/DE-ICE SYSTEM	
US	86-26-02	FLIGHT MANUAL - LIMITATIONS/ICING ENVIRONMENT	
US	87-04-03	FLAP FLEXIBLE SHAFT	051/27-007
US	88-13-01	AUTOPILOT/ELECTRIC PITCH TRIM SYSTEM	206
US	88-21-01R1	AUTOPILOT - MANUAL/ELECTRIC PITCH TRIM SYSTEM	
US	88-23-01	FLAP CONTROL - TORQUE TUBE JOINT	067/27-008
MU 2B	220		
		( MU 2B SERIES )	
JN	642-70	FUEL SYSTEM - ANTI-ICE ADDITIVE	112
JN	643-70	FUEL QUANTITY INDICATOR	109
JN	653-70	ENGINE NACELLE TAIL AREA - FUEL ENTRAPPMENT	116
JN	730-71	TOP COATING INSPECTION ON INTEGRAL TANK	143A
JN	730-1-72	TOP COATING INSPECTION ON INTEGRAL TANK	143A, 143B
JN	859-72	TWO BATTERY SYSTEM - SERIES RELAY	156
JN	9474-74	FLAP FLEXIBLE SHAFT	162A
JN	1202-75	ENGINE NACELLE LATCHES	171A
JN	1235-75	MLG FWD DOOR EMERGENCY OPERATING CABLE	170
JN	1272-75	MLG FWD DOOR ACTUATING MECHANISM SUPPORT	172
JN	1094A-76	FLAP JACK SCREW	167B
JN	1370A-81	TIP TANK FUEL / STROBE LIGHT	174C
JN	2048-81	ENGINE FIRE DETECTION CIRCUIT	187A
JN	2263-83	NLG - LH DRAG STRUT BRACKET	195
JN	730-2-86	TOP COATING INSPECTION ON INTEGRAL TANK	143C
JN	2856-87	TO STANDARDIZE THE WAY TO DISENGAGE THE AUTOPILOT	
JN	3378-90	RUDDER TRIM TAB	211
JN	3464-91	BENDIX AUTOPILOT	213
JN	4311-95	WINDSHIELD CRACK INSPECTION	224A
JN	4838-98	LANDING GEAR DRIVE TRAIN	235
JN	4889-98	INAPPROPIATE CALIBRATION OF ENGINE TORQUEMETER	233
JN	4890-98	INAPPROPIATE CALIBRATION OF ENGINE TORQUEMETER  INAPPROPIATE ADJUSTMENT FLIGHT IDLE FUEL FLOW	233
JN	5030-99	FATIGUE CRACKS OF FUSELAGE FRAME	MHI 209B
OIV	2020-33	TATIOUS CRACKS OF TOSELAGE FRAME	14111 2030
MU 2B	35	( MU 2B SERIES )	
JN	947A-74	FLAP FLEXIBLE SHAFT	162A
JN		ENGINE NACELLE LATCHES	171A
JN	1202-75	MLG FWD DOOR EMERGENCY OPERATING CABLE	170
JN	1235-75	MLG FWD DOOR EMERGENCY OPERATING CABLE MLG FWD DOOR ACTUATING MECHANISM SUPPORT	170
	1272-75	FLAP JACK SCREW	
JN	1094A-76		167B
JN	1353-76	BARREL NUTS - INNER/OUTER WING CONNECTION	175

MAKE / CONS		(SEDIFO	SEDIE)	
MODEL / MO ORIGIN ORIGINE	ODELE AD NUMBER NUMERO DE CONSIGNE	(SERIES /	SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
MU 2B3		( MU	2B SERIES )	
	UED / SUITE)	( 100	ZD SERIES /	
JN	1370A-81		TIP TANK FUEL / STROBE LIGHT	174C
JN	2263-83		NLG - LH DRAG STRUT BRACKET	195
JN	2545-86		GENERATOR CIRCUIT WIRES	201
JN JN	2856-87 2545-1-88		TO STANDARDIZE THE WAY TO DISENGAGE THE AUTOPILOT GENERATOR CIRCUIT WIRES	206 201A
JN	3464-91		BENDIX AUTOPILOT	213
JN	4311-95		WINDSHIELD CRACK INSPECTION	224A
JN	4838-98		LANDING GEAR DRIVE TRAIN	235
JN	4889-98		INAPPROPIATE CALIBRATION OF ENGINE TORQUEMETER	233
JN JN	4890-98		INAPPROPIATE ADJUSTMENT FLIGHT IDLE FUEL FLOW FATIGUE CRACKS OF FUSELAGE FRAME	234
US	5030-99 93-07-11		NOSE DOWN TRIM	MHI 209B 079/27-010
US	97-20-14		FLIGHT INTO KNOWN ICING CONDITIONS	0/9/2/-010
US	98-20-39		WING TIP TANK ATTACH BOLTS	225
MU 283	6	( MU	2B SERIES )	
JN	1094A-76		FLAP JACK SCREW	167B
JN	1353-76		BARREL NUTS - INNER/OUTER WING CONNECTION	175
JN	1370A-81		TIP TANK FUEL / STROBE LIGHT	174C
JN	2048-81		ENGINE FIRE DETECTION CIRCUIT	187A
JN JN	2263-83 3378-90		NLG - LH DRAG STRUT BRACKET	195
JN	3464-91		RUDDER TRIM TAB BENDIX AUTOPILOT	211 213
JN	4311-95		WINDSHIELD CRACK INSPECTION	224A
JN	4838-98		LANDING GEAR DRIVE TRAIN	235
JN	4889-98		INAPPROPIATE CALIBRATION OF ENGINE TORQUEMETER	233
JN	4890-98		INAPPROPIATE ADJUSTMENT FLIGHT IDLE FUEL FLOW	234
JN	5030-99		FATIGUE CRACKS OF FUSELAGE FRAME	MHI 209B
US US	93-07-11		NOSE DOWN TRIM	079/27-010
US	94-11-04 97-20-14		GROUND IDLE ADJUSTMENT FLIGHT INTO KNOWN ICING CONDITIONS	
US	98-20-39		WING TIP TANK ATTACH BOLTS	225
MU 2B3	64	•		
CF	CF-89-06		ELECTRICAL PITCH TRIM SYSTEM	
US	79-24-02		OUTER FUEL TANK WIRING	
US	80-04-01		AVIONIC EQUIPMENT MOUNTING SHELF	
US	81-25-04R1		ELECTRICAL WIRING INSPECTION	
	84-12-04		TEMP PLACARD ANTI-ICE SYSTEM	
	84-25-02 86-20-01		TRIM TAB BRACKETS	
	86-26-02		PITOT TUBE - ANTI-ICE/DE-ICE SYSTEM FLIGHT MANUAL - LIMITATIONS/ICING ENVIRONMENT	
	87-04-03		FLAP FLEXIBLE SHAFT	051/27-007
US	88-13-01		AUTOPILOT/ELECTRIC PITCH TRIM SYSTEM	206
	88-21-01R1		AUTOPILOT - MANUAL/ELECTRIC PITCH TRIM SYSTEM	
	88-23-01		FLAP CONTROL - TORQUE TUBE JOINT	067/27-008
	93-07-11		NOSE DOWN TRIM	079/27-010
	94-11-04 96-25-02		GROUND IDLE ADJUSTMENT OPERATION IN SEVERE ICING CONDITIONS	062/20 602 (402)
	97-20-14		FLIGHT INTO KNOWN ICING CONDITIONS	063/30-009 (108)
	97-25-02		POWER LEVER POSITIONING BELOW FLIGHT IDLE STOP	
	98-20-39		WING TIP TANK ATTACH BOLTS	225
MU 2B40	0			
	CF-89-06		ELECTRICAL PITCH TRIM SYSTEM	
US	79-24-02		OUTER FUEL TANK WIRING	
	81-25-04R1		ELECTRICAL WIRING INSPECTION	
	84-12-04		TEMP PLACARD ANTI-ICE SYSTEM	
	84-25-02		TRIM TAB BRACKETS	
	86-20-01 86-26-02		PITOT TUBE - ANTI-ICE/DE-ICE SYSTEM FLIGHT MANUAL - LIMITATIONS/ICING ENVIRONMENT	
	87-04-03		FLAP FLEXIBLE SHAFT	051/27-007
	88-13-01		AUTOPILOT/ELECTRIC PITCH TRIM SYSTEM	206
US	88-21-01R1		AUTOPILOT - MANUAL/ELECTRIC PITCH TRIM SYSTEM	
	88-23-01		FLAP CONTROL - TORQUE TUBE JOINT	067/27-008
	93-07-11		NOSE DOWN TRIM	079/27-010
	94-11-04		GROUND IDLE ADJUSTMENT	
	96-25-02		OPERATION IN SEVERE ICING CONDITIONS	063/30~009 (108)
	97-20-14 97-25-02		FLIGHT INTO KNOWN ICING CONDITIONS	
	98-20-39		POWER LEVER POSITIONING BELOW FLIGHT IDLE STOP WING TIP TANK ATTACH BOLTS	225
			WING III TANK ATTACH BULTS	225

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

	OWEN DE CONSIGNE	SUJET		BULLETIN DE SERVICE DE REF
MITSUBIS				
US 8 US 8 US 8 US 8 US 8 US 8 US 9	CF-89-06 66-20-01 86-26-02 87-04-03 88-13-01 88-21-01R1 88-23-01 88-23-01	AUTOPILOT/ELECTRIC PIT AUTOPILOT - MANUAL/ELE FLAP CONTROL - TORQUE NOSE DOWN TRIM GROUND IDLE ADJUSTMENT	DE-ICE SYSTEM TIONS/ICING ENVIRONMENT CH TRIM SYSTEM CTRIC PITCH TRIM SYSTEM TUBE JOINT	051/27-007 206 067/27-008 079/27-010
US 9	96-25-02 97-20-14 97-25-02 98-20-39	OPERATION IN SEVERE IC FLIGHT INTO KNOWN ICIN POWER LEVER POSITIONING WING TIP TANK ATTACH BO	ING CONDITIONS G CONDITIONS G BELOW FLIGHT IDLE STOP OLTS	063/30-009 (108) 225
MU 300 9	SERIES 8-06-30	OUTFLOW/SAFETY VALVE FA		AS 103570-21-4012R1
MU 300 CF C	F-94-18	300 SERIES ) AFM FLIGHT IN KNOWN IC	ING CONDITIONS	
MOLINO O			SEE/VOIR: EIRIAVION OY	
PIK 20		20 SERIES )	SEE/VOIR: EIRIAVION OY	
MONOCOUPE 90AF				
MOONEY M18C				
US 5 US 5 US 7	1-03-01 3-17-01 9-22-03 9-11-05 R1 9-18-07	FUEL LINE REWORK CONTROL STICK BOOT EMPENNAGE WOOD DETERIORATION WOOD DETERIORATION		
M20 SERI				
US 98	5-23-04 8-21-21 8-21-26	ELECTRIC GEAR SYSTEMS BOB FIELDS AEROCESSORIE MAIN LDG FAILURE CAUSED	S STC D BY LEG BRACKET FAILURE	M20-265 13 APR 98
CF CF US 55 US 55 US 55 US 61 US 63 US 67 US 73 US 67 US 67 US 75	68-16 76-16R1 7-10-01 3-23-03 3-06-03 3-14-02 22-07 3-10-05 5-22-03 7-11-05 3-21-01 7-17-04 6-19-10	SERIES ) FIN DETERIORATION WOODEN STRUCTURE FAA A LANDING GEAR BELLCRANK AILERON COUNTERBALANCE HINGE BEARING BRACKETS FUEL SELECTOR VALVE FUEL AND OIL PRESSURE G EMPENNAGE ATTACH BRACKE TAIL TRUSS TAIL TRUSS TAIL TRUSS REPLACEMENT FLIGHT CONTROL LANDING CONTROL WHEEL SHAFT WOOD STRUCTURE - PROOF	BRACKET BRACE  AGE LINES TS  GEAR SYSTEM	M2O-17OA
M2OA CF CF	( <b>M20</b>	SERIES ) FIN DETERIORATION		
US 58 US 59 US 59 US 59 US 61 US 63 US 65 US 65 US 65	0-11-03 1-14-02 1-25-06 -22-07 1-10-05 1-22-03 11-05 1-21-01 17-04	WOODEN STRUCTURE FAA A CARBURETOR AIR BOX REWO HINGE BEARING BRACKETS EXHAUST HEATER INSPECTI FUEL SELECTOR VALVE CARBURETOR ALTERNATE AI FUEL AND OIL PRESSURE G EMPENNAGE ATTACH BRACKE TAIL TRUSS TAIL TRUSS TAIL TRUSS REPLACEMENT FLIGHT CONTROL LANDING CONTROL WHEEL SHAFT WOOD STRUCTURE - PROOF	RK ON R SOURCE AGE LINES TS GEAR SYSTEMS	M20-170A

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

US 67-22-07					BOLLETIN DE SERVICE DE REF.
M208	MODNEY				
US 72-10-1 US 77-21-01 US 77-21-01 US 77-21-01 US 77-21-01 US 77-17-03 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 75-04-09 US 67-23-08 US 75-04-09 US 75-04-09 US 75-04-09 US 75-04-09 US 77-17-04 US 78-17-01 US 78-17-01 US 78-17-04 US 78-17-04 US 78-17-01 US 98-24-11 US 78-17-01 US 98-24-11 US 78-17-04 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-2			( M20	SEDIES )	
US 77-17-04   FLIGHT CONTROL LANDING GEAR SYSTEMS   M20-264   US 77-17-04   FLIGHT CONTROL LINES   M20-264   US 68-24-11   M20-264   FUEL TANK BAYS AND RIB STATION INSP   US 68-07-05   ELECTRIC LANDING GEAR SYSTEMS   US 75-09-06   ELECTRIC LANDING GEAR SYSTEMS   US 76-09-08   LANDING GEAR ACTUAL MINEMERS   US 76-10-05   LANDING GEAR ACTUAL MINEMERS   US 78-10-05   LANDING GEAR ACTUAL MINEMERS   US 89-24-03   FUEL PUMP   US 67-23-06   GEOTOR TRANSMITTER   US 67-23-06   GEOTOR TRANSMITTER   US 67-23-06   FUEL TANK BAYS AND RIB STATION INSP   M200   M30		61-22-07	( 1420		
US 88-24-03  M20C  US 66-07-05  US 67-23-06  US 75-04-09  US 77-04  US 77-04  US 77-04  US 78-09-08  US 78-09-08  US 78-09-08  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-05  US 78-10-06  US 78-10-05  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10-06  US 78-10					
M20C					
M20C					
US 66-07-06 DUKES FUEL PUMP   US 67-32-06 DUKES FUEL PUMP   US 73-21-01 FLIGHT CONTROL LANDING GAR SYSTEMS   US 73-04-09 LANDING GAR ACTUATOR   US 73-04-09 ENGINE MOUNT MEMBERS   US 76-10-06 ENGINE MOUNT MEMBERS   US 77-10-01 EMERGENCY LOCATOR TRANSMITTER   US 85-24-03 FUEL TAMA BAYS AND RIB STATION INSP   M20-264   M200   US 66-07-30-6   US 73-21-01 FLIGHT CONTROL LINKS   M20-264   M201   US 85-24-03 FUEL TAMA BAYS AND RIB STATION INSP   M202   US 66-07-30-6   US 73-21-01 FLIGHT CONTROL LINDING GAR SYSTEMS   US 73-21-01 FLIGHT CONTROL LINDING GAR SYSTEMS   US 85-24-03 CONTROL WHEEL SHAFT   US 85-24-03 FLIED CONTROL WHEEL SHAFT   US 85-24-03 FLIED CONTROL WHEEL SHAFT   US 75-04-09 LANDING GAR ACTUATOR   US 75-04-09 LANDING GAR SEMBLY   US 75-04-09 LANDING GAR SEMBLY   US 75-04-09 LANDING GAR ACTUATOR   US 75-04-09 LAN	US	98-24-11		AILERON CONTROL LINKS	M20-264
US 66-07-06 DUKES FUEL PUMP   US 67-32-06 DUKES FUEL PUMP   US 73-21-01 FLIGHT CONTROL LANDING GAR SYSTEMS   US 73-04-09 LANDING GAR ACTUATOR   US 73-04-09 ENGINE MOUNT MEMBERS   US 76-10-06 ENGINE MOUNT MEMBERS   US 77-10-01 EMERGENCY LOCATOR TRANSMITTER   US 85-24-03 FUEL TAMA BAYS AND RIB STATION INSP   M20-264   M200   US 66-07-30-6   US 73-21-01 FLIGHT CONTROL LINKS   M20-264   M201   US 85-24-03 FUEL TAMA BAYS AND RIB STATION INSP   M202   US 66-07-30-6   US 73-21-01 FLIGHT CONTROL LINDING GAR SYSTEMS   US 73-21-01 FLIGHT CONTROL LINDING GAR SYSTEMS   US 85-24-03 CONTROL WHEEL SHAFT   US 85-24-03 FLIED CONTROL WHEEL SHAFT   US 85-24-03 FLIED CONTROL WHEEL SHAFT   US 75-04-09 LANDING GAR ACTUATOR   US 75-04-09 LANDING GAR SEMBLY   US 75-04-09 LANDING GAR SEMBLY   US 75-04-09 LANDING GAR ACTUATOR   US 75-04-09 LAN	Manc		( M20	CEDIEC )	
US   67-23-06   DUKES FUEL PUMP   TO   TO   TO   TO   TO   TO   TO   T		66-07-05	( M20		
US   73-21-01					
US 75-04-09 LANDING GEAR ACTUATOR US 76-10-05 LEAKING FUEL US 76-10-05 LEAKING FUEL US 76-10-05 LEAKING FUEL US 78-17-01 US 85-24-03 FUEL TANK BAYS AND RIB STATION INSP  M200 SERIES US 78-24-011 FUEL TANK BAYS AND RIB STATION INSP  M201 SERIES US 78-24-01 FUEL TANK BAYS AND RIB STATION INSP  M202 SERIES US 77-17-04 US 85-24-03 FUEL TANK BAYS AND RIB STATION INSP  M203 FUEL TANK BAYS AND RIB STATION INSP  M204 SERIES US 78-09-08 ENGINE MOUNT MEMBERS US 78-09-08 ENGINE MOUNT MEMBERS US 78-24-01 FUEL TANK BAYS AND RIB STATION INSP  M205 SERIES US 66-07-05 ELECTRIC LANDING GEAR SYSTEMS US 68-22-03 FUEL TANK BAYS AND RIB STATION INSP  M206 M20 SERIES US 66-07-05 ELECTRIC LANDING GEAR SYSTEMS US 67-23-06 ELECTRIC LANDING GEAR US 67-20-06 ELECTRIC LANDING GEAR US 67-20-06 ELECTRIC LANDING GEAR US 73-21-01 FLIGHT CONTROL LANDING GEAR US 73-21-01 FLIGHT CONTROL LANDING GEAR US 77-08-06 ELECTRIC LANDING GEAR US 77-08-06 ELECTRIC LANDING GEAR US 77-08-06 ELECTRIC LANDING GEAR US 77-18-01 ELAKING FUEL US 77-18-01 ENGINE GEAR SYSTEMS US 78-24-01 FLIGHT CONTROL LANDING GEAR SYSTEMS US 78-24-01 FLIGHT CONTROL LANDING GEAR SYSTEMS US 77-08-06 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-08-06 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 77-18-01 ENGINE GEAR ACTUATOR US 78-18-01 ENGINE GEA	US				
US   76-10-05					
US 78-17-01 US 78-17-01 US 78-17-01 US 98-24-03 US 98-24-03 FUEL TANK BAYS AND RIB STATION INSP  M200 M200 M200 M200 M200 M200 M200 M2					
US					
US					
M20D					
M20D				ATLEDON CONTROL LINKS	****
US 66-07-05 US 77-23-06 US 73-21-01 US 75-90-08 US 77-17-04 US 77-17-04 US 77-17-04 US 78-24-03 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-03 US 66-12-03 US 66-12-03 US 66-12-03 US 66-12-03 US 66-12-03 US 66-12-04 US 67-23-06 US 67-23-06 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-01-0-05 US 78-04-09 US 78-10-05 US 78-04-09 US 77-17-04 US 77-18-01 US 78-04-09 US 78-10-05 US 78-04-09 US 78-10-05 US 78-04-09 US 78-10-05 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-04 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 78-04-09 US 7		30.27.11		ATLERON CONTROL LINKS	M20-264
US   67-29-06	M2OD		( M20	SERIES )	
US 67-23-06 US 73-21-01 US 73-21-01 US 75-09-08 US 77-17-04 US 98-24-03 US 98-24-03 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-10 US 75-04-09 US 75-04-09 US 75-04-09 US 77-08-06 US 77-18-01 US 98-24-03 US 88-24-03 US 98-24-11 US 77-18-01 US 98-24-11 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 78-24-01 US 98-24-11 US 77-18-01 US 78-24-01 US 98-24-03 US 98-24-03 US 98-24-03 US 98-24-03 US 98-24-03 US 98-24-03 US 78-17-04 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 77-08-06 US 78-24-07 US 78-24-01 US 78-24-01 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-24-03 US 78-					
US				DUKES FUEL PUMP	
US   87-17-04   CONTROL WHEEL SHAFT   US   85-24-03   FUEL TANK BAYS AND RIB STATION INSP					
US					
M20E					
M20E				ATTERON CONTROL LINKS	
US   65-12-03   SPEED RANGE VIBRATION STRESSES     US   66-07-05   ELECTRIC LANDING GEAR     US   67-23-06   DUKES FUEL PLIMP     US   73-21-01   FLIGHT CONTROL LANDING GEAR SYSTEMS     US   75-04-09   LANDING GEAR ACTUATOR     US   75-09-08   ENGINE MOUNT MEMBERS     US   77-08-06   ENGINE MOUNT MEMBERS     US   77-08-06   ENGINE OIL     US   77-18-01   ENGINE OIL     US   77-18-01   ENGINE OIL     US   85-24-03   FUEL PLIMPS     US   85-24-03   FUEL TANK BAYS AND RIB STATION INSP     US   67-22-07   FLIGHT CONTROL LINKS     US   75-04-09   ENGINE OIL     US   75-04-09   ENGINE MOUNT MEMBERS     US   75-09-08   ENGINE MOUNT MEMBERS     US   75-09-08   ENGINE MOUNT MEMBERS     US   77-18-01   ENGINE OIL     US   77-18-01   ENGINE OIL     US   77-18-01   ENGINE OIL     US   77-18-01   ENGINE OIL     US   78-15-02   MLG STRES     US   85-24-03   FUEL PLIMPS     US   78-24-03   FUEL PLIMPS     US   78-15-04   ENGINE OIL     US   78-15-04   ENGINE OIL     US   78-15-05   EMERGENCY LOCATOR TRANSMITTER     US   78-16-08   FUEL PLIMPS     US   78-24-01   FUEL CAP RETAINING LANYARD     US   78-24-01   FUEL CAP RETAINING LANYARD     US   77-17-04   CONTROL LINKS     US   78-24-01   AILERON CONTROL LINKS     US   78-24-01   AILERON CONTROL LINKS     US   78-24-01   AILERON CONTROL LINKS     US   78-24-01   AILERON CONTROL LINKS     US   78-24-01   AILERON CONTROL LINKS     US   78-24-01   AILERON CONTROL LINKS     US   78-24-01   FUEL CAP RETAINING GEAR SYSTEMS     US   78-24-01   AILERON CONTROL LINKS     US   78-26-08   FUEL TANK BAYS AND RIB STATION INSPECTION     M20-264     M203   M20-264     US   78-17-04   CONTROL LINKS     US   78-18-01   ENGINE OIL COOLER     U				ATELION CONTROL LINKS	M20-264
US 66-07-06 US 73-21-01 US 75-04-09 US 75-09-08 US 75-09-08 US 75-09-08 US 77-08-06 US 77-08-06 US 77-08-06 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 77-18-01 US 80-13-03 US 85-24-03 US 98-24-11 US 77-18-01 US 73-21-01 US 73-21-01 US 77-08-08 US 78-09-08 US 85-24-03 US 98-24-11 US 80-13-03 US 98-24-11 US 80-13-03 US 98-24-11 US 77-18-01 US 77-08-06 US 73-21-01 US 77-08-08 US 73-21-01 US 75-04-09 US 75-04-09 US 75-04-09 US 75-04-09 US 75-04-09 US 75-04-09 US 75-04-09 US 76-04-09 US 76-08-06 US 76-10-05 US 77-08-06 US 77-08-06 US 78-17-01 US 78-17-04 US 78-17-04 US 78-17-04 US 78-24-01 US 78-24-03 US 98-24-11 US 77-18-01 US 78-24-03 US 98-24-11 US 78-17-04 US 78-24-03 US 98-24-11 US 77-17-04 US 78-24-03 US 98-24-11 US 77-17-04 US 77-08-06 US 78-24-03 US 98-24-11 US 77-17-04 US 78-24-03 US 98-24-11 US 77-17-04 US 78-24-03 US 98-24-11 US 77-18-01 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-15-02 US 78-			( M20	SERIES )	
US   67-23-06					
US   73-21-01					
US   75-04-09					
US 75-09-08 US 76-10-05 US 77-08-06 US 77-17-04 US 77-18-01 US 77-18-01 US 77-18-01 US 80-13-03 US 85-24-03 US 98-24-11 US 77-19-04 US 77-17-04 US 77-18-01 US 77-18-01 US 80-13-03 US 85-24-03 US 98-24-11 US 78-04-09 US 78-15-09-08 US 75-09-08 US 75-09-08 US 76-10-05 US 77-18-01 US 77-18-01 US 77-08-06 US 77-18-01 US 77-18-01 US 77-08-06 US 78-15-02 US 78-17-01 US 78-06-04 US 80-13-03 US 85-24-03 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-11 US 98-24-03 US 98-24-11 US 98-24-11 US 98-24-11 US 77-17-06 US 98-24-11 US 77-18-06 US 85-24-03 US 98-24-11 US 77-18-06 US 85-24-03 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 85-24-03 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 85-24-03 US 98-24-11 US 77-18-06 US 85-24-03 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 98-24-11 US 77-18-06 US 78-15-02 US 78-15-02 US 78-17-01 US 78-15-02 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-01 US 78-17-02 US 78-17-01 US 78-17-02 US 78-17-01 US 78-17-02 US 78-17-02 US 78-17-02 US 78-17-02 US				LANDING GEAR ACTUATOR	
US 77-08-06 ENGINE OIL US 77-17-04 US 77-18-01 ENGINE OIL CONTROL WHEEL SHAFT US 80-13-03 FUEL PUMPS US 85-24-03 FUEL TANK BAYS AND RIB STATION INSP  M2OF US 67-22-07 RUDDER ASSEMBLY FLIGHT CONTROL LANDING GEAR SYSTEMS US 75-04-09 LANDING GEAR ACTUATOR US 75-09-08 ENGINE OIL COLER US 77-08-06 ENGINE OIL COLER US 77-08-06 ENGINE OIL COLER US 77-18-01 ENGINE OIL COLER US 78-15-02 MLG SIDE BRACE BOLTS US 80-13-03 FUEL PUMPS US 80-13-03 FUEL LANDING GEAR SYSTEMS US 78-17-01 ENGINE OIL COLER US 78-17-04 CONTROL LANDING GEAR SYSTEMS US 85-24-03 FUEL LANDING GEAR SYSTEMS US 98-24-11 AND STATE OF THE OWN OF THE OWN OF THE OWN OF THE OWN OF THE OWN OWN OWN OWN OWN OWN OWN OWN OWN OWN					
US   77-18-01   ENGINE OIL COOLER	US	76-10-05			
US		77-08-06		ENGINE OIL	
US				CONTROL WHEEL SHAFT	
US					
M2OF					
M20F				ATTERON CONTROL TANKS	
US   67-22-07   RUDDER ASSEMBLY   FLIGHT CONTROL LANDING GEAR SYSTEMS				ATERION CONTROL LINKS	M20-264
US   73-21-01	M2OF		( M20	SERIES )	
US 75-04-09					
US 75-09-08					
US 76-10-05					
US 77-08-06					
US 77-17-04 CONTROL WHEEL SHAFT US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK US 80-13-03 FUEL PUMPS US 97-26-08 FUEL CAP RETAINING LANVARD US 98-24-11 AILERON CONTROL LINKS M20-264  M20G (M20 SERIES ) US 73-21-01 FLIGHT CONTROL LANDING GEAR SYSTEMS US 75-09-08 ENGINE MOUNT MEMBERS US 77-17-04 CONTROL WHEEL SHAFT US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 98-24-11 AILERON CONTROL LINKS M20-264  M20J (M20 SERIES ) US 77-18-01 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 77-08-06 INSTRUMENT CONDITIONS US 77-08-06 ENGINE MUMP MEMBERS US 77-08-06 ENGINE OIL COOLER US 78-15-02 MLG STREE BOLTS US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
US 77-18-01					
US 78-17-01	US				
US 79-06-04 ELEVATOR CONTROL LOCK US 80-13-03 FUEL PUMPS US 85-24-03 FUEL TANK BAYS AND RIB STATION INSP US 97-26-08 FUEL CAP RETAINING LANYARD US 98-24-11 AILERON CONTROL LINKS M20-264  M20G (M20 SERIES ) US 73-21-01 FLIGHT CONTROL LANDING GEAR SYSTEMS US 75-09-08 ENGINE MOUNT MEMBERS US 77-17-04 CONTROL WHEEL SHAFT US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 98-24-11 AILERON CONTROL LINKS M20-264  M20J (M20 SERIES ) US 77-06-01 INSTRUMENT CONDITIONS US 77-08-06 ENGINE OIL US 77-18-01 ENGINE OIL US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
US 80-13-03 FUEL PUMPS US 97-26-08 FUEL TANK BAYS AND RIB STATION INSP US 98-24-11 AILERON CONTROL LINKS M20-264  M20G (M20 SERIES ) US 73-21-01 FLIGHT CONTROL LANDING GEAR SYSTEMS US 75-09-08 ENGINE MOUNT MEMBERS US 77-17-04 CONTROL WHEEL SHAFT US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 98-24-11 AILERON CONTROL LINKS M20-264  M20J (M20 SERIES ) US 77-06-01 INSTRUMENT CONDITIONS US 77-08-06 ENGINE OIL US 77-08-06 ENGINE OIL US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
US 85-24-03					
US 97-26-08 FUEL CAP RETAINING LANYARD  US 98-24-11 AILERON CONTROL LINKS M20-264  M20G  US 73-21-01 FLIGHT CONTROL LANDING GEAR SYSTEMS  US 75-09-08 ENGINE MOUNT MEMBERS US 77-17-04 CONTROL WHEEL SHAFT US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 98-24-11 AILERON CONTROL LINKS M20-264  M20J  US 77-06-01 INSTRUMENT CONDITIONS US 77-08-06 ENGINE DIL US 77-18-01 ENGINE DIL US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
M2OG			F	THE CAR RETAINING LANGES	
M20G					M20-264
US 73-21-01 FLIGHT CONTROL LANDING GEAR SYSTEMS  US 75-09-08 ENGINE MOUNT MEMBERS  US 77-17-04 CONTROL WHEEL SHAFT  US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230  US 98-24-11 AILERON CONTROL LINKS M20-264   M2OJ  US 77-06-01 INSTRUMENT CONDITIONS  US 77-08-06 ENGINE OIL  US 77-18-01 ENGINE OIL COOLER  US 78-15-02 MLG SIDE BRACE BOLTS  US 78-17-01 EMERGENCY LOCATOR TRANSMITTER  US 79-06-04 ELEVATOR CONTROL LOCK					M2U-264
US 75-09-08 ENGINE MOUNT MEMBERS US 77-17-04 CONTROL WHEEL SHAFT US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 98-24-11 AILERON CONTROL LINKS M20-264  M2OJ US 77-06-01 INSTRUMENT CONDITIONS US 77-08-06 ENGINE DIL US 77-18-01 ENGINE DIL US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK	M2OG	70.01.0			
US 77-17-04 CONTROL WHEEL SHAFT US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 98-24-11 AILERON CONTROL LINKS M20-264  M20J (M20 SERIES ) US 77-08-06 INSTRUMENT CONDITIONS US 77-08-06 ENGINE OIL US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK			F	LIGHT CONTROL LANDING GEAR SYSTEMS	
US 85-24-03 FUEL TANK BAYS AND RIB STATION INSPECTION M20-230 US 98-24-11 AILERON CONTROL LINKS M20-264  M2OJ (M2O SERIES ) US 77-06-01 INSTRUMENT CONDITIONS US 77-08-06 ENGINE DIL US 77-18-01 ENGINE DIL US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
US 98-24-11 AILERON CONTROL LINKS M20-230 M20J (M20 SERIES ) US 77-06-01 INSTRUMENT CONDITIONS US 77-08-06 ENGINE DIL US 77-18-01 ENGINE DIL COOLER US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
M2OJ ( M2O SERIES )  US 77-06-01 INSTRUMENT CONDITIONS  US 77-18-06 ENGINE DIL  US 77-18-01 ENGINE DIL COOLER  US 78-15-02 MLG SIDE BRACE BOLTS  US 78-17-01 EMERGENCY LOCATOR TRANSMITTER  US 79-06-04 ELEVATOR CONTROL LOCK			Δ	ALLERON CONTROL LINKS	M20-230 M20-364
US 77-06-01 INSTRUMENT CONDITIONS US 77-08-06 ENGINE OIL US 77-18-01 ENGINE OIL COOLER US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					MZU - 204
US 77-08-06 ENGINE OIL  US 77-18-01 ENGINE OIL COOLER  US 78-15-02 MLG SIDE BRACE BOLTS  US 78-17-01 EMERGENCY LOCATOR TRANSMITTER  US 79-06-04 ELEVATOR CONTROL LOCK	M2OJ	77.00.0			
US 77-18-01 ENGINE OIL COOLER US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
US 78-15-02 MLG SIDE BRACE BOLTS US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
US 78-17-01 EMERGENCY LOCATOR TRANSMITTER US 79-06-04 ELEVATOR CONTROL LOCK					
US 79-06-04 ELEVATOR CONTROL LOCK					
	US .	79-06-04			
	ATDODA	ET /AEDONIES			

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT

US US	JED / SUITE)	( M20 SERIES )	
M2OJ (CONTINU US US	JED / SUITE)	( M20 SERIES )	
(CONTINU US US	JED / SUITE)	( M20 SERIES )	
US US	JED / SOTIE)		
US	80-13-03		
	80-13-03	FUEL PUMPS	
	85-24-03	OIL PRESSURE FITTINGS	
		FUEL TANK BAYS AND RIB STATION INSP	
	88-25-11 92-08-15	BAGGAGE DOOR EXIT MECHANISM	M20-239
	95-26-16R1	RODDER IMBLANCE	M20-252
	97-26-08	ALTERNATE AIR DOOR BOLT COTTER PIN	M20-250B/M20-253A
		FUEL CAP RETAINING LANYARD	
03	90-24-11	AILERON CONTROL LINKS	M20-264
M2OK			
		( M20 SERIES )	
	80-02-12	FUSELAGE TUBULAR STRUCTURE	
	85-24-03	FUEL TANK BAYS AND RIB STATION INSP	
	88-25-11	FUSELAGE TUBULAR STRUCTURE FUEL TANK BAYS AND RIB STATION INSP BAGGAGE DOOR EXIT MECHANISM	M20-239
	95-17-06	CRACKED EXHAUST TRANSITION TUBE	MSB 95-305-1
US	95-18-12	FUEL SELECTOR VALVE	M20-256
US	98-24-11	AILERON CONTROL LINKS	M20-264
M2OM			
		( M20 SERIES )	
US	98-24-11	AILERON CONTROL LINKS	M20-264
MODANE	SAULNIER		
MS880B	DAULNIEK		
	60-007-000	ELEVIDIC TUDOTTI E OCUTA	
	62-007-002	FLEXIBLE THROTTLE CONTROL	6
	62-011-003	FUEL SYSTEM - FLEXIBLE TUBING	9
	63-001-005	LEADING EDGE FLAPS	14
	63-017-007 64-008-008	LEADING EDGE FLAPS	14
FR (	64-008-008	ENGINE COMPARTMENT COOLING	25,30
FR	65-014-009	GLIDER TOWING DEVICE	36
	66-010-010	FUSELAGE - SEALING & PACKING	44
	67-034-013	ENGINE OIL PRESSURE PIPE CONNECTION	49
	68-063	FUEL SHUT-OFF	55
	69-078	BATTERY CABLES	68
	70-017	FUEL LINES	56
	70-018	CARBURETTOR HEAT INDICATOR	57
FR :	70-032	INSTRUMENT GUAGE MARKINGS SHIELDED GROUNDING CABLES	73
FR	70-089	SHIELDED GROUNDING CABLES	79
	72-013	BATTERY RELAY PROTECTION	96
	72-123	FUEL TANK CAPACITY	
	73-067	ENGINE COWLING LATCHES	77R1
	74-005	AILERONS & HINGES	108
	74-053	ELECTRICAL FLAP SELECTOR	111
	75-001	OIL FILLER ACCESS DOOR	116
	78-085(A)	WING SPLICE-PIECES	129
	82-089(A)	CORROSION	133-2
	86-160(A)R1	HORIZONTAL STABLIZER ELECTRIC FUEL PUMP DIAPHRAGM	145/1
	89-105(A)R3	ENGINE INLET FOAM-TYPE AIR-FILTER ELEMENTS	113_R2
	90-229(AB)R2	ENGINE INCE LONG TANDING CEAD	RALLYE 149
	91-163(A)R2	WHEEL AXLE NOSE LANDING GEAR NLG-YOKE PIVOT ASSEMBLY	
	93-143(A)	NOSE LANDING GEAR ATTACHMENT FITTING	SOCATA 151 152-32 REV 1
I'N S	94-182(A)R1	NOSE LANDING GEAR ATTACHMENT FITTING	102-32 REV 1
MS885			
	62-007-002	FLEXIBLE THROTTLE CONTROL	6
	62-007-002 62-011-003	FUEL SYSTEM - FLEXIBLE TUBING	9
	62-011-003 63-001-005	LEADING EDGE FLAPS	14
	63-017-007	LEADING EDGE FLAPS	14 25,30
	64-008-008	ENGINE COMPARIMENT COOLING	36
	65-014-009	GLIDER TOWING DEVICE	44
	66-010-010	FUSELAGE - SEALING & PACKING	49
	67-034-013	ENGINE OIL PRESSURE PIPE CONNECTION	68
	69-078	BATTERY CABLES	56
	70-017	FUEL LINES	73
	70-032	INSTRUMENT GUAGE MARKINGS	13
	72-123	FUEL TANK CAPACITY	77R1
	73-067	ENGINE COWLING LATCHES	
	74-005	AILERONS & HINGES	108
FR 7	78-085(A)	WING SPLICE-PIECES	129
FR 8	36-160(A)R1	HORIZONTAL STABLIZER	145/1
FR 9	90-229(AB)R2	ENGINE INLET FOAM-TYPE AIR-FILTER ELEMENTS	RALLYE 149
	91-163(A)R2	WHEEL AXLE NOSE LANDING GEAR	150/2
	93-143(A)	NLG-YOKE PIVOT ASSEMBLY	SOCATA 151
FR 9	94-182(A)R1	NOSE LANDING GEAR ATTACHMENT FITTING	152-32 REV 1

	ISTRUCTEUR	(APPLIE APPLIE)	
MODEL / N ORIGIN	AD NUMBER	(SERIES / SERIE) SUBJECT	REFERENCE SERVICE BULLETIN
ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
MORANE	SAULNIER		
MS893			
FR	66-015-011	OIL-COOLER - FLEXIBLE TUBING	41
FR	66-021-012	OIL-COOLER FLEXIBLE TUBING	45
FR FR	67-034-013 68-063	ENGINE OIL PRESSURE PIPE CONNECTION	49
FR	70-018	FUEL SHUT-OFF CARBURETTOR HEAT INDICATOR	55 57
FR	70-032	INSTRUMENT GUAGE MARKINGS	73
FR	72-123	FUEL TANK CAPACITY	, 5
FR	73-067	ENGINE COWLING LATCHES	77R1
FR	74-005	AILERONS & HINGES	108
FR	74-053	ELECTRICAL FLAP SELECTOR	111
FR FR	76-062(A) 78-147(A)	OIL RETURN_PIPING CARBURETTOR HEAT FLAP	124 137
FR	78-149(A)	ENGINE MOUNTS	98/3
FR	78-205(A)	ENGINE MOUNTS	30/3
FR	86-160(A)R1	HORIZONTAL STABLIZER	145/1
FR	90-229(AB)R2	ENGINE INLET FOAM-TYPE AIR-FILTER ELEMENTS	RALLYE 149
FR	91-163(A)R2	WHEEL AXLE NOSE LANDING GEAR	150/2
FR	93-143(A)	NLG-YOKE PIVOT ASSEMBLY	SOCATA 151
FR	94-182(A)R1	NOSE LANDING GEAR ATTACHMENT FITTING	152-32 REV 1
MORAVAI	V		
Z142C			
CK	Z142C/02	MIXTURE CONTROL SETTING	Z142C/02
CK	Z142C/03	FUEL DRAIN VALVES	Z142C/3
CK	Z142C/1	AEROBATIC OPERATION LIFE RANGE	Z142C/1
CK CK	Z142C/10A Z142C/11A	STRESS ON PROPELLER FLANGE CAUSED BY SPINS	Z142C/10A
CK	Z142C/11A Z142C/12A	FIRE EXTINGUISHER HOLDER MAINTENANCE MANUAL REVISION	Z142C/11A
CK	Z142C/4A	TRIM CONTROL PULLEY	Z142C/12A Z142C/4A
CK	Z142C/5A	AFM AND MAINT. MANUAL CHANGES	Z142C/5A
CK	Z142C/6A	ALTERNATE STATIC SOURCE	Z142C/6A
CK	Z142C/7A	NOSE WHEEL STRUT INTERFERENCE	Z142C/7A
CK	Z142C/8AR1	AFM AND MAINT. MANUAL CHANGES	Z142C/8A
CK CK	Z142C/9AR1 T-088/1999	RIGGING MEASUREMENTS	Z142C/9A REV1
CK	T-091/1999	OVERLOADING OF WING MAIN SPAR ATTACHMENT FITTINGS LIST OF A/C NOT APPLICABLE TO CAA-AD-T-088/1999	Z142C/14A, Z242L/33A
CK	T-125/1999	AIRFRAME SERVICE LIFE - FLIGHT RESTRICTIONS	Z 42/44A, Z 142/41A, Z 242L/27A
***************************************			
Z242L	7040/4		,
CK	Z242/1	MANUAL MODIFICATIONS	Z242/1
CK CK	Z242L/03 Z242L/10A	ENGINE SPEED INDICATOR	Z242L/03
CK	Z242L/11A	INSP. PANELS AND IDENT. PLATE-SI 1/94 SUPERSEDED NOSE WHEEL STRUT INTERFERENCE	Z242L/10A Z242L/11A
CK	Z242L/12AR1	AIRPLANE FLIGHT MANUAL	Z242L/12AR1
CK	Z242L/13AR1	MAINT MANUAL AMENDMENT - LEVELING/RIGGING	was take / I amily I
CK	Z242L/14A	FLIGHT MANUAL, MAINTENANCE MANUAL CORRECTIONS	
CK	Z242L/15A	CRACKS ON THE EXHAUST MUFFLER FIRST CHAMBER FACES	Z242L/15A
CK	Z242L/16A	FWD C OF G UNDER LIGHT LOAD (FLT MAN. PAGES SENT)	Z242L/16A
CK CK	Z242L/17A Z242L/18A	AUXILIARY TANK CAP	Z242L/17A
CK	Z242L/18A Z242L/2	FIRE EXTINGUISHER HOLDER AEROBATIC OPERATION LIFE LIMITS	Z242L/18A Z242L/2
CK	Z242L/20A	CHANGE TO AIRWORTHY LIMITS- RIVET & BOLT REPLACE	20A
CK	Z242L/21A	ELEVATOR FAIRINGS	21A
CK	Z242L/22A	CONTROLS-COTTER PIN REPLACEMENT	22A
CK	Z242L/4	EXHAUST SYSTEM	Z242L/4
CK	Z242L/5	CONTROLS BUSHING	Z242L/5
CK	Z242L/6 Z242L/7AR1	FUEL DRAIN VALVES MODIFICATIONS TO CANADIAN CONFIGURATION REV 1	Z242L/6
CK	Z242L/8A	PROP GOVERNOR CONTROL ROD	Z242L/7A Z242L/8A
CK	Z242L/9	·· CONTROL TUBE RANGE	Z242L/8A Z242/9
CK	2-029/97	OIL SYSTEM SLUDGE VALVE INCORRECT LOCKING	Z242L/25A
CK	T-088/1999	OVERLOADING OF WING MAIN SPAR ATTACHMENT FITTINGS	
CK	T-125/1999	AIRFRAME SERVICE LIFE - FLIGHT RESTRICTIONS	Z 242L/27A
CK	T-126/1999	AIRFRAME SERVICE LIFE	Z 242L/27A
CK	042/1999	FREEZE-UP OF MAIN ENGINE VENT LINE	Z242L/19A REV.3
MUDRY			
CAP 10			
FR	88-134(A)	RUDDER CONTROL	CAP10B 11
FR	91-112(A)	FUEL SYSTEM	CAP10B 13
FR FR	92-240(A)R1 94-136(A)	MAIN WING SPAR	10B-57-003R1
FR	1999-222(A)R1	WING RIB MODIFICATION SPAR INSPECTION	108-57-004
		O. AIV THOREOTION	990501

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

MAVAL	ACFT FAC		
N3N 3			
		OOUTER AT THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STAT	
03	60-03-06	CONTROL STICK	
NAVION			
	N SERIES		
US	47-11-01	RUDDER-NOSE GEAR STEERING BELLCRANK	
US	47-11-02	HARTZELL PROPELLER BLADE REWORK	
US	47-21-04	FUEL SCUPPER DRAIN LINE	
US	47-21-05	PROPELLER CONTROL FRICTION LOCK	
US	47-21-07	CARBURETOR AIR INTAKE SCOOP FILLER ST IP	
US	47-21-08	GENERATOR TERMINAL STUD INSULATOR	
US	47-21-09	HYDRAULIC SYSTEM MODIFICATIONS	
US	47-21-10	PROPELLER GUIDE PIN DOWEL	
US	47-31-01	HYDRAULIC CYLINDER LINES	
US	47-31-02	CARBURETOR VAPOR RETURN LINE	
US	47-31-03	FUEL DRAIN COCK	
US	48-06-03	HARTZELL DRODGILED DIAGE THIS TOTAL	
US	48-08-03	HARTZELL PROPELLER BLADE INSPECTION	
US		FUEL VALVE CONTROL SUPPORT CLIP	
	48-29-01	FUEL PUMP DRAIN	
US	49-05-03	CONTINENTAL ENGINES BEARING INSERTS	
US	49-09-02	BOOSTER PUMP REWORK	
US	49-11-01	CARTER FUEL PUMP REWORK	
US	49-12-02	ROMEC FUEL PUMP VENT PLUGS	
US	49-28-01	UNSATISFACTORY SPINNER	
US	50-10-02	AIR INTAKE HOSE	
US	51-07-01	THROTTLE HOUSING	
US	52-24-01	AILERON CONTROL CHAIN GUARD	
US	52-26-01	STABILIZER SPAR WEB	
US	53-08-01	HORIZONTAL STABILIZER FITTING	
US	54-18-01	WING-TO-FUSELAGE ATTACHMENT	
US	55-01-01	FUSELAGE FRAME CRACKS	
US	56-03-03		
US		WING REAR SPAR FITTING INSPECTION	
US	59-06-04	HYDRAULIC ACTUATING CYLINDERS	
	63-21-05	MAIN AND NOSE RETRACTION LINKS	
US	68-20-06	RUDDER HORN INSPECTION	
US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
NAVIO	V	( NAVION SERIES )	
	V		
Α		( NAVION SERIES )	
	<b>N</b> 62-03-03		
Α		( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING	
<b>A</b> US	62-03-03	( NAVION SERIES )	
A US US	62-03-03 68-20-06	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION	
A US US	62-03-03 68-20-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING  RUDDER HORN INSPECTION  ENGINE OIL	
A US US US	62-03-03 68-20-06 75-05-02	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )	
A US US US B US	62-03-03 68-20-06 75-05-02	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING	
A US US US B US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION	
A US US US B US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL	
A US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING	
A US US US B US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL	
A US US US B US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE DIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION	
A US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING	
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE DIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION	
A US US B US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE DIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION	
A US US US B US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )	00. Fo. 404
A US US B US US US US US US US US US US C US C	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING  HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS	CC-E2-46A
A US US US US US US US US US US US US CS US CS CF CF	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN	CC~E2~46A
A US US US US US US US US US US US CS US CS CF CF CF	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB	CC-E2-46A
A US US US US US US US US US US US US CS US CS CF CF	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN	CC-E2-46A
A US US US US US US US US US US US CS US CS CF CF CF	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB	CC~E2~46A
A US US B US US US US US US US CS US US CS CF CF CF	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB	CC-E2-46A
A US US B US US US US US US US CS US US CS CF CF CF	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING  HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )	CC-E2-46A
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING  HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING	CC-E2-46A
A US US US US US US US US US CF CF CF NORSEN	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 VN MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06	( NAVION SERIES )  LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES )  CARBURETOR DUCTING  HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )	CC-E2-46A
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK IV	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )	CC-E2-46A
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK IV	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )	CC-E2-46A
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 WAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK IV MAN MK VI 46-23-05	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )  HORIZONTAL STAB	CC-E2-46A
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 VA MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK V MAN MK V MAN MK V MAN MK VI	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )  HORIZONTAL STAB FULE BURNING HEATER	
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 WAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK IV MAN MK VI 46-23-05	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )  HORIZONTAL STAB	CC-E2-46A
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK IV MAN MK V MAN MK V MAN MK V MAN MK V MAN MK V	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )  HORIZONTAL STAB FULE BURNING HEATER	
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 VN MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK V MAN MK V MAN MK V MAN MK VI	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )  HORIZONTAL STAB FULE BURNING HEATER EDO FLOATS	
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 (N MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK V MAN MK V	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )  HORIZONTAL STAB FULE BURNING HEATER EDO FLOATS  GROSS WEIGHT FLOATS INSTALLED	E5/44
A US US US US US US US US US US US US US	62-03-03 68-20-06 75-05-02 52-08-02 53-03-01 56-27-04 62-03-03 68-20-06 VN MAN SERIES CF-48-01 CF-50-07 CF-58-06 CF-63-06 MAN MK V MAN MK V MAN MK V MAN MK VI	( NAVION SERIES ) LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION ENGINE OIL  ( NAVION SERIES ) CARBURETOR DUCTING HARTZELL PROPELLER VIBRATION ENGINE COOLING KIT REMOVAL LANDING GEAR SELECTOR VALVE FITTING RUDDER HORN INSPECTION  ( NAVION SERIES )  AUX BELLY FUEL TANKS AUXILIARY FIN MAINPLANE LEADING EDGE RIB WING LIFT STRUT EYEBOLT FITTING  ( NORSEMAN SERIES )  ( NORSEMAN SERIES )  HORIZONTAL STAB FULE BURNING HEATER EDO FLOATS	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUBJECT
SUBJECT
SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
NORTH	AMERICAN		
HARVA		SEE/VOIR: HARVARD	
SNJ5			
ATCC			
AT6C US	46-11-01	LANDING GEAR RETRACTING STRUT	
US	46-17-01	FLAP CONTROL UNIVERSAL JOINT PINS	
US US	46-46-02 49-07-02	ELEVATOR STOP FUEL SYSTEM PLACARD	
US	50-09-01	STABILIZER SPAR FITTINGS AND SHIMS	
US	50-38-01	FUSELAGE STRUCTURE CORROSION	
T6G			
US	81-14-10	HORIZONTAL STABILIZER SPAR	
B25J			
T28A			
US	58-22-02	LANDING GEAR TRUNNION SHAFT	
US	61-05-05	WRIGHT R-1300-1A ENGINES	
PARTEN	AV I A		
P68 SI	ERIES		
IT IT	83-54/P.68-28 84-129/P.68-31	STABILATOR TORQUE TUBE BRACKET STABILATOR TRAVEL STOP	57 63R1
ÎT	84-146/P.68-32	AILERON CONTROL CHAIN	64R1
IT	85-128/P.68-33R2	WINGSPARS	65R3
IT IT	85-32/P.68-27R2 86-22/P.68-35	FLAP BELLCRANK BRACKETS BRAKE OIL LINE	56 68
ΙT	88-167/P.68-37	STABILATOR TRIM TAB	73R1
IT IT	89-71/P.68-39	ENGINE MOUNT BOLTS	76R1
IT	89-72/P.68-36R3 90-262/P.68-40	ENGINE MOUNT - WING ATTACHMENT ENGINE AND PROP CONTROL CABLES	70R2 81
ΙT	91-125/P.68-42	MUFFLER ASSEMBLY	83
IT IT	91-272/P.68-44 92-155	STABILTOR STABILATOR TORQUE TUBE	85 87R1
ΪŤ	94-014	FUEL SELECTOR CONTROL - KEY INSTALLATION	90
ΙŢ	94-026	CORROSION-STABILATOR TORQUE TUBE ATTACH SLEEVES	91
IT IT	94-027 94-028	ENGINE OIL COOLER HOSES ENGINE ALTERNATE AIR	88 25R1
IT	95-076	CONTROL WHEEL ROD UNIVERSAL JOINTS	48 R1
IT IT	95-335 96-032	FUEL LINES INSTALLATION OF INSPECTION DOORS IN MID WING BOX	61R3 93
ĪŤ	96-337	FLIGHT CONTROL CABLES	75R1 & 75R3 95, 56
IT	98-111	ICING CONDITIONS	
ΙT	98-226	WING AND STABILATOR - LIMIT OF FATIGUE LIFE	
		8 SERIES )	
IT IT	81-100/P.68-23 91-124/P.68-30R3	MAGNETO GROUND WIRE ENGINE & JANITROL FUEL LINES	51 61
ΪŤ	94-053	INSTRUMENT PANEL	89
P68C	( ps:	8 SERIES )	
IT	81-100/P.68-23	MAGNETO GROUND WIRE	51
IT	81-129/P.68-24	ALTERNATOR OUTPUT CABLE	49
IT IT	83-26/P.68-15R3 87-36/P.68-34R1	FLAP ACTUATOR SWITCH FIBERGLASS WING LEADING EDGES	55R1 67R1
IT	91-124/P.68-30R3	ENGINE & JANITROL FUEL LINES	61
IT	91-243/P.68-43	FUSELAGE FRAME # 1	84
PETERSO J4	?N		
PIAGGIO P136L1			
ΙŢ	59-2/P.136-8R1	PONTOON RUDDER - LOCKING DEVICE	
IT IT	60-70/P.136-14 61-25/P.136-15	FUEL BREATHER INSTALLATION MAIN UNDERCARRIAGE RETRACTION RAM	
ΙT	61-32/P.136-16	PONTOON RUDDER CONTROL CABLE	136-5
IT IT	61-84/P.136-7 64-66/P.136-20R1	ELEVATOR - SEMI-BALANCE CORRECTING TAB	420.0
IT	64-69/P.136-20R1	PLACARD - HYDRAULIC PRESSURE MLG JACK LOCK	136-8 136-9

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

		BULLETIN DE SERVICE DE REF.
0		
	MAIN LANDING GEAR DOOR SYSTEM	ASB 80-0016
	THE SOURCE DOCKTILAD GROWING	80-0017
	MLG PINTLE PIN	80-0025
	WING CENTRAL TRAILING EDGE	80-0015
92-166	MLG DOORS AND HINGES	80-0020
92-178	EMERGENCY PRESSURIZATION DUCT	80-0020
	WING CENTRAL TRAILING EDGE	80-0021
92-2	ANTI-ICE SYSTEM	80-0015 80-0005R3
93-054	WATER ACCUMULATION IN LOWER COMPARTMENTS	ASB-80-0035
93-302	EMERGENCY EXIT DOOR - CHECK/MODIFICATION	80-0043
93-312	SEALING OF VERTICAL STAB TIP FAIRING	80-0043
93-320	FUEL QUANTITY INDICATION SYSTEM	80~0042
93-369	HARTZELL PROPELLER MODEL HC-ESN - BLADE CORROSTON	80/H75-0001P2
94-002	DOOR SEAL REGULATING VALVE HEATING SYSTEM	80-0028R1
94-097	HYDRAULIC BRAKE SYSTEM	80-002881
94-114	WING/AILERONS	80-0060
94-119		80-0055
94-142		80-0031
95-027	MLG DRAG BRACE UPPER LINK	80-0064
95-059	MODIFICATION OF FUSELAGE FMERG EXIT DOOR FRAMES	80-0057
95-060	FORWARD WING LEADING FDGF	
95-087	WATER PROTECTION - ENGINE AND PROPELLED CONTROLS	80-0071
95-183	RUDDER TOROUF THRE FLANGE INSPECTION	80-0066 SR-80-0076
		SB-80-0076
	FREON AIR INLET DUCT/WIRING INTERFERENCE	80-0084
	FLAP DRIVE UNIT	80-00083
		80-0093 5B-80-0080
	DEEVENT JAMMING OF DUDDED CARLES	
		80-0096 SB 80 0004
		SB-80-0081
		SB-80-0082
	PPOP IOW PITCH STOP SWITCH SUPPORT	80-0094
	BUCKMELL COLLING V/D DISENCYCEMENT DOCCEDADA	80-0080
	AEM AMMENDMENT - POWED LEVERS	ASB-80-0100
		FAA AD 97-22-11
		80-0101
		80-0072R1 80-0107
)		
)/285		
1999-053(A)R1	ENGINE AIR INTAKE BOXES	161
78-075(A)	E! ADS	75
		77
		90
		97
		101R3
		109
		112
		114R1
		120
		135
		137
		139
	RUDDER BAR DISTORTION	143
1996-051(A)R3	WING ATTACHMENTS	145R2
96-276(A)R1	TYPE TRANSFORMATION	153
1999-053(A)R1	ENGINE AIR INTAKE BOXES	161
1999-115(A)	STALL SPEEDS	155R1
86-041	AIRBRAKE	
AF		
<b>2</b> 99-507	HORIZONTAL TRIM TAB ACTUATOR INSPECTION	178
	AVANTI T91-32 91-433 92-121 92-130 92-166 92-178 92-179 92-2 93-054 93-302 93-312 93-320 93-369 94-002 94-097 94-114 94-119 94-142 95-027 95-069 95-060 95-087 95-183 95-224 96-148 96-158 97-022 97-148 97-149 97-193 97-217 97-290 98-126 98-329 99-219  AROBIN 1/285 1999-053(A)R1  78-075(A) 80-005(A) 80-186(A) 82-070(A) 83-09(A) 83-206(A)R3 86-148(A)R1 89-072(A) 83-09(A) 8	MANNTI 191-32 194-333 191-4333 192-130 194-333 192-130 292-121 MLG PINTLE PIN 192-130 192-130 MING CENTRAL TRAILING EDGE 192-178 192-166 MLG DOORS AND HINGES 192-178 193-166 MLG DOORS AND HINGES 192-179 WING CENTRAL TRAILING EDGE 192-179 WING CENTRAL TRAILING EDGE 192-179 WING CENTRAL TRAILING EDGE 192-179 WING CENTRAL TRAILING EDGE 193-1054 ANTI-ICE SYSTEM 193-30-504 ANTI-ICE SYSTEM 193-312 SERREGENCY EXIT DOOR - CHECK/MODIFICATION 193-312 SERREGENCY EXIT DOOR - CHECK/MODIFICATION 193-312 SERREGENCY EXIT DOOR - CHECK/MODIFICATION 193-312 SERREGENCY EXIT DOOR - CHECK/MODIFICATION 193-369 HARTZELL PROPELLER MODEL HG-ESD 193-369 HARTZELL PROPELLER MODEL HG-ESD 194-097 HYDRAULIC BRAKE SYSTEM 194-119 FMS AND AUTOPILOT 194-119 FMS AND AUTOPILOT 195-027 MLG DRAG BRACE UPPER LINK 195-027 MLG DRAG BRACE UPPER LINK 195-027 MLG DRAG BRACE UPPER LINK 195-065 MODIFICATION OF WING-LAGE AREA EXIT DOOR FRAMES 195-060 FORWARD WING LEADING EDGE 195-060 FORWARD WING LEADING EDGE 196-148 FOR MODIFICATION OF WING LAGE HERD EXIDED 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 196-148 FLAP DRIVE UNIT DUCT/WIRING INTERFERENCE 197-149 CABIN UPPER ENTRY DOOR PIN GUIDE REPLACEMENT 197-149 CRAIN UPPER ENTRY DOOR PIN GUIDE REPLACEMENT 197-149 CRAIN UPPER ENTRY DOOR PIN GUIDE REPLACEMENT 197-149 REAR PRESSURIZED BULKHEAD 197-149 REAR PRESSURIZED BULKHEAD 197-149 REAR PRESSURIZED BULKHEAD 197-149 REAR PRESSURIZED BULKHEAD 197-149 REAR PRESSURIZED BULKHEAD 197-149 REAR PRESSURIZED BULKHEAD 197-149 REAR PRESSURIZED BULKHEAD 199-051(A) ROBER BARS 190-024 ROBIN 199-053(A) ROBER BARS 190-024 ROBIN 199-054 ROBIN 199-055 ROBIN 199-055 ROBIN 199-055 ROBIN 199-055 ROBIN 199-056 ROBIN 199-056 ROBIN 199-057 ROBIN 199-057 ROBIN 199-057 ROBIN 199-057 ROBIN 199-0

MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE) ORIGIN AD NUMBER
ORIGINE NUMBER OF CONSIGNE SUBJECT REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. PILATUS PC6 B1H2 SW 83-017 AILERON, ELEVATOR & RUDDER GUST LOCKS 137
LANDING FLAP MOUNTING BRACKET 139 SW 84-005 LANDING FLAP MOUNTING BRACKET
LANDING GEAR - TAIL WHEEL GUARD
AILERON / FLAP MOUNT ATTACHMENT BRACKETS
FLAPS - FLECTRICAL ACTUATOR MOUNTING BRAC SW 84-007 141R1 SW 84-023 13882 FLAPS - ELECTRICAL ACTUATOR MOUNTING BRACKET 84-030 140R1 FLAPS - ELECTRICAL ACTUATOR MOUNTING BRACKET 140

VERTICAL STABILIZER - CAP ANGLES/GUSSET PLATES 142

HORIZONTAL STABILIZER - CAP ANGLES/GUSSET PLATES 143

HORIZONTAL STABILIZER - INSPECTION FOR CARCASTA 84-180 SW 84-181 SW SW 84-182 HORIZONTAL STABILIZER - INSPECTION FOR CRACKS 144 86-042 SW TRIM ACTUATOR BRACKET RUDDER PEDAL SUPPORTS / TORQUE TUBE 89-301 SW A-162 95-451 COLLECTOR TANK VENTING SYSTEM 171 99-507 SW HORIZONTAL TRIM TAB ACTUATOR INSPECTION 178 PC6 350H2 AILERON, ELEVATOR & RUDDER GUST LOCKS
LANDING FLAP MOUNTING BRACKET SW 83-017 137 SW 84-005 139 LANDING GEAR - TAIL WHEEL GUARD
AILERON / FLAP MOUNT ATTACHMENT BRACKETS
FLAPS - ELECTRICAL ACTUATOR MOUNTING BRACKET 84-007 141R1 SW 84-023 138R2 SW 84-030 140R1 SW 84-180 VERTICAL STABILIZER - CAP ANGLES/GUSSET PLATES 142 HORIZONTAL STABILIZER - CAP ANGLES/GUSSET PLATES
HORIZONTAL STABILIZER - INSPECTION FOR CRACKS
TRIM ACTUATOR BRACKET 84-181 SW 143 84-182 SW 144 SW 86-042 SW 95-451 COLLECTOR TANK VENTING SYSTEM HORIZONTAL TRIM TAB ACTUATOR INSPECTION SW 99-507 178 PC 12 SERIES SW 96-139 HYDRAULIC HANDPUMP INSTALLATION 29-001 SW 96-416 PROPELLER DE-ICING CONTROLLER 30-002 SW 96-535A ELEVATOR MAGNETIC COMPASS DEVIATION ELEVATOR 55-001 SW 97-001 24-002 ELEVATOR SW 97-002 24-003R1 AILERON TIE-ROD ASSEMBLY 27-001

RETROFIT CABIN LAYOUT - HEAD INJURY CRITERIA 25-003

VENT VALVE SYSTEM 28-005

CORPORATE COMMUTER CABIN LAYOUT 25-006 SW 97-174 SW 97-249A 25-003 REV1 SW 98-126 SW 98-179 98-352 ALTERNATE FLAP SYSTEM SW 27-004 STANDBY MAGNETIC COMPASS SWING SW 98-426 98-426 STANDBY MAGNET 98-460 FLAP ACTUATORS 34-006 SW 27-005 98-537 SW CUT-OUT RELAY 24-009 SW 99-142 LIMITED SERVICE - FLAP SCREW ACTUATORS
GENERATOR 2 EXITATION - MODIFICATION 27-007 99-143 SW 24-012 SW 99-241 FLAP DRIVE SHAFTS 27-003 SW 99-348 WINDSHIELD WIRING MOD. 30-005 FLAP INBOARD ATTACHMENT FITTINGS - MODIFICATION 57-004 SW 99-353 STICK PUSHER SYSTEM- REPLACE CAPSTAN AND SERVO GENERATOR 2 SUPPRESSION FILTER SW 99-406 22-003 SW 99-542 24-014 POWERPLANT PIPE ASSEMBLIES, INSPECTION/ADJUSTMENT 71-004 WINDSHIELD HEATER OPERATION, POH/AFM TEMP. REV. AFM TEMP REV NO 14 SW 2000-007 SW 2000-008 PC 12 45 ( PC 12 SERIES ) PIPER 112 WING STRUT CORROSION-CRACKED FORKS US 99-01-05 528D, 910A US 99-26-19 WING STRUT CORROSION OR DENTS - CRACKED FORKS 13 CF CF-58-09 CARBURETTOR HEAT CONTROL 47-50-03 US CANVAS SEAT INSPECTION 49-14-01 ELEVATOR CONNECTOR TUBE FITTING 52-07-03 LIFT STRUT REWORK
58-01-07 CONTROL SYSTEM TURNBUCKLES
58-12-02 AILERON HINGE BRACKETS
68-05-01 FXHAUST MUFFLERS US US 68-05-01 US EXHAUST MUFFLERS US 78-10-03 FUEL VENTING 85-06-04 US FUEL TANK US 99-01-05 WING STRUT CORROSION-CRACKED FORKS 528D,910A J3C SERIES 47-50-03 US CANVAS SEAT INSPECTION US 49-14-01 ELEVATOR CONNECTOR TUBE FITTING US . 50-05-01 NICOPRESS SLEEVE REWORK

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT SUJET

URIGIN	NE NOMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
	SERIES		
US	INUED / SUITE) 52-07-03		
US	58-01-07	LIFT STRUT REWORK CONTROL SYSTEM TURNBUCKLES	
US	58-12-02	AILERON HINGE BRACKETS	
US	68-05-01	EXHAUST MUFFLERS	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
13C		( J3C SERIES )	
J3C5		( J3C SERIES )	
J3C6		( J3C SERIES )	
US	46-37-01 46-37-02	FUEL STRAINER GASKET	
US	47-50-06	FUEL STRAINER POSITION SHOCK STRUT CRACKS	
		SHOOK STROT CRACKS	
J3C65		( J3C SERIES )	
US US	46-37-01	FUEL STRAINER GASKET	
US	46-37-02 47-50-06	FUEL STRAINER POSITION SHOCK STRUT CRACKS	
	47 00 00	SHOCK STRUT CRACKS	
	SERIES		
US	47-50-03	CANVAS SEAT INSPECTION	
US US	49-14-01 52-07-03	ELEVATOR CONNECTOR TUBE FITTING	
US	58-01-07	LIFT STRUT REWORK  CONTROL SYSTEM TURNBUCKLES	
US	58-12-02	AILERON HINGE BRACKETS	
US	68-05-01	EXHAUST MUFFLERS	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
J3F50		( J3F SERIES )	
J3F60	)	( J3F SERIES )	
J3F65	5	( J3F SERIES )	
J3L S	SERIES		
US	47-50-03	CANVAS SEAT INSPECTION	
US	49-14-01	ELEVATOR CONNECTOR TUBE FITTING	
US	52-07-03	LIFT STRUT REWORK	
US US	58-01-07 58-12-02	CONTROL SYSTEM TURNBUCKLES AILERON HINGE BRACKETS	
US	68-05-01	EXHAUST MUFFLERS	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
101.05			
J3L65		( J3L SERIES )	
J4 SE	RIES		
US	78-10-03	FUEL VENTING	522
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
J4A		( J4 SERIES )	
US	68-05-01	EXHAUST MUFFLERS	
J4E	00.05.1	( J4 SERIES )	
US	68-05-01	EXHAUST MUFFLERS	
L4B			
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
	RIES		
J5 SE	RIES	CONTROL SYSTEM TURNBUCKLES	
US US	58-01-07 68-05-01	EXHAUST MUFFLERS	
US	78-10-03	FUEL VENTING	522
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
J5A		( J5 SERIES )	
J5C		( J5 SERIES )	
030		( 00 JERIES )	

MAKE / CON. MODEL / M ORIGIN ORIGINE	STRUCTEUR FODELE AD NUMBER NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
PIPER			
PA11			
US	47-50-06	SHOCK STRUT CRACKS	
US	48-03-03	HEADER TANK INSTALLATION	
US US	49-14-01	ELEVATOR CONNECTOR TUBE FITTING	
US	50-05-01 52-07-03	NICOPRESS SLEEVE REWORK LIFT STRUT REWORK	
US	58-12-02	AILERON HINGE BRACKETS	
US	68-05-01	EXHAUST MUFFLERS	
US	78-10-03	FUEL VENTING	522
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
PA11S			
US	52-07-03	LIFT STRUT REWORK	
US	58-12-02	AILERON HINGE BRACKETS	
US US	68-05-01 78-10-03	EXHAUST MUFFLERS FUEL VENTING	
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
2440 6	PRICE		
PA12 S	78-10-03	FUEL VENTING	522
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	522 528D,910A
DA12			
PA12 US	46-36-02	( PA12 SERIES ) AIRSCOOP REWORK	
UŞ	46-36-03	MUFFLER BRACE	
US	46-37-01	FUEL STRAINER GASKET	
US	47-22-03	LANDING GEAR TIE STRAP	
US	47-47-01	LANDING GEAR REINFORCEMENT	
US	47-47-02	BATTERY BOX INSULATING SPACER	
US US	47-47-04	STARTER SOLENOID REPLACEMENT	
US	48-01-02 48-13-03	COWL SUPPORT BRACES BATTERY HOLD DOWN BRACKETS	
US	48-13-04	FUSE-CLIP ATTACHMENT	
US	48-14-01	FUEL LINE ELBOW	
US	49-14-01	ELEVATOR CONNECTOR TUBE FITTING	
US	49-27-02	AILERON BELLCRANK CASTINGS	
US	50-05-01	NICOPRESS SLEEVE REWORK	
US US	51-21-02 60-01-07	AILERON HINGE BRACKETS	
US	68-05-01	TAIL BRACE WIRES EXHAUST MUFFLERS	
US	74-17-04	FABRIC REINFORCEMENT	
US	76-06-06	PA-14 WING FLAPS	
US	85-06-04	FUEL TANK	
PA12S		( PA12 SERIES )	
US	46-37-01	FUEL STRAINER GASKET	
US	47-47-03	SEAPLANE FUSELAGE INSPECTION	
US	49-14-01	ELEVATOR CONNECTOR TUBE FITTING	
US US	50-05-01 51-21-02	NICOPRESS SLEEVE REWORK	
US	60-01-07	AILERON HINGE BRACKETS TAIL BRACE WIRES	
US	68-05-01	EXHAUST MUFFLERS	
US	74-17-04	FABRIC REINFORCEMENT	
US	76-06-06	PA-14 WING FLAPS	
US	85-06-04	FUEL TANK	
PA14	***************************************		
US	49-27-02	AILERON BELLCRANK CASTINGS	
US	60-01-07	TAIL BRACE WIRES	
US US	68-05-01	EXHAUST MUFFLERS	
US	74-17-04 78-10-03	FABRIC REINFORCEMENT FUEL VENTING	
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
PA15			
US	50-23-01	SHOCK STRUT FITTINGS	
US	58-12-02	AILERON HINGE BRACKETS	
US	68-05-01	EXHAUST MUFFLERS	
US	74-17-04	FABRIC REINFORCEMENT	
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A

MAKE / CO	NSTRUCTEUR MODELE	(SERIES / SERIE)	
ORIGINE ORIGINE	AD NUMBER	SUBJECT	REFERENCE SERVICE BULLETIN
01050			BULLETIN DE SERVICE DE REF.
PIPER PA16			
CF	CF-58-07	OPEN BUS BAR	1
US	51-23-03 57-22-01	BATTERY BOX INSULATION	
US US	58-12-02	FIRE PREVENTION REWORK	
US	68-05-01	AILERON HINGE BRACKETSEXHAUST MUFFLERS	
US	74-17-04	FABRIC REINFORCEMENT	
US	78-10-03	FUEL VENTING	522
US	85-06-04	FUEL TANK	522
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
PA16S CF		00511 0110 011	
US	CF-58-07 57-22-01	OPEN BUS BAR	1
US	58-12-02	FIRE PREVENTION REWORK AILERON HINGE BRACKETS	
US	68-05-01	EXHAUST MUFFLERS	
US	74-17-04	FABRIC REINFORCEMENT	
US	78-10-03	FUEL VENTING	
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
PA17			
US	50-23-01	SHOCK STRUT FITTINGS	
US	58-12-02	AILERON HINGE BRACKETS	
US	68-05-01	EXHAUST MUFFLERS	
US	74-17-04	FABRIC REINFORCEMENT	
US US	85-06-04 99-01-05	FUEL TANK	
		WING STRUT CORROSION-CRACKED FORKS	528D,910A
	SERIES		
US US	53-04-01 60-10-08	CONTROL STICK ATTACHMENT	
US	62-02-05	FUEL SELECTOR VALVE RUDDER CABLE ATTACHMENT LUG	
US	68-05-01	EXHAUST MUFFLERS	
US	78-10-03	FUEL VENTING	
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
PA18		( PA18 SERIES )	
US	51-19-02	OIL RADIATOR HOSE	
US	53-24-04	FUEL-HYDRAULIC LINES	
US US	59-10-08	GAS TANK CAP VENT	
US	72-01-07	FAILURE OF ENGINE MOUNT	
PA18	105	( PA18 SERIES )	
US	72-01-07	FAILURE OF ENGINE MOUNT	
PA18 1	125	( PA18 SERIES )	
US	72-01-07	FAILURE OF ENGINE MOUNT	
PA18 1	135	( PA18 SERIES )	
US	72-01-07	FAILURE OF ENGINE MOUNT	
DA40	150	( DA40 SERVES )	
PA18 1	61-16-05	( PA18 SERIES )  CONTROL CABLE REPLACEMENT	
US	69-23-03	LOWER LONGERON INSPECTION	
US	81-06-08	LOWER FUSELAGE ATTACHMENT TAB	
PA18A		( PA18 SERIES )	
US	54-19-01	BRAKE LINE COVER PLATE	
US	59-10-08	GAS TANK CAP VENT	
US	62-02-05	RUDDER CABLE ATTACHMENT LUG	
US	72-01-07	FAILURE OF ENGINE MOUNT	
US	85-06-04	FUEL TANK	
PA18A	135	( PA18 SERIES )	
US	61-16-05	CONTROL CABLE REPLACEMENT	
US	72-01-07	FAILURE OF ENGINE MOUNT	
PA18A	150	( PA18 SERIES )	
US	61-16-05	CONTROL CABLE REPLACEMENT	
PA18AS	150	( PA18 SERIES )	
US	61-16-05	CONTROL CABLE REPLACEMENT	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER SUBJECT
NUMBERO DE CONSIGNE SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
PIPER		(	
PA18S		( PA18 SERIES )	
PA18S	105	( PA18 SERIES )	
1 4 103	103	( TATO SERIES )	
PA18S	135	( PA18 SERIES )	
		, , , , , , , , , , , , , , , , , , , ,	
PA18S	150	( PA18 SERIES )	***************************************
US	61-16-05	CONTROL CABLE REPLACEMENT	
	SERIES	ODEN, DUC. DAG	· · · · · · · · · · · · · · · · · · ·
CF US	CF-58-07 57-22-01	OPEN BUS BAR FIRE PREVENTION REWORK	1
US	60-01-07	TAIL BRACE WIRES	
US	60-10-08	FUEL SELECTOR VALVE	
ÜS	68-05-01	EXHAUST MUFFLERS	
US	72-21-03	FUEL LINE FAILURE	
US	74-17-04	FABRIC REINFORCEMENT	
US	78-10-03	FUEL VENTING	
US	85-02-05R1	BRAKE OPERATIONS	
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
PA20		( PA20 SERIES )	
US	51-19-02	OIL RADIATOR HOSE	
US	51-23-03	BATTERY BOX INSULLATION	
US	53-24-04	FUEL-HYDRAULIC LINES	
US	58-16-01	CIGAR LIGHTER FUSE	
US	59-10-08	GAS TANK CAP VENT	
		/ >	
PA20 1	15	( PA20 SERIES )	
PA20 1	25	( PA20 SERIES )	
FAZU I	33	( PAZU SERIES )	
PA20 1	50	( PA20 SERIES )	
	-A-F		
PA20S		( PA20 SERIES )	
PA205	135	( PA20 SERIES )	
PA22 S	EDIEC		
CF CF	CF-58-07	OPEN BUS BAR	1
US	51-27-03	NOSE WHEEL DRAIN	1
US	55-07-02	LANDING GEAR TUBE REINFORCEMENT	***************************************
US	55-08-04	IGNITION FILTER REPLACEMENT	
US	55-22-03	FUEL TANK CAP	
US	57-22-01	FIRE PREVENTION REWORK	
US	58-16-01	CIGAR LIGHTER FUSE	
US US	60-01-07	TAIL BRACE WIRES	
US	60-10-08 67-24-02	FUEL SELECTOR VALVE	
US	68-05-01	ENGINE FUEL STARVATION  EXHAUST MUFFLERS	
us	72-21-03	FUEL LINE FAILURE	
US	74-17-04	FABRIC REINFORCEMENT	
US	78-10-03	FUEL VENTING	
US	85-02-05R1	BRAKE OPERATIONS	
US	85-06-04	FUEL TANK	
US	99-01-05	WING STRUT CORROSION-CRACKED FORKS	528D,910A
PA22	***************************************	( PA22 SERIES )	***************************************
US	51-19-02	OIL RADIATOR HOSE	
US	51-23-03	BATTERY BOX INSULLATION	
US	53-24-04	FUEL-HYDRAULIC LINES	
US	59-10-08	GAS TANK CAP VENT	
US	64-05-04	UPPER MAIN OLEO BEARINGS	
US	73-09-06	THROTTLE HANGUP	
PA22 1	08	( PA22 SERIES )	
US	64-05-04	UPPER MAIN OLEO BEARINGS	
		C. TER MAIN DELO DEARTINGS	
PA22 1	35	( PA22 SERIES )	
US	64-05-04	UPPER MAIN OLEO BEARINGS	
DAGG	F.0	1	
PA22 1		( PA22 SERIES )	
US	60-05-03	SAFETY BELT	
	AET / AEDONEEC		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

	NOWENO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
PIPER	0		
	2 150	( DAGO CEDETE )	
	INUED / SUITE)	( PA22 SERIES )	
US		CONTROL CARLE SERVICES	
US	64-05-04	CONTROL CABLE REPLACEMENT UPPER MAIN OLEO BEARINGS	
US	73-09-06	THROTTLE HANGUP	
		THINGO!	
	2 160	( PA22 SERIES )	
US	60-05-03	SAFETY BELT	
US	61-16-05	CONTROL CABLE REPLACEMENT	
US	64-05-04	UPPER MAIN OLEO BEARINGS	
US	73-09-06	THROTTLE HANGUP	
PA22	5	(	
PAZZ	:5	( PA22 SERIES )	
DAGG	S 150	( Dicc crowns )	
US	61-16-05	( PA22 SERIES )	
US	73-09-06	CONTROL CABLE REPLACEMENT	
	75 03 00	THROTTLE HANGUP	
PA22	S 160	( PA22 SERIES )	
US	61-16-05	CONTROL CABLE REPLACEMENT	
US	73-09-06	THROTTLE HANGUP	
		THE PROOF	
PA23	SERIES		
US	55-21-02	FRONT WING SPAR ATTACHMENT FITTING	
US	57-21-01	RUDDER TRIM TAB PIN	
US	58-22-03	GOODRICH G-3-787 WHEEL	
US	63-07-03	RUDDER TRIM TABS	
US	63-24-03	RUDDER TRIM TAB CONTROL ROD ASSY	
US	71-18-03	LEFT NOSE WHEEL DOOR HINGE	
US	79-11-06	LANDING GEAR SELECTOR LEVER	
US	88-21-07R1	FUEL - VENT LINES, CAPS & CELLS	340
US	96-21-04	HYDRAULIC HOSES (SUPERSEDES 86-17-07	822
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
PA23		2400 000000	
CF	CE-EC-10	( PA23 SERIES )	
US	CF-56-10	GENERATOR & STARTER ATTACHMENT BRACKETS	
US	55-11-02 55-13-01	THERMAL RELIEF VALVES	
US	55-14-02	IDLER BELLCRANK INSTALLATION	
US	56-27-03	HYDRAULIC CYLINDER REPLACEMENT	
US	57-01-02	AILERON BALANCE WEIGHT BRACKETS STABILIZER ATTACHMENT BOLTS	
US	57-05-03	ELEVATOR PUSH-PULL TUBE	
US	57-10-02	OIL PRESSURE GAGE LINE	
US	57-13-08	ANTI-RETRACTION DEVICE	
US	57-19-01	ELEVATOR ROD END BEARING	
US	58-01-06	STABILIZER FITTING	
US	58-04-03	RUDDER TRIM TAB ADJUSTMENT SCREW	
US	59-08-03	OPERATING LIMITATIONS PLACARD	
US	60-03-07	ENGINE STARTER SOLENOID	
US	60-03-08	FUEL CONTROL CABLE AND WIRE	
US	63-12-02	ELEVATOR RIB CRACKS	
US	63-26-03	TAIL AREA INSPECTION	
US	69-13-03	HEATER EXHAUST TUBE	
US	71-12-01	ENGINE CONTROL SUPPORT BRACKET	
US	74-22-05	FULL VALVE STEM AND CAP NUT	
US	78-08-03	HINGE BRACKET ASSEMBLY	
US	80-18-10	FUEL SELECTOR VALVES	
US	80-26-04R1	RUDDER CABLE PULLEY AT CABIN STEP	672
US	81-04-05R1	FLAP-SPAR HINGE ATTACHMENT	
US	85-02-05R1	BRAKE OPERATIONS	
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
PA23	160	( PA23 SERIES )	
US	60-03-08	FUEL CONTROL CABLE AND WIRE	
US	63-07-03	RUDDER TRIM TABS	
US	63-24-03	RUDDER TRIM TABS	
US	63-26-03	TAIL AREA INSPECTION	
US	69-13-03	HEATER EXHAUST TUBE	
US	71-12-01	ENGINE CONTROL SUPPORT BRACKET	
	74-22-05	FULL VALVE STEM AND CAP NUT	
US	78-08-03	HINGE BRACKET ASSEMBLY	
US	80-18-10	FUEL SELECTOR VALVES	
US	80-26-04R1	RUDDER CABLE PULLEY AT CABIN STEP	672
US	85-02-05R1	BRAKE OPERATIONS	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

PIPER PA23 1 (CONTIN	60	( 0.00 0.00.00	
PA23 1	60	( 0.00 050750 )	
	60		
(CONTIN		( PA23 SERIES )	
	UED / SUITE)		
US	92-13-04	FUEL - WATER CONTAMINATION	827A
US	93-06-02	FUEL TIP TANKS "PUSH LOK" HOSES	MET-CO-AIRE 23-001
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	1121 00 AINE 20 001
		The second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second secon	
PA23 2	35	( PA23 SERIES )	
CF	CF-95-21	DRIFT SIGHT INSTALLATION	
US	69-13-03	HEATER EXHAUST TUBE	
US	72-11-01		
US		POSSIBLE FIRE FROM FUEL VAPOR	
	74-06-01	AIRESEARCH TURBOCHARGERS	
US	74-13-03	STABILATOR ATTACH BOLTS	
US	74-22-05	FULL VALVE STEM AND CAP NUT	
US	80-18-10	FUEL SELECTOR VALVES	
US	80-26-04R1	RUDDER CABLE PULLEY AT CABIN STEP	672
US	81-04-05R1	FLAP-SPAR HINGE ATTACHMENT	
US	83-22-01R1	FUEL WEIGHT LIMITATIONS	
US	85-02-05R1	BRAKE OPERATIONS	
US	93-06-02	FUEL TIP TANKS "PUSH LOK" HOSES	MET-CO-AIRE 23-001
US	99-05-09	INDUCTION AIR FILTER	
US	99-14-01		1022
03	33 14 01	OPERATING IN SEVERE ICING CONDITIONS	
PA23 2	50	( DA22 CEDICE )	
		( PA23 SERIES )	
CF	CF-95-21	DRIFT SIGHT INSTALLATION	
US	64-21-05	HARTZELL PROPELLER GOVERNORS	
US	66-18-03	INDUCTION SYSTEM ICING	
US	68-07-04	ENGINE MOUNT	
US	68-21-03	EXHAUST TAILPIPE	
US	69-13-03	HEATER EXHAUST TUBE	
US	70-22-05	ELECTRICAL SYSTEM MODIFICATION	
US	71-12-01	ENGINE CONTROL SUPPORT BRACKET	
	71-12-05	ELECTRIC TRIM SWITCH MOD	
	71-21-06	ENGINE FIRE WALL FLEX DUCT	
	72-11-01		
US	72-14-05	POSSIBLE FIRE FROM FUEL VAPOR	
		ENGINE EXHAUST SYSTEM STACKS	
	72-21-07	LONGITUDINAL STABILITY	
	74-06-01	AIRESEARCH TURBOCHARGERS	
	74-10-01	OUTBOARD FLAP HINGE	
	74-13-03	STABILATOR ATTACH BOLTS	
	74-22-05	FULL VALVE STEM AND CAP NUT	
US	75-11-05	GLARE SHIELD PANEL	
US	76-11-07	MAGNETIC COMPASS DEVIATIONS	
	77-01-05	STROBE NAV LIGHT WIRE	
	77-09-10	ELECTRIC TRIM SWITCH	
	77-23-09	FUEL FLOW	
-	78-02-03	STABILATOR	
	79-26-01		
		STABILATOR SKINS AND FRAME	
	80-18-10	FUEL SELECTOR VALVES	
	80-26-04R1	RUDDER CABLE PULLEY AT CABIN STEP	672
	81-04-05R1	FLAP-SPAR HINGE ATTACHMENT	
	83-22-01R1	FUEL WEIGHT LIMITATIONS	
	85-02-05R1	BRAKE OPERATIONS	
	93-06-02	FUEL TIP TANKS "PUSH LOK" HOSES	MET-CO-AIRE 23-001
	99-05-09	INDUCTION AIR FILTER	1022
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	1022
PA24 SE	RIES		
CF CF	CF-58-07	OPEN BUS BAR	
US	61-16-06		1
		FUEL SELECTOR VALVE HANDLES	
	62-26-05	EXHAUST SYSTEM	
	63-27-03	LANDING GEAR RETRACTION MOTOR CIRCUIT	
	68-05-01	EXHAUST MUFFLERS	
	97-01-01R1	MAIN LANDING GEAR SIDEBRACE STUD CRACKS	
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
PA24		( PA24 SERIES )	
	58-25-05	DOOR LATCH MODIFICATION	
	59-06-05		
	59-07-05	NOSE GEAR BUNGEE	
		OIL COOLER LINES CLEARANCE	167
	59-12-09	CONTROL WHEEL SPROCKET STUD	
	59-13-02	AILERON BALANCE WEIGH!	
115	59-26-02	FUEL CELL VENT TUBES	
	20 04 05		
US (	60-24-03 62-10-03	FUEL VENT TUBES AILERON COUNTERWEIGHT BAY REWORK	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE · (SERIES / SERIE)

	50381	BULLETIN DE SERVICE DE REF.
PIPER		
PA24	( PA24 SERIES )	
(CONTINUED / SUITE)	, ounted ,	
US 64-22-03	LANDING GEAR SAFETY SWITCH	
US 65-25-03	NOSE LANDING GEAR DRAG LINK CLEVIS	
US 68-13-03	FUEL CELL COLLAPSE	
US 72-22-05	OPERATION LIMITATION PLACARD	
US 74-13-01	STABILATOR TORQUE TUBE	
US 74-13-03 US 75-05-02	STABILATOR ATTACH BOLTS	
	ENGINE DIL	
US 75-12-06 US 75-27-08	FIN FORWARD SPAR	
US 77-08-01	TORQUE TUBE BEARING FITTINGS	
US 77-13-21	AILERON SPAR CRACKS	
US 79-20-10	PREVENT LANDING GEAR COLLAPSE INCORPORATION OF PIPER KIT 763893	
US 82-23-01R1	PLACARD NEAR FLAP ACTUATOR	
US 83-19-03	LOWER SPAR CAP INSPECTION	754
US 85-02-05R1	BRAKE OPERATIONS	751
US 94-13-10	STABILATOR TORQUE TUBE BEARING SUPPORT FITTINGS	411A
US 99-05-09	INDUCTION AIR FILTER	1022
		1022
PA24 250	( PA24 SERIES )	
US 59-06-05	NOSE GEAR BUNGEE	
US 59-12-09	CONTROL WHEEL SPROCKET STUD	
US 59-13-02 US 59-26-02	AILERON BALANCE WEIGHT	
US 59-26-02 US 60-24-03	FUEL CELL VENT TUBES	
US 61-16-06	FUEL VENT TUBES FUEL SELECTOR VALVE HANDLES	
US 61-20-02	EXHAUST STACK REINFORCEMENT	
US 62-10-03	AILERON COUNTERWEIGHT BAY REWORK	
US 62-26-05	EXHAUST SYSTEM	
US 63-27-03	LANDING GEAR RETRACTION MOTOR CIRCUIT	
US 64-10-04	CARBURETOR AIR BOX DEFLECTOR VANES	
US 64-22-03	LANDING GEAR SAFETY SWITCH	
US 65-11-04	STABILATOR CONTROL SYSTEM	
US 65-25-03	NOSE LANDING GEAR DRAG LINK CLEVIS	
US 68-13-03	FUEL CELL COLLAPSE	
US 72-22-05	OPERATION LIMITATION PLACARD	
US 74-13-01 US 74-13-03	STABILATOR TORQUE TUBE	
US 74-13-03 US 75-05-02	STABILATOR ATTACH BOLTS	
US 75-12-06	ENGINE OIL FIN FORWARD SPAR	
US 75-27-08	TORQUE TUBE BEARING FITTINGS	
US 76-19-07	STABILATOR WEIGHT ASSY	
US 77-08-01	AILERON SPAR CRACKS	
US 77-13-21	PREVENT LANDING GEAR COLLAPSE	
US 79-20-10	INCORPORATION OF PIPER KIT 763893	
US 82-23-01R1	PLACARD NEAR FLAP ACTUATOR	
US 83-19-03	LOWER SPAR CAP INSPECTION	751
US 85-02-05R1	BRAKE OPERATIONS	
US 94-13-10	STABILATOR TORQUE TUBE BEARING SUPPORT FITTINGS	411A
US 99-05-09	INDUCTION AIR FILTER	1022
PA24 260	( PA24 SERIES )	
US 65-11-04	STABILATOR CONTROL SYSTEM	
US 66-18-04	BAGGAGE DOOR LATCH	
US 71-12-05	ELECTRIC TRIM SWITCH MOD	
US 72-22-05	OPERATION LIMITATION PLACARD	
US 74-13-01	STABILATOR TORQUE TUBE	
US 74-13-03	STABILATOR ATTACH BOLTS	
US 75-05-02	ENGINE DIL	
US 75-12-06	FIN FORWARD SPAR	
US 75-27-08	TORQUE TUBE BEARING FITTINGS	
US 76-19-07	STABILATOR WEIGHT ASSY	
US 77-08-01	AILERON SPAR CRACKS	
US 77-09-10	ELECTRIC TRIM SWITCH	
US 77-13-21	PREVENT LANDING GEAR COLLAPSE	
US 79-20-10	INCORPORATION OF PIPER KIT 763893	
US 82-23-01R1	PLACARD NEAR FLAP ACTUATOR	751
US 83-19-03	LOWER SPAR CAP INSPECTION BRAKE OPERATIONS	7.51
US 85-02-05R1 US 91-21-09	INDUCTION SYSTEM ICING	861
US 91-21-09 US 94-13-10	STABILATOR TORQUE TUBE BEARING SUPPORT FITTINGS	411A
US 99-05-09	INDUCTION AIR FILTER	1022
55 55 55		
		AYDODATT /AFDONESS

# INDEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN CANADA

	INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA			
	ONSTRUCTEUR / MODELE	(SERIES / SERIE)		
ORIGI		SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.	
PIPER	400	( DAGA SERVES )		
US	65-11-04	( PA24 SERIES ) STABILATOR CONTROL SYSTEM		
US	66-30-07	FUEL PURGE VALVE HOSE ASSEMBLY		
US US	74-13-01 74-13-03	STABILATOR TORQUE TUBE STABILATOR ATTACH BOLTS		
US	75-12-06	FIN FORWARD SPAR		
US US	75-27-08 77-08-01	TORQUE TUBE BEARING FITTINGS AILERON SPAR CRACKS		
US	77-13-21	PREVENT LANDING GEAR COLLAPSE		
US	79-12-08 79-20-10	FUEL SELECTOR VALVES		
US	83-10-01	INCORPORATION OF PIPER KIT 763863 WATER AND FUEL SYSTEM INSP		
US US	83-19-03	LOWER SPAR CAP INSPECTION	751	
US	85-02-05R1 94-13-10	BRAKE OPERATIONS STABILATOR TORQUE TUBE BEARING SUPPORT FITTINGS	411A	
DAGE	SERIES		7118	
US	80-21-08	FORWARD WING SPARS		
US	90-02-06	FORWARD WING SPAR CAPS		
US US	95-12-01 99-01-05	WING CRACKING/CORROSION, SUPERSEDES 93-21-12 WING STRUT CORROSION-CRACKED FORKS	F29D 2404	
US	99-26-05	INGESTION OF AIR FILTER PIECES INTO ENGINE	528D,910A 1022	
PA25		( PA25 SERIES )		
US	62-02-06	WING SPAR HINGE FITTING		
US	65-15-05 72-24-02	ELEVATOR CONTROL SYSTEM THROTTLE MOVEMENT PLACARD		
US	73-26-01	FORWARD WING SPARS		
US US	77-21-06 85-02-05R1	FUSELAGE STEEL TUBING CLUSTER BRAKE OPERATIONS		
PA25 US	63-17-05	( PA25 SERIES )  LANDING GEAR SHOCK STRUTS		
US	64-24-05	FUSELAGE LANDING GEAR FITTING SEALS		
US US	65-15-05 67-14-07	ELEVATOR CONTROL SYSTEM ENGINE EXHAUST SYSTEM		
US	73-15-05	CRACKS IN HOPPER BAY LONGERONS		
US US	73-26-01 74-18-02	FORWARD WING SPARS FUEL LINES		
US	77-21-06	FUSELAGE STEEL TUBING CLUSTER		
US	85-02-05R1	BRAKE OPERATIONS		
PA25 US		( PA25 SERIES )		
US	73-26-01 74-18-02	FORWARD WING SPARS FUEL LINES		
US	77-21-06	FUSELAGE STEEL TUBING CLUSTER		
US	85-02-05R1	BRAKE OPERATIONS		
PA28 US	<b>SERIES</b> 62-19-03	DDODELLED ATTACK DOLTO		
US	64-06-06	PROPELLER ATTACH BOLTS CONTROL WHEELS		
US US	67-20-04 67-26-02	MAIN LANDING GEAR TORQUE LINK		
US	86-17-01	FUEL SELECTOR VALVE AMMETER TERMINAL POSTS	811A	
US	87-08-08R3	WING LOWER SPAR CAP (RESCINDED)	PIPER SL 997	
US US	95-26-13 96-10-03	OIL COOLER HOSE RUPTURES_(SUPERSEDES AD 76-25-06) FLAP HANDLE ATTACH BOLT	SB 965	
US	97-01-01R1	MAIN LANDING GEAR SIDEBRACE STUD CRACKS	20 963	
US	98-21-21	BOB FIELDS AEROCESSORIES STC		
PA28 US	<b>140</b> 65-06-06	( PA28 SERIES )		
US	67-12-06	FUEL QUANTITY GAUGE SENDER UNITS INSPECT TUBES FOR INTERNAL CORROSION		
US US	67-26-03	FUEL SYSTEMS SCREENS AND FILTERS		
US	69-22-02 70-16-05	FAILURE OF CONTROL WHEEL CRACKS IN MUFFLER		
US	70-18-05	LANDING GEAR TORQUE LINK BOLTS		
US US	70-26-04 71-14-06	STABILIZER BALANCE WEIGHT TUBE TO PREVENT GROUNDING OF MAGNETOS		
US	71-21-08	BINDING OF FUEL SELECTOR HANDLE		
US US	72-08-06 72-14-07	MAIN LANDING GEAR TORQUE LINKS BOLTS IN STABILATOR HINGE FITTINGS		
US	72-24-02	THROTTLE MOVEMENT PLACARD		
US	74-06-02	AVCON MUFFLERS		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

SUBJECT SUJET

ONIO	INC. NOWERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
PIPE	R		
	8 140	( PA28 SERIES )	
(CON	TINUED / SUITE)	( FRED SERIES )	
US		REAR SEAT BELT INSTALLATION	
US	74-13-04	THROTTLE CONTROL CABLE	
US	75-02-03 75-08-03	NOSE WHEEL FORK ASSEMBLY	
US	77-01-01		
US	77-23-03	FUEL QUANTITY GAGE ROD END BEARINGS	
US	96-10-01R1	LANDING LIGHT SUPPORT AND SEAL REPLACEMENT	075
US	99-05-09	INDUCTION AIR FILTER	975
DAGG	3 150		
US	62-26-06	( PA28 SERIES )	
US	65-06-06	EXHAUST SYSTEM FUEL QUANTITY GAUGE SENDER UNITS	
US	66-20-05	PROPELLER SPINNER	
US	67-12-06	INSPECT TUBES FOR INTERNAL CORROSION	
US	67-26-03	FUEL SYSTEMS SCREENS AND ELLTERS	
US	69-22-02	FAILURE OF CONTROL WHEEL	
US	70-16-05 70-18-05	CRACKS IN MOFFLER	
US	70-26-04	LANDING GEAR TORQUE LINK BOLTS STABILIZER BALANCE WEIGHT TUBE	
US	71-14-06	TO PREVENT GOUNDING OF MAGNETOS	
US	72-08-06	MAIN LANDING GEAR TURQUE LINKS	
US	72-14-07	BOLTS IN STABILATOR HINGE FITTINGS	
US	72-24-02	THROTTLE MOVEMENT PLACARD	
US	75-02-03 75-08-03	NOSE WHEEL FORK ASSEMBLY FUEL DRAIN VALVES	
US	77-01-01	FUEL QUANTITY GAGE	
US	96-10-01R1	LANDING LIGHT SUPPORT AND SEAL REPLACEMENT	975
US	99-05-09	INDUCTION AIR FILTER	1022
DAGG			
US US	<b>151</b> 74-14-04	( PA28 SERIES ) REDUCED WEIGHT PLACARD	
US	74-24-12	AILERON CENTERING ASSEMBLY	
US	75-08-03	FUEL DRAIN VALVES	
US	75-16-04	CARBURETOR AIR BOX VALVE	
US	77-01-01	FUEL QUANTITY GAGE	
US US	77-01-03 77-23-03	CARBURETOR AIR FILTER BOXES	
US	81-23-05	ROD END BEARINGS SEAT SPRINGS AND BATTERY BOX	
US	99-26-05	INGESTION OF AIR FILTER PIECES INTO ENGINE	1022
	160	( PA28 SERIES )	
US US	62-26-06 65-06-06	EXHAUST SYSTEM	
US	66-20-05	FUEL QUANTITY GAUGE SENDER UNITS PROPELLER SPINNER	
US	67-12-06	INSPECT TUBES FOR INTERNAL CORROSION	
US	67-26-03	FUEL SYSTEMS SCREENS AND FILTERS	
US	69-22-02	FAILURE OF CONTROL WHEEL	
US	70-16-05	CRACKS IN MUFFLER	
US	70-18-05 70-26-04	LANDING GEAR TORQUE LINK BOLTS STABILIZER BALANCE WEIGHT TUBE	
US	71-14-06	TO PREVENT GROUNDING OF MAGNETOS	
US	72-08-06	MAIN LANDING GEAR TORQUE LINKS	
US	72-14-07	BOLTS IN STABILATOR HINGE FITTINGS	
US	72-24-02	THROTTLE MOVEMENT PLACARD	
US	75-02-03	NOSE WHEEL FORK ASSEMBLY	
US	75-08-03 77-01-01	FUEL DRAIN VALVES FUEL QUANTITY GAGE	
US	96-10-01R1	LANDING LIGHT SUPPORT AND SEAL REPLACEMENT	975
US	99-05-09	INDUCTION AIR FILTER	1022
5			
	161	( PA28 SERIES )	
US US	77-23-03 79-02-05	ROD END BEARINGS FUEL FLOW	
US	79-13-03	FIRE HAZARD PREVENTION	
US	79-22-02	FUEL LEAKAGE	
US	80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
US	81-23-05	SEAT SPRINGS AND BATTERY BOX	1000
US	99-26-05	INGESTION OF AIR FILTER PIECES INTO ENGINE	1022
PA28	180	( PA28 SERIES )	
US	65-06-06	FUEL QUANTITY GAUGE SENDER UNITS	
US	66-20-05	PROPELLER SPINNER	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

PIPER			
PA28		( PA28 SERIES )	
US	67-12-06 67-26-03	INSPECT TUBES FOR INTERNAL CORROSION	
US	69-15-01	FUEL SYSTEMS SCREENS AND FILTERS CONTROL WHEEL PIN	
US	69-22-02 70-16-05	FAILURE OF CONTROL WHEEL CRACKS IN MUFFLER	
US	70-18-05	LANDING GEAR TORQUE LINK BOLTS	
US	70-26-04 71-14-06	STABILIZER BALANCE WEIGHT TUBE TO PREVENT GROUNDING OF MAGNETOS	
US	71-21-08	BINDING OF FUEL SELECTOR HANDLE	
US	72-08-06 <b>72</b> -14-07	MAIN LANDING GEAR TORQUE LINKS BOLTS IN STABILATOR HINGE FITTINGS	
US	72-17-05	ELECTRIC TRIM SWITCH	
US	74-09-04 74-26-07	REAR SEAT BELT INSTALLATION TO DETECT INCORRECT PLACARD	
US	75-02-03 75-08-03	NOSE WHEEL FORK ASSEMBLY	
US	75-24-02	FUEL DRAIN VALVES LOOSE SEATS	
US US	77-01-01 77-23-03	FUEL QUANTITY GAGE	
US	96-10-01R1	ROD END BEARINGS LANDING LIGHT SUPPORT AND SEAL REPLACEMENT	975
US	99-05-09	INDUCTION AIR FILTER	1022
PA28		( PA28 SERIES )	
US	77-01-01 77-23-03	FUEL QUANTITY GAGE ROD END BEARINGS	
US	79-13-03	FIRE HAZARD PREVENTION	
US	79-22-02 80-14-02	FUEL LEAKAGE THROTTLE CABLE	
US	80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
US	99-05-09	INDUCTION AIR FILTER	1022
PA28 US		( PA28 SERIES )	
US	79-13-03 79-22-02	FIRE HAZARD PREVENTION FUEL LEAKAGE	
US US	80-14-03 99-05-09	BENDIX, KING OR NARCO TRANSMITTERS	
		INDUCTION AIR FILTER	1022
PA28 US	<b>235</b> 65-06-06	( PA28 SERIES )  FUEL QUANTITY GAUGE SENDER UNITS	
US	67-12-06	INSPECT TUBES FOR INTERNAL CORROSION	
US	67-26-03 69-15-01	FUEL SYSTEMS SCREENS AND FILTERS CONTROL WHEEL PIN	
US	69-22-02	FAILURE OF CONTROL WHEEL	
US	70-18-05 70-26-04	LANDING GEAR TORQUE LINK BOLTS STABILIZER BALANCE WEIGHT TUBE	
US	71-14-06	TO PREVENT GROUNDING OF MAGNETOS	
US US	72-08-06 72-14-07	MAIN LANDING GEAR TORQUE LINKS BOLTS IN STABILATOR HINGE FITTINGS	
US US	72-17-05 74-09-04	ELECTRIM TRIM SWITCH	
US	74-18-06	REAR SEAT BELT INSTALLATION FUEL QUANTITY PLACARDS	
US	74-19-01 75-02-03	OUTER WING SPARS NOSE WHEEL FORK ASSEMBLY	
US	75-24-02	LOOSE SEATS	
US US	76-18-04 77-01-01	FUEL VALVE FUEL QUANTITY GAGE	
US	77-12-01	FUEL SYSTEM	
US	77-23-03 78-23-01	ROD END BEARINGS FUEL DRAIN ASSEMBLY	
US	79-22-02	FUEL LEAKAGE	
US	99-05-09	INDUCTION AIR FILTER	1022
PA28 US		( PA28 SERIES )	
US	79-13-03 79-22-02	FIRE HAZARD PREVENTION FUEL LEAKAGE	
US	80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
PA28R		( PA28 SERIES )	
US	68-12-04 69-12-01	GEAR RETRACTION FITTINGS AIR INDUCTION HOSE	
US US	69-15-01	CONTROL WHEEL PIN	
03	70-09-02	PROPELLER SPINNER	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE (SERIES / SERIE) SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
PIPER			
PA28R	180	( PA28 SERIES )	
(CONT I	NUED / SUITE)	( PAZ8 SERIES )	
US	70-26-04	STABILIZER BALANCE WEIGHT TUBE	
US	71-21-08	BINDING OF FUEL SELECTOR HANDIF	
US	72-14-07	BOLTS IN STABILATOR HINGE FITTINGS	
US	72-17-05	ELECTRIC TRIM SWITCH	
US	75-08-03 75-24-02	FUEL DRAIN VALVES	
US	76-15-08	LOOSE SEATS NOSE GEAR TRUNNION	
US	77-23-03	ROD END BEARINGS	
US	80-19-01	CARBON MONOXIDE IN CABIN	
US	94-14-14	INSTALLATION OF NOSE LANDING GEAR MOD KIT	51 988
			31 300
PA28R		( PA28 SERIES )	
US	69-12-01 69-15-01	AIR INDUCTION HOSE	
US	70-09-02	CONTROL WHEEL PIN PROPELLER SPINNER	
US	70-26-04	STABILIZER BALANCE WEIGHT TUBE	
US	71-21-08	BINDING OF FUEL SELECTOR HANDLE	
US	72-14-07	BOLTS IN STABILATOR HINGE FITTINGS	
US	72-17-05	ELECTRIC TRIM SWITCH	
US	74-09-04	REAR SEAT BELT INSTALLATION	
US	75-08-03	FUEL DRAIN VALVES	
US	75-24-02 76-15-08	LOOSE SEATS	
US	77-01-01	NOSE GEAR TRUNNION FUEL QUANTITY GAGE	
US	77-23-03	ROD END BEARINGS	
US	80-19-01	CARBON MONOXIDE IN CABIN	
US	81-11-02R1	OIL DRAIN VALVES	
US	82-06-11R1	NIG INSPECT RIG MODIEV	
US	94-14-14	INSTALLATION OF NOSE LANDING GEAR MOD KIT	SL 988
PA28R	201	( DAGO CEDIEC )	
US	77-23-03	( PA28 SERIES ) ROD END BEARINGS	
US	79-02-05	FUEL FLOW	
US	79-13-03	FIRE HAZARD PREVENTION	
US	79-22-02	FUEL LEAKAGE	
US	80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
US	80-19-01	CARBON MONOXIDE IN CABIN	
US	81-11-02R1	OIL DRAIN VALVES	
US US	82-06-11R1 94-14-14	NLG, INSPECT, RIG, MODIFY	21 022
		INSTALLATION OF NOSE LANDING GEAR MOD KIT	2r 300
PA28R	201T	( PA28 SERIES )	
US	77-23-03	ROD END BEARINGS	
US	79-02-05	FUEL FLOW	
US	79-13-03	FIRE HAZARD PREVENTION	
US US	79-22-02	FUEL LEAKAGE	
US	80-14-03 82-06-11R1	BENDIX, KING OR NARCO TRANSMITTERS NLG, INSPECT, RIG, MODIFY	
US	94-14-14	INSTALLATION OF NOSE LANDING GEAR MOD KIT	SL 988
US	99-05-09	INDUCTION AIR FILTER	1022
		(	
PA28R1		( PA28 SERIES )	
US US	79-13-03	FIRE HAZARD PREVENTION FUEL LEAKAGE	
US	79-22-02 80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
US	80-19-01	CARBON MONOXIDE IN CABIN	
US	81-11-02R1	OIL DRAIN VALVES	
US	82-06-11R1	NLG, INSPECT, RIG, MODIFY	
US	94-14-14	INSTALLATION OF NOSE LANDING GEAR MOD KIT	SL 988
DAGGDT	201T	( PA28 SERIES )	
US	79-13-03	FIRE HAZARD PREVENTION	
US	79-13-03	FUEL LEAKAGE	
US	80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
US	82-06-11R1	NLG, INSPECT, RIG, MODIFY	
US	94-14-14	INSTALLATION OF NOSE LANDING GEAR MOD KIT	SL 988
US	99-05-09	INDUCTION AIR FILTER	1022
0.4.00			
PA30 CF	CF-71-14	AIR FLOW MODIFICATION KIT	SL 558
US	64-09-05	INDUCTION SYSTEM ALTERNATE AIR DOORS	32 000
US	64-16-06	NOSE GEAR RETRACTION TUBES	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

PIPE	R		
PA3			
	TINUED / SUITE)		
US		HARTZELL PROPELLER GOVERNOR	
US		HEAVY WALLED TORQUE TUBE STABILATOR CONTROL SYSTEM	
US	66-18-04	BAGGAGE DOOR LATCH	
US	66-28-06	STABILATOR SYSTEM	
US	67-19-05	OXYGEN CYLINDER MOUNTING CHANNELS	
US		HEATER EXHAUST TUBE	
US	69-24-04	MINIMUM CONTROL SPEED	
US	70-15-17	OPERATING LIMITATION PLACARD	
US	70-22-05 71-12-05	ELECTRICAL SYSTEM MODIFICATIONS ELECTRIC TRIM SWITCH MOD	
US	74-13-01	STABILATOR TORQUE TUBE	
US	74-13-03	STABILATOR ATTACH BOLTS	
US	74-16-08	AFT BULKHEAD ASSEMBLY	
US	75-27-08	TORQUE TUBE BEARING FITTINGS	
US	76-18-05	FORWARD FIN ATTACHMENT	
US	77-08-01 77-09-10	AILERON SPAR CRACKS	
US	77-13-21	ELECTRIC TRIM SWITCH PREVENT LANDING GEAR COLLAPSE	
US	78-12-07	FUEL SELECTOR VALVE	
US	79-12-08	FUEL SELECTOR VALVE	
US	79-20-10	INCORPORATION OF PIPER KIT 763893	
US	82-23-01R1	PLACARD NEAR FLAP ACTUATOR	
US	83-10-01	WATER AND FUEL SYSTEM INSPECTION	
US	83-19-03	LOWER SPAR CAP INSPECTION	751
US	85-02-05R1 94-13-10	BRAKE OPERATIONS	4444
US	97-01-01R1	STABILATOR TORQUE TUBE BEARING SUPPORT FITTINGS MAIN LANDING GEAR SIDEBRACE STUD CRACKS	411A
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
	SERIES	4 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	
US	92-27-05	AILERON CONTROL SYSTEM	
	93-24-02R1	ELEVATOR CONTROL TUBE ASSEMBLY	
115	96~10-14	MAIN I ANDING CEAD ECOMADO CIDE DOACE INCOCOTION	
US US	96~10-14 96-21-03	MAIN LANDING GEAR FORWARD SIDE BRACE INSPECTION	SB 845A
US US US	96-10-14 96-21-03 96-21-04	MAIN LANDING GEAR FORWARD SIDE BRACE INSPECTION INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07)	SB974, SB967
US	96-21-03	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07)	SB974, SB967 822
US US	96-21-03 96-21-04	MAIN LANDING GEAR FORWARD SIDE BRACE INSPECTION INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC	SB974, SB967 822
US US US US	96-21-03 96-21-04 96-24-13 98-21-21	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC	SB974, SB967 822
US US US US	96-21-03 96-21-04 96-24-13 98-21-21	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES )	SB974, SB967 822
US US US US	96-21-03 96-21-04 96-24-13 98-21-21	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES	SB974, SB967 822
US US US US PA31 US	96-21-03 96-21-04 96-24-13 98-21-21	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING	SB974, SB967 822
US US US US PA31 US US US	96-21-03 96-21-04 96-24-13 98-21-21 (P 67-25-06 68-13-01 68-20-04 69-06-04	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES	SB974, SB967 822
US US US US PA31 US US US US	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS	SB974, SB967 822
US US US US PA31 US US US US US	96-21-03 96-21-04 96-24-13 98-21-21 (F 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING	SB974, SB967 822
US US US US PA31 US US US US US US	96-21-03 96-21-04 96-24-13 98-21-21 (F 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION	SB974, SB967 822
US US US US US US US US US US US	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR	SB974, SB967 822
US US US US PA31 US US US US US US	96-21-03 96-21-04 96-24-13 98-21-21 (F 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 (F 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 (F 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-10 75-09-10 76-04-11	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 (F) 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELECYATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-07-03	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-00 74-26-10 75-09-10 76-04-11 77-03-03 77-07-03 77-07-03	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL SHORT	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-10 75-09-10 76-04-11 77-03-03 77-03-03 77-08-02 77-09-10 77-12-02	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21 67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-07-03 77-08-02 77-09-10 77-12-02 77-14-14	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-O7) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELECYATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL SHORT ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TRIM SWITCH	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-07-03 77-08-02 77-09-10 77-12-02 77-14-14 77-19-06	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-O7) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL SHORT ELECTRIC TRIM SWITCH ELEVATOR BALANCE WEIGHTS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-08-02 77-08-02 77-09-10 77-12-02 77-14-14 77-19-06 77-24-01	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-O7) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELECYATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-08-02 77-09-10 77-12-02 77-14-14 77-19-06 77-24-01 78-01-02	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC THEMS WITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES STABILIZERS AND FINS ELEVATOR BUNGEE	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-07-03 77-07-03 77-08-02 77-14-14 77-19-06 77-24-01 78-01-02 78-05-05	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-O7) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL SHORT ELECTRICAL SHORT ELECTRIC TRIM SWITCH ELECTRIC TRIM SWITCH ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA S	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-08-02 77-09-10 77-12-02 77-14-14 77-19-06 77-24-01 78-01-02	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-O7) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELECYATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL TRIM SWITCH ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SH	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-07-03 77-07-03 77-07-03 77-07-03 77-07-02 77-12-02 77-14-14 77-19-06 77-24-01 78-01-02 78-05-05 78-08-10	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-O7) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL SHORT ELECTRICAL SHORT ELECTRIC TRIM SWITCH ELECTRIC TRIM SWITCH ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA SHORT ELECTRICA S	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-08-02 77-09-10 77-12-02 77-14-14 77-19-06 77-24-01 78-01-02 78-05-05 78-08-10 79-12-02 79-14-02 79-14-02	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC THEMS WITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES STABILIZERS AND FINS ELEVATOR BUNGEE CABIN DOOR LATCH FUEL SELECTOR LEVER ELEVATOR SURFACE TRAVEL	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-04 74-26-04 77-03-03 77-07-03 77-07-03 77-08-06 77-09-10 77-12-02 77-14-14 77-19-06 77-24-01 78-01-02 78-01-02 78-08-10 79-12-02 79-12-02 79-14-06	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-07) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR TORQUE TUBE ELEVATOR STRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRI	SB974, SB967 822
US US US US US US US US US US US US US U	96-21-03 96-21-04 96-24-13 98-21-21  67-25-06 68-13-01 68-20-04 69-06-04 69-11-05 69-13-04 70-22-05 70-26-06 71-01-04 71-12-05 74-26-04 74-26-10 75-09-10 76-04-11 77-01-06 77-03-03 77-08-02 77-09-10 77-12-02 77-14-14 77-19-06 77-24-01 78-01-02 78-05-05 78-08-10 79-12-02 79-14-02 79-14-02	INBOARD AILERON HINGE BRACKET CRACKS HYDRAULIC HOSES (SUPERSEDES 86-17-O7) LANDING GEAR SELECTOR CABLE (SUPERSEDES 75-26-18) BOB FIELDS AEROCESSORIES STC  PA31 SERIES ) OIL COOLER HOSES ELECTRICAL WIRE ARCING ELEVATOR TORQUE TUBE ELEVATOR FRICTION SYSTEM STALL STRIPS LANDING GEAR WARNING ELECTRICAL SYSTEM MODIFICATION CRACKS IN ELEVATOR AND RUDDER SPAR TOXIC FUMES FROM BATTERY ELECTRIC TRIM SWITCH MOD EXPLOSION HAZARDS SHUTTING DOWN ENGINE PUSH-PULL TUBE END FITTINGS LOOSE BOLTS HORIZONTAL STABILIZER AIRCRAFT DATA PLATE ELECTRICAL TERMINALS ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICAL SHORT ELECTRICA TRIM SWITCH ELEVATOR BALANCE WEIGHTS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES STABILIZERS AND FINS ELEVATOR BURGALE CABIN DOOR LATCH FUEL SELECTOR LEVER ELEVATOR SUFFACE TRAVEL CONTROL WHEEL SHAFT STUD LIGHTER CIRCUIT BREAKER	SB974, SB967 822

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

I .		BULLETIN DE SERVICE DE REF
PIPER		
PA31	( PA31 SERIES )	
(CONTINUED / SUITE)	( INDI SERIES )	
US 80-17-06	PLACARDS	
US 80-18-10		
US 80-26-05	FUEL SELECTOR VALVES MLG DOOR HINGES	
US 82-16-05R1	TUPPOCHARCED EXTRACT DARK CONTRACT	
US 82-27-13R2	TURBOCHARGER EXHAUST PIPE COUPLING	644C
US 85-08-05	FLAP EXTENSION SYSTEM	
US 87-21-01	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS	
US 93-23-13	ENGINE COWLING BAFFLE SEALS	797B
US 96-10-15		SB693/SL875
US 96-12-12	CRACKS AT WING STATION 147.5	SB 647A
US 96-21-11	FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04	SB 636A
US 97-07-03	MLG ACTUATOR REINFOREMENT BRACKET	923
US 98-08-18	NOSE WHEEL	700A
US 98-09-25	ELEVATOR BUNGEE SPRING	626C
US 99-06-01	REPLACE LOWER SPAR SPLICE PLATE	1003
US 99-12-05	HORIZONTAL STABILIZER REAR SPAR	1007
US 99-14-01	INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING	998A
33 14 01	OPERATING IN SEVERE ICING CONDITIONS	
PA31 300	( PA31 SERIES )	
US 68-13-01		
US 68-20-04	ELECTRICAL WIRE ARCING	
US 69-06-04	ELEVATOR TORQUE TUBE	
US 69-11-05	ELEVATOR FRICTION SYSTEM	
US 69-13-04	STALL STRIPS	
US 70-22-05	LANDING GEAR WARNING	
US 70-26-06	ELECTRICAL SYSTEM MODIFICATION	
US 71-01-04	CRACKS IN ELEVATOR AND RUDDER SPAR	
US 71-12-05	TOXIC FUMES FROM BATTERY	
US 74-26-04	ELECTRIC TRIM SWITCH MOD	
US 74-26-10	EXPLOSION HAZARDS	
US 75-09-10	SHUTTING DOWN ENGINE	
	PUSH-PULL TUBE END FITTINGS	
	LOOSE BOLTS	
	ELECTRICAL SHORT	
US 77-09-10 US 77-12-02	ELECTRIC TRIM SWITCH	
	ELEVATOR BALANCE WEIGHTS	
US 77-19-06	AILERON CABLES	
US 78-05-05	CABIN DOOR LATCH	
US 79-12-02	ELEVATOR SURFACE TRAVEL	
US 79-14-02	CONTROL WHEEL SHAFT STUD	
US 80-14-06	WING ATTACHMENTS	
US 80-18-10	FUEL SELECTOR VALVES	
US 80-26-05	MLG DOOR HINGES	
US 82~27-13R2	FLAP EXTENSION SYSTEM	
US 85-08-05	STRUT HOUSING INSPECTION	7070
US 85-08-05 US 87-21-01	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS	7978
US 85-08-05 US 87-21-01 US 93-23-13	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS	SB693/SL875
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5	SB693/SL875 SB 647A
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04	SB693/SL875 SB 647A SB 636A
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET	SB693/SL875 SB 647A SB 636A 923
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL	SB693/SL875 SB 647A SB 636A 923 700A
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING	SB693/SL875 SB 647A SB 636A 923 700A 626C
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003
US 85-08-05 US 87-21-01 US 93-23-10 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZODITAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003
US 85-08-05 US 87-21-01 US 93-23-10 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZODITAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES )	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01  PA31 310  PA31 325	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES )	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01  PA31 310  PA31 325 US 76-04-11	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES ) LOOSE BOLTS	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01  PA31 310  PA31 325 US 76-04-11 US 76-15-07	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES ) LOOSE BOLTS ELEVATOR BALANCE WEIGHTS	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01  PA31 310  PA31 325 US 76-04-11 US 76-15-07 US 77-01-06	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS  ENGINE COWLING BAFFLE SEALS  CRACKS AT WING STATION 147.5  FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04  MLG ACTUATOR REINFORCEMENT BRACKET  NOSE WHEEL  ELEVATOR BUNGEE SPRING  REPLACE LOWER SPAR SPLICE PLATE  HORIZONTAL STABILIZER REAR SPAR  INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING  OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES )  LOOSE BOLTS  ELEVATOR BALANCE WEIGHTS  HORIZONTAL STABILIZER	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01  PA31 310  PA31 325 US 76-04-11 US 76-15-07 US 77-01-06 US 77-07-03	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES ) ( PA31 SERIES ) LOOSE BOLTS ELEVATOR BALANCE WEIGHTS HORIZONTAL STABILIZER ELECTRICAL TERMINALS	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-06-01 US 99-12-05 US 99-14-01  PA31 310  PA31 325 US 76-04-11 US 77-07-03 US 77-07-03 US 77-07-03 US 77-07-03	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  (PA31 SERIES ) LOOSE BOLTS ELEVATOR BALANCE WEIGHTS HORIZONTAL STABILIZER ELECTRICAL TERMINALS ELECTRICAL SHORT	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05  US 87-21-01  US 93-23-13  US 96-10-15  US 96-12-12  US 96-21-11  US 97-07-03  US 98-08-18  US 98-09-25  US 99-12-05  US 99-14-01  PA31 310  PA31 325  US 76-04-11  US 76-15-07  US 77-01-06  US 77-08-02  US 77-00-09	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS  ENGINE COWLING BAFFLE SEALS  CRACKS AT WING STATION 147.5  FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04  MLG ACTUATOR REINFORCEMENT BRACKET  NOSE WHEEL  ELEVATOR BUNGEE SPRING  REPLACE LOWER SPAR SPLICE PLATE  HORIZONTAL STABILIZER REAR SPAR  INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING  OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES )  ( PA31 SERIES )  LOOSE BOLTS  ELEVATOR BALANCE WEIGHTS  HORIZONTAL STABILIZER  ELECTRICAL TERMINALS  ELECTRICAL SHORT  VIBRATION EFFECTS	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05  US 87-21-01  US 93-23-13  US 96-10-15  US 96-12-12  US 96-21-11  US 97-07-03  US 98-08-18  US 98-09-25  US 99-06-01  US 99-12-05  US 99-14-01  PA31 310  PA31 325  US 76-04-11  US 76-15-07  US 77-01-06  US 77-07-03  US 77-08-02  US 77-10-09  US 77-14-14	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS  ENGINE COWLING BAFFLE SEALS  CRACKS AT WING STATION 147.5  FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04  MLG ACTUATOR REINFORCEMENT BRACKET  NOSE WHEEL  ELEVATOR BUNGEE SPRING  REPLACE LOWER SPAR SPLICE PLATE  HORIZONTAL STABILIZER REAR SPAR  INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING  OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES )  LOOSE BOLTS  ELEVATOR BALANCE WEIGHTS  HORIZONTAL STABILIZER  ELECTRICAL TERMINALS  ELECTRICAL SHORT  VIBRATION EFFECTS  SKIN DEFORMATION & LOOSE/MISSING RIVE S	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 99-06-01 US 99-12-05 US 99-14-01  PA31 310  PA31 325 US 76-04-11 US 76-15-07 US 77-07-03 US 77-07-03 US 77-08-02 US 77-10-09 US 77-10-06	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGES SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES ) LOOSE BOLTS ELEVATOR BALANCE WEIGHTS HORIZONTAL STABILIZER ELECTRICAL TERMINALS ELECTRICAL TERMINALS ELECTRICAL SHORT VIBRATION EFFECTS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05 US 87-21-01 US 93-23-13 US 96-10-15 US 96-12-12 US 96-21-11 US 97-07-03 US 98-08-18 US 98-09-25 US 99-12-05 US 99-14-01  PA31 310  PA31 325 US 76-04-11 US 76-15-07 US 77-01-06 US 77-07-03 US 77-10-09 US 77-14-14 US 77-19-06 US 77-19-06 US 77-19-06 US 77-19-06 US 77-19-06	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  (PA31 SERIES ) LOSE BOLTS ELEVATOR BALANCE WEIGHTS HORIZONTAL STABILIZER ELECTRICAL TERMINALS ELECTRICAL SHORT VIBRATION EFFECTS SK IN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES STABILIZERS AND FINS	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05  US 87-21-01  US 93-23-13  US 96-10-15  US 96-12-12  US 96-21-11  US 97-07-03  US 98-08-18  US 98-09-25  US 99-12-05  US 99-14-01  PA31 310  PA31 325  US 76-04-11  US 76-15-07  US 77-01-06  US 77-01-06  US 77-08-02  US 77-10-09  US 77-10-09  US 77-10-06  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-06  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-06	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES ) LOOSE BOLTS ELEVATOR BALANCE WEIGHTS HORIZONTAL STABILIZER ELECTRICAL TERMINALS ELECTRICAL SHORT VIBRATION EFFECTS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES STABILIZERS AND FINS ELEVATOR BUNGEE	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05  US 87-21-01  US 93-23-13  US 96-10-15  US 96-12-12  US 96-21-11  US 97-07-03  US 98-08-18  US 99-06-01  US 99-12-05  US 99-14-01  PA31 310  PA31 325  US 76-04-11  US 76-15-07  US 77-01-06  US 77-07-03  US 77-01-06  US 77-10-09  US 77-14-14  US 77-19-06  US 78-01-02  US 78-01-02  US 78-01-02  US 78-01-02  US 78-01-02	STRUT HOUSING INSPECTION  FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES ) ( PA31 SERIES ) LOOSE BOLTS ELEVATOR BALANCE WEIGHTS HORIZONTAL STABILIZER ELECTRICAL TERMINALS ELECTRICAL SHORT VIBRATION EFFECTS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES STABILIZERS AND FINS ELEVATOR BUNGEE CABIN DOOR LATCH	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007
US 85-08-05  US 87-21-01  US 93-23-13  US 96-10-15  US 96-12-12  US 96-21-11  US 97-07-03  US 98-08-18  US 98-09-25  US 99-12-05  US 99-14-01  PA31 310  PA31 325  US 76-04-11  US 76-15-07  US 77-01-06  US 77-01-06  US 77-08-02  US 77-10-09  US 77-10-09  US 77-10-06  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-06  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-09  US 77-10-06  US 77-10-06	STRUT HOUSING INSPECTION FUEL FILLER OPENINGS ENGINE COWLING BAFFLE SEALS CRACKS AT WING STATION 147.5 FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04 MLG ACTUATOR REINFORCEMENT BRACKET NOSE WHEEL ELEVATOR BUNGEE SPRING REPLACE LOWER SPAR SPLICE PLATE HORIZONTAL STABILIZER REAR SPAR INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING OPERATING IN SEVERE ICING CONDITIONS  ( PA31 SERIES ) LOOSE BOLTS ELEVATOR BALANCE WEIGHTS HORIZONTAL STABILIZER ELECTRICAL TERMINALS ELECTRICAL SHORT VIBRATION EFFECTS SKIN DEFORMATION & LOOSE/MISSING RIVE S AILERON CABLES STABILIZERS AND FINS ELEVATOR BUNGEE	SB693/SL875 SB 647A SB 636A 923 700A 626C 1003 1007

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

PIPER		/ >	
PA31		( PA31 SERIES )	
	NUED / SUITE)	··· ··· ··· ··· ··· ··· ··· ·· ·· ·· ··	
US	79-14-02	CONTROL WHEEL SHAFT STUD	
US	79-20-07	LIGHTER CIRCUIT BREAKER	
US	80-13-06	AIR DOOR CATCH ASSY ATTACH	
US	80-14-06	WING ATTACHMENTS	
US	80-17-02	ELEVATOR BALANCE WEIGHTS	
US	80-17-06	PLACARDS	
US	80-18-10	FUEL SELECTOR VALVES	
US	80-26-05	MLG DOOR HINGES	
US	82-16-05R1	TURBOCHARGER EXHAUST PIPE COUPLING	644C
US	82-27-13R2	FLAP EXTENSION SYSTEM	
US	85-08-05	STRUT HOUSING INSPECTION	
US	87-21-01	FUEL FILLER OPENINGS	797B
US	93-23-13	ENGINE COWLING BAFFLE SEALS	SB693/SL875
US	96-10-15	CRACKS AT WING STATION 147.5	SB 647A
US	96-12-12	FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04	SB 636A
US	96-21-11	MLG ACTUATOR REINFORCEMENT BRACKET	923
US	97-07-03	NOSE WHEEL	700A
US	98-08-18	ELEVATOR BUNGEE SPRING	626C
US	98-09-25	REPLACE LOWER SPAR SPLICE PLATE	1003
US	99-06-01	HORIZONTAL STABILIZER REAR SPAR	1007
US	99-12-05	INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING	998A
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
	050	( 0.01 0.0000	
PA31		( PA31 SERIES )	
US	74-26-10	SHUTTING DOWN ENGINE	
US	75-06-04	FORWARD RUDDER CONTROL CABLE	
US	75-09-10	PUSH-PULL RUBE END FITTINGS	
US	76-04-10	TOXIC FUMES	
US	76-04-11	LOOSE BOLTS	
US	76-15-07	ELEVATOR BALANCE WEIGHTS	
US	77-01-06	HORIZONTAL STABILIZER	
US	77-07-03	ELECTRICAL TERMINALS	
US	77-08-02	ELECTRICAL SHORT	
US	77-09-10	ELECTRIC TRIM SWITCH	
US	77-14-14	SKIN DEFORMATION & LOOSE/MISSING RIVE S	
US	77-19-06	AILERON CABLES	
US	77-24-01	STABILIZERS AND FINS	
US	78-01-02	ELEVATOR BUNGEE	
US	78-05-05	CABIN DOOR LATCH	
US	78-26-11	ELEVATOR CONTROL SYSTEM	
US	79-12-02	ELEVATOR SURFACE TRAVEL	
US	79-14-02	CONTROL WHEEL SHAFT STUD	
US	79-20-07	LIGHTER CIRCUIT BREAKER	
US	80-13-06	AIR DOOR CATCH ASSY ATTACH	
US	80-14-06	WING ATTACHMENTS	
US	80-17-02	ELEVATOR BALANCE WEIGHTS	
US	80-17-06	PLACARDS	
US	80-18-10	FUEL SELECTOR VALVES	
US	80-26-05	MLG DOOR HINGES	
US	82-16-05R1	TURBOCHARGER EXHAUST PIPE COUPLING	644C
US	82-27-13R2	FLAP EXTENSION SYSTEM	
US	85-08-05	STRUT HOUSING INSPECTION	
US	87-21-01	FUEL FILLER OPENINGS	7978
US	93-23-13	ENGINE COWLING BAFFLE SEALS	SB693/SL875
US	96-10-15	CRACKS AT WING STATION 147.5	SB 647A
US	96-12-12	FUSELAGE STATION BULKHEAD SUPERSEDES 80-22-04	SB 636A
US	96-21-11	MLG ACTUATOR REINFORCEMENT BRACKET	923
US	97-07-03	NOSE WHEEL	700A
US	98-08-18	ELEVATOR BUNGEE SPRING	626C
US	98-09-25	REPLACE LOWER SPAR SPLICE PLATE	1003
US	99-06-01	HORIZONTAL STABILIZER REAR SPAR	1007
US	99-12-05	INSPECT ELEVATOR SPAR FOR FATIGUE CRACKING	998A
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
DA24 4	350 T1020	( DAGA CEDIEC )	
	350 11020	( PA31 SERIES )	
PA31P		( PA31 SERIES )	
US	71-12-05	ELECTRIC TRIM SWITCH MOD	
US	74-26-10	SHUTTING DOWN ENGINE	
US	75-09-10	PUSH-PULL TUBE END FITTINGS	
US	75-16-02	RUDDER NOSE GEAR	
US	75-22-14	PROPELLER AIR DOME PRESSURE	
ATDO	RAFT/AERONEFS		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

	- HOMENO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
PIPER			
PASTE		( DAD+ CCDYCC )	
		( PA31 SERIES )	
US	NUED / SUITE)	1,0000	
US	76-04-11 76-06-09	LOOSE BOLTS	
US	76-06-09	ENGINE EXHAUST SYSTEM	
US	76-11-06	VIBRATION EFFECTS	
US	77-08-02	SWITCH BUS BAR LINK	
US	77-08-02	ELECTRICAL SHORT	
US	79-12-02	ELECTRIC TRIM SWITCH	
US	79-14-02	ELEVATOR SURFACE TRAVEL	
US	80-02-15	CONTROL WHEEL SHAFT STUD	
US	80-18-10	ELEVATOR BUTT RIB CRACKS	
US	80~26-05	FUEL SELECTOR VALVES	
US	81-23-06	MLG DOOR HINGES	
US	82-27-13R2	FLAP TRACK STRUCTURE	
US	85-02-05R1	FLAP EXTENSION SYSTEM	
US	85-05-01	BRAKE OPERATIONS	
US	85~08-05	INSPECTION OF F S 332 O BULKHEAD	
US	87-21-01	STRUT HOUSING INSPECTION	
US	96-21-11	FUEL FILLER OPENINGS	797B
US	97-07-03	MLG ACTUATOR REINFORCEMENT BRACKET	923
US	98-08-18	NOSE WHEEL	700A
US	99-14-01	ELEVATOR BUNGEE SPRING	626C
33	55 17 01	OPERATING IN SEVERE ICING CONDITIONS	
PA31T		( PA31 SERIES )	
US	75~16-02	RUDDER NOSE GEAR	
US	76-03-01	ELEVATOR TRIM TAB SYSTEM	
US	76-04-11	LOOSE BOLTS	
US	76-18-06	ELEVATOR STRUCTURE	
US	77-08-02	ELECTRICAL SHORT	
US	78-02-01	MAIN LANDING GEAR	
US	78-08-12	FLAP SYSTEM OPERATION	
US	78-12-06	NOSE LANDING GEAR WHEEL ASSY	
US	78-13-06	MAIN LANDING GEAR WHEEL ASSY	
US	79-12-02	ELEVATOR SURFACE TRAVEL	
US	79-14-02	CONTROL WHEEL SHAFT STUD	
US	79-19-09	ELECTROLUMINESCENT PANEL INVERTERS	
US	80-01-08	OIL COOLER INLET HOSE	
US	80-02-15	ELEVATOR BUTT RIB CRACKS	
US	80-11-06	AIRCRAFT DATA PLATE	1
US	80-14-08	AFM REVISION	
US	80-25-05	VOLTAGE REGULATOR MODIFICATION	
US	80-26-05	MLG DOOR HINGES	
US	81-01-01	PROPELLER DEICE RELAY	
US	81-23-06	FLAP TRACK STRUCTURE	
US	82-11-04	EMERGENCY EXIT WINDOW MODIFICATION .	
US	82-27-13R2	FLAP EXTENSION SYSTEM	
US	85-08-05	STRUT HOUSING INSPECTION	
US	96-10-13	HORIZONTAL STAB. STRUCTURE FAILURE	SB 773A
US	96-21-11	MLG ACTUATOR REINFORCEMENT BRACKET	923
US	97-26-12	POWER LEVERS POSITIONING BELOW FLIGHT IDLE STOP	
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
PA31T		( PA31 SERIES )	
US	78-02-01	MAIN LANDING GEAR	57A
US	79-12-02	ELEVATOR SURFACE TRAVEL	649
US	79-14-02	CONTROL WHEEL SHAFT STUD	651
US	79-19-09	ELECTROLUMINESCENT PANEL INVERTER	
US	80-01-08	OIL COOLER INLET HOSE	
US	80-02-15	ELEVATOR BUTT RIB CRACKS	658
US	80-11-06	AIRCRAFT DATA PLATE	
US	80-25-05	VOLTAGE REGULATOR MODIFICATION	
US	80-26-05	LANDING GEAR DOOR	
US	81-01-01	PROP & INTAKE DEICE	
US	81-23-06	RIB AND SPAR CRACKS	
US	82-11-04	EMERGENCY EXIT WINDOW	733
US	82-27-13R2	FLAP SYSTEM	
US	85-08-05	STRUT HOUSING INSP.	
US	96-10-13	HORIZONTAL STAB. STRUCTURAL FAILURE	773A
US	96-21-11	MLG ACTUATOR REINFORCEMENT BRACKET	923
US	97-26-12	POWER LEVERS POSITIONING BELOW FLIGHT IDLE STOP	
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	

MODEL / N		(SERIES / SERIE)	
ORIGINE	AD NUMBER NUMERO DE CONSIGNÉ	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
PIPER			
PA31T	2	( PA31 SERIES )	
US	82-11-04	EMERGENCY EXIT WINDOW MODIFICATION	
US	85-08-05	STRUT HOUSING INSPECTION	CD 7704
US US	96-10-13 96-21-11	HORIZONTAL STAB. STRUCTURE FAILURE MLG ACTUATOR REINFORCEMENT BRACKET	SB 773A 923
US	97-02-01	BRAKE CYLINDER CHAFING ON MLG	7034 REV B
US	97-26-12	POWER LEVERS POSITIONING BELOW FLIGHT IDLE STOP	
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
PA32	SERIES		
US	67-20-04	MAIN LANDING GEAR TORQUE LINK	
US	67-26-02	FUEL SELECTOR VALVE	
US US	68-01-03 80-14-03	FORWARD & REAR WING-TO-FUSELAGE FITTI GS BENDIX, KING OR NARCO TRANSMITTERS	
US	86-17-01	AMMETER TERMINAL POSTS	811A
US	95-26-13	OIL COOLER HOSE RUPTURES (SUPERSEDES 76-25-06)	3110
US	96-10-03	FLAP HANDLE ATTACH BOLT	SB 965
US	97-01-01R1	MAIN LANDING GEAR SIDEBRACE STUD CRACKS	
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
PA32 2		( PA32 SERIES )	
US	67-03-07	FUEL TANK SELECTOR VALVE	
US US	67-12-06	INSPECT TUBES FOR INTERNAL CORROSION	
US	67-26-03 69-15-01	FUEL SYSTEM SCREENS AND FILTERS CONTROL WHEEL PIN	
US	69-13-01	FAILURE OF CONTROL WHEEL	
US	70-18-05	LANDING GEAR TORQUE LINK BOLTS	
US	70-26-04	STABILATOR BALANCE WEIGHT TUBE	
US	71-09-05	FRONT SEAT BELT ATTACHING HARDWARE	
US	72-08-06	MAIN LANDING GEAR TORQUE LINKS	
US US	72-14-07	BOLTS IN STABILATOR HINGE FITTINGS	
US	72-17-05 74-09-02	ELECTRIC TRIM SWITCH STALL WARNING LIGHT	
US	74-18-13	NOSE GEAR VIBRATION	
ÜS	74-19-01	OUTER WING SPARS	
US	75-02-03	NOSE WHEEL FORK ASSEMBLY	
US	75-10-03	BAGGAGE DOOR	
US US	75-24-02	LOOSE SEATS	
US	76-18-04 77-01-01	FUEL VALVE FUEL QUANTITY GAGE	
US	77-12-01	FUEL SYSTEM	
US	77-23-03	ROD END BEARINGS	
US	78-23-01	FUEL DRAIN ASSEMBLY	
US	80-14-01	FUEL TANK VENT SYSTEM	
US	87-08-08R3	WING LOWER SPAR CAP (RESCINDED)	PIPER SL 997
US	99-05-09	INDUCTION AIR FILTER	1022
PA32 3		( PA32 SERIES )	
US	67-26-03	FUEL SYSTEMS SCREENS AND FILTERS	
US US	67-30-06 69-15-01	ENGINE AIR INDUCTION SYSTEM CONTROL WHEEL PIN	
US	69-22-02	FAILURE OF CONTROL WHEEL	
US	70-18-05	LANDING GEAR TORQUE LINK BOLTS	
US	70-26-04	STABILATOR BALANCE WEIGHT TUBE	
US	71-09-05	FRONT SEAT BELT ATTACHING HARDWARE	
US	72-08-06	MAIN LANDING GEAR TORQUE LINKS	
US	72-14-07	BOLTS IN STABILATOR HINGE FITTINGS	
US US	72-17-05 74-09-02	ELECTRIC TRIM SWITCH STALL WARNING LIGHT	***************************************
US	74-18-13	NOSE GEAR VIBRATION	
US	74-19-01	OUTER WING SPARS	
US	75-02-03	NOSE WHEEL FORK ASSEMBLY	
US	75-10-03	BAGGAGE DOOR	
US	75-24-02	LOOSE SEATS	
US US	76-18-04 77-01-01	FUEL VALVE	
US	77-12-01	FUEL QUANTITY GAGE FUEL SYSTEM	
US	77-23-03	ROD END BEARINGS	
US	78-23-01	FUEL DRAIN ASSEMBLY	
US	80-14-01	FUEL TANK VENT SYSTEM	
	80-14-02	THROTTLE CABLE	
US			
	87-08-08R3 99-05-09	WING LOWER SPAR CAP (RESCINDED) INDUCTION AIR FILTER	PIPER SL 997 1022

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
PIPER			
PA32	301T	( PA32 SERIES )	
PA32R	300	( PA32 SERIES )	
US	76-11-09	FUEL LEAKAGE	
US	76-15-08	NOSE GEAR TRUNNION	
US	76-18-04	FUEL VALVE	
US	77-23-03	ROD END BEARINGS	
US	78-16-08	LOSS OF ENGINE OIL	
US	78-23-01 80-14-01	FUEL DRAIN ASSEMBLY	
US	80-14-02	FUEL TANK VENT SYSTEM THROTTLE CABLE	
US	81-24-07	NLG MODIFICATION	
US	93-05-10	ENGINE MOUNT DRAG LINK	955
US	99-05-09	INDUCTION AIR FILTER	
PA32R	301	( PA32 SERIES )	
US	81-24-07	NLG MODIFICATION	
US	93-05-10	ENGINE MOUNT DRAG LINK	955
US	99-05-09	INDUCTION AIR FILTER	1022
	301T	( PA32 SERIES )	
US	80-17-10	THROTTLE MOVEMENT	
US US	81-24-07 93-05-10	NLG MODIFICATION	
03	93-05-10	ENGINE MOUNT DRAG LINK	955
PA32R1		( PA32 SERIES )	
US	78-22-07	CONTROL COLUMN TRAVEL	
US US	78-23-01 79-13-04	FUEL DRAIN ASSEMBLY	
US	79-26-04	FUEL LEAKAGE PREVENTION RUDDER SKIN CRACKS	
US	80-14-01	FUEL TANK VENT SYSTEM	
US	80-17-10	THROTTLE MOVEMENT	
US	80-20-05	TURBOCHARGER EXHAUST SYSTEM	
us	81-24-07	NLG MODIFICATION	
US	93-05-10	ENGINE MOUNT DRAG LINK	955
PA34 S	ERIES		
US	88-04-05	FORWARD BAGGAGE COMPARTMENT DOOR	633A, 633B, 872
US US	92-08-04	RUDDER SYSTEM	899
US	93-24-14 94-13-11	NLG TRUNNION BOLT AND STACK MAIN LANDING GEAR TRUNNION	7070
US	96-10-03	FLAP HANDLE ATTACH BOLT	787B SB 965
US	97-01-01R1	MAIN LANDING GEAR SIDEBRACE STUD CRACKS	
US	98-21-21	BOB FIELDS AEROCESSORIES STC	
PA34 2	00	( PA34 SERIES )	
US	72-14-07	BOLTS IN STABILATOR HINGE FITTINGS	
US	72-17-01	INDUCTION AIR BOX VALVE	
US	72-18-06	STABILATOR TIP BALANCE WEIGHTS	
US US	73-11-02 73-13-01	MAIN LANDING GEAR SUPPORT STRUCTURE	
US	73-13-01	RUDDER TRIM TAB CRACKS IN EXHAUST SYSTEM	
US	74-17-08	FUEL LINE CLAMPS	
US	74-19-01	OUTER WING SPARS	
US	75-20-03	USABLE FUEL DATA	
US US	75-24-02	LOOSE SEATS	
US	77~23-03 80-09-04	ROD END BEARINGS VERTICAL FIN AND STABILATOR ATTACH	
US	83-14-05	HEAT EXCHANGER/TAILPIPE ASSYS	
US	92-13-05	NLG CENTERING SPRING ASSY BOLT	893
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
PA34 2	ООТ	( PA34 SERIES )	
US	75-20-03	USABLE FUEL DATA	
US	75-24-02	LOOSE SEATS	
US	75-25-03	ENGINE OIL	
US US	77-23-03	ROD END BEARINGS FUEL LINES	
	78-21-03 80-09-04	VERTICAL FIN AND STABILATOR ATTACH	
	80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
	86-17-01	AMMETER TERMINAL POSTS	811A
US	92-13-05	NLG CENTERING SPRING ASSY BOLT	893
	99-05-09	INDUCTION AIR FILTER	1022
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
1022
***************************************
828
828
***************************************
686
673B ACS SB 92-01 686

		(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETI
PIPER			BULLETIN DE SERVICE DE REF
PA39			
	NUED / SUITE)		
US US	83-19-03	LOWER SPAR CAP INSPECTION	751
US	85-02-05R1 94-13-10	BRAKE OPERATIONS	
US	97-01-01R1	STABILATOR TORQUE TUBE BEARING SUPPORT FITTINGS	411A
US	98-21-21	MAIN LANDING GEAR SIDEBRACE STUD CRACKS BOB FIELDS AEROCESSORIES STC	
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
PA42			
US	90-02-11	AFM AMENDMENT - ENGINE OVERHAUL PERIODS	
US	96-21-03	INBUARD AILERON HINGE BRACKET CRACKS	SB974, SB967
US US	96-21-04 97-26-12	HYDRAULIC HOSES (SUPERSEDES 86-17-07)	822
US	99-14-01	POWER LEVERS POSITIONING BELOW FLIGHT IDLE STOP OPERATING IN SEVERE ICING CONDITIONS	
A42	720	TO SEVERE TOTAL CONDITIONS	
US	97-26-12	POWER LEVERS POSITIONING BELOW FLIGHT IDLE STOP	
US	99-14-01	OPERATING IN SEVERE ICING CONDITIONS	
A44	SERIES		
US	94-13-11	MAIN LANDING GEAR TRUNNION	7070
US	94-14-14	INSTALLATION OF NOSE LANDING GEAR MOD KIT	787B
US	96-10-03	FLAP HANDLE ATTACH BOLT	SL 988 SB 965
US	98-21-21	BOB FIELDS AEROCESSORIES STC	30 303
Δ44	180	( PA44 SERIES )	
US	79-02-02	FUEL SUPPLY LINES	
US	79-05-11	ENGINE POWER CONTROL LOSS	
US	79-12-11	FUEL PRIMER MOD KITS	
US	80-12-03	NOSE LANDING GEAR	
US US	80-14-03	BENDIX, KING OR NARCO TRANSMITTERS	
US	80-21-11 81-10-01	LEFT AND RIGHT AILERONS	
US	81-10-04	NOSE CONE SPARS AILERON MODIFICATION	
US	81-16-10	OUTBOARD LEADING EDGE SKIN	
US	85-02-05R1	BRAKE OPERATIONS	
A44	180T	( PA44 SERIES )	
US	81-16-10	OUTBOARD LEADING EDGE SKIN	
US	85-02-05R1	BRAKE OPERATIONS	
US	86-20-11	AMMETER TERMINAL POSTS	847
	SERIES		
US	92-18-08	BENDIX/KING KAP 150/KFC 150 FLIGHT CONTROL SYSTE	
US	96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
446 3		( PA46 SERIES )	
US	87-04-01	ALTERNATE AIR VALVE	PSL 985
US US	88-25-08 92-13-06	ENGINE COOLING SYSTEM  JAMMED TRIM TAB	892
JS	92-13-07	EMPENNAGE RIVETS	953 944
JS	92-15-14	VACUUM SYSTEM	947A
US	98-04-26	OPERATING IN SEVERE ICING CONDITIONS	AWD
US	99-15-04	IMPROPERLY CALIBRATED OR DEFECTIVE TEMP PROBES	
A46 3	50P	( PA46 SERIES )	
us	92-13-06	JAMMED TRIM TAB	953
US	92-13-07	EMPENNAGE RIVETS	944
US US	92-15-14	VACUUM SYSTEM	947A
JS JS	95-23-12	MANIFOLD PRESSURE LIMITS PLACARD	982
JS	98-04-26 99-15-04	OPERATING IN SEVERE ICING CONDITIONS  IMPROPERLY CALIBRATED OR DEFECTIVE TEMP PROBES	AWD
US	99-16-06	PREVENT THE POT. FAILURE OF WING ATTACH FITTINGS	1027
PER A	EROSTAR		
460 S	ERIES	45M 4 POLL	
US IS	83-14-07R3	AFM & POH	0.40
US US	87-07-09 87-21-01	EXHAUST SYSTEM FUEL FILLER OPENINGS	818 797B
JS	88-21-05	INFLIGHT ENGINE FIRE	1310
JS	88-25-02	FLUID CARRYING HOSES & ASSOCIATED EQUIPMENT	761, 815
US	89-03-04	UPPER CABIN DOOR	600-74, 980
LIC	00 01 00		

90-01-02

US

920

TURBOCHARGER TAILPIPE ASSY - FIRE DETECTION KIT

	ONSTRUCTEUR / MODELE	(SEDIES (SEDIE)	
ORIGIN	N AD NUMBER	(SERIES / SERIE) SUBJECT E SUJET	REFERENCE SERVICE BULLETIN
Gillion	VE NOMERO DE CONSTON	20051	BULLETIN DE SERVICE DE REF
	AEROSTAR		
	SERIES INUED / SUITE)		
US	93-13-08	MLG TORQUE LINKS	7400
US	94-15-13	NOSE LANDING GEAR DRAG BRACE	746C 600-128
US	95-23-11	HORIZONTAL STAB. CRACKED ATTACH FITTINGS	SB600-130
US US	98-04-23 98-21-21	SEVERE ICING CONDITIONS	AWD
US	98-24-29	BOB FIELDS AEROCESSORIES STC WING UPPER SPAR CAP	600 400
			600-132
PA60		( PAGO SERIES )	
US US	70-23-04 70-23-05	WING FLAP TRACKS FUEL PRESSURE INDICATORS	600-22A
US	70-25-09	MICROPHONE JACK CONNECTION	600-28
US	71-02-05	MAIN CABIN DOOR LOCK PINS	600-26
US	71-05-06	MAIN LANDING GEAR	
US US	71-10-02 71-17-07	OVER VOLTAGE RELAY GROUND	
US	74-25-02	WING FLAP ATTACHMENT RIB  ELECTRICAL ATTITUDE/DIRECTIONAL GYROS	
US	78~18-05	LH AND RH FUEL QUANTITY INDICATOR	
US	79-01-05	FUEL STARVATION	
US US	79-08-05 79-18-10	ENGINE NACELLES	
US	80-12-14	CABIN DOOR LATCHING MECHANISM ENGINE FIRE	
US	80-19-14	HORIZONTAL / VERTICAL STABILIZER	
D. 4.00			
PA60 US	70-23-04	( PAGO SERIES )	
US	70-23-04	WING FLAP TRACKS FUEL PRESSURE INDICATOR	600-22A
US	70-25-09	MICROPHONE JACK CONNECTION	600-28 600-26
US	71-02-05	MAIN CABIN DOOR LOCK PINS	000-26
US US	71-05-06 71-10-02	MAIN LANDING GEAR	
US	71-10-02	OVER VOLTAGE RELAY INBOARD WING FLAP ATTACHMENT	
US	74-25-02	ELECTRICAL ATTITUDE/DIRECTIONAL GYROS	
US	78-18-05	LH & RH FUEL QUANTITY INDICATOR	
US US	79-01-05 79-08-05	FUEL STARVATION	
US	79-08-05	ENGINE NACELLES CABIN DOOR LATCHING MECHANISM	600-80
US	80-12-14	ENGINE FIRE	
US	80-18-03	FUEL PRESSURE SYSTEM	
US	80-19-14	HORIZONTAL/VERTICAL STABILIZER	600-88A
PA60	601P	( PAGO SERIES )	
US	71-10-02	OVER VOLTAGE RELAY	
US US	74-25-02	ELECTRICAL ATTITUDE/DIRECTIONAL GYROS	
US	78-18-05 79-01-05	LH AND RH FUEL QUANTITY INDICATOR FUEL STARVATION	
US	79-08-05	ENGINE NACELLES	
US	80-12-14	ENGINE FIRE	
US US	80-18-03 80-19-14	FUEL PRESSURE SYSTEM	
05	80 13-14	HORIZONTAL / VERTICAL STABILIZER	
PA60	602P	( PAGO SERIES )	
PITTS			
S1S			
US	76-16-08	RUDDER CONTROL #1	
US	96-10-12	FLIGHT CONTROL STICK WALL THICKNESS	SB 23
US	96-12-03R2	FUSELAGE WING ATTACH FITTING CRACKS	25
S1T			
US	96-10-12	FLIGHT CONTROL STICK WALL THICKNESS	5B 00
US	96-12-03R2	FUSELAGE WING ATTACH FITTING CRACKS	SB 23 25
S2A			
US	61-14-06	CONTROL CARLES	
US	63-05-03	CONTROL CABLES WING MAIN SPAR WEB FLANGES	
US	66-14-01	WING LOWER SPAR CAPS	
US	72-19-02	AILERON INTERCONNECT TUBES #1	
US	72-19-05 73 <b>-</b> 07 <b>-</b> 06	HORIZONTAL STABILIZER SUPPORT TUBE #1	
US	73-16-06	HORIZONTAL STABILIZER SUPPORT TUBE #1 INDUCTION AIR BOX FLAPPER DOOR #1	
US	76-16-08	RUDDER CONTROL #1	
US	85-01-04	COCKPIT CONTROL TUBE ASSY #1	
4700	DAFT (AFDONESS		

	MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE)			
ORIGIN ORIGINE	AD NUMBER	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.	
PITTS			DOCE THE DE SERVICE DE REF.	
S2A (CONTI	NUED / SUITE)			
US	96-09-08R1	LONGERON CRACKS		
US US	96-10-12	FLIGHT CONTROL STICK WALL THICKNESS	SB 24 SB 23	
US	96-12-03R2 97-26-20	FUSELAGE WING ATTACH FITTING CRACKS LONGERON CRACKS	25	
\$2B		ZONGENON CRACKS	SB 24	
US	63-05-03	WING MAIN SPAR WEB FLANGES		
US	66-14-01	WING LOWER SPAR CAPS		
US US	96-09-08R1 96-10-12	LONGERON CRACKS FLIGHT CONTROL STICK WALL THICKNESS	SB 24	
US	96-12-03R2	FUSELAGE WING ATTACH FITTING CRACKS	SB 23 25	
US	97-26-20	LONGERON CRACKS	SB 24	
PORTER. CP65	FIELD			
PZL	•••••••••••••••••••••••••••••••••••••••			
KR 03.	A BI-31/KR-03A/95	A IDMODITATING CONDECTIVITY		
PL	BZ-32/KR-03A/95	AIRWORTHINESS DIRECTIVES ISSUED IN 1994 INTRODUCTION OF CHANGES TO MM AND REPAIR MANUAL		
PL PL	BE-34/KR-03A/96 SP-0048-1999-A	CRACKS IN AIR BRAKE ARM		
		ACTUAL FLYING HOURS RECORDED	BE-35/KR-03A/99	
M 18 :	CF-95-09	CDACKING DE VEDTOAL EST		
PL	K/02.126/89	CRACKING OF VERICAL FIN REAR SPAR PIPE - TWO-POSITION FUEL SELECTOR VALVE	E/02.051/83 K/02.126/89	
PL PL	K/02.127/89 K/02.132/89	PUSH-PULL CABLES - CARBURETTOR / PROPELLER	K/02.127/89	
PL	K/02.141/90	AILERON ATTACH HINGES ELECTRO HYDRAULIC CONTROL SYSTEM & FLEX OIL LINES	K/02.132/89 K/02.141/90	
PL PL	E/02.142/91 E/02.151/94	AIRCRAFT SERVICE LIFE	E/02.142/91	
PL	E/02.151/94 E/02.152./94	DESCRIPTIVE OPERATIONAL DOCUMENTATION SUPP. AIRCRAFT LIFE EXTENSION	E/02.151/94 E/02.152./94	
M 18		( M 18 SERIES )		
PL	E/1921/80	SPECIFICATIONS FOR PZL M 18 FLIGHT MANUAL	E/1921/80	
PL PL	E/1925/80 U/1846/80	CHANGES IN PZL M 18 FLIGHT MANUAL FUEL LINE	E/1925/80	
PL	U/1859/80	REPLACEMENT OF FUEL LINES	U/1846/80 U/1859/80	
PL PL	U/1922/80 U/1923/80	DESIGN MODIFICATIONS BRAKE HYDRAULIC LINES	U/1922/80	
PL	U/1924/80	ELEVATOR CONTROL SYSTEM	U/1923/80 U/1924/80	
PL PL	U/1926/80 E/011/81	TAIL WHEEL HUB FLIGHT MANUAL CHANGES	U/1926/80	
PL	E/017/81	AMENDMENT - AIRCRAFT DESCRIPTION & SERVICE MANUAL	E/011/81 E/017/81	
PL PL	E/020/81 E/021/81	FLT MANUAL SUPP # 1 - OVERLOAD OPERATION FLIGHT MANUAL AMENDMENTS	E/020/81	
PL	E/023/81	AFM SUPPLEMENT #1	E/021/81 E/023/81	
PL PL	E/024/81 E/025/81	AMENDMENT - AIRCRAFT DESCRIPTION & SERVICE MANUAL RUDDER SKIN INSPECTION	E/024/81	
PL	R/028/81	RUDDER REPAIR	E/025/81 R/028/81	
PL PL	U/009/81 U/010/81	FUEL, HYDRAULIC SYSTEMS AND OTHER ASSEMBLIES	U/009/81	
PL	U/012/81	SECURING OF COUNTERWEIGHTS PUSH RODS - AILERON CONTROL SYSTEM	U/010/81 U/012/81	
PL PL	U/013/81		U/013/81	
PL	U/014/81 U/018/81		U/014/81 U/018/81	
PL PL	U/019/81	COUNTERWEIGHTS BALANCING SLUGS	U/019/81	
PL	U/026/81 E/033/82	ENGINE MOUNT LUG BOLTS  AMENDMENT - AIRCRAFT DESCRIPTION & SERVICE MANUAL	U/026/81 E/033/82	
PL	E/034/82	MLG SHOCK STRUT FLT MANUAL AMENDMENTS # 18 & 19	E/034/82	
PL PL	E/039/82 E/043/82	UPDATING - AIRPLANE DESCRIPTION & SERVICE MANUAL	E/039/82 E/043/82	
PL	E/048/82	FLAPS COUPLER REPLACEMENT	E/048/82	
PL PL	K/032/82 K/045/82		K/032/82 K/045/82	
PL	U/029/82	SHUT-OFF VALVE	U/029/82	
PL PL	U/035/82 U/044/82		U/035/82 U/044/82	
PL	U/047/82	SUPP #1 MSB U/044/82 - BOLT WHEEL BRAKING SYSTEM	U/047/82	
PL PL	E/02.051/83 K/02.052/83		E/02.051/83 K/02.052/83	
PL	K/02.053/83		K/02.053/83	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

0.71		
PZL M 18 ( M	18 SERIES )	
(CONTINUED / SUITE)		***************************************
PL K/02.060/83 PL E/02.062/84	ENGINE FRAME REPLACEMENT REVISION - AIRPLANE DESCRIPTION & SERVICE MANUAL	K/02.060/83 E/02.062/84
PL E/02.064/84	DESIGN CHANGES - ENGINE FRAME & CONTROL SYSTEM	E/02.062/84 E/02.064/84
PL K/02.067/84	TORQUE TUBE - THROTTLE CONTROL SYSTEM	K/02.067/84
PL K/02.070/84 PL E/02.082/85	SUPP TO MSB K/O2.060/83 PUSH PULL CABLE REPLACMENT	
PL K/02.079/85	ENGINE FRAME SHOCK ABSORBER SUP TO K/02.060/83 STARTING SWITCH LOCATION CHANGE	E/02.082/85
PL E/02.090/86	REVISIONS - AIRPLANE SERVICE DESCRIPTION DOCUMENTS	
PL E/02.098/86 PL K/02.095/86	SUPP TO MSB E/02.082/85 ENG FRAME SHOCK ABSORBER	E/02.098/86
PL K/02.095/86	THROTTLE CONTROL LEVER SAFETY BELT BUCKLE	K/02.095/86 K/02.116/87
PL K/02.124/88	CONTROL STICK LOCKING MECHANISM	K/02.124/88
PL K/02.135/89	FIN - RUDDER UPPER JOINT ATTACH AREA	K/02.135/89
M 18A ( M	18 SERIES )	
M 18B ( M	18 SERIES )	
SZD 30		
PL BE-027/87 PL BS-033/93	LIFE LIMITS INSP OF GLUE JOINTS ON RECTANGULAR WINGPORTION	BE-027/87
PL B5-033/93	INSP OF GLUE JUINIS ON RECTANGULAR WINGPORTION	BS-033/93
SZD 36A		
SZD 41A	LITALO COLO COCT. DAN DECLA COLO	
CF CF-93-13R2 PL BE-08/79	WING SPAR ROOT PIN REPLACEMENT LIFE LIMITS TO 1500 HRS	TELEX POLISH CAA BE-08/79
PL BA-011/81	RUDDER SAFETY PIN / CENTRAL RIB	BA-011/81
PL BE-026/86	EXTENSION OF LIFE LIMITS TO 3000 HRS	BE-026/86
PL BE-027/86 PL BR-032/87	STEEL CABLES RUDDER CONTROL SYSTEM WING TO FUSELAGE CONNECTION	BE-027/86
PL BE-045/93	CANCELATION OF 1000 HOUR INSP AFTER 6 YEARS	BR-032/87 BE-044 PARA 3.2
C7D 40 4 .		
SZD 48 1 · PL BE-08/79	LIFE LIMITS TO 1500 HRS	BE-08/79
PL BA-011/81	RUDDER SAFETY PIN / CENTRAL RIB	BA-011/81
PL BE-023/85 PL BE-026/86	TOST EUROPA G 62 SELF-RELEASING TOW HOOK	BE-023/85
PL BE-027/86	EXTENSION OF LIFE LIMITS TO 3000 HRS STEEL CABLES RUDDER CONTROL SYSTEM	BE-026/86 BE-027/86
PL BR-032/87	WING TO FUSELAGE CONNECTION	BR-032/87
PL BE-045/93	CANCELATION OF 1000 HOUR INSP AFTER 6 YEARS	BE-044 PARA 3.2
SZD 50 3 PL BE-12/50-3/83	DUDDED DOV LIGHT AT HODER HATHER DOLT	25 12/22 2/22
PL BK-10/50-3/83	RUDDER BOX HOLE AT UPPER HINGE BOLT LEVER HOUSING AILERON CONTROL SYSTEM	BE-12/50-3/83 BK-10/50-3/83
PL BK-25/50-3/84	LUGS - CANOPY FRAME CROSS-ROD	BK-25/50-3/84
PL BK-26/50-3/84 PL BE-28/50-3/86	ELEVATOR FITTING ALLOWABLE PLAY	BK-26/50-3/84
PL BE-28/50-3/86 PL BE-29/50-3/86	NEW EDITION FLIGHT MANUAL TECHNICAL SERVICE MANUAL REVISION	BE-28/50-3/86 BE-29/50-3/86
PL BE-30/50-3/86	EXTENSION OF FLIGHT LIMITATIONS	BE-30/50-3/86
PL BE-31/50-3/86	TECHNICAL SERVICE MANUAL EXTENSION	BE-31/50-3/86
PL BE-34/50-3/87 PL BK-33/50-3/87	EXTENSION OF LIFE LIMITS TO 6000 HRS  SPARS CONNECTING PIN	BE-34/50-3/87 BK-33/50-3/87
PL BE-37/50-3/89	MARKINGS FOR AEROBATIC AC-SEE BE-30/50-3/86	BE-37/50-3/89
PL BE-38/50-3/89 PL BE-39/50-3/89	TRIM TAB CONTROL CABLE PULLEY	BE-38/50-3/89
PL BE-39/50-3/89 PL BR-40/50-3/90	RUDDER UPPER HINGE RIB LIGHTENING HOLE TAILPLANE SECURING PIN REPLACEMENT	BE-39/50-3/89 BR-40/50-3/90
PL BA-047/50-3/94	STOP SCREWS ON AIR BRAKE ARM DISTANCE SLEEVES LOOS	DR 40/30-3/30
SZD 55 1		
CK BE/R-10/55-1/96	LIFE EXTENSION TO 3000 FLYING HOURS	
SZD 59 PL BK-003/SZD-59/96	TOM CHANCE TOOLS 4 TO TOOLS	
PL BK-003/SZD-59/96 PL BK-004/SZD-59/97	TSM CHANGE ISSUE 1 TO ISSUE 2 RUDDER MODIFICATION	***************************************
PL BE-006/SZD-59/98	LIFE LIMITATIONS	
PL SP-0032-1999-A	ELEVATOR ACTUATING LEVER, IN FUSELAGE AFT PORTION	BE-008/SZD-59/99
PZL 104 PL 10481004	INTRODUCTION - LITERABLE & STAFF COAS	40404004
PL 10481004	INTRODUCTION - LIFTABLE & FIXED SKIS FUEL TANKS FILLER PLUGS	10481004 10481005
PL 10481006	AZRGK TYPE ELECTRICAL SWITCHES	10481006
ATROPACT /ACRONICES		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET		REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
PZL				
PZL 1	04			
(CONTI	NUED / SUITE)			
PL PL	10481008 10483011	WING FUEL TANK GUAGE	S TUBES	10481008
PL	10483012	CABLE COMPONENTS LIF		10483011
PL PL	10485014	M-9F MAGNETOS ON AI-	14RA ENGINES	10483012 10485014
PL	10488015 10488016	SHOULDER HARNESS - L AIRFRAME SERVICE LIF	PPER FERRULE	10488015
PL	10489017	REVISIONS - FLT MAN.	MAINT MAN & SCHEDULED INSPS	10488016 10489017
PL PL	10490018 10493023	AIRFRAME SERVICE LIF	E	10490018
PL	10496025	AIRFRAME SERVICE LIF	WARNING SYSTEM SWITCH	10493023 10496025
PL	1194168	REVISION TO TBO AND	OPERATIONAL LIFE	1194168
PZL BI	ELSKO			
SZD 5				
PL PL	BE-001/85 BE-009/93	REV. TO FLIGHT MANUA	L & TECH MANUAL LANE MOUNTING SLEEVE	BE-001/85
		NEI ENGENENT OF TAILE	LANE MOUNTING SLEEVE	BE-009/93
PZL SW. PW 5	IDNIK SA			
RAVEN RX6			SEE/VOIR: AEROSTAR	
RX7 SI	ERIES			
RX7		( RX7 SERIES )	SEE/VOIR: AEROSTAR	
S55A S	SERIES		SEE/VOIR: AEROSTAR	
\$55A		( S55A SERIES )	SEE/VOIR: AEROSTAR	
	SERIES		SEE/VOIR: AEROSTAR	
S60A		( S60A SERIES )	SEE/VOIR: AEROSTAR	
S66A			SEE/VOIR: AEROSTAR	
S77A			SEE/VOIR: AEROSTAR	
REARWIN 185	<u> </u>			
REIMS A	IVIATION			
FR	71-092	AFT ENG STOPPAGE ON I		71-21
FR FR	72-041 77-092-IMP(A)	ELEVATOR PITCH CHANGE SINGLE ENGINE TAKEOFE		77-8
FR	78-113-IMP(A)		EB DOUBLERS	78-2
FR FR	79-155-IMP(A) 87-045(A)	FUEL FILLER CAP		77-6
FR	88-123(A)	SHOULDER HARNESS SEAT RAILS		83-6
FR	96-188-IMP(A)	OIL FILTER ADAPTER		00.04
FR	97-050(AB)	FLUID SYSTEMS		96-21
FT337G		AET CAICTAIN CTORS OF	201   157055	74 04
FR FR	71-092 72-041	AFT ENGINE STOPPAGE C ELEVATOR PITCH HORN A		71-21
FR	77-092-IMP(A)	SINGLE ENGINE TAKEOFF		77-8
FR FR	78-113-IMP(A) 79-155-IMP(A)	WING SPAR CAPS AND WE FUEL FILLER CAP	B DOUBLERS	78-2 77-6
FR	87-045(A)	SHOULDER HARNESS		
FR FR	88-123(A) 96-188-IMP(A)	SEAT RAILS OIL FILTER ADAPTER		83-6
FR	97-050(AB)	FLUID SYSTEMS		96-21
REPUBLI	С			
RC 3 CF	CF-57-13	FUEL CELL INSPECTION		
US	47-21-11	FIREWALL STUDS		1
US US	47-21-12 47-21-13	NO SMOKING DECAL ELEVATOR CONTROL		3
US	47-21-14	ELEVATOR CABLE		14

MODEL	15 7 2 11 SN 10 13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23 25
RC 3	7 2 11 SN 10 13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
RC 3 (CONTINUED / SUITE)  US 47-21-15 RADIO FILTER  US 47-21-16 FUEL DRAIN  US 47-21-17 BACKFIRE SCREEN  US 47-21-19 FLEXIBLE CONTROLS  US 47-21-20 OIL PRESSURE LINE  US 47-21-21 FLOAT STRUT  US 47-21-22 ENGINE MOUNTING BOLTS  US 47-21-23 ENGINE COOLING FANS  US 47-47-10 WING REINFORCING ANGLES  US 47-47-11 PROP REVERSE CONTROL  US 47-47-12 CARB HEAT  US 47-47-13 PROP COUNTERVEIGHT  US 47-47-14 SUMP OIL INLET SCREEN  US 47-47-14 SUMP OIL INLET SCREEN  US 47-47-03 ELEVATOR TRIM TAB  US 48-01-03 ELEVATOR TRIM TAB  US 48-01-03 FUEL PUMPS  US 49-03-01 FUEL PUMPS  US 49-03-03 WING STRUT CORROSION	7 2 11 SN 10 13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-21-15	7 2 11 SN 10 13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-21-16 FUEL DRAIN US 47-21-17 BACKFIRE SCREEN US 47-21-18 MIXTURE CONTROL US 47-21-19 FLEXIBLE CONTROLS US 47-21-20 DIL PRESSURE LINE US 47-21-21 FLOAT STRUT US 47-21-22 ENGINE MOUNTING BOLTS US 47-21-23 ENGINE COOLING FANS US 47-47-10 WING REINFORCING ANGLES US 47-47-11 PROP REVERSE CONTROL US 47-47-12 CARB HEAT US 47-47-13 PROP COUNTERWEIGHT US 47-47-14 SUMP DIL INLET SCREEN US 47-47-14 SUMP DIL INLET SCREEN US 47-51-08 TAILWHEEL CONTROL CABLE US 48-01-03 ELEVATOR TRIM TAB US 48-11-04 HYDRAULIC PUMP HANDLE US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION	7 2 11 SN 10 13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-21-17 BACKFIRE SCREEN US 47-21-18 MIXTURE CONTROL US 47-21-19 FLEXIBLE CONTROLS US 47-21-20 OIL PRESSURE LINE US 47-21-21 FLOAT STRUT US 47-21-22 ENGINE MOUNTING BOLTS US 47-21-23 ENGINE COOLING FANS US 47-47-10 WING REINFORCING ANGLES US 47-47-11 PROP REVERSE CONTROL US 47-47-12 CARB HEAT US 47-47-13 PROP COUNTERWEIGHT US 47-47-14 SUMP OIL INLET SCREEN US 47-47-14 SUMP OIL INLET SCREEN US 47-51-08 TAILWHEEL CONTROL CABLE US 48-01-03 ELEVATOR TRIM TAB US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION	2 11 5N 10 13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1
US 47-21-18 MIXTURE CONTROL  US 47-21-19 FLEXIBLE CONTROLS  US 47-21-20 OIL PRESSURE LINE  US 47-21-21 FLOAT STRUT  US 47-21-23 ENGINE MOUNTING BOLTS  US 47-27-10 WING REINFORCING ANGLES  US 47-47-11 PROP REVERSE CONTROL  US 47-47-12 CARB HEAT  US 47-47-13 PROP COUNTERWEIGHT  US 47-47-14 SUMP OIL INLET SCREEN  US 47-51-08 TAILWHEEL CONTROL CABLE  US 48-01-03 ELEVATOR TRIM TAB  US 49-03-01 FUEL PUMPS  US 49-31-02 FUEL TANK CAPACITY  US 53-23-03 WING STRUT CORROSION	11 SN 10 13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71
US 47-21-20	13 12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71
US 47-21-21 FLOAT STRUT US 47-21-22 ENGINE MOUNTING BOLTS US 47-21-23 ENGINE COOLING FANS US 47-47-10 WING REINFORCING ANGLES US 47-47-11 PROP REVERSE CONTROL US 47-47-12 CARB HEAT US 47-47-13 PROP COUNTERWEIGHT US 47-47-14 SUMP OIL INLET SCREEN US 47-51-08 TAILWHEEL CONTROL CABLE US 48-01-03 ELEVATOR TRIM TAB US 48-01-04 HYDRAULIC PUMP HANDLE US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION	12 47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-21-22 ENGINE MOUNTING BOLTS  US 47-21-23 ENGINE COOLING FANS  US 47-47-10 WING REINFORCING ANGLES  US 47-47-11 PROP REVERSE CONTROL  US 47-47-12 CARB HEAT  US 47-47-13 PROP COUNTERWEIGHT  US 47-47-14 SUMP OIL INLET SCREEN  US 47-51-08 TAILWHEEL CONTROL CABLE  US 48-01-03 ELEVATOR TRIM TAB  US 48-11-04 HYDRAULIC PUMP HANDLE  US 49-03-01 FUEL PUMPS  US 49-31-02 FUEL TANK CAPACITY  US 53-23-03 WING STRUT CORROSION	47 57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71
US 47-47-10 WING REINFORCING ANGLES US 47-47-11 PROP REVERSE CONTROL US 47-47-12 CARB HEAT US 47-47-13 PROP COUNTERWEIGHT US 47-47-14 SUMP OIL INLET SCREEN US 47-51-08 TAILWHEEL CONTROL CABLE US 48-01-03 ELEVATOR TRIM TAB US 48-11-04 HYDRAULIC PUMP HANDLE US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION	57 19 21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-47-11 PROP REVERSE CONTROL US 47-47-12 CARB HEAT US 47-47-13 PROP COUNTERWEIGHT US 47-47-14 SUMP OIL INLET SCREEN US 47-51-08 TAILWHEEL CONTROL CABLE US 48-01-03 ELEVATOR TRIM TAB US 48-11-04 HYDRAULIC PUMP HANDLE US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION	21 18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-47-12 CARB HEAT  US 47-47-13 PROP COUNTERWEIGHT  US 47-47-14 SUMP OIL INLET SCREEN  US 47-51-08 TAILWHEEL CONTROL CABLE  US 48-01-03 ELEVATOR TRIM TAB  US 48-11-04 HYDRAULIC PUMP HANDLE  US 49-03-01 FUEL PUMPS  US 49-31-02 FUEL TANK CAPACITY  US 53-23-03 WING STRUT CORROSION	18 58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-47-13 PROP COUNTERWEIGHT US 47-47-14 SUMP OIL INLET SCREEN US 47-51-08 TAILWHEEL CONTROL CABLE US 48-01-03 ELEVATOR TRIM TAB US 48-11-04 HYDRAULIC PUMP HANDLE US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION	58 17, SUPP. 2 20, SUPP. 1 22 71 23
US 47-51-08 TAILWHEEL CONTROL CABLE US 48-01-03 ELEVATOR TRIM TAB US 48-11-04 HYDRAULIC PUMP HANDLE US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION  ROBIN	17, SUPP. 2 20, SUPP. 1 22 71 23
US 48-01-03 ELEVATOR TRIM TAB  US 48-11-04 HYDRAULIC PUMP HANDLE  US 49-03-01 FUEL PUMPS  US 49-31-02 FUEL TANK CAPACITY  US 53-23-03 WING STRUT CORROSION  ROBIN	20, SUPP. 1 22 71 23
US 48-11-04 HYDRAULIC PUMP HANDLE US 49-03-01 FUEL PUMPS US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION  ROBIN	22 71 23
US 49-31-02 FUEL TANK CAPACITY US 53-23-03 WING STRUT CORROSION  ROBIN	71 23
US 53-23-03 WING STRUT CORROSION  ROBIN	
ROBIN	25
R2160 SEF/VOIR DIERRE PORTN	
R2160 SEE/VOIR: PIERRE ROBIN	
ROBINSON	
R22 SERIES  CF CF-96-08 CHANGES TO AIRCRAFT FLIGHT MANUAL	CURERARES
CF CF-98-15 HELICOPTER RESCUE SYSTEMS	SUPERCEDES 95-26-04 CAR 702.21
US 80-11-07 MAIN ROTOR BLADES	
US 80-21-53 MAIN TRANSMISSION GEARS US 80-24-01 TAILCONE	5
US 80-24-01 TAILCONE US 80-26-06 TAIL ROTOR PLATE	4
US 81-05-52R1 MAIN GEAR BOX	6 SL 9
US 82-03-07 MAIN ROTOR BLADES	
US 82-11-01 STEEL TUBE FRAME US 82-15-07 TAIL ROTOR DRIVE SHAFT	18
US 83-15-07R1 MAIN ROTOR BLADE INSPECTION	
US 84-18-04 MAIN ROTOR GEARBOX	
US 87-18-03 MAIN ROTOR PITCH LINK ASSEMBLY US 88-26-01R2 A158-1 MAIN ROTOR SPINDLE & A106 JOURNAL	
US 88-26-01R2 A158-1 MAIN ROTOR SPINDLE & A106 JOURNAL US 90-17-01 CARB. AIRBOX LATCH REMOVAL	60 TECHNICAL REPORT
US 92-06-17 BOLT FAILURES P/N NAS1304-16 STAMPED 'AF'	69
US 94-15-08 MAIN ROTOR BLADE INSPECTION	72
US 95-06-03 MAIN ROTOR MAST SEPARATION-SPANNER NUTS US 95-11-09 PLACARD AGAINST LOW G CYCLIC PUSHOVER	CD
US 95-23-05 TAIL ROTOR OUTPUT KEY (SUPERSEDES AD 94-17-07)	SB-79
US 96-09-29 V BELT SHEAVE P/N A170-11 OR J OR A170 -2J	SB-77
US 97-02-14 PILOT MISMANAGEMENT OF ROTOR RPM US 97-25-05 MIXTURE CONTROL TOLE CUITOFE	SUPERCEDES 96-11-08
US 97-25-05 MIXTURE CONTROL IDLE CUTOFF US 98-21-09 FUEL TANK VENTS	SB 82 SB-83
US 99-02-02 FLEXPLATE FAILURE (SUPERSEDES 95-06-07 98-14-08)	75
US 99-07-17 SPRAG CLUTCH ASSEMBLY	85
R22 ( R22 SERIES )	
R22 BETA ( R22 SERIES )	
R22 MARINER ( R22 SERIES )	
R44	
CF CF-96-09 CHANGES TO AIRCRAFT FLIGHT MANUAL	SUPERCEDES 95-26-05
OF SE 13 HELICOPTER RESCUE SYSTEMS	CAR 702.21
US 94-26-10 CYCLIC CONTROL SYSTEM FAILURE US 95-09-07 PREVENT BINDING IN THE CYCLIC CONTROL SYSTEM	SUPERCEDES 94-17-18
US 95-11-10 PLACARD AGAINST LOW G CYCLIC PUSHOVER	SB-4 SB-6
US 96-11-09 SUPERCEDED BY 97-02-15	55-0
US 96-18-22 MAIN ROTOR GEARBOX INSPECTION (GEAR FINISH)	SB-15
US 97-02-15 PILOT MISMANAGEMENT OF ROTOR RPM US 97-16-02 SPRAG CLUTCH REPLACEMENT	SUPERCEDES 96-11-09
US 98-04-12 LATERAL CYCLIC TRIM SPRING SHAFT WEAR	SB 21, SB 23 SB-26
US 98-05-10 FAILURE OF ALUMINUM ELBOWS	SB-25
US 98-22-16 MAIN ROTOR BLADE CRACKING- SUPERSEDES 98-12-19	SB 27B, 28

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER (SERIES / SERIE)

ORIGINE	NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
ROBINS	ON		
R44	NUED / SUITE)		
US	99-07-18	SPRAG CLUTCH ASSEMBLY	
US	99-13-11 99-17-17	AUX FUEL TANK SUMP DRAIN TUBE	32
US	99-23-01	MAIN ROTOR YOKE ASSEMBLY CYCLIC CONTROL-PILOT GRIP CRACKING	RHC R44 SB-35
DUCKAR	LL INTL	SOUTH OF THE OF SERVING	
114 SI		SEE/VOIR: AERO COMMAND	ED
114		· proportion : manual representation of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control of the control	
	,	114 SERIES ) SEE/VOIR: AERO COMMAND	ER
700		SEE/VOIR: AERO COMMAND	ER
	N SCHNEIDER		
LS 1C	71-45	VENT HOLE / AILERON CONTROL	
GY	72-138	C OF G - FLIGHT MANUAL - WINCH LAUNCHING	2 15
GY GY	74-323/2 74-5	FLIGHT CONTROL CABLE CONNECTIONS	
GY	74-70	TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72, SH MAIN WING ATTACHMENT BOLTS	72 20
GY GY	74-96	AILERON GAP	19
GY	77-155 78-162	HORIZONTAL ALL MOVING TAIL TRIM	32 34
GY	78-290	FUSELAGE INSPECTION HOLE COVER	36
GY GY	79-44 82-184	RUDDER, AILERON & ELEVATOR BEARINGS SERVICE LIFE	37
	02 101	SERVICE EIFE	40
LS 4 GY	81-112	CONTROL STICK / CROUND DELEACE	
GY	81-113	CONTROL STICK / GROUND RELEASE AIR BRAKE FLAPS	4004 4005
GY GY	82-214 83-118	FRONT HOLDER OF TRIMMING LEAD (MOUNTING)	4010
GY	83-158	UNDERCARRIAGE BRAKE LEVER AIRBRAKE FLAPS LOWER LEAF	4019 4020
GY	87-254/2	EXTENSION OF SERVICE LIFE	4027A
GY GY	93-083 93-155	TRIM WEIGHT HOLDER INSPECTION AND REPLACEMENT BONDING-ELEVATOR MOUNT BRACKET	TM 3040/4033 4035
GΥ	1999-270	AIR BRAKE LOCKING IN FUSELAGE	4042
LS 6B			
GY	86-140/2	OPERATING LIMITS	6009
GY GY	89-60 91-110	DEFLECTOR - WING AIR BRAKE BOXES PEDAL ADJUSTMENT CABLE	6019 6022
GY	1999-266	CANOPY EMERGENCY JETTISON	6036
ROOS AM	ERICAN EAGLE		
101	Environ. Enote		
RYAN			
ST3KR			
US US	46-06-01 51-28-03	FRONT FIN SPAR FUEL VALVE PLACARD	
	. 20 00	TOLE TREVE TERONIES	
340B	••••••		
SN	1-022 REV.E	PROP HUB ASSEMBLIES	DOWTYROTOL 340-61-54
SN SN	1-033 REV.A 1-034	AC GENERATORS NACELLE - DRAG STRUT BOLTS	340-24-016 340-54-026
	1-036 REV.A	STABILIZER - TOP CLOSURE RIB	340-54-026
SN	1-038 REV.A	YAW OSCILLATIONS	340-55-026R1
	1-041 1-042	AUTO PILOT ELECTRICAL WIRE SIZE FORWARD COWLING DOORS	340-34-068 340-71-035
SN	1-044 REV.A	FORWARD TOTLET SERVICE DOOR	0-10 02 0101(1
	1-045 1-046	LAVATORY CIRCUIT BREAKER INNER-WING FUEL TANKS	340-25-181 340-28-013
		INNER-WING FUEL TANKS EMERGENCY LIGHTING PASSENGER DOOR HANDLE	340-33-030
SN	1-048	PASSENGER DOOR HANDLE	340-52-014
SN	1-049 REV.A 1-050	REFUEL/DEFUEL PANEL LIGHTS	340-34-02/R1
SN	1-051	STABILIZER DECING	340-30-039
SN	1-052 1-054	FUEL ACCESS DOOR BLEED AIR SENSOR LOOPS	340-57-020 340-36-006
SN	1-055	FUSELAGE-PROTECTIVE SHIELD	340-53-008
SN	1-056	MOTOR OPERATED FUEL VALVES	340-28-016

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
SAAB			
340B			
	UED / SUITE)		
SN	1-057	AC GENERATOR CONTROL RELAYS	340-24-22
SN	1-060 REV.A	ELEVATOR AND AILERON COVES	340-51-012
SN SN	1-061	MLG RETRACT ACTUATOR BRACKET BOLT	340-32-094
SN	1-064R1 1-065	PROP-BRAKE VALVE LIMIT SWITCH	340-61-032, -033
SN	1-067	OVERWING EMERGENCY EXIT BEAMS ENGINE CONTROLS BETA STOP	340-53-047
SN	1-070R1	ENGINE CONTROLS-FLIGHT IDLE STOP	340-76-034 340-76-032, 031,034
SN	1-072	FLAP FITTINGS	340-57-027
SN	1-074	STABILIZER-RUDDER NOSE RIB	340-55-032
SN	1-075R1	BRAKE STACK INSPECTION	340-32-105 & 110
SN SN	1-079 1-080	FIRE PROTECTION	340-26-015
SN	1-085R1	FIRE HANDLE SWITCHES ANTI-SKID SYSTEM	
SN	1-103R1	CEILING AND LAVATORY LIGHTS	340-32-107
SN	1-105	REAR FUSELAGE-SEALING OF FIRE SHIELD AT APU	340-33-040R1 340-53-052
SN	1-106R1	FORWARD LAV. WASTE BIN FIRE EXTINGUISHER	340-33-032
SN	1-110R2	HORIZONTAL STABILIZER INSP.	340-55-033 & 034
SN	1-113R1	PAX-FLUORESCENT LIGHTING	340-33-047
SN	1-115R1	WINDSHIELD WIPERS	340-30-081
SN SN	1-116 1-117R1	FLIGHT IDLE STOP OVERRIDE KNOB	340-76-041
SN	1-118	FLAPS-REPLACEMENT OF SUPPORT STRAP	340-57-033R2
SN	1-119R1	BAGGAGE NET PLACARDS ENGINE AIR INTAKE MODIFICATION	340-25-244
SN	1-120	ICE AND RAIN PROTECTION-DEICE VALVE	340-30-073R1
SN	1-125	LANDING GEAR - RELAY 15GA	340-30-080
SN	1-127	LANDING GEAR - BRAKES	340-32-114
SN	1-128	POWER CONTROLS-QUADRANT POWER CAM SCREW	340-76-042
SN	1-133	HORIZONTAL STABILIZER INSPECTION OF HOLES	340-55-34
SN SN	1-134 1-135R1	NOSE WHEEL ASSEMBLIES	340-32-116R1
SN	1-141	ENGINE MOUNTS	340-71-057R1
SN	1-139R1	FUSELAGE-MAIN FRAME-AILERON CONTROL BRAKE ASSEMBLIES	340-53-061
SN	1-143	ENG CONTROL QUAD-FLT IDLE STOP SOLENOID BRACKET	340-32-114 340-76-043
SN	1-145	HYDRAULIC POWER-INTRO NEW SWIVEL BRACKET	340-29-009 PEV 2
SN	1-146	WINGS- MLG SUPPORT ASSEMBLY, BEARING HOUSING NOT	340-57-036
SN	1-148	INSPECTION OF FLIGHT IDLE STOP OVERRIDE KNOR	340~76~0/1P1
SN SN	1-149 1-151	INSPECTION OF WIRING IN CABIN COMPARTMENT CEILING	
UK	006-03-93	REPLACEMENT OF CARGO COMPARTMENT SMOKE DETECTORS SEATS	340-26-023
	017-03-93	SEATS	FEEL SB 25-20-1287R3 25-20-1294R1
	_		23 20 123481
SAUNDER: ST 27	S		
	CF-87-13	AILERON MASS BALANCE WEIGHTS	DATE THE LIVE
		ATELION PASS BALANCE WEIGHTS	BAE TNS W19
CHEIBE	VE TY		
BERGFAI GY	1/55	MUSEL OUT OUT / OUT / OUT	
GY	1/55	WHEEL CUT-OUT / SKID RUN-OUT	6
	71-87	AILERON DEFLECTION LEVER ELEVATOR PUSH PULL ROD/CONTROL LEVER	1/71
	73-140	WING SPAR	1/71
GΥ	74-323/2	FLIGHT CONTROL CABLE CONNECTIONS	
GY	74-38	SPAR ROOT ZONE	104-2/74
	75-42	SPAR ROOT	104-3/74
	79-501	RELEASE HOOK ATTACHMENT	104-15
	84-207 85-125	WING BOLTS ELEVATOR / AIR BRAKES - CONNECTING BOLTS	104-17
Q I	00 120	ELEVATOR / AIR BRAKES - CUNNECTING BULIS	104/85
BERGFAL	KE II/55		
GY	1/55	WHEEL CUT-OUT / SKID RUN-OUT	6
	60-9	CONTROL CABLES	8
	66-3 71-87	AILERON DEFLECTION LEVER	1/71
	74-17	ELEVATOR PUSH PULL ROD/CONTROL LEVER AILERON BELLCRANKS	1/71
	74-323/2	FLIGHT CONTROL CABLE CONNECTIONS	1/66
GY	79-501	RELEASE HOOK ATTACHMENT	104-15
GY	84-207	WING BOLTS	104-15
GY	85-125	FIGURES / ATR BOARDS	104/85
BERGFAL	KE TIT		
	1/55	WHEEL CLIT-OUT / SKID DUN OUT	
	60-9	WHEEL CUT-OUT / SKID RUN-OUT CONTROL CABLES	6
			8
AIRCRA	AFT/AERONEES		

INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA				
MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBEI ORIGINE NUMERO D	(SERIES / SERIE)		REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF	
SCHE I BE			DOLLETIN DE SERVICE DE REP	
BERGFALKE II	I			
(CONTINUED / S GY 66~3		····		
GY 71-87	A I L ERON EL EVATO	DEFLECTION LEVER R PUSH PULL ROD/CONTROL LEVER	1/71	
GY 74-17	AILERON	BELLCRANKS	1/71 1/66	
GY 74-323 GY 75-269	2 FLIGHT	CONTROL CABLE CONNECTIONS		
GY 79-501	RELEASE	R OPERATING LEVER HOOK ATTACHMENT	104-2/75 104-15	
GY 84-207 GY 85-125	WING BOI	LTS	104-15	
	CCLVATOR	R / AIR BRAKES - CONNECTING BOLTS	104/85	
L SPATZ SERI GY 74-323,	_	CONTROL CABLE CONNECTIONS		
L SPATZ III	( L SPATZ SEI	RIES )		
GY 63-1	AILERON		CHANGE NO1	
L SPATZ 55	( L SPATZ SE	DIEC )		
GY 63-1	AILERON		CHANGE NO1	
SF 26A		• •	OLANGE NOT	
GY 74-323/	2 FLIGHT (	CONTROL CABLE CONNECTIONS		
GY 75-270		BELLCRANK	232-1/75	
SF 27A				
GY 74-323/		CONTROL CABLE CONNECTIONS		
GY 75-48	ELEVATOR	DRIVE SHAFT	TM 257-1/74	
SF 28B				
GY 97-140	TRUMA V8	FUEL SHUT OFF VALVE	770-20	
ZUGVOGEL III				
GY 74-323/		ONTROL CABLE CONNECTIONS		
GY 74-434	C OF G -	FLIGHT & MAINT MANUAL AMENDMENTS		
SCHEMPP-HIRTH CIRRUS				
GY 69-136 GY 74-323/	FLIGHT C	ONTROLS - ASKUBAL BALL BEARING ROD ENDS ONTROL CABLE CONNECTIONS	1/69	
GY 74-5		QUIPMENT - NOSE COUPLING 72, E72, S72,SH72		
GY 82-103 GY 85-56	ELEVATOR	& RUDDER FLUTTER	265-6	
GY 85-56 GY 86-15	SERVICE	CONTROL LIFE	TM 265-8 265-9	
GY 93-013	AIRBRAKE	LEVER COUPLING BALLS	265-10	
GY 1998-25	EXTENSIO	N OF SERVICE LIFE	265-9	
DISCUS B				
GY 92-360/ GY 94-031		ACTUATING ROD INTERNAL CORROSION	360-9	
	INCREASE	IN TIME IN SERVICE TO 12000 HRS	360-11	
JANUS CM GY 1999-26	LIODIZONI	AL CTARTITION MACC RALANCE	005 07/000 45	
MINI NIMBUS S		AL STABILIZER - MASS BALANCE	295-27/809-15	
MINI NIMBUS B		SERIES )		
GY 86-16	SERVICE L	_IFE	328-7	
GY 87-126/: GY 92-360/:		DRIVE BRACKET ACTUATING ROD INTERNAL CORROSION	286-24,328-8 328-10	
			020 10	
MINI NIMBUS C GY 86-16	•		339-7	
GY 87-126/3	SERVICE L B ELEVATOR	DRIVE BRACKET	328-7 286-24, 328-8	
GY 92-360/2	ELEVATOR	ACTUATING ROD INTERNAL CORROSION	328-10	
MINI NIMBUS H	S7 ( MINI NIMBUS	SERIES )		
GY 86-16	SERVICE L	İFE	328-7	
GY 87-126/3 GY 95-015		DRIVE BRACKET MENT OF HORIZONTAL STABILIZER	286-24,328-8 328/11	
NIMBUS 2 SERI	S			

86-036/2

NIMBUS 2

( NIMBUS 2 SERIES )
EXTENSION OF SERVICE TIME

MAKE / CONSTRUCT		RIES / SERIE)	
ORIGIN AD NU ORIGINE NUME	IMBER	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
SCHEMPP-HII			
NIMBUS 2 (CONTINUED ,		NIMBUS 2 SERIES )	
GY 95-0		REINFORCEMENT OF HORIZONTAL STABILIZER	TECH NOTE 286/33
NIMBUS 2B		NIMBUS 2 SERIES )	
	036/2 126/3	EXTENSION OF SERVICE TIME ELEVATOR DRIVE BRACKET	TECH NOTE 286-22 286-24,328-8
	360/2	ELEVATOR ACTUATING ROD INTERNAL CORROSION	286-28
S SERIES			
CF CF-6 GY 67-0	67-03 01	RUDDER CONTROL CABLE GUIDE PULLEYS RUDDER CONTROL CABLE GUIDE PULLEYS BALL BEARINGS	8, 10
GY 74-3 GY 74-5	323/2	FLIGHT CONTROL CABLE CONNECTIONS TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72,SH72	
s		S SERIES )	
GY 65-2 GY 66-2		ELEVATOR ACTUATOR ROD	5
GY 69-3		AILERON AND ELEVATOR ACTUATOR ROD GLUE JOINT - BULKHEAD / FUSELAGE PLYWOOD SHELL	11
SHK 1	( :	S SERIES )	
GY 69-3	31	GLUE JOINT - BULKHEAD / FUSELAGE PLYWOOD SHELL	9
SH1		S SERIES )	
GY 65-2 GY 66-2		ELEVATOR ACTUATOR ROD AILERON AND ELEVATOR ACTUATOR ROD	5 8
GY 69-3	0	GLUE JOINT - BULKHEAD / FUSELAGE PLYWOOD SHELL	11
STANDARD C			
GY 74-3 GY 74-5	23/2	FLIGHT CONTROL CABLE CONNECTIONS  TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72, SH72	***************************************
GY 76-7 GY 76-8		SEAT - TOW RELEASE LEVER	278-18
	51/4	FUSELAGE FRAME AIRBRAKE ACTUATING LEVER BALL JOINTS	278-17 278-23
GY 80-1 GY 80-2		ELEVATOR ASSEMBLY	SB2 LANAVEERE INDUST
GY 80-2		ELEVATOR DRIVE ELEVATOR "T" FITTING	278-25 278-26
GY 81-09 GY 92-30		SERVICE LIFE	278-28
GY 95-0		ELEVATOR ACTUATING ROD INTERNAL CORROSION REINFORCEMENT OF HORIZONTAL STABILIZER	278-33 278/36
VENTUS B			
GY 92-36 GY 1999-		ELEVATOR ACTUATING ROD INTERNAL CORROSION	349-16
	001	EXTENSION OF SERVICE LIFE	TN 349-24
GY 92-36	60/2	ELEVATOR ACTUATING ROD INTERNAL CORROSION	825-17
GY 1999-	-304	LIFE EXTENSION	TECH NOTE 825-21
VENTUS CM	-365	MODIFICATION OF ENGINE & COMPONENTS	825~22
GY 92-36		ELEVATOR ACTUATING ROD INTERNAL CORROSION	825-17
GY 1999-	-304		TECH NOTE 825-21
SCHLEICHER KA 6 SERIES	•		
GY 60-5	•	MAIN SPAR	1
GY 60-7 GY 62-7		MAIN SPAR BRAKE FLAPS - AIRBRAKE - ACTUATOR ROD FORK	
GY 72-7/			7 21
GY 74-32	23/2	FLIGHT CONTROL CABLE CONNECTIONS	
KA 6 CR	( к	A 6 SERIES )	
<b>KA 6E</b> GY 68-10		A 6 SERIES )	
GY 70-86		FLT INSTMENTS-STATIC AIR COMPENSATION THERMOS BTLS ALL-MOVING TAIL - TUBULAR SPAR/BOLT	17 18
K 7			
GY 60-15		ELEVATOR	3
GY 72-7/	'3	ELEVATOR LOCAL INC.	4 18
GY 74-32	23/2	FLIGHT CONTROL CABLE CONNECTIONS	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

ORIGINE NUMERO DE CONS	IGNE SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
SCHLEICHER		
K8 SERIES		
GY 60-13	PEDALS	2
GY 60-17 GY 72-7/3	ELEVATORS	3
GY 74-323/2	ELEVATOR - GLUE JOINTS FLIGHT CONTROL CABLE CONNECTIONS	23
GY 80-158	COCKPIT HOOD LOCK	0.1
		21
<b>K8</b> GY 70-50	( K8 SERIES )	
GY 96-005	AIRBRAKE - PUSH PULL ROD/FLAP CROSS SHAFT LE	EVER 9, 10
	COMPLETE INSPECTION OF FUSELAGE TUBE SKELETO	ON ETC. TECH NOTE 24
K8B	( K8 SERIES )	
GY 96-005	COMPLETE INSPECTION OF FUSELAGE TUBE SKELETO	ON ETC. TECH NOTE 24
ASW 12		
GY 74-323/2	FLIGHT CONTROL CABLE CONNECTIONS	
GY 89-115	SPAR WEBS & PLYWOOD BLOCKS	4
ASK 13		
GY 68-110	LANDING GEAR SHOCK / BUFFER PLATE	3
GY 68-53	FAIR LEAD WHEEL BRAKE CARLE	2
GY 72-7/3 GY 74-323/2	ELEVATOR - LOOSE JOINTS	12
GY 74-323/2 GY 91-144	FLIGHT CONTROL CABLE CONNECTIONS WING MAIN FITTINGS	
GY 91-173	AIRBRAKE CONTROL CIRCUIT	13 14
		, -
ASW 15 SERIES GY 74-323/2	ELICUT CONTROL OCCUPANTO	
GY 81-265	FLIGHT CONTROL CABLE CONNECTIONS ELEVATOR ACTUATOR BELLCRANK	21
GY 81-91	SERVICE LIFE	20
GY 82-221	ELEVATOR ACTUATOR BELLCRANK	22
ASW 15	( ASW 15 SERIES )	
CF CF-88-10R2	WING SPAR	23
GY 71-117	COVER - FRONT MAIN/CENTER BULKHEAD	4, 6
GY 73-20	RUDDER GAP	10
ASW 15B	( ASW 15 SERIES )	
CF CF-88-10R2	WING SPAR	23
ASW 17 GY 76-11	WATER BALLAST SYSTEM	
GY 89-115	SPAR WEBS & PLYWOOD BLOCKS	12
GY 93-124	INCREASED SERVICE LIFE	TN 13
ASW 19 SERIES		
GY 76-258	RUDDER SKIN PANELS FREQUENCY	2
GY 78-303	FUSELAGE HANDHOLE COVER	7
GY 81-74/2	AILERON HINGE BEARING	12
GY 84-115 GY 84-31	TOW RELEASE - CABLE GUIDE FITTING SERVICE LIFE	18
GY 84-65	TAILPLANE FLUTTER	17
GY 97-010	SERVICE LIFE INCREASE ON WINGS AND WING SPARS	
ASW 19	( ASW 19 SERIES )	
	( NOW 19 SERIES )	
ASW 19B	( ASW 19 SERIES )	
ASW 20 SERIES		
GY 77-294	FRONT TOW COUPLING ATTACHMENT	7
GY 78-303	FUSELAGE HANDHOLE COVER	4
GY 81-54	AILERON & FLAP CONTROL	12
GY 81-74/2 GY 84-43	AILERON HINGE BEARING SERVICE LIFE	12 17
GY 87-141	AILERON CONTROL	31
GY 87-148	PITCH OSCILLATION	30
GY 1998-255	INCREASE SERVICE LIFE	29/2
ASW 20	( ASW 20 SERIES )	
GY 84-115	TOW RELEASE - CABLE GUIDE FITTING	21
<b>ASW 20B</b> GY 84-115	( ASW 20 SERIES )  TOW RELEASE - CABLE GUIDE FITTING	21
5, 115		

ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
SCHLEICHER ASW 20BL	( ASW 20 SERIES )	
ASW 20C	( ASW 20 SERIES )	
ASW 24 SERIES	( ASW 20 SERIES )	
	INCREASE SERVICE LIFE	29/2
ASW 24	( ASW 24 SERIES )	
<b>ASW 27</b> GY 1999-283	ELEVATOR CONTROL CIRCUIT CLEARANCE CHECK	TEOU NOTE TO THE TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL TOTAL T
RHONLERCHE II	SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELECTION OF SELEC	TECH NOTE NO. 5
GY 60-08 GY 60-10	WING RUDDER	<u>6</u>
GY 60-12 GY 60-14	AILERON CONTROL CABLES	7 4, 5
GY 62-05/2	RIB 4A ELEVATOR CONTROL CABLE	8
GY 63-02 GY 67-04	CONTROL COLUMN AILERON	10
GY 74-323/2	FLIGHT CONTROL CABLE CONNECTIONS	12
GY 75-166 GY 77-268	CONTROL STICK CONNECTION	13
	CLEVIS PIN - AILERON CONTROL CABLE	14
SCHWEIZER SGS 1 23		
US 71-17-09 US 87-02-01	OSCILLATIONS AND VIBRATIONS	102-23-2
US 87-17-01	TOW RELEASE TOW RELEASE ASSEMBLY	SA-001
SGS 1 26 SERIES		SA-001.3,-005.1
US 87-02-01	TOW RELEASE	SA-001
US 87-17-01	TOW RELEASE ASSEMBLY	SA-001.3,-005.1
SGS 1 26	( SGS 1 26 SERIES )	
SGS 1 26A	( SGS 1 26 SERIES )	
SGS 1 26B	( SGS 1 26 SERIES )	
SGS 1 26C	( SGS 1 26 SERIES )	
SGS 1 26D	( SGS 1 26 SERIES )	
SGS 1 26E	( SGS 1 26 SERIES )	
SGS 1 34 US 87-02-01	TOW RELEASE	
US 87-17-01	TOW RELEASE ASSEMBLY	SA-001 SA-001.3,-005.1
SGS 1 35 US 87-02-01	TOW DELEACE	
US 87-17-01	TOW RELEASE TOW RELEASE ASSEMBLY	SA-001 SA-001.3,-005.1
SGS 1 36		34 001.3, -005.1
SGU 1 19		
US 87-02-01	TOW RELEASE	SA-004
US 87-17-01	TOW RELEASE ASSEMBLY	SA-001 SA-001.3,-005.1
SGU 1 20		
US 87-02-01 US 87-17-01	TOW RELEASE TOW RELEASE ASSEMBLY	SA-001
TSC 1A	- AUGENOL AUGENOL	SA-001.3,-005.1
TSC 1A1		
TSC 1A2		
SGS 2 32 US 87-02-01	TOW RELEASE	24-004
US 87-17-01	TOW RELEASE ASSEMBLY	SA-001 SA-001.3,-005.1

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN
CCUWE 17ED		BULLETIN DE SERVICE DE REF.
SCHWEIZER SGS 2 33 SERIES US 76-13-11R1 US 77-23-10 US 87-02-01 US 87-17-01	FWD/AFT FUSELAGE TUBULAR LONGERONS SPAR WEB AND BOLTS TOW RELEASE TOW RELEASE ASSEMBLY	102-33-1.1 SA-001 SA-001.3,-005.1
SGS 2 33	( SGS 2 33 SERIES )	
SGS 2 33A	( SGS 2 33 SERIES )	
SGU 2 22 SERIES US 76-13-11R1 US 87-02-01 US 87-17-01	FWD/AFT FUSELAGE TUBULAR LONGERONS TOW RELEASE TOW RELEASE ASSEMBLY	102-33-1.1 SA-001 SA-001.3,-005.1
SGU 2 22	( SGU 2 22 SERIES )	
SGU 2 22C	( SGU 2 22 SERIES )	
SGU 2 22CK	( SGU 2 22 SERIES )	
SGU 2 22E	( SGU 2 22 SERIES )	
SGU 2 22EK	( SGU 2 22 SERIES )	
TG 3A US 87-17-01	TO DE CASE	
G 164 SERIES	TOW RELEASE ASSEMBLY	SA-001.3,-005.1
G 164A	SEE/VOIR: GRUMMAN  ( G 164 SERIES ) SEE/VOIR: GRUMMAN	
G 164B	( G 164 SERIES ) SEE/VOIR: GRUMMAN	
269C	SEE/VOIR: HUGHES	
269C 1	SEE/VOIR: HUGHES	
269D	SEE/VOIR: HUGHES	
SEMCO		
US 73-24-02 US 75-11-03 US 80-14-09	VERTICAL FUEL HOSE COUPLER DEFLATION SYSTEM GONDOLA FITTINGS	
SHORT&HARLAND SC7		
UK 0416 PRE 80 UK 0417 PRE 80 UK 0418 PRE 80 UK 0419 PRE 80 UK 0420 PRE 80 UK 0421 PRE 80 UK 0424 PRE 80 UK 0425 PRE 80 UK 0426 PRE 80 UK 0427 PRE 80 UK 0428 PRE 80 UK 0429 PRE 80 UK 0429 PRE 80 UK 0431 PRE 80 UK 0431 PRE 80 UK 0431 PRE 80 UK 0433 PRE 80 UK 0433 PRE 80	PLACARDS FAA REQUIREMENTS AUTO-PILOT TORQUE LIMITING RESISTOR BOARD AUTO-PILOT AILERON SERVO CONTROL CABLE ELECTRICAL POWER LID PANEL 1D ELECTRICAL POWER LID PANEL 1D AUTOMATIC POWER CHANGE-OVER 1ST PILOT'S HORIZON RUDDER BAR ASSEMBLY FLAP CONTROL MECHANISM FLAP MECHANISM SUPPORT STRUCTURE PIN AILERON CONTROL ROD DE-ICING PIPE INSTRUMENTS STAND-BY STATIC CORRECTED LABEL A.S.I. INSTRUMENTS STAND-BY STATIC CORRECTED LABEL A.S.I. INSTRUMENTS STAND-BY STATIC CORRECTED LABEL A.S.I. INSTRUMENTS STAND-BY STATIC CORRECTED LABEL A.S.I. STRUMENTS STAND-BY STATIC CORRECTED LABEL A.S.I. INSTRUMENTS STAND-BY STATIC CORRECTED LABEL A.S.I. STRUMENTS STAND-BY STATIC CORRECTED LABEL A.S.I. INSTRUMENTS STAND-BY STATIC CORRECTED LABEL ALTIM. ALTERNATE STATIC SYSTEM - 2ND PILOT'S INSTRUMENTS LANDING GEAR BRAKE FLANGE STRUCTURES - EXTERND SERVICE LIFE	11-58 22-51 22-A59 24-55 24-54 24-65 27-55 27-56A 27-A64 27-66 30-50 31-51 31-52 31-53 31-54 32-A67
UK 0434 PRE 80 UK 0436 PRE 80 UK 0437 PRE 80 UK 0439 PRE 80 UK 0442 PRE 80 UK 0443 PRE 80 UK 0444 PRE 80 UK 0445 PRE 80 UK 0446 PRE 80	STRUCTURES - EXTEND SERVICE LIFE FUSELAGE STUB WING FRONT SPAR FUSELAGE NOSE UNDERCARRIAGE LOWER ATTACHMENT FIN/TAILPLANE ATTACHMENT FLAP AILERON SHROUD ATTACHMENT LUGS LIFT STRUT FITTING TO WING RIB OUTBCARD HINGE ARM ON INNER FLAP WINGS LIFT STRUT FAIRING HARTZELL PROPELLER INC. SERVICE BULLETIN NO.105A	53-62 55-53 57-51 57-59 57-461 57-63

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

		00007	BULLETIN DE SEMVICE DE REF.
SHORT	&HARLAND		
SC7			
UK	INUED / SUITE)	HADTZELL DRODELLED INC. CEDVICE DIVLETIN NO 1004	
UK	0447 FRE 80	HARTZELL PROPELLER INC. SERVICE BULLETIN NO.123A ENGINE MOUNTING SHOCK ABSORBER	61-51
UK	0447 PRE 80 0448 PRE 80 0449 PRE 80 0450 PRE 80	ENGINE MOUNTING SHOCK ABSORBER ENGINE PLENIUM BOTTOM HEAT SHIELD ENGINE  OLL SAMBLES/ENGINE OLL ELLIED	71-56
UK	0450 PRE 80	ENGINE	72-61
UK	0451 PRE 80 0452 PRE 80 0453 PRE 80 0454 PRE 80	OIL SAMPLES/ENGINE OIL FILTER FNGINF	72-63
UK	0452 PRE 80	ENGINE	72-64
UK UK	0453 PRE 80	ENGINE	72-65
UK	0454 PRE 80	ENGINE CONTROLS SPLIT DIN/CROUND/AID LEVED	72-66
UK	0456 PRF 80	ENGINE CONTROLS SPLIT PIN/GROUND/AIR LEVER ENGINE CONTROLS SPRING HEEL BLOCK/AIR/GROUND LEVE FEATHER CONTROL RODS ROOF CONSOLE NOSE UNDERCARRIAGE LIFE EXTENSION ARTIFICIAL HORIZONS	/6-51A D 76-450
UK	0457 PRE 80	FEATHER CONTROL RODS ROOF CONSOLE	76-57
UK	0458 PRE 80	NOSE UNDERCARRIAGE LIFE EXTENSION	D R SB 32-4M
UK	0459 PRE 80	ARTIFICIAL HORIZONS  ELECTRICAL GENERATION SYSTEMS  MANDATORY LIFE LIMITATIONS  LOCKING PINS ONE PIECE CARGO DOOR  OUTER FLAP  AUTO-PILOT SERVO CLUTCH	NOTICE NO.81
UK	0460 PRE 80	ELECTRICAL GENERATION SYSTEMS	NOTICE NO.82
UK	0461 PRE 80	MANDATORY LIFE LIMITATIONS	MAINT. MANUAL
UK	006-11-80	LOCKING PINS ONE PIECE CARGO DOOR	52-65
UK	027-12-80	AUTO DI OT SERVO CLUTOU	57-62R1
UK	067-12-80	PETAINING PIN/GROUND/AIR LEVER	22-A61
UK	004-04-81	MAIN INDEPCARRIAGE SHOCK ARCORDED	76-58
UK	017-12-81	MAIN UNDERCARRIAGE/BRAKE FLANGE	D.R. SB 32-7M D.R. SB 32-10M
UK	019-09-81	FATIGUE LIFE LIMITATIONS	51-52R1
UK	002-04-82	MAIN UNDERCARRIAGE/LIFTING REQUIREMENTS	D.R. SB 32-6M
UK	007-07-82	LOCKING PINS ONE PIECE CARGO DOOR  OUTER FLAP AUTO-PILOT SERVO CLUTCH RETAINING PIN/GROUND/AIR LEVER MAIN UNDERCARRIAGE SHOCK ABSORBER MAIN UNDERCARRIAGE/BRAKE FLANGE FATIGUE LIFE LIMITATIONS MAIN UNDERCARRIAGE/LIFTING REQUIREMENTS ENGINE PROPELLERS	72-68
UK	002-09-83	PROPELLERS	61-52
UK	005-12-83	MAIN UNDERCARRIAGE SHOCK ABSORBER ATTACHMENT LUG	D.R. SB 32-14M
UK	006-07-83	PROPELLERS PROPELLERS MAIN UNDERCARRIAGE SHOCK ABSORBER ATTACHMENT LUG AILERON SERVO MOTOR MAIN UNDERCARRIAGE FUEL FLEXIBLE FUMEPROOF SHROUDS	22-63
UK	003-03-86	MAIN UNDERCARRIAGE FUEL FLEXIBLE FUMEPROOF SHROUDS BRAKE UNIT - DUNLOP SB 32-1108 FLIGHT CONTROL RODS WING ATTACHMENT BUSHES INSPECTION	D.R. SB 32-9M
UK	005-11-95	PRAKE LINIT DUNI OD CD CO 1100	28-58
UK	008-03-95	FLIGHT CONTROL PORS	32-71
UK	009-01-96	FLIGHT CONTROL RODS WING ATTACHMENT BUSHES INSPECTION	27-74K2 52-69D2
			30 0000
SD3 3	30	FUEL CVOTEM OR WATER	
UK	0185 PRE 80	FUEL SYSTEM GRAVITY FEED CHECK VALVES	SD3-28-12
UK	0188 PRF 80	PNELIMATIC DE-ICING SYSTEM	SD3-28-13
UK	0190 PRE 80	FUEL SYSTEM GRAVITY FEED CHECK VALVES FUEL SYSTEM CHECK VALVE GRAVITY FEED PIPE PNEUMATIC DE-ICING SYSTEM MAIN LANDING GEAR SWIVEL SUB-ASSEMBLY MAIN LANDING GEAR SWIVEL - SHOCK STRUT ATTACH.PINS NOSE LANDING GEAR TRUNNION MAIN LANDING GEAR WHEEL ASSEMBLITES	SD3-30-A04
UK	0191 PRE 80	MAIN LANDING GEAR SWIVEL - SHOCK STRUT ATTACH PINS	SD3-32-05
UK	0192 PRE 80	NOSE LANDING GEAR TRUNNION	SD3-32-06
	0193 PRE 80	MAIN LANDING GEAR WHEEL ASSEMBLIES	SD3-32-09
UK	0195 PRE 80	MAIN LANDING GEAR DOWNLOCK STOP	SD3-32-18
UK UK	0196 PRE 80	NOSE LANDING GEAR CYLINDER	SD3-32-19
UK	0197 PRE 80	NOSE LANDING GEAR STEERING COLLAR	SD3-32-24
UK	0199 PRF 80	MAIN LANDING GEAR DUWNLUCK STUP	SD3-32-25
UK	0200 PRF 80	MATALIANDING GEAD REAM ASSEMBLIES	SD3-32-26
UK	0201 PRE 80	NOSE LANDING GEAR DOWNLOCK MECHANISM HOUSING	203-32-20
UK	0204 PRE 80	NOSE/MAIN LANDING GEAR RETRACTION ACTUATORS	SD3-32-50
UK	0204 PRE 80 0205 PRE 80 0206 PRE 80 0207 PRE 80	MAIN LANDING GEAR SWIVEL SUB-ASSEMBLY MAIN LANDING GEAR SWIVEL - SHOCK STRUT ATTACH.PINS NOSE LANDING GEAR TRUNNION MAIN LANDING GEAR WHEEL ASSEMBLIES MAIN LANDING GEAR DOWNLOCK STOP NOSE LANDING GEAR CYLINDER NOSE LANDING GEAR STEERING COLLAR MAIN LANDING GEAR DOWNLOCK STOP NOSE LANDING GEAR STEERING BELLCRANK MAIN LANDING GEAR STEERING BELLCRANK MAIN LANDING GEAR BEAM ASSEMBLIES NOSE LANDING GEAR DOWNLOCK MECHANISM HOUSING NOSE/MAIN LANDING GEAR RETRACTION ACTUATORS MAIN LANDING GEAR CYLINDER NOSE LANDING GEAR CYLINDER NOSE LANDING GEAR LINK SUB-ASSEMBLY	SD3-32-55
UK	0206 PRE 80	MAIN LANDING GEAR CYLINDER  NOSE LANDING GEAR LINK SUB-ASSEMBLY  MAIN WHEEL HALF HUBS  MAIN LANDING GEAR DOWNLOCK MECHANISM  NOSE LANDING GEAR DOWNLOCK MECHANISM  NOSE LANDING GEAR SHOCKSTRUT CYLINDER  LANDING GEAR MENASCO SERVICE BULLETIN NO 22 E7	SD3-32-60
UK	0207 DDE 00	MATAL MITEL MALE INDO	SD3-32-64
UK	0208 PRE 80 0209 PRE 80 0210 PRE 80 0211 PRE 80	MAIN LANDING GEAR DOWNLOCK MECHANISM	SD3-32-65
UK UK	0209 PKE 80	NOSE LANDING GEAR DOWNLOCK MECHANISM	SD3-32-66
UK	0210 PKE 80	NOSE LANDING GEAR SHOCKSTRUT CYLINDER LANDING GEAR MENASCO SERVICE BULLETIN NO.32-57 PASSENGER COMPARTMENT FUSELAGE ROOF	SD3-32-68
UK	0211 PRE 80	PASSENGER COMPARTMENT FUSELACE BOOF	SD3-32-79
UK	0212 PRE 80	STUB WING STRUCTURE	
UK	0214 PRE 80	CONTROLS PENETRATION OF FUSELAGE ROOF	SD3-53-07 SD3-53-18
UK	0215 PRE 80	FRONT AND REAR SPAR FRAMES	SD3-53-18 SD3-53-19(5480)
UK	0216 PRE 80	FUSELAGE SPAR FRAMES REINFORCING PLATES	SD3-53-20
UK	0217 PRE 80	STUB WING STRUCTURAL BOLTED JOINTS	SD3-53-21(5477)
UK	0218 PRE 80	FUSELAGE SPAR FRAMES REINFORCING PLATES	SD3-53-22
UK	0219 PRE 80	FUSELAGE SPAR FRAMES REINFORCING PLATES	SD3-53-23
UK	UZZU FRE OU	FUSELAGE SPAR FRAMES REINFURCING PLATES	SD3-53-24
UK UK	0221 PRE 80	FUSELAGE SPAR FRAMES REINFORCING PLATES	SD3-53-25
UK	0222 PRE 80 0223 PRE 80	FUSELAGE SPAR FRAMES REINFORCING PLATES	SD3-53-26
UK	0223 PRE 80	MAIN LANDING GEAR SWIVEL PIN STUB WING STRUCTURE BUTTSTRAPS FUSELAGE SKIN PANELS	SD3-53-A27
UK	0225 PRE 80	WING DRAG LINK ATTACHMENTS FUSELAGE	SD3-53-28
UK	0226 PRE 80	FRONT AND REAR SPAR FRAMES	SD3-53-29 SD3-53-30
UK	0227 PRE 80	FUSELAGE SPAR FRAMES REINFORCING PLATES	SD3-53-31
		THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE S	353 33 31

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

		36321	BULLETIN DE SERVICE DE REF
	T&HARLAND		
SD3			
	INUED / SUITE)		
UK	0228 PRE 80	STUB WING SPARS	SD3-53-34
UK UK	0229 PRE 80	RUDDER TORQUE TUBE	SD3-55-05(5345)
UK	0230 PRE 80	RODDER TORQUE TUBE HINGE LINE WING TRAILING EDGE SHROUDS PROPELLER PROXIMITY SWITCH WIRING	SD3-57-05
	0232 PRE 80	PROPELLER PROXIMITY SWITCH WIRING LOW BLADE ANGLE PITCH MECHANISM SUPPORT BRACKET HARTZELL PROPELLER ATTACHING BOLTS FINGING SUPPORT THE PROPERTY	SD3-61-A03
UK UK	0233 PRE 80 0234 PRE 80	LOW BLADE ANGLE PITCH MECHANISM SUPPORT BRACKET	SD3-61-A05
UK		HARTZELL PROPELLER ATTACHING BOLTS	SD3-61-06
UK	0235 PRE 80	ENGINE SUPPORT TUBE BRACKETS MANDATORY LIFE LIMITATIONS FUSELAGE TOP SKIN	SD3-71-04(5434)
	0236 PRE 80	MANDATORY LIFE LIMITATIONS	MAINT, MANUAL
UK	004-07-80	FUSELAGE TOP SKIN	SD3-53-41
UK	010-09-80	FULL TIME GEAR MENASCO SERVICE BUILTELIN NO 33-35	CD3-33-0E
UK	011-09-80	LANDING GEAR - MENASCO SERVICE BULLETIN NO 32-48	SD3-33-33
UK	004-06-81	LANDING GEAR ~ MENASCO SERVICE BULLETIN NO.32-61	SD3-32-86
UK	006-12-81	FUSELAGE FRAME	SD3-53-43
UK	007-12-81	ENGINE CONTROLS LEVER IN THE POWER CONTROL CIRCUIT	SD3-76-01
UK	008-12-81	ENGINE CONTROL POWER INPUT LEVER LANDING GEAR - MENASCO SERVICE BULLETIN NO. 32-65R2	SD3-76-02
UK	014-06-81	LANDING GEAR - MENASCO SERVICE BULLETIN NO.32-65R2	SD3-32-90R2
UK	013 00 81	LANDING GEAR - MENASCU SERVICE BULLETIN NO.32-72	SD3-32-92
UK	001-04-82	FUEL LEAKAGE CHECKS	SD3-28-16
UK	007-01-82	TRAVEL ON RIGHT AILERON	SD3-27-23
UK	008-01-82	WINDOWS	SD3-56-02
UK	010-08-82	RIB/SKIN ATTACHMENT CLEATS WING STATION 160	SD3-57-10R2
UK	016-04-82	FUEL FUME SEAL INSTALLATION	SD3-53-47
UK	021-02-82	AFT BAGGAGE COMPARTMENT	SD3-25-30
UK	001-11-83	LANDING GEAR - MENASCO SERVICE BULLETIN NO.32-74	SD3-32-101
UK	007-08-83	HURIZUNIAL STABILIZER - FUSELAGE ATTACH, FITTINGS	SD3-55-16R4
UK	035-06-83	LANDING GEAR - MENASCO SERVICE BULLETIN NO.32-71	SD3-32-96
UK	036-06-83	CREW SEAT HADNESS	CD0 0F 00
UK	037-06-83	FUEL FLEXIBLE FUME PROOF DUCTS  ELECTRICAL POWER FUEL TANK ELECTRICAL CONNECTIONS ELECTRICAL TOPOLE TUPE	SD3-28-17
UK	007-02-84	ELECTRICAL POWER	SD3-24-18
UK	009-10-84	FUEL TANK ELECTRICAL CONNECTIONS	SD3-28-22
UK	005-03-85	ELEVATOR TORQUE TUBE	SD3-27-29
UK	005-08-85	FUSELAGE TOP SKIN	SD330-53-53
UK	006-03-85 006-10-85	ELEVATOR CONTROL CIRCUIT	SD3-27-A28
UK	006-10-85	IMPROVED FUEL PIPE SHROUDS	SD330-28-29
UK		ELEVATOR CONTROL CIRCUIT IMPROVED FUEL PIPE SHROUDS AUTOMATIC FLIGHT CONTROL SYSTEM SEALANT TO FUSELAGE TOP SKIN	SD3-22-A02
UK	007-11-85	SEALANT TO FUSELAGE TOP SKIN	SD330-53-58
UK	009-01-85	LANDING GEAR - MENASCO SERVICE BULLETIN NO.32-79	SD3-32-109
UK	018-09-85	NAVIGATION PITOT TUBES .	SD330-34-26
UK	004-04-86	EMERGENCY OXYGEN BOTTLES	SD330-25-47
UK	004-04-86 005-04-86	ENGINE MOUNTING STRUCTURE	SD330-71-20
UK	005-10-86	KEYSTONE LANDING GEAR WARNING HORN	SD330-32-114
UK	006-06-86	ELECTRICAL WIRING CIRCUIT BREAKER NO.49 & NO.252	SD330-22-05
UK	011-02-86	ELEVATOR AND RUDDER CONTROL LEVERS	SD330-27-31
UK	012-07-86	ELECTRICAL POWER ECE CONTACTOR BODIES	SD330-24-21
UK	001-02-88	NOSE LANDING GEAR - PINTLE PIN	SD330-32-119
UK	001-05-90	PITOT/STATIC HEATERS	SD330-24-25R2
UK	018-10-90		A26-106
UK	015-02-91	LP LEVER OPERATION	SD330-28-35
UK	014-10-92	AUTOPILOT COMPUTER	SD3-22-02
UK	015-10-92	ELEVATOR BOB WEIGHT GUARD	SD3-27-27
UK	016-10-92	FUEL SHROUDS	SD330-28-32
UK	017-10-92	AFT FUEL SYSTEM JUNCTION BOXES	SD330-28-33
UK	018-10-92		SD3 53 48R1
UK	012-03-93		SD330-53-65R1
UK	005-04-95	ATTACH BOLTS FIN TO TAILPLANE	SD330-55-18
UK	005-09-95	FLAP HYDRAULIC UNIT	SD330-27-34
UK	006-02-97	ELEVATOR AND RUDDER SKIN FLUTES	SD330-55-19
UK	008-01-97		SD3-27-36
UK	002-12-98	FIRE EXTINGUISHER ADAPTOR COVERS	SD330-26-14R1
UK		ICE AND RAIN PROTECTION	SD330-30-33
UK	006-11-98	SIUB WING SHEAK DECKS AND KIBS	5D33U-53-68
UK	008-10-98	EMERGENCY BRAKE ACCUMULATOR MOUNT	SD330-29-19
UK	013-11-98	ELEVATOR TORQUE TUBE BEARINGS HOUSING BOLT	SD330-27-37R1
UK		ENGINE MOUNT	SD330-71-23R2
UK	008-02-99	DXYGEN SYSTEM 'O' RING	SD330-35-1
SD3 6	60		
UK	003-09-83	MAIN AND NOSE UNDERCARRIAGE	D.R.S.B.32-6SD
UK	006-12-83	MANDATORY LIFE LIMITATIONS	MAINT. MANUAL
UK		MAIN UNDERCARRIAGE PINILE PIN - PINILE NUI	SD360-32-10
UK UK	015-11-83		SD360-32-10 SD360-71A02
UK UK UK		ENGINE FLEXIBLE MOUNTS IRVIN GREAT BRITAIN LTD. SERVICE BULLETIN NO.2	SD360-71A02

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

SD3	&HARLAND		
(CONT	INUED / SUITE)		
UK	027-06-83 002-03-84	M.L.G. REAR PINTLE PIN	
UK	002-03-84	OIL COOLER LEFT AIR INTAKE SCOOP	SD360-32-A03 SD360-71-05
UK	006-04-84	PITOT STATIC SYSTEM	50360-71-05
UK	010-10-84	FUEL TANK ELECTRICAL CONNECTIONS	SD360-34-09
UK	015-05-84	PITOT STATIC SYSTEM FUEL TANK ELECTRICAL CONNECTIONS FUSELAGE FRAME 475	SD360-53-11
UK	000-05-65	MASS BALANCE ELEVATOR TAB AND FLEVATOR	SD360-55-02
UK	006-08-85	ELEVATOR AND RUDDER CONTROL LEVERS	SD360-27-04
UK	006-08-85 007-03-85	ELEVATOR TORQUE TUBE STABILISERS TAILPLANE ATTACHMENT FITTINGS FUEL DAILY WATER DRAIN CHECKS FUSELAGE TOP SKIN ICE AND RAIN PROTECTIONS SYSTEM REAR SPAR OF HORIZONTAL STABILISER SPAR WEBS OF HORIZONTAL STABILISERS FDR INDICATING/RECORDING SYSTEM FUEL PIPE SHROUDS AILERON CONTROL LEVER AND RODS LANDING GEAR WARNING HORN ELEVATOR TRIM CONTROL INDICATOR ELEVATOR TRIM CONTROL INDICATOR AUTOFLIGHT SERVO CABLES	SD360-27-06
UK	007-10-85	STABILISERS TAILPLANE ATTACHMENT FITTINGS	SD360-55-10R3
UK	008-10-85	FUEL DAILY WATER DRAIN CHECKS	SD360-28-17
UK	009-11-85	FUSELAGE TOP SKIN	SD360-53-22
UK	010-01-85	ICE AND RAIN PROTECTIONS SYSTEM	SD360-IL-80
UK	017-09-85	REAR SPAR OF HORIZONTAL STABILISER	SD360-55-06
UK	003-04-85	SPAR WEBS OF HORIZONTAL STABILISERS	SD360-55-11
UK	002-04-86	FUR INDICATING/RECORDING SYSTEM	SD360-31-04
UK	005-05-86	ATTERON CONTROL LEVED AND DOOR	SD360-28-12
UK	005-05-86	ATTERON CONTROL LEVER AND RODS	SD360-27-09
UK	007-03-86	FLEVATOR TRIM CONTROL TARRESTOR	SD360-32-23
UK	008-03-86	FLEVATOR TRIM CONTROL INDICATOR	SD360-27-10
UK	008-03-86 010-11-86 013-07-86	AUTOFLIGHT SERVO CABLES	SD360-27-11
UK	013-07-86	FLECTRICAL POWER FOR CONTACTOR PORTES	SD360-22-11
UK	002-04-87	ELECTRICAL POWER ECE CONTACTOR BODIES RUDDER GUST LOCK	SD360-24-06
UK		LEFT-HAND GARMENT BAG STOWAGE	SD360-27-11 SD360-22-11 SD360-24-06 SD360-27-16 SD360-25-34
UK	003-01-87 004-07-87	HARTZELL PROPELLER INC SERVICE BULLETIN 154	SD360-25-34
UK	005-04-87	PROPELLERS - LIFE LIMITATION	SD360-61-405
UK	007-03-87	GROUND SUPPLY REVERSE POLARITY	SD360-81-A05
UK	011-09-87 013-01-87	NAVIGATION IDC ALTIMETER	SD360-34-31
UK		ELECTRICAL POWER ECE CONTACTOR BODIES RUDDER GUST LOCK LEFT-HAND GARMENT BAG STOWAGE HARTZELL PROPELLER INC SERVICE BULLETIN 154 PROPELLERS - LIFE LIMITATION GROUND SUPPLY REVERSE POLARITY NAVIGATION IDC ALTIMETER HARTZELL PROPELLER BLADES HORIZONTAL STABILIZER	SD360-61-404
UK	002-04-88	HORIZONTAL STABILIZER NOSE LANDING GEAR – ABUTMENT PLATE SCREWS ENGINE POWER CONTROL CABLES RUDDER GUST LOCK MICROSWITCH	SD360-55-16
UK	006-02-88		SD360-32-28
UK	011-04-88 012-04-88	ENGINE POWER CONTROL CABLES	SD360-76-08R1
UK	001-08-90	RUDDER GUST LOCK MICROSWITCH DUNLOP MAIN WHEEL TYRES	
UK			02 1044
UK	002-05-90 007-09-90	PITOT/STATIC HEATERS	SD360-24-18R3
UK	018-10-90	ENGINE POWER CONTROLS  PORTABLE FIRE EXTINGUISHER (SEE MISC. AD'S)  RUDDER TORQUE TUBE FITTING  WING STRUT FITTING CRACKS  LP LEVER OPERATION  MLG REAR PINTLE PIN  MLG PISTON ROD SLOTS (DOWTY SB 32-69SD)  EMERGENCY LIGHTING SYSTEM  WING STRUT DISTANCE PIECE INSPECTION  ULTRASONIC INSPECTION-HORIZONTAL STABILIZER	SD360-76-11
UK	003-05-91	RUDDER TOROUTE TURE EITTING	A26-106
UK	003-05-91 010-03-91	WING STRUT FITTING CRACKS	5D360-55-17
UK	016-02-91	WING STRUT FITTING CRACKS  LP LEVER OPERATION	50360-37-12
UK	007-08-92	MLG REAR PINTLE PIN	SD360-32-33
UK	7000 00 32	MLG PISTON ROD SLOTS (DOWTY SB 32-69SD)	SD360-32-32
UK	009-06-92	EMERGENCY LIGHTING SYSTEM	SD360-33-23
UK	014-03-93	WING STRUT DISTANCE PIECE INSPECTION ULTRASONIC INSPECTION-HORIZONTAL STABILIZER IMPROVE RUDDER GUST LOCK SYSTEM FLAP HYDRAULIC UNITS	SD360-53-38R1
UK UK	026-01-93	ULTRASONIC INSPECTION-HORIZONTAL STABILIZER	SD360-55-19
UK	013 02 34	IMPROVE RUDDER GUST LOCK SYSTEM	SD360-27-23R1
UK	007-09-95 010-09-95	FLAP HYDRAULIC UNITS	SD360-27-24
UK	005-09-96	MLG-SHOCK ABSORBER GLAND NUT-DOWTY SB 32-78SD	SD360-32-34
UK	007 OF 00	STUB WING SHEAR DECKS	SD360-53-42
UK	006-11-97	STUB WING SHEAR DECKS STROBE LIGHT AND POWER SUPPLY SHEAR DECKS CORROSION DIODES INSPECTION FLAP LEVER BRACKET AND LEVERS FIRE EXTINGUISHER ADAPTOR COVERS EMERGENCY BRAKE ACCUMULATOR MOUNT ENGINE LIMITATIONS LABEL ELEVATOR TRIM CONTROL CABLES	SD360-33-25R1
UK	008-09-97	DIODES INSPECTION	SD360-53-43R1
UK	011-01-97 003-12-98 010-10-98 015-11-98	FLAP LEVER BRACKET AND LEVERS	SD360-39-04R1
UK	003-12-98	FIRE EXTINGUISHER ADAPTOR COVERS	SD360-27-26
UK	010-10-98	EMERGENCY BRAKE ACCUMULATOR MOUNT	5D360-20-11K1
ÜK	015-11-98	ENGINE LIMITATIONS LABEL	SD360-29-06
UK	016-11-98	ELEVATOR TRIM CONTROL CABLES	SD360-17-23
UK	017-11-98	ELEVATOR TORQUE TUBE BEARINGS HOUSING BOLT	SD360-27-28P1
UK	018-11-98	· ENGINE MOUNT	SD360-71-18R3
UK	011-03-99	AIR CONDITIONING WIRING	SD360-21-23 -21
STAT	ARCHETTI		
S205 2			
3205 2	66-88/S.205-1	DEAD CDAD / ATLEDON OUTCOMES	
IT.	67-100/S.205-9	REAR SPAR / AILERON OUTBOARD HINGE BRACKET	205B4
ΪŤ	67-106/S.205-5R1	AILERON - CABLE GUARD ASSEMBLY FUEL LEVEL INDICATOR TRANSMITTER	205B17
IT	67-26/S.205-4	RIGHT LANDING GEAR CONTROL ROD	S.205 B13A
ΙT	67-70/5.205-7	FLAP CONTROL SYSTEM	205B11
ΙT	67-85/S.205-6R1	NOSE GEAR BRACE CROSS MEMBER	205B15
IT	68-102/S.205-14	MARKING MODIFICATIONS	205B 14A 205B21
IT	68-33/S.205-11	FIREWALL ASSEMBLY INSULATION	205B21 205B19
IT	68-66/S.205-12	FUSELAGE FRAME NO. 2	205B20
AIRC	RAFT/AERONEFS		

MAKE / CONSTRUCTEUR
MODEL / MODELE (
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
STAI M	IRCHETT I		
S205 2	22/R		
	UED / SUITE)		
IT	68-84/\$.205-13	MLG - MICROSWITCH INSTALLATION	205854
IT IT	69-165/S.205-15R2 69-99/S.205-17R1	ENGINE CONTROL SUPPORT	205R22R
	70-192/S.205-21	FLAP CONTROL LEVER/FUEL TANK SELECTOR CONTROL KNOB	205SI-9
ĪŢ	70-76/S.205-20	MECHANICAL ENGINE DRIVEN FUEL PUMP FLAP CONTROL LEVER	205B26
IT	71-214/S.205-25	EVE BOLT CREACE EXTENDE	205 B25
IT	71-80/S.205-23	FUSELAGE / FRONT SPAR ATTACHMENTS NOSE GEAR DRAG LINK ASSEMBLY MLG CROSS MEMBERS	205B-32
IT	72-102/S.205-3R3	NOSE GEAR DRAG LINK ASSEMBLY	205-B12A
IT IT	72-110/S.205-30 72-2/S.205-24R1	MLG CROSS MEMBERS WING TANK FUEL LEVEL TRANSMITTER SCUPPERS	205B36
ÎT	72-29/S.205-27	WING TANK FUEL LEVEL TRANSMITTER SCUPPERS	205B29A
IT	72-88/S.205-28	AILERON / FLAP CONTROL CABLES LG TORQUE LINK PINS / TOW BAR ALTERNATOR BRACKET	205B31
ΙT	72-95/S.205-29	ALTERNATOR BRACKET	205B35 205B34
ΙT	73-132/5.205-32	LANDING CEAR ACTUATOR ORACICET	
IT	73-176/S.205-27	AILERON AND FLAP CONTROL CABLES	205B31B
IT IT	75-197/S.205-34	LANDING GEAR ACTUATOR	205B40
IT	76-154/S.205-38 76-5/S.205-35	WING STAD COLO	
IT	76-7/S.205-36	I ANDING GEAD DUCHINGS	205B42
ĪT	77-17/\$.205-39	NLG LEG PLATE BOLTS	205B41
IT	77-233/\$.205-42	UPPER MLG LEGS	203846
IT	77-235/S.205-44	TOROUF TUBE	205-B50
IT	77-236/S.205-22R1	MIC MIEEL AVIE COMMISSION STREET	205-B27A
IT	77-240/S.205-45	BUSHES	205B51
IT IT	79-206/S.205-41R1 81-244/S.205-46	MILEL ED ACCEMBLIZED	205 B47A
IT	83-185/\$.205-48	MUFFLER ASSEMBLIES	205B56
ĪŤ	84-142/S.205-42R7	MLG BRACE ASSEMBLIES	205B5 /
ΙT	89-28/5.205-43R2	GEAR ACTUATOR SHOCK ABSORBER	205-B49 REV A
IT	89-32/\$.205-31	WING RIB BRACKETS	205B37E
IT	93-221	LANDING GEAR ACTUATOR	205B49REVB
IT IT	95-119	MAIN GEAR BRACE ASSEMBLIES	205B58
IT	95-120 95-237	WING REAR SPAR - FLAP BRACKET ATTACHMENT MLG BRACE ASSEMBLIES GEAR ACTUATOR SHOCK ABSORBER WING RIB BRACKETS LANDING GEAR ACTUATOR MAIN GEAR BRACE ASSEMBLIES CONTROL CABLES EYE END INSPECTION REPLACEMENT/INSPECTION FLAP CABLE PULLEY BRACKET	205B48 F
		NET EACHMENT/ INSPECTION TEAP CABLE POLLEY BRACKET	205860
SIKORSK S51	Υ		
CF	CF-98-15	HELICORTED DESCUE SYSTEMS	040 700 04
US		CONTROL SYSTEM CHAIN AND SPROCKETS	CAR 702.21 17 SIC
US	47-32-15 47-50-08	HELICOPTER RESCUE SYSTEMS CONTROL SYSTEM CHAIN AND SPROCKETS VERTICAL HINGE PINS PLANET PINION SHAFTS WEAR	7 SIC
US	48-17-03	PLANET PINION SHAFTS WEAR BEVEL DRIVE GEAR SPLINES TAIL CONE MOUNTING LONGERONS GEAR SHAFT REPLACEMENT ROTOR LINK ASSEMBLIES	8 REV B SIC
	48-18-02	BEVEL DRIVE GEAR SPLINES	40 REV A SIC
US	50-08-01 51-22-01	TAIL CONE MOUNTING LONGERONS	38 REV A SIC
US US	51-22-01	DOTOR LINE ACCEMBLIES	172 SIC 122 REV B SIC
	56-13-02	MAIN ROTOR HIB REPLACEMENT	76 REV D & F SIC
	56-16-03		676 SIC
	60-13-04	ROTOR SHANK ROD	
US	67-29-06	TAIL ROTOR SLEEVE & TUBE ASSY	
S55 SEI	DIFS		
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
0.5	54-01-03	FUEL STRAINER SCREEN	1430-410 SIC
US	54-13-01 54-16-01 54-19-02	STAR ASSEMBLY BOLT REPLACEMENT	1410-222 SIC
US	54-16-01		1435-383 SIC
US	54-19-02	MAIN TRANSMISSION SERVO SAFETY CLIP SUPPORT ASSEMBLY CRACKS	1440-458 SIC
05	54-20-02		
	55-25-04 56-16-03		1420-632 SIC 1410-669 SIC
	56-23-03	HORIZONTAL HINGE PIN ASSEMBLY	
UŞ	60-13-04	ROTOR SHANK ROD	
	63-05-02	MAIN ROTOR BLADES	
	65-08-02	MAIN ROTOR BLADES	55B10-4
US	66-04-03		55B10-7E
	67-17-06 67-29-07		55B20-1E 55B40-5
			55B35-3
			55840-6
US	73-16-01	ENGINE TURBINE FAILURE	55-01-1 ASB
US	75-22-12	INFLIGHT POWER LOSS	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER	(SERIES / SERIE)	
ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
SIKORSKY		
S55	( S55 SERIES )	
US 75-04-02	MAIN ROTOR SPINDLES	
S55/T	( S55 SERIES )	
S55B	( S55 SERIES )	
US 70-12-04 US 75-04-02	MAIN ROTOR SHAFT CRACKS	55835-3
03 /5-04-02	MAIN ROTOR SPINDLES	
S55B/T	( S55 SERIES )	
S58 SERIES		
CF CF-98-15 US 57-19-02	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US 59-16-04	HYDROMECHANICAL CLUTCH ROLLERS DAMPER TRUNNION BOLT	······································
US 60-17-03R1 US 60-24-04	MAIN ROTOR BLADE SPAR	58B15-4K
US 61-01-03	ELECTRICAL CABLE INPUT BEVEL GEAR	58B55-1 1635-117 REV A&E SIC
US 64-02-06R1 US 66-19-04	FILON AND TAIL CONE FITTINGS	58B20-11A
US 74-15-06	TAIL ROTOR BLADES TAIL ROTOR GEAR BOX	58B15-6A 58B35-17C
US 75-07-07 US 75-07-08	EMERGENCY HATCH HANDLES	55B50-1A
US 75-07-08 US 75-13-01	TAIL ASSEMBLY MAIN ROTOR ASSEMBLY	58B15-14A
US 78-21-05	TAIL ROTOR BLADES	58B10-10 58B40-5
US 82-01-07 US 85-17-08	HORIZONTAL HINGE PINS MAIN ROTOR HEAD BOLTS	
US 86-25-05	TAIL ROTOR GEARBOX DINIONS/GEARS	58B10-19 58B35-26
US 94-12-07 US 95-10-09	ENGINE DRIVESHAFT ASSEMBLY	SUPERCEDES ON-10-00
US 95-26-08	MAIN GEARBOX RING GEAR FAILURE MAIN ROTOR SHAFT ASSEMBLY	ASB 58B35-32
\$58E	( S58 SERIES )	
US 89-25-01	ENGINE FIRE EXTINGUISHING SYSTEM	
S58E/T	( S58 SERIES )	
US 78-05-01 US 90-10-02	FUEL BYPASS LINES	58B30-12C
	ENGINE DRIVESHAFT ASSY	58B 35-30
<b>S58J</b> US 89-25-01	( S58 SERIES ) ENGINE FIRE EXTINGUISHING SYSTEM	
	ENGINE FIRE EXTINGUISHING SYSTEM	
<b>S61 SERIES</b> CF CF-98-15	HELICOPTER RESCUE SYSTEMS	
US 65-08-02	MAIN ROTOR BLADES	CAR 702.21 61B15-3
US 66-19-04 US 67-29-05	TAIL ROTOR BLADES	61B15-5A
US 68-19-07	ROTARY WING HUB HINGE PINS ROTOR BLADE SPINDLES	61B10-4
US 70~09-03 US 71-05-01	TAIL GEAR BOX PITCH BEAMS	61B35-7
US 71-21-03	MAIN LANDING GEAR AXLE LINK IN SERVO VALVE INPUT LINKAGE	61B25-3 61B65-6A
US 72-03-01 US 78-20-05R4	ALUM FORGINGS FLIGHT CONTROL SYSTEM	61B40-5A
US 79-12-10	MAIN ROTOR SPINDLES TAIL ROTOR BLADE	61B10-33F
US 80-17-07 US 84-01-51	HORIZONTAL HINGE PINS	61B15-26 61B15-1E
US 84-25-01	ROTARY WING HEAD SHAFT NUT MAIN GEARBOX INSPECTION	61810-14
US 86-23-08	MAIN ROTOR HUB LOWER PLATE	
US 89-07-09 US 90-01-04	MAIN ROTOR GEARBOX - HELICAL GEAR MAIN ROTOR HUB UPPER PLATE	0.10.10
US 91-12-01	<ul> <li>MAIN ROTOR HEAD SLEEVE AND SPINDLE ASSY</li> </ul>	61B10-46 61B10-48
US 97-19-06 US 98-26-02	MAIN ROTOR BLADE DEBONDING MAIN ROTOR SHAFT	ASB61B15-29A
	MATIV ROTOR SHAFT	\$6135-20640-001
S61L US 68-20-08	( S61 SERIES ) FUNCTIONAL TEST OF AFCS	CAROT
US 68-21-06	FUNCTIONAL TEST OF AFCS DEACTIVATE AFCS	61865-1
US 70-08-03 US 70-15-01	HEATER INLET CHECK VALVE CABIN HEATER BLOWER	
	ELECTRICAL FEEDER WIRE GAGE	61B55-14 61B55-27A
US 72-25-04 US 73-15-01	OF MATIN KOTOK CONTROL	61835-18
US 74-20-07R5	REAR FUSELAGE AND PYLON FITTINGS MAIN ROTOR BLADES	61B2O-6A 61B15-6P
US 74-20-09	MAIN ROTOR BLADES	61B15-9F

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)

ORIGINE ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN
CIKODO			BULLETIN DE SERVICE DE REF
SIKORSI S61L		( S61 SERIES )	
(CONTIN	NUED / SUITE)	( SOI SEKIES )	
US	74-25-05	MAIN ROTOR BLADES	
US	74-25-06 75-12-01	TAKEOFF GROSS WEIGHT LIMITATION	
US	75-17-33	MAIN ROTOR BLADES BAGGAGE DOORS	61B15-18B
US	75-26-10	BAGGAGE DOORS COMPONENT REPLACEMENT	65B20-11B
US	76-03-02	FRACTURES IN BARREL NUTS	61B35-36B
US	76-06-01	HYDRAULIC PUMPS	
US	76-08-01R1 78-12-05	TAIL ROTOR PYLON FIXED S-61L TYPE LANDING GEARS	61B20-13C
US	84-11-03	POSSIBLE FLANGE FAILURE	61B25-6C
US	85-15-05	MAIN ROTOR HORN EYEBOLT/EYEBOLT ASSY	
US	85-18-05R2 87-15-11	MAIN ROTOR BLADES	61B15-6RP
03	87-15-11	MAIN GEARBOX SERVO SUPPORT BRACKET	
S61N		( S61 SERIES )	
US	68-20-08	FUNCTIONAL TEST OF AFCS	61B65-1
US US	68-21-06 70-08-03	DEACTIVATE AFCS	
US	70-08-03	HEATER INLET CHECK VALVE CABIN HEATER BLOWER	61855-14
US	72-16-06	ELECTRICAL FEEDER WIRE GAGE	61B55-27A
US	72-25-04	LUSS OF MAIN ROTOR CONTROL	61835-18
US US	74-20-07R5 74-20-09	MAIN ROTOR BLADES	61B15-6P
US	74-25-05	MAIN ROTOR BLADES MAIN ROTOR BLADES	61B15-9F
US	74-25-06	TAKEOFF GROSS WEIGHT LIMITATION	
US	75-08-15	BAGGAGE DOORS	
US US	75-12-01 75-17-33	MAIN ROTOR BLADES BAGGAGE DOORS	61B15-18B
US	75-26-10	BAGGAGE DOORS COMPONENT REPLACEMENT	65820-118
US	76-03-02	FRACTURES IN BARREL NUTS	61B35-36B
US	76-06-01	HYDRAULIC PUMPS	
US US	78-05-07 78-12-05	MAIN LANDING GEAR FIXED S-61L TYPE LANDING GEARS	61855-40
US	84-11-03	POSSIBLE FLANGE FAILURE	61B25-6C
US	85-15-05	MAIN ROTOR HORN EYEBOLT/EYEBOLT ASSY	
US	85-18-05R2	MAIN ROTOR BLADES	61B15-6RP
US US	87-15-11 89-04-01R3	MAIN GEARBOX SERVO SUPPORT BRACKET	61B25-15 PT III
		TOTAL CONTROL MENT SCOTTON TOTAL MASERIALT	01020 10 11 111
S64 SE CF	RIES CF-98-15	UCI TODATTA DECOLIE CVCTEMO	CAD 700 04
Cr	CL-38-12	HELICOPTER RESCUE SYSTEMS	CAR 702.21
S64E		( S64 SERIES )	
US	74-16-05	MAIN ROTOR HEAD	
US US	75-11-11 76-06-01	TORQUEMETER ENGINE TO GEARBOX SHAFT FAILURE HYDRAULIC PUMP PISTONS - FLAKING OF CHROME PLATING	
US	85-18-01	MAIN ROTOR BLADE OUTER SPARS	64B15-8A
US	85-25-03	TORQUE TUBE INNER BRACKET ASSEMBLY	64B10-4A ASB
US	90-26-12 97-19-10	MAIN ROTOR BLADE SPAR	64B15-4C
US	97-19-10	MAIN TRANSMISSION PLATES(SUPERSEDES 77-20-01)	64B35-7C
S76 SE			
CF	CF-98-15	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US	98-17-15	SWASHPLATE ASSY RETAINER BOLTS	76-65-47
S76A		( S76 SERIES )	
CF	CF-84-05	TAIL ROTOR CONTROL CABLES	CSH 76-133A
CF	CF-90-05	NUMBER 1 PRIMARY SYSTEM	76-24-9
US US	79-25-08 80-14-16R1	HYDRAULIC PUMPS MAIN ROTOR BLADE SPINDLE	76-65-13A
US	80-22-55R4	MAIN ROTOR DAMPER RODS	
US	81-07-51R1	MAIN ROTOR SPINDLES	76-65-22B
US	81-09-07	MAIN ROTOR BLADES	76-65-23
US	81-21-04 81-23-04	MAIN ROIDR BLADES MAIN ROTOR SCISSORS ASSEMBLY MAIN GEARBOX OVERHAUL	76-66-14
US	82-06-08	DC GENERATORS	76-24-7
US	82-06-51	MAIN GEARBOX SHAFT AND SPUR PINIONS	76-66-16A
US	82-17-03	ROTOR BRAKE ASSEMBLY R & L MLG POSITIONING ROD ENDS	76-77-7
	82-25-01R1 84-06-02	. TAIL ROTOR BLADES	76-32-10 76-65-35
	84-08-01	SHAFT BEARING ASSEMBLY	76-66-18
US	84-10-02	MAIN ROTOR BLADE SPAR	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)
SUBJECT

ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
SIKORS	KY		SOCCETIVOE SERVICE DE REF.
S76A	NUED / CUTTO)	( S76 SERIES )	
US	NUED / SUITE) 84-15-04	TAIL ROTOR CONTROLS	
US	84-17-01	MAIN ROTOR PITCH HORN	76-133 CSB
US	84-19-51R1	CENTER FIREWALL SUPPORTS	76-53-25 ASB
US	85-15-06 86-09-11	TAIL ROTOR DRIVE SHAFT BEARINGS	76-66-20 ASB
US	86-14-07	MAIN & NOSE LANDING GEAR COMPONENTS PILOTS YAW CONTROL ROD ASSEMBLY	76-32-20
US US	86-19-14	TAIL ROTOR ASSEMBLY	76-67-22A
US	87-12-06 87-23-07R1	GENERATOR CONTROL UNIT	76-24-8
US	87-25-02	ELECTRICAL DOOR LOCKING ACTUATOR AC ELECTRICAL POWER	76-52-10A
US US	89-07-12	TAIL ROTOR HORN	76-24-5
US	91-08-03 91-24-13	FATIGUE FAILURE - VERTICAL PYLON FORWARD FITTING	76-55-12
US	94-14-20	VERTICAL PYLON SPAR CAP & WEB T/R BLADE SPAR ELLIPTICAL CENTERING PLUG DISBOND	76-55-12
US	99-11-04	AC GENERATOR INTERLOCK SYSTEM	ASB 76-65-35A REV 76-77-4A REV A
US	99-19-30	TAIL GEARBOX FORWARD FAIRING	76-55-16
S76C		( S76 SERIES )	
US US	99-01-09 99-07-01	FUEL SUPPLY LINE FITTING	76-28-4
US	99-19-30	HYDROMECHANICAL UNIT TAIL GEARBOX FORWARD FAIRING	
TOUY		TATE GEARDON FORWARD FAIRING	76-55-16
COUPE	60		
KYPOWE	R I 1000		
GDIV 41	1000		
LINGSE 41 2B	37		
41 ∠B UK	0147 PRE 80	CHOILI DED LIADNECC ATTACAMENT	
UK	0148 PRE 80	SHOULDER HARNESS ATTACHMENT SHOULDER HARNESS ATTACHMENT	96
UK	0149 PRE 80	CANOPY CATCH	97 98
UK	0150 PRE 80	CANOPY CATCH	99
43 3B			
UK	0151 PRE 80	SHOULDER HARNESS ATTACHMENT	96
UK	0152 PRE 80 0153 PRE 80	SHOULDER HARNESS ATTACHMENT CANOPY CATCH	97
		CANOFT CATCH	99
43 3D UK	Oded DDE BO		
UK	O151 PRE 80 O152 PRE 80	SHOULDER HARNESS ATTACHMENT SHOULDER HARNESS ATTACHMENT	96
UK	0153 PRE 80	CANOPY CATCH	97
50			99
UK	001-07-87	AFT FIN SPAR	
		ATT THE STAR	107/T50
<b>51</b> UK	005-09-97	41104741104	
	003 03 37	ALUMINUM ALLOY SPAR BOOMS	109/T51 ISS. 2
59D			
	0159 PRE 80 0160 PRE 80	CANOPY CATCH SPIGOT MOUNTING	4
	0161 PRE 80	ANTISYMMETRIC WING BENDING VIBRATION MANDATORY INSPECTION OF WINGS	
UK	0162 PRE 80	ELEVATOR ACTUATOR FITTING	
	0163 PRE 80	ELEVATOR ACTUATOR BRACKET	18
	0164 PRE 80 0165 PRE 80	DIVE BRAKE OPERATING LIMITATIONS DIVE-BRAKE CONTROL MECHANISM	
UK	0166 PRE 80	UNIBAL BEARINGS ALUMINIUM HOUSINGS ON ROOT RIBS	28
	0167 PRE 80	RODDER PEDALS	31 33
	0168 PRE 80 0169 PRE 80	INSPECTION OF RUDDER CABLES	
UK	002-01-82	INSPECTION CRITICAL AREAS LOOSE BOLTS RUDDER ACTUATOR	T T NO 10: /===
	019-01-87	ELEVATOR PUSH ROD	T.I.NO.101/T59 T.I.NO.106/T59
67C			
CF	CF-96-23	RUDDER CABLE FAIRLEADS INSTALLATION	1100
	MOD575	NOSEWHEEL STEERING EYE BOLT	MOD # 670 MOD # M575/2
	022 150/1	FUEL FLOW CHECK	022
	33/4	ELEVATOR BELLCRANK PIVOT STIFFNUT BACKING OFF COMPLIANCE TIME CHANGE FOR MOD M412	150/1
		TANGE TIME GHANGE FOR MOD M412	M412

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)
SUBJECT
SUJET REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			BULLETIN DE SERVICE DE REF.
SLING:	SBY		
T67C			
	INUED / SUITE)		
UK	82/1	DELAMINATION OF WING WALK AREA	
UK	83/2	NOSEWHEEL STEEDING ADM ATTACHMENT DOLT	MOD M669B, M669C
UK	013-11-85	NOSEWHEEL STEERING ARM ATTACHMENT BOLT	83
UK	005-05-87	INSPCTION OF RUDDER/TOE BRK ASSY HEX CAP SCREWS	SB008#2 & MOD:162#3
UK	016-05-87	RUDDER PEDAL/CABLE CLEARANCE LIMITATIONS MAX G LOAD	015
UK	017-05-87	WING TOP HOLE FOR MLG LEGS	MOD # 237ISS. 2
UK	018-05-87	BATTERY TRAY	MOD # 239 ISS. 2
UK	004-07-88	BATTERY TRAY  RUDDER PEDAL ADJUST  RUDDER CABLE SUPPORT	MOD # 245 ISS. 2
UK	014-11-88	DUDDER CARLE CURRORT	MOD # 363
UK	024-03-89		MOD # 3/1
UK	0.15 00 00	AEROQUIP 601 HOSES	029
UK	002-01-93	RH ELEV. GLASS ROPE REINFORCEMENT AILERON SUPPORT RIB OUTBOARD (RIB 8) CRACKING TAILPLANE ATTACH BOLTS	MOD # 366A ISS.2
UK	006-01-93	ATLERON SUPPORT RIB OUTBOARD (RIB 8) CRACKING	SB42 & MOD:M510B
UK	007-01-93		010 13301 2
UK	008-01-93	FLAP CENTRE DRIVE BRACKETS	018
UK	010-01-93	SERVICE LIFE	020
UK	010-01-93	FLIGHT IN THUNDERSTORM AND LIGHTNING	O25 ISSUE 2
	012-01-93	SAFETY MARNESS INSPECTION	031
UK	014-01-93	RUDDER BAR PEDAL SUPPORT LUGS	O33 ISSUE 4
UK	015-01-93	RUDDER HINGE SUPPORT ANGLES	034
UK	015-03-93	ENGINE SETTING TO ALLEVIATE ENGINE STOP IN SPIN	43 ISSUE 2
UK	017-01-93	THROTTLE CABLE-INSPECTION	O4O ISSUE 2
UK	019-01-93	REROUTED BONDING CABLE	MOD # 400
UK	001-12-94	NOSE LANDING GEAR INSPECTION AND MODIFICATION CLEARANCE U/C LEG AND ENGINE MOUNT	65 ISS.1&MOD:M646#3
UK	004-03-94	CLEARANCE U/C LEG AND ENGINE MOUNT	SB44#1 & MOD:575#2
UK	004-04-94	FUEL FLOW-AEROBATIC FLIGHT	22 ISS. 3
UK	005-03-94	FLOP TUBE SUPPORT SPRING	MOD M567/2
UK	005-04-94	INSPECT THROTTLE CABLE RUDDER CABLE SUPPORT	SB55#3 & MOD:M496B#2
UK	006-03-94	RUDDER CABLE SUPPORT	MOD M444B
UK	010-05-94		52 ISS 3
UK	011-03-94	WINDSCREEN DE-MISTING DUCT ROUTING	48 ISS 1
UK	013-05-94		MOD // F70
UK	015-03-94	RUDDER CABLE TO LINK PLATE SCREW	51
UK	002-10-95	WIRING TO THE STARTER	MOD # 571
UK	008-04-95	CONTROL COLUMN TO SEAT CLEARENCE	79/2
UK	009-04-95	LOCATING SPIGOT ON SEAT	MOD MOCE
UK	002-12-97	FLEVATOR BELLCRANK PIVOT STIFFWHT BACKING OFF	150/1
UK	003-09-97	INSPECTION OF STEERING ARM ON NOSE LEG	139 ISS.1 FH 32-16,
UK	005-08-97	CANOPY LATCH CHECK PLACARD	M810
UK		DIDDED DEDAL DAD INSCRICTION	120 ISSUE 3
UK	012-01-97 009-03-99	RUDDER PEDAL BAR INSPECTION MASTER SWITCH ALTERNATIVE DIODE	M754
		772 01002	
SOCATA			
TB 9			
FR	79-251(A)	BEARING FRAME	
FR	80-059(A)	SUMP DRAIN	
FR	81-057(A)	PROP CONE	
FR	81-082(A)	HORIZONTAL STABILIZER	
FR	81-202(A)	FORWARD C OF G	
FR	82-094(A)	ELEVATOR REINFORCEMENT	14, 15
FR	82-128(A)R1	ENGINE MOUNT	16/1
FR	82-144(A)	TRIM TAB	18
FR	85-043(A)	PITCH TRIM	24
FR			25
	85-090(A)	HORIZONTAL STABILIZER	
FR	85-130(A)	BATTERY TRAY	18
FR	87-003(A)	STABILATOR CONTROL ROD	29
FR	87-118(A)	BRAKE HYDRAULIC LINE ATTACHMENT	33
FR	87-141(A)R2	REAR ATTACHMENT FRAME OF HORIZONATAL STABILIZER	35/1
FR	89-097(A)R1	FRONT SEAT SAFETY BELTS	10-044-25
FR	89-098(A)R1	FRONT SEAT SLIDERS	43/1
FR	89-177(A)R3	FUEL TANKS	48/3
FR	90-143(A)	OIL COOLER	50-1
FR	90-240(A)	CARBURATOR AIRBLEED ON ENGINE COWLING	51
FR	91-031(A)	HORIZONTAL STABILIZER BALANCE WEIGHT	57
FR	91-143(A)R1	CATCHES ON CABIN ACCESS DOOR	58/1
FR	92-152(A)R4	EXHAUST SYSTEM	10-072-78 REV 2
FR	92-155(A)R1	FUEL TANK AIR VENT SYSTEM	10-064/1-28 REV 1
FR	94-114(A)R1	FRONT SEATS	10-075-25 REV 1
FR	94-247(A)	WING RIBS, FUEL TANK AREA	
FR	94-248(A)	RIB ATTACHMENT	10-083-55
FR	94-264(A)R1	WING FRONT ATTACHMENTS	10-081-57 REV 1
FR	94-265(A)R4	MAIN LANDING GEAR	10-085-57 REV 2
FR	96-142(A)	UPPER ATTACHMENT OF FRONT BELTS	10-104-25
, , ,	30 (42(A)	OFFICE ATTROPPED OF TROPPED DEETS	10 104 20

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER SUBJECT
SUJET

REFERENCE SERVICE BULLETIN

FR 96-143(A)	URIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
TB 9	SOCATA			
FR   996-143(A)				
FR   99-143(A)		NUED / SUITE)		
FR	FR	96-143(A)	UPPER ATTACHMENT OF FRONT BELTS	10-103-25
TR			FUEL SYSTEM	
TB 10 FR 79-251(A) FR 81-057(A)	FR	1999-319(A)	VERTICAL STABILIZER FORWARD JUNCTION DOUBLER	10 000 20
FR	TR 10			
FR 80-059(A)			DEADING EDAME O	
FR   81-052(A)   PROP CONE   FR   81-052(A)   HORIZONTAL STABILIZER   FR   81-202(A)   HORIZONTAL STABILIZER   FR   81-202(A)   HORIZONTAL STABILIZER   FR   81-202(A)   HORIZONTAL STABILIZER   FR   81-202(A)   HORIZONTAL STABILIZER   FR   81-043(A)   HINT TAB   FR   81-043(A)   HINT TAB   FR   81-043(A)   BALLANCE WEIGHTS HORIZ. STAB.   SL   18   FR   81-043(A)   BALLANCE WEIGHTS HORIZ. STAB.   SL   18   FR   81-043(A)   BALLANCE WEIGHTS HORIZ. STAB.   SL   18   FR   81-043(A)   BALLANCE WEIGHTS HORIZ. STAB.   SL   18   FR   81-141(A)R2   HORIZONTAL STAB. ATTACHMENTS   33   FR   87-141(A)R2   HORIZONTAL STAB. ATTACHMENTS   33   FR   81-141(A)R2   HORIZONTAL STAB. ATTACHMENTS   33   FR   81-141(A)R2   HORIZONTAL STAB. ATTACHMENTS   10-044-25   FR   89-177(A)R3   FRONT SEAT BELT ATTACHMENTS   43/1   FRONT SEAT BELT ATTACHMENTS   43/1   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENTS   44/3   FRONT SEAT BELT ATTACHMENT   44/3   FRONT SEAT BELT TARK SEAT FACKS   44/3   FRONT SEAT BELT TARK SEAT SEAT FACKS   44/4   FRONT SEAT BELT TARK SEAT SEAT FACKS   44/4   FRONT SEAT SEAT SEAT FACKS   44/4   FRONT SEAT SEAT FACKS   44/4   FRONT SEAT SEAT FACKS   44/4   FRONT SEAT SEAT FACKS   44/4   FRONT SEAT SEAT SEAT FACKS   44/4   FRONT SEAT SEAT FACKS   44/4   FRONT SEAT SEAT FACKS   44/4   FRONT SEAT SEAT SEAT SEAT SEAT SEAT SEAT SEA				
FR 81-032(A)				
FR 81-202(A)	FR			
FR 82-144(A)   FINI TAB				
FR   82-434(A)				
FR 85-090(A)   PITCH TRIM   PR 85-090(A)   BALANCE WEIGHTS HORIZ. STAB.   SL 18   FR 85-130(A)   BATTERY TRAY   SL 18   FR 85-130(A)   STABILATOR CONTROL ROD   29   FR 87-118(A)   BRAKE HYDRAULIC LINE ATTACHMENTS   33   FR 87-141(A)R2   HORIZONTAL STAB. ATTACHMENTS   35/14   FR 87-095(A)R1   FRONT SEAT BELT ATTACHMENTS   10-044-25   FR 89-095(A)R1   FRONT SEAT TRACKS   43/1   FRONT SEAT TRACKS   48/3   FUEL TANK DRAINING   48/3   FUEL TANK DRAINING   48/3   FUEL TANK DRAINING   48/3   FUEL TANK DRAINING   48/3   FUEL TANK DRAINING   48/3   FUEL TANK DRAINING   48/3   FUEL TANK AIR VENT   57/4   FRONT SEAT TRACKS   58/1   FR 91-145(A)   AUTOPILOT CONTROL SYSTEM   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28RT   60-644/1-28				
FR 85-090(A)   BALANCE WEIGHTS HORIZ. STAB.   24				
FR 85-130(A)   SATTERY TRAY   SATTERY TRAY   STABLATOR CONTROL ROD   SE   FR 87-118(A)   STABLATOR CONTROL ROD   SE   FR 87-118(A)   BRAKE HYDRAULIC LINE ATTACHMENTS   35,74   STABLATOR CONTROL ROD   SE   SE   SE   SE   SE   SE   SE   S				24
FR 87-003(A)   STABILATOR CONTROL ROD   20				
FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 39 FR 87-141(A)R2 HORIZONTAL STAB. ATTACHMENTS 35/1 FR 89-098(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-098(A)R1 FRONT SEAT TRACKS 10-044-25 FR 89-177(A)R3 FUEL TANK DRAINING 48/3 FR 90-143(A) OIL COOLER 58/7 FR 91-031(A) BOOM BALANCE WEIGHT 57 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-143(A)R1 FRONT SEAT BLIT ARK REA 10-044-25 FR 92-155(A)R1 FUEL TANK AIR VENT 10-064/1-28R1 FR 92-155(A)R1 FUEL TANK AIR VENT 10-064/1-28R1 FR 92-206(A)R3 EXHAUST SYSTEM 58 10-073-78R FR 94-247(A) FIRST STEEM 10-073-78R FR 94-247(A) FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-249(A)R1 FIRST STEEM 10-073-78R FR 94-265(A)R4 MING FRONT ATTACHMENTS 10-083.55 FR 94-265(A)R4 MING FRONT ATTACHMENTS 10-083.55 FR 94-265(A)R4 MING FRONT ATTACHMENTS 10-081.57 REV FR 94-265(A)R4 MING FRONT ATTACHMENTS 10-081.57 REV FR 99-319(A) VERTICAL STABILIZER FORWARD JUNCTION DOUBLER 10-099-28  TB 20 FR 84-074(A) FUEL SYSTEM 10-099-28  TB 20 FR 84-074(A) NOSE GEAR TO STABILIZER FORWARD JUNCTION DOUBLER 10-099-28  FR 85-015(A) FUEL SYSTEM 10-099-28  FR 85-015(A) FUEL SYSTEM 10-099-28  FR 85-03(A) BATTERY TRAY 10-099-28  FR 87-030(A) STABILTOR CONTROL ROD 29 FR 87-030(A) STABILTOR CONTROL ROD 29 FR 87-031(A) STABILTOR STABILT LITER STATCHMENTS 10-044-25 FR 89-195(A)R1 HIGH STATCHMENTS 10-044-25 FR 89-096(A)R2 HIGH STATCHMENTS 10-044-25 FR 89-096(A)R2 HIGH STATCHMENTS 10-044-25 FR 89-183(A)R1 FIRE MALL FRAME FR 89-196(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-196(A)R1 FIRE MALL FRAME FR 89-196(A)R1 FIRE MALL FRAME FR 89-196(A)R1 FIRE MALL FRAME FR 89-196(A)R1 FIRE FRAME 10-075-25R1 FR				
FR 87-141(1) R2				
FR 89-098(A)R1	FR	87-141(A)R2	HORIZONTAL STAB. ATTACHMENT	
FR   89-098 (A)R1   FRONT SEAT TRACKS   43/1   FR   89-177 (A)R2   FUEL TANK DRAINING   48/3   FR   90-143 (A)   OIL COOLER   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1   50/1		89-097(A)R1		
FR 90-143(A) DIL CODLER 50/1 FR 91-031(A) BOOM BALANCE WEIGHT 50/1 FR 91-143(A)R1 CABIN ACCES DOOR CATCHES 58/1 FR 91-143(A)R1 CABIN ACCES DOOR CATCHES 58/1 FR 91-143(A)R1 CABIN ACCES DOOR CATCHES 58/1 FR 91-143(A)R1 FUEL TANK ARE WEIGHT 10-064/1-28R1 FR 92-155(A)R1 FUEL TANK ARE WEIGHT 10-064/1-28R1 FR 92-206(A)R3 EXHAUST SYSTEM 58 10-073-78R FR 94-114(A)R1 FRONT SEAT 10-075-25R1 FR 94-24R1(A) WING RIBS, FUEL TANK AREA 10-075-25R1 FR 94-24R1(A) WING RIBS, FUEL TANK AREA 10-083-55 FR 94-248(A) FIN INTERMEDIATE RIB ATTACHMENT 10.083.55 FR 94-249(A)R1 WING FRONT ATTACHMENTS 10.081.57 REV FR 94-264(A)R1 WING FRONT ATTACHMENTS 10.081.57 REV FR 94-264(A)R1 WING FRONT ATTACHMENTS 10.081.57 REV FR 94-265(A)R4 MAIN LANDING GEAR THACHMENTS 10-03-25 FR 1999-062(A) FUEL SYSTEM 10-03-25 FR 1999-062(A) FUEL SYSTEM 10-03-25 FR 1999-062(A) FUEL SYSTEM 20-03-28 FR 1999-062(A) FUEL SYSTEM 20-03-28 FR 88-044(A) NOSE GEAR MICROSWITCHES 23 FR 88-044(A) NOSE GEAR MICROSWITCHES 23 FR 88-045(A) BATTERY TRAY SL FR 88-015(A) BATTERY TRAY SL FR 88-030(A) BATTERY TRAY SL FR 88-117(A) NLG - LH HOYRAULIC LINE ATTACHMENTS 33 FR 89-096(A)R1 FRONT SEAT TRACKS 43/1 FR 89-097(A)R1 FRONT SEAT TRACKS 43/1 FR 89-144(A) R1 FRONT SEAT TRACKS 58/1 FR 89-154(A) R1 FRONT SEAT TRACKS 64/1 FR 89-154(A) R1 FRONT SEAT TRACKS 58/1 FR 89-154(A) R1 FRONT SEAT TRACKS 64/1 FR 89-154(A) R1 FRONT SEAT TRACKS 64/1 FR 89-154(A) R1 FRONT SEAT TRACKS 66/1 FR 99-143(A) R1 FRONT SEAT TRACKS 64/1 FR 99-143(A) R1 FRONT SEAT TRACKS 64/1 FR 99-144(A) R1 FRONT SEAT TRACKS 64/1 FR 99-144(A) R1 FRONT SEAT TRACKS 66/1 FR 99-144(A) R1 FRONT SEAT TRACKS				
PR   90-031(A)   OIL COOLER   50/1				
FR   91-145(A) R1   CABIN ACCESS DOOR CATCHES   55/1				
FR   91-145(A)				57
FR 92-155(A)R1 FUEL TANK AIR VENT 10-064/1-28R1 FR 92-206(A)R3 EXHAUST SYSTEM 10-064/1-28R1 FR 94-14(A)R1 FRONT SATS 10-073-78R SP 94-247(A) WING RIBS, FUEL TANK AREA 10.084,57 FR 94-248(A) FIN INTERMEDIATE RIB ATTACHMENT 10.083,55 FR 94-249(A)R1 WING REAR ATTACHMENT FITTINGS 10.082,57 REV FR 94-264(A)R1 WING REAR ATTACHMENT FITTINGS 10.081,57 REV FR 94-266(A)R1 WING REAR ATTACHMENT FITTINGS 10.081,57 REV FR 94-265(A)R4 MAIN LANDING GEAR 10.081,57 REV FR 94-265(A)R4 MAIN LANDING GEAR 10.085,57 REV FR 94-265(A)R4 MAIN LANDING GEAR 10.085,57 REV FR 96-143(A) UPPER ATTACHMENTS OF FRONT BELTS 10-10-325 FR 1999-062(A) FUEL SYSTEM 10-099-28 FR 1999-062(A) FUEL SYSTEM 10-099-28 FR 84-021(A) ENGINE MOUNT 20 FR 85-015(A) WING PARIA HOLES 22 FR 85-043(A) PITCH TRIM 24 FR 85-03(A) PITCH TRIM 24 FR 85-03(A) BATTERY TRAY 25 FR 85-03(A) BATTERY TRAY 26 FR 85-03(A) MAIN LANDING GEAR MICROSWITCHES 27 FR 87-030(A) STABILIATOR CONTROL RDD 29 FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS 28 FR 87-031(A) MAIN LANDING GEAR BOXES 30 FR 87-031(A) MAIN LANDING GEAR BOXES 30 FR 87-031(A) MAIN LANDING GEAR BOXES 30 FR 87-117(A) NLG - LH HYDRAULIC LINE 34 FR 87-118(A) PRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-118(A) PRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-118(A) PRAKE HYDRAULIC LINE ATTACHMENTS 35 FR 87-141(A)R2 HORN LEVEL ATTACHMENTS 35 FR 87-141(A)R2 HORN LEVEL ATTACHMENTS 35 FR 87-141(A)R2 HORN LEVEL ATTACHMENTS 35 FR 87-141(A)R2 HORN LEVEL ATTACHMENTS 35 FR 87-141(A)R2 HORN LEVEL ATTACHMENTS 35 FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40 6 45/2 FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40 6 45/2 FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENTS 50-1 FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENTS 50-1 FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENTS 50-1 FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENTS 50-1 FR 89-176(A)R1 FRONT SEAT SEAT TRACES 50 FR 80-143(A)R1 FRONT SEAT SEAT TRACES 50 FR 80-143(A)R1 FRONT SEAT SEAT TRACES 50 FR 80-143(A)R1 FRONT SEAT TRACES 50 FR 80-143(A)R1 FRONT SEAT TRACES 50 FR 80-143(A)R1 FRONT SEAT TRACES 50 FR 80-143(A)R1 F				
FR 92-206(A)R3 EXHAUST SYSTEM SB 10-073-78R FR PR 34-114(A)R1 FRONT SEATS 10-073-78R FR PR 94-124R(A) FIN INTERMEDIATE RIB ATTACHMENT 10-083.55 FR 94-248(A) FIN INTERMEDIATE RIB ATTACHMENT 10-083.55 FR 94-249(A)R1 WING REAR ATTACHMENT 11TINGS 10-083.55 FR 94-264(A)R1 WING REAR ATTACHMENT FITTINGS 10-082.57 REV FR 94-265(A)R1 WING FRONT ATTACHMENT 11TINGS 10-081.57 REV FR 94-265(A)R1 WING FRONT ATTACHMENTS 10-081.57 REV FR 94-265(A)R1 WING FRONT ATTACHMENTS 10-081.57 REV FR 99-19(A) UPPER ATTACHMENTS 0F FRONT BELTS 10-103-25 FR 1999-062(A) FULL SYSTEM 10-103-25 FR 1999-062(A) FULL SYSTEM 10-103-25 FR 1999-019(A) VERTICAL STABILIZER FORWARD JUNCTION DOUBLER 10-099-28 FR 84-074(A) NOSE GEAR 21 FR 85-004(A) LANDING GEAR MICROSWITCHES 23 FR 85-015(A) WING - DRAIN HOLES 26 FR 85-015(A) WING - DRAIN HOLES 26 FR 85-03(A) PITCH TRIM 24 FR 87-031(A) BATTERY TRAY SL 18 FR 85-03(A) STABILATOR CONTROL ROD 29 FR 87-031(A) MAIN LANDING GEAR BOXES 30 FR 87-031(A) ATLERONS - BALANCE WEIGHT RIVETS 28 FR 87-117(A) NICG - LH HYDRAULIC LINE 34 FR 87-114(A)R2 HORAULIC LINE 34 FR 87-114(A)R2 HORAULIC LINE 34 FR 87-114(A)R2 HORAULIC LINE 34 FR 89-096(A)R2 HORAULIC LINE ATTACHMENTS 35/1 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 35/1 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-197(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-196(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-196(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-196(A)R1 FRONT SEAT BELT ATTACHMENT 10-072-78 REV 10-075-25R1 FR 91-144(A) PORTOR SEAT SEAT SEAT SEAT SEAT SEAT SEAT SEAT				
FR 94-114(A)R1 FRONT SEATS FR 94-247(A) WING RIBS, FUEL TANK AREA FR 94-248(A) FIN INTERMEDIATE RIB ATTACHMENT FR 94-248(A) FIN INTERMEDIATE RIB ATTACHMENT FR 94-249(A)R1 WING REAR ATTACHMENT FITTINGS FR 94-246(A)R1 WING REAR ATTACHMENT FITTINGS FR 94-265(A)R4 MAIN LANDING GEAR FR 96-143(A) UPPER ATTACHMENTS FOR TOOL 082, 57 REV FR 96-143(A) UPPER ATTACHMENTS OF FRONT BELTS FR 1999-062(A) FUEL SYSTEM FR 1999-062(A) FUEL SYSTEM FR 1999-062(A) FUEL SYSTEM FR 1999-062(A) FUEL SYSTEM FR 1999-062(A) FUEL SYSTEM FR 84-074(A) NOSE GEAR FR 85-004(A) LANDING GEAR MICROSWITCHES FR 85-004(A) LANDING GEAR MICROSWITCHES FR 85-004(A) LANDING GEAR MICROSWITCHES FR 85-004(A) PITCH TRIM FR 85-03(A) BATTERY TRAY FR 87-030(A) BATTERY TRAY FR 87-030(A) STABILATOR CONTROL ROD FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS FR 87-117(A) NLG - LH HYDRAULIC LINE ATTACHMENTS FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS FR 87-114(A) BRAKE HYDRAULIC LINE ATTACHMENTS FR 87-114(A) BRAKE HYDRAULIC LINE ATTACHMENTS FR 87-114(A) BRAKE HYDRAULIC LINE ATTACHMENTS FR 89-099(A)R2 HORIZONTAL STABILIZER ATTACHMENTS FR 89-099(A)R2 HORIZONTAL STABILIZER ATTACHMENTS FR 89-099(A)R1 FRONT SEAT BELT ATTACHMENTS FR 89-099(A)R1 FRONT SEAT BELT ATTACHMENTS FR 89-099(A)R1 FRONT SEAT BELT ATTACHMENTS FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENT FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENT FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENT FR 89-176(A)R1 FRONT SEAT BELT ATTACHMENT F				
FR 94-247(A) WING RIBS, FUEL TANK AREA  FR 94-248(A) FIN INTERMEDIATE RIB ATTACHMENT  FR 94-249(A)R1 WING REAR ATTACHMENT  FR 94-264(A)R1 WING FRONT ATTACHMENT  FR 94-265(A)R4 WING FRONT ATTACHMENTS  10.083.557 REV  FR 94-265(A)R4 WING FRONT ATTACHMENTS  10.081.57 REV  FR 94-263(A) UPPER ATTACHMENTS OF FRONT BELTS  10.085.57 REV  FR 1999-082(A) FUEL SYSTEM  FR 1999-319(A) VERTICAL STABILIZER FORWARD JUNCTION DOUBLER  TB 20  FR 84-021(A) ENGINE MOUNT  CO  FR 84-021(A) NOSE GEAR  FR 85-04(A) LANDING GEAR MICROSWITCHES  FR 85-04(A) LANDING GEAR MICROSWITCHES  FR 85-04(A) WING - DRAITH HOLES  FR 85-04(A) BATTERY TRAY  FR 85-130(A) BATTERY TRAY  FR 85-130(A) BATTERY TRAY  FR 87-030(A) STABILATOR CONTROL ROD  FR 87-030(A) STABILATOR CONTROL ROD  FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS  28  FR 87-117(A) NIG - HYDRAULIC LINE  FR 87-1117(A) BRAKE HYDRAULIC LINE ATTACHMENT  FR 87-114(A) BRAKE HYDRAULIC LINE ATTACHMENT  FR 89-096(A)R2 MIG / NIG ARTICULATING STAYS  FR 89-097(A)R1 FRONT SEAT BELL ATTACHMENTS  FR 89-097(A)R1 FRONT SEAT BELL ATTACHMENTS  FR 89-096(A)R1 FRONT SEAT BELL ATTACHMENTS  FR 89-108(A)R1 FRONT SEAT BELL ATTACHMENTS  FR 89-175(A)R1 FIREWALL FRAME  FR 89-175(A)R1 FIREWALL FRAME  FR 89-175(A)R1 FIREWALL FRAME  FR 89-174(A) OIL COOLER  FR 91-134(A) PUEL LANKS ORAINING  FR 89-174(A) OIL COOLER  FR 91-144(A) PROP DEIC CIRCULT PROTECTION  FR 91-143(A)R1 FUEL PUMP / CHECK VALVE  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PROTECTION  FR 91-146(A) PROP DEIC CIRCULT PRO	FR			
FR   94-248(A)		94-247(A)		
FR 94-29(A)R1 WING REAR ATTACHMENT FITTINGS 10.082.57 REV FR 94-265(A)R1 WING REAR ATTACHMENTS 10.082.57 REV FR 94-265(A)R4 MAIN LANDING GEAR 10.085.57 REV FR 96-143(A) UPPER ATTACHMENTS OF FRONT BELTS 10.035.57 REV FR 1999-062(A) FUEL SYSTEM 10-103-25 FR 1999-319(A) VERTICAL STABILIZER FORWARD JUNCTION DOUBLER  TB 20  FR 84-021(A) ENGINE MOUNT 20 FR 84-074(A) NOSE GEAR 21 FR 85-040(A) LANDING GEAR MICROSWITCHES 23 FR 85-043(A) PITCH TRIM 24 FR 85-043(A) PITCH TRIM 24 FR 85-130(A) BATTERY TRAY 51 FR 87-030(A) BATTERY TRAY 51 FR 87-030(A) MAIN LANDING GEAR BOXES 30 FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS 28 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-114(A) BRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 35/1 FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40.8 45/2 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 40.8 45/2 FR 89-097(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 FIREWALL FRAME 46/3 FR 89-175(A)R1 FIREWALL FRAME 46/3 FR 91-134(A) DIL COULER ATTACHMENTS 57 FR 91-145(A) DIL COULER ATTACHMENTS 57 FR 91-145(A) DIL COULER 57 FR 91-144(A) PROP DEIC CIRCULT TROTECTION 59 FR 91-145(A) DIL COULER 57 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-144(A) PROP DEIC CIRCULT PROTECTION 59 FR 91-145(A) FUEL TANKS DOUTLET FILTER 61 FR 91-246(A) FUEL TANK SOUTLET FILTER 61 FR 91-246(A) FUEL TANK SOUTLET FILTER 61 FR 91-246(A) FUEL TANK SOUTLET FILTER 61 FR 91-2			FIN INTERMEDIATE RIB ATTACHMENT	10 000 EE
FR   94-265(A)R4			WING REAR ATTACHMENT FITTINGS	10.082.57 REV 1
FR   99-143(A)			WING FRONT ATTACHMENTS	10.081.57 REV.1
FR				10.085.57 REV.2
TB 20			UPPER ATTACHMENTS OF FRONT BELTS	
TB 20				10-099-28
FR			TENTIONE STABILIZER TORWARD SUNCTION DOUBLER	
FR 84-074(A) NOSE GEAR 21 FR 85-004(A) LANDING GEAR MICROSWITCHES 23 FR 85-004(A) WING - DRAIN HOLES 23 FR 85-043(A) PITCH TRIM 24 FR 85-130(A) BATTERY TRAY 32 FR 87-030(A) STABILATOR CONTROL ROD 29 FR 87-030(A) MAIN LANDING GEAR BOXES 30 FR 87-030(A) MAIN LANDING GEAR BOXES 30 FR 87-117(A) NLG - LH HYDRAULIC LINE 34 FR 87-117(A) NLG - H HYDRAULIC LINE 34 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 34 FR 87-114(A) BRAKE HYDRAULIC LINE ATTACHMENT 35/1 FR 89-096(A)R2 HORIZONTAL STABILLIZER ATTACHMENT 35/1 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 43/1 FR 89-098(A)R1 FRONT SEAT BELT ATTACHMENTS 43/1 FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1 FR 90-143(A) OIL COOLER 50/1 FR 91-031(A) BOOM BALANCE WEIGHT 57/1 FR 91-144(A) PODP DEICE CIRCUIT PROTECTION 59 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-146(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-146(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-146(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-146(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-126(A) FUEL TANKS OUTLET FILTER 61 FR 92-225(A)R4 EXHAUST SYSTEM 10-072-78 REV 61 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-58R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084.57				
FR 85-04(A) LANDING GEAR MICROSWITCHES 23 FR 85-015(A) WING - DRAIN HOLES 26 FR 85-043(A) PITCH TRIM 24 FR 85-130(A) BATTERY TRAY 518 FR 87-030(A) STABILATOR CONTROL ROD 29 FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS 28 FR 87-031(A) AILERONS - BALANCE WIGHT RIVETS 28 FR 87-117(A) NLG - LH HYDRAULIC LINE 34 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-141(A)R2 HORIZONTAL STABILIZER ATTACHMENT 35/1 FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40 & 45/2 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-098(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1 FR 89-175(A)R1 FIREWALL FRAME 42/1 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1 FR 91-031(A) BOOM BALANCE WEIGHT 57 FR 91-143(A) OIL COOLER 57 FR 91-143(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EMHAUST SYSTEM 10-072-78 REV 10-071-55R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-080-57 REV. FR 94-247(A) WING RIBS, FUEL TANK AREA 10-080-57 REV. FR 94-247(A) WING RIBS, FUEL TANK AREA 10-086-57 REV.				20
FR 85-015(A) WING - DRAIN HOLES 26 FR 85-043(A) PITCH TRIM 24 FR 85-030(A) BATTERY TRAY 5L 18 FR 87-030(A) STABILATOR CONTROL ROD 29 FR 87-031(A) AILERONS BALANCE WEIGHT RIVETS 30 FR 87-117(A) NLG - LH HYDRAULIC LINE 34 FR 87-117(A) NLG - LH HYDRAULIC LINE 34 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 35/1 FR 89-096(A)R2 HORIZONTAL STABILIZER ATTACHMENT 35/1 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-097(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 FRONT SEAT TRACKS 43/1 FR 89-177(A)R3 FUEL TANKS DRAINING 46/1 FR 89-183(A)R1 FLE PUMP / CHECK VALVE 47/1 FR 91-143(A) DIL COOLER 50-1 FR 91-143(A) BOOM BALANCE WEIGHT 57 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-146(A) FUEL TANKS OUTLET FILTER 61 FR 92-225(A)R1 FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R2 EVALUATION SYSTEM 60 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV 10-071-55R3 FR 93-126(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-072-78 REV 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-085-57 REV.				21
FR 85-043(A) PITCH TRIM 24  FR 85-130(A) BATTERY TRAY 24  FR 87-030(A) STABILATOR CONTROL ROD 29  FR 87-030(A) MAIN LANDING GEAR BOXES 30  FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS 28  FR 87-117(A) NLG - LH HYDRAULIC LINE 34  FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 33  FR 87-114(A)R2 HORIZONTAL STABILIZER ATTACHMENT 35/1  FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40 & 45/2  FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25  FR 89-08(A)R1 FRONT SEAT TRACKS 43/1  FR 89-115(A)R1 FIREWALL FRAME 46/1  FR 89-177(A)R3 FUEL TANKS DRAINING 48/3  FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1  FR 90-143(A) OIL COOLER 59  FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59  FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59  FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59  FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60  FR 91-146(A) PROP DEICE CIRCUIT PROTECTION 59  FR 91-146(A) PROP DEICE CIRCUIT PROTECTION 59  FR 91-146(A) PROP DEICE CIRCUIT PROTECTION 59  FR 91-146(A) PROP DEICE CIRCUIT PROTECTION 59  FR 91-246(A) FUEL TANKS OUTLET FILTER 61  FR 92-225(A)R4 EXHAUST SYSTEM 60  FR 91-246(A) FUEL TANKS OUTLET FILTER 61  FR 92-225(A)R4 EXHAUST SYSTEM 10-072-78 REV 10-071-55R3  FR 93-247(A) FUEL TANK AIR VENT 10-067-028R1  FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3  FR 94-247(A) WING RIBS, FUEL TANK AREA 10-075-25R1  FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084.57				
FR 85-130(A) BATTERY TRAY FR 87-003(A) STABILATOR CONTROL ROD FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS FR 87-0117(A) NLG - LH HYDRAULIC LINE FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS FR 87-141(A)R2 HORIZONTAL STABILIZER ATTACHMENT FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS FR 89-098(A)R1 FRONT SEAT BELT ATTACHMENTS FR 89-098(A)R1 FRONT SEAT BELT ATTACHMENTS FR 89-108(A)R1 FRONT SEAT BELT ATTACHMENTS FR 89-175(A)R1 FIREWALL FRAME FR 89-177(A)R3 FUEL TANKS DRAINING FR 89-177(A)R3 FUEL TANKS DRAINING FR 89-183(A)R1 FUEL PUMP / CHECK VALVE FR 91-031(A) BOOM BALANCE WEIGHT FR 91-143(A) OIL COOLER FR 91-144(A) PROP DEICE CIRCUIT PROTECTION FR 91-145(A) AUTOPILOT CONTROL SYSTEM FR 91-145(A) AUTOPILOT CONTROL SYSTEM FR 91-145(A) AUTOPILOT CONTROL SYSTEM FR 91-145(A) AUTOPILOT CONTROL SYSTEM FR 91-145(A) FUEL TANKS OUTLET FILTER FR 92-152(A)R4 EXHAUST SYSTEM FR 92-152(A)R4 EXHAUST SYSTEM FR 92-225(A)R1 FUEL TANKS OUTLET FILTER FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS FR 94-114(A)R1 FRONT SEATS FR 94-247(A) WING RIBS, FUEL TANK AREA FR 95-084(A) FR 95-084(A) WING RIBS, FUEL TANK AREA FR 95-084(A) FR 95-084(A) WING RIBS, FUEL TANK AREA				
FR 87-03(A) STABILATOR CONTROL ROD 29 FR 87-030(A) MAIN LANDING GEAR BOXES 30 FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS 28 FR 87-117(A) NLG - LH HYDRAULIC LINE 34 FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS 33 FR 87-141(A)R2 HORIZONTAL STABILIZER ATTACHMENT 35/1 FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40 & 45/2 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-098(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1 FR 89-175(A)R1 FIREWALL FRAME 42/1 FR 89-175(A)R1 FIREWALL FRAME 42/1 FR 89-183(A)R1 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL TANKS DRAINING 48/3 FR 90-143(A) OIL COOLER 50-1 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-146(A) NOSE GEAR MOUNT FRAME 49 FR 91-26(A) FUEL TANKS OUTLET FILTER 61 FR 92-225(A)R1 FUEL TANKS OUTLET FILTER 61 FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-144(A)R1 FRONT SEATS FR 94-144(A)R1 FRONT SEATS FR 94-247(A) WING RIBS, FUEL TANK AREA 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-075-25R1				
FR 87-030(A) MAIN LANDING GEAR BOXES  FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS  FR 87-117(A) NLG - LH HYDRAULIC LINE  FR 87-118(A) BRAKE HYDRAULIC LINE ATTACHMENTS  FR 87-141(A)R2 HORIZONTAL STABILIZER ATTACHMENT  FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS  FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENT  FR 89-098(A)R1 FRONT SEAT BELT ATTACHMENTS  FR 89-098(A)R1 FRONT SEAT TRACKS  FR 89-175(A)R1 FRONT SEAT TRACKS  FR 89-177(A)R3 FUEL TANKS DRAINING  FR 89-183(A)R1 FUEL TANKS DRAINING  FR 90-143(A) DIL COOLER  FR 91-031(A) BOOM BALANCE WEIGHT  FR 91-144(A) PROP DEICE CIRCUIT PROTECTION  FR 91-145(A) AUTOPILOT CONTROL SYSTEM  FR 91-145(A) FUEL TANKS OUTLET FILTER  FR 92-152(A)R4 EXHAUST SYSTEM  FR 92-255(A)R4 FUEL TANK AIR VENT  FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS  FR 94-114(A)R1 FUEL TANK AIR VENT  FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS  FR 94-114(A)R1 FUEL TANK AIR VENT  FR 94-247(A) WING RIBS, FUEL TANK AREA  FR 94-247(A) WING RIBS, FUEL TANK AREA  FR 94-247(A) WING RIBS, FUEL TANK AREA  FR 95-084(A) MAIN LANDING GEAR  FR 94-247(A) WING RIBS, FUEL TANK AREA  10-085-57 REV.		87-003(A)		
FR				
FR			AILERONS - BALANCE WEIGHT RIVETS	
FR 87-141(A)R2 HORIZONTAL STABILIZER ATTACHMENT 35/1   FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40 & 45/2   FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25   FR 89-098(A)R1 FRONT SEAT TRACKS 10-044-25   FR 89-108(A)R1 FRONT SEAT TRACKS 43/1   FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1   FR 89-175(A)R1 FIREWALL FRAME 42/1   FR 89-177(A)R3 FUEL TANKS DRAINING 48/3   FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1   FR 90-143(A) OIL COOLER 50-1   FR 91-031(A) BOOM BALANCE WEIGHT 57   FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59   FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59   FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60   FR 91-160(A) NOSE GEAR MOUNT FRAME 49   FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV   FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV   FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3   FR 94-114(A)R1 FRONT SEATS 10-080-57 REV.   FR 94-247(A) WING RIBS. FUEL TANK AREA 10-084-57   FR 94-247(A) WING RIBS. FUEL TANK AREA 10-084-57			NLG - LH HYDRAULIC LINE	
FR 89-096(A)R2 MLG / NLG ARTICULATING STAYS 40 & 45/2 FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-098(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1 FR 89-175(A)R1 FIREWALL FRAME 42/1 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1 FR 90-143(A) OIL COOLER 50-1 FR 91-031(A) BOOM BALANCE WEIGHT 57 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 92-152(A)R4 EXHAUST SYSTEM 61 FR 92-225(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 99-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-247(A) WING RIBA NATIONAL AREA 10-084-57 FR 94-247(A) WING RIBAS. FUEL TANK AREA 10-085-57 REV.			BRAKE HYDRAULIC LINE ATTACHMENTS	
FR 89-097(A)R1 FRONT SEAT BELT ATTACHMENTS 10-044-25 FR 89-098(A)R1 FRONT SEAT TRACKS 110-044-25 FR 89-108(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1 FR 89-177(A)R3 FIEWALL FRAME 42/1 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1 FR 90-143(A) OIL COOLER 57 FR 91-031(A) BOOM BALANCE WEIGHT 57 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV 19-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-114(A)R1 FRONT SEATS 10-080-57 REV. FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084-57			MIG / NIG ADTICH ATTACHMENT	35/1
FR 89-098(A)R1 FRONT SEAT TRACKS 43/1 FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1 FR 89-175(A)R1 FIREWALL FRAME 42/1 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1 FR 90-143(A) OIL COOLER 57 FR 91-031(A) BOOM BALANCE WEIGHT 57 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 57 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-114(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 99-245(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-114(A)R1 FRONT SEATS 10-080-57 REV. FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084-57			FRONT SEAT BELT ATTACHMENTS	
FR 89-108(A)R1 NLG LEVER ADJUSTING SCREW 46/1 FR 89-175(A)R1 FIREWALL FRAME 42/1 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1 FR 90-143(A) OIL COOLER 50-1 FR 91-031(A) BOOM BALANCE WEIGHT 57 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084-57			FRONT SEAT TRACKS	
FR 89-175(A)R1				
FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP / CHECK VALVE 47/1 FR 90-143(A) DIL COOLER 50-1 FR 91-031(A) BOOM BALANCE WEIGHT 57 FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-114(A)R1 FRONT SEATS 10-080-57 REV. FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084-57		89-175(A)R1	FIREWALL FRAME	
FR   90-143(A)   OIL COOLER   57	FR		FUEL TANKS DRAINING	
FR   90-143(A)			FUEL PUMP / CHECK VALVE	
FR 91-143(A)R1 CABIN ACCESS DOOR CATCHES 58/1 FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-075-25R1 FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084.57				
FR 91-144(A) PROP DEICE CIRCUIT PROTECTION 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-080-57 REV. FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10.084.57			BUUM BALANCE WEIGHT	
FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 94-114(A)R1 FRONT SEATS 10-080-57 REV. FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084.57			CABIN ACCESS DOOR CATCHES	
FR 91-160(A) NOSE GEAR MOUNT FRAME 49 FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK ATR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-080-57 REV. FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084.57			AUTOPILOT CONTROL SYSTEM	
FR 91-246(A) FUEL TANKS OUTLET FILTER 61 FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-080-57 REV. FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084.57				
FR 92-152(A)R4 EXHAUST SYSTEM 10-072-78 REV FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1 FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-080-57 REV. FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10.084.57	FR			
FR 92-225(A)R1 FUEL TANK AIR VENT FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-067-028R1 FR 1994-266(A)R3 MAIN LANDING GEAR 10-080-57 REV. FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10.084.57	FR	92-152(A)R4		
FR 93-012(A)R2 RUDDER BALANCE WEIGHT/STIFFENERS 10-071-55R3 FR 1994-266(A)R3 MAIN LANDING GEAR 10-080-57 REV. FR 94-114(A)R1 FRONT SEATS 10-075-25R1 FR 94-247(A) WING RIBS, FUEL TANK AREA 10-084.57 FR 95-084(A) MAIN LANDING GEAR 10-084.57			FUEL TANK AIR VENT	
FR 94-114(A)R1 FRONT SEATS 10-080-57 REV. FR 94-247(A) WING RIBS, FUEL TANK AREA 10.084.57			RUDDER BALANCE WEIGHT/STIFFENERS	
FR 94-247(A) WING RIBS, FUEL TANK AREA 10-075-25R1 FR 95-084(A) WAIN LANDING CEAR 10.084.57			MAIN LANDING GEAR	
FR 95-084(A) WING RIBS, FUEL TANK AREA 10.084.57				
TAIN LANDING GEAR				10.084.57
10.091.57			MAIN LANDING GEAR	10.091.57

MAKE / CONSTRUCTEUR MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. SOCATA TR 20 (CONTINUED / SUITE)
FR 96-143(A) UPPER ATTACHMENTS OF FRONT BELTS 10-103-25 97-032(A) FD LANDING GEAR MICROSWITCH 10-105-32 FR 1999-062(A) FUEL SYSTEM 10-099-28 FR 1999-319(A) VERTICAL STABILIZER FORWARD JUNCTION DOUBLER FR 1999-386(A) NON-CONFORMANCE OF PROPELLER GOVERNOR CONTROLS 10-112-61 TB 21 FR 84-021(A) ENGINE MOUNT 20 FR 84-074(A) NOSE GEAR 21 FR 85-004(A) LANDING GEAR MICROSWITCHES 23 85-015(A) FR WING - DRAIN HOLES 26 FR 85-043(A) PITCH TRIM 24 FR 85-130(A) BATTERY TRAY SI 18 FR 87-003(A) STABILATOR CONTROL ROD 29 87-030(A) FR MAIN LANDING GEAR BOXES 30 FR 87-031(A) AILERONS - BALANCE WEIGHT RIVETS 28 FR 87-042(A) TURBO CHARGER 87-117(A) FR NLG - LH HYDRAULIC LINE BRAKE HYD. LINE ATTACHMENTS FR 87-118(A) 33 FR 87-141(A)R2 89-096(A)R2 HORIZONTAL STABILIZER ATTACHMENT 35/1 FR MLG/NLG ARTICULATING STAYS 40 & 45/2 FRONT SEAT BELT ATTACHMENTS FR 89-097(A)R1 10-044-25 FR 89-098(A)R1 FRONT SEAT TRACKS 43/1 89-108(A)R1 89-175(A)R1 FR NLG LEVER ADJUSTING SCREW 46/1 FR FIREWALL FRAME 42/1 FR 89-177(A)R3 FUEL TANKS DRAINING 48/3 FR 89-183(A)R1 FUEL PUMP/CHECK VALVE 47/1 90-143(A) OIL COOLER FR 50/1 BOOM BALANCE WEIGHT CABIN ACCESS DOOR CATCHES PROP DEICE CIRCUIT PROTECTION FR 91-031(A) FR 91-143(A)R1 58/1 FR 91-144(A) 59 FR 91-145(A) AUTOPILOT CONTROL SYSTEM 60 91-160(A) FR NOSE GEAR MOUNT FRAME 49 FR FUEL TANKS OUTLET FILTER 91-246(A) 61 FR 92-225(A)R1 FUEL TANK AIR VENT 10-067-028R1

FR	1994-266(A)R3
FR	94-114(A)R1
FR	94-247(A)
FR	95-084(A)
FR	96-143(A)
ED	97-022(A)

93-012(A)R2

1999-062(A)

1999-319(A)

1999-386(A)

91-196(B)

92-001(B)

92-002(B)

92-003(B)

92-151(B)R1

92-154(B)R1

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

FR

TBM 700 FR

WING RIBS, FUEL TANK AREA MAIN LANDING GEAR UPPER ATTACHMENTS OF FRONT BELTS LANDING GEAR MICROSWITCH FUEL SYSTEM VERTICAL STABILIZER FORWARD JUNCTION DOUBLER

ALTERNATOR-RECTIFIER

YAW SERVO ACTUATOR

FUEL LOW PRESSURE SWITCH

MAIN LANDING GEAR

FRONT SEATS

NON-CONFORMANCE OF PROPELLER GOVERNOR CONTROLS NOSE GEAR WHEEL ANTI-ICE WINDSHIELD

RUDDER BALANCE WEIGHT/STIFFENERS

INERTIAL SEPARATOR EMERGENCY BEACON 92-034(B) 92-035(B) POWER PLANT COWLINGS 92-036(B) RH AILERON 92-039(B) ICING CONDITIONS 92-040(B) AP/TRIM MASTER SWITCH 92-041(B) OIL COOLING SYSTEM 92-150(B) YAW CONTROL

92-207(B) VACUUM PRESSURE SWITCH 92-220(B) FUSELAGE DRAINING 92-221(B) PITCH CONTROL BELLCRANK 92-239(B) OIL COOLER SYSTEM CABIN DUMP SYSTEM 93-013(B) 93-019(B) BATTERY OVERHEATING INDICATION - MODIFICATION 93-041(B) ELEVATOR HORNS DEICING

FR FR 93-178(B) RUDDER SKIN UNBONDING FR WATER ACCUMULATION IN CONTROL SURFACES 93-179(B) FR 93-193(B) ESS BUS TIE INVERTER FR 94-068(B) EFIS CONFIGURATION FR PROP CONTROL 94-109(B)

AIRCRAFT/AERONEFS

10-071-55R3

10-075-25R1

10.084.57 10.091.57

10-103-25

10-105-32

10-099-28

10-112-61

70.002.32

70.003.56

70.004.24

70.005.71

70.009.25

70.007.71

70.010.57

70.011.30

70.008.22

70.012.79

70.015.27

70-016-37

70-021-53

70-013-27

70-024-79

70-014-21

70-020-30

70-027-55

70-028-55

70-022-24

70-030-34

70-042-76

SB 70-026-24

70.023.22R1

70.017.28R1

10-080-57 REV 3

MAKE / CONSTRUCTEUR MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF SOCATA TBM 700 (CONTINUED / SUITE) FR 94-110(B)R1 FLAP CARRIAGES 70-048-57R1 FR 94-111(B) FRAME REINFORCEMENTS 70-035-53 FR 94-112(B) GROUND POWER RECEPTACLE 94-113(B) 70-038-24 FR HORIZONTAL STABILIZER 70-034-55 FR 94-214(B)R2 ELEVATOR TRIM 70-053-27R2 FR 94-267(B) WINDSHIELD DEICING 70.037.30 FR 94-268(B) WING TIP DRAINING 95-033(B) 70.052.57 FR FLAP RAILS FITTINGS OIL COOLER
SIDE TRIM PANEL
AUXILEC STARTER GENERATOR MOUNTING ADAPTER 70-058-57 FR 95-034(B)R1 70-060-79 REV.1 FR 95-166(B) FR 70-061-25 95-242(B)R1 70-071-24 FR 96-037(B)R1 MAIN LANDING GEAR DOORS CRACKS IN THE TRIM TAB FITTINGS (BEARINGS)

OXYGEN GENERATOR STRIKE PINS

HODIZONIAL 70-073-32 96-118(A)R1 FR 70-079-55 R1 FR 98-195(A) 70-046-35 FR 1999-060(A) HORIZONTAL STABLIZER 70-077-55 STAMPE SV4 SERIES CF-87-12 CF CENTRE SECTION TIE RODS 72-026(A)R1 FR CENTRE SECTION TIE BOLTS FR 88-055(A) BOLTS - REAR BRACKET OF WING CABANE SV4R ( SV4 SERIES ) SV4C ( SV4 SERIES ) START & FLUG H101 74-323/2 GY FLIGHT CONTROL CABLE CONNECTIONS CANOPY CLOSURE 74-41 GΥ GΥ 74-5 TOWING EQUIPMENT - NOSE COUPLING 72, E72, S72, SH72 TOWING EQUIPMENT - NOSE COUPLING 72, E72, S
CANOPY CLOSURE
WING EXTENSION PIECES
SECURING OF TAIL PLANE UNIT
FLIGHT CONTROL - FOOT REST
SERVICE LIFE
FIGHT & SERVICE MANUALS 74-63 GY 101-8 GY 79-441/2 101-14 GΥ 82-121 101-21 GV 83-155 101-22 GΥ 88-78 GY 89-175 101-26 FLIGHT & SERVICE MANUALS AILERON BELCRANK ATTACHMENT 101-27/2 GY 92-191 101-29 GΥ 1998-108 AIRBRAKE LEVER 101-25/2 STEMME STEMME S10 VT 1998-400 GΥ 1999-224/4 WASTEGATE CONTROL CABLE WASTEGATE CONTROL CABLE
VARIABLE PITCH PROPELLER-FORK CONVERSION A31-10-051 A-31-10-034 R1 GV STINSON L5 SERIES US 46-31-02 TORQUE TUBE AFT OF REAR SEAT ELEVATOR PUSH-PULL TUBE 47-50-04 US L5 ( L5 SERIES ) 15F ( L5 SERIES ) US 46-31-01 HINGED SEAT BACK L5E1 ( L5 SERIES ) 115 46-31-01 HINGED SEAT BACK 15G ( L5 SERIES ) US 46-31-01 HINGED SEAT BACK SR JR SR8B SR8CM SR9E SR9FM

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
ST I NSOI 10 US	<b>v</b> 46-39-01	OLEO TRUSS WEAR	
10A		OCTO TROSS WEAR	
SR10F			
SRIOK			
HW 75			
US	46-39-01	OLEO TRUSS WEAR	224
V77			
108 SE US US US	RIES 47-50-11 50-17-02 50-25-01	ASH TRAY MODIFICATION RUDDER CABLE INSPECTION FUEL DRIP STRIP	
108 CF	CF-49-07	O8 SERIES ) RUDDER CONTROL CABLES	
108 1 US	47-50-12	08 SERIES ) STABILIZER ATTACHMENT FITTING	
108 2 US	49-16-02	08 SERIES ) WING FABRIC INSPECTION	
108 3 US		08 SERIES ) WING FABRIC INSPECTION	
STOL UC 1			
SWEARIN SA26 S			
US	81-26-05R1	LOWER FORWARD WING STN 99 ATTACH FITTING	26-57-40-015
US US	87-13-11 90-24-03	LANDING GEAR SELECTOR LEVER RUDDER TRIM TAB LINK ASSEMBLIES	26-32-30-39 26-SN-061
US US	96-20-08 97-02-02	COCKPIT & CABIN WINDOWS PITCH CONTROL	26-56-20-042R1,038R1 26-27-30-046
SA26AT		A26 SERIES )	
	69-11-01 77-04-08	COCKPIT SIDE WINDOW SPAR BRACKETS	
SA26T		N26 SERIES )	
US	CF-80-22 69-11-01	PROP REVERSING LINKAGE INTERCONNECT COCKPIT SIDE WINDOW	
US <b>SA226</b> S	77-04-08	SPAR BRACKETS	
US	76-20-04	WHEEL WELLS	
	77-18-05 77-25-03	VARIABLE AUTHORITY STEERING SYSTEM LANDING GEAR ACTUATOR ROD ENDS	
	79-13-07	BAGGAGE COMPARTMENT	
	79-25-04 81-15-01	MODELS INCORPORATING ROSEMOUNT SERVOS STRUCTURAL WEAR OR DAMAGE	
	81-24-04 81-26-04	CHANGE TO AFM "ICING CONDITIONS"	
	82-23-06	CABLE GUARD & RETAINER INSTALLATION MLG DOOR INSTALLATION	
	83-15-09	NOSE WHEEL STEERING SYSTEMS MOD	
US	85-04-01R1 85-22-06R1	HYDRAULIC AND OXYGEN LINE INSP STALL AVOIDANCE SYSTEM (SAS)	
	86-10-08 86-24-11	ELEVATOR GUST LOCK SYSTEM FLIGHT MANUAL - LIMITATIONS / ICING ENVIRONMENT	226-27-041
US	87-02-02	PRIMARY CONTROL SYSTEM CABLES	
	87-13-11 90-03-19R1	LANDING GEAR SELECTOR LEVER BATTERY BUS RELAY	226-32-048 SA226-24-032
US	90-05-06R1	MLG DOOR / NACELLE SKINS	SA226-32-055
	90-24-03 92-19-08	RUDDER TRIM TAB LINK ASSEMBLIES RUDDER PEDAL LINK ATTACHMENT	226-SN-162 226-27-027
US !	93-15-01	HORIZONTAL STABILIZER PIVOT FITTINGS	226-55-010
US !	94-07-10R1	WING SKIN	226-57-018R3

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

SWEARINGEN SA226 SERIES		
(CONTINUED / SUITE	)	
US 95-17-07	MLG DOOR STOP BOLT REMOVAL	SA226-32-043
US 95-17-09R1		SA226-24-034
US 95-24-11	FOD BARRIERS	226-53-012
US 95-25-07	MLG DOOR TANGS	226-32-059
US 96-03-03	PUWER CONTROL CABLE	226-76-009
US 96-09-16	AIRCRAFT IN SEVERE ICING - AFM INSERT	
US 96-19-05	LANDING GEAR YOKES	SA226-32-065
US 96-20-08	COCKPIT & CABIN WINDOWS	226-56-001R1,002R1
US 97-02-02 US 97-10-13	PITCH CONTROL	226-27-060
US 97-11-13	CORRODED ELEVATOR TORQUE TUBE GENERATOR SYSTEM	226-27-050
US 97-23-01		226-24-027, 23,26,31
US 98-04-05	FLAP ACTUATOR ATTACH BRACKETS	226-SL-005,& 014 57-016
US 98-19-15R1	HORIZONTAL STABILIZER MOVEMENT	226-SL-017
US 99-06-02		226-31-017
US 99-21-05		A32-014
5100017		
SA226AT	( SA226 SERIES )	
US 73-08-02	OPERATION IN ICING CONDITIONS	
US 80-09-08R2 US 90-14-01		226-52-008
US 90-14-01 US 92-01-02	FASSENGER CABIN WINDOW SIN 181	226-56-004
US 92-18-07	PARKING BRAKE SYSTEM POWER LEVER DETENT	226-32-049
US 93-07-12		226-76-008
US 93-09-05	HORIZONTAL STAB REAR SPAR ELEVATOR RETURN SPRING	226-55-005R1
US 95-18-05	CARGO DOOR	226-27-032
US 98-06-25	INSPECT CARGO DOOR LOWER BELT FRAMES .	226-52-008R1 226-53-007
	THE PER PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PERSON OF THE PE	226-53-007
SA226T	( SA226 SERIES )	
US 73-08-02	OPERATION IN ICING CONDITIONS	
US 92-01-02	PARKING BRAKE SYSTEM	226-32-049
US 92-18-07	POWER LEVER DETENT	226-76-008
US 93-07-12	HORIZONTAL STAB REAR SPAR	226-55-005R1
SA226TC	( SA226 SERIES )	
US 80-09-08R2	CARGO DOOR LATCHING MECHANICM	000 50 000
US 84-13-01	CARGO DOOR LATCHING MECHANISM GENERATOR CONTROL J-BOX	226-52-008
US 90-14-01	PASSENGER CABIN WINDOW STN 181	226-56-004
US 92-01-02	PARKING BRAKE SYSTEM	226-32-049
US 92-18-07	POWER LEVER DETENT	226-76-008
US 93-07-12	HORIZONIAL STAD REAK SPAK	226-55-005R1
US 93-09-05	ELEVATOR RETURN SPRING	226-27-032
US 95-18-05	CARGO DOOR	226-52-008R1
US 98-06-25	INSPECT CARGO DOOR LOWER BELT FRAMES	226-53-007
SA227 SERIES		
US 82-05-05R1	PROPELLER ICE ACCUMULATION	
US 83-15-09	NOSE WHEEL STEERING SYSTEMS MOD	
US 84-13-01	GENERATOR CONTROL J-BOX	
US 85-22-06R1	STALL AVOIDANCE SYSTEM (SAS)	
US 86-10-08	ELEVATOR GUST LOCK SYSTEM	227-27-016
US 86-25-04	FLIGHT MANUAL - LIMITATIONS/ICING ENVIRONMENT	
US 87-02-02 US 90-03-19R1	PRIMARY CONTROL SYSTEM CABLES	
US 90-03-19R1 US 90-05-06R1	BATTERY BUS RELAY	SA227-24-013
US 90-05-06R1	MLG DOOR / NACELLE SKINS	SA227-32-027
US 92-19-08	RUDDER TRIM TAB LINK ASSEMBLIES	227-SN-074
US 93-09-05	RUDER PEDAL LINK ATTACHMENT ELEVATOR RETURN SPRING	227-27-029
US 93-15-01	HORIZONTAL STABILIZER PIVOT FITTINGS	227-27-002
US 94-07-10R1	WING SKIN	227-55-006
US 95-17-09R1	LEFT AND RIGHT HAND ESSENTIAL BUSS	227-57-005R2 SA227-24-015
US 95-24-11	FOD BARRIERS	227-53-005
US 96-03-03	POWER CONTROL CABLE	227-76-004
US 96-09-16	AIRCRAFT IN SEVERE ICING - AFM INSERT	
US 96-19-05	LANDING GEAR YOKES	SA227-32-039
US 96-20-08	COCKPIT & CABIN WINDOWS	227-56-002R1,003R1
US 97-02-02 US 97-10-13	PITCH CONTROL	227-27-041
US 97-10-13 US 97-11-13	CORRODED ELEVATOR TORQUE TUBE	227-27-028
US 97-23-01	GENERATOR SYSTEM	227-24-008, 005,012
US 98-19-15R1	PRECISION PITCH TRIM ACTUATOR HORIZONTAL STABILIZER MOVEMENT	227-SL-011, & 031
US 99-06-02	WING SPAR FATIGUE CRACKING	227-SL-033
	THE STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF STATE OF	

INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA			
MAKE / CONS MODEL / M ORIGIN	STRUCTEUR ODELE AD NUMBER	(SERIES / SERIE) SUBJECT	
ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
SWEARIN			
SA2274	C	( SA227 SERIES )	
US	90-14-01	PASSENGER CABIN WINDOW STN 181	227-56-004
US US	92-01-02 92-18-07	THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE S	227-32-017
US	93-07-12	POWER LEVER DETENT	227-76-002
US	93-08-09	HORIZONTAL STAB REAR SPAR NOSE WHEEL STEERING	227-55-002R1
US	95-01-07	LOWER WING SKIN PANEL	227-32-030
US	98-06-25	INSPECT CARGO DOOR LOWER BELT FRAMES	227-57-002R1 227-53-003
SA2270			22, 33 333
US	90-24-03	RUDDER TAB LINK	
US	94-07-10R1	WING SKIN	227-SN-074
US	95-17-09R1	LEFT HAND & RIGHT HAND ESSENTIAL BUS	CC7-57-002R2 CC7-24-002
US	95-24-11	FOD BARRIERS	CC7-53-002
US	96-03-03	POWER CONTROL CABLE	CC7-76-001
US US	96-09-16	AIRCRAFT IN SEVERE ICING-AFM INSERT	
US	96-19-05 97-02-02	LANDING GEAR YOKES	CC7-32-007
US	97-23-01	PITCH CONTROL PRECISION PITCH TRIM ACTUATOR	CC7-27-010
US	98-19-15R1	HORIZONTAL STABILIZER MOVEMENT	CC7-SL-021,227SL-011
US	99-06-02	WING SPAR FATIGUE CRACKING	CC7-SL-023
CACOTO			
SA227D US	0 90-24 <b>-</b> 03	DUDDED TAD LANK	
US	93-08-09	RUDDER TAB LINK NOSE WHEEL STEERING	227-SN-074
US	94-07-10R1	WING SKIN	227-32-030
US	95-17-09R1	LEFT HAND & RIGHT HAND ESSENTIAL BUS	CC7-57-002R2 CC7-24-002
US	95-24-11	FOD BARRIERS	CC7-53-002
US	96-03-03	POWER CONTROL CABLE	CC7-76-001
US US	96-09-16	AIRCRAFT IN SEVERE ICING-AFM INSERT	
US	96-19-05 97-02-02	LANDING GEAR YOKES	CC7-32-007
US	97-02-02	PITCH CONTROL PRECISION PITCH TRIM ACTUATOR	CC7-27-010
US	98-19-15R1	HORIZONTAL STABILIZER MOVEMENT	227-SL-011, 031 CC7-SL-023
US	99-06-02	WING SPAR FATIGUE CRACKING	001 31 023
AYLOR&			
A			
BC SER	IES		
	47-16-03	WING STRUT FITTINGS	
US	50-41-01	ELEVATOR HORN BOLT	
US	51-09-03	FUEL SHUTOFF VALVE CLIP	
BCS12D US	47-13-02	( BC SERIES ) FUEL HOSE	
BC12 6	5	( BC SERIES )	
US	47-13-02	FUEL HOSE	
US	87-03-08	HOSE ASSEMBLY - OIL PRESSURE GUAGE	
BC12D		( BC SERIES )	
	47-13-02	FUEL HOSE	
	78-20-11	AILERON CONTROL MALFUNCTION	
	87-03-08	HOSE ASSEMBLY - OIL PRESSURE GUAGE	
BC12D 4	85	( BC SERIES )	
3C12D 8	35	( BC SERIES )	
BC12D1		( BC SERIES )	
BC65		( BC SERIES )	
	47-13-02	FUEL HOSE	
BF SERI	47-16-03	WING STRUT FITTINGS	

US 47-16-03 US 50-41-01

51-09-03

US

WING STRUT FITTINGS ELEVATOR HORN BOLT FUEL SHUTOFF VALVE CLIP

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUBJECT
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

UK 002-11-98 PRESSURE RELIEF VALVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COMMENT OF THE PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77Z  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COMMENT OF THE PRESSURE RELIEF VALVES 4  UK 003-11-98 PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX8 90  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COMMENT OF THE PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX8 90  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COMMENT OF THE PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COMMENT OF THE PRESSURE RELIEF VALVES 4  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COMMENT OF THE PRESSURE RELIEF VALVES 4	ORIGINE	NUMERO DE CONSIGNE		SUJET	BULLETIN DE SERVICE DE REF.
BF 12 65					
BL SERIES  US 47-16-03  US 47-16-03  US 51-09-03  ELEVATOR HORN BOLT  SELT 55  BL12 65  (BL SERIES)  BL65  (BL SERIES)  BL65  (BL SERIES)  BL65  (BL SERIES)  BL65  (BL SERIES)  BL79-08  HOSE ASSEMBLY - DIL PRESSURE GUAGE  F19  US 75-18-05  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  US 79-04-04  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  AILERON CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  BOLT SERVER  CONTROL MALFUNCTION  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOLT SERVER  BOL					
US	BF12 6	35	( BF	SERIES )	
US	DI CEE	TEC			
US   S0-41-01				WING STRIT FITTINGS	
BL12 65					
BL12 65					
BL65					
19	BL12 6	55	( BL	SERIES )	
19					
US	BL65		( BL	SERIES )	
US	4.0				
F19		970209		HOSE ASSEMBLY - OIL BRESSIBE GLAGE	
US 75-18-05 US 78-20-11 AILERON CONTROL MALFUNCTION US 79-04-04 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  20  F21 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  20  F21 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  20  F21 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  20  F21 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  20  F21 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  20  F21 US 63-16-05 US 63-16-06 LANDING GEAR ACTUATING CYLINDERS US 63-21-05 LANDING GEAR RETRACTION LINKS US 63-21-05 US 63-21-05 LANDING GEAR RETRACTION LINKS US 63-16-06 US 63-16-06 LANDING GEAR SELECTOR VALVE US 63-16-06 US 63-16-06 LANDING GEAR RETRACTION LINKS US 63-16-06 US 63-16-06 US 63-16-06 US 63-16-06 US 63-16-06 US 63-16-06 US 63-16-06 US 63-16-06 US 63-16-08 US 63-16-08 US 63-16-08 US 63-16-08 US 63-16-08 US 63-16-08 US 63-16-08 US 63-16-09 US 63-16-08 US 63-16-08 LANDING GEAR RETRACTION LINKS US 64-08-04 NOSE GEAR SUPPORT BRACE  14  THUNDER  AK6 56 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 65 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77Z UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77Z UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX8 90 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX8 90 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 002-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 002-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUAVES UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV CUA	US	87-03-08		HUSE ASSEMBLY - OIL PRESSURE GUAGE	
US   75-18-05	F19				
US 78-20-11 US 79-04-04 CHARGING CIRCUIT FIRE HAZARD  20  F21 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  20  F21 US 87-03-08 HOSE ASSEMBLY - OIL PRESSURE GUAGE  DC065  FEMCO D16 D16 D16 D16 D16 D16 D16 D16 D16 D16		75-18-05		ENGINE MOUNT BOLTS	
STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOC	US	78-20-11			
STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOCK   STOC	US	79-04-04			
F21	US	87-03-08		HOSE ASSEMBLY - OIL PRESSURE GUAGE	
F21					
DCO65   DCO65   DCO65   DCO65   DCO65   DCO65   DCO65   DCO665	20				
DCO65   DCO65   DCO65   DCO65   DCO65   DCO65   DCO65   DCO665	E04				
DC065		87-03-08		HOSE ASSEMBLY - OTL PRESSURE GUAGE	
### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF VALVES ### PRESSURE RELIEF V	05	0, 00 00		TOSE ASSEMBLY OIL TRESSORE GOAGE	
D16	DC065				
D16					
US   63-16-05					
US   63-16-06					
US   63-21-05					
US   64-08-04   NOSE GEAR SUPPORT BRACE   14					SL 81
D16A					4./
US	US	64-06-04		NOSE GEAR SUPPURT BRACE	14
US	D16A				
US		63-16-05		FLAP & LANDING GEAR ACTUATING CYLINDERS	SL 79
US   64-08-04   NOSE GEAR SUPPORT BRACE   14					SL 81
### THUNDER   AX6   56		63-21-05		LANDING GEAR RETRACTION LINKS	
AX6 56	US	64-08-04		NOSE GEAR SUPPORT BRACE	14
AX6 56	~				
UK         O01-O7-96         THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         4 INCOME OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV CONTROL OF THE TURNING VENTS<					
UK				THUNDED AND COLT TURNING VENTS	2 TSSUE 1 REV C
UK					
AX7 65  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THUNDER AND COLT TURNING VENTS 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THUNDER AND COLT TURNING VENTS 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77Z  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OWN ON THE COUNTY OWN ON THE COUNTY OWN ON THE COUNTY OWN ON THE COUNTY OWN ON THE COUNTY OWN OWN OWN OWN OWN OWN OWN OWN OWN OWN					7 ISSUE "B"
UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV COULD         UK       002-11-98       PRESSURE RELIEF VALVES       4         UK       003-11-98       BURNER FRAME CROSS BAR WELDS       7 ISSUE "B"         AX7       77         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV COULD         UK       003-11-98       BURNER FRAME CROSS BAR WELDS       7 ISSUE "B"         AX7       77Z       UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV COULD         UK       002-11-98       PRESSURE RELIEF VALVES       4         UK       003-11-98       BURNER FRAME CROSS BAR WELDS       7 ISSUE "B"         AX8       90         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV COULD         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV COULD         UK       003-11-98       PRESSURE RELIEF VALVES       4         UK       003-11-98       BURNER FRAME CROSS BAR WELDS       7 ISSUE "B"         AX9       140         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV COULD         UK       001-07-96       THUNDER AND COLT TURNING					
UK         OO2-11-98         PRESSURE RELIEF VALVES         4           UK         OO3-11-98         BURNER FRAME CROSS BAR WELDS         7 ISSUE "B"           AX7         77           UK         OO1-07-96         THUNDER AND COLT TURNING VENTS         2 ISSUE 1 REV OUT OUT OUT OUT OUT OUT OUT OUT OUT OUT	AX7 65				
UK   OO3-11-98   BURNER FRAME CROSS BAR WELDS   7 ISSUE "B"				THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
AX7 77  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OO2-11-98 PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77Z  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OO3-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX8 90  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OO2-11-98 PRESSURE RELIEF VALVES 4  UK 002-11-98 PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OO2-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OO2-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"					
UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL TO TURNING VENTS         UK       002-11-98       BURNER FRAME CROSS BAR WELDS       7 ISSUE "B"         AX7       77Z         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS         UK       003-11-98       PRESSURE RELIEF VALVES       4         UK       003-11-98       BURNER FRAME CROSS BAR WELDS       7 ISSUE "B"         AX8       90         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS         UK       003-11-98       PRESSURE RELIEF VALVES       4         UK       003-11-98       BURNER FRAME CROSS BAR WELDS       7 ISSUE "B"         AX9       140         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS         UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS         UK       002-11-98       PRESSURE RELIEF VALVES       4	UK	003-11-98		BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL TO TURNING VENTS       2 ISSUE 1 REV CONTROL TO TURNING VENTS       2 ISSUE 1 REV CONTROL TO TURNING VENTS       4 ISSUE 1 REV CONTROL TO TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       2 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNING VENTS       4 ISSUE 1 REV CONTROL TURNI	A V 7 77				
UK 002-11-98 PRESSURE RELIEF VALVES 4 UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX7 77Z  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE				THUNDED AND COLT TURNING VENTS	2 ISSUE 1 DEV C
Name					4
AX7 77Z  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THUNDER AND COLT TURNING VENTS 4  UK 002-11-98 PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX8 90  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THE VERY OWNER OF THE VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OWNER OF THE VALVES 4  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNE		003-11-98			7 ISSUE "B"
UK       001-07-96       THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       4 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       4 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       4 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF THUNDER AND COLT TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       2 ISSUE 1 REV CONTROL OF TURNING VENTS       3 ISSUE 1 REV CONTROL OF TURNING VENTS       4 ISSUE 1 REV CONTROL OF TURNING VENTS       4 ISSUE 1 REV CONTROL OF TURNING VENTS       4 ISSUE 1 REV CONTROL OF TURNING VENTS       4 ISSUE 1 REV CONTROL OF TURNING VENTS       4 ISSUE 1 REV CONTROL OF TURNING VENTS       4 ISSUE 1 REV					
UK 002-11-98					
UK 002-11-98	UK	001-07-96		THUNDER AND COLT TURNING VENTS	2 ISSUE 1 REV C
AX8 90  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PROOF OF THE PRO				PRESSURE RELIEF VALVES	4
UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THE PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THE PRESSURE RELIEF VALVES 4	UK	003-11-98		BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THE PRESSURE RELIEF VALVES 4  UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140  UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUNTY OF THE PRESSURE RELIEF VALVES 4	AYP DO				
UK 002-11-98 PRESSURE RELIEF VALVES 4 UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"  AX9 140 UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COLT UK 002-11-98 PRESSURE RELIEF VALVES 4			•••••	THINDED AND COLT TURNING VENTS	2 ISSUE 1 DEV C
UK     OO3-11-98     BURNER FRAME CROSS BAR WELDS     7 ISSUE "B"       AX9 140     UK     OO1-07-96     THUNDER AND COLT TURNING VENTS     2 ISSUE 1 REV COUNTY       UK     OO2-11-98     PRESSURE RELIEF VALVES     4					
AX9 140  UK 001-07-96					·
UK 001-07-96 THUNDER AND COLT TURNING VENTS 2 ISSUE 1 REV COUK 002-11-98 PRESSURE RELIEF VALVES 4					
UK 002-11-98 PRESSURE RELIEF VALVES 4	AX9 14	0			
					2 ISSUE 1 REV C
TIV (VIV-11-OP DIDNED EDAME ODGE DAD MELDE TACCHE NON				PRESSURE RELIEF VALVES	
UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"	UK	003-11-98		BURNER FRAME CROSS BAR WELDS	7 ISSUE "B"
AX10 210	AX40 0	10			
UK 002-11-98 PRESSURE RELIEF VALVES 4				PRESSURE DELITER VALVES	4
UK 003-11-98 BURNER FRAME CROSS BAR WELDS 7 ISSUE "B"					
7 1330E B				THE OLOGO DAY ACEDS	, 10000

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER (SERIES / SERIE)

ORIGINE ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
THURST			
TSC 1		SEE/VOIR: SCHWEIZER	
TSC 1		SEE/VOIR: SCHWEIZER	
TRAVEL.			
VARGA			· ····································
<b>2150A</b> US	65-12-04	ELEVATOR HORN	
US US	65-28-05 80-02-08	MAIN LANDING GEAR OLEOS RUDDER BALANCE ATTACH BOLTS	
US US	80-13-08 81-20-02	THROTTLE MOVEMENT VENT TUBE ASSEMBLY	
US	82-08-04	ELEVATOR HORN ASSEMBLY	
VERTOL 42A			
CF US	CF-98-15 58-20-04	HELICOPTER RESCUE SYSTEMS CLUTCH COUPLING REPLACEMENT	CAR 702.21
US US	60-23-05 64-19-06	BELLCRANK ASSEMBLY RETIREMENT	0050 714
US US	64-27-04 68-06-01	SPIRAL BEVEL PINION GEARS WOOD ROTOR BBLADE ROOT SOCKET TRANSMISSION DRIVE SHAFT	2059 IM
44 SER		TOWNSHIPSTON DRIVE SHAFT	
CF US	CF-98-15 58-20-04	HELICOPTER RESCUE SYSTEMS	CAR 702.21
US US	59-09-04	CLUTCH COUPLING REPLACEMENT FAN DISC ASSEMBLY	
US	59-19-02 59-20-01	ENGINE COOLING FAN ASSEMBLY SPAR WEIGHT ASSEMBLY STRAPS	
US US	60~10~10 60~23~05	ROTOR BLADE RETIREMENT BELLCRANK ASSEMBLY RETIREMENT	
US US	64-19-06 68-06-01	SPIRAL BEVEL PINION GEARS TRANSMISSION DRIVE SHAFT	
<b>44B</b> CF	65 60 60	( 44 SERIES )	
CF	CF-62-02 CF-64-02	AS PER TECHNICAL MEMORANDUM FATIGUE FAILURE OF MAIN ROTOR SPAR	TM 2056-1
VICKERS	NT 757		
CF UK	CF-57-09 0980 PRE 80	OIL PRESSURE WARNING DEVICE	D 004 00 0 004
UK	0981 PRE 80	NACELLES - STRUCTURE COCKPIT PRESSURE FLOORING	D.321 OR D.791 D.591
UK	0982 PRE 80 0983 PRE 80	ELECTRICAL CIRCUIT FLAP CONTROL BUS-BAR MAIN POWER PANELS	D.594 D.691
UK UK	0984 PRE 80 0985 PRE 80	FUEL HEATER INSTALLATION ENG. FUEL FILTER DE-ICING	D.693
UK	0986 PRE 80	ELECT. GENERATOR EQUALIZING SUPPRESSOR CONNECTORS OVER-VOLT RELAYS/GENERATOR SYSTEM	D.771 & D.1213
UK	0987 PRE 80 0988 PRE 80	FIRE DETECTOR BULB/ENGINE BREATHER PIPE ENGINE CONTROL ROD MICROSWITCH	D.817&M.190/239
UK	0989 PRE 80	FUEL SYSTEM DRAIN COCK FLOWMETERS	D.841 D.864
UK	0990 PRE 80	GROUND FINE PITCH STOP FROM 4 DEGREE TO 8 DEGREE	
UK	0991 PRE 80 0992 PRE 80	PROPELLER GROUND FINE PITCH CIRCUIT PITCH SOLENOIDS SEGREGATED	D.907 D.908
UK	0993 PRE 80	FLAME SHIELD VENT LINE INBOARD NACELLE	D.942
UK UK	0994 PRE 80 0995 PRE 80	LANDING GEAR RETRACTION JACK "HIGH VOLTAGE" WARNING LABEL IGNITER LEADS	D.945 OR D.1060 D.957&D.1168
UK	0996 PRE 80	ELECTRICAL GENERATOR SHORTING	D.969
UK	0997 PRE 80	COMMUNICATIONS - WHIP AERIALS BONDING WIRES AILERON & RUDDER ASSEMBLIES WINGS NACELLE STRUT ATTACHMENT FITTING	D. 985
UK	0998 PRE 80	WINGS NACELLE STRUT ATTACHMENT FITTING	D.1031/PTL 111
UK	1000 PRE 80	WINGS NACELLE STRUT ATTACHMENT FITTING TAILPLANE L.E. ATTACHMENT FITTING STARBOARD CONTROL COLUMN NACELLES - MAIN CHASSIS BACK STAY POST	D. 1075/TNS 87
UK UK	1001 PRE 80	NACELLES - MAIN CHASSIS BACK STAY POST	D. 1081 D. 1099
UK	1003 PRE 80	ELEVATOR TURQUE TUBE GIMBAL RING	D.1147/PTL 27
UK	1004 PRE 80	WINGS - ENGINE NACELLE FITTING	D. 1208/PTL 34
UK	1006 PRE 80	120 AMP. THERMAL CIRCUIT BREAKER	D. 1317
UK UK	1007 PRE 80	ELECTRICAL CHASSIS WARNING SYSTEM	D. 1321
	1008 PRE 80 1009 PRE 80		D.1324 D.1384/PTL 52
	1010 PRE 80		D.1416

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJECT
SUJUET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
VICKER:	<u> </u>		
VISCO	JNT 757		
(CONTIN	NUED / SUITE)	RUDDER & ELEVATOR LOCK LEVER BUS-BAR DISTRIBUTION FUEL PUMP SYSTEM ELECTRICAL EMERGENCY INVERTER FUEL FILTER DE-ICING CIRCUIT ELEVATOR TRIM TABL VALVE H.P. LEVER BY-PASS VALVE TO FLOWMETERS FINE PITCH "LOCK REMOVED" WARNING LIGHT FINE PITCH LOCK WIRING	
UK	1011 PRE 80	RUDDER & ELEVATOR LOCK LEVER	D.1421/TNS 64
UK	1012 PRE 80	BUS-BAR DISTRIBUTION FUEL PUMP SYSTEM	D. 1535
UK	1013 PRE 80	FUEL FILTER DE-ICING CIRCUIT	D. 1594
UK	1015 PRE 80	ELEVATOR TRIM TABL	D. 1596
UK	1016 PRE 80	VALVE H.P. LEVER	D. 1609
UK UK	1017 PRE 80	BY-PASS VALVE TO FLOWMETERS	D.1613
UK	1019 PRE 80	FINE PITCH "LOCK WIRING LIGHT	D. 1637
UK	1020 PRE 80	AC PHASE TRANSFORMERS	D. 1642
UK	1021 PRE 80	FINE PITCH LOCK WIRING FINE PITCH LOCK WIRING AC PHASE TRANSFORMERS PROPELLER CONTROL CIRCUITS CRASH SWITCH MOUNTING & FUSELAGE SKIN PROPELLER HUB SWITCH WIRING	D. 1682
UK UK	1022 PRE 80	CRASH SWITCH MOUNTING & FUSELAGE SKIN	D.1700 & D.1805
UK	1023 FRE 80	TAPER DISTANCE THRES MACELLE STRUTG AT CEAR DOV	D. 1732
UK	1025 PRE 80	FEATHERING PUMP MOTORS	D.1742/PTL 87
UK	1026 PRE 80	NACELLES 2 AND 3 FIREWALL	D. 1856/D. 2253
UK UK	1027 PRE 80	BUS-BAR INVERTERS & WARNING LIGHT SYSTEM	D.2018
UK	1020 PRE 80	SKIN STRUCTURE TO MAIN COAR	D.2019
UK	1030 PRE 80	AILERON LEVER GROUP	D.2081 PI.C-F
UK	1031 PRE 80	ELEVATOR ROD ATTACHMENT BOLT	D.2120/PTL 140
UK UK	1032 PRE 80	AC PHASE TRANSFORMERS PROPELLER CONTROL CIRCUITS CRASH SWITCH MOUNTING & FUSELAGE SKIN PROPELLER HUB SWITCH WIRING TAPER DISTANCE TUBES NACELLE STRUTS AT GEAR BOX FEATHERING PUMP MOTORS NACELLES 2 AND 3 FIREWALL BUS-BAR INVERTERS & WARNING LIGHT SYSTEM BUS-BAR PITOT HEAD HEATERS SKIN STRUCTURE TO MAIN SPAR AILERON LEVER GROUP ELEVATOR ROD ATTACHMENT BOLT MINIMUM RPM SETTING FOR AUTOMATIC FEATHERING RETRACTION JACK & DOWNLOCK DAMPER END FITTING ELEVATOR ANTI-BALANCE TAB MECHANISM RETRACTION JACK CYLINDER END ATTACHMENT BOLT PROPELLER HUB SWITCH WIRING WINGS SPROCKET SHAFT NUTS ON FLAP UNITS OUTER AILERON LOCK ASSEMBLY WINGS FLAP CHAIN TURNBUCKLES FRONT PRESSURE BULKHEAD ENGINE MOUNTING ATTACHMENTS WING ROOT TERMINAL STUDS AUTO-PILOT AILERON CLUTCH MILD STEEL LEVER TO SELECTOR SWITCHES AUTOMATIC PILOT MASTER SWITCHES MAIN CHASSIS RAM FOOT ELECTRICAL AUTO-PILOT GENERATOR CONTROL CIRCUIT PRE-STALL WARNING TEST CIRCUIT RUDDER TRIM TAB & ELEVATOR SPRING TAB FIRE PROTECTION INSTRUMENTS ALTIMETERS LANDING GEAR - BRAKE PIPING NON-RETURN VALVE	D.2207
UK	1033 PRE 80	RETRACTION JACK & DOWNLOCK DAMPER END FITTING	D.2235/D.2265
UK	1035 PRE 80	RETRACTION JACK CYLINDER END ATTACHMENT ROLL	D.2239/PTL 160
UK	1036 PRE 80	PROPELLER HUB SWITCH WIRING	D. 2292
UK UK	1037 PRE 80	WINGS SPROCKET SHAFT NUTS ON FLAP UNITS	D. 2439
UK	1038 PRE 80	OUTER AILERON LOCK ASSEMBLY	D.2491
UK	1040 PRE 80	FRONT PRESSURE BULKHEAD	D.2554
UK	1041 PRE 80	ENGINE MOUNTING ATTACHMENTS	D.2581/PTI 179
UK	1042 PRE 80	WING ROOT TERMINAL STUDS	D. 2628
UK UK	1043 PRE 80	AUTO-PILOT AILERON CLUTCH	D.2651
UK	1045 PRE 80	AUTOMATIC PILOT MASTER SWITCHES	D.2673/R.2961 D
UK	1046 PRE 80	MAIN CHASSIS RAM FOOT	D. 2685
UK	1047 PRE 80	ELECTRICAL AUTO-PILOT	D.2703
UK UK	1048 PRE 80	GENERATOR CONTROL CIRCUIT	D.2818
UK	1050 PRE 80	RUDDER TRIM TAR & FLEVATOR SPRING TAR	D. 2858
UK	1051 PRE 80	RUDDER TRIM TAB & ELEVATOR SPRING TAB  FIRE PROTECTION  INSTRUMENTS ALTIMETERS  LANDING GEAR - BRAKE PIPING NON-RETURN VALVE  ELECTRICAL - BELLING & LEE FUSES  NAVIGATION VOR/LOC AERIALS  MAIN CHASSIS UPLOCK UNIT  LOCKING OF DOOR BOLT SLEEVE FRONT & REAR ENTRANCE  PROPELLERS - DOWTY ROTOL MOD V.P. 1941  NOSEWHEEL BAY STRUCTURE	D.2926/D.3009
UK	.1052 PRE 80	INSTRUMENTS ALTIMETERS	D. 2927
UK UK	1053 PRE 80	LANDING GEAR - BRAKE PIPING NON-RETURN VALVE	D.2994
UK	1055 PRE 80	NAVIGATION VOR/LOC AFRIALS	D.3015
UK	1056 PRE 80	MAIN CHASSIS UPLOCK UNIT	D.3049/PTL 236
UK	1057 PRE 80	LOCKING OF DOOR BOLT SLEEVE FRONT & REAR ENTRANCE	D.3051
UK	1058 PRE 80	PROPELLERS - DOWTY ROTOL MOD V.P. 1941	D.3106
UK	1060 PRE 80	INVERTER BACK GUADOS	D.3147
UK	1061 PRE 80	PROPELLERS - DOWTY ROTOL MOD V.P. 1941  NOSEWHEEL BAY STRUCTURE INVERTER RACK GUARDS  FLIGHT CONTROLS TRIM TENSIONER HOUSING BREATHER PIPE OVERHEAT DETECTORS  AIR CONDITIONING NACELLE DUCTS  AIR CONDITIONING - GODFREY MOD P1195 & P1196 WINGS - FIRE EXTINGUISHER BOTTLES STARTER SELECTOR RELAY ELECTRICAL FLANGED LINER TO ALTERNATORS PROPELLER - DOWTY ROTOL MOD V.P. 2480	D.3157
UK	1062 PRE 80	BREATHER PIPE OVERHEAT DETECTORS	D.3187
UK UK	1063 PRE 80	AIR CONDITIONING NACELLE DUCTS	D.3198
UK	1064 PRE 80	WINGS - FIRE EXTINGUISHED POTTLES	D.3204 PT. A&B
UK	1066 PRE 80	STARTER SELECTOR RELAY	D.3218
UK	1067 PRE 80	ELECTRICAL FLANGED LINER TO ALTERNATORS	D.3220
UK	1068 PRE 80		D.3221
UK UK	1069 PRE 80 1070 PRE 80	COVER TO CONTROL COLUMN HOUSING	D.3223/PTL 275
UK	1071 PRE 80	NACELLES - ENGINE BREATHER PIPES BUS-BAR UNDER VOLTAGE WARNING LIGHTS	D.3226
UK	1072 PRE 80	ESSENTIAL BATTERY FED DC BUS-BAR	D.3232 D.3233
UK	1073 PRE 80	ROLLS-ROYCE MOD 1550	D SOSE DART D
	1074 PRE 80 1075 PRE 80	AIR CONDITIONING - CABIN BLOWER (DOWTY ROTOL)	D.3237
	1076 PRE 80	EMERGENCY POWER SYSTEM INBOARD ENGINE STARTER SELECTOR RELAYS	D.3239
UK	1077 PRE 80	ELECTRICAL FLAP MOTORS	D.3241 D.3242 PART A
	1078 PRE 80	PRE-STALL WARNING CIRCUIT STICK SHAKER	D.3244
	1079 PRE 80	PROPELLER FEATHERING MANUAL SYSTEM	D.3245
	1080 PRE 80 1081 PRE 80	ELECTRICAL VOLTAGE SENSING UNIT UNDERFLOOR ELECTRICS BAY REGION	D.3246 PART B
	1082 PRE 80	VOLTMETER BATTERY SUPPLY	D.3249 D.3254
	NET / AEDONIESS		0.3254

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

			BULLETIN DE SERVICE DE REF
VICKE	RS		
	DUNT 757		
(CONT)	INUED / SUITE)	ELECTRICALLY-OPERATED ARTIFICIAL HORIZON ELECTRICAL SMITHS SERVICE BULLETIN 22-866 ALTERNATORS REDESIGNED END HOUSING ASSEMBLY POWER PLANT LOW TORQUE SWITCH-IN POWER PLANT L.P. IMPELLER HUB REAR FACE POWER PLANT CONTROL BOX MOUNTING BOLTS LANDING GEAR LOCK CABLE TURNBUCKLE FLAP BEAM ATTACHMENT FITTINGS MAIN CHASSIS RETRACTION JACK ASSEMBLIES MAIN CHASSIS OLEO CYLINDERS NO.3 FLAP AND AILERON GRAVINER FIRE EXTINGUISHER MAIN UNDERCARRIAGE CROSS SHAFT BEARING CHANNELS	
UK UK	1083 PRE 80	ELECTRICALLY-OPERATED ARTIFICIAL HORIZON	D.3260
UK	1085 PRE 80	ALTERNATORS PERSONNER FOR AUGUSTANS ASSESSED.	D.3272
UK	1086 PRE 80	POWER PLANT LOW TOROUTE SWITCH-IN	D.3275
UK	1087 PRE 80	POWER PLANT L.P. IMPELLER HUB REAR EACE	D.3281
UK	1088 PRE 80	POWER PLANT CONTROL BOX MOUNTING BOLTS	D.3282
UK	1089 PRE 80	LANDING GEAR LOCK CABLE TURNBUCKLE	D.3284
UK UK	1090 PRE 80	FLAP BEAM ATTACHMENT FITTINGS	PTL 151
UK	1091 PRE 80	MAIN CHASSIS RETRACTION JACK ASSEMBLIES	PTL 171
UK	1093 PRF 80	NO 3 FLAD AND ATLEBON	PTL 191
UK	1094 PRE 80	GRAVINER FIRE EXTINGUISHER	PTL 208
UK	1095 PRE 80	MAIN UNDERCARRIAGE CROSS SHAFT BEARING CHANNELS	PTI 211
UK	1096 PRE 80	MAIN UNDERCARRIAGE UP-LOCK OPERATING LEVERS	PTL 213
UK	1097 PRE 80	FUSELAGE LIFE	PTL 221
UK	1098 PRE 80	MAIN UNDERCARRIAGE RAM FOOT FITTINGS	PTL 225
UK	1100 PRE 80	WING SPAR ATTACHMENT HOINTS	PTL 228
UK	1101 PRE 80	NOSE INDERCAPPIAGE TOPSION LINE HINCE DIAG	PTL 230
UK	1102 PRE 80	MAIN UNDERCARRIAGE CROSS THRE FUN FITTINGS	PTL 233
UK	1103 PRE 80	NOSE UNDERCARRIAGE BRACING STRUCTURE	PTI 240
UK	1104 PRE 80	INNER MAIN PLANES END RIB STRUCTURE	PTL 241
UK	1105 PRE 80	FUSELAGE LEADING EDGE FRAME STRUCTURE	PTL 242
UK UK	1106 PRE 80	NO.3 FLAP AND AILERON GRAVINER FIRE EXTINGUISHER MAIN UNDERCARRIAGE CROSS SHAFT BEARING CHANNELS MAIN UNDERCARRIAGE CROSS SHAFT BEARING CHANNELS MAIN UNDERCARRIAGE RAM FOOT FITTINGS INBOARD ENGINE NACELLE STRUCTURE ATTACHMENT BOLT WING SPAR ATTACHMENT JOINTS NOSE UNDERCARRIAGE TORSION LINK HINGE PINS MAIN UNDERCARRIAGE CROSS TUBE END FITTINGS NOSE UNDERCARRIAGE CROSS TUBE END FITTINGS NOSE UNDERCARRIAGE BRACING STRUCTURE INNER MAIN PLANES END RIB STRUCTURE FUSELAGE LEADING EDGE FRAME STRUCTURE ENGINE MOUNT SUPPORT TUBES MAIN CHASSIS TOP YOKES PYRENE FIRE EXTINGUISHERS MAIN UNDERCARRIAGE RETRACTION JACK PIVOT BOLTS FLYING CONTROL ROD GUIDE BEAM AT FUSELAGE NOSE UNDERCARRIAGE LOCK PLUNGER ENGAGEMENT ELEVATOR HINGE BEAMS TAIL PLANE SPAR ROOT JOINT FITTINGS NOSE WHEEL STEERING TWIN RELIEF VALVE AILERON CONTROL ROD TUBES, PORT & STARBOARD CABIN SUPER-CHARGER WIRE DUNLOP HYDRAULIC SYSTEM FLEXIBLE HOSES ENGINE NACELLE CROSS BEAM ATTACH. EYE END FITTINGS ELEVATOR ROOT END RIBS, PORT & STARBOARD FUSELAGE EXTERNAL SKIN AREA WING CENTRE SECTION LOWER SPAR BOOM FLAP GEARBOX DRIVE MOTORS GENERATOR MAIN EARTH ALUMINIUM CABLE ASSEMBLIES HEAVY DUTY ALUMINIUM CABLE ASSEMBLIES LENDING FLAP TORQUE SHAFTS, LEFT/RIGHT HAND ASSEM. LANDING FLAP TORQUE SHAFTS, LEFT/RIGHT HAND ASSEM. LANDING FLAP OPERATING CHAIN LINK PIN ASSEMBLIES TAILING EDGE MEMBER ACCESS TAILPLANE REAR SPAR TOP FORWARD BOOMS	PTL 252
UK	1107 PRE 80	MAIN CMASSIS TOP YOKES	PTL 255
UK	1110 PRE 80	MAIN UNDERCARRIAGE PETPACTION JACK DIVOT POLITS	PTL 256
UK	1111 PRE 80	FLYING CONTROL ROD GUIDE BEAM AT FUSELAGE	PTL 259
UK	1112 PRE 80	NOSE UNDERCARRIAGE LOCK PLUNGER ENGAGEMENT	PTI 262
UK	1113 PRE 80	ELEVATOR HINGE BEAMS	PTL 263
UK	1114 PRE 80	TAIL PLANE SPAR ROOT JOINT FITTINGS	PTL 264 ISSUE 3
UK	1115 PRE 80	NOSE WHEEL STEERING TWIN RELIEF VALVE	PTL 265
UK	1110 PKE 80	CARIN SUBER-CHARGED WIRE	PTL 266
UK	1118 PRF 80	DUNIOP HYDRAULTO SYSTEM FLEXTRIE HOSES	PIL 267
UK	1119 PRE 80	ENGINE NACELLE CROSS BEAM ATTACH, EVE END FITTINGS	PTI 273
UK	1120 PRE 80	ELEVATOR ROOT END RIBS, PORT & STARBOARD	PTL 274
UK	1121 PRE 80	FUSELAGE EXTERNAL SKIN AREA	PTL 278
UK	1122 PRE 80	WING CENTRE SECTION LOWER SPAR BOOM	PTL 279
UK	1123 PRE 80	FLAP GEARBOX DRIVE MOTORS	PTL 283
UK	1124 PRE 80	HEAVY DITY ALIMINIUM CARLE ASSEMBLIES	PIL 288
UK	1126 PRE 80	LENDING FLAP TORQUE SHAFTS LEFT/RIGHT HAND ASSEM	PTI 290
UK	1127 PRE 80	LANDING FLAP OPERATING CHAIN LINK PIN ASSEMBLIES	PTL 291
UK	1128 PRE 80	TRAILING EDGE MEMBER ACCESS	PTL 292
UK	1129 PRE 80	TAILPLANE REAR SPAR TOP FORWARD BOOMS	PTL 298
UK	1130 PRE 80	TRAILING EDGE MEMBER ACCESS TAILPLANE REAR SPAR TOP FORWARD BOOMS MAIN LANDING GEAR SHOCK ABSORBER STRUT GLAND NUT VICKERS ARMSTRONG TYPE ESCAPE CHUTES	PTL 299
UK	1131 PRE 80	VICKERS ARMSTRONG TYPE ESCAPE CHUTES	PTL 303
UK	1132 PKE 80	FLYING CONTON S LINDDESSIDISED ADEAS	PTL 304
UK	1134 PRE 80	DUNLOP 4 ELEMENT MK III HYD. BRAKE CONTROL VALVE FLYING CONTROLS UNPRESSURISED AREAS ROLLS-ROYCE DART ENGINE CONTROL BOX MOUNTING BOLTS ROLLS-ROYCE LOW PRESSURE IMPELLER HYDRAULIC SYSTEM MICRONIC ELLERS	PTL 306
UK	1135 PRE 80	ROLLS-ROYCE LOW PRESSURE IMPELLER	PTL 307
UK	1136 PRE 80	HYDRAULIC SYSTEM MICRONIC FILTERS	PTL 308
UK	1137 PRE 80	HYDRAULIC SYSTEM MICRONIC FILTERS INNER PLANE TRAILING EDGE MEMBER BOOM & LINER ASS. ARTIFICIAL HORIZON PLESSEY FLIGHT DATA RECORDERS EMERGENCY POWER ARTIFICIAL HORIZON	PTL 309
UK	1138 PRE 80	ARTIFICIAL HORIZON	REF.DEF/O17
UK	1139 PRE 80	ARTIFICIAL HORIZON PLESSEY FLIGHT DATA RECORDERS EMERGENCY POWER ARTIFICIAL HORIZON	INS 356
UK	1140 PRE 80 1141 PRE 80	EMERGENCY POWER ARTIFICIAL HORIZON INSPECTION PRESSURE CABIN STRUCTURE	NOTICE NO.81
UK	1141 PRE 80	MAJOR STRUCTURAL COMPONENTS	
UK	002-04-81		PTL 310
UK	008-02-82		PTL 313
UK	009-02-82		PTL 314
UK	021-04-82		PTL 311
UK	022-04-82		PTL 312
UK UK	008-02-85	POWER PLANT DE-ICING GENERATOR AC LANDING GEAR HYD. SELECTOR ELECTRICAL ACTUATOR	PTL 315
UK	008-03-85 001-06-86		SS/VIS/629 PTL 317
UK	013-02-86		PTL 316
UK	001-07-88		C.W. 886135
UK	011-02-90	LIFE EXTENSION PROGRAM - STRUCTURES	PTL 320 LAST REV
	000 00 01	REAR PRESSURE BULKHEAD - CORROSION	PTL 325R2
UK	009-06-91 009-09-91		PTL 334 ISSUE 2

MODEL / M ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
V I CKER:	S		
	UNT 757		
UK	NUED / SUITE) 011-12-91	TOP STRUT INNER WING BRACING STRUCT - VIS INSP	PTL 332
UK	014-11-91	CRACKING OF NLG ATTACHMENT FITTING-INSP	PTL 331
UK	018-02-91 008-06-94	INSPECTION OF NACELLE STRUCTURE EYE END FITTINGS ENGINE NACELLE STRUCTURE	PTL 326 PTL 258
UK	009-06-94	"W" ENG FRAME SOCKET FITT INSP HOLES - VIS INSP	PTL 501 ISSUE 2
UK	003-09-96	FLAP WARNING HORN	D3155
/IKING TR 1			
VOLAIRE	<u> </u>		
10			
WACO			
UIC			
YKC S			
AQC 6			
EQC 6			
ZQC 6			
GXE			
YMF			
INF			•••••••••••••••••••••••••••••••••••••••
US	46-50-01	FUEL LINE REWORK	
RNF		FUEL LYNE DELICON	
US	46-50-01	FUEL LINE REWORK	
UPF 7			
VKS 7	47 07 04	(TNO TNOTTOTAL (TNY 1771)	
US	47-27-01	WING INSPECTION (TANK AREA)	
YKS 7			
	/ MASCH		
GY GY	<b>IS SERIES</b> 70-31	BRAKE CHUTE COUPLING	20
GY	74-323/2	FLIGHT CONTROL CABLE CONNECTIONS	20
GY	76-268	ELEVATOR CONTROL	27-60/1
PHOEBU	IS B1	( PHOEBUS SERIES )	
GY GY	75-52 82-220	RUDDER CONTROL CABLE ARM	27-20/1
GY	82-220	LIFETIME OF GLIDER	V.6.5.82
PHOEBU		( PHOEBUS SERIES )	
GY	82-220	LIFETIME OF GLIDER	V.6.5.82
EATHER 620B	PLY		
US	96-16-06	WING HINGE PINS	SERVICE NOTE 15
OLF HI	RTH		
DOPPEL	RAAB IV		
	55-2 70-53	WHEEL / SKID	1
GY GY	70-53	AILERON HINGE SUPPORT FLIGHT CONTROL CABLE CONNECTIONS	6
ZENAIR			
CH 200	0		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

AERONCA E-113C		
AIRESEARCH		
TPE331-1 SERIES US 70-04-04	HIGH SPEED PINION DETAINING NUT	505
US 70-19-02	HIGH SPEED PINION RETAINING NUT HIGH SPEED PINION BEARING	624
US 71-05-07 US 73-26-07R3	HIGH SPEED PINION ASSEMBLY FUEL PUMP SHAFT	628R2, 632R1
US 74-10-10	BRACKETS - FUEL CONTROL ASSEMBLY	TPE331-72-0027R4 TPE331-73-0028
US 75-10-05 US 76-16-01	TORQUE SENSOR ASSEMBLY ARM HIGH SPEED PINION BEARING TUBES	606R7
US 78-05-02	PROPELLER PITCH CONTROL SLEEVE ASSEMBLY	TPE331-72-0092 TPE331-72-0115R1
US 78-25-08R3 US 84-01-04	MAIN REDUCTION GEAR DRIVE THIRD STAGE TURBINE WHEEL	TPE331-72-0061R1
US 84-10-06R1	FUEL CONTROL / PUMP ASSEMBLY	TPE331-72-0351 TPE331-73-0121R3
US 89-07-07R1 US 92-26-08	TURBINE OIL SCAVENGE PUMP	331-72-0533R2
US 93-05-09	THIRD STAGE STATOR ASSEMBLIES INNER SEAL SUPPORT - 3RD STAGE TURBINE STATOR	NF331-A72-11921 TPE331-A72-0384R3,R4
US 93-15-11 US 94-09-08	PROPELLER PITCH CONTROL GASKET	TPE331-A72-0857,0858
US 95-16-08	THIRRD STAGE TURBINE WHEELS REVIEW OF MAINTENANCE RECORDS	ASB TPE331-A72-0906
TPE331-1	( TPE331-1 SERIES )	
TPE331-1-151G	( TPE331-1 SERIES )	
TPE331-1-151K	( TPE331-1 SERIES )	
TPE331-2 SERIES US 70-04-04	MICH CREED DINION DETAINING MIT	
US 70-19-02	HIGH SPEED PINION RETAINING NUT HIGH SPEED PINION BEARING	587 624
US 71-05-07 US 73-26-07R3	HIGH SPEED PINION ASSEMBLY	628R2, 632R1
US 73-26-07R3 US 74-10-10	FUEL PUMP SHAFT BRACKETS - FUEL CONTROL ASSEMBLY	TPE331-72-0027R4 TPE331-73-0028
US 75-10-05 US 76-16-01	TORQUE SENSOR ASSEMBLY ARM	606R7
US 78-05-02	HIGH SPEED PINION BEARING TUBES PROPELLER PITCH CONTROL SLEEVE ASSEMBLY	TPE331-72-0092 TPE331-72-0115R1
US 78-25-08R3 US 84-01-04	MAIN REDUCTION GEAR DRIVE	TPE331-72-0061R1
US 84-10-06R1	THIRD STAGE TURBINE WHEEL FUEL CONTROL / PUMP ASSEMBLY	TPE331-72-0351 TPE331-73-0121R3
US 89-07-07R1 US 92-26-08	TURBINE OIL SCAVENGE PUMP	331-72-0533R2
US 93-05-09	THIRD STAGE STATOR ASSEMBLIES INNER SEAL SUPPORT - 3RD STAGE TURBINE STATOR	NF331-A72-11921 TPE331-A72-0384R3,R4
US 93-15-11 US 94-09-08	PROPELLER PITCH CONTROL GASKET	TPE331-A72-0857,0858
US 94-09-08 US 95-16-08	THIRRD STAGE TURBINE WHEELS REVIEW OF MAINTENANCE RECORDS	ASB TPE331-A72-0906
TPE331-2-201A	( TPE331-2 SERIES )	
TPE331-43 SERIES		
US 71-05-07	HIGH SPEED PINION ASSEMBLY	628R2, 632R1
US 73-26-07R3 US 84-10-06R1	FUEL PUMP SHAFT FUEL CONTROL / PUMP ASSEMBLY	TPE331-72-0027R4 TPE331-73-0121R3
US 93-15-11	PROPELLER PITCH CONTROL GASKET	TPE331-A72-0857,0858
US 95-16-08	REVIEW OF MAINTENANCE RECORDS	
TPE331-43A	( TPE331-43 SERIES )	
US 86-08-06R1 US 89-07-07R1	SECOND STAGE TURBINE ROTOR AND STATOR TURBINE OIL SCAVENGE PUMP	TPE331-A72-0522R2 331-72-0533R2
ALLISON 250-B17 SERIES		
CF CF-89-19	FUEL PUMP DRIVE SHAFT	CEB~A-1226
250-B17C	( 250-B17 SERIES )	CEB 1084R4
US 79-21-01R1 US 82-24-05	THIRD STAGE TURBINE WHEEL BLADES FUEL CONTROL/POWER TURBINE GOVERNOR ASSEMBLIES	CEB 1084R4 CEB-A-229
US 83-03-02R1	THIRD STAGE TURBINE WHEEL	CEB-A-1174/1146
US 88-17-01	BENDIX FUEL CONTROL	CEB-A-1272R2
250-C18 SERIES CF CF-70-08	CORROSION IN COMPRESSOR	
US 68-12-06	SIXTH STAGE COMPRESSOR BLADES	CEB 48

MAKE / CONSTRUCTEUR				
MODEL / MODELE ORIGIN AD NUMBER	(SERIÉS / SERIE) SUBJECT	REFERENCE SERVICE BULLETIN		
ORIGINE NUMERO DE CONSIGNE		BULLETIN DE SERVICE DE REF		
ALLISON				
250-C18 SERIES				
(CONTINUED / SUITE) US 69-16-05	GEAR BOX / DIL DUTLET MAGNETIC PLUGS	CSL 6		
US 69-18-02	POWER TRAIN DRIVE GEAR INTERNAL SPLINES	CSL 35, 61		
US 69-18-04	TORQUEMETER SHAFTGEAR	CSL 34		
US 69-26-03 US 72-03-06	POWER & ACCESSORY GEAR BOX SECOND STAGE TURBINE WHEEL	CSL 57, 58,CEB-86R1 CSL-10		
US 77-15-12	POWER TURBINE COUPLING NUT	CSL 88R5		
US 78-14-08	FUEL PUMP DRIVE SPLINES	61		
US 82-24-05	FUEL CONTROL/POWER TURBINE GOVERNOR ASSEMBLIES			
US 98-24-28	MAIN FUEL CONTROL BELLOWS	CEB-A-282/GT-242R2		
250-C18	( 250-C18 SERIES )			
US 68-22-02	COMPRESSOR ASSEMBLY	CEB 51, 52		
250-C18A .	( 250-C18 SERIES )			
US 68-22-02	COMPRESSOR ASSEMBLY	CEB 51, 52		
250-C18B	( 250-C18 SERIES )			
	, 200 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0			
250-C20 SERIES US 72-03-06	SECOND STAGE TURBINE WHEEL	CSL-10		
US 74-14-03	SECOND STAGE TURBINE WHEEL FUEL CONTROL RIGGING	CSL 1023		
US 77-15-12	POWER TURBINE COUPLING NUT	CSL 1060R5		
US 82-24-05 US 88-17-01	FUEL CONTROL/POWER TURBINE GOVERNOR ASSEMBLIES	CEB-A-1206		
US 96-19-01	BENDIX FUEL CONTROL BEARING SEPARATOR INSTABILITY	CEB-A-1272R2 T95-SB001RA		
US 98-24-28	MAIN FUEL CONTROL BELLOWS	CEB-A-282/GT-242R2		
250-C20	( 250-C20 SERIES )			
CF CF-89-19	FUEL PUMP DRIVE SHAFT			
US 73-19-07	FUEL TUBE	CEB 1040R2		
US 77-09-08 US 78-14-08	BLEED VALVE DIAPHRAGM FUEL PUMP DRIVE SPLINES	1116R2		
US 79-21-01R1	THIRD STAGE TURBINE WHEEL BLADES	1007 CEB 1084R4		
US 82-13-03	HIGH PRESSURE FUEL CONTROL FILTER	CEB-A-1144R5		
US 83-03-02R1	THIRD STAGE TURBINE WHEEL	CEB-A-1174/1146		
250-C20B	( 250-C20 SERIES )			
CF CF-89-19	FUEL PUMP DRIVE SHAFT			
US 77-09-08 US 78-14-08	BLEED VALVE DIAPHRAGM FUEL PUMP DRIVE SPLINES	1071R2		
US 79-21-01R1	THIRD STAGE TURBINE WHEEL BLADES	1007 CEB 1084R4		
US 82-13-03	HIGH PRESSURE FUEL CONTROL FILTER	CEB-A-1144R5		
US 83-03-02R1	THIRD STAGE TURBINE WHEEL	CEB-A-1174/1146		
250-C20F	( 250-C20 SERIES )			
CF CF-89-19	FUEL PUMP DRIVE SHAFT			
US 83-03-02R1	THIRD STAGE TURBINE WHEEL	CEB-A-1174/1146		
250-C20J	( 250-C20 SERIES )	***************************************		
CF CF-89-19	FUEL PUMP DRIVE SHAFT			
250-C20R	( 250-C20 SERIES )			
250-C20R/2	( 250-C20 SERIES )			
250-C20R/4				
US 88-17-01	BENDIX FUEL CONTROL	CEB-A-1272R2		
250-C20S	( 250-C20 SERIES )			
CF CF-89-19	FUEL PUMP DRIVE SHAFT			
US 93-25-05	INSPECT DRIVESHAFT FLEX COUPLING BOLTS	04-780		
250-C20W	( 250-C20 SERIES )			
US 96-19-01	BEARING SEPARATOR INSTABILITY	T95-SB001RA		
250-C28 SERIES				
US 79-16-06	ACCESSORY DRIVE GEARBOX	CEB 72-2003R2		
US 82-24-05	FUEL CONTROL/POWER TURBINE GOVERNOR ASSEMBLIES	CEB-A-73-2026		
US 85-25-07R1 US 85-25-08	OUTER COMBUSTION CASE COMPRESSOR MOUNT ASSEMBLY	72-2113R4/3115R4 72-2085/3085R1		
US 86-20-13	TURBINE SPLINE ADAPTER	CEB-A-72-2132		
US 96-19-01	BEARING SEPARATOR INSTABILITY	T95-SBOO1RA		

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT SUJET REFERENCE SERVICE BULLETIN

ORIGINE NOMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
ALLISON 250-C28 SERIES (CONTINUED / SUITE)		
US 98-24-28	MAIN FUEL CONTROL BELLOWS	CEB-A-282/GT-242R2
250-C28	( 250-C28 SERIES )	
250-C28B US 78-26-01 US 79-06-05 US 79-18-13 US 82-03-02 US 83-01-04 US 85-25-09 US 85-25-12 US 86-16-03 US 89-23-12	( 250-C28 SERIES ) ELECTRICAL SYSTEM OVERSPEED CONTROL SYSTEM THIRD STAGE TURBINE WHEEL PLACARD - ENGINE OVERSPEED CIRCUIT TURBINE ASSEMBLY TURBINE SHAFTING / COUPLING COUPLING - TURBINE TO COMPRESSOR FIRST STAGE TURBINE WHEEL SECOND STAGE TURBINE NOZZLE	CEB 73-2003 CEB 73-2009R2 CEB-A-73-2020 CEB-A-72-2082 R4 CEB-A-72-2127R1 CEB-A-72-2138 CEB-A-72-2044R4
250-C28C US 79-18-13 US 83-01-04 US 85-25-09 US 85-25-12 US 86-16-03 US 89-23-12	( 250-C28 SERIES ) THIRD STAGE TURBINE WHEEL TURBINE ASSEMBLY TURBINE SHAFTING / COUPLING COUPLING - TURBINE TO COMPRESSOR FIRST STAGE TURBINE WHEEL SECOND STAGE TURBINE NOZZLE	CEB-A-72-2082 CEB-A-72-2127R1 CEB-A-72-2127R1 CEB-A-72-2138 CEB-A-72-2044R4
250-C30 SERIES  US 79-16-06  US 81-13-12R1  US 82-24-05  US 84-24-54R2  US 85-25-07R1  US 85-25-08  US 86-19-12  US 86-20-13  US 88-07-06  US 88-17-01  US 98-24-28	ACCESSORY DRIVE GEARBOX FOURTH STAGE TURBINE NOZZLES FUEL CONTROL/POWER TURBINE GOVERNOR ASSEMBLIES COUPLING - TURBINE TO COMPRESSOR OUTER COMBUSTION CASE COMPRESSOR MOUNT ASSEMBLY FIRST STAGE TURBINE WHEEL ABSORBING RING TURBINE SPLINE ADAPTER PRESSURE OIL TUBE ASSEMBLY BENDIX FUEL CONTROL MAIN FUEL CONTROL	72-2113R4/3115R4 72-2085/3085R1 CEB-A-72-3136
250-C30 US 79-06-05 US 84-17-51R1 US 85-06-51 US 96-19-01	( 250-C30 SERIES )  OVERSPEED CONTROL SYSTEM  SECOND STAGE TURBINE NOZZLE SEAL  MAGNETIC PLUGS - POWER AND ACCESSORY GEARBOX BEARING SEPARATOR INSTABILITY	CEB 73-3006R2 CEB-A-72-3127R1 CEB-A-72-3098R5 T95-SB001RA
<b>250-C30P</b> US 96-19-01	( 250-C30 SERIES ) BEARING SEPARATOR INSTABILITY	T95-SB001RA
<b>250-C30S</b> US 84-17-51R1 US 85-06-51	( 250-C30 SERIES ) SECOND STAGE TURBINE NOZZLE SEAL	CEB-A-72-3127R1
<b>250-C40B</b> US 97-25-09	HELICAL POWER TAKEOFF GEARSHAFT ASSEMBLY	A-72-5009
<b>250-C47B</b> US 98-10-03	REPLACEMENT OF MAIN ELECTRICAL HARNESS AND HMU	CEB-A-73-6010
250-C47M	,	
AE-3007C US 98-11-32 US 99-02-51	# 4 BEARING - P/N 23062504 STARTED SHAFT SEAL - OIL LEAK THRU ASS GEARBOX	A-79-014R4
501-D13 SERIES US 60-21-01 US 69-21-03 US 75-17-32 US 75-22-05 US 78-09-09 US 79-25-03 US 80-14-13 US 81-03-02 US 86-17-06	TORQUE METER HOUSING / SHAFT FIRST STAGE COMPRESSOR WHEELS SECOND STAGE TURBINE WHEELS SECOND STAGE TURBINE WHEEL THIRD AND FOURTH STAGE TURBINE WHEELS SECOND, THIRD AND FOURTH STAGE TURBINE WHEELS FIRST STAGE TURBINE WHEEL FIRST, SECOND, THIRD & FOURTH STAGE TURBINE WHEELS AUTOFEATHER - THRUST SENSITIVE SWITCH ASSEMBLIES	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
ALLISON 501-D13 US 59-13-01 US 59-18-01 US 59-21-03	( 501-D13 SERIES )  PROPELLER SHAFT ROLLER BEARING  GROUND IDLE / FOURTH STAGE TURBINE BLADES FIRST STAGE COMPRESSOR BLADES	72-74 72-77 61, 80
<b>501-D13D</b> US 60-07-01	( 501-D13 SERIES ) THIRD AND FOURTH STAGE TURBINE BLADES	72-77
501-D13H	( 501-D13 SERIES )	
501-D22 SERIES US 69-21-03	FIRST STAGE COMPRESSOR WHEELS	CSL-120
<b>501-D22A</b> US 75-07-06	( 501-D22 SERIES ) SECOND STAGE TURBINE BLADES	COIL-1019
501-D22G	( 501-D22 SERIES )	
ALVIS LIMITED LEONIDES 514/8A	· ·	
AVCO LYCOMING O-145-A2		
US 91-14-22 US 94-06-09	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
0-145-B2 US 91-14-22 US 94-06-09	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
<b>0-145-B3</b> US 91-14-22 US 94-06-09	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	SL L163B, SB 475 R A CSB 641
US 75-08-09 US 80-25-02R2 US 90-04-06R1 US 91-14-22 US 93-11-11 US 94-06-09 US 95-03-10 US 98-17-11	OIL PUMP DRIVE SHAFT/IMPELLER ENGINE PUSHRODS PROPELLER GOVERNOR OIL LINES & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PUSH RODS ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION	381B, 385C 453, SI 1388A, 1068A 488 A & SL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES 002 CSB 641 522 454B, 455D, 524, 456
US 75-08-09 US 80-25-02R2 US 90-04-06R1 US 91-14-22 US 93-11-11 US 94-06-09 US 95-03-10 US 98-17-11	OIL PUMP DRIVE SHAFT/IMPELLER ENGINE PUSHRODS PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PUSH RODS ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION	381B, 385C 453, SI 1388A, 1086A 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES OO2 CSB 641 522 454B, 455D, 524, 456
0-235-C	( 0-235-C SERIES )	
0-235-C1	( O-235-C SERIES )	
0-235-C1B	( O-235-C SERIES )	
0-235-C1C	( 0-235-C SERIES )	
D-235-C2	( 0-235-C SERIES )	
0-235-C2C  0-235-K SERIES US 75-08-09 US 80-25-02R2 US 90-04-06R1 US 91-14-22 US 93-11-11	O-235-C SERIES )  OIL PUMP DRIVE SHAFT/IMPELLER  ENGINE PUSHRODS  PROPELLER GOVERNOR OIL LINE & FITTINGS  PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES  AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	381B, 385C 453, SI 1388A, 1068A 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES 002

MAKE / CONS MODEL / MO		
ORIGIN	AD NUMBER	
ORIGINE	NUMERO DE	CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

AVCO LYCOMING	SUJET	BULLETIN DE SERVICE DE REF.
O-235-K SERIES (CONTINUED / SUITE)		
US 94-06-09 US 95-03-10 US 96-09-10 US 98-17-11	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PUSH RODS ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION	CSB 641 522 454B, 455D, 524, 456
0-235-K2C	( O-235-K SERIES )	
0-235-L SERIES		
US 75-08-09 US 80-25-02R2 US 90-04-06R1 US 91-14-22 US 93-11-11 US 94-06-09 US 95-03-10 US 96-09-10 US 98-17-11	CRANKSHAFT INSPECTION	AERO ACCESSORIES 002 1
0-235-L2A	( D-235-L SERIES )	
0-235-L2C US 78-25-01	( O-235-L SERIES )  CONDENSERS - SLICK MAGNETOS	432
US 75-08-09 US 80-25-02R2 US 90-04-06R1 US 91-14-22 US 93-11-11 US 94-06-09 US 95-03-10 US 96-09-10 US 98-17-11	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PUSH RODS	AERO ACCESSORIES 002
0-235-N2C	( O-235-N SERIES )	
<b>0-290</b> US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	
US 91-14-22 US 93-11-11 US 94-06-09 US 96-09-10 US 98-17-11	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	AERO ACCESSORIES 002
US 91-14-22 US 93-11-11 US 94-06-09 US 96-09-10 US 98-17-11	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION	SL L163B, SB 475 R A AERO ACCESSORIES 002 CSB 641 454B, 455D, 524, 456
US 91-14-22 US 93-11-11 US 94-06-09 US 96-09-10 US 98-17-11	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE DIL PUMP IMPELLERS CRANKSHAFT INSPECTION  DIL PUMP DRIVE SHAFT/IMPELLER	SL L163B, SB 475 R A AERO ACCESSORIES 002 CSB 641 454B, 455D, 524, 456 381B, 385C 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES 002
US 91-14-22 US 93-11-11 US 94-06-09 US 96-09-10 US 98-17-11 0-290-B US 75-08-09 US 90-04-06R1 US 91-14-22 US 93-11-11 US 94-06-09 US 96-09-10	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION  OIL PUMP DRIVE SHAFT/IMPELLER PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION  ENGINE OIL PUMP IMPELLERS	SL 163B, SB 475 R A AERO ACCESSORIES 002 CSB 641 454B, 455D, 524, 456 381B, 385C 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES 002 CSB 641
US 91-14-22 US 93-11-11 US 94-06-09 US 96-09-10 US 98-17-11 0-290-B US 75-08-09 US 90-04-06R1 US 91-14-22 US 93-11-11 US 94-06-09 US 96-09-10 US 98-17-11	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE DIL PUMP IMPELLERS CRANKSHAFT INSPECTION  OIL PUMP DRIVE SHAFT/IMPELLER PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION  ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION  ( O-290-C SERIES ) OIL PUMP DRIVE SHAFT / IMPELLER PROPELLER GOVERNOR OIL LINE & FITTINGS	SL L163B, SB 475 R A AERO ACCESSORIES OO2 CSB 641 454B, 455D, 524, 456  381B, 385C 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES OO2 CSB 641 454B, 455D, 524, 456  454B, 455D, 524, 456  381B, 385C 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES OO2

MAKE / CONS MODEL / MO ORIGIN ORIGINE	TRUCTEUR DDELE AD NUMBER NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
AVCO LY	COMING		
0-290- US US US US US US US	D SERIES 75-08-09 90-04-06R1 91-14-22 93-11-11 94-06-09 96-09-10 98-17-11	OIL PUMP DRIVE SHAFT/IMPELLER PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL PUMP IMPELLERS CRANKSHAFT INSPECTION	381B, 385C 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES 002 CSB 641 454B, 455D, 524, 456
0-290-	D	( D-290-D SERIES )	
0-290- US US US US US US US US	D2 SERIES 54-02-01 75-08-09 90-04-06R1 91-14-22 93-11-11 94-06-09 96-09-10 98-17-11	MAGNETÓ TIMING OIL PUMP DRIVE SHAFT / IMPELLER PROPELLER GOVERNOR DIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE DIL PUMP IMPELLERS CRANKSHAFT INSPECTION	169 381B, 385C 488 A & SIL 1435 1 SL L163B, SB 475 R A AERO ACCESSORIES 002 CSB 641 454B, 455D, 524, 456
0-290-	D2	( 0-290-D2 SERIES )	
0-290-	D2A	( D-290-D2 SERIES )	
0-290-	D2B	( 0-290-D2 SERIES )	
0-290-	D2C	( O-290-D2 SERIES )	
0-320		( 0-320-A SERIES )	
US	A SERIES 55-02-02 59-10-07 63-23-02 64-16-05 66-20-04 73-23-01 75-08-09 87-10-06R1 90-04-06R1 91-14-22 92-12-05 93-11-11 94-06-09 96-09-10 97-15-11 98-02-08 98-17-11	GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER CYLINDER BAFFLE CLAMPS  EXHAUST VALVE STEM / CAMSHAFT  AC FUEL PUMP OIL FILTER ADAPTER GASKET PISTON PINS OIL PUMP DRIVE SHAFT/IMPELLER ROCKER ARM ASSEMBLY PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL PUMP IMPELLERS PISTON PINS CRANKSHAFT INSPECTION CRANKSHAFT INSPECTION	176 254A 293B 293B 307 367F 381B, 385C 477A 488 A & SIL 1435 1 SL L163B, SB 475 R A 501 REV B AERO ACCESSORIES 002 CSB 641 454B, 455D, 524, 456 527C 505B
0-320-4		( O-320-A SERIES )	
0-320-4		( 0-320-A SERIES )	
0-320-A		( 0-320-A SERIES )	
0-320-A		( D-320-A SERIES )	
0-320-A		( 0-320-A SERIES )	
D-320-A		( 0-320-A SERIES )	
D-320-A		( 0-320-A SERIES )	
O-320-A	3D	( O-320-A SERIES )	
0-320-A	44	( O-320-A SERIES )	
US !	SERIES 55-02-02 59-10-07 63-23-02	GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER CYLINDER BAFFLE CLAMPS EXHAUST VALVE STEM / CAMSHAFT	176 254A 293B

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

	30321	BULLETIN DE SERVICE DE REF.
AVCO LYCOMING D-320-B SERIES		
(CONTINUED / SUITE)		
US 64-16-05	AC FUEL PUMP	
US 66-20-04	OIL FILTER ADAPTER GASKET	298
US 73-23-01	PISTON PINS	307 367F
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	
US 87-10-06R1	RUCKER ARM ASSEMBLY	477A
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & CTI 443E 4
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05 US 93-11-11	PISTON PINS	501 REV B
US 93-11-11 US 94-06-09	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 96-09-10	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
US 97-15-11	ENGINE OIL PUMP IMPELLERS PISTON PINS	454B, 455D, 524, 456
US 98-17-11	CRANKSHAFT INSPECTION	527C
0-320-B1A	( O-320-B SERIES )	
US 98-02-08	CRANKSHAFT INSPECTION	505B
0 000 040		
US 98-02-08	( O-320-B SERIES )	
03 98-02-08	CRANKSHAFT INSPECTION	505B
0-320-B1C	( O-320-B SERIES )	
US 98-02-08	CRANKSHAFT INSPECTION	505B
	2.00.00.00.00.00.00.00.00.00.00.00.00.00	5056
0-320-B2A	( O-320-B SERIES )	
US 98-02-08	CRANKSHAFT INSPECTION	505B
0-320-B2B	( 0 000 0 050750 )	
US 98-02-08	( O-320-B SERIES )	
30 O2 O8	CRANKSHAFT INSPECTION	505B
0-320-B2C	( O-320-B SERIES )	
	,	
O-320-B3A	( O-320-B SERIES )	
US 98-02-08	CRANKSHAFT INSPECTION	505B
0-320-B3B	( D-320-B SERIES )	
US 98-02-08	COANICCIAET THEORETTAN	505B
	CRANKSMAFT INSPECTION	- 505B
0-320-B3D	( O-320-B SERIES )	
US 98-02-08	CRANKSHAFT INSPECTION	505B
O-320-C SERIES		
US 55-02-02	CASKET - 10MED ACCESSORY DRIVE ADARTED COVER	170
US 59-10-07	GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER CYLINDER BAFFLE CLAMPS	176 254A
US 63-23-02	EXHAUST VALVE STEM / CAMSHAFT	
US 64-16-05	AC FUEL PUMP	298
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 73-23-01	PISTON PINS	367F
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 87-10-06R1 US 90-04-06R1	ROCKER ARM ASSEMBLY	477A
US 90-04-06R1 US 91-14-22	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A 501 REV B
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 97-15-11	PISTON PINS	527C
US 98-02-08	CRANKSHAFT INSPECTION	505B
US 98-17-11	CRANKSHAFT INSPECTION	
0-320-C1A	( 0-320-C SERIES )	
0.020.011	( O SZO C SERIES )	
0-320-C1B	( O-320-C SERIES )	
0-320-C2A	( 0-320-C SERIES )	
O-320-C2B	( 0-320-C SERIES )	
	( O OLO O CLITTLO )	
0-320-C2E	( 0-320-C SERIES )	
0-320-C3A	( 0-220-C SERIES )	
0 320-C3A	( O-320-C SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE
SUJJET

US 94-06-09	ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
0-320-03B				
D-320-D SERIES			( 0 200 C CERTEC )	
US 55-02-02 US 59-10-07 US 63-22-02 US 63-22-02 US 63-22-02 US 63-22-02 US 63-22-02 US 63-22-02 US 63-22-02 US 63-22-02 US 63-22-02 US 73-22-01 US 73-22-01 US 73-22-01 US 73-22-01 US 73-22-01 US 73-22-01 US 73-22-01 US 73-22-01 US 73-22-01 US 73-22-01 US 87-10-0681 US 87-10-0681 US 87-10-0681 US 87-10-0681 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-10-0301 US 93-02-030 US 93-17-11 US 93-02-030 US 93-17-11 US 93-02-030 US 93-17-11 US 93-02-030 US 93-17-11 US 93-02-030 US 93-17-11 US 93-02-030 US 93-17-11 US 93-02-030 US 93-17-11 US 93-02-0301 US 93-03-0301 US 93-03-0301 US 93-17-11 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-0301 US 93-03-03	0-320-	-038	( U-320-C SERIES )	
US 59-10-07 CYLINDER BAFFLE CLAMPS 298 US 63-22-02 EXAMSUS VALVE STEM / CAMSHAFT 298 US 64-16-05 AC FUEL PLUMP 298 US 64-16-05 AC FUEL PLUMP 388 US 67-10-0681 PLOYER STOPPAGE AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND PLOYER AND P	0-320-	D SERIES		•••••••••••••••••••••••••••••••••••••••
US 63-22-02 US 64-16-05 US 66-20-04 US 66-20-04 US 66-20-04 US 66-20-04 US 75-06-09 US 75-06-09 US 87-10-0681 US 90-04-0681 US 90-04-0681 US 90-04-0681 US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES US 92-12-05 US 92-12-05 US 94-06-09 US 94-06-09 US 96-09-10 US 98-09-10 US 98-17-11 US 99-15-11 US 99-15-11 US 99-16-29 US 98-17-11 US 99-16-29 US 98-17-11 US 98-17-11 US 99-16-09 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-17-11 US 98-18-18-18-18-18-18-18-18-18-18-18-18-18				
US 64-16-05 US 68-20-04 US 68-20-04 US 68-20-04 US 75-08-09 US 87-06-809 US 87-06-81 US 90-04-0681 US 90-04-0681 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-15-11 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 US 91-14-22 U				
US 66-20-04 US 73-20-01 US 75-08-09 US 75-08-09 US 75-08-09 UL PUMP DRIVE SHAFT/IMPELLER US 91-10-06RT US 91-10-06RT US 91-10-22 US 92-12-05 US 93-11-11 AC L VCOMING & RADAY DIAPHRAGM FUEL PUMPS US 93-11-11 AC L VCOMING & RADAY DIAPHRAGM FUEL PUMPS US 93-11-11 AC L VCOMING & RADAY DIAPHRAGM FUEL PUMPS US 93-10-11 BENDIX MACNETOS CAPACITORS/OPEN CIRCUIT CONDITION US 94-08-09 US 93-09-10 US 94-09-10 US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION D-320-D1A  (D-320-D SERIES)  D-320-D2A (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D2C (D-320-D SERIES)  D-320-D2C (D-320-D2C (D-320-D2C (D-320-D2C (D-320-D2C (D-320-D2C			AC FILE DIMP	
US				
US 87-10-0681 PROCKER ARM ASSEMBLY US 90-00-00681 PROPEDIES OF SERIES 1				
US   90-04-06R1			OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 91-14-22 US 92-12-06 US 93-11-11 US 94-06-09 US 93-11-11 US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-09 US 98-02-09 US 98-02-09 US 98-02-09 US 98-02-09 US 98-02-09 US 98-02-09 US 98-02-09 US 98-17-11 US 98-09-01 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-17-11 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 98-02-08 US 9				
US   92-12-05				
US 93-11-11 US 94-06-09 US 96-09-10 US 96-09-10 US 96-09-10 US 96-09-10 US 96-09-10 US 96-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-07-010 US 98-09-10 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-07-010 US 98-08-08 US 98-10-07 US 98-08-08 US 98-10-07 US 98-08-08 US 98-10-07 US 98-08-08 US 98-10-09 US 98-08-09-10 US 98-08-09 US 98-08-09 US 98-08-09 US 98-08-09 US 98-08-09 US 98-08-09 US 98-08-09 US 98-08-09 US 98-09-10 US 99-08-08 US 98-11-11 US 91-14-22 US 92-12-05 US 93-11-11 US 91-14-22 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10 US 98-09-10	US	92-12-05		
US 94-06-09	US	93-11-11		AERO ACCESSORIES 002
U.S. 98-715-11				
US 98-02-08 US 98-17-11 CRANKSHAFT INSPECTION  0-320-D1A ( 0-320-D SERIES )  0-320-D2A ( 0-320-D SERIES )  0-320-D2B ( 0-320-D SERIES )  0-320-D2C ( 0-320-D SERIES )  0-320-D2G ( 0-320-D SERIES )  0-320-D2G ( 0-320-D SERIES )  0-320-D2G ( 0-320-D SERIES )  0-320-D2H ( 0-320-D SERIES )  0-320-D2H ( 0-320-D SERIES )  0-320-D2H ( 0-320-D SERIES )  0-320-D2J ( 0-320-D SERIES )  0-320-D3G ( 0-320-D SERIES )  0-320-D3G ( 0-320-D SERIES )  0-320-D3G ( 0-320-D SERIES )  0-320-D3G ( 0-320-D SERIES )  0-320-E SERIES  US 55-02-02 ( GASKET - LOHER ACCESSORY DRIVE ADAPTER COVER 176 (				454B, 455D, 524, 456
US 98-17-11 CRANKSHAFT INSPECTION  0-320-D1A ( 0-320-D SERIES )  0-320-D1D ( 0-320-D SERIES )  0-320-D2A ( 0-320-D SERIES )  0-320-D2B ( 0-320-D SERIES )  0-320-D2C ( 0-320-D SERIES )  0-320-D2C ( 0-320-D SERIES )  0-320-D2D ( (0-320-D SERIES )  0-320-D2J ( 0-320-D SERIES )  0-320-E SERIES US 55-02-02 ( 0-320-D SERIES )  US 55-02-02 ( GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER 176 (				
O-320-D1D ( 0-320-D SERIES ) O-320-D2A ( 0-320-D SERIES ) O-320-D2B ( 0-320-D SERIES ) O-320-D2C ( 0-320-D SERIES ) O-320-D2G ( 0-320-D SERIES ) O-320-D2G ( 0-320-D SERIES ) O-320-D2H ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3C-D3G ( 0-320-D SERIES ) O-320-D3C-D3C ( 0-320-D SERIES ) O-320-D3C-D3C ( 0-320-D SERIES ) O-320-D3C-D3C ( 0-320-D SERIES )				3036
0-320-D1D ( 0-320-D SERIES ) 0-320-D2A ( 0-320-D SERIES ) 0-320-D2B ( 0-320-D SERIES ) 0-320-D2C ( 0-320-D SERIES ) 0-320-D2G ( 0-320-D SERIES ) 0-320-D2G ( 0-320-D SERIES ) 0-320-D2H ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-D SERIES ) 0-320-E SERIES ( 0-320-E SERIES ) 0-320-E SERIES ( 0-320-E SERIES ) 0-320-E SERIES ( 0-320-E SERIES ) 0-320-E SERIES ( 0-320-E SERIES )				
O-320-D2A ( 0-320-D SERIES ) O-320-D2B ( 0-320-D SERIES ) O-320-D2C ( 0-320-D SERIES ) O-320-D2G ( 0-320-D SERIES ) O-320-D2H ( 0-320-D SERIES ) O-320-D2H ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES )	0~320-	D1A	( D-320-D SERIES )	
O-320-D2A ( 0-320-D SERIES ) O-320-D2B ( 0-320-D SERIES ) O-320-D2C ( 0-320-D SERIES ) O-320-D2G ( 0-320-D SERIES ) O-320-D2H ( 0-320-D SERIES ) O-320-D2H ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-D SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES ) O-320-D3G ( 0-320-E SERIES )	0-320-	D1D	( 0-320-D SERIES )	
0-320-D2B ( 0-320-D SERIES ) 0-320-D2C ( 0-320-D SERIES ) 0-320-D2G ( 0-320-D SERIES ) 0-320-D2H ( 0-320-D SERIES ) 0-320-D2J ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-E SERIES US 55-02-02 GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER 176 US 59-10-07 CYLINDER BAFFLE CLAMPS 254A 254A 254A 2554A 2			( o olo b olitico )	
D-320-D2C ( 0-320-D SERIES )  D-320-D2G ( 0-320-D SERIES )  O-320-D2H ( 0-320-D SERIES )  O-320-D2J ( 0-320-D SERIES )  O-320-D3G ( 0-320-D SERIES )  O-320-E SERIES US 55-02-02 GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER 176 254A 254A 254A 254A 254A 254A 254A 254A	0-320-	D2A	( O-320-D SERIES )	
0-320-D2C ( 0-320-D SERIES ) 0-320-D2G ( 0-320-D SERIES ) 0-320-D2H ( 0-320-D SERIES ) 0-320-D2J ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-E SERIES	0-220	DAD	( 0 000 D CEDIEC )	
0-320-D2G ( 0-320-D SERIES ) 0-320-D2H ( 0-320-D SERIES ) 0-320-D2J ( 0-320-D SERIES ) 0-320-D3G ( 0-320-D SERIES ) 0-320-E SERIES US 55-O2-O2 GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER 176 US 59-10-O7 CYLINDER BAFFLE CLAMPS 254A US 63-23-O2 EXHAUST VALVE STEM / CAMSHAFT 293B US 64-16-O5 AC FUEL PUMP 298 US 64-16-O5 AC FUEL PUMP 298 US 73-23-O1 PISTON PINS 367F US 75-O8-O9 OIL PUMP DRIVE SHAFT/ IMPELLER 381B, 385C US 87-10-O6R1 ROCKER ARM ASSEMBLY 477A US 90-O4-O6R1 ROCKER ARM ASSEMBLY 477A US 92-12-O5 PISTON PINS US 93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES OU S 93-11-11 PISTON PINS US 93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES OU S 98-O2-O8 CRAMKSHAFT INSPECTION 505B US 98-O2-O8 CRAMKSHAFT INSPECTION 505B US 98-O2-O8 CRAMKSHAFT INSPECTION 505B US 98-O2-O8 CRAMKSHAFT INSPECTION 505B US 93-O2-E2A ( 0-320-E SERIES ) 0-320-E2B ( 0-320-E SERIES ) 0-320-E2G ( 0-320-E SERIES )	0-320-	UZB	( U-320-D SEKIES )	
0-320-D2G ( 0-320-D SERIES )  0-320-D2H ( 0-320-D SERIES )  0-320-D2J ( 0-320-D SERIES )  0-320-D3G ( 0-320-D SERIES )  0-320-E SERIES	0-320-	D2C	( O-320-D SERIES )	
D-320-D2H ( D-320-D SERIES )  D-320-D3G ( D-320-D SERIES )  O-320-E SERIES US 55-O2-O2 GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER 176 US 59-10-07 CYLINDER BAFFLE CLAMPS 254A US 63-23-O2 EXHAUST VALVE STEM / CAMSHAFT 259B US 64-16-O5 AC FUEL PUMP 298 US 64-16-O5 AC FUEL PUMP 298 US 73-23-O1 PISTON PINS 367F US 75-O8-O9 DIL PUMP DRIVE SHAFF/IMPELLER 381B, 385C US 87-10-O6R1 ROCKER ARM ASSEMBLY 477A US 90-O4-O6R1 ROCKER ARM ASSEMBLY 477A US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R US 92-12-O5 PISTON PINS US 93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES OU S 98-O2-O8 CRAMKSHAFT INSPECTION 505B US 98-07-15-11 PISTON PINS US 98-07-15-11 PISTON PINS US 98-02-O8 CRAMKSHAFT INSPECTION 505B US 98-17-11 CRAMKSHAFT INSPECTION 505B US 98-17-11 CRAMKSHAFT INSPECTION 505B US 98-17-11 CRAMKSHAFT INSPECTION 505B US 98-02-DE SERIES ) U-320-E2B ( U-320-E SERIES ) U-320-E2B ( U-320-E SERIES )				
D-320-D2J	0-320-	D2G	( D-320-D SERIES )	
D-320-D2J	0-320-	D2H	( D-320-D SERIES )	
O-320-D3G		<del></del>		
US   95-02-02   GASKET   LOWER ACCESSORY DRIVE ADAPTER COVER   176	0-320-	D2J	( O-320-D SERIES )	
US   95-02-02   GASKET   LOWER ACCESSORY DRIVE ADAPTER COVER   176	0-320-	nae	( D-220-D SERIES )	
US 55-02-02 GASKET - LOWER ACCESSORY DRIVE ADAPTER COVER 176 US 59-10-07 CYLINDER BAFFLE CLAMPS 254A  US 63-23-02 EXHAUST VALVE STEM / CAMSHAFT 293B US 64-16-05 AC FUEL PUMP 298 US 66-20-04 OIL FILITER ADAPTER GASKET 307 US 73-23-01 PISTON PINS 367F US 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C US 87-10-06R1 ROCKER ARM ASSEMBLY 477A US 90-04-06R1 PROPELLER GOVERNOR OIL LINE & FITTINGS 488 A & SIL 1435 1 US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R US 92-12-05 PISTON PINS 501 REV B US 93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES OO CSB 641 US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION 454B, 455D, 524, 45 US 98-02-08 CRANKSHAFT INSPECTION 505B US 98-07-15-11 CRANKSHAFT INSPECTION 505B  US 98-07-16-11 CRANKSHAFT INSPECTION 505B  US 98-07-16-11 CRANKSHAFT INSPECTION 505B  US 93-0-E2A (0-320-E SERIES)  U-320-E2B (0-320-E SERIES)  U-320-E2C (0-320-E SERIES)  U-320-E2C (0-320-E SERIES)		DUG	( O J20 D JERIES )	
US 59-10-07				
US 63-23-02 EXHAUST VALVE STEM / CAMSHAFT 293B US 64-16-05 AC FUEL PUMP 298 US 66-20-04 OIL FILTER ADAPTER GASKET 307 US 73-23-01 PISTON PINS 367F US 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C US 87-10-06R1 ROCKER ARM ASSEMBLY 477A US 90-04-06R1 PROPELLER GOVERNOR OIL LINE & FITTINGS 488 A & SIL 1435 1 US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R US 92-12-05 PISTON PINS 501 REV B US 93-11-11 AC, LYCOMING RAJAY DIAPHRAGM FUEL PUMPS 501 REV B US 93-11-11 AC, LYCOMING RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES OO US 96-09-10 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CRANKSHAFT INSPECTION 505B US 98-02-08 CRANKSHAFT INSPECTION 505B US 98-17-11 CRANKSHAFT INSPECTION 505B  D-320-E2A (D-320-E SERIES)  D-320-E2B (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2D (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)				
US 64-16-05				
US 66-20-04				
US 75-08-09				
US 87-10-06R1 ROCKER ARM ASSEMBLY US 90-04-06R1 PROPELLER GOVERNOR DIL LINE & FITTINGS US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL 1435 1 US 92-12-05 PISTON PINS US 93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES OO US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 97-15-11 PISTON PINS US 97-15-11 PISTON PINS US 98-02-08 CRANKSHAFT INSPECTION US 98-17-11 CRANKSHAFT INSPECTION  D-320-E1A (D-320-E SERIES)  D-320-E2B (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)				367F
US 90-04-06R1				
US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R US 92-12-05 PISTON PINS US 93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES OO BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE DIL PUMP IMPELLERS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B US 98-17-11 CRANKSHAFT INSPECTION 505B  D-320-E1A (D-320-E SERIES)  D-320-E2B (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)				
US 92-12-05 US 93-11-11 US 93-11-11 US 94-06-09 US 96-09-10 US 97-15-11 US 98-02-08 US 98-17-11 US 98-17-11 US 98-02-E2B US 98-02-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2H US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B US 0-320-E2B U			PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	
US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 45 US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B US 98-17-11 CRANKSHAFT INSPECTION  D-320-E1A ( D-320-E SERIES )  D-320-E2B ( D-320-E SERIES )  D-320-E2C ( D-320-E SERIES )  D-320-E2C ( D-320-E SERIES )  D-320-E2D ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )			PISTON PINS	
US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 45 US 97-15-11 PISTON PISTON 527C US 98-02-08 CRANKSHAFT INSPECTION 505B US 98-17-11 CRANKSHAFT INSPECTION  D-320-E1A (D-320-E SERIES)  D-320-E2A (D-320-E SERIES)  D-320-E2B (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2C (D-320-E SERIES)  D-320-E2D (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)  D-320-E2G (D-320-E SERIES)			AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  US 98-17-11 CRANKSHAFT INSPECTION  D-320-E1A ( D-320-E SERIES )  D-320-E2B ( D-320-E SERIES )  D-320-E2C ( D-320-E SERIES )  D-320-E2D ( D-320-E SERIES )  D-320-E2D ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )				
US 98-02-08				
US 98-17-11 CRANKSHAFT INSPECTION  D-320-E1A ( D-320-E SERIES )  D-320-E2A ( D-320-E SERIES )  D-320-E2B ( D-320-E SERIES )  D-320-E2C ( D-320-E SERIES )  D-320-E2D ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )	_			
D-320-E2A ( D-320-E SERIES )  D-320-E2B ( D-320-E SERIES )  D-320-E2C ( D-320-E SERIES )  D-320-E2D ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2H ( D-320-E SERIES )	US	98-17-11	CRANKSHAFT INSPECTION	
D-320-E2A ( D-320-E SERIES )  D-320-E2B ( D-320-E SERIES )  D-320-E2C ( D-320-E SERIES )  D-320-E2D ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2H ( D-320-E SERIES )	0-220-	C 4 A	( D-220 E CEDIEC )	
D-320-E2B ( D-320-E SERIES )  D-320-E2C ( D-320-E SERIES )  D-320-E2D ( D-320-E SERIES )  D-320-E2G ( D-320-E SERIES )  D-320-E2H ( D-320-E SERIES )	U-320-	LIA	( U-320-E SEKIES )	
O-320-E2C ( O-320-E SERIES )  O-320-E2D ( O-320-E SERIES )  O-320-E2G ( O-320-E SERIES )  O-320-E2H ( O-320-E SERIES )	0-320-	E2A	( D-320-E SERIES )	
O-320-E2C ( O-320-E SERIES )  O-320-E2D ( O-320-E SERIES )  O-320-E2G ( O-320-E SERIES )  O-320-E2H ( O-320-E SERIES )		<u></u>		
D-320-E2D ( D-320-E SERIES ) D-320-E2G ( D-320-E SERIES )  O-320-E2H ( D-320-E SERIES )	0-320-	£2B	( D-320-E SERIES )	
O-320-E2D ( O-320-E SERIES ) O-320-E2G ( O-320-E SERIES ) O-320-E2H ( O-320-E SERIES )	0-320-	E2C	( 0-320-E SERIES )	
0-320-E2G ( 0-320-E SERIES )  0-320-E2H ( 0-320-E SERIES )				
0-320-E2H ( 0-320-E SERIES )	0-320-	E2D	( D-320-E SERIES )	
0-320-E2H ( 0-320-E SERIES )	0-320-	- 2G	( N-320-E SERIES )	
, s s	0 020		( O SZO E SERIES )	
	0-320-	E2H	( O-320-E SERIES )	
[]-220-E24	0-220	24	( 0 000 F CERVES )	
0-320-E3A ( 0-320-E SERIES )	0-320-1	LJA	( U-320-E SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

15   98-02-08   CRANKSHAFT INSPECTION   505B	ORIGINE NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
0-320-E3D ( 0-320-E SERIES )  0-320-E3D ( 0-320-E SERIES )  0-320-E3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )  0-320-B3D ( 0-320-ESRIES )	AVCO LYCOMING		
0-320-ESH	0-320-E3B	( O-320-E SERIES )	
D-320-E3H	0-320-E3D	( 0-320-E SERIES )	
US 55-02-02 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 59-10-07 US 73-23-01 US 73-23-01 US 77-20-07 ROCKER ARM RETAINING STUDS / TAPPETS US 79-20-07 ROCKER ARM RETAINING STUDS / TAPPETS US 79-10-08 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-10-09 US 59-11-11 US 59-11-11 AC. LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS US 59-15-11 US 59-10-0382 US 59-17-11 CRAINSHAFT INSPECTION US 59-10-0382 US 59-17-10 US 59-10-0382 US 59-17-10 US 59-10-0382 US 59-17-11 CRAINSHAFT INSPECTION US 59-10-0382 US 59-17-10 US 59-10-0382 US 59-17-10 US 59-10-0382 US 59-17-10 US 59-10-0382 US 59-17-11 US 59-10-0382 US 59-17-11 CRAINSHAFT INSPECTION US 59-10-0382 AERO ACCESSORIES US 59-12-05 US 59-10-0382 US 59-17-11 US 59-10-0382 AERO ACCESSORIES US 59-12-05 US 59-10-0382 US 59-10-0382 AERO ACCESSORIES US 59-12-05 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US 59-10-0382 US	D-320-F3H		
US   55-02-02		( D-320-E SERIES )	
US 59-10-07 CVLINDER BAFFLE CLAMPS   176		CACHET	
US   G3-23-02   EXHAUST VALVE STEM / CAMSHAFT   2938   US   G4-16-005   AC FUEL PUMP   298   US   G4-16-005   AC FUEL PUMP   298   US   G4-16-005   AC FUEL PUMP   298   US   G7-23-01   US   75-08-09   OIL FILTER ADAPTER GASKET   307   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367		CYLINDER BAFFLE CLAMPS	
US 73-23-01 PISTON PINS 307  US 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER 367  US 77-09-07 ROCKER ARM RETAINING STUDS / TAPPETS 423  US 78-12-08 OIL PUMP DRIVE SHAFT/IMPELLER 423  US 78-12-09 CRAMKSHAFT ASSEMBLY 422  US 78-12-09 CRAMKSHAFT ASSEMBLY 422  US 80-04-03R2 EXHAUST VALVE SPRING SEATS 442  US 80-04-03R2 EXHAUST VALVE SPRING SEATS 443  US 93-11-11 AC LYCOMING RAD AND AND AND AND AND AND AND AND AND A		EXHAUST VALVE STEM / CAMSHAFT	
US   73-23-01   PISTON PINS   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F   367F		AC FUEL PUMP	298
1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5   1.5		PISTON PINS	
US 78-12-08		OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 80-04-03R2 EAHAUST VALVE SPRING SEATS/HYDRAULIC LIFTERS 425  US 80-14-07 EAHAUST VALVE SPRING SEATS 447  US 80-04-06R1 PROPELLER GOVERNOR OIL LINE & FITTINGS 488 A 8 SIL 1435 1  US 32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-15 PISTON PINS 501 REV 8  32-14-16 PISTON PINS 501 REV 8  32-15 PISTON PINS 501 REV 8  32-15 PISTON PINS 501 REV 8  32-15 PISTON PINS 501 REV 8  32-15 PISTON PINS 501 REV 8  32-16 PISTON PINS 501 REV 8  32-16 PISTON PINS 501 REV 8  32-16 PISTON PINS 501 REV 8  32-16 PISTON PINS 501 REV 8  32-17 PISTON PINS 501 REV 8  32-17 PISTON PINS 501 REV 8  32-17 PISTON PINS 501 REV 8  32-17 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8  32-18 PISTON PINS 501 REV 8	US 78-12-08	OIL PUMP DRIVEN IMPELLER	
US		CRANKSHAFT ASSEMBLY	
US 90-04-0681 US 92-12-05 US 93-11-11 US 92-12-05 US 93-11-11 US 92-12-05 US 93-02-08 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-09-10 US 93-11-11 CRAMSHAFT INSPECTION US 93-17-11 CRAMSHAFT INSPECTION US 93-17-11 CRAMSHAFT INSPECTION US 93-17-11 CRAMSHAFT INSPECTION US 93-17-11 CRAMSHAFT INSPECTION US 77-07-07 US 79-04-05 US 79-04-05 US 79-04-05 US 93-02-08 US 93-02-05 US 93-02-05 US 93-02-05 US 93-02-05 US 93-02-05 US 93-02-05 US 93-02-05 US 93-02-05 US 93-02-05 US 93-02-06 US 93-02-08 US 93-02-08 US 93-02-08 US 93-02-08 US 93-02-08 US 93-02-08 US 93-02-08 US 93-02-08 US 93-03-03 US 93-03 US 93-03-03 US 93-03-03 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-02-08 US 93-03-08 US 93-02-08 US 93-03-08 US 93-02-08 US 93-02-09 US 93-03-09 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-08 US 93-03-09 US 93-03-09 US 93-03-09 US 93-03-09 US 93-03-09 US 93-03-09 US 93-03-09 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-03 US 93-03-0		EXMAUST VALVE SPRING SEATS/HYDRAULIC LIFTERS EXHAUST VALVE SPRING SEATS	
US   92-12-05		PROPELLER GOVERNOR OIL LINE & FITTINGS	
US   94-06-09		PISTON PINS	501 REV B
US 97-15-11	US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSR 641
US   98-02-08		ENGINE DIL PUMP IMPELLERS	454B, 455D, 524, 456
US 98-17-11 CRANKSHAFT INSPECTION  0-320-H2AD US 77-07-07 OIL FILLER EXTENSION - PERFORATED SLEEVE 407A  AEID-320-E SERIES US 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430  US 79-04-05 BENDIX FUEL INJECTORS 428, 429, 430  US 79-04-05 BENDIX FUEL INJECTORS 428, 429, 430  US 79-04-05 BENDIX FUEL INJECTORS 428, 429, 430  US 90-04-06R1 ROCKER ARM ASSEMBLY 477A  US 90-04-06R1 PROPFELLER GOVERNOR OIL LINE & FITTINGS 48B A 8 SIL 1435 1  US 91-14-22 PROPFENG STOPPAGE - DIRECT DRIVE PISTON ENGINES 507 REV B  US 93-02-05 FUEL INJECTOR FUEL LINES  US 93-02-05 FUEL INJECTOR FUEL LINES  US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION  US 96-09-10 FISTON PINS  US 96-23-03 HIGH PRESSURE FUEL PUMP 525A  US 98-02-08 CRANKSHAFT INSPECTION  AEID-320-E1B  US 98-02-08 (AEID-320-E SERIES)  AID-320-A SERIES  US 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382  AID-320-A SERIES  US 77-04-05 BENDIX FUEL INJECTORS 429, 430  US 87-10-06R1 PROPFENG STOPPAGE - DIRECT DRIVE PISTON ENGINES 505B  AID-320-A SERIES  US 79-04-05 BENDIX FUEL INJECTORS 433A  US 90-04-06R1 ROCKER ARM ASSEMBLY 477A  US 90-04-06R1 ROCKER ARM ASSEMBLY 477A  US 91-14-22 PROPFENG STOPPAGE - DIRECT DRIVE PISTON ENGINES 501 REV B SENDIX FUEL INJECTORS 433A  US 97-04-05 BENDIX FUEL INJECTORS 433A  US 97-04-05 BENDIX FUEL INJECTORS 433A  US 97-04-05 BENDIX FUEL INJECTORS 429, 430  US 79-04-05 BENDIX FUEL INJECTORS 429, 429, 430  US 79-04-06 PROPFENG STOPPAGE - DIRECT DRIVE PISTON ENGINES 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS 51 REV B SENDIX FUEL INJECTORS	115 00-00-00		
US   77-07-07			
US 77-07-07		( O-320-H SERIES )	
AEIO-320-E SERIES  US 78-23-10  BENDIX FUEL INJECTORS  428, 429, 430  US 79-04-05  BENDIX FUEL INJECTORS  433A  433A  437 4  437 4  437 4  438 4 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8		OIL FILLER EXTENSION - PERFORATED SLEEVE	
US 78-23-10		ENGINE MOUNTING BRACKET ATTACHMENT BOLTS	SI 1380
US   79-04-05		DENOTY FUEL TO DESCRIPTION	
US 87-10-06R1		BENDIX FUEL INJECTORS  BENDIX FUEL INJECTORS	
US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B SB 475 R A US 92-12-05 PISTON PINS 501 REV B 342A US 93-02-05 FUEL INJECTOR FUEL LINES 342A US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 L435 L456 L50 L50 L50 L50 L50 L50 L50 L50 L50 L50		ROCKER ARM ASSEMBLY	
US 92-12-05 PISTON PINS 501 REV B US 93-02-05 FUEL INJECTOR FUEL LINES US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION US 96-09-10 ENGINE OIL PUMP IMPELLERS US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  ALID-320-E1B (AEIO-320-E SERIES) US 98-17-11 CRANKSHAFT INSPECTION  AEIO-320-E2B (AEIO-320-E SERIES) US 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430 US 79-04-05 BENDIX FUEL INJECTORS 433A US 97-16-06R1 ROCKER ARM ASSEMBLY 477A US 90-04-06R1 PROPELLER GOVERNOR OIL LINE & FITTINGS 48 A & SIL 1435 1 US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A US 93-02-05 FUEL INJECTOR FUEL LINE US 93-02-05 PISTON PINS 501 REV B US 93-02-05 PISTON PINS 501 REV B US 96-09-10 ENGINE OIL PUMP IMPELLERS  AIO-320-A2B (AIO-320-A SERIES) US 66-20-04 OIL FILTER ADAPTER GASKET 507		PROPELLER GOVERNOR OIL LINE & FITTINGS PROPERCY STOPPAGE - DIRECT DRIVE RISTON ENGINES	488 A & SIL 1435 1
US 94-06-09  BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION  CSB 641  US 96-09-10  ENGINE OIL PUMP IMPELLERS  4548, 4550, 524, 456  US 96-23-03  US 97-15-11  PISTON PINS  CRANKSHAFT INSPECTION  AEID-320-E1B  US 98-17-11  CRANKSHAFT INSPECTION  AEID-320-E2B  AID-320-E3B  ( AEID-320-E SERIES )  AID-320-A SERIES  US 75-09-15  US 78-23-10  BENDIX FUEL INJECTORS  US 79-04-05  BENDIX FUEL INJECTORS  US 87-10-06R1  US 90-04-06R1  PROPELLER GOVERNOR DIL LINE & FITTINGS  US 90-04-06R1  PROPELLER GOVERNOR DIL LINE & FITTINGS  US 91-14-22  PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES  US 93-02-05  PISTON PINS  US 93-02-06  PUEL INJECTOR FUEL LINES  US 93-02-06  PISTON PINS  SO1 REV B  342A  US 94-06-09  BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION  SO2B 641  CSB 641  SSB 641  4548, 4550, 524, 456  US 97-15-11  PISTON PINS  SO2B  AID-320-ASERIES  US 66-20-04  OIL FILTER ADAPTER GASKET  307	US 92-12-05	PISION PINS	
US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 96-23-03 HIGH PRESSURE FUEL PUMP 5256 US 98-02-08 CRANKSHAFT INSPECTION 505B  AEID-320-E1B (AEID-320-E SERIES) US 98-17-11 CRANKSHAFT INSPECTION  AEID-320-E2B (AEID-320-E SERIES)  AID-320-A SERIES US 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382 US 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430 US 79-04-05 BENDIX FUEL INJECTORS 428, 429, 430 US 87-10-06R1 ROCKER ARM ASSEMBLY 477A US 90-04-06R1 ROCKER ARM ASSEMBLY 477A US 90-04-06R1 PROPPELLER GOVERNOR OIL LINE & FITTINGS 488 A & SIL 1435 1 US 91-14-22 PROPPENS TOPPAGE - DIRECT DRIVE PISTON ENGINES SL 163B, SB 475 R A US 92-12-05 PISTON PINS 501 REV B US 93-02-05 FUEL INJECTOR FUEL LINES US 96-09-10 ENGINE OIL PUMP IMPELLERS US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 OIL FILTER ADAPTER GASKET 307			342A
US 96-23-03	US 96-09-10	ENGINE OIL PUMP IMPELLERS	
US   98-02-08   CRANKSHAFT INSPECTION   505B			525A
AEID-320-E1B US 98-17-11 CRANKSHAFT INSPECTION  AEID-320-E2B (AEID-320-E SERIES )  AID-320-A SERIES US 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382 US 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430 US 79-04-05 BENDIX FUEL INJECTORS 433A US 87-10-06R1 ROCKER ARM ASSEMBLY 477A US 90-04-06R1 PROPELLER GOVERNOR DIL LINE & FITTINGS 488 A & SIL 1435 1 US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES 501 REV B US 93-02-05 FUEL INJECTOR FUEL LINES 501 REV B US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE DIL PUMP IMPELLERS 454B, 455D, 524, 456 US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 DIL FILTER ADAPTER GASKET 307			
US   98-17-11   CRANKSHAFT INSPECTION	AF 10-220-F1B	( ACTO 200 C CENTEC )	
AID-320-A SERIES  US 75-09-15			
AID-320-A SERIES  US 75-09-15	AETO-220-E2B	( AFIO 200 F CEDIEC )	
US 75-09-15	ALIO 320-E2B	( AEIU-320-E SERIES )	
US 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430  US 79-04-05 BENDIX FUEL INJECTORS 433A  US 87-10-06R1 ROCKER ARM ASSEMBLY 477A  US 90-04-06R1 PROPELLER GOVERNOR OIL LINE & FITTINGS 488 A & SIL 1435 1  US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A  US 92-12-05 PISTON PINS 501 REV B  US 93-02-05 FUEL INJECTOR FUEL LINES 342A  US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641  US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456  US 97-15-11 PISTON PINS 527C  US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  US 66-20-04 DIL FILTER ADAPTER GASKET 307		FUEL FLOW DIVIDED COVER CASKET	
US 79-04-05 BENDIX FUEL INJECTORS 433A US 87-10-06R1 ROCKER ARM ASSEMBLY 477A US 90-04-06R1 PROPELLER GOVERNOR OIL LINE & FITTINGS 488 A & SIL 1435 1 US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A US 92-12-05 PISTON PINS 501 REV B US 93-02-05 FUEL INJECTOR FUEL LINES 342A US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 DIL FILTER ADAPTER GASKET 307	US 78-23-10		
US 90-04-06R1 PROPELLER GOVERNOR DIL LINE & FITTINGS 488 A & SIL 1435 1 US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A US 92-12-05 PISTON PINS 501 REV B US 93-02-05 FUEL INJECTOR FUEL LINES 342A US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE DIL PUMP IMPELLERS 454B, 455D, 524, 456 US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 DIL FILTER ADAPTER GASKET 307	US 79-04-05	BENDIX FUEL INJECTORS	433A
US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A US 92-12-05 PISTON PINS 501 REV B US 93-02-05 FUEL INJECTOR FUEL LINES US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 DIL FILTER ADAPTER GASKET 307			
US 93-02-05 FUEL INJECTOR FUEL LINES 342A US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE DIL PUMP IMPELLERS 454B, 455D, 524, 456 US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 DIL FILTER ADAPTER GASKET 307	US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 DIL FILTER ADAPTER GASKET 307			
US 97-15-11 PISTON PINS 527C US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES)  IO-320-B SERIES US 66-20-04 DIL FILTER ADAPTER GASKET 307	US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 98-02-08 CRANKSHAFT INSPECTION 505B  AIO-320-A2B (AIO-320-A SERIES )  IO-320-B SERIES US 66-20-04 OIL FILTER ADAPTER GASKET 307		ENGINE OIL PUMP IMPELLERS	
AIO-320-A2B (AIO-320-A SERIES )  IO-320-B SERIES US 66-20-04			
IO-320-B SERIES US 66-20-04 OIL FILTER ADAPTER GASKET 307			
US 66-20-04 DIL FILTER ADAPTER GASKET 307		NACTOR OFFICE AND ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADDRESS OF THE ADD	
		OIL FILTER ADAPTER GASKET	307
	US 67~22-06	FUEL INJECTORS/DIAPHRAGM ASSEMBLY	305B
US 73-23-01 PISTON PINS 367F US 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C			
US 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382	US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	
US 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430	US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT
SUBJECT

OHIGINE	NUMERO DE CONSIGNE	SUJE I	BULLETIN DE SERVICE DE REF
	COMING		
10-320	D-B SERIES		
(CONTIN	UED / SUITE)		
US	79-04-05	BENDIX FUEL INJECTORS	433A
US	87-10-06R1	ROCKER ARM ASSEMBLY	477A
US	90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US	91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US	92-12-05	PISTON PINS	501 REV B
US	93-02-05	FUEL INJECTOR FUEL LINES	342A
US	93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	
US		AC, LICUMING & RAUAY DIAFIRAGIN FUEL FUNPS	AERO ACCESSORIES 002
	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US	96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US	96-23-03	HIGH PRESSURE FUEL PUMP	525A
US	97-15-11	PISTON PINS	527C
US	98-02-08	CRANKSHAFT INSPECTION	505B
US	98-17-11	CRANKSHAFT INSPECTION	
US	98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
10-320	)-B1A	( IO-320-B SERIES )	
US	64-16-05	AC FUEL PUMP	298
US	65-03-03	CRANKSHAFT FLANGE	300A
	00 00 00	OND THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPER	300A
10-320	-C SERIES		
US	66-20-04	OIL FILTER ADAPTER GASKET	307
US	67-22-06	ELEL TALLECTORS (DIADERASM ACCEMBLY	
		FUEL INJECTORS/DIAPHRAGM ASSEMBLY	305B
US	73-23-01	PISTON PINS	367F
US	75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US	75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US	78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US	79-04-05	BENDIX FUEL INJECTORS	433A
US	87-10-06R1	ROCKER ARM ASSEMBLY	477A
US	90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US	91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	
US	92-12-05	PISTON PINS	SL L163B, SB 475 R A
US			501 REV B
	93-02-05	FUEL INJECTOR FUEL LINES	342A
US	93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
	96-09-10	ENGINE DIL PUMP IMPELLERS	454B, 455D, 524, 456
US	96-23-03	HIGH PRESSURE FUEL PUMP	525A
US	97-15-11	PISTON PINS	527C
US	98-02-08	CRANKSHAFT INSPECTION	505B
US	98-17-11	CRANKSHAFT INSPECTION	3035
	98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
		CHANCY LEAR ROMEC AN ROTARY FOEL POMP	529
10-320	-C1A	( IO-320-C SERIES )	
10-320	-E SERIES		
US	66-20-04	OIL FILTER ADAPTER GASKET	307
US	67-22-06		
US		FUEL INJECTORS/DIAPHRAGM ASSEMBLY	305B
	73-23-01	PISTON PINS	367F
US	75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US	75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US	78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US	79-04-05	BENDIX FUEL INJECTORS	433A
US	87-10-06R1	ROCKER ARM ASSEMBLY	477A
US	90-04-06R1	PROPELLER GOVERNOR DIL LINE & FITTINGS	488 A & SIL 1435 1
US	91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
	92-12-05	PISTON PINS	
US	93-02-05		501 REV B
		FUEL INJECTOR FUEL LINES	342A
US	93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
US	96-09-10	" ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US	96-23-03	HIGH PRESSURE FUEL PUMP	525A
US	97-15-11	PISTON PINS	527C
US	98-02-08	CRANKSHAFT INSPECTION	505B
US	98-17-11	CRANKSHAFT INSPECTION	3330
US	98-18-12		529
			323
10-320		( IO-320-E SERIES )	
10-320	••••••••••••••	( IO-320-E SERIES )	
10~320	-E2A	( IO-320-E SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
AVCO LY	COMING		
10-320		( IO-320-E SERIES )	
10-320	)-E3D	( IO-320-E SERIES )	· ····································
L10-32	O SERIES		
US	75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	391B 3950
US	87-10-06R1	MOCKEY AVIA ASSEMBLY	477A
US	96-09-10 96-23-03	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US	97-15-11	HIGH PRESSURE FUEL PUMP PISTON PINS	525A
US	98-02-08	CRANKSHAFT INSPECTION	527C
US	98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	505B 529
LI0-32	O-B1A	( LIO-320 SERIES )	
0-340-	A SERIES		
	59-10-07	CYLINDER BAFFLE CLAMPS	254A
US	64-16-05	AC FUEL PUMP	298
US US	66-20-04 87-10-06R1	OIL FILTER ADAPTER GASKET	307
US	90-04-06R1	ROCKER ARM ASSEMBLY	477A
US	91-14-22	PROPELLER GOVERNOR DIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	488 A & SIL 1435 1
US	92-12-05	FISION FINS	501 REV B
US US	94-06-09 96-09-10	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL PUMP IMPELLERS	CSB 641
0-340-	A 1 A	( O-340-A SERIES )	454B, 455D, 524, 456
		( o o to A delited )	
	A SERIES	0/// 71/252 21/27/27	
US	59-10-07 64-16-05	CYLINDER BAFFLE CLAMPS  AC FUEL PUMP	254A
	66-20-04	OIL FILTER ADAPTER GASKET	298 307
US	73-23-01	PISTON PINS	367F
	75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	
	87-10-06R1	ROCKER ARM ASSEMBLY	477A
	90-04-06R1 91-14-22	PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	488 A & SIL 1435 1
US	92-12-05	PISTON PINS	SL L163B, SB 475 R A   501 REV B
	93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
	95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
	96-09-10 97-15-11	ENGINE OIL PUMP IMPELLERS PISTON PINS	454B, 455D, 524, 456
	98-17-11	CRANKSHAFT INSPECTION	527C
D-360-	A 1 A	( O-360-A SERIES )	
	98-02-08	CRANKSHAFT INSPECTION	505B
D-360-A	110	( D-360-A SERIES )	
	98-02-08	CRANKSHAFT INSPECTION	505B
D-360-#	<b>\1F</b> 98-02-08	( O-360-A SERIES ) CRANKSHAFT INSPECTION	505B
			3030
	\1F6	( D-360-A SERIES )	
US	98-02-08	CRANKSHAFT INSPECTION	505B
O-360-A	1F6D	( D-360-A SERIES )	
	98-02-08	CRANKSHAFT INSPECTION	505B
0-360-A	11G6	( D-360-A SERIES )	
		CRANKSHAFT INSPECTION	505B
D-360-A	1G6D	( D-360-A SERIES )	
	79-15-02	CARBURETOR - ECONOMIZER PLUG	434
	98-02-08	CRANKSHAFT INSPECTION	505B
0-360-A	146	( O-360-A SERIES )	
	98-02-08	CRANKSHAFT INSPECTION	505B
D-360-4	1P	( O-360-A SERIES )	
	98-02-08	CRANKSHAFT INSPECTION	505B

MAKE / CONSTRUCTEUR MODEL / MODELE	(SERIES / SERIE)	
ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
AVCO LYCOMING		
<b>D-360-A2A</b> US 98-02-08	( D-360-A SERIES ) CRANKSHAFT INSPECTION	505B
<b>D-360-A2D</b> US 98-02-08	( D-360-A SERIES ) CRANKSHAFT INSPECTION	505B
<b>0-360-A2E</b> US 98-02-08	( O-360-A SERIES ) CRANKSHAFT INSPECTION	505B
<b>0-360-A2F</b> US 98-02-08	( D-360-A SERIES ) CRANKSHAFT INSPECTION	505B
<b>0-360-A2G</b> US 98-02-08	( D-360-A SERIES ) CRANKSHAFT INSPECTION	505B
<b>D-360-A3A</b> , US 98-02-08	( D-360-A SERIES ) CRANKSHAFT INSPECTION	505B
<b>0-360-A3A(C)</b> US 98-02-08	( D-360-A SERIES ) CRANKSHAFT INSPECTION	505B
O-360-A4A	( O-360-A SERIES )	
0-360-A4G	( D-36C-A SERIES )	
0-360-A4J	( O-360-A SERIES )	
D-360-A4K	( O-360-A SERIES )	
D-360-A4M	( O-360-A SERIES )	
<b>0-360-A4N</b> US 98-02-08	( O-360-A SERIES ) CRANKSHAFT INSPECTION	505B
<b>0-360-B SERIES</b> US 59-10-07	CYLINDER BAFFLE CLAMPS	0544
US 64-16-05	AC FUEL PUMP	254A 298
US 66-20-04 US 73-23-01	OIL FILTER ADAPTER GASKET PISTON PINS	307 367F
US 75-08-09 US 87-10-06R1	OIL PUMP DRIVE SHAFT/IMPELLER ROCKER ARM ASSEMBLY	381B, 385C
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	477A 488 A & SIL 1435 1
US 91-14-22 US 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	501 REV B AERO ACCESSORIES 002
US 94-06-09 US 95-07-01	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
US 95-07-01 US 96-09-10	CONNECTING ROD BOLTS ENGINE OIL PUMP IMPELLERS	SUPERIOR AIR #95-002 454B, 455D, 524, 456
US 97-15-11	PISTON PINS	527C
US 98-02-08 US 98-17-11	CRANKSHAFT INSPECTION CRANKSHAFT INSPECTION	505B
O-360-B1A	( O-360-B SERIES )	
<b>D-360-C SERIES</b> US 59-10-07	CVI INDED PAFFIE CLAMPS	0544
US 59-10-07 US 64-16-05	AC FUEL PUMP	254A 298
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 73-23-01 US 75-08-09	PISTON PINS OIL PUMP DRIVE SHAFT/IMPELLER	367F 381B, 385C
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 90-04-06R1 US 91-14-22	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 91-14-22 US 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A 501 REV B
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09 US 95-07-01	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CONNECTING ROD BOLTS	CSB 641 SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 97-15-11 US 98-02-08	PISTON PINS CRANKSHAFT INSPECTION	527C
US 98-17-11	CRANKSHAFT INSPECTION	505B
D-360-C1A	( D-360-C SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

		BOLLETIN DE SERVICE DE REF.
AVCO LYCOMING D-360-C1E	( D-360-C SERIES )	
D-360-C1F	( O-360-C SERIES )	
0-360-C1G	( D-360-C SERIES )	
D-360-C2A	( D-360-C SERIES )	
0-360-C2D	( D-360-C SERIES )	
0-360-C2E	( O-360-C SERIES )	· ······
D-360-C2F	( 0-360-C SERIES )	
D-360-C4P	( O-360-C SERIES )	
O-360-E SERIES		
US 59-10-07	CVI INDER PAEELE CLAMPS	
US 64-16-05	CYLINDER BAFFLE CLAMPS  AC FUEL PUMP	254A
US 66-20-04	OIL FILTER ADAPTER GASKET	298 307
US 73-23-01	PISTON PINS	367F
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 80-04-03R2	EXHAUST VALVE SPRING SEATS/HYDRAULIC LIFTERS	435
US 80-14-07	EXHAUST VALVE SPRING SEATS	447
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 90-04-06R1	PROPELLER GOVERNOR DIL LINE & FITTINGS	488 A & SIL 1435 1
US 92-12-05	PISTON PINS	501 REV B
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09 US 97-15-11	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 97-15-11 US 98-02-08	PISTON PINS	527C
US 98-17-11	CRANKSHAFT INSPECTION CRANKSHAFT INSPECTION	505B
D-360-E1A6D	( 0 200 F CERTEC )	
US 79-10-03R2	( O-360-E SERIES )  ENGINE MOUNTING BRACKET ATTACHMENT BOLTS	CT 4000
05 75 TO 05R2	ENGINE MOUNTING BRACKET ATTACHMENT BULTS	SI 1380
0-360-F SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A
US 64-16-05	AC FUEL PUMP	298
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 73-23-01	PISTON PINS	367F
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 91-14-22 US 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 93-11-11	PISTON PINS AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	501 REV B
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	AERO ACCESSORIES 002
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 97-15-11	PISTON PINS	527C
US 98-02-08	CRANKSHAFT INSPECTION	505B
US 98-17-11	CRANKSHAFT INSPECTION	
D-360-F1A6	( D-360-F SERIES )	
O-360-J SERIES	DACTON DANG	5070
US 97-15-11 US 98-17-11	PISTON PINS CRANKSHAFT INSPECTION	527C
0-360-J2A	( O-360-J SERIES )	
		454B 455D 534 456
US 96-09-10	ENGINE OIL PUMP IMPELLERS	4340, 4330, 324,436
AEIO-360-A SERIES		
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 78-23-10	BENDIX FUEL INJECTORS	
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
SHORE HOMENO DE CONSTONE		SELECTION OF SELECTION OF RELEASE
AVCO LYCOMING		
AEIO-360-A SERIES (CONTINUED / SUITE)		
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
US 98-02-08	CRANKSHAFT INSPECTION	505B
AEI0-360-A1A	( AEIO-360-A SERIES )	
US 84-13-05	CRANKSHAFT FLANGE	465A
AEI0-360-A1B6	( AEIO-360-A SERIES )	
AEI0-360-A1E	( AEIO-360-A SERIES )	
US 84-13-05	CRANKSHAFT FLANGE	465A
AEID-360-B SERIES		
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 78-23-10 US 79-04-05	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05 US 84-13-05	BENDIX FUEL INJECTORS CRANKSHAFT FLANGE	433A 465A
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05 US 94-06-09	FUEL INJECTOR FUEL LINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	342A
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
AEI0-360-B2F	( AEIO-360-B SERIES )	
US 98-02-08	CRANKSHAFT INSPECTION	505B
AEI0-360-B4A	( AEIO-360-B SERIES )	
AEIO-360-H SERIES		
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 90-04-06R1 US 91-14-22	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A 501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 96-23-03 US 97-15-11	HIGH PRESSURE FUEL PUMP PISTON PINS	525A 527C
US 98-02-08	CRANKSHAFT INSPECTION	505B
AEIO-360-H1A	( AEIO-360-H SERIES )	
US 84-13-05	CRANKSHAFT FLANGE	465A
HIO-360 SERIES		
US 73-23-01	PISTON PINS	367F
US 75-08-09	OIL PUMP DRIVE SHAFT / IMPELLER	381B, 385C
US 78-23-10 US 79-04-05	BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS	428, 429, 430 433A
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	3424
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
US 95-07-01 US 96-09-10	CONNECTING ROD BOLTS ENGINE OIL PUMP IMPELLERS	SUPERIOR AIR #95-002 454B, 455D, 524, 456
US 96-23-03	HIGH PRESSURE FUEL PUMP	FAFI
US 97-15-11	PISTON PINS	527C
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
HIO-360-A1A US 67-22-06	( HIO-360 SERIES ) FUEL INJECTORS/DIAPHRAGM ASSEMBLY	305B
		3036
HIO-360-B1A US 64-16-05	( HIO-360 SERIES )  AC FUEL PUMP	298
		200

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT

ORIGINE NOMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
AVCO LYCOMING HID-360-B1A (CONTINUED / SUITE)	( HIO-360 SERIES )	
US 67-22-06 US 87-10-06R1	FUEL INJECTORS/DIAPHRAGM ASSEMBLY ROCKER ARM ASSEMBLY	305B 477A
HIO-360-B1B	( HIO-360 SERIES )	
US 64-16-05	AC FUEL PUMP	298
US 67-22-06 US 87-10-06R1	FUEL INJECTORS/DIAPHRAGM ASSEMBLY	305B
03 87 10 OBK1	ROCKER ARM ASSEMBLY	477A
HIO-360-C1A	( HIO-360 SERIES )	
US 67-22-06	FUEL INJECTORS/DIAPHRAGM ASSEMBLY	305B
US 75-09-15 US 98-17-11	FUEL FLOW DIVIDER COVER GASKET	382
9	CRANKSHAFT INSPECTION	
HIO-360-D1A	( HID-360 SERIES )	
US 72-21-04	MAGNETO DISTRIBUTER BUSHING	336B
US 73-15-04 US 89-13-02	MAGNETO - RUBBER DRIVE PLATE GROMMET	
03 03 13 02	BENDIX - SERVO FUEL INJECTORS	485
HIO-360-E1A	( HID-360 SERIES )	
HIO-360-E1AD	( HIO-360 SERIES )	
HIO-360-E1BD	( HIO-360 SERIES )	
HIO-360-F1AD	( HIO-360 SERIES )	
HO-360 SERIES	DICTON DINC	
US 97-15-11	PISTON PINS	527C
HO-360-C1A	( HO-360 SERIES )	
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524,456
IO-360-A SERIES		
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 71-05-02	CRANKCASE MAIN BEARINGS	326
US 71-11-02	INTAKE & EXHAUST HYDRAULIC TAPPET PLUNGER ASSY	328
US 73-23-01 US 75-08-09	PISTON PINS OIL PUMP DRIVE SHAFT/IMPELLER	367F
US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	381B, 385C 382
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 90-04-06R1 US 91-14-22	PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	488 A & SIL 1435 1 SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09 US 95-07-01	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CONNECTING ROD BOLTS	CSB 641 SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
US 98-02-08 US 98-17-11	CRANKSHAFT INSPECTION  CRANKSHAFT INSPECTION	505B
US 98-18-12	CRANKSHAFT INSPECTION  CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
TO 000 111	(	
IO-360-A1A US 64-16-05	( IO-360-A SERIES )  AC FUEL PUMP	298
US 66-06-03	CONNECTING ROD ASSEMBLY	302A
US 67-22-06	FUEL INJECTORS/DIAPHRAGM ASSEMBLY	305B
IO-360-A1B	( IO-360-A SERIES )	
IO-360-A1B6	( IO-360-A SERIES )	
IO-360-A1B6D	( IO-360-A SERIES )	
US 93-14-15	MAXIMUM MANIFOLD AIR PRESSURE - RE STC SE4757NM	
	( IO-360-A SERIES )	
IO-360-A2	( IO-360-A SERIES )	

MAKE / CONSTRUCTEUR (SERIES / SERIE) REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. SUBJECT ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE AVCO LYCOMING ( IO-360-A SERIES ) IO-360-A2A US 67-22-06 FUEL INJECTORS/DIAPHRAGM ASSEMBLY 305B IO-360-A2B ( IO-360-A SERIES ) IO-360-A3B6 ( IO-360-A SERIES ) ( IO-360-A SERIES ) IO-360-A3B6D MAXIMUM MANIFOLD AIR PRESSURE - RE STC SE4757NM 115 93-14-15 IO-360-B SERIES OTI FILTER ADAPTER GASKET 307 115 66-20-04 367F 73-23-01 PISTON PINS OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C 75-08-09 FUEL FLOW DIVIDER COVER GASKET 382 75-09-15 428, 429, 430 78-23-10 BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS 433A 79-04-05 477A ROCKER ARM ASSEMBLY
PROPELLER GOVERNOR OIL LINE & FITTINGS 87-10-06R1 488 A & SIL 1435 1 90-04-06R1 SL L163B, SB 475 R A PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES 91-14-22 PISTON PINS 501 REV B 92-12-05 FUEL INJECTOR FUEL LINES 3424 93-02-05 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002 93-11-11 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 94-06-09 SUPERIOR AIR #95-002 95-07-01 CONNECTING ROD BOLTS ENGINE DIL PUMP IMPELLERS 454B, 455D, 524, 456 96-09-10 HIGH PRESSURE FUEL PUMP 525A 96-23-03 527C 97-15-11 PISTON PINS CRANKSHAFT INSPECTION 505B 98-02-08 CRANKSHAFT INSPECTION
CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 98-17-11 98-18-12 ( IO-360-B SERIES ) TO-360-R1R AC FUEL PUMP US 64-16-05 298 67-22-06 FUEL INJECTORS/DIAPHRAGM ASSEMBLY 305B US IO-360-B1D ( ID-360-B SERIES ) FUEL INJECTORS/DIAPHRAGM ASSEMBLY US 67-22-06 305B IO-360-B1E ( IO-360-B SERIES ) IO-360-B1F ( IO-360-B SERIES ) IO-360-B4A ( IO-360-B SERIES ) IO-360-C SERIES OIL FILTER ADAPTER GASKET 307 66-20-04 US CRANKCASE MAIN BEARINGS 326 71-05-02 71-11-02 INTAKE & EXHAUST HYDRAULIC TAPPET PLUNGER ASSY 328 73-23-01 PISTON PINS 367F OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C 75-08-09 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382 BENDIX FUEL INJECTORS 428, 429, 430 78-23-10 433A 79-04-05 BENDIX FUEL INJECTORS 488 A & SIL 1435 1 PROPELLER GOVERNOR OIL LINE & FITTINGS 90-04-06R1 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A 91-14-22 501 REV B PISTON PINS US 92-12-05 FUEL INJECTOR FUEL LINES 342A 93-02-05 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002 93-11-11 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 94-06-09 SUPERIOR AIR #95-002 CONNECTING ROD BOLTS US 95-07-01 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 96-09-10 HIGH PRESSURE FUEL PUMP 525A US 96-23-03 PISTON PINS 527C US 97-15-11 CRANKSHAFT INSPECTION 505B 98-02-08 CRANKSHAFT INSPECTION US 98-17-11 98-18-12 CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 529 ID-360-C1A6D ( IO-360-C SERIES )

IO-360-C1C

IO-360-C1C6

( IO-360-C SERIES )

( ID-360-C SERIES )

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SÉRVICE DE REF.
AVCO LYCOMING ID-360-C1D6	( IO-360-C SERIES )	
IO-360-C1E6	( 10-360-C SERIES )	
IO-360-C1F	( ID-360-C SERIES )	
ID-360-D SERIES US 96-09-10 US 96-23-03 US 97-15-11 US 98-02-08 US 98-17-11 US 98-18-12	ENGINE OIL PUMP IMPELLERS HIGH PRESSURE FUEL PUMP PISTON PINS CRÄNKSHÄFT INSPECTION CRANKSHAFT INSPECTION CRANKJERT INSPECTION CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	454B, 455D, 524, 456 525A 527C 505B 529
IO-360-D1A	( IO-360-D SERIES )	
ID-360-L SERIES US 98-02-08 US 98-17-11 US 98-18-12	CRANKSHAFT INSPECTION CRANKSHAFT INSPECTION CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	505B 529
IO-360-L2A US 96-23-03 US 97-15-11	( IO-360-L SERIES ) HIGH PRESSURE FUEL PUMP PISTON PINS	525A 527C
LID-360-C1E6  US 73-23-01  US 75-08-09  US 75-09-15  US 79-04-05  US 90-04-06R1  US 91-14-22  US 92-12-05  US 93-11-11  US 94-06-09  US 95-07-01  US 96-23-03  US 97-15-11  US 98-02-08  US 98-17-11  LD-360 SERIES  US 59-10-07  US 64-16-05  US 66-20-04  US 73-23-01  US 75-08-09  US 79-10-03R2	BENDIX FUEL INJECTORS PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CONNECTING ROD BOLTS ENGINE OIL PUMP IMPELLERS HIGH PRESSURE FUEL PUMP PISTON PINS CRANKSHAFT INSPECTION CRANKSHAFT INSPECTION CYLINDER BAFFLE CLAMPS AC FUEL PUMP OIL FILTER ADAPTER GASKET PISTON PINS OIL PUMP DRIVE SHAFT/IMPELLER ENGINE MOUNTING BRACKET ATTACHMENT BOLTS	SUPERIOR AIR #95-002 454B, 455D, 524, 456 525A 527C 505B 254A 298 307 367F 381B, 385C SI 1380
US 90-04-06R1 US 91-14-22 US 92-12-05 US 93-11-11 US 94-06-09 US 96-09-10 US 97-15-11 US 98-02-08	PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE / DIRECT DRIVE PISTON ENGINES PISTON PINS AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION OIL PUMP IMPELLERS PISTON PINS CRANKSHAFT INSPECTION	488A & SIL 1435 1 SL L163B, SB 475 R A 501 REV B AERO ACCESSORIES 002 CSB 641 454B, 455D, 524, 456 527C 505B
LD-360-A1G6D US 79-15-02 US 90-04-06R1 US 91-14-22 US 95-07-01 US 96-09-10	( LO-360 SERIES )  CARBURETOR - ECONOMIZER PLUG PROPELLER GOVERNOR OIL LINE & FITTINGS PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES CONNECTING ROD BOLTS ENGINE OIL PUMP IMPELLERS	434 488 A & SIL 1435 1 SL L163B, SB 475 R A SUPERIOR AIR #95-002 454B, 455D, 524, 456
LO-360-A1H6	( LD-360 SERIES )	
US 79-10-03R2 US 80-04-03R2 US 80-14-07 US 90-04-06R1	( LO-360 SERIES ) ENGINE MOUNTING BRACKET ATTACHMENT BOLTS EXHAUST VALVE SPRING SEATS/HYDRAULIC LIFTERS EXHAUST VALVE SPRING SEATS PROPELLER GOVERNOR OIL LINE & FITTINGS	SI 1380 435 447 488 A & SIL 1435 1

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
AVCO LYCOMING		
LTD-360-E1A6D		
US 80-04-03R2	EXHAUST VALVE SPRING SEATS/HYDRAULIC LIFTERS	435 488 A & SIL 1435 1
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	501 REV B
US 92-12-05	PISTON PINS AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 93-11-11 US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 94-06-09 US 97-15-11	PISTON PINS	527C
US 98-02-08	CRANKSHAFT INSPECTION	505B
TO-360-C1A6		
US 90-04-06R1	PROPELLER GOVERNOR DIL LINE & FITTINGS	488 A & SIL 1435 1 SL L163B, SB 475 R A
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	501 REV B
US 92-12-05	PISTON PINS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 94-06-09 US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
us 98-02-08	CRANKSHAFT INSPECTION	505B
TD-360-C1A6D		
US 80-02-13	TURBOCHARGER OIL DRAIN FLANGE	426
US 90-04-06R1	PROPELLER GOVERNOR OIL LINE & FITTINGS	488 A & SIL 1435 1
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS CRANKSHAFT INSPECTION	527C 505B
US 98-02-08	CRAINCSTIAFT INSELCTION	
TD-360-E1A6D	THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE P	405
US 80-04-03R2	EXHAUST VALVE SPRING SEATS/HYDRAULIC LIFTERS	435 488 A & SIL 1435 1
US 90-04-06R1	PROPELLER GOVERNOR DIL LINE & FITTINGS PISTON PINS	501 REV B
US 92-12-05	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 94-06-09 US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
US 98-02-08	CRANKSHAFT INSPECTION	505B
0-435		
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
0-435-A		
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
0-435-C		
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
D-435-C1		
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
0-435-1		0
US 91-14-22	PROP/ENG STOPPAGE ~ DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
GO-435-C2 SERIES		
US 51-24-01	EXHAUST VALVE SEATS	145
US 62-23-05	PROPELLER SHAFT OIL SEAL RING	290
US 94-06-09 US 98-18-12	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
GO-435-C2 US 69-25-08	( GO-435-C2 SERIES ) REDUCTION GEAR PINION CAGE ATTACHMENT NUT	319A
GD-435-C2B	( GO-435-C2 SERIES )	
	,	
GO-435-C2B1	( GO-435-C2 SERIES )	
GO-435-C2B2	( GO-435-C2 SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER	(SERIES / SERIE) SUBJECT	
ORIGINE NUMERO DE CONSIGNE	· SONTEL	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
AVCO LYCOMING GD-435-C2B26	( GO-435-C2 SERIES )	
TVO-435 SERIES US 68-08-08 US 80-04-04R1 US 94-06-09	HYDRAULIC VALVE LIFTER CRANKSHAFT FLANGE BOLTS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	314A SI 1209B CSB 641
TVO-435-B1A	( TVO-435 SERIES )	
TVO-435-D1A	( TVO-435 SERIES )	
TVO-435-D1B	( TVO-435 SERIES )	
TVO-435-F1A	( TVO-435 SERIES )	
TVO-435-G1A	( TVO-435 SERIES )	
VO-435-A SERIES US 68-08-08 US 80-04-04R1 US 94-06-09	HYDRAULIC VALVE LIFTER CRANKSHAFT FLANGE BOLTS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	314A SI 1209B CSB 641
VO-435~A1B	( VD-435-A SERIES )	
VO-435-A1D	( VO-435-A SERIES )	
VO-435-A1E	( VO-435-A SERIES )	
VO-435-A1F	( VO-435-A SERIES )	
GO-480-B SERIES US 59-10-07 US 62-23-05 US 69-25-08 US 92-12-05 US 94-06-09 US 97-15-11 US 98-18-12	CYLINDER BAFFLE CLAMPS PROPELLER SHAFT OIL SEAL RING REDUCTION GEAR PINION CAGE ATTTACHMENT NUT PISTON PINS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PISTON PINS CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	254A 290 319A 501 REV B CSB 641 527C 529
GO-480-B	( GO-480-B SERIES )	
GO-480-B1A6	( GO-480-B SERIES )	
GO-480-B1B	( GO-480-B SERIES )	
GO-480-B1C	( GO-480-B SERIES )	
GO-480-B1D	( GO-480-B SERIES )	
GD-480-F SERIES US 59-10-07 US 62-23-05 US 69-25-08 US 92-12-05	CYLINDER BAFFLE CLAMPS PROPELLER SHAFT OIL SEAL RING REDUCTION GEAR PINION CAGE ATTTACHMENT NUT PISTON PINS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	254A 290 319A 501 REV B
US 94-06-09 US 97-15-11 US 98-18-12	PISTON PINS CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	527C 529
GD-480-F1A6	( GO-480-F SERIES )	
G0-480-F6	( GO-480-F SERIES )	
GD-480-G SERIES US 59-10-07 US 60-11-06 US 62-23-05 US 69-25-08 US 92-12-05 US 94-06-09 US 97-15-11 US 98-18-12	CYLINDER BAFFLE CLAMPS CRANKSHAFT COUNTERWEIGHT PROPELLER SHAFT OIL SEAL RING REDUCTION GEAR PINION CAGE ATTTACHMENT NUT PISTON PINS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PISTON PINS CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	254A 249A 290 319A 501 REV B CSB 641 527C 529
GO-480-G1A6	( GO-480-G SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER	(SERIES / SERIE) SUBJECT	REFERENCE SERVICE BULLETIN
ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
AVCO LYCOMING		
GD-480-G1D6	( GD-480-G SERIES ) PISTON PINS	367F
US 73-23-01	F 1310N 1 1N3	
GO-480-G2D6	( GO-480-G SERIES )	
GSO-480-B SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A 249A
US 60-11-06 US 62-23-05	CRANKSHAFT CDUNTERWEIGHT PROPELLER SHAFT DIL SEAL RING	290
US 69-25-08	REDUCTION GEAR PINION CAGE ATTTACHMENT NUT	319A
US 92-12-05	PISTON PINS	501 REV B
US 94-06-09 US 97-15-11	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PISTON PINS	527C
03 97 13 11		
GSO-480-B1A6	( GSO-480-B SERIES )	
GSO-480-B1B6	( GSO-480-B SERIES )	
GSD-480-B1J6	( GSO-480-B SERIES )	
IGSO-480-A SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A
US 62-23-05	PROPELLER SHAFT OIL SEAL RING	290 319A
US 69-25-08 US 78-23-10	REDUCTION GEAR PINION CAGE ATTTACHMENT NUT BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 92~12-05	PISTON PINS	501 REV B
US 93-02-05 US 94-06-09	FUEL INJECTOR FUEL LINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	342A CSB 641
US 97-15-11	PISTON PINS	527C
IGSO-480-A1A6 US 68-08-08	( IGSO-480-A SERIES ) HYDRAULIC VALVE LIFTER	314A
IGSO-480-A1E	( IGSO-480-A SERIES )	
US 73-23-01	PISTON PINS	367F
US 81-03-05	MIXTURE CONTROL SHAFT ASSEMBLY	444
O-540-A SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A
US 63-14-03 US 64-16-05	OIL PUMP DRIVE SHAFT AC FUEL PUMP	295 298
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 91-14-22 US 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A 501 REV B
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01 US 96-09-10	CONNECTING ROD BOLTS  ENGINE OIL PUMP IMPELLERS	SUPERIOR AIR #95-002 454B, 455D, 524, 456
US 96-09-10 US 97-15-11	PISTON PINS	527C
US 98-17-11	CRANKSHAFT INSPECTION	
D-540-A1A	( D-540-A SERIES )	
0-540-A1A5	( D-540-A SERIES )	
O-540-A1B5	( O-540-A SERIES )	
0-540-A1C5	( D-540-A SERIES )	
US 73-23-01	PISTON PINS	367F
O-540-A1D5 US 73-23-01	( O-540-A SERIES ) PISTON PINS	367F
0-540-A2B	( O-540-A SERIES )	
O-540-A4B5	( O-540-A SERIES )	
O-540-B SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A
US 63-14-03 US 64-16-05	OIL PUMP DRIVE SHAFT AC FUEL PUMP	295 298

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJET
SUJET

ORIGINE NUMERO DE CONSIGNE	SUJET .	BULLETIN DE SERVICE DE REF
AVOG LVCGMING		
AVCO LYCOMING 0-540-B SERIES		
(CONTINUED / SUITE)		
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 87-10-06R1	ROCKER ARM ASSEMBLY	4771
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISION PINS	501 REV B
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09 US 95-07-01	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 96-09-10	CONNECTING ROD BOLTS  ENGINE OIL PUMP IMPELLERS	SUPERIOR AIR #95-002
US 97-15-11	PISTON PINS	454B, 455D, 524, 456 527C
	131014 1 1113	5270
0-540-B1A5	( O-540-B SERIES )	
US 73-23-01	PISTON PINS	367F
0.540.0005	/	
0-540-B2B5	( O-540-B SERIES )	
US 66-14-03 US 73-23-01	CRANKSHAFT IDLER SHAFT	308
US 99-04-04	PISTON PINS SLICK - MAGNETO IMPULSE COUPLING	367F
03 33 04 04	SEICK MAGNETO IMPOESE COOPLING	SB1~98
0-540-B2C5	( O-540-B SERIES )	
US 73-23-01	PISTON PINS	367F
US 99-04-04	SLICK - MAGNETO IMPULSE COUPLING	SB1-98
0-540-B4B5	( 0-540-B SERIES )	
US 73-23-01	PISTON PINS	367F
O-540-E SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A
US 63-14-03	OIL PUMP DRIVE SHAFT	295
US 64-16-05	AC FUEL PUMP	298
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-11-11 US 94-06-09	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	AERO ACCESSORIES 002
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 97-15-11	PISTON PINS	527C
0-540-E4B5	( O-540-E SERIES )	0075
US 73-23-01	PISTON PINS	367F
US 99-04-04	SLICK - MAGNETO IMPULSE COUPLING	SB1-98
0-540-E4C5	( O-540-E SERIES )	
US 73-23-01	PISTON PINS	367F
US 99-04-04	SLICK - MAGNETO IMPULSE COUPLING	SB1-98
O-54O-F SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A
US 63-14-03	OIL PUMP DRIVE SHAFT	295
US 64-16-05	AC FUEL PUMP OIL FILTER ADAPTER GASKET	298 307
US 66-20-04 US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 75-08-09 US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 97-15-11	PISTON PINS	527C
0-540~F1B5	( O-540-F SERIES )	
US 99-03-05	CRANKSHAFT GEAR RETAINING BOLTS PN STD-2209	
55 55 55		
0-540-G SERIES		
US 59-10-07	CYLINDER BAFFLE CLAMPS	254A
US 63-14-03	OIL PUMP DRIVE SHAFT	295 298
US 64-16-05	AC FUEL PUMP OIL FILTER ADAPTER GASKET	307
US 66-20-04	OIL LILLEN ADAPTER GASKET	
		ENGINES (MOTELIES

### INDEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN CANADA

INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA MAKE / CONSTRUCTEUR (SERIES / SERIE) MODEL / MODELE ORIGIN AD NUMBER
ORIGINE NUMBER CONSIGNE SUBJECT REFERENCE SERVICE BUILLETIN SILIF AVCO LYCOMING 0-540-G SERIES (CONTINUED / SUITE) 381B, 385C 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER US ROCKER ARM ASSEMBLY 477A 87-10-06R1 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A 91-14-22 92-12-05 PISTON PINS 501 REV B AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002 93-11-11 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 94-06-09 95-07-01 CONNECTING ROD BOLTS SUPERIOR AIR #95-002 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 96-09-10 PISTON PINS 97-15-11 ( D-540-G SERIES ) 0-540-G1A5 PISTON PINS 367F US 73-23-01 ( 0-540-G SERIES ) 0-540-G185 O-540-J SERIES CYLINDER BAFFLE CLAMPS 2544 59-10-07 US 295 63-14-03 OIL PUMP DRIVE SHAFT 64-16-05 AC FUEL PUMP 298 OIL FILTER ADAPTER GASKET 307 66-20-04 OIL PUMP DRIVE SHAFT/IMPELLER 75-08-09 381B, 385C 87-10-06R1 ROCKER ARM ASSEMBLY 477A US PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002
BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 91-14-22 US 93-11-11 CONNECTING ROD BOLTS US 95-07-01 SUPERIOR AIR #95-002 0-540-J1A5D ( 0-540-J SERIES ) ( 0-540-J SERIES ) D-540-J3A5D 0-540-J3C5D ( O-540-J SERIES ) D-540-L SERIES 59-10-07 2544 US CYLINDER BAFFLE CLAMPS OIL PUMP DRIVE SHAFT 295 63-14-03 64-16-05 AC FUEL PUMP 298 66-20-04 OIL FILTER ADAPTER GASKET 307 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C 75-08-09 ROCKER ARM ASSEMBLY

PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES

AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS

AERO ACCESSORIES 002 87-10-06R1 US 91-14-22 93-11-11 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 SUPERIOR AIR #95-002 US 95-07-01 CONNECTING ROD BOLTS HIGH PRESSURE FUEL PUMP 525A 96-23-03 ( 0-540-L SERIES ) 0-540-L3C5D AEIO-540-D SERIES 78-23-10 BENDIX FUEL INJECTORS
BENDIX FUEL INJECTORS 428, 429, 430 US 433A 79-04-05 87-10-06R1 ROCKER ARM ASSEMBLY 477A PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A 91-14-22 501 REV B US 92-12-05 PISTON PINS 93-02-05 FUEL INJECTOR FUEL LINES 342A 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 525A US 96-23-03 HIGH PRESSURE FUEL PUMP PISTON PINS 527C 97-15-11 98-18-12 CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 529 AE IO-540-D4A ( AEIO-540-D SERIES ) US 95-07-01 CONNECTING ROD BOLTS SUPERIOR AIR #95-002 AEIO-540-L SERIES

CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP ( AEIO-540-L SERIES ) AFT0-540-L1B5

92-12-05

93-02-05

94-06-09

US 91-14-22

US

US

501 REV B

342A

PISTON PINS

FUEL INJECTOR FUEL LINES

HIGH PRESSURE FUEL PUMP

PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A

BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641

	MAKE / CONSTRUCTEUR MODEL / MODELE (SERIES / SERIE)		
ORIGIN ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN
			BULLETIN DE SERVICE DE REF.
	YCOMING 540-L1B5	( AEIO-540-L SERIES )	
	NUED / SUITE)	( ALIO-540-L SERIES )	
US	97-15-11	PISTON PINS	527C
IGO-5	40-A SERIES		
US	62-23-05	PROPELLER SHAFT OIL SEAL RING	290
US	69-25-08	REDUCTION GEAR PINION CAGE ATTTACHMENT NUT	319A
US	73-23-01 74-13-05	PISTON PINS CONNECTING ROD ASSEMBLIES	367F
US	78-23-10	BENDIX FUEL INJECTORS	351A 428, 429, 430
US	79-04-05	BENDIX FUEL INJECTORS	433A
US	92-12-05 93-02-05	PISTON PINS FUEL INJECTOR FUEL LINES	501 REV B
US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	342A CSB 641
US	97-15-11	PISTON PINS	527C
US	98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
	40-A1A	( IGO-540-A SERIES )	
US	75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US	81-03-05	MIXTURE CONTROL SHAFT ASSEMBLY	444
	540-B SERIES		
US	62-23-05 69-25-08	PROPELLER SHAFT OIL SEAL RING	290
US	72-21-06	REDUCTION GEAR PINION CAGE ATTTACHMENT NUT CRANKCASE BEARINGS	319A 326, 327B
US	73-23-01	PISTON PINS	367F
US	74-13-05	CONNECTING ROD ASSEMBLIES	351A
US	78-23-10 79-04-05	BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS	428, 429, 430 433A
US	92-12-05	PISTON PINS	501 REV B
US	93-02-05	FUEL INJECTOR FUEL LINES	342A
US	94-06-09 97-15-11	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PISTON PINS	CSB 641 527C
IGSO-	540-B1A	( IGSO-540-B SERIES )	
IGSO-	540-B1C	( IGSO-540-B SERIES )	
10-540	D-A SERIES		
US	63-14-03	OIL PUMP DRIVE SHAFT	295
US	66-20-04	OIL FILTER ADAPTER GASKET	307
US	75-08-09 75-09-15	OIL PUMP DRIVE SHAFT/IMPELLER FUEL FLOW DIVIDER COVER GASKET	381B, 385C 382
US	78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US	79-04-05	BENDIX FUEL INJECTORS	433A
US	91-14-22 92-12-05	PROP/ENG STOPPAGE ~ DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A 501 REV B
US	93-02-05	FUEL INJECTOR FUEL LINES	342A
US	93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US	94-06-09 95-07-01	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CONNECTING ROD BOLTS	CSB 641 SUPERIOR AIR #95-002
US	96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US	96-23-03	HIGH PRESSURE FUEL PUMP	525A
US	97-15-11 98-17-11	PISTON PINS CRANKSHAFT INSPECTION	527C
US	98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
TO-540	D=44145	( IO-540-A SERIES )	
	D-AA1A5 83-22-04	FUEL DIAPHRAGM ASSEMBLY	467
		( TO 540 A CEPTEC )	
10-540	D-AB1A5	( IO-540-A SERIES )	
10-540	D-AC1A5	( IO-540-A SERIES )	
	)-A1A5	( ID-540-A SERIES )	2675
US US	73-23-01 81-03-05	PISTON PINS MIXTURE CONTROL SHAFT ASSEMBLY	367F 444
		THE SHARE SHARE A PARTIE A	
	O-C SERIES	OT DUMP DRIVE SHAFT	295
US US	63-14-03 64-16-05	OIL PUMP DRIVE SHAFT  AC FUEL PUMP	298
US	66-20-04	OIL FILTER ADAPTER GASKET	307
US	75-08-09	. OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C 382
US	75-09-15	FUEL FLOW DIVIDER COVER GASKET	362

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT REFERENCE SERVICE BULLETIN BUILETIN DE SERVICE DE REF AVCO IVCOMING IO-540-C SERIES (CONTINUED / SUITE) BENDIX FUEL INJECTORS 428. 429. 430 79-04-05 BENDIX FUEL INJECTORS 4331 US ROCKER ARM ASSEMBLY 477A 87-10-06R1 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A 91-14-22 92-12-05 PISTON PINS 501 REV B 342A 93-02-05 FUEL INJECTOR FUEL LINES AC. LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002 93-11-11 94-06-09 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 SUPERIOR AIR #95-002 95-07-01 CONNECTING ROD BOLTS ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 96-09-10 96-23-03 HIGH PRESSURE FUEL PUMP 525A US 97-15-11 PISTON PINS 527C CRANKSHAFT INSPECTION 98-17-11 98-18-12 CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 520 ( 10-540-C SERIES ID-540-C1B5 US 67-22-06 FUEL INJECTORS/DIAPHRAGM ASSEMBLY 305B IO-540-C1C5 ( IO-540-C SERIES ) FUEL INJECTORS/DIAPHRAGM ASSEMBLY 305B US 67-22-06 IO-540-C4R5 ( IO-540-C SERIES ) US 67-22-06 FUEL INJECTORS/DIAPHRAGM ASSEMBLY 305R 73-23-01 US PISTON PINS 367F IO-540-C4D5D ( IO-540-C SERIES ) IO-540-D SERIES US 63-14-03 OIL PUMP DRIVE SHAFT 295 OIL FILTER ADAPTER GASKET 66-20-04 307 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C 75-08-09 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382 US BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS 78-23-10 428, 429, 430 433A 79-04-05 87-10-06R1 ROCKER ARM ASSEMBLY 477A 91-14-22 SL L163B, SB 475 R A 501 REV B US PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS 92-12-05 93-02-05 FUEL INJECTOR FUEL LINES 342A US 93-11-11 AC. LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 94-06-09 95-07-01 CONNECTING ROD BOLTS SUPERIOR AIR #95-002 US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 HIGH PRESSURE FUEL PUMP 5254 96-23-03 US 97-15-11 PISTON PINS 527C CRANKSHAFT INSPECTION
CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 98-17-11 98-18-12 529 IO-540-D4A5 ( IO-540-D SERIES )
FUEL INJECTORS/DIAPHRAGM ASSEMBLY 305B 67-22-06 US 73-23-01 PISTON PINS US 367F IO-540-E SERIES 63-14-03 OIL PUMP DRIVE SHAFT US 295 66-20-04 OIL FILTER ADAPTER GASKET 307 US OIL PUMP DRIVE SHAFT/IMPELLER 75-08-09 381B, 385C FUEL FLOW DIVIDER COVER GASKET US 75-09-15 382 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430 79-04-05 US BENDIX FUEL INJECTORS 433A US 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A PISTON PINS 501 REV B 115 92-12-05 US 93-02-05 FUEL INJECTOR FUEL LINES 342A AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002 US 93-11-11 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 94-06-09 95-07-01 CONNECTING ROD BOLTS SUPERIOR AIR #95-002 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 96-09-10 96-23-03 HIGH PRESSURE FUEL PUMP 525A 97-15-11 PISTON PINS 527C 98-17-11 CRANKSHAFT INSPECTION US CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 98-18-12 529 IO-540-E1A5 ( IO-540-E SERIES ) 73-23-01 PISTON PINS 367F

MAKE / CONSTRUCTEUR

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. AVCO LYCOMING IO-540-E1B5 ( IO-540-E SERIES ) US 73-23-01 PISTON PINS TO-540-G SERIES 63-14-03 OIL PUMP DRIVE SHAFT 66-20-04 US OIL FILTER ADAPTER GASKET 307 LIS 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382 78-23-10 BENDIX FUEL INJECTORS
BENDIX FUEL INJECTORS 428, 429, 430 79-04-05 433A PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES 91-14-22 PISTON PINS SL L163B, SB 475 R A 92-12-05 US 501 REV B FUEL INJECTOR FUEL LINES AC, LYCOMING & RAJAY DIAF US 93-02-05 342A 93-11-11 US AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS AERO ACCESSORIES 002 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 95-07-01 CONNECTING ROD BOLTS SUPERIOR AIR #95-002 US 96-09-10 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 96-23-03 HIGH PRESSURE FUEL PUMP 525A 97-15-11 PISTON PINS 527C US 98-17-11 CRANKSHAFT INSPECTION US 98-18-12 CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 529 IO-540-G1A5 ( ID-540-G SERIES ) US 69-08-09 PLACARD - MANIFOLD PRESSURE TO-540-G1R5 ( IO-540-G SERIES ) 78-23-08 FUEL PUMP / INJECTOR TUBE US 421 FUEL DIAPHRAGM ASSEMBLY US 83-22-04 467 IO-540-G1D5 ( IO-540-G SERIES ) 73-23-01 115 PISTON PINS 367F US 83-22-04 FUEL DIAPHRAGM ASSEMBLY 467 IO-540-J SERIES US 63-14-03 OIL PUMP DRIVE SHAFT US 66-20-04 OIL FILTER ADAPTER GASKET 307 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C FUEL FLOW DIVIDER COVER GASKET 75-09-15 BENDIX FUEL INJECTORS
BENDIX FUEL INJECTORS 78-23-10 428, 429, 430 US 79-04-05 433A US 87-10-06R1 ROCKER ARM ASSEMBLY 477A 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES
PISTON PINS SL L163B, SB 475 R A 501 REV B US 92-12-05 FUEL INJECTOR FUEL LINES US 93-02-05 3424 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS US 93-11-11 AERO ACCESSORIES 002 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 94-06-09 SUPERIOR AIR #95-002 US 95-07-01 CONNECTING ROD BOLTS ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 US 96-09-10 HIGH PRESSURE FUEL PUMP 525A US 96-23-03 US 97-15-11 PISTON PINS CRANKSHAFT INSPECTION
CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP US 98-17-11 98-18-12 529 -J4A5 ( IO-540-J SERIES ) IO-540-J4A5 367F US IO-540-K SERIES 63-14-03 295 OIL PUMP DRIVE SHAFT US OIL FILTER ADAPTER GASKET 307 66-20-04 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C 75-08-09 US FUEL FLOW DIVIDER COVER GASKET 382 US 75-09-15 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430 US BENDIX FUEL INJECTORS 433A 79-04-05 SL L163B, SB 475 R A PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES US 91-14-22 501 REV B US 92-12-05 PISTON PINS FUEL INJECTOR FUEL LINES

AC. LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS 342A 93-02-05 AERO ACCESSORIES 002 US 93-11-11 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 94-06-09 CONNECTING ROD BOLTS HIGH PRESSURE FUEL PUMP SUPERIOR AIR #95-002 US 95-07-01 525A US 96-23-03 PISTON PINS 527C 97-15-11 CRANKSHAFT INSPECTION US 98-17-11 CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 98-18-12

MAKE / CONSTRUCTEUR

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF SUBJECT AVCO LYCOMING IO-540-K1A5 ( IO-540-K SERIES ) PISTON PINS 367F US 73-23-01 FUEL DIAPHRAGM ASSEMBLY 83-22-04 467 ENGINE OIL PUMP IMPELLERS 454B. 455D. 524. 456 US 96-09-10 SLICK - MAGNETO IMPULSE COUPLING SB1-98 99-04-04 115 IO-540-K1B5 ( IO-540-K SERIES ) US 73-23-01 PISTON PINS 73-23-01 83-22-04 FUEL DIAPHRAGM ASSEMBLY 467 LIS 96-09-10 ENGINE OIL PUMP IMPELLERS
SLICK - MAGNETO IMPULSE COUPLING 454B, 455D, 524, 456 US SB1-98 115 99-04-04 IO-540-K1F5 ( ID-540-K SERIES ) PISTON PINS US 73-23-01 367F MIXTURE CONTROL SHAFT ASSEMBLY ENGINE OIL PUMP IMPELLERS 444 96-09-10 454B, 455D, 524, 456 US ( IO-540-K SERIES ) ID-540-K1F5 FUEL PUMP / INJECTOR TUBE 421 US 78-23-08 FUEL DIAPHRAGM ASSEMBLY 467 US 83-22-04 96-09-10 FNGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 115 ( ID-540-K SERIES ) FUEL DIAPHRAGM ASSEMBLY IO-540-K1G5 US 83-22-04 US 96-09-10 454B, 455D, 524, 456 ENGINE OIL PUMP IMPELLERS SLICK - MAGNETO IMPULSE COUPLING SB1-98 US 99-04-04 IO-540-K1G5D ( ID-540-K SERIES ) US 83-22-04 FUEL DIAPHRAGM ASSEMBLY 467 ( IO-540-K SERIES ) IO-540-K1J5 US 83-22-04 FUEL DIAPHRAGM ASSEMBLY 467 ENGINE OIL PUMP IMPELLERS 454B, 455D, 524, 456 96-09-10 115 IO-540-L SERIES US 63-14-03 OTI PUMP DRIVE SHAFT 66-20-04 OIL FILTER ADAPTER GASKET 307 OIL PUMP DRIVE SHAFT/IMPELLER FUEL FLOW DIVIDER COVER GASKET 75-08-09 75-09-15 381B, 385C US 382 75-09-15 78-23-10 BENDIX FUEL INJECTORS 428, 429, 430 BENDIX FUEL INJECTORS 433A US 79-04-05 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES US 91-14-22 SL L163B, SB 475 R A 92-12-05 PISTON PINS 501 REV B 92-12-05 PISTON PINS
93-02-05 FUEL INJECTOR FUEL LINES
93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS
94-06-09 PENDLY MAGNETOS CARACITORS (OPEN CIRCUIT CONDITI US 3424 AERO ACCESSORIES 002 US BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 US 94-06-09 454B, 455D, 524, 456 ENGINE OIL PUMP IMPELLERS US 96-09-10 96-23-03 HIGH PRESSURE FUEL PUMP 525A US 5270 97-15-11 PISTON PINS US 98-17-11 98-18-12 CRANKSHAFT INSPECTION US CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP IO-540-L4B5 ( IO-540-L SERIES ) IO-540-M SERIES 63-14-03 63-20-04 295 US OIL PUMP DRIVE SHAFT OIL FILTER ADAPTER GASKET 307 US 75-08-09 OIL PUMP DRIVE SHAFT/IMPELLER 381B, 385C 75-09-15 FUEL FLOW DIVIDER COV 78-23-10 BENDIX FUEL INJECTORS 79-04-05 BENDIX FUEL INJECTORS 91-14-22 PROP/FNG STOPPAGE - D 75-09-15 FUEL FLOW DIVIDER COVER GASKET 382 428, 429, 430 BENDIX FUEL INJECTORS US 433A 91-14-22 PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES SL L163B, SB 475 R A 501 REV B US 92-12-05 PISTON PINS 92-12-05 PISTON PINS
93-02-05 FUEL INJECTOR FUEL LINES
93-11-11 AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS
94-06-09 BENDIX MAGNETOS CAPACITORS (OPEN CIRCUIT CONDIT 342A US US AERO ACCESSORIES 002 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 94-06-09 95-07-01 CONNECTING ROD BOLTS
96-09-10 ENGINE OIL PUMP IMPELLERS
96-23-03 HIGH PRESSURE FUEL PUMP
PISTON PINS SUPERIOR AIR #95-002 454B, 455D, 524, 456 US 525A US PISTON PINS 97-15-11 527C US CRANKSHAFT INSPECTION CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP 98-17-11 US 529 98-18-12 US

MAKE / CONSTRUCTEUR

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

	30021	BULLETIN DE SERVICE DE REF.
AVCO LYCOMING		
IO-540-M1A5	( IO-540-M SERIES )	
ID-540-N SERIES		
US 63-14-03	OIL PUMP DRIVE SHAFT	295
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 75-08-09 US 75-09-15	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 78-23-10	FUEL FLOW DIVIDER COVER GASKET BENDIX FUEL INJECTORS	382
US 79-04-05	BENDIX FUEL INJECTORS	428, 429, 430 433A
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05 US 93-11-11	FUEL INJECTOR FUEL LINES	342A
US 94-06-09	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	AERO ACCESSORIES 002
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-09-10	ENGINE OIL PUMP IMPELLERS	454B, 455D, 524, 456
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
US 98-17-11	CRANKSHAFT INSPECTION	
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
IO-540-N1A5	( IO-540-N SERIES )	
IO-540-R SERIES	OT DUMO POTUE OUTS	
US 63-14-03 US 66-20-04	OIL PUMP DRIVE SHAFT OIL FILTER ADAPTER GASKET	295
US 75-08-09	OIL FILTER ADAPTER GASKET OIL PUMP DRIVE SHAFT/IMPELLER	307 381B, 385C
US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	3816, 3850
US 78-23-10	BENDIX FUEL INJECTORS	428. 429. 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05 US 93-02-05	PISTON PINS FUEL INJECTOR FUEL LINES	501 REV B 342A
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
US 98-17-11 US 98-18-12	CRANKSHAFT INSPECTION CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
30 10 12	CHANCY CEAR ROMEC AN ROTART FOLL FOR	
IO-540-R1A5	( IO-540-R SERIES )	
IO-540-S SERIES	OIL PUMP DRIVE SHAFT	295
US 63-14-03 US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	4334
US 91-14-22 US 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A   501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 93-11-11	AC. LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11 US 98-17-11	PISTON PINS CRANKSHAFT INSPECTION	527C
US 98-17-11 US 98-18-12	CRANKSHAFT INSPECTION  CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
10 12		
ID-540-S1A5	( 10-540-S SERIES )	40.4
US 78-23-08	FUEL PUMP / INJECTOR TUBE	421
US 83~22-04	FUEL DIAPHRAGM ASSEMBLY	467
IO-540-T SERIES		
US 63-14-03	OIL PUMP DRIVE SHAFT	295
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	381B, 385C
US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US 78-23-10	BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS	428, 429, 430 433A
US 79-04-05	DEMOTA FUEL INDECTORS	700A

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

AVCO LYCOMING		
IO-540-T SERIES		
(CONTINUED / SUITE)		
US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 97-15-11	PISTON PINS	527C
US 98-17-11	CRANKSHAFT INSPECTION	
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
IO-540-T4A5D	( IO-540-T SERIES )	
IO-540-T4B5D	( IO-540-T SERIES )	
	,	
IO-540-W SERIES		
US 63-14-03	OIL PUMP DRIVE SHAFT	295
US 66-20-04	OIL FILTER ADAPTER GASKET	307
US 75-08-09	OIL PUMP DRIVE SHAFT/IMPELLER	
US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
	ROCKER ARM ASSEMBLY	477A
	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 91-14-22		
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 96-23-03	HIGH PRESSURE FUEL PUMP	525A
US 98-17-11	CRANKSHAFT INSPECTION	
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
IO-540-W1A5D	( IO-540-W SERIES )	
IVO-540-A1A		
US 68-08-08	HYDRAULIC VALVE LIFTER	314A
US 73-05-01	CONNECTING ROD ASSEMBLIES	303B, C, D, E,F
US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 80-04-04R1	CRANKSHAFT FLANGE BOLTS	SI 1209B
US 92-12-05	PISTON PINS	501 REV B
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 97-15-11	PISTON PINS	527C
03 37-13-11	1310N FINS	3276
LTIO-540 CEDIES		
LTIO-540 SERIES	DENDIY FILEL INJECTORS	128 129 120
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430 433A
US 79-04-05	BENDIX FUEL INJECTORS	
US 83-22-04	FUEL DIAPHRAGM ASSEMBLY	467
US 91-08-07	FUEL PUMP VENT HOSE FITTING LEAK CHECK	494,497 & SI 1460
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 97-15-11	PISTON PINS	527C
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
LTIO-540-F2BD	( LTIO-540 SERIES )	
US 97-01-04	REPLACEMENT CYLINDERS	96-002 REV. A
LTI0-540-J2B	( LTIO-540 SERIES )	
US 97-01-04	REPLACEMENT CYLINDERS	96-002 REV. A
LTI0-540-J2BD	( LTIO-540 SERIES )	
US 97-01-04	REPLACEMENT CYCLINDERS	96-002 REV. A
TIO-540-A SERIES		
US 71-13-01	FUEL INJECTOR MANIFOLD/NOZZLE TUBE ASSEMBLIES	335

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

		BULLETIN DE SERVICE DE REF.
AVCO LYCOMING TID-540-A SERIES (CONTINUED / SUITE) US 75-09-15 US 78-23-10 US 79-04-05	FUEL FLOW DIVIDER COVER GASKET BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS	382 428, 429, 430
US 91-08-07 US 91-14-22 US 92-12-05 US 93-02-05	FUEL PUMP VENT HOSE FITTING LEAK CHECK PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS FUEL INJECTOR FUEL LINES	433A 494,497 & SI 1460 SL L163B, SB 475 R A 501 REV B 342A
US 93-11-11 US 94-06-09 US 95-07-01 US 97-15-11 US 98-17-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CONNECTING ROD BOLTS PISTON PINS CRANKSHAFT INSPECTION	AFRO ACCESSORIES 002
US 98-18-12 TIO-540-AA1AD	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP  ( TIO-540-A SERIES )	529
TIO-540-AB1AD US 87-10-06R1	( TIO-540-A SERIES ) ROCKER ARM ASSEMBLY	477A
TIO-540-AE2A	(_TID-540-A SERIES )	411A
US 89-15-10 US 91-10-04	ENGINE FUEL PUMP DIAPHRAGM EXHAUST TRANSITION FLANGE BOLTS	487 491A
TIO-540-AF1A	( TIO-540-A SERIES )	
TIO-540-AF1B	( TIO-540-A SERIES )	
TIO-540-AJ1A	( TIO-540-A SERIES )	
TIO-540-A1A	( TIO-540-A SERIES )	
TIO-540-A1B	( TIO-540-A SERIES )  ( TIO-540-A SERIES )	
TIO-540-A2B	( TIO-540-A SERIES )	
US 73-23-01	PISTON PINS	367F
TIO-540-A2C US 73-23-01 US 97-01-04	( TIO-540-A SERIES ) PISTON PINS REPLACEMENT CYLINDERS	367F 96-002 REV. A
TIO-540-C SERIES US 87-10-06R1	ROCKER ARM ASSEMBLY	477A
US 91-08-07 US 91-14-22 US 92-12-05 US 93-02-05	FUEL PUMP VENT HOSE FITTING LEAK CHECK PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS FUEL INJECTOR FUEL LINES	494,497 & SI 1460 SL L163B, SB 475 R A 501 REV B 342A
US 93-11-11 US 94-06-09 US 95-07-01	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CONNECTING ROD BOLTS	AERO ACCESSORIES 002
US 97-15-11 US 98-18-12	PISTON PINS CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	527C 529
TIO-540-C1A	( TID-540-C SERIES )	367F
US 73-23-01 US 75-09-15	PISTON PINS FUEL FLOW DIVIDER COVER GASKET	382
US 78-23-10 US 79-04-05	BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS	428, 429, 430 433A
TIO-540-F SERIES US 97-15-11 US 98-18-12	PISTON PINS CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	527C 529
T10-540-F2BD US 75-09-15 US 78-23-10 US 79-04-05	( TIO-540-F SERIES )  FUEL FLOW DIVIDER COVER GASKET  BENDIX FUEL INJECTORS  BENDIX FUEL INJECTORS	382 428, 429, 430 433A
US 83-22-04 US 91-08-07 US 91-14-22 US 93-11-11	BENDIX FUEL INJECTORS  FUEL DIAPHRAGM ASSEMBLY  FUEL PUMP VENT HOSE FITTING LEAK CHECK  PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES  AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	467 494,497 & SI 1460 SL L163B, SB 475 R A AERO ACCESSORIES 002

(SERIES / SERIE)

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT SUJET

AVCO LYCOMING TIO-540-F2BD	( TID-FAOUE CEDIEC )	
(CONTINUED / SUITE)	( TIO-540-F SERIES )	
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
US 97-01-04	REPLACEMENT CYLINDERS	96-002 REV. A
770 540 1 650756		
TIO-540-J SERIES US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 91-08-07	FUEL PUMP VENT HOSE FITTING LEAK CHECK	494,497 & SI 1460
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05 US 93-11-11	FUEL INJECTOR FUEL LINES AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	342A AERO ACCESSORIES 002
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSR 641
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 97-15-11	PISTON PINS	527C
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
TIO-540-J2B	( TID-EAO- I CEDIEC )	
US 97-01-04	( TIO-540-J SERIES ) REPLACEMENT CYLINDERS	96-002 REV. A
	TELEVENERI OLETADENS	30 002 KEV. A
TIO-540-J2BD	( TIO-540-J SERIES )	
US 73-23-01	PISTON PINS	367F
US 83-22-04	FUEL DIAPHRAGM ASSEMBLY	467
US 97-01-04	REPLACEMENT CYLINDERS	96-002 REV. A
TIO-540-R SERIES		
US 97-15-11	PISTON PINS	527C
US 98-17-11	CRANKSHAFT INSPECTION	
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
T10-540-R2AD	( TIO-540-R SERIES )	
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS	433A
US 91-08-07	FUEL PUMP VENT HOSE FITTING LEAK CHECK	494,497 & SI 1460
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	
US 93-11-11	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	AERO ACCESSORIES 002
US 94-06-09 US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 97-01-04	REPLACEMENT CYLINDERS	96-002 REV. A
TIO-540-S SERIES		
US 97-15-11 US 98-18-12	PISTON PINS CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	527C
03 30-16-12	CRAINE/ LEAR RUMEC AN RUTARY FUEL PUMP	529
TIO-540-S1AD	( TIO-540-S SERIES )	
US 75-09-15	FUEL FLOW DIVIDER COVER GASKET	382
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05 US 80-17-10	BENDIX FUEL INJECTORS THROTTLE MOVEMENT	433A
US 83-22-04	FUEL DIAPHRAGM ASSEMBLY	448 467
US 91-08-07	FUEL PUMP VENT HOSE FITTING LEAK CHECK	494,497 & SI 1460
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 91-21-01R1	ENGINE EXHAUST SYSTEM	484, 499A
US 93-05-22 US 93-11-11	FUEL INJECTOR FUEL LINES SUPPORT CLAMPS	AEDD ACCESSORIES CO.
US 94-06-09	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	AERO ACCESSORIES 002
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 97-01-04	REPLACEMENT CYLINDERS	96-002 REV. A
TIO 540 T 5555		
TIO-540-T SERIES US 78-23-10	DENDTY FIEL THIECTORS	409 400 400
US 79-04-05	BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS	428, 429, 430 433A
US 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES	342A
US 93-11-11 US 94-06-09	AC, LYCOMING & RAJAY DIAPHRAGM FUEL PUMPS	AERO ACCESSORIES 002
US 97-15-11	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PISTON PINS	527C
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
TIO-540-T2AD	( TIO-540-T SERIES )	
US 91-08-07	FUEL PUMP VENT HOSE FITTING LEAK CHECK	494,497 & SI 1460

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT SUJET

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
AVCO LYCOMING		
TIO-540-U SERIES		
US 83-22-04	FUEL DIAPHRAGM ASSEMBLY	467
03 37 13 11	PISTON PINS	527C
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
T10-540-U2A	( TTO FAC !! OSPICE )	
US 91-08-07	( TIO-540-U SERIES )  FUEL PUMP VENT HOSE FITTING LEAK CHECK PISTON PINS  FUEL INJECTOR LINES	
US 92-12-05	PISTON DING	494,497 & SI 1460
US 93-02-05	FUEL INJECTOR LINES	342A
		0-12-1
VO-540-B SERIES		
CF CF~73-10	CONNECTING ROD BOLT FAILURE CONNECTING ROD ASSEMBLIES CONNECTING ROD ASSEMBLIES TAPPET BODY & PLUNGER ASSEMBLY	303D
CF CF-73-13 CF CF-74-03	CONNECTING ROD ASSEMBLIES	1081A
US 62-03-02	CONNECTING ROD ASSEMBLIES TAPPET BODY & PLUNGER ASSEMBLY HYDRAULIC VALVE LIFTER	1011
US 68-08-08	HYDRAULIC VALVE LIFTER	3144
US 73-05-01		303B, C, D, E,F
US 73-23-01	PISTON PINS	
US 80-04-04R1	CRAINCHAFT FLANGE BULTS	21 12098
US 92-12-05	PISTON PINS	501 REV B
US 94-06-09 US 97-15-11	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
03 9/-10-11	PISTON PINS	527C
VO-540-B1B3	( VD-540-B SERIES )	
	,	
VO-540-C SERIES		
CF CF-73-10	CONNECTING ROD BOLT FAILURE CONNECTING ROD ASSEMBLIES CONNECTING ROD ASSEMBLIES TAPPET BODY & PLUNGER ASSEMBLY HYDRAULIC VALVE LIFTER CONNECTING ROD ASSEMBLIES	303D
CF CF-73-13	CONNECTING ROD ASSEMBLIES	1081A
CF CF-74-03 US 62-03-02	CUNNECTING ROD ASSEMBLIES	1011
US 68-08-08	HYDRAULIC VALVE LIFTER CONNECTING ROD ASSEMBLIES PISTON PINS	3144
US 73-05-01	CONNECTING ROD ASSEMBLIES	303B, C, D, E,F
US 73-23-01	PISTON PINS	367F
US 80-04-04R1	CRANKSHAFT FLANGE BOLTS	SI 1209B
US 92-12-05	PISTON PINS	501 REV B
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 97-15-11	PISTON PINS	527C
VO-540-C2A	( VO-540-C SERIES )	
70 010 027	( 10 0 10 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	
TIGO-541 SERIES		
US 92-12-05	PISTON PINS	501 REV B
US 93-02-05	FUEL INJECTOR FUEL LINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	34ZA
US 94-06-09 US 97-15-11	PISTON PINS	527C
US 98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	
05	OTTALLY LEAR MOREO AIT TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TO THE TOTAL AIR TOTAL AIR TOTAL AIR TO THE TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOTAL AIR TOT	
TIGO-541-E1A	( TIGO-541 SERIES )	
115 72 02-04	PISTON PINS	367F
US 78-23-10	BENDIX FUEL INJECTORS BENDIX FUEL INJECTORS	428, 429, 430
US 79-04-05	BENDIX FUEL INJECTORS FUEL DIAPHRAGM ASSEMBLY	433A 467
US 83-22-04 US 91-08-07	FUEL DIAPHRAGM ASSEMBLY FUEL PUMP VENT HOSE FITTING LEAK CHECK	494,497 & SI 1460
03 91-08-07	FOLL FORM VENT HOSE ITTITING LEAR OFFER	101,101
TIO-541-E SERIES		
US 73-23-01	PISTON PINS	367F
US 78-23-10	BENDIX FUEL INJECTORS	428, 429, 430
US 78-23-10 US 79-04-05	BENDIX FUEL INJECTORS	433A 494,497 & SI 1460
US 91-08-07	FUEL PUMP VENT HOSE FITTING LEAK CHECK	501 REV B
US 92-12-05 US 93-02-05	PISTON PINS FUEL INJECTOR FUEL LINES	342A
US 93-02-05 US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-07-01	CONNECTING ROD BOLTS	SUPERIOR AIR #95-002
US 97-15-11	PISTON PINS	527C
TIO-541-E1A4	( TIO-541-E SERIES )	467
US 83-22-04	FUEL DIAPHRAGM ASSEMBLY	467
TID 544 5404	( TIO-541-E SERIES )	
TIO-541-E1B4 US 83-22-04	FUEL DIAPHRAGM ASSEMBLY	467
03 65-22-04	TOEL DIATEMON ROOF DET	
TID-541-E1C4	( TIO-541-E SERIES )	
US 83-22-04	FUEL DIAPHRAGM ASSEMBLY	467

MODEL / M ORIGIN	STRUCTEUR ODELE AD NUMBER NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
	COMING SERIES		
US	73-23-01	PISTON PINS	367F
US US	75-09-15 78-23-10	FUEL FLOW DIVIDER COVER GASKET BENDIX FUEL INJECTORS	382 428, 429, 430
US	79-04-05	BENDIX FUEL INJECTORS	433A
US US	91-14-22 92-12-05	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES PISTON PINS	SL L163B, SB 475 R A 501 REV B
US	93-02-05	FUEL INJECTOR FUEL LINES	342A
US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US US	95-07-01 97-15-11	CONNECTING ROD BOLTS PISTON PINS	SUPERIOR AIR #95-002 527C
US	98-17-11	CRANKSHAFT INSPECTION	500
US	98-18-12	CRANE/LEAR ROMEC "AN" ROTARY FUEL PUMP	529
10-720	)-A1B	( IO-720 SERIES )	
10-720	)-B1B	( IO-720 SERIES )	
10-720	)~B1BD	( IO-720 SERIES )	
10-720	D-D1CD	( IO-720 SERIES )	
R-680 US	91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
R-680-	B4D		
US US	91-14-22 94-06-09	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
		BENDIA MAGNETUS CAPACITORS/OPEN CIRCOIT CONDITION	C3D 641
R-680- US	<b>B4E</b> 91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
R-680-			
US US	91-14-22 94-06-09	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
R-680-	12		
	91-14-22	PROP/ENG STOPPAGE - DIRECT DRIVE PISTON ENGINES	SL L163B, SB 475 R A
US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
R-680-	17		
	SERIES		
US US	75-22-02 77-17-08	TORQUEMETER BOOST PUMP DRIVE SHAFT FUEL REGULATOR P1 MULTIPLIER LEVER	0031 0048R1
US	97-07-05	N2 SPUR GEAR NUT RETAINER	T5311/T53-L-11-0080
T5311B		( T5311 SERIES )	
US	74-09-03	COMPRESSOR ROTOR DISCS/CENTRIFUGAL IMPELLER	0033
	SERIES		
US US	75-22-02 77-17-08	TORQUEMETER BOOST PUMP DRIVE SHAFT FUEL REGULATOR P1 MULTIPLIER LEVER	0031 0048R1
US	97-07-05	N2 SPUR GEAR NUT RETAINER	T5313B/T5317-0081
US	97-21-07R1	ACCESSORY DRIVE CARRIER ASSEMBLY	T53-L-703-A0092
T5313B		( T5313 SERIES )	000004
US US	71-08-06 75-01-05	OVERSPEED GEAR BEARING CENTRIFUGAL COMPRESSOR IMPELLER	0022R1 0042
US	75-12-12	BOLTS - 2ND STAGE GAS PRODUCER CYLINDER	0028R2
US US	87-12-05 95-10-04	GAS PRODUCER & POWER TURBINE DISKS & SPACERS CENTRIFUGAL COMPRESSOR IMPELLER	0020R2 T5313B/17-0052R2
US	96-17-01	SECOND STAGE POWER TURBINE DISKS	
	SERIES		
US US	75-22-02 77-17-08	TORQUEMETER BOOST PUMP DRIVE SHAFT FUEL REGULATOR P1 MULTIPLIER LEVER	0031 0048R1
US	95-10-04	CENTRIFUGAL COMPRESSOR IMPELLER	T5313B/17-0052R2
US US	97-07-05 97-21-07R1	N2 SPUR GEAR NUT RETAINER ACCESSORY DRIVE CARRIER ASSEMBLY	T5313B/T5317-0081
	J. ZI VIKI	ASSESSOR! DRIVE CARRIER ASSEMBLY	T53-L-703-A0092

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT SUJET

ORIGINE NOMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
AVCO IVCOMING		
AVCO LYCOMING T5317A	( TECAT CERTER )	
	( T5317 SERIES )	
30.22.11	ENGINE FUEL REGULATOR	ASB T5317A-1-A0106R1
T5508D		
US 76-12-05	COMPRESSOR BLEED AIR BAND INNER BEVEL GEAR ASSEMBLY	FE00 0000 0007
US 78-07-04	INNER REVEL GEAD ACCEMBLY	5508-0003, ~0007
US 86-19-13	FIRST STAGE TURBINE DISK	5508-0013
US 94-02-01	IMPELLER - CYCLIC LIFE	5508-0031R1
	IPH EECEN CICLIC LIFE	T5508D-0002R7, -0040
LTS-101-600 SERIES		
US 86-10-04	GAS PRODUCER BLADE DAMPER	
US 88-14-01	# 3 & 4 BEARINGS / POWER TURRINE DISCS	77-30-0104R1
US 92-15-07	CAST POWER TURBINE (PT) ROTOR BLADES	72-00-009285
US 93-13-11	CAST POWER TURBINE (PT) ROTOR BLADES GAS GENERATOR TURBINE ROTOR DISKS	IT 101-71-00-0002P12
US 94-18-06	#2 BEARING REPLACEMENT	LT-101-72-50-0163R1
US 95-09-02	FUEL PUMP INTERNAL DRIVE SPLINE TEETH	LT101-73-20-165R1
US 95-16-04	AXIAL COMPRESSOR ROTORS	LT 101-72-30-0088
US 96-12-05		LT101-72-50-0144
US 96-12-27	GAS GENERATOR TURBINE DISKS	LT-101-72-50-0150
		27 107 72 00 0100
LTS-101-600A	( LTS-101-600 SERIES )	
US 79-06-06R2	OIL ANALYSIS / SCAVENGE CHIP DETECTOR	101-72-0003R1
US 79-20-03	ACCESS DRIVE GEAR - FUEL CONTROL, FUEL & OIL PUMP	
LTS-101-600A-2	( LTS-101-600 SERIES )	
US 79-06-06R2	OIL ANALYSIS / SCAVENCE CHIP DETECTOR	101-72-0003R1
US 79-20-03	ACCESS DRIVE GEAR - FUEL CONTROL, FUEL & DIL PUMP	3V-W733
US 83-16-03	OVERSPEED LIMITER	LTS101A-73-0043
US 84-02-07	OUTPUT GEAR ASSEMBLY / TORQUEMETER GEAR ASSEMBLY	
US 84-14-01	T4 INDICATOR SYSTEM	101A-71-00-0061
US 96-06-10	INCORPORATE IMPROVED POWER TURBINE RETENTION SYS	LTS101A-72-50-0134R2
US 96-10-04	IMPROVED FUEL CONTROL UNIT	73-20-0166R1, R2
		· ·
LTS-101-600A-3	( LTS-101-600 SERIES )	
US 96-06-10	INCORPORATE IMPROVED POWER TURBINE RETENTION SYS	
US 96-10-04	IMPROVED FUEL CONTROL UNIT	73-20-0166R1, R2
LTS-101-650 SERIES		
US 86-10-04	GAS PRODUCER BLADE DAMPER	
05 88-14-01	# 3 & 4 BEARINGS / POWER TURBINE DISCS	77-30-0104R1
US 92-15-07	# 3 & 4 BEARINGS / POWER TORBINE DISCS CAST POWER TURBINE (PT) ROTOR BLADES	72-00-0093R5
US 93-13-11	GAS GENERATOR TORBINE ROTOR DISKS	LT 101-71-00-0002R12
US 94-18-06	#2 BEARING REPLACEMENT	LT-101-72-50-0163R1
US 95-09-02	FUEL PUMP INTERNAL DRIVE SPLINE TEETH	LT101-73-20-165R1
US 95-16-04	AXIAL COMPRESSOR ROTORS	LT 101-72-30-0088
US 95-26-01		LTS101B-72-50-0119
US 96-12-05	POWER TURBINE ROTORS	LT101-72-50-0144
US 96-12-27	GAS GENERATOR TURBINE DISKS	LT-101-72-50-0150
1.75 464 5555	( 170 101 050 050750 )	
LTS-101-650B-1	( LTS-101-650 SERIES )	LTS101. 70. 10. 0100
US 95-08-14	ENGINE ELECTRONIC OVERSPEED PROTECTION SYSTEM	LTS101-73-10-0169
LTS 404 C500 0	( LTC. 404CEO CERTES )	
LTS-101-650C-3	( LTS-101-650 SERIES )	LTS101-73-10-0169
US 95-08-14	ENGINE ELECTRONIC OVERSPEED PROTECTION SYSTEM	L13101 73 10-0165
LTS-101-750 SERIES		
US 88-14-01	# 3 & 4 BEARINGS / POWER TURBINE DISCS	77-30-0104R1
115 92-45-07	CAST POWER TURBINE (PT) ROTOR BLADES	72-00-0093R5
US 92-15-07 US 93-13-11	GAS GENERATOR TURBINE (PT) ROTOR BEADES  GAS GENERATOR TURBINE ROTOR DISKS	LT 101-71-00-0002R12
	#2 BEARING REPLACEMENT	LT-101-72-50-0163R1
US 94-18-06 US 95-09-02	FUEL PUMP INTERNAL DRIVE SPLINE TEETH	LT101-73-20-165R1
	AXIAL COMPRESSOR ROTORS	LT 101-72-30-0088
US 95-16-04 US 95-26-01	INSTALLATION OF IMPROVED POWER TURBINE	LTS101B-72-50-0116
US 96-12-27	GAS GENERATOR TURBINE DISKS	LT-101-72-50-0150
03 90-12-21	GAS GENERATOR FORDING DISKS	
LTS-101-750B-1	( LTS-101-750 SERIES )	
US 95-08-14	ENGINE ELECTRONIC OVERSPEED PROTECTION SYSTEM	LTS101-73-10-0169
03 95-08-14	CHATILE EFFORMATO OVERSI FED I MOTEOLISM STOTEM	
LTS-101-750C-1	( LTS-101-750 SERIES )	
	GAS PRODUCER BLADE DAMPER	
US 86-10-04 US 95-08-14	ENGINE ELECTRONIC OVERSPEED PROTECTION SYSTEM	LTS101-73-10-0169
33 33 08 14	LITERIA CELOTIFICATE OF ENTITY EED THE TELEVISION OF ENTITY	
ALF-502L SERIES		
US 80-22-53	FOUR AND FIVE BEARING OIL INLET TUBES	72-0008, -0010

MODEL / M ORIGIN ORIGINE	AD NUMBER	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
44.00 11	COMING		
	COMING  OLUMNICATION SERIES		
	NUED / SUITE)		
US	82-25-10	1ST STAGE COMPRESSOR STATOR VANE / 4TH STG NOZZLE	72-0012R2, -0025R1
US	83-03-51	4TH STAGE TURBINE ROTOR ASSEMBLY	72-0038
US	86-07-13	FOURTH STAGE COMPRESSOR VANE ASSEMBLIES	ALF502L-72-0137
US	87-15-03	GAS PRODUCER SPACER	ALF502L-72-0163
US	91-14-05	THIRD STAGE HIGH COMPRESSOR ROTOR DISKS	ALF 502L 72-203R3
US US	93-10-07	THIRD STAGE COMPRESSOR DISKS THIRD STAGE TURBINE DISK	ALF502L 72-259
US	93-14-13 95-04-11	THIRD STAGE TURBINE DISK	ALF502L 72-270 ALF502 72-0004R11
US	97-05-11R1	OIL FILTER BYPASS VALVE	502L-79-0171
US	97-11-05	INSPECTION OF FUEL MANIFOLD ASSEMBLY	ALF/LF 73-1002
ALF-50		( ALF-502L SERIES )	
US	96-04-02	COMPRESSOR AND TURBINE DISK REMOVAL FROM SERVICE	ALF 502 72-0004R12
ALF-50	<b>SERIES</b> 83-03-51	4TH STAGE TURBINE ROTOR ASSEMBLY	72-0038
US	87-15-03	GAS PRODUCER SPACER	ALF502R-72-0163
US	90-24-01	THIRD STAGE HIGH COMPRESSOR DISKS	ALF502R-72-0163 ALF502R-72-203R2
US	92-08-51	MODIFICATION/REWORK ENGINE FUEL CONTROLS (BAE146)	
US	93-10-07	THIRD STAGE COMPRESSOR DISKS	ALF502R 72-259
US	93-14-13	THIRD STAGE TURBINE DISK	ALF502R 72-270
US	95-03-15	TURBINE DISK / COMPRESSOR ROTOR DISKS	ALF502R 72-281
US	95-04-11	THIRD STAGE TURBINE DISK	ALF502 72-0002R22
US US	97-05-11R1 97-11-05	OIL FILTER BYPASS VALVE INSPECTION OF FUEL MANIFOLD ASSEMBLY	502R-79-0160R1,-016 ALF/LF 73-1002
ALF-50		( ALF-502R SERIES )	
US	99-15-06	UNCOMMANDED REDUCTION OF ENG THRUST DUE ICING	ALF/LF 72-1020R2
M337 S	ERIES		
M337 S		( M337 SERIES )	
M337 S		( M337 SERIES )  PISTON PIN BEARING	505-05
M337 S M337AK BOMBARD 501 AS	DIER ROTAX		505-05
M337 S M337AK BOMBARD 501 AS 505	OIER ROTAX	PISTON PIN BEARING	
M337 S M337AK BOMBARD 501 AS	DIER ROTAX		505-05 505-05 505-06
M337 S M337AK BOMBARD 501 AS 505 AS AS 912 A	64 64 69 SERIES	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX	505-05
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS	64 64 69 SERIES	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING	505-05 505-06 912-02R1
M337 S M337AK BOMBARD 501 AS 505 AS AS AS 912 A AS AS	64 69 SERIES 75	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION	505-05 505-06 912-02R1 912-06
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS	64 64 69 SERIES 75 80 82	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED	505-05 505-06 912-02R1 912-06 912-07
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION	505-05 505-06 912-02R1 912-06 912-07 912-09
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION	505-05 505-06 912-02R1 912-06 912-07 912-09
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08 912-18R1
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING    IGNITION UNIT - GROUNDING CABLE LUG CONNECTION    SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED    INSPECT CARBURETOR FOR CONTAMINATION    SMD - IGNITION UNITS    HARDNESS CHECK OF CAMSHAFT    FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08 912-18R1
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION  SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED  INSPECT CARBURETOR FOR CONTAMINATION  SMD - IGNITION UNITS  HARDNESS CHECK OF CAMSHAFT  FUEL PUMP & STEEL FUEL LINE	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08 912-18R1
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08 912-18R1 912-20R1
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08 912-18R1 912-20R1
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )  PROPELLER GEARBOX	505-05 505-06 912-02R1 912-06 912-07 912-08 912-18R1 912-20R1 912-19
M337 S M337AK BOMBARD 501 AS 505 AS AS AS 912 A AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES ) PROPELLER GEARBOX	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08 912-18R1 912-20R1
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )  PROPELLER GEARBOX	505-05 505-06 912-02R1 912-06 912-07 912-08 912-18R1 912-20R1 912-19
M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )  PROPELLER GEARBOX	505-05 505-06 912-02R1 912-06 912-07 912-09 912-08 912-18R1 912-20R1 912-19
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	64 64 69 SERIES 75 80 82 83 84 92/1 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )  PROPELLER GEARBOX	505-05 505-06 912-02R1 912-06 912-07 912-08 912-18R1 912-20R1 912-19
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	91ER ROTAX 64 64 69 SERIES 75 80 82 83 84 92/1 94/1 89 94/1 95 HERCULES	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )  PROPELLER GEARBOX	505-05 505-06 912-02R1 912-06 912-07 912-08 912-18R1 912-20R1 912-19
M337 S M337AK BOMBARD 501 AS 505 AS AS AS AS AS AS AS AS AS AS AS AS AS	91ER ROTAX 64 64 69 SERIES 75 80 82 83 84 92/1 94/1 89 94/1	PISTON PIN BEARING  PISTON PIN BEARING  DUCATI 965675 - ELECTRONIC IGNITION BOX  STATOR & IGNITER HOUSING  IGNITION UNIT - GROUNDING CABLE LUG CONNECTION SMD IGNITION SYSTEM - RADIO XMISSION EFFECTED INSPECT CARBURETOR FOR CONTAMINATION SMD - IGNITION UNITS HARDNESS CHECK OF CAMSHAFT FUEL PUMP & STEEL FUEL LINE  ( 912 A SERIES )  ( 912 A SERIES )  PROPELLER GEARBOX	505-05 505-06 912-02R1 912-06 912-07 912-08 912-18R1 912-20R1 912-19

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
CFM INTERNATIONAL		
CFM56-3 SERIES		
(CONTINUED / SUITE) FR 94-195(B)	EAN DISK LIFE LIMITS	
FR 97-010(B)R1	FAN DISK LIFE LIMITS LIFE LIMITS LOW PRESSURE TURBINE	72-695
FR 97-298(B)R2	FAN DISK INSPECTION	72-855 72-854R1
FR 97-327(B) FR 98-080(B)R1	HIGH PRESSURE TURBINE DISK	72-843
FR 98-096(B)	HPC STG 1 & 2 SPOOLS / # 3 BEARING AIR/OIL SEAL ACCESSORY GEARBOX AND TRANSFER GEARBOX	72-855 & 72-856 72-863R1
FR 98-198(B)R1	ACCESSORY GEARBOX (AGB)	72-877R1
FR 1999-245(B)R1	INSP OF FUEL FILTER COVER ATTACHMENT PARTS	CFM56- ND.73-A129
CFM56-3C	( CFM56-3 SERIES )	
US 96-25-11	STAGE 1 FAN DISK	72-543
CFM56-5 SERIES	10.000	
FR 89-181(B)R3 FR 94-272(B)R3	#3 BEARING INSPECTION OF HIGH PRESSURE COMPRESSOR ROTOR	72-440,72-064,72-229
FR 97-010(B)R1	LP TURBINE STUB SHAFT AND CONICAL SUPPORT	72-440,72-064,72-229
US 96-18-16 US 97-05-13	LOW PRESSURE TURBINE ROTOR (LPTR) STUB SHAFT AIR STARTER	72-338
US 97-06-01	HIGH PRESSURE COMPRESSOR ROTOR	80-003 72-440,-064,-229
CFM56-5A1	( CFM5G-5 SERIES )	
FR 94-099(B)	AIR STARTER	80-003
FR 98-334(B)	LIFE LIMITS FOR HPT FRONT AIR SEALS	
CFM56-5A3	( CFM56-5 SERIES )	
FR 94-099(B) FR 98-334(B)	AIR STARTER LIFE LIMITS FOR HPT FRONT AIR SEALS	80-003
` '		
CFM56-5A5 FR 98-334(B)	( CFM56-5 SERIES ) LIFE LIMITS FOR HPT FRONT AIR SEALS	
CFM56-5C4	( CFM56-5 SERIES )	
FR 97-199(B)	REDUCTION OF TURBINE ROTOR LIFE LIMITS	
FR 97-354(B)R4	CANCELLATION OF DGAC AD 97-354(B)R3	VARIOUS
FR 1998-427(B)R2 FR 1998-546(B)R2		VARIOUS CFMI SB 78-A057
FR 98-097(B)	ACCESSORY GEARBOX AND TRANSFER GEARBOX	72-350R1
CURTISS WRIGHT		
CURTISS OX-5		
R-540A		
R-760E-2		
R-975E-3		
R-1300 SERIES		
	( p. 4000 CERTEC )	
R-1300-3D	( R-1300 SERIES )	
R-1820 SERIES US 51-12-01	PISTON PINS	C9-156A
R-1820-56A	( R-1820 SERIES )	
R-1820-80	(R-1820 SERIES )	
R-1820-99	( R-1820 SERIES )	
R-1820-103 US 60-07-08	(R-1820 SERIES ) MASTER ROD ASSEMBLY	C9-353
R-1820-G202A	( R-1820 SERIES )	
R-2600-20		
R-2600-29A		
R3350-24WA		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
CURT I 55 982C9H	WRIGHT		
989C9H	E2		
DEHAVIL	L AND		
GIPSY	MAJOR SERIES 33-1	INSPECTION OF WOODEN PROPELLER HUBS FOR FRACTURES	
CF	34-1	INSPECTION OF WOODEN PROPELLER HUB FLANGES	
CF	CF-74-01	TAPERED FRONT END CRANKSHAFT	
GIPSY	MAJOR	( GIPSY MAJOR SERIES )	
		( GIPSY MAJOR SERIES )	
GIPSY	MAJOR 1C	( GIPSY MAJOR SERIES )	
GIPSY	MAJOR 1F	( GIPSY MAJOR SERIES )	
GIPSY	MAJOR 10	( GIPSY MAJOR SERIES )	
GIPSY	MAJOR 10 MK1	( GIPSY MAJOR SERIES )	
GIPSY	MAJOR 10 MK1-	B( GIPSY MAJOR SERIES )	
GIPSY	MAJOR 10 MK2-	( GIPSY MAJOR SERIES )	
GIPSY	QUEEN 2		
GIPSY	QUEEN 3		
FAIRCHI			
	<b>C SERIES</b> 52-03-01	PISTON MODIFICATION	
US	54-09-01	CARBURETOR HOTSPOT HEATER ASSEMBLY	91
6-440-	C2	( 6-440-C SERIES )	
6-440-	C5	( 6-440-C SERIES )	
FRANKLI 4A4-10			
2A-120	-B		
2A-120	-c		
	O SERIES	CVI INDED DACE ELANCE	
	48-50-01 0-83		69
6A4-15		( GA4-150 SERIES ) ( GA4-150 SERIES )	
6A4-16			
	51-15-02	CRANKCASE ASSEMBLY	10
6A4-16			
4AC-17	6-BA2		
4AC-17			
4AC-19			
<b>6V4-20</b> US	<b>0-C32</b> 51-28-02	OIL PUMP GEARS	86
6A8-21	5-B8F		
6A8-21	5-B9F		
4A-235	-B		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

ED ANIVI TH		
FRANKLIN 6A-335-B		
6AS-335-B		
6V-335-A1A		
6V-335-B		
6VS-335-A		
6A-350 SERIES		
6A-350-C1	( 6A-350 SERIES )	
6A-350-C2	( 6A-350 SERIES )	
0-425-9		
GARRETT		
ATF3-6A-4C		
US 84-20-51	EXHAUST DEFLECTER LINER AND SEAL ASSEMBLIES	ATF3-72-6092
US 94-23-04	INSPECTION FOR CRACKS IN HPT ROTOR ASSEMBLY	ASB ATF3-A72-6184
TPE331-3 SERIES		
US 73-26-07R3	FUEL PUMP SHAFT	TPE331-72-0027R4
US 74-10-10 US 74-24-05	BRACKETS - FUEL CONTROL ASSEMBLY	TPE331-73-0028
US 75-10-05	PIN - PROPELLER PITCH CONTROL SLEEVE ASSEMBLY TORQUE SENSOR ASSEMBLY ARM	TPE331-3U-303G 606R7
US 76-16-01	HIGH SPEED PINION BEARING TUBES	TPE331-72-0092
US 78-05-02	PROPELLER PITCH CONTROL SLEEVE ASSEMBLY	TPE331-72-0115R1
US 78-25-08R3	MAIN REDUCTION GEAR DRIVE	TPE331-72-0061R1
US 84-01-04 US 84-10-06R1	THIRD STAGE TURBINE WHEEL	TPE331-72-0351
US 89-07-07R1	FUEL CONTROL / PUMP ASSEMBLY TURBINE DIL SCAVENGE PUMP	TPE331-73-0121R3 331-72-0533R2
US 92-26-08	THIRD STAGE STATOR ASSEMBLIES	NF331-A72-11921
US 93-05-09	INNER SEAL SUPPORT - 3RD STAGE TURBINE STATOR	TPE331-A72-0384R3,R4
US 93-15-11	PROPELLER PITCH CONTROL GASKET	TPE331-A72-0857,0858
US 94-09-08 US 94-26-07	THIRD STAGE TURBINE WHEELS FUEL CONTROL GOVERNOR DRIVE	ASB TPE331-A72-0906 ASB TPE331-A73-0226
US 95-16-08	REVIEW OF MAINTENANCE RECORDS	ASB 1PE331-A73-0226
US 97-15-10	REVISION TO AFM OR PILOT'S OPERATING HANDBOOK	TPE331-73-0236
TPE331-3U	( TPE331-3 SERIES )	
US 98-04-15	THIRD STAGE TURBINE ROTOR	NF-TPE331-A72-10961
TPE331-3U-304G	( TPE331-3 SERIES )	
US 98-04-15	THIRD STAGE TURBINE ROTOR	NF-TPE331-A72-10961
TPE331-3UW	( TPE331-3 SERIES )	
US 98-04-15		NF-TPE331-A72-10961
TPE331-3UW-303G	( TPE331-3 SERIES )	
US 98-04-15	THIRD STAGE TURBINE ROTOR	NF-TPE331-A72-10961
TPE331-5 SERIES		
US 73-26-07R3	FUEL PUMP SHAFT	TPE331-72-0027R4
US 74-10-10	BRACKETS - FUEL CONTROL ASSEMBLY	TPE331-73-0028
US 74-24-05 US 75-10-05	PIN - PROPELLER PITCH CONTROL SLEEVE ASSEMBLY TORQUE SENSOR ASSEMBLY ARM	TPE331-5-251C 606R7
US 76-16-01	HIGH SPEED PINION BEARING TUBES	TPE331-72-0092
US 78-05-02	PROPELLER PITCH CONTROL SLEEVE ASSEMBLY	TPE331-72-0115R1
US 78-25-08R3	MAIN REDUCTION GEAR DRIVE	TPE331-72-0061R1
US 84-01-04	THIRD STAGE TURBINE WHEEL FUEL CONTROL / PUMP ASSEMBLY	TPE331-72-0351 TPE331-73-0121R3
US 84-10-06R1 US 89-07-07R1	TURBINE OIL SCAVENGE PUMP	331-72-0533R2
US 92-26-08	THIRD STAGE STATOR ASSEMBLIES	NF331-A72-11921
US 93-05-09	INNER SEAL SUPPORT - 3RD STAGE TURBINE STATOR	TPE331-A72-0384R3,R4
US 93-15-11	PROPELLER PITCH CONTROL GASKET	TPE331-A72-0857,0858
US 94-09-08	THIRD STAGE TURBINE WHEELS FUEL CONTROL GOVERNOR DRIVE	ASB TPE331-A72-0906 ASB TPE331-A73-0226
US 94-26-07 US 95-16-08	REVIEW OF MAINTENANCE RECORDS	A30 11 C001 A70 0220
US 97-15-10	REVISION TO AFM OR PILOT'S OPERATING HANDBOOK	TPE331-73-0236
US 98-04-15	THIRD STAGE TURBINE ROTOR	NF-TPE331-A72-10961

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SÉRIE)
SUBJECT
SUJET

GARRETT TPE331-5	( TPE331-5 SERIES )	
TPE331-5-251K	( TPE331-5 SERIES )	
TPE331-5-252M	( TPE331-5 SERIES )	
TPE331-6 SERIES US 73-26-07R3 US 74-10-10 US 74-24-05 US 75-10-05 US 76-16-01 US 78-05-02 US 78-25-08R3 US 84-01-04 US 84-01-04 US 89-07-07R1 US 92-26-08 US 93-15-11 US 94-09-08 US 94-26-07 US 95-16-08 US 97-15-10 US 98-04-15	FUEL PUMP SHAFT BRACKETS - FUEL CONTROL ASSEMBLY PIN - PROPELLER PITCH CONTROL SLEEVE ASSEMBLY TORQUE SENSOR ASSEMBLY ARM HIGH SPEED PINION BEARING TUBES PROPELLER PITCH CONTROL SLEEVE ASSEMBLY MAIN REDUCTION GEAR DRIVE THIRD STAGE TURBINE WHEEL FUEL CONTROL / PUMP ASSEMBLY TURBINE OIL SCAVENGE PUMP THIRD STAGE STATOR ASSEMBLIES INNER SEAL SUPPORT - 3RD STAGE TURBINE STATOR PROPELLER PITCH CONTROL GASKET THIRD STAGE TURBINE WHEELS FUEL CONTROL GOVERNOR DRIVE REVIEW OF MAINTENANCE RECORDS REVISION TO AFM OR PILOT'S OPERATING HANDBOOK THIRD STAGE TURBINE ROTOR	TPE331-72-0027R4 TPE331-73-0028 TPE331-6-251M 606R7 TPE331-72-0092 TPE331-72-0061R1 TPE331-72-0051 TPE331-73-0121R3 331-72-05382 NF331-A72-0384R3, R4 TPE331-A72-0857, 0858 ASB TPE331-A72-0906 ASB TPE331-A73-0226  TPE331-73-0236 NF-TPE331-A72-10961
TPE331-6	( TPE331-6 SERIES )	
TPE331-6-252B	( TPE331-6 SERIES )	
TPE331-6-252M	( TPE331-6 SERIES )	
TPE331-6-252T	( TPE331-6 SERIES )	
TPE331-8 SERIES US 89-07-07R1 US 93-02-01 US 93-15-11 US 95-16-08 US 98-12-09	TURBINE OIL SCAVENGE PUMP STRATOFLEX FUEL MANIFOLD ASSEMBLIES PROPELLER PITCH CONTROL GASKET REVIEW OF MAINTENANCE RECORDS FUEL MANIFOLD	331-72-0533R2 TPE331-A73-0198R1 TPE331-A72-0857,0858
TPE331-8	( TPE331-8 SERIES )	
TPE331-8-403S	( TPE331-8 SERIES )	
TPE331-10 SERIES  US 84-10-06R1  US 88-12-10  US 89-07-07R1  US 93-02-01  US 93-15-11  US 94-26-07  US 95-16-08  US 97-15-10  US 98-12-09	FUEL CONTROL / PUMP ASSEMBLY 2ND STAGE TURBINE ROTOR TURBINE OIL SCAVENGE PUMP STRATOFLEX FUEL MANIFOLD ASSEMBLIES PROPELLER PITCH CONTROL GASKET FUEL CONTROL GOVERNOR DRIVE REVIEW OF MAINTENANCE RECORDS REVISION TO AFM OR PILOT'S OPERATING HANDBOOK FUEL MANIFOLD	TPE331-73-0121R3 TPE331-A72-0571 331-72-0533R2 TPE331-A73-0198R1 TPE331-A72-0857,0858 ASB TPE331-A73-0226 TPE331-73-0235
TPE331-10 US 79-12-04	( TPE331-10 SERIES ) THIRD STAGE TURBINE WHEEL	
TPE331-10-511M	( TPE331-10 SERIES )	
TPE331-10N-512S	( TPE331-10 SERIES )	
TPE331-10R-511	( TPE331-10 SERIES )	
TPE331-10T	( TPE331-10 SERIES )	
TPE331-10UA	( TPE331-10 SERIES )	
TPE331-10UA-511G	( TPE331-10 SERIES )	
TPE331-10UGR	( TPE331-10 SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
GARRETT		
TPE331-10UGR-514H	( TPE331-10 SERIES )	
THE COLIN TOOLIN STAIN	( IFESSI-10 SEKIES )	
TPE331-11 SERIES		······································
US 84-10-06R1	FUEL CONTROL / PUMP ASSEMBLY	TPE331-73-0121R3
US 88-12-10	2ND STAGE TURBINE ROTOR	TPE331-A72-0571
US 89-07-07R1	TURBINE OIL SCAVENGE PUMP	331-72-0533R2
US 93-02-01	STRATOFLEX FUEL MANIFOLD ASSEMBLIES	TPE331-A73-0198R1
US 93-15-11 US 94-26-07	PROPELLER PITCH CONTROL GASKET	TPE331-A72-0857,0858
US 94-26-07 US 95-16-08	FUEL CONTROL GOVERNOR DRIVE	ASB TPE331-A73-0221
US 97-15-10	REVIEW OF MAINTENANCE RECORDS	
US 98-12-09	REVISION TO AFM OR PILOT'S OPERATING HANDBOOK FUEL MANIFOLD	TPE331-73-0235
00 00 12 00	TOCK MANIFOLD	
TPE331-11	( TPE331-11 SERIES )	
TPE331-11U	( TPE331-11 SERIES )	
TPE331-11U-611G	( TPE331-11 SERIES )	
TDE224-44U C40C		
TPE331-11U-612G	( TPE331-11 SERIES )	
TPE331-12 SERIES		
US 93-02-01	STRATOFLEX FUEL MANIFOLD ASSEMBLIES PROPELLER PITCH CONTROL GASKET	TPE331-A73-0198R1
US 93-15-11	PROPELLER PITCH CONTROL GASKET	TPE331-A73-0198R1 TPE331-A72-0857,0858
US 94-26-07	FUEL CONTROL GOVERNOR DRIVE	ASB TPE331-A73-0226
US 95-16-08	REVIEW OF MAINTENANCE RECORDS	
US 97-15-10	REVISION TO AFM OR PILOT'S OPERATING HANDBOOK	TPE331-73-0235
US 98-12-09	FUEL MANIFOLD	
**************************************	( )	
IPE331-12UAR-701H	( TPE331-12 SERIES )	
TPE331-12UHR	( TPE331-12 SERIES )	
17 L 3 3 1 1 2 0 1 1 K	( IFE351-12 SERIES )	
TPE331-14 SERIES		
	······································	
TPE331-14GR-805H	( TPE331-14 SERIES )	
TFE731-2 SERIES		
US 74-11-06	ENGINE FUEL CONTROL COMPUTER	TFE731-76-3002
US 74-13-09 US 74-18-16	FUEL PUMP	TFE731-73-3004
US 74-18-16	FUEL CONTROL COMPUTER FUEL PUMPS	TFE731-A76-3005 TFE731-73-3005
US 75-07-10	GEAR BOX VERTICAL BEVEL GEAR BEARING SUPPORT	TFE731-72-3019
US 78-22-10	LOW PRESSURE ROTOR THRUST BALL BEARING	112701 72 0010
US 80-16-04	TIE ROD	TFE731-72-3105, 3106
US 81-24-08	TURBINE INTERSTAGE TRANSITION DUCT	TFE731-72-3159
US 82-23-03R1	HIGH PRESSURE COMPRESSOR IMPELLER	TFE731-72-3239RWK
US 86-03-01	TURBINE INTERSTAGE TRANSITION DUCTS	TFE731-72-3309R1
US 89-22-16	DIGITAL ELECTRONIC ENGINE CONTROLS (DEEC)	TFE731-76-3049
US 90-24-06	THERMOCOUPLE LEAD ASSEMBLIES	TFE731-A77-3020
US 92-21-06 US 96-04-01	LOW PRESSURE TURBINE (LPT) ROTOR DISKS FAN DISK FATIGUE CRACKING	TFE731-A72-3474 ASB TFE731-A72-3504
US 96-04-01 US 96-05-03	FIRST STAGE FAN ROTOR DISC	TFF731-A72-3432
US 96-18-13	FAN ROTOR DISK DOVETAIL SLOTS	TFE731-A72-3569
US 98-17-01R1	FLEXIBLE FUEL TUBE	A73-3132, -3128
25 17 0111		
TFE731-2	( TFE731-2 SERIES )	
US 86-11-05	FAN ROTOR DISC	TFE731-A72-3328R2
US 97-04-03	LPT SEAL PLATES	TFE731-72-3573
TEE 201 0 00	( TETTO ( 0 CEDIFC )	
TFE731~2-2B	( TFE731-2 SERIES )	172-2006
US 74-18-12	HYDROMECHANICAL FUEL CONTROL ORFICE ASSEMBLY	A73-3006
TFE731-2-1C	( TFE731-2 SERIES )	
	( I LI J L J LIVE )	
TFE731-3 SERIES		
US 75-07-10	GEAR BOX VERTICAL BEVEL GEAR BEARING SUPPORT	TFE731-72-3019
US 78-22-10	LOW PRESSURE ROTOR THRUST BALL BEARING	
US 80-16-04	TIE ROD	TFE731-72-3105, 3106
US 81-24-08	TURBINE INTERSTAGE TRANSITION DUCT	TFE731-72-3159
US 82-23-03R1	HIGH PRESSURE COMPRESSOR IMPELLER	TFE731-72-3239RWK
US 86-03-01	TURBINE INTERSTAGE TRANSITION DUCTS	TFE731-72-3309R1
US 88-18-03	HIGH PRESSURE TURBINE ROTAR (HTPR) DISC	TFE731-A72-3376 TFE731-A72-3388
US 90-03-04	HIGH PRESSURE TURBINE ROTOR DISCS	IFE/31-A/2-3388

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONS	(SERIES / SERIE) SUBJECT SIGNE SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
GARRETT TFE731-3 SERIES (CONTINUED / SUTTE US 90-24-06 US 92-21-06 US 94-07-03 US 95-07-02 US 96-05-03 US 96-18-13 US 98-17-01R1	THERMOCOUPLE LEAD ASSEMBLIES LOW PRESSURE TURBINE (LPT) ROTOR DISKS FIRST STAGE LOW PRESSURE TURBINE NOZZLES FIRST & SECOND STAGE LPT DISKS FIRST STAGE FAN ROTOR DISC FAN ROTOR DISK DOVETAIL SLOTS	TFE731-A77-3020 TFE731-A72-3474 VARIOUS TFE731-A72-3544,3557 TFE731-A72-3432 TFE731-A72-3569 A73-3132, -3128
TFE731-3 US 86-11-05 US 94-23-05 US 96-04-01	( TFE731-3 SERIES ) FAN ROTOR DISC 1ST & 2ND STAGE LOW PRESSURE TURBINE DISK FAN DISK FATIGUE CRACKING	TFE731-A72-3328R2 TFE731-A72-3544 ASB TFE731-A72-3504
TFE731-3-1C	( TFE731-3 SERIES )	
TFE731-3-1G US 96-04-01	( TFE731-3 SERIES ) Fan disk fatigue Cracking	ASB TFE731-A72-3504
TFE731-3-1H US 96-04-01	( TFE731-3 SERIES ) FAN DISK FATIGUE CRACKING	ASB TFE731-A72-3504
TFE731-3AR US 94-23-05	( TFE731-3 SERIES ) 1ST & 2ND STAGE LOW PRESSURE TURBINE DISK	TFE731-A72-3544
TFE731-3C US 96-05-03 US 97-04-03	( TFE731-3 SERIES ) FIRST STAGE FAN ROTOR DISC LPT SEAL PLATES	TFE731-A72-3432 TFE731-72-3573
TFE731-3R US 86-11-05 US 96-04-01	( TFE731-3 SERIES ) FAN ROTOR DISC FAN DISK FATIGUE CRACKING	TFE731-A72-3328R2 ASB TFE731-A72-3504
TFE731-3R-1H	( TFE731-3 SERIES )	
TFE731-5 SERIES US 89-22-16 US 90-24-06		TFE731-76-3049 TFE731-A77-3020
TFE731-5BR	( TFE731-5 SERIES )	
TFE731-5R	( TFE731-5 SERIES )	
TFE731-5R-1H	( TFE731-5 SERIES )	
TFE731-20R		
TFE731-40 SERIE		
TFE731-40R-200G US 98-10-15 US 99-07-19	( TFE731-40 SERIES )  REPLACEMENT OF FUEL LINE FUEL FLOW TUBE ASSEMBLY	TFE731-A73-5111 ASB TFE731-A73-5119
GENERAL ELECTRIC CT7-9B		
US 94-17-16 US 96-26-01 US 97-25-07	ULTRASONIC INSPECTION OF PROP SHAFT FLANGE GGT STAGE 2 FORWARD COOLING PLATE 1ST OR 2ND GAS GENERATOR TURBINE DISK	A72-350R3 A72-381 A72-393, 72-390R1
CT58-140 SERIES US 74-25-01 US 79-23-04 US 93-10-09 US 94-07-05 US 97-19-17	FUEL FILTER TO FLOW DIVIDER  OPERATING CYCLES LIFE LIMITED ROTATING COMPO STAGE 1 & 2 HIGH PRESSURE TURBINE (HPT) DISK STAGE 1 AND 2 TURBINE WHEELS INSPECTION OF CRITICAL ROTATING PARTS	S 72-126R1, SAA 206 A72-126
CT58-140-1 US 64-26-02 US 67-01-02 US 69-17-03 US 69-23-02 US 76-13-02 US 78-26-08	( CT58-140 SERIES ) STARTER DRIVE SHAFT BEARING FIRST STAGE COMPRESSOR ROTOR DISC FIRST AND SECOND STAGE TURBINE ROTOR DISCS SECOND STAGE COMPRESSOR ROTOR DISC SHAFT OIL COOLER - TO - FUEL FILTER HOSE LUBE AND SCAVENGE PUMPS	141 , 80-2 A73-69 A72-157

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

CAIGINE NOIMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
OFNERAL FLECTRIO		
GENERAL ELECTRIC	( 0750	
CT58-140-1	( CT58-140 SERIES )	
(CONTINUED / SUITE)	07107	
US 81-02-02 US 81-18-03	STAGE ONE TURBINE WHEEL	A72-159, CEB 255
	FUEL CUNTRULS / LEAD LAG SERVO HOUSING	A73-71. CEB 261R1
	GAS GENERATOR TURBINE ROTOR & POWER TURBINE WHEELS	CT58-A72-173
US 97-21-08	STAGE 1&2 FORWARD AND STAGE 2 AFT COOLING PLATES	72-188R1
CF6-50 SERIES		
US 79-13-09	HIGH ODECOMES ASSESSED TO THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OWNER OF THE OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNER OWNE	
US 82-20-03	HIGH PRESSURE COMPRESSOR ROTOR SPOOLS	
US 82-20-03 US 82-25-08	FIRST STAGE HIGH PRESSURE TURBINE DISKS	72-700, 72-709
US 84-01-01	HIGH PRESSURE TURBINE SPACER / IMPELLER	72-748
US 85-25-56R1	COMPRESSOR CASE / INLET STATOR VANES / BLADES	72-549, -550, -551
US 86-12-03	LPT COOLING AIR MANIFOLD TUBE	75-54, -55, -58
US 87-23-06		A72-859R1
US 89-01-02	HIGH PRESSURE TURBINE IMPELLER SPACER	72-906
US 90-12-06	HIGH PRESSURE TURBINE - STAGE 2 DISKS LOW PRESSURE TURBINE - VENT TUBE EXTENSION ASSY	72-947
US 90-19-09	HIGH PRESSURE TURBINE STAGE #1 DISKS	72-395R3
US 90-23-15	TUDDINE MID EDAME (TME) CDACKS	72-966
US 91-01-04	TURBINE MID FRAME (TMF) CRACKS STAGE 1 FAN DISKS	72-957R2
IIS 91-10-03P1	HIGH PRESSURE COMPRESSOR REAR SHAFT	70-05904
US 91-15-16		72-958R1
US 91-23-13	HIGH PRESSURE TURBINE THERMAL SHIELDS STAGE 1 FAN DISKS	
US 93-13-10	12 STAGE COMPRESSOR DISK	72-1006B1
US 93-13-10	HIGH PRESSURE TURBINE (HPT) THERMAL SHIELD	72-1006R1
US 94-08-05		72-1021R1
US 94-08-05 US 94-09-18	STAGE 1 OR 2 HIGH RESSURE TURNING AND SHROUD	72-1002 72-100201
US 95-08-03	STAGE 1 OR 2 HIGH PRESSURE TURBINE DISK FAILURE HIGH PRESSURE TURBINE ROTOR STAGE 2 DISK	72-1002, 72-1003R1
US 95-17-15		72-1069R2
	INSPECTION OF SIDE LINKS	72-1092R1
US 95-18-14	HIGH PRESSURE COMPRESSOR ROTOR (HPCR) - FPI	72-A1139
US 97-22-14 US 98-22-06	HIGH PRESSURE COMPRESSOR ROTOR 3-9 SPOOL FAN DISK	
	1111 - 1111	ASB 72-A988R6
US 99-08-18	TIME LIMITS ON CRITICAL ROTATING PARTS	AC CDEOTETED THE AD
US 99-18-20	TO PREVENT INADVERTENT THRUST REVERSER DEPLOY	AS SPECIFIED IN AD
US 99-24-15	PREVENT HPCR STAGE 3-9 SPOOL CRACKING/SEPARATION	VARIOUS
CF6-50C2	( CF6-50 SERIES )	
CF6-50C2	( Cro-50 SERIES )	
CF6-80C2 SERIES		
US 90-26-01	FUEL MANIFOLDS	73-053R3
US 91-11-05	HIGH PRESSURE COMPRESSOR ROTOR STAGE 11-14 SPOOLS	
	HIGH PRESS COMPRESSOR ROTOR - STAGES 11-14 SHAFTS	72-130P2
US 91-15-25 US 91-20-02	INSPECTION & REPLACEMENT OF RH & LH FUEL MANIFOLDS	73-114R2 -115R1
US 93-14-18		72-565R1
US 94-06-03	1ST STAGE HIGH DRESSURE TURRINE (HPT) DISK	72-614R1
US 94-20-06		72-628,72-648,72-095
US 95-10-11	INSPECTION OF CENTER DRIVE UNIT BRAKE	78-1002R1
US 95-18-14	HIGH PRESSURE COMPRESSOR ROTOR (HPCR) - FPI	75 100211
US 96-16-07	INSPECTION OF R/H REAR MOUNT LINK	72-835R1
US 96-16-07 US 97-22-14	HIGH PRESSURE COMPRESSOR ROTOR 3-9 SPOOL	72-A906
US 98-22-06	FAN DISK	ASB 72-A478R4
	ACCESSORY GEARBOX IDLER ADAPTERS	ASB 73-A283R2
	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS	NOU TO RECORE
US 99-08-13	PREVENT HPCR STAGE 3-9 SPOOL CRACKING/SEPARATION	VARIOUS
US 99-24-15	PREVENT HECK STAGE 3-9 SPULL CRACKING/ SEPARATION	
CEC-90C2	( CEG-BOC2 SEDIES )	
CF6-80C2	( CF6-80C2 SERIES ) HIGH PRESSURE TURBINE STAGE ,1 SHROUD	72-473R1
US 91-05-21	HIGH PRESSURE TURDING STAGE ! SHKOOD	12 47011
CF6-80C2A2	( CF6-80C2 SERIES )	
		ASB78A1081/78A4022
US 99-18-19		AS SPECIFIED IN AD
US 99-18-20	IN PREVENT INADVERTENT THRUST REVERSER DEPLOY	AS SI LOTI IED IN AD
CEC 8000015	( CF6-80C2 SERIES )	
CF6-80C2B1F	( CF6-80C2 SERIES )	
050 000055	( OFC BOCO CERTEC )	
CF6-80C2B6	( CF6-80C2 SERIES ) HIGH PRESSURE TURBINE STAGE 1 SHROUD	72-473R1
US 91-05-21	HIGH PRESSURE TURBINE STAGE I SHRUUD	12 4/3K1
050 0000555	( ofc poco serves )	
CF6-80C2B6F	( CF6-80C2 SERIES )	72-473R1
US 91-05-21	HIGH PRESSURE TURBINE STAGE 1 SHROUD	72 475KT
050 00544		
CF6-80E1A4	ODITICAL LICE LIMITED ENGINE DOTATING DARTS	
US 99-08-13	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS	VARIOUS
US 99-24-15	PREVENT HPCR STAGE 3-9 SPOOL CRACKING/SEPARATION	VARIOUS

MODEL / MC	TRUCTEUR DELE AD NUMBER NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
CF34-1	ELECTRIC		
US	88-06-07	FUEL CONTROL	73-5, 73-6
US	97-06-14	FAN DISKS	
US	97-06-15	STAGE 1 ROTOR DISK	
US	99-22-10	TO PREVENT HPC SPOOL AND DISC CRACKING	.50 005 / /50
US	99-23-26	UNCOMMANDED ENGINE ACCELERATION	A73-32R1/R2
CF34-3			70 5 70 6
	88-06-07	FUEL CONTROL	73-5, 73-6
US	97-06-14	FAN DISKS STAGE 1 ROTOR DISK	
US US	97-06-15 99-22-10	TO PREVENT HPC SPOOL AND DISC CRACKING	
US	99-23-26	UNCOMMANDED ENGINE ACCELERATION	A73-32R1/R2
CF34-3	A 1		
US US	99-22-10	TO PREVENT HPC SPOOL AND DISC CRACKING	
US	99-23-26	UNCOMMANDED ENGINE ACCELERATION	A73-32R1/R2
CF34-3	Δ2		
US	97-06-14	FAN DISKS	
US	97-06-15	STAGE 1 ROTOR DISK	
US	99-22-10	TO PREVENT HPC SPOOL AND DISC CRACKING	
US	99-23-26	UNCOMMANDED ENGINE ACCELERATION	A73-32R1/R2
CF34-3	В		
US	99-23-26	UNCOMMANDED ENGINE ACCELERATION	A73-32R1/R2
CF34-3	B1		
US	99-23-26	UNCOMMANDED ENGINE ACCELERATION	A73-32R1/R2
CF700-	2D-2		
US	75-05-13	COMPOUND TURBINE AND FAN BLADES	A72-124, -125
ŲS	75-19-05	ACCESSORY DRIVE HORIZONTAL DRIVE SHAFT	A72-130
US	78-07-06	COMPRESSOR DISKS	A72-140
US	80-08-06R1	TURBINE DISKS	A72-142
US	85-18-03	FIRST STAGE TURBINE DISK	A72-145 72-154
	97-13-10	REPLACEMENT OF FAN GUARDS REMOVAL OF TURB TORQUE RINGS - COMP DRIVE SHAFTS	
US US	97-25-08 98-23-06	COMBUSTOR LINER	A72 100
<b>CJ610</b> -	<b>6</b> 73-23-05	FIRST AND SECOND STAGE TURBINE DISCS	A72-70, -80
US	78-07-06	COMPRESSOR DISKS	A72-130
US	97-25-08	REMOVAL OF TURB TORQUE RINGS - COMP DRIVE SHAFTS	
US	98-23-06	COMBUSTOR LINER	
CJ610-	R Λ		
US	80-08-06R1	TURBINE DISKS	A72-135
US	85-18-03	FIRST STAGE TURBINE DISK	A72-142
US	97-25-08	REMOVAL OF TURB TORQUE RINGS - COMP DRIVE SHAFTS	A72-147
US	98-23-06	COMBUSTOR LINER	
GL <i>ADDEN</i> KINNER	PRODUCTS B-5		
KINNER	R-5		
	46-06-02	MASTER ROD	E-1-8
US	46-06-03	MASTER ROD KNUCKLE PIN HOLES	KCE-33, -4
KINNER	R-5 SERIES	2	
KINNER	R-55		
	46-06-03	MASTER ROD KNUCKLE PIN HOLES	KCE-33, -4
KINNER	R-56		
	46-06-03	MASTER ROD KNUCKLE PIN HOLES	KCE-33, -4
R-440-	1		

MAKE / CONS	STRUCTEUR ODELE
ORIGIN	AD NUMBER

(SERIES / SERIE)

ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
INTERNATIONAL AERO V2527-A5 US 99-04-03 US 99-08-11 US 99-13-01	HIGH PRESSURE COMPRESSOR (HPC) DRUMS - STAGE 9-12 CRITICAL LIFE LIMITED ENGINE ROTATING PARTS HIGH PRESSURE TURBINE FAILURE	
JACOBS AIRCRAFT L-6MB		A2500-ENG-72-0190R2
R-755-9		
R-755A2		
R-755B2		
KLIMOV TB3-117BMA		
LIMBACH MOTORENBAU SL1700 SERIES		
L2000 SERIES GY 97-237	CARBURETTOR FLOATS	55
L2000 EB1A	( L2000 SERIES )	
L2000 EB1C	( L2000 SERIES )	
MONOCOUPE LAMBERT R-266		
PRATT & WHITNEY R-985 SERIES CF 54-6 US 56-06-02 US 57-05-04 US 66-14-04 US 68-09-01 US 70-10-02 US 78-08-07 R-985-AN-1 R-985-AN-5 R-985-AN-6 R-985-AN-6B R-985-AN-12 R-985-AN-12B R-985-AN-14 R-985-AN-14B R-985-14B R-985-39 R-985-39A	CRANKSHAFT CRACKS CYLINDER FLANGE ATTACHING STUDS CRANKSHAFT REWORK CAM REDUCTION DRIVE GEAR ASSEMBLY CRANKSHAFT FLYWEIGHT & FLYWEIGHT LINERS GEROTOR PUMP DRIVE PIN / FUEL INJECTOR FILTER CYLINDER HEADS (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES) (R-985 SERIES)	1488 REV "A" 1000, A42 1488 1671 REV A 1758 REV A
R-1340 SERIES US 56-06-02 US 99-11-02 R-1340-AN-1	CYLINDER FLANGE ATTACHING STUDS CYLINDERS ( R-1340 SERIES )	1000, A42 1787
R-1340-AN-2	( R-1340 SERIES )	
R-1340-S1H1-G	( R-1340 SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
PRATT & WHITNEY R-1340-S3H1	( R-1340 SERIES )	
R-1340-S3H1-G	( R-1340 SERIES )	
R-1340-40	( R-1340 SERIES )	
R-1340-53	( R-1340 SERIES )	
R-1340-59	( R-1340 SERIES )	
R-1340-61	( R-1340 SERIES )	
<b>R-1830 SERIES</b> US 56-06-02	CYLINDER FLANGE ATTACHING STUDS	1000, A42
R-1830-92	( R-1830 SERIES )	
R-2000 SERIES US 53-09-01 US 56-06-02	LINK (KNUCKLE) PINS CYLINDER FLANGE ATTACHING STUDS	1000, A42
R-2000-4	( R-2000 SERIES )	
R-2000-6	( R-2000 SERIES )	
R-2000-7M2	( R-2000 SERIES )	
R-2800 SERIES US 48-22-01 US 49-40-02 US 51-05-01 US 56-03-02 US 56-06-02 US 64-10-05	WATER - ALCOHOL INJECTION SYSTEM SUPERCHARGER IMPELLER THRUST BEARING ANTIDETONANT INJECTION (WET POWER) FOR TAKEOFF PRSS CARBURETEUR DERICHMENT VALVE COVER CYLINDER FLANGE ATTACHING STUDS EXHAUST VALVE	892 REV B 43 1000, A42
R-2800-CA18	( R-2800 SERIES )	
R-2800-CB16	( R-2800 SERIES )	
R-2800-27	( R-2800 SERIES )	
R-2800-34	( R-2800 SERIES )	
R-2800-51	( R-2800 SERIES )	
R-2800-52WM2	( R-2800 SERIES )	
R-2800-75M1	( R-2800 SERIES )	
R-2800-79	( R-2800 SERIES )	
WASP C SERIES US 56-06-02	CYLINDER FLANGE ATTACHING STUDS	1000, A42
WASP CA3	( WASP C SERIES )	
WASP CB3	( WASP C SERIES )	
WASP CB16	( WASP C SERIES )	
WASP S SERIES US 56-06-02 US 96-15-02 US 99-11-02	CYLINDER FLANGE ATTACHING STUDS ENGINE CRANKSHAFT COUNTERWEIGHT FAILURE CYLINDERS	1000, A42 SL NO 134, 135 1787
WASP S1H1-G	( WASP S SERIES )	
WASP S3H1	( WASP S SERIES )	
WASP S3H1-G	( WASP S SERIES )	
TWIN WASP D SERIES US 56-06-02	CYLINDER FLANGE ATTACHING STUDS	1000, A42

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

ORIGIN	E NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
00477	0		
	& WHITNEY WASP D3	( TWIN WASP D SERIES )	
TWIN	WASP D5	( TWIN WASP D SERIES )	
PT6A	-6		
CF	CF-78-03	MODIFICATIONS	
CF	CF - 78 - 14	MODIFIED #2 BEARING	1188R1
	CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A	-6A		
CF	CF-78-03	MODIFICATIONS	
CF	CF-78-14	MODIFIED #2 BEARING	1188R1
CF CF	CF-96-24 CF-98-41	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A	-6B		
CF	CF-78-14	MODIFIED #2 BEARING BLEFD OFF VALVE (ROV)	1188R1
	CF-96-24		100012, 0044, 4204
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A	-6/C20		
CF	CF-78-03	MODIFICATIONS	
CF	CF-78-14	MODIFIED #2 BEARING	1188R1
	CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF.	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A	-11		
CF	CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-	-11AG		
	CF-96-24	BLEED OFF VALVE	1538R2, 3344, 4204
	-15AG		
CF CF	CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-	-20		
	CF-78-03	MODIFICATIONS	
	CF-78-14	MODIFIED #2 BEARING	1188R1
CF	CF-96-24 CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 3344, 4204
01	0, 00 41	EMINOST BOST WEEDING CANTEE OF STATEMEN ACTO	
PT6A-	·20A		
CF CF	CF-78-03	MODIFICATIONS	1188R1
CF	CF-78-14 CF-96-24	MODIFIED #2 BEARING BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
			.,
PT6A-		AMODIE VOAT TONG	
CF CF	CF-78-03 CF-78-14	MODIFICATIONS MODIFIED #2 BEARING	1188R1
	CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
DTC	0.4		
PT6A-		MODIFICATIONS	
CF	CF-78-03 CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
PT6A-	25 CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
	CF-96-24 CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
01	30 41	CAMPOOL DOOR RESIDENCE OF STREET AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRESS AND ADDRE	
PT6A-			450000 0044 4004
	CF-96-24	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 3344, 4204
CF	CF-98-41	EXMAUST DUCT WELDTING CARRIED OUT BY STANDARD AERO	1430
PT6A-	25C		
CF	CF-99-23	BLEED OFF VALVE COTTER PIN WEAR	1574R1
DTO	0.7		
PT6A~	CF-78-03	MODIFICATIONS	
OI .	01 70 03	- COTT CONTROLL	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

PRATT & WHITNEY PTGA-27			
(CONTINUED / SUITE)	BLEED OFF VALVE (BOV)	153882 33	44 4204
CF CF-96-24 CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO		77, 7207
PT6A-28	MODIFICATIONS		
CF CF-78-03 CF CF-96-24	MODIFICATIONS BLEED OFF VALVE (BOV)	1538R2, 33	44, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	
PT6A-28A	()	450000 00	44 4004
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 33	44, 4204
PT6A-34 CF CF-78-03	MODIFICATIONS		
CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 33	
CF CF-78-03 CF CF-96-24 CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	
PT6A-34A			
CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 33	
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	
PT6A-34AG	7-10	150050	44 4604
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 33	
CF CF-98-41	EXHAUST DUCT WELDTING CARRIED OUT DT STANDARD AERO		
PT6A-34B CF CF-96-24	01550 055 11115 (0011)	150000 00	14 1201
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 33-	
PT6A-36 CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 33	44 4204
CF CF-98-41			, , , , , , , , , , , , , , , , , , , ,
PT6A-38	HIGH PRESSURE OIL LEAK	3099R1	
CF CF-78-05 CF CF-78-16 CF CF-96-24	FCU - BYPASS VALVE DIAPHRAGM	3103	
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 33	44, 4204
Cr Cr-98-41	EXHAUST DOCT WELDTING CARRIED DOT BY STANDARD ALKO	1400	
PT6A-41	LITCH DDECCUDE OT LEAV	3099R1	
CF CF-78-05	HIGH PRESSURE OIL LEAK FCU - BYPASS VALVE DIAPHRAGM	3103	
CF CF-78-05 CF CF-78-16 CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 33	44, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	
PT6A-42			
CF CF-83-28 CF CF-96-24	COMPRESSOR HUB	450000 00	11 1201
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	44, 4204
PT6A-44 CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 33	44. 4204
CF CF-98-24	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO		
PT6A-45 SERIES			
PT6A-45	( PT6A-45 SERIES )		
CF CF-78-05	HIGH PRESSURE OIL LEAK	3099R1	
CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 33	
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	
PT6A-45A	( PTGA-45 SERIES )	20005	
CF CF-78-05 CF CF-78-16	HIGH PRESSURE OIL LEAK  FCU - BYPASS VALVE DIAPHRAGM	3099R1 3103	
CF CF-78-16 CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 33	44, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	
PT6A-45B			
CF CF-96-24		1538R2, 33	44, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT

		BULLETIN DE SERVICE DE REF
PRATT & WHITNEY		
PT6A-45R CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-50 CF CF-88-22R2	ENGINE OIL SYSTEM DEPOIS	CT1 4040
CF CF-96-24	ENGINE OIL SYSTEM DEBRIS BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-96-24 CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-60A		
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 3344, 4204
		1430
CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-61		
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 3344, 4204
	EXTRACT BOOT WEEDING CANNIED BOT BY STANDARD ALKO	1450
PT6A-65AR CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV)	152882 2244 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
8704 055		
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-65R		
CF CF-96-24		1538R2, 3344, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-66		
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 3344, 4204
	Extract poor weeping ontities out it officers and	, 100
PT6A-67AF	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-96-24 CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
DTC4 0746		
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE	1538R2, 3344, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-67B		
CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
PT6A-67B CF CF-96-24 CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
PT6A-67D	700	450000 0044 4004
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-68	RIFED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
PT6A-68A CF CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6A-112		450000 0011 1001
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1538R2, 3344, 4204
	EXTRACT DUCT WEEDING CANNIES OF ST STANDARD ACTO	
PT6A-114 SERIES		
PT6A-114	( PT6A-114 SERIES )	1538R2, 3344, 4204
CF CF-96-24 CF CF-98-41	BLEED OFF VALVE (BOV) EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	
PT6A-114A CF CF-96-24	( PTGA-114 SERIES ) BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
CF CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE C

MODEL / MO ORIGIN ORIGINE			REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
DDATT &	WHITNEY		
	144	( PT6A-114 SERIES )	
(CONTIN	UED / SUITE)	·	
CF	CF-99-23	BLEED OFF VALVE COTTER PIN WEAR	1574R1
PT64-1	35 SERIES		
	CF-96-24	BLEED OFF VALVE (BOV)	1538R2, 3344, 4204
PT6A-1	<b>35</b> CF-98-41	( PT6A-135 SERIES )  EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
Ci	C1 30 41	EXHAUST BOOK WEEDING ONNITED OF BY SYNTONIE YELD	
	35A	( PT6A-135 SERIES )	
CF	CF-98-41	EXHAUST DUCT WELDING CARRIED OUT BY STANDARD AERO	1430
PT6B-9			
	CF-78-03	MODIFICATIONS	
CF	CF-78-14	MODIFIED #2 BEARING	1188R1
DTCR-2	6 SERIES		
F10D 3	O SERIES		
PT6B~3		( PT6B-36 SERIES )	
CF	CF-88-01R1	GAS GENERATOR CASE LONGITUDIONAL SEAM WELDS	11041, 11031R1
PT6B-3	64	( PT6B-36 SERIES )	
	CF-87-17R1	THIRD STAGE STATOR VANE	11033, 11034
CF	CF-88-01R1	GAS GENERATOR CASE LONGITUDIONAL SEAM WELDS	11041, 11031R1
PT6T-3			
	OF 70 4E	AUTOMATIC FCU - BYPASS VALVE DIAPHRAGM	5153
CF	CF-78-15 CF-83-04	FUEL CONTROL CONTAMINATION/POWER SECTION OVERSPEED	
CF	CF-87-14R2	GAS GENERATOR CASE SEAM WELDS	5239R1
PT6T-3	R		
	CF-83-04	FUEL CONTROL CONTAMINATION/POWER SECTION OVERSPEED	
CF	CF-87-14R2	GAS GENERATOR CASE SEAM WELDS	5239R1
PT6T-3	D		
, , , , ,			
PT6T-6		AUTOMATIO FOUR BYDACC VALVE BIADUDACM	5153
CF CF	CF-78-15 CF-83-04	AUTOMATIC FCU - BYPASS VALVE DIAPHRAGM FUEL CONTROL CONTAMINATION/POWER SECTION OVERSPEED	
CF	CF-87-14R2	GAS GENERATOR CASE SEAM WELDS	5239R1
PW118 CF	CF-87-16	REDUCTION GEARBOX OIL FEED TUBE BRACKET	20128, 20193
CF	CF-88-26R1	HIGH PRESSURE TURBINE COMPONENTS	20002R4
CF	CF-89-14R1	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING HAMILTON STANDARD HYDRO-MECHANICAL UNITS (HMU)	20907
CF CF	CF-90-24R2 CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATÉS & "O" RINGS	21077R7, 21373R3
PW118A CF	CF-87-16	REDUCTION GEARBOX OIL FEED TUBE BRACKET	20128, 20193
CF	CF-88-26R1	HIGH PRESSURE TURBINE COMPONENTS	20002R4
CF	CF-89-14R1	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING	20907
CF CF	CF-90-24R2 CF-91-26R1	HAMILTON STANDARD HYDRO-MECHANICAL UNITS (HMU) INTERCOMPRESSOR CASE - INTERNAL OIL FIRES	20914R3
CF	CF-92-03R2	INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20957R3, 20962R1
	CF-94-01	HIGH PRESSURE FURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW118B			
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
DW4404			
PW119A CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22		21077R7, 21373R3
PW119B CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

ORIGINE	NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
	& WHITNEY		
PW119			
CF CF	CF-94-01 CF-96-22	HIGH PRESSURE TURBINE (HPT) DISK	
C	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW120			
CF	CF-88-26R1	HIGH PRESSURE TURBINE COMPONENTS	20002R4
CF	CF-89-14R1	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING	20907
CF CF	CF-90-24R2 CF-94-01	HAMILTON STANDARD HYDRO-MECHANICAL UNITS (HMU)	
CF	CF-96-22	HIGH PRESSURE TURBINE (HPT) DISK FUEL NOZZLE - LOCKING PLATES & "O" RINGS	
		FORE MOZZEE EDORING PEATES & O RINGS	21077R7, 21373R3
PW120			
CF	CF-88-26R1	HIGH PRESSURE TURBINE COMPONENTS	20002R4
CF CF	CF-89-14R1 CF-90-21	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-24R2	FUEL PUMP FILTER COVER "O" RING HAMILTON STANDARD HYDRO-MECHANICAL UNITS (HMU)	20907
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
01/404			
PW121 CF		HICH DRECCIPE TURBING COMPONENTS	
CF	CF-88-26R1 CF-89-14R1	HIGH PRESSURE TURBINE COMPONENTS TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20002R4
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING	20417, 20456 20907
CF	CF-90-24R2	HAMILTON STANDARD HYDRO-MECHANICAL UNITS (HMU)	20307
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW121	Δ		
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW123			
	CF-89-14R1	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING	20355R1, 20897
CF	CF-90-22R1	LOW PRESSURE TURBINE STUB SHAFT / BEARING FAILURE	20938R1
CF CF	CF-91-02	TORQUE FLUCTUATIONS - FUEL PUMP INTERCOMPRESSOR CASE - INTERNAL OIL FIRES	20946R1
CF	CF-91-26R1 CF-92-03R2	INTERCOMPRESSOR CASE - INTERNAL OIL FIRES  INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20914R3
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	20957R3, 20962R1
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW123/	A F		
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING	20355R1, 20897
CF	CF-90-22R1	LOW PRESSURE TURBINE STUB SHAFT / BEARING FAILURE	
	CF-91-02	TORQUE FLUCTUATIONS - FUEL PUMP	20946R1
CF	CF-91-26R1	INTERCOMPRESSOR CASE - INTERNAL OIL FIRES	20914R3
CF	CF-92-03R2	INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20957R3, 20962R1
CF CF	CF-94-01 CF-96-22	HIGH PRESSURE TURBINE (HPT) DISK FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
		TOLL NOZZEL COMMOTERES & O MINGS	210//11/, 213/313
PW1238			
	CF-92-03R2	INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20957R3, 20962R1
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	0107707 0107000
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW1230	C		
	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW1230	)		
	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
Butter			
PW123E		HICH DRESCURE TURRINE (HRT) DISK	
CF CF	CF-94-01 CF-96-22	HIGH PRESSURE TURBINE (HPT) DISK  FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
OI.	50 22	TOLE HOLLE EDONATION FAILS OF O MINOS	2.077117
PW124E	3		
CF	CF-89-14R1	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING	20907
CF CF	CF-90-22R1 CF-91-02	LOW PRESSURE TURBINE STUB SHAFT / BEARING FAILURE TORQUE FLUCTUATIONS - FUEL PUMP	20938R1 20946R1
CF	CF-91-26R1	INTERCOMPRESSOR CASE - INTERNAL OIL FIRES	20914R3

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

( SERIES / SERIE )

BER SUBJECT
DE CONSIGNE SUJET

URIGINE	NUMERO DE CONSIGNE	2015 1	DOLLETING DE CONTROL DE TIET
PRATT &	& WHITNEY		
PW1248	3		
	UED / SUITE)		
	CF-92-03R2	INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20957R3. 20962R1
	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7. 21373R3
CF	Cr-96-22	FUEL NUZZLE - LUCKING PLATES & U KINGS	210/787, 213/383
PW125E			00415 00450
	CF-89-14R1	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-21	FUEL PUMP FILTER COVER "O" RING	20907
CF	CF-91-02	TORQUE FLUCTUATIONS - FUEL PUMP	20946R1
CF	CF-91-19	LOW PRESSURE TURBINE - BEARING FAILURE	21018R1
CF	CF-91-26R1	INTERCOMPRESSOR CASE - INTERNAL OIL FIRES	20914R3
	CF-92-03R2	INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20957R3, 20962R1
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
Cr	CF-96-22	FOLL NOZZEL - LOCKING FEATES & G KINGS	2107787, 2107585
211100			
PW126			00445 00450
CF	CF-89-14R1	TEMPORARY HIGH PRESSURE ROTOR SEIZURE	20417, 20456
CF	CF-90-21	FUEL PUMP FILTER COVER "D" RING	20907
CF	CF-91-19	LOW PRESSURE TURBINE - BEARING FAILURE	21018R1
CF	CF-91-26R1	INTERCOMPRESSOR CASE - INTERNAL OIL FIRES	20914R3
CF	CF-92-03R2	INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20957R3, 20962R1
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
01	0. 00 22	, DEL HOLLEL LOVINITO I ENTED O DINING	
PW1264			
		FUEL PUMP FILTER COVER "O" RING	20907
CF	CF-90-21		
CF	CF-91-19	LOW PRESSURE TURBINE - BEARING FAILURE	21018R1
CF	CF-91-26R1	INTERCOMPRESSOR CASE - INTERNAL OIL FIRES	20914R3
CF	CF-92-03R2	INTERNAL OIL FIRES INTERCOMPRESSOR CASE (ICC)	20957R3, 20962R1
CF	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-96-22	FUEL NOZZLE ~ LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW127	SERIES		
	CF-94-01	HIGH PRESSURE TURBINE (HPT) DISK	
CF	CF-95-22	ELECTRONIC ENGINE CONTROL (EEC) SOFTWARE	21327R1
0,	0, 30 22	ELECTRICATE ENGINE GEOGRAPHICS	2102711
PW127		( PW127 SERIES )	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
Cr	CF-96-22	FUEL NUZZLE - LUCKING PLATES & U KINGS	210/18/, 213/383
		( 0.1107 050750 )	
	١	( PW127 SERIES )	0.107777
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW127E		( PW127 SERIES )	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW1270	•	( PW127 SERIES )	
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
PW1270	)	( PW127 SERIES )	
	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
OF.	01 30 22	FOLL MOZZEL LOOKING FEATES G. O. KINGS	21377117, 21373113
DWAGE		( DW107 CEDICC )	
PW127E		( PW127 SERIES )	0107707 0107000
CF	CF-96-22	FUEL NOZZLE - LOCKING PLATES & "O" RINGS	21077R7, 21373R3
		/ \	
PW127F		( PW127 SERIES )	
PW150A	1		
PW305			
	CF-99-28	REDUCTION IN SERVICE LIFE OF STAGE 4 LPT DISK	
OI .	0. 33 20	ALDOOTION IN DERVIOL EITE OF STAGE 4 EFF DISK	
PW305A			
		DEDUCTION IN CEDVICE LIFE OF STACE 4 LDT DISK	
CF	CF-99-28	REDUCTION IN SERVICE LIFE OF STAGE 4 LPT DISK	
PW530A			
CF	CF-98-18	SECOND STAGE STATOR COMPRESSOR RUB INSPECTION	30044R2
PW5454	1		
JETD12	A SERIES		
	71-24-05	COMPRESSOR ROTOR DISC FAILURE	3421
US	97-02-13	COMPRESSOR HUBS; 2ND & 3RD STAGE DISKS & SPACERS	
00	0, 02 10	SOM RESSOR HOUS, ZND & SINGE DISKS & SPACERS	A3D 3030KT

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT

SUBJECT REFERENCE SERVICE BULLETIN
SUJET BULLETIN DE SERVICE DE REF.

ORIGINE NOWERO DE CONSIGN	SE SUJET	BULLETIN DE SERVICE DE REF.
PRATT & WHITNEY JFTD12A-4A	( JFTD12A SERIES )	
US 61-26-04 US 62-14-05 US 64-05-05 US 67-28-05 US 69-01-04 US 73-07-08 US 73-15-02 US 74-15-05 US 80-12-5182 US 82-14-02 US 96-23-10	FUEL CONTROL THROTTLE VALVE PACKING FIRST STAGE FAN HUB / FAN BLADES NUMBER 6 BEARING OIL TUBE ASSEMBLIES JAM NUT - FUEL CONTROL TO FUEL RETURN LINE ELBOW LUGS - TURBINE NOZZLE CASE / TURBINE BLADE / DISC 14 STAGE COMPRESSOR DISC FIRST STAGE FAN BLADES FIRST STAGE FAN BLADES THIRD STAGE TURBINE DISK	274 387 1066, 1219 2081R2 1511R4 3993 4733 5136 5358 ASB A6208R3
US 99-01-08  JT3D-1  US 62-16-05  US 62-22-02  US 66-05-05  US 80-19-03	HIGH-PRESSURE COMPRESSOR DISKS STAGES 7 THROUGH 15  ( JT3D SERIES )  FOURTH STAGE COMPRESSOR ROTOR DISCS FOURTH STAGE COMPRESSOR ROTOR DISCS P/N 393504 SECOND STAGE COMPRESSOR ROTOR DISC FIFTH STAGE COMPRESSOR DISKS	
JT3D-3B US 75-04-07 US 89-22-07	( JT3D SERIES )  10TH STAGE COMPRESSOR DISK STRUCTURAL INTEGRITY	
JT8D SERIES  CF CF-86-07R2  US 70-02-02  US 70-11-03	COMBUSTION CHAMBERS 6 STAGE COMPRESSOR ROTOR DISC 6 STAGE COMPRESSOR DISC / BLADE RETENTION TANGS	5639R10
US 70-25-08 US 70-26-05 US 75-05-06 US 86-02-52R1 US 86-08-04R1	COMBUSTION CHAMBERS HIGH PRESSURE COMPRESSOR ~ SLEEVE SPACERS	2817R1 4389R7 5639 5649
US 86-09-02R2 US 91-24-14 US 94-25-07 US 95-16-07 US 95-26-03 US 96-23-14	COMBUSTION CHAMBERS / CASE IDENTIFICATION OF 4 1/2 BEARING SPACER P/N 525961 COMBUSTION CHAMBER OUTER CASE 9 THRU 12 HIGH PRESSURE COMPRESSOR DISK 7TH - 12TH STAGE HIGH PRESSURE COMPRESSOR DISKS COMBUSTION CHAMBER OUTER CASE (CCOC)	ASB 5842R3 4723R12 ASB A6226
US 98-04-39 US 98-12-07 US 98-12-07 US 98-21-24 US 99-01-08	COMBUSTION CHAMBER OUTER CASE (CCCC)  COMBUSTION CHAMBER OUTER CASE (CCCC)  HIGH PRESSURE COMPRESSOR (HPC) DISK  COMPRESSOR DISK  HIGH-PRESSURE COMPRESSOR DISKS STAGES 7 THROUGH 15  ROTATING ENGINE PARTS	ASB A6202R1 ASB 6038R5 ENG BULLETN JT8D-025
JT8D-7	( JT8D SERIES )	
US 71-07-01 US 71-25-07 US 75-01-01 US 76-20-02 US 76-24-01	FRONT COMPRESSOR FRONT HUB FUEL NOZZLE SUPPORT ASSEMBLIES LOW TURBINE SHAFT SPLINE / COMPRESSOR HUB SPLINES 2ND STAGE FAN BLADE 8TH STAGE COMPRESSOR DISK	2406
US 77-03-06 US 77-16-12 US 78-23-12 US 80-15-51 US 87-14-01R1	FRONT COMPRESSOR FRONT HUB LOW PRESSURE TURBINE SHAFT / # 4 1/2 BEARING THIRD STAGE TURBINE BLADE RETENTION RIVETS REAR COMPRESSOR FRONT HUB SECOND STAGE FAN BLADES	4661 4639 4592R1 5154R1 5729R2
US 89-24-02 US 95-02-16 US 97-19-12 US 97-19-14	SECOND STAGE FAN DISC #7 FUEL NOZZLE 4TH STAGE LOW PRESSURE TURBINE HUB 3RD & 4TH STAGE LOW PRESS TURBINE (LPT) BLADE SET	A6153R1, A6169R2 A6274R1 5913R5, 6039R3
US 71-07-01 US 71-25-07 US 75-01-01 US 76-20-02 US 76-24-01 US 77-03-06 US 77-16-12 US 78-23-12	( JT8D SERIES ) FRONT COMPRESSOR FRONT HUB FUEL NOZZLE SUPPORT ASSEMBLIES LOW TURBINE SHAFT SPLINE / COMPRESSOR HUB SPLINES 2ND STAGE FAN BLADE 8TH STAGE COMPRESSOR DISK FRONT COMPRESSOR FRONT HUB LOW PRESSURE TURBINE SHAFT / # 4 1/2 BEARING THIRD STAGE TURBINE BLADE RETENTION RIVETS	2944R5 3536 2452, 4357 2406 4661 4639 4592R1
US 78-23-12 US 80-15-51	REAR COMPRESSOR FRONT HUB	5154R1

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT

PRATT & WHITNEY JT8D-7A	( JT8D SERIES )	
(CONTINUED / SUITE) US 87-14-01R1 US 89-24-02	SECOND STAGE FAN BLADES SECOND STAGE FAN DISC # 7 FUEL NOZZLE 4TH STAGE LOW PRESSURE TURBINE HUB	5729R2
US 95-02-16 US 97-19-12	# 7 FUEL NOZZLE 4TH STAGE LOW PRESSURE TURBINE HUB	A6153R1, A6169R2 A6274R1
US 97-19-14	3RD & 4TH STAGE LOW PRESS TURBINE (LPT) BLADE SET	5913R5, 6039R3
<b>JT8D-7B</b> US 76-20-02	( JT8D SERIES ) 2ND STAGE FAN BLADE	2406
US 76-24-01	8TH STAGE COMPRESSOR DISK	4004
US 77-03-06 US 77-16-12	LOW PRESSURE TURBINE SHAFT / # 4 1/2 BEARING	4639
US 78-23-12 US 80-15-51	THIRD STAGE TURBINE BLADE RETENTION RIVETS	4592R1
US 87-14-01R1	SECOND STAGE FAN BLADES	5729R2
US 89-24-02 US 95-02-16	2ND STAGE FAN BLADE 8TH STAGE COMPRESSOR DISK FRONT COMPRESSOR FRONT HUB LOW PRESSURE TURBINE SHAFT / # 4 1/2 BEARING THIRD STAGE TURBINE BLADE RETENTION RIVETS REAR COMPRESSOR FRONT HUB SECOND STAGE FAN BLADES SECOND STAGE FAN DISC # 7 FUEL NOZZLE 4TH STAGE LOW PRESSURE TURBINE HUB	A6152D1 A6160D2
US 97-19-14	3RD & 4TH STAGE LOW PRESS TURBINE (LPT) BLADE SET	5913R5, 6039R3
<b>JT8D-9A</b> US 76-24-01	( JT8D SERIES )	
US 77-07-11	VANES - 4TH STAGE TURBINE STATOR / ROTOR	
US 77-16-12 US 78-17-02R3	8TH STAGE COMPRESSOR DISK VANES - 4TH STAGE TURBINE STATOR / ROTOR LOW PRESSURE TURBINE SHAFT / # 4 1/2 BEARING COMPRESSOR FRONT HUB BLADE SLOTS THIRD STAGE TURBINE BLADE RETENTION RIVETS REAR COMPRESSOR FRONT HUB	4639 4841R6
US 78-23-12	THIRD STAGE TURBINE BLADE RETENTION RIVETS	4592R1
US 80-15-51 US 87-14-01R1	REAR COMPRESSOR FRONT HUB SECOND STAGE FAN BLADES	5154R1 5729R2
US 89-25-11	THIRD STAGE TURBINE BLADE RETENTION RIVETS REAR COMPRESSOR FRONT HUB SECOND STAGE FAN BLADES FIRST STAGE FAN BLADES RETAINING PLATES	5841
US 95-02-16 US 95-10-10		A6153R1, A6169R2 6104R3
US 97-19-12	FRONT COMPRESSOR FAN HUB 4TH STAGE LOW PRESSURE TURBINE HUB	A6274R1
		5913R5, 6039R3
<b>JT8D-15</b> US 76-12-06	( JT8D SERIES ) 2ND STAGE FAN BLADE PIN RIVET / BUSHING	4577
US 77-16-12	LOW PRESSURE TURRINE SHAFT / # 4 1/2 BEARING	4639
US 78-17-02R3 US 80-15-51	COMPRESSOR FRONT HUB BLADE SLOTS REAR COMPRESSOR FRONT HUB SECOND STAGE TURBINE DISK SECOND STAGE FAN BLADES ETBST STAGE FAN BLADES	4841R6 5154R1
US 85-19-51R1	SECOND STAGE TURBINE DISK	5541R1. 5510R1
US 87-14-01R1 US 89-25-11	SECOND STAGE FAN BLADES FIRST STAGE FAN BLADES RETAINING PLATES	5729R2 5841
US 95-02-16	FIRST STAGE FAN BLADES FIRST STAGE FAN BLADES RETAINING PLATES # 7 FUEL NOZZLE FRONT COMPRESSOR FAN HUB 4TH STAGE LOW PRESSURE TURBINE HUB 200 % ATH STAGE LOW PRESSURE TURBINE (LDT.) BLADE SET	A6153R1, A6169R2
US 95-10-10 US 97-19-12	FRONT COMPRESSOR FAN HUB  4TH STAGE LOW PRESSURE TURBINE HUB	6104R3 A6274R1
US 97-19-14	4TH STAGE LOW PRESSURE TURBINE HUB 3RD & 4TH STAGE LOW PRESS TURBINE (LPT) BLADE SET	5913R6, 6039R3
JT8D-17	( JTBD SERIES )	
US 76-12-06 US 77-16-12	2ND STAGE FAN BLADE PIN RIVET / BUSHING LOW PRESSURE TURBINE SHAFT / # 4 1/2 BEARING	4577
US 78-17-02R3	COMPRESSOR FRONT HUB BLADE SLOTS	4639 4841R6
US 77-16-12 US 78-17-02R3 US 80-15-51 US 85-19-51R1	REAR COMPRESSOR FRONT HUB SECOND STAGE TURBINE DISK	5154R1 5541R1, 5510R1
US 87-14-01R1	SECOND STAGE FAN BLADES	5729R2
US 87-14-01R1 US 89-25-11 US 95-02-16 US 95-10-10	FIRST STAGE FAN BLADES RETAINING PLATES # 7 FUEL NOZZLE	5841 A6153R1, A6169R2
US 95-10-10	FRONT COMPRESSOR FAN HUB	6104R3
US 97-19-12 US 97-19-14	4TH STAGE LOW PRESSURE TURBINE HUB 3RD & 4TH STAGE LOW PRESS TURBINE (LPT) BLADE SET	A6274R1 5913R5, 6039R3
JT8D-17A	( JT8D SERIES )	,
US 78-17-02R3	COMPRESSOR FRONT HUB BLADE SLOTS	4841R6
US 89-25-11 US 94-20-09	FIRST STAGE FAN BLADES RETAINING PLATES THIRD & FOURTH STAGE LP TURBINE SETS	5841 ASB 5913R6
US 95-02-16	# 7 FUEL NOZZLE	A6153R1, A6169R2
US 95-10-10	FRONT COMPRESSOR FAN HUB	6104R3
JT9D SERIES		
JT9D-7	( JT9D SERIES )	
US 70-25-03 US 73-16-05	THRUST REVERSAL SYSTEM 4TH & 5TH STAGE TURBINE DISCS	2841 3785
03 /3-16-03		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT SUJET

PRATT & WHITNEY JT9D-7	( JT9D SERIES )	
(CONTINUED / SUITE)		
US 74-10-05R1 US 76-12-03	2ND STAGE TURBINE NOZZLE GUIDE VANE SUPPORT	3946, 4146
115 70-00-00	6 STAGE TURBINE DISK / NUMBER 4 BEARING OIL TUBES	
US 76-24-03	NUMBER 3 BEARING COMPARTMENT LABYRINTH SEAL FAN BLADES	4391, 4703
US 77-01-07	FIFTH STAGE TURBINE HUB	4573 4671
US 78-08-13	MAIN GEAR BOX BEARINGS	4854
US 78-16-05	# 4 BEARING DIL SCAVANGE TUBE / 6 STG TURBINE DISK	
US 78-17-08	15TH STAGE COMPRESSOR DISK	4908
US 82-26-03	FUEL SIGNALS MANIFOLD	5202
US 85-12-02	CENTRIFUGAL OIL FILTER BEARINGS	5486R3
US 86-09-01R1	LOW PRESSURE TURBINE CASE	5292R4, 5735R1
US 88-24-05 US 89-10-07	SIXTH STAGE TURBINE INNER AIRSEAL DIFFUSER CASE - INSERT # 4 & 7 STRUTS	4835R5
US 90-23-19	HIGH PRESSURE TURBINE STAGE 1 ROTATING AIR SEAL	5730
US 93-19-02R1	DIFFUSER CASE	JT9D-7R4-72-393R1 5591R7, 6076R1
US 94-15-16	MFC, ENG VANE CONTROL & ENG VANE BLEED CONTROL	3331117, 3073111
US 96-25-10	TURBINE EXHAUST CASE (TEC)	6113, 5907, 6118R3
US 98-23-07RS	RESCINDS FAA AD 98-23-07	ASB JT9D-A6322R1
US 99-08-12	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS	
US 99-15-02	TO PREVENT CCOC RUPTURE DUE TO CRACKING	JT9D A6343R1, 4482R1
ITOD-75	( ITOD CEDIEC )	
JT9D-7F US 70-25-03	( JT9D SERIES ) THRUST REVERSAL SYSTEM	2841
US 73-16-05	4TH & 5TH STAGE TURBINE DISCS	3785
US 76-12-03	6 STAGE TURBINE DISK / NUMBER 4 BEARING DIL TUBES	
US 76-20-03	NUMBER 3 BEARING COMPARTMENT LABYRINTH SEAL	4391, 4703
US 76-24-03	FAN BLADES	4573
US 77-01-07	FIFTH STAGE TURBINE HUB	4671
US 78-08-13	MAIN GEAR BOX BEARINGS	4854
US 78-16-05	# 4 BEARING OIL SCAVANGE TUBE / 6 STG TURBINE DISK	
US 78-17-08	15TH STAGE COMPRESSOR DISK	4908
US 82-26-03 US 85-12-02	FUEL SIGNALS MANIFOLD CENTRIFUGAL OIL FILTER BEARINGS	5202 5486R3
US 85-12-02 US 86-09-01R1	LOW PRESSURE TURBINE CASE	5292R4, 5735R1
US 88-24-05		4835R5
US 89-10-07	DIFFUSER CASE - INSERT # 4 & 7 STRUTS	5730
US 90-23-19	HIGH PRESSURE TURBINE STAGE 1 ROTATING AIR SEAL	JT9D-7R4-72-393R1
US 93-19-02R1	DIFFUSER CASE	5591R7, 6076R1
US · 94-15-16	MFC, ENG VANE CONTROL & ENG VANE BLEED CONTROL	
US 98-23-07RS	RESCINDS FAA AD 98-23-07	ASB JT9D-A6322R1
US 99-08-12 US 99-15-02	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS TO PREVENT CCOC RUPTURE DUE TO CRACKING	JT9D A6343R1, 4482R1
03 99-13-02	TO PREVENT COOK NOT TOKE DOE TO CHACKING	0130 4004011, 4402111
JT9D-7R4 SERIES		
US 70-25-03	THRUST REVERSAL SYSTEM	2841
US 73-16-05	4TH & 5TH STAGE TURBINE DISCS	3785
US 76-12-03	6 STAGE TURBINE DISK / NUMBER 4 BEARING OIL TUBES	4552 4573
US 76-24-03	FAN BLADES # 4 BEARING OIL SCAVANGE TUBE / 6 STG TURBINE DISK	
US 78-16-05 US 83-22-52R1	FUEL NOZZLES	JT9D-7R4-73-4
US 90-23-19	HIGH PRESSURE TURBINE STAGE 1 ROTATING AIR SEAL	JT9D-7R4-72-393R1
US 91-03-03	HIGH PRESSURE COMPRESSOR TURBINE DRIVESHAFT	JT9D-7R4-72-375R2
US 94-08-06	FAN BLADE LEADING EDGE	72-255R5
US 96-17-11	LOW PRESSURE TURBINE (LPT) VANE	JT9D-7R4-72-480
US 97-25-10R1		JT9D-7R4-72-536R2
US 98-21-22R1	14TH & 15TH STAGE HIGH PRESSURE COMPRESSOR DISKS TO PREVENT HP COMPRESSOR DISC FAILURE	JT9D-7R4-72-553 R1
US 99-20-04	IN PREVENT OF CONTRACTOR DISC PATENCE	0.00 /14 /2 000 117
JT9D-7R4D	( JT9D-7R4 SERIES )	
US 86-03-03	FUEL NOZZLES	
US 86-23-03	HIGH PRESSURE TURBINE ROTOR AIRSEAL	JT9D-7R4-72-318
US 86-25-51	INLET GUIDE & VARIABLE STATOR VANES	72-316
US 87-23-05R1		72-311R3,-312R5 72-336R5 -117R4
US 90-14-08	ENGINE VANE AND BLEED CONTROL (EVBC) TURBINE EXHAUST CASE (TEC)	72-336R5, -117R4 6113, 5907, 6118R3
US 96-25-10 US 98-23-07RS	RESCINDS FAA AD 98-23-07	ASB JT9D-A6322R1
US 99-08-12	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS	
33 00 12		
JT15D SERIES	ENERGENOV FUEL CURT OFF LAWYER	7000 7200
CF CF-91-37R1	EMERGENCY FUEL SHUT-OFF LINKAGE	7288,7306

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
PRATT & WHITNEY JT15D-1	( JT15D SERIES )	
CF CF-75-09	FUEL LEAKS	7069
CF CF~80-26R1 CF CF-87-05R1	BEVEL GEAR FATIGUE FAILURE FAN BLADE ROOT	7152,7258,7269 7257
CF CF-91-18	HIGH PRESSURE TURBINE BLADE BOROSCOPE INSPECTION	7297, SIL 7046, 7037
CF CF-91-28	HIGH PRESSURE TURBINE BLADES	7293R1, 7310
JT15D-1A	( JT15D SERIES )	7450 7050 7000
CF CF-80-26R1 CF CF-87-05R1	BEVEL GEAR FATIGUE FAILURE FAN BLADE ROOT	7152,7258,7269 7257
CF CF-91-18	HIGH PRESSURE TURBINE BLADE BOROSCOPE INSPECTION	7297, SIL 7046, 7037
CF CF-91-28	HIGH PRESSURE TURBINE BLADES	7293R1, 7310
JT15D-1B CF CF-87-05R1	( JT15D SERIES ) FAN BLADE ROOT	7257
CF CF-91-18	HIGH PRESSURE TURBINE BLADE BOROSCOPE INSPECTION	7297, SIL 7046, 7037
CF CF-91-28	HIGH PRESSURE TURBINE BLADES	7293R1, 7310
JT15D-4	( JT15D SERIES )	
CF CF-75-09 CF CF-78-04	FUEL LEAKS · · · FUEL MANIFOLD LEAK	7069 7087R1
CF CF-80-26R1		7152,7258,7269
CF CF-87-05R1	FAN BLADE ROOT	7257
CF CF-88-03R1 CF CF-91-18	LOW PRESSURE COMPRESSOR CASE HIGH PRESSURE TURBINE BLADE BOROSCOPE INSPECTION	7268 7297, SIL 7046, 7037
JT15D-4B	( JT15D SERIES )	
CF CF-87-05R1	FAN BLADE ROOT	7257
CF CF-88-03R1	LOW PRESSURE COMPRESSOR CASE	7268
CF CF-91-03 CF CF-91-18	GAS GENERATOR CASE HIGH PRESSURE TURBINE BLADE BORDSCOPE INSPECTION	7240R1, 7262R2 7297, SIL 7046, 7037
ITAED AC		,,
JT15D-4C CF CF-87-05R1	( JT15D SERIES ) FAN BLADE ROOT	7257
CF	LOW PRESSURE COMPRESSOR CASE	7268
CF CF-90-24R2 CF CF-91-18	HAMILTON STANDARD HYDRO-MECHANICAL UNITS (HMU) HIGH PRESSURE TURBINE BLADE BOROSCOPE INSPECTION	7297, SIL 7046, 7037
JT15D-4D	( JT15D SERIES )	
CF CF-87-05R1 CF CF-88-03R1	FAN BLADE ROOT	7257
CF CF-91-18	LOW PRESSURE COMPRESSOR CASE HIGH PRESSURE TURBINE BLADE BOROSCOPE INSPECTION	7268 7297, SIL 7046, 7037
JT15D-5	( JT15D SERIES )	
CF CF-90-24R2	HAMILTON STANDARD HYDRO-MECHANICAL UNITS (HMU)	
JT15D-5A	( JT15D SERIES )	
CF CF-92-19R1	FUEL FLOW DIVIDER SPILL VALVE DIAPHRAGM	7371, 7372
JT15D-5B	( JT15D SERIES )	
JT15D-5C	( JT15D SERIES )	
JT15D-5D	( JT15D SERIES )	
JT15D-5F	( JT15D SERIES )	
PW4000 SERIES		
US 90-22-02	LOW PRESSURE TURBINE (LPT) SHAFT	ASB PW4ENG 72-328
US 96-13-08 US 98-19-03	THRUST REVERSERS - RE STC # SE744NE 2ND STAGE HPT AIRSEAL	PW4NAC 78-78R6 A72-628R1
PW4056	( PW4000 SERIES )	
US 93-08-16 US 98-23-08	HIGH PRESSURE COMPRESSOR / AIR SEAL MODS. TO PREVENT HIGH PRESSURE COMPRESSOR SURGE	ASB 747-73A2O55 PW4 FNG 72-484R3
US 99-08-15	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS	
US 99-15-01 US 99-17-16	TO PREVENT UNCONTAINED DISK FAILURE TO PREVENT A HIGH PRESSURE COMPRESSOR SURGE EVENT	PW4ENG 72-657
		NO OFFICE TEN TIN AN
PW4060 US 93-08-16	( PW4000 SERIES ) HIGH PRESSURE COMPRESSOR / AIR SEAL	ASB 767-73A0033
US 98-23-08	MODS. TO PREVENT HIGH PRESSURE COMPRESSOR SURGE	PW4 ENG 72-484R3
US 99-08-15 US 99-17-16	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS TO PREVENT A HIGH PRESSURE COMPRESSOR SURGE EVENT	AS SPECIFIED IN AD
55 55 17 10	TO THE VEHI A HIGH PRESSURE COMPRESSOR SURGE EVENT	AS SECUTED IN AD

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

CHIGINE	NOWERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
PRATT	& WHITNEY		
PW416	8		
US	97-11-06	FAN BLADES	PW4G-100-72-69,-81
US	98-04-14	FRONT PYLON MOUNT BOLTS	PW4G-100-A71-9R1
US	98-19-03 99-08-15 99-15-01	2ND STAGE HPT AIRSEAL	A72-80R1
US	99-08-15	CRITICAL LIFE LIMITED ENGINE ROTATING PARTS	
	33 13 01	TO PREVENT UNCONTAINED DISK FAILURE	PW4G 100-72-105
ROLLS	ROYCE		
DART	506		
UK	1930 PRE 80	LOW TORQUE SWITCH	DA61-12R3
UK	1932 PRE 80	ENGINE REDUCTION GEAR	DA72-297
UK	1933 PRE 80	PROPELLER SHAFTS	DA72-367
UK	1934 PRE 80	TURBINE WHEELS AND SHAFT LOW PRESSURE	DA72-347
UK	1936 PRE 80 1947 PRE 80	FUEL BURNERS	DA73-A54
UK	1947 PRE 80	LOW PRESSURE IMPELLER	DA72-A445
UK	1949 PRE 80	FUEL BURNER SHROUD NUTS AEROQUIP TYPE FUEL PIPES	DA73-68
	1950 PRE 80	CONTROL BOX MOUNTING BOLTS	DA73-73
UK	1951 PRE 80	CONTROL DOW MOUNTAINS	DA76-16 DA76-A17
UK	002-02-82	COMBUSTION CHAMBERS - AIR CASING	DA76-A17 DA72-A471
UK	002-10-82	COMBUSTION EQUIPMENT - ANTI-TEAR STRAPS	DA72-475
UK	004-02-82	COMBUSTION CHAMBERS - AIR CASING COMBUSTION EQUIPMENT - ANTI-TEAR STRAPS AEROQUIP FUEL PIPE RK 38451A	DA73-A75
UK	007-05-82	NOZZEE BOX AND GOIDE VANES	DA72-451
UK	005-02-83	AEROQUIP FUEL PIPES	DA73-A76
UK	011-10-84	LOW PRESSURE IMPELLER	DA72-A488R2
UK	001-05-86	SMITHS TORQUE PRESSURE TRANSMITTER	DA77-A12
UK UK	006-08-86	HIGH PRESSURE (HP) IMPELLER	DA72-496
UK	014-11-86 008-03-93	FUEL BURNER SHROUD NUT	DA73-A81R1
UK	002-12-96	SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT LOW TORQUE SWITCH	DA73-A86
UK	002-09-99	LUB. DART ENGINE ACCESSORY GEARBOX DRIVE SHAFT	DA 61-13 83-518 DOWTY SEPT/99
	002 00 00	ESS. BART ENGINE ACCESSORT GEARDON BRIVE SHATT	83-318 DOWLY SEP1/99
DART	514-7		
UK	1927 PRE 80	ANTI-TEAR STRIPS	61-9
UK	1930 PRE 80	LOW TORQUE SWITCH	DA61-12R3
UK	1934 PRE 80	TURBINE WHEELS AND SHAFT LOW PRESSURE	DA72-347
UK	1935 PRE 80	REDUCTION GEAR - FEATHERING PROBE	DA72-348R13
UK	1936 PRE 80	FUEL BURNERS	DA73-A54
UK UK	1945 PRE 80 1947 PRE 80	IMPELLERS AND SHAFTS LOW PRESSURE IMPELLER	DA72-430
UK	1948 PRE 80	FUEL BURNER SHROUD NUTS	DA72-A445 DA73-68
	1949 PRE 80	AFROOUTP TYPE FUEL PIPES	DA73-73
UK	1950 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-16
UK	1951 PRE 80	CONTROL DOV MOUNTING DOLTS	DA7C A47
UK	002-02-82	COMBUSTION CHAMBERS - AIR CASING COMBUSTION EQUIPMENT - ANTI-TEAR STRAPS	DA72-A471
UK	002-10-82	COMBUSTION EQUIPMENT - ANTI-TEAR STRAPS	DA72-475
UK	004-02-82	AEROQUIP FUEL PIPE RK 38451A	DA73-A75
UK	007-05-82	NOZZLE BOX AND GUIDE VANES	DA72-451
UK	011-10-84	LOW PRESSURE IMPELLER	DA72-A488R2
UK	011-10-84 001-05-86 006-08-86	SMITHS TORQUE PRESSURE TRANSMITTER HIGH PRESSURE (HP) IMPELLER	DA77-A12 DA72-496
UK	006-08-86 007-08-86	OIL COOLER MATRIX TUBE	DA72-496 DA72-497
UK	014-11-86	FUEL BURNER SHROUD NUT	DA73-A81R1
UK	008-03-93	SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT	
UK	002-12-96	LOW TORQUE SWITCH	DA 61-13
UK	002-09-99	LUB. DART ENGINE ACCESSORY GEARBOX DRIVE SHAFT	83-518 DOWTY SEPT/99
	529 SERIES	LOW TODOUG CHITTON	DAC4 1000
UK	1930 PRE 80	LOW TORQUE SWITCH	DA61-12R3
UK	1933 PRE 80	PROPELLER SHAFTS REDUCTION GEAR - FEATHERING PROBE	DA72-367 DA72-348R13
UK UK	1935 PRE 80 1936 PRE 80	FILE RURNERS	
UK	1943 PRE 80	FUEL BURNERS FLAME TUBE	DA72-420
UK	1945 PRE 80	IMPELLERS AND SHAFTS	DA72-430
UK	1947 PRE 80	LOW PRESSURE IMPELLER	DA72-A445
UK	1948 PRE 80	FUEL BURNER SHROUD NUTS	DA73-68
UK	1949 PRE 80	AEROQUIP TYPE FUEL PIPES	DA73-73
UK	1950 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-16
UK	1951 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-A17
UK	002-02-82	COMBUSTION CHAMBERS - AIR CASING	DA72-A471
UK	002-10-82	COMBUSITON EQUIPMENT - ANTI-TEAR STRAPS	DA72-475
UK	004-02-82	AEROQUIP FUEL PIPE RK 38451A FLAME TUBE SUSPENSION	DA73-A75 DA72-470
UK UK	008-05-82	FLAME TUBE SUSPENSION	DA72-470 DA72-472
- 00	018-04-82	LEWIS LOST DOSLETATOR	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT
SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET	BOLLETIN DE SERVICE DE MEZ.
ROLLS			
	529 SERIES		
(CONTI	NUED / SUITE)	AEROQUIP FUEL PIPES	DA73-A76
UK	005-02-83	AEROQUIP FUEL PIPES	DA72-485
UK	011-10-84	AEROQUIP FUEL PIPES FLAME TUBE SUSPENSION LOW PRESSURE IMPELLER SMITHS TORQUE PRESSURE TRANSMITTER	DA72-A488R2
UK	001-05-86	SMITHS TOPOLIE DESSLIPE TRANSMITTER	DA77-A12
UK	001-05-86 005-08-86 007-08-86	SNUBBER SCREWS EXPANSION CHAMBERS/FLAME TUBE HEAD	DA72-423
UK	007-08-86	OIL COOLER MATRIX TUBE	DA72-497
UK	014-11-86	FUEL BURNER SHROUD NUT	DA73-A81R1
	008-06-89	LOW PRESSURE TURBINE DISC	DA72-A512
UK	009-06-89	FUEL BURNER SHROUD NUT LOW PRESSURE TURBINE DISC ACOUSTICALLY LINED AIR INTAKE COWLING SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT	DA72-513
UK	008-03-93	SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT	DA73-A86
UK	009-06-89 008-03-93 004-09-94 002-12-96	LD IMPELLED	DA72-307P6
UK	002-12-96	LOW TORQUE SWITCH	DA 61-13
UK	002-05-98	HP TURBINE BLADES REWORK	DA72-530
UK	003-05-98 002-09-99	FUEL BURNER FUEL FLOW CALCULATIONS	DA73~A87
UK	002-09-99	LOW TORQUE SWITCH HP TURBINE BLADES REWORK FUEL BURNER FUEL FLOW CALCULATIONS LUB. DART ENGINE ACCESSORY GEARBOX DRIVE SHAFT	83-518 DOWTY SEP1/99
DART	529-7E	( DART 529 SERIES )	
DART	529-8X	( DART 529 SERIES )	
DART	532 SERIES		
UK	1930 PRE 80	LOW TORQUE SWITCH	DA61-12R3
UK	1933 PRE 80	PROPELLER SHAFTS	DA72-367
UK	1930 PRE 80 1933 PRE 80 1935 PRE 80 1936 PRE 80	REDUCTION GEAR - FEATHERING PROBE	DA72-348R13
	1936 PRE 80	FUEL BURNERS	DA73-A54
UK	1943 PRE 80	REDUCTION GEAR - FEATHERING PROBE FUEL BURNERS FLAME TUBE IMPELLERS AND SHAFTS	DA72-420
UK UK	1343 1112 00	THE ELLENG AND SHALLS	DA72-430 DA72-A445
UK	1947 PRE 80 1948 PRE 80 1949 PRE 80	ELLE BUDNED CHOOLD NUTS	DA72-4445 DA73-68
UK	1949 PRE 80	AEROQUIP TYPE FUEL PIPES	DA73-73
UK	1950 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-16
UK	1950 PRE 80 1951 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-A17
UK	002-02-82 002-10-82 004-02-82 008-05-82	COMBUSTION CHAMBERS - AIR CASING	DA72-A471
UK	002-10-82	COMBUSTION EQUIPMENT - ANTI-TEAR STRAPS	DA72-475
UK	004-02-82	AEROQUIP FUEL PIPE RK 38451A	DA73-A75
UK	008-05-82	FLAME TUBE SUSPENSION	DA72-470
UK			DA72-472
UK	013 04 82 005-02-83 006-08-84 011-10-84	AEROQUIP FUEL PIPES	DA73-A76
UK	006-08-84	FLAME TUBE SUSPENSION	DA72-485
UK	011-10-84	LOW PRESSURE IMPELLER SMITHS TORQUE PRESSURE TRANSMITTER	DA72-A488R2
UK	001-05-86	SMITHS TORQUE PRESSURE TRANSMITTER	DA77-A12
UK	005-08-86	SNUBBER SCREWS EXPANSION CHAMBERS/FLAME TUBE HEAD	
UK	007-08-86	OIL COULER MAIKIX TUBE	DA72-497
UK UK	014-11-86	FUEL BURNER SHROUD NUT LOW PRESSURE TURBINE DISC	DA73-A61R1
UK	008-06-89	LOW PRESSURE IMPELLER SMITHS TORQUE PRESSURE TRANSMITTER SNUBBER SCREWS EXPANSION CHAMBERS/FLAME TUBE HEAD OIL COOLER MATRIX TUBE FUEL BURNER SHROUD NUT LOW PRESSURE TURBINE DISC SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT	DA72-A312 DA73-A86
UK	002-12-96	LOW TOPOLIE SWITCH	DA 61-13
UK	002-12-96 002-05-98	HP TURBINE BLADES REWORK	DA72-530
UK	003-05-98	FUEL BURNER FUEL FLOW CALCULATIONS	DA73-A87
UK	002-09-99	HP TURBINE BLADES REWORK FUEL BURNER FUEL FLOW CALCULATIONS LUB. DART ENGINE ACCESSORY GEARBOX DRIVE SHAFT	83-518 DOWTY SEPT/99
	532-7	( DART 532 SERIES )	
UK	004-09-94	HP IMPELLER	DA72-307R6
DART UK	<b>534-2</b> 1930 PRE 80	LOW TORQUE SWITCH	DA61-12R3
UK	1933 PRE 80	PROPELLER SHAFTS	DA72-367
UK	1935 PRE 80	REDUCTION GEAR - FEATHERING PROBE	DA72-348R13
UK	1943 PRE 80	FLAME TUBE	DA72-420
UK	1945 PRE 80	IMPELLERS AND SHAFTS	DA72-430
UK	1947 PRE 80	LOW PRESSURE IMPELLER	DA72-A445
UK	1949 PRE 80	AEROQUIP TYPE FUEL PIPES	DA73-73
UK	1950 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-16
UK	1951 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-A17
UK	002-02-82	COMBUSTION CHAMBERS - AIR CASING	DA72~A471
UK	002-10-82	COMBUSTION EQUIPMENT ~ ANTI-TEAR STRAPS	DA72-475
UK	004-02-82	AEROQUIP FUEL PIPE RK 38451A	DA73-A75
UK	008-05-82	FLAME TUBE SUSPENSION	DA72-470
UK	018-04-82	FLAME TUBE SUSPENSION	DA72-472
UK UK	005-02-83 006-08-84	AEROQUIP FUEL PIPES	DA73~A76 DA72-485
UK	011-10-84	FLAME TUBE SUSPENSION LOW PRESSURE IMPELLER	DA72-485 DA72-A488R2
	011 10 04	LOW TRESOURE IMPLEEER	DATE ATOOKE

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER

ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

			BULLETIN DE SERVICE DE REF.
ROLLS	ROYCE		
	534-2		
	INUED / SUITE)		
UK	001-05-86	SMITHS TORQUE PRESSURE TRANSMITTER	DA77 A10
UK	005-08-86	SNUBBER SCREWS EXPANSION CHAMBERS/FLAME TUBE HEAD	DA77-A12
UK	007-08-86	UIL COOLER MATRIX TUBE	DA72~423 DA72~497
UK	014-11-86	FILE PLIDNED CHOOLD AND	DA73-A81R1
UK	008-06-89 008-03-93 004-09-94 002-12-96	LOW PRESSURE TURBINE DISC	DA72-A512
UK	008-03-93	SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT	DA73-A86
UK UK	004-09-94	HP IMPELLER	DA70 007DC
UK.	002-12-96	LOW TORQUE SWITCH HP TURBINE BLADES REWORK FUEL BURNER FUEL FLOW CALCULATIONS	DA 61-13
UK	002 05 98	THE RIPHED FUEL FLOW CALCULATIONS	DA72-530
UK	002-09-99	HP TURBINE BLADES REWORK FUEL BURNER FUEL FLOW CALCULATIONS LUB. DART ENGINE ACCESSORY GEARBOX DRIVE SHAFT	DA73-A87
	001 00 00	ESD. DART ENGINE ACCESSORY GEARBOX DRIVE SMAFT	83-518 DOWLY SEPT/99
DART	535-2		
UK	1930 PRE 80	LOW TORQUE SWITCH PROPELLER SHAFTS REDUCTION GEAR - FEATHERING PROBE FLAME TUBE IMPELLERS AND SHAFTS	DA61-12R3
UK	1933 PRE 80	PROPELLER SHAFTS	DA72-367
UK	1935 PRE 80	REDUCTION GEAR - FEATHERING PROBE	DA72-348R13
UK	1943 PRE 80	FLAME TUBE	DA72-420
UK UK	1945 PRE 80		
	1947 PRE 80 1949 PRE 80	FLAME TUBE IMPELLERS AND SHAFTS LOW PRESSURE IMPELLER AEROQUIP TYPE FUEL PIPES	DA72-A445
UK	1950 PRE 80	CONTROL BOX MOUNTING BOLTS	DA 73 - 73
UK	1951 PRE 80	LOW PRESSURE IMPELLER AEROQUIP TYPE FUEL PIPES CONTROL BOX MOUNTING BOLTS CONTROL BOX MOUNTING BOLTS	DA76-16
UK	002-02-82	COMBUSTION CHAMBERS - AIR CASING	DA76-A17 DA72-A471
UK	002-10-82	CONTROL BOX MOUNTING BOLTS CONTROL BOX MOUNTING BOLTS COMBUSTION CHAMBERS - AIR CASING COMBUSTION EQUIPMENT - ANTI-TEAR STRAPS AEROQUIP FUEL PIPE RK 38451A FLAME TUBE SUSPENSION FLAME TUBE SUSPENSION	DA72-475
UK	004-02-82	AEROQUIP FUEL PIPE RK 38451A	DA73-A75
UK	008-05-82	FLAME TUBE SUSPENSION	DA72-470
UK	018-04-82	FLAME TUBE SUSPENSION	DA72-472
UK	005-02-83	AEROQUIP FUEL PIPE RK 38451A FLAME TUBE SUSPENSION FLAME TUBE SUSPENSION AEROQUIP FUEL PIPES	DA73-A76
UK	006-08-84	FLAME TUBE SUSPENSION	DA72-485
UK	011-10-84	LOW PRESSURE IMPELLER	DA72-A488R2
UK	001-05-86	SMITHS TORQUE PRESSURE TRANSMITTER	DA77-A12
UK	005-08-86	FLAME TUBE SUSPENSION LOW PRESSURE IMPELLER SMITHS TORQUE PRESSURE TRANSMITTER SNUBBER SCREWS EXPANSION CHAMBERS/FLAME TUBE HEAD OIL COOLER MATRIX TUBE	DA72-423
UK	014-11-86	OIL COOLER MATRIX TUBE FUEL BURNER SHROUD NUT LOW PRESSURE TURBINE DISC SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT	DA72-497
UK	008-06-89	LOW PRESSURE TURRINE DISC .	DA73-A81R1 DA72-A512
UK	008-03-93	SERVO PIPE - FUEL PUMP TO FUEL CONTROL UNIT	DA73-A86
UK	004-09-94	HP IMPELLER	DA72-307R6
UK	002-12-96	LOW TORQUE SWITCH	DA 61-13
UK	002-05-98	HP TURBINE BLADES REWORK	DA72-530
UK	003-05-98	HP IMPELLER LOW TORQUE SWITCH HP TURBINE BLADES REWORK FUEL BURNER FUEL FLOW CALCULATIONS	DA73-A87
UK	002-09-99	LUB. DART ENGINE ACCESSORY GEARBOX DRIVE SHAFT	83-518 DOWTY SEPT/99
DADT	536-2		
	1930 PRE 80	LOW TOPOLIE SWITCH	DAG1-12D3
UK	1930 PRE 80	LOW TORQUE SWITCH REDUCTION GEAR - FEATHERING PROBE FLAME TUBE	DA72-348R13
UK	1943 PRE 80	FLAME TUBE	DA72-420
UK	1947 PRE 80	LOW PRESSURE IMPELLER	DA72-A445
UK	1950 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-16
UK	1951 PRE 80	CONTROL BOX MOUNTING BOLTS	DA76-A17
UK	002-02-82	COMBUSTION CHAMBERS - AIR CASING	DA72-A471
UK	002-10-82	CONTROL BOX MOUNTING BOLTS COMBUSTION CHAMBERS - AIR CASING COMBUSTION EQUIPMENT - TEAR STRAPS AEROQUIP FUEL PIPE RK 38451A	DA72-475
UK	004-02-82	AERUQUIP FUEL PIPE RK 38451A	DA 73 - 470
UK	008-05-82	FLAME TUBE SUSPENSION	DA72-470 DA72-472
UK UK	018-04-82 005-02-83 006-08-84	FLAME TUBE SUSPENSION AEROQUIP FUEL PIPES	DA72 A7C
UK	006-08-84	FLAME TUBE SUSPENSION	DA72-485
UK	011-10-84	LOW PRESSURE IMPELLER	DA72-A488R2
UK	001-05-86		DA77-A12
UK	005-08-86	SNUBBER SCREWS EXPANSION CHAMBERS/FLAME TUBE HEAD	
UK	007-08-86		DA72-497
UK	014-11-86	FUEL BURNER SHROUD NUT	DA73-A81R1
UK	008-06-89		DA72-A512
UK	008-03-93		DA73-A86
UK	004-09-94		DA72-307R6
UK	002-12-96	LOW TORQUE SWITCH	DA 61-13
UK	002-05-98	HP TURBINE BLADES REWORK FUEL BURNER FUEL FLOW CALCULATIONS	DA72-530 DA73-A87
UK UK	003-05-98 002-09-99	LUB. DART ENGINE ACCESSORY GEARBOX DRIVE SHAFT	
OK	002 03-33	LOD, DANI LINGTINE ACCESSION GERMOON DATAL STATE	

20 JANUARY/JANVIER 2000

BR700 SERIES

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) SUBJECT

ROLLS I	ROYCE -71042-20	( BR700 SERIES )	
GY	1998-467/2	SEPARATION OF ENGINE CORE FAIRINGS	72-900062R3,-100900R
D0011.	-22B-02		
UK	0011 PRE 80	LOW PRESSURE COMPRESSOR (FAN) DISCS LOW PRESSURE COMPRESSOR ROTOR SHAFT LOW PRESSURE COMPRESSOR ROTOR COMPRESSOR INTERMEDIATE CASE P1 PROBE ENGINE LIGHT DUTY ELECTRICAL HARNESS VARIABLE INLET GUIDE VANE (VIGV) VARIABLE INLET GUIDE VANES STAGES 4 & 5 STATOR VANES HS EXTERNAL GEAR-BOX - OIL TANK FILLER COMPRESSOR INTERMEDIATE CASE OIL RETURN LINE EXHAUST - COLD STREAM TRANSLATING COWL SPEED AND TEMPERATURE GOVERNING SYSTEM HP TURBINE DISC HP TURBINE ROTOR	72-A2655
UK	0012 PRE 80	LOW PRESSURE COMPRESSOR ROTOR SHAFT	72-3074
UK	0015 PRE 80	LOW PRESSURE COMPRESSOR ROTOR	72-3062
UK	0016 PRE 80	COMPRESSOR INTERMEDIATE CASE	72-A3077
UK	0017 PRE 80	PI PRUBE	71-2210
UK	0019 PRE 80	VARIABLE INLET GUIDE VANE (VIGV)	72-3326
UK	0020 PRE 80	VARIABLE INLET GUIDE VANES	72-3335
UK	0021 PRE 80	STAGES 4 & 5 STATOR VANES	72-3482
UK	0022 PRE 80	HS EXTERNAL GEAR-BOX - OIL TANK FILLER	72-3533
UK	0023 PRE 80	COMPRESSOR INTERMEDIATE CASE OIL RETURN LINE	72-3650 78-A3672
UK	0024 PRE 80	SPEED AND TEMPERATURE GOVERNING SYSTEM	73-3673
UK	0026 PRE 80	HP TURBINE DISC	72-4300
UK	0027 PRE 80	HP TURBINE ROTOR	72-A4301
UK	0028 PRE 80	HP TURBINE ROTOR	72-4303
UK	0029 PRE 80	HP TURBINE DISC	72-4304
UK	0031 PRE 80	HP TURBINE DISC  HP TURBINE ROTOR  HP TURBINE ROTOR  HP TURBINE DISC  HP AND LP FUEL PUMPS  HP COMPRESSOR ROTOR STAGE 1 & 2 DISC ASSEMBLIES  HP COMPRESSOR ROTOR STAGE 1 TO 2 DISC ASSEMBLIES  AIRBORNE VIBRATION MONITORING (AVW) SYSTEM  FUEL FILTER IN HP FUEL LINE TO BURNER MANIFOLD  IP COMPRESSOR STAGE 6 TO 7 ROTOR ASSEMBLIES	73-4776 72-A5722
UK	016-03-81	HP COMPRESSOR ROTOR STAGE 1 TO 2 DISC ASSEMBLIES	72-A5885
UK	018-08-81	AIRBORNE VIBRATION MONITORING (AVW) SYSTEM	77-A6422
UK	019-03-81	FUEL FILTER IN HP FUEL LINE TO BURNER MANIFOLD	73-5184
UK	005-05-82	IP COMPRESSOR STAGE 6 TO 7 ROTOR ASSEMBLIES	
UK	013-06-82	I P COMPRESSOR ROTOR & IP TURBINE DISCS	72-5887R4 72-6574
UK	012-05-84	IP COMPRESSOR STAGE 6 TO 7 ROTOR ASSEMBLIES IP COMPRESSOR ROTOR & IP TURBINE DISCS LP COMPRESSOR ROTOR (FAN) IP AND LP COMPRESSOR LOCATION BEARINGS	72-6847R8
UK	006-06-85 003-07-86 002-05-88 003-05-88	HP COMPRESSOR	72-A7774
UK	003-07-86	LOW PRESSURE TURBINE - 2ND STAGE NOZZLE VANE	72-8301R8
UK	002-05-88	ENGINE INDICATING SYSTEM	77-A8443
UK UK	003-05-88	AIRBORNE VIBRATION MONITORING (AVM) SYSTEM ENGINE INDICATING SYSTEM	
UK	008-05-88 010-01-90 004-01-94	OIL DRAIN HOLES IP COMPRESSOR 1-5 ROTOR SHAFT HIGH PRESSURE COMPRESSOR - STAGE 3 DISC	72-896382
UK	004-01-94	HIGH PRESSURE COMPRESSOR - STAGE 3 DISC	RB211-72-9661R3
UK	003-01-99	IP COMPRESSOR STAGE 6 & 7 ROTOR SHAFT ASSEMBLY	RB211-72-C538
DD044	E04D4 00		
UK	-524B4-02	SPEED GOVERNING SYSTEM	73-4305
UK	0030 PRE 80 0037 PRE 80	HP COMPRESSOR ROTOR	70 F004
UK	016-03-81	HP COMPRESSOR ROTOR STAGE 1 TO 2 DISC ASSEMBLIES	72-A5885
UK	018-08-81	AIRBORNE VIBRATION MONITORING (AVW) SYSTEM	77-A6422
UK UK	019-03-81	LD COMPRESSOR ROTOR (EAN) SHAFTS	73-5184
UK	006-05-82 009-06-82 013-03-82	FUEL FILTER IN HP FUEL LINE TO BURNER MANIFOLD LP COMPRESSOR ROTOR (FAN) SHAFTS IP COMPRESSOR ROTOR & IP TURBINE DISCS	72-5887R3
UK			72-6574
UK	014-03-82	LP COMPRESSOR (FAN)	76-6576
UK	014-03-82 016-11-82 012-05-84	LP COMPRESSOR (FAN) LP TURBINE SHAFT IP AND LP COMPRESSOR LOCATION BEARINGS	72-5884
UK	006-06-85	HP COMPRESSOR LOCATION BEARINGS HP COMPRESSOR	72-6847R8 72-A7774
UK	002-05-88	ENGINE INDICATING SYSTEM	77-A8443
UK	016-11-82 012-05-84 006-06-85 002-05-88 003-05-88	AIRBORNE VIBRATION MONITORING (AVM) SYSTEM	
UK	008-05-88 019-10-92 004-01-94 005-07-95	ENGINE INDICATING SYSTEM	77-A8444
UK	019-10-92	LP TURBINE STAGE 2 NOZZLE VANES HIGH PRESSURE COMPRESSOR - STAGE 3 DISC	72-9672R1
UK UK	005-07-95	HIGH PRESSURE COMPRESSOR ~ STAGE 3 DISC INSPECTION OF COMBUSTION LINER ASSY PHASE 2 COMBUSTION LINER	RB211-72-9661R3 RB211-72-B482R7
UK	009-01-98	PHASE 2 COMBUSTION LINER ASSY	RB211-72-9462R7
UK	003-01-99	IP COMPRESSOR STAGE 6 & 7 ROTOR SHAFT ASSEMBLY	RB211-72-C538
	F0554		
RB211-	535E4 RB211-72-C817	HD TURBINE DISC- EDDY CURRENT OF COOLING ATRICOLES	DP011-70-0017
UK	RB211-72-C930	HP TURBINE DISC- EDDY CURRENT OF COOLING AIR HOLES RADIAL DRIVE STEADY BEARING FAILURES	RB211-72-C817 RB211-72-C930
UK	008-07-85	COMBUSTION OUTER CASE	72-7775R3
UK	012-03-85	FUEL SYSTEMS AIR TUBES	
UK	013-03-85	FUEL CONTROL	73-7905
UK UK	001-07-86	HP BLEED VALVE SOLENOID, LOW SET	75-8285
UK	007-07-90 009-03-93	THROTTLE CONTROL - NEW LOWER GEARBOX COVER BRACKET FUEL SYSTEM TUBES & FITTINGS	
UK	016-03-93	FUEL SYSTEM TUBES & FITTINGS	73-9664, -9761
UK	004-01-94	HIGH PRESSURE COMPRESSOR - STAGE 3 DISC	RB211-72-9661R3
UK	008-07-94	LP FUEL TUBE FROM LP FILTER TO HP PUMP	RB211-73-B048R1
UK	005-05-96	FUEL FLOW GOVERNOR-INCREASED LOW IDLE FUEL FLOW	211-73-B869 R1
	TNES /MOTELIES		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUBJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
ROLLS I	DOVCE		
	-535E4		
(CONIT IN	HIED / SHITE)		
UK	007-01-97	LOW PRESSURE FUEL TUBE FLEXIBLE SECTIONS FLEXIBLE FUEL PIPE RESPECIFIED FAILURE OF RADIAL DRIVE STEADY BEARING RADIAL DRIVE STEADY BEARING	DR211-72-R007D4
UK	007-10-97	FLEXIBLE FUEL PIPE RESPECIFIED	RB211-73-0907R4
UK	005-07-99	FAILURE OF RADIAL DRIVE STEADY BEARING	RB211-72-C815R2
UK	006-05-99	RADIAL DRIVE STEADY BEARING	RB211-72-C810R2
RR211	TRENT 772B-60		
UK	003-11-99	LP COMPRESSOR HILTRASONIC TAKER OF BLADE DOCTO	DD011 011 D0 000
UK	003-11-99 004-10-99	LP COMPRESSOR-ULTRASONIC INSP OF BLADE ROOTS RB211 TRENT 772B-60 INSTALLED ON AIRBUS A330	RB211-211-72-C878
		ASSO	NB.211-72-0491
SPEY 5	511-8		
UK	2231 PRE 80	FUEL AND AIR TUBES OIL SCAVENGE SOLE PLATE	SP 72-A477
UK	2232 PRE 80	HP COMPRESSOR - STACE O TO E POTOR DISCOS	SP 72-502
UK	2242 PRE 80	HP SHUT-OFF VALVE PRIMARY STRAINED	SP 72-715 SP 72-490
UK	004-10-83	HP 2 TURBINE DISC SLEEVE	SP 72-932
UK	011-10-85	COMBUSTION SECTION	SP 72-997
SDEW S	TET AT BERTER	OIL SCAVENGE SOLE PLATE  HP COMPRESSOR - STAGE 2 TO 5 ROTOR DISCS  HP SHUT-OFF VALVE PRIMARY STRAINER  HP 2 TURBINE DISC SLEEVE  COMBUSTION SECTION	
SPET	122-12 2FKTE2		
UK	2231 PRF 80	ENGINE - LOW POWER INDICATION FUEL AND AIR TUBES	SP 71-242
UK	2237 PRE 80	ENGINE FUEL AND CONTROL - FUEL TURES	SP 73-A161
UK	2238 PRE 80	HP COMPRESSOR - STAGE 2 TO 5 ROTOR DISCS	SP 72-715
UK	2241 PRE 80	ENGINE - LOW POWER INDICATION FUEL AND AIR TUBES  ENGINE FUEL AND CONTROL - FUEL TUBES HP COMPRESSOR - STAGE 2 TO 5 ROTOR DISCS TURBINE DISC SLEEVES BLEED VALVE MECHANISM HP 2 TURBINE DISC SLEEVE STAGE 12 HP COMPRESSOR DISC AND SEAL HP 1 AND HP 2 TURBINE DISCS COMBUSTION SECTION LP TURBINE ROTOR & INTERSTAGE SEAL LOW PRESSURE TURBINE/INTERSTAGE SEAL H.P. COMPRESSOR STAGE 7 DISCS - REVISED LIVES MOD 6147 TRANSPLY COMBUSTION LINER HEAD SECTION STEEL HP & LP TURBINE DISCS	SP 72-A886
UK	001-10-82	BLEED VALVE MECHANISM	SP 72-A963
UK	004-10-83	HP 2 TURBINE DISC SLEEVE	SP 72-932
UK	009-02-84	HP 1 AND HP 2 TURRINE DISCS	SP 72-969
UK	011-10-85	COMBUSTION SECTION	SP 72-997
UK	005-09-88	LP TURBINE ROTOR & INTERSTAGE SEAL	SP72-1020R1
UK	009-05-88	LOW PRESSURE TURBINE/INTERSTAGE SEAL	SP72-A1019
UK UK	001-07-90	H.P. COMPRESSOR STAGE 7 DISCS - REVISED LIVES	SP72-1034R1
UK	003-09-92	STEEL HD & LD TUDRINE DISCS	SP 72-1038
UK	002-02-97	LP STAGE 2 TURBINE BLADES	SP72-1044 SP72-1045R2
UK	008-08-97	STEEL HP & LP TURBINE DISCS LP STAGE 2 TURBINE BLADES LP TURBINE STAGE 2 NOZZLE GUIDE VANES SEAL SUPPORT LP TURBINE STAGE 2 NOZZLE GUIDE VANE SEAL SUPPORT	SP72-1053R2
UK	007-05-99	LP TURBINE STAGE 2 NOZZLE GUIDE VANE SEAL SUPPORT	SP72-1063
		( SPEY 555-15 SERIES )	
SPEY 5	55-15N	( SPEY 555-15 SERIES ) STAINLESS STEEL EXHAUST COLLECTOR	
UK	005-01-87	STAINLESS STEEL EXHAUST COLLECTOR	SP 78-125
VIPER	E22		
UK	0046 PRF 80	HP COCK OPERATING ROD	73-498
UK	0047 PRE 80	AIR - COMPRESSOR - BLOW-OFF VALVE	75-A31
UK	0048 PRE 80		75-A32
UK	0049 PRE 80	FUEL PUMP BLANKING PLUGS AND CONNECTIONS	73-A101
UK	010-10-80	EXHAUST CONE ASSEMBLY	72-A338
UK	002-07-90	CYCLIC LIFE STAGES 5 & 6 COMPRESSOR DISCS COMPRESSOR CASING / CENTRE SECTION JOINT OIL TANK & OIL PUMP DRAIN VALVES IMPROVED FUEL PUMP THE CONTROL OF TAXABLE DEPOSIT OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE PUMP OF THE P	72-A388R2
UK	030-04-90	OIL TANK & OIL PUMP DRAIN VALVES	72-A381
UK	003-02-96	IMPROVED FUEL PUMP	73-A115R3
UK	008-11-97	FUEL CUNTRUL - BY-PASS VALVE ASSY WASHER	13-A121
UK	011-11-97	FUEL CONTROL - BY-PASS VALVE ASSY WASHER	73-A120
VIPER	601-22		
UK	0041 PRE 80	INNER EXHAUST CONE	72-A69
UK	0042 PRE 80	HIGH PRESSURE FUEL PUMP	73-10
UK	0043 PRE 80	HP COCK OPERATING ROD	73-A13
UK	0044 PRE 80	HP FUEL PUMP	73-A15
UK	0045 PRE 80	MODIFIED FLEXIBLE FUEL TUBE	73-A17 73-A19
UK	020-06-80 012-10-88	FUEL PUMP BLANKING PLUGS AND CONNECTIONS AIR - BLOW-OFF VALVE	75-A19
UK	049-09-89	CYCLIC LIFE STAGES 5 & 6 COMPRESSOR DISCS	72-A154
UK	004-07-90	ENGINE - INSPECT FOR PULLED INSERTS	72-A173
UK	015-04-90	OIL TANK DRAIN VALVE	79-44
UK	009-11-97	INSP AUGMENTOR AND BY-PASS VALVE ASSY WASHER	73-A35
UK	010-11-97	WASHER REPL, AUGMENTOR AND BYPASS VALVE ASSY COMPRESSOR "O" STAGE INSPECTION PROCEDURE	73-A36 72-A176
UK	003-06-99	COMPRESSOR O STRACTION FROM PROCEDURE	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

TELEDYNE CONTINENTA	L	
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
A-65 SERIES US 46-36-01 US 81-07-06 US 94-06-09 US 98-17-11	PISTON PINS FUEL PUMP / FUEL PUMP SCREEN BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CRANKSHAFT INSPECTION	M46-6 M81-8 CSB 641
A-65	( A-65 SERIES )	
A-65-1	( A-65 SERIES )	
A-65-8	( A-65 SERIES )	
A-65-8F	( A-65 SERIES )	
A-65-9J	( A-65 SERIES )	
A-65-12F	( A-65 SERIES )	
A-65-14	( A-65 SERIES )	
A-75 SERIES US 46-36-01 US 81-07-06 US 94-06-09 US 98-17-11	PISTON PINS FUEL PUMP / FUEL PUMP SCREEN BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CRANKSHAFT INSPECTION	M46-6 M81-8 CSB 641
A-75-3	( A-75 SERIES )	
A-75-8	( A-75 SERIES )	
A-75-8F	( A-75 SERIES )	
A-75-9	( A-75 SERIES )	
C-75 SERIES  US 49-50-01  US 81-07-06  US 94-05-05R1  US 94-06-09  US 98-17-11	GENERATOR DRIVE COUPLING RUBBER DISC FUEL PUMP / FUEL PUMP SCREEN CYLINDER ROCKER SHAFT BOSSES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CRANKSHAFT INSPECTION	M49-4 M81-8 CSB 641
C-75-12 US 47-40-02	( C-75 SERIES ) PISTON PINS	M47~9
C-75-12F US 47-40-02	( C-75 SERIES ) PISTON PINS	M47-9
A-80 SERIES US 46-36-01 US 94-06-09	PISTON PINS BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	M46-6 CSB 641
A-80-6	( A-80 SERIES )	
A-80-8	( A-80 SERIES )	
A-80-8F	( A-80 SERIES )	
A-80-9	( A-80 SERIES )	
C-85 SERIES US 49-50-01 US 81-07-06 US 93-22-05 US 94-05-05R1 US 94-06-09 US 98-17-11	GENERATOR DRIVE COUPLING RUBBER DISC FUEL PUMP / FUEL PUMP SCREEN AIR VALVE - CARBURETOR INTAKE HOUSING ASSEMBLY CYLINDER ROCKER SHAFT BOSSES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CRANKSHAFT INSPECTION	M49-4 M81-8 CSB-93-13 CSB 641
C-85-8	( C-85 SERIES )	
C-85-8F	( C-85 SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT

	30021	BULLETIN DE SERVICE DE REF.
TELEDYNE CONTINENTAL C-85-8FJ	( C-85 SERIES )	
C-85-8J	( C-85 SERIES )	
C-85-12 US 47-40-02	( C-85 SERIES ) PISTON PINS	M47-9
<b>C-85-12F</b> US 47-40-02	( C-85 SERIES ) PISTON PINS	M47~9
C-85-12FJ	( C-85 SERIES )	
C-85-12J	( C-85 SERIES )	
C-85-14	( C-85 SERIES )	
C-90 SERIES US 49-50-01 US 81-07-06 US 93-22-05 US 94-05-05R1 US 94-06-09	GENERATOR DRIVE COUPLING RUBBER DISC FUEL PUMP / FUEL PUMP SCREEN AIR VALVE - CARBURETOR INTAKE HOUSING ASSEMBLY CYLINDER ROCKER SHAFT BOSSES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
C-90-8	( C-90 SERIES )	
C-90-8F US 98-17-11	( C-90 SERIES ) CRANKSHAFT INSPECTION	
C-90-8FJ	( C-90 SERIES )	
C-90-12F US 98-17-11	( C-90 SERIES ) CRANKSHAFT INSPECTION	
C-90-14F	( C-90 SERIES )	
C-90-16F	( C-90 SERIES )	
C-125 SERIES US 47-40-02 US 49-50-01 US 81-07-06 US 94-05-05R1 US 94-06-09	PISTON PINS GENERATOR DRIVE COUPLING RUBBER DISC FUEL PUMP / FUEL PUMP SCREEN CYLINDER ROCKER SHAFT BOSSES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	M47-9 M49-4 M81-8 CSB 641
C-125-1	( C-125 SERIES )	
C-125-2 C-145 SERIES	( C-125 SERIES )	
US 49-50-01 US 50-20-01 US 94-05-05R1 US 94-06-09	GENERATOR DRIVE COUPLING RUBBER DISC CRANKCASE / CYLINDER BARRELS CYLINDER ROCKER SHAFT BOSSES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	M49-4 M50-2 CSB 641
C-145-2	( C-145 SERIES )	
C-145-2H	( C-145 SERIES )	
E-165-2 US 50-32-01 US 60-06-04 US 63-15-01	OIL PUMP DRIVE GEAR SHAFT GENERATOR DRIVE GEAR NUT INTERNAL TOOTH LOCKWASHER EXHAUST VALVES	
US 94-06-09 US 97-21-02	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PISTON PIN PLUG WEAR	CSB 641 CSB97-10
US 51-26-03 US 60-06-04 US 63-15-01 US 94-06-09 US 97-21-02	HYDRAULIC VALVE LIFTERS  GENERATOR DRIVE GEAR NUT INTERNAL TOOTH LOCKWASHER EXHAUST VALVES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION PISTON PIN PLUG WEAR	
	( E-185 SERIES ) OIL PUMP DRIVE GEAR SHAFT	M48-14, -15

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE SUBJECT
SUBJECT
SUBJECT

ORIGINE NUMERO DE CO	ONSIGNE SUJET	BULLETIN DE SERVICE DE REF.
TELEDYNE CONTIN E-185-2	NENTAL ( E-185 SERIES )	
E-185-3 US 50-32-01	( E-185 SERIES ) OIL PUMP DRIVE GEAR SHAFT	M48-14, -15
E-185-8 US 60-12-01	( E-185 SERIES ) PISTON PIN ASSEMBLY	
E-185-9 US 60-12-01	( E-185 SERIES ) PISTON PIN ASSEMBLY	
E-185-11 US 60-12-01	( E-185 SERIES ) PISTON PIN ASSEMBLY	
0-200 SERIES US 81-07-06 US 93-10-02 US 93-22-05	CYLINDER VALVE RETAINING KEY AIR VALVE - CARBURETOR INTAKE HOUSING ASSEMBL	M81-8 93-12 Y CSB-93-13
US 94-05-05 US 94-06-09 US 96-12-06 US 96-12-22 US 98-17-11	R1 CYLINDER ROCKER SHAFT BOSSES BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDI CYLINDER HEAD / MAGNETO TIMING ENGINE OIL FILTER ADAPTERS ASSEMBLIES	94-8
0-200-A US 93-11-03	( O-200 SERIES )	
0-200-В	( O-200 SERIES )	
E-225 SERIES US 60-06-04	GENERATOR DRIVE GEAR NUT INTERNAL TOOTH LOCKW	ASHED M57-A
US 63-15-01 US 94-06-09 US 97-21-02	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDI	TION CSB 641
E-225-4 US 60-12-01	( E-225 SERIES ) PISTON PIN ASSEMBLY	
E-225-8 US 60-12-01 US 98-17-11		
E-225-9	( E-225 SERIES )	
IO-240-B		
6-285 SERIES US 91-19-03 US 94-06-09	CHAMPION OIL FILTERS P/N'S CH48108 & CH48109 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDI	TION CSB 641
<b>6-285-B</b> US 74-22-04	( 6-285 SERIES ) CRANKCASE MAIN BEARING OIL SUPPLY PASSAGES	M74-21
US 93-10-02 US 94-05-05F US 94-06-09		93-12 TION CSB 641
US 98-17-11	CRANKSHAFT INSPECTION ( 0-300 SERIES )	
US 93-11-03	CONNECTING ROD	
D-300-C	( D-300 SERIES ) ( D-300 SERIES )	
US 93-11-03	CONNECTING ROD	
US 93-11-03	( D-300 SERIES ) CONNECTING ROD	
GD-300 SERIES US 94-05-05F US 94-06-09		TION CSB 641

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
TELEDYNE CONTINENTAL GO-300-A	( GO-300 SERIES )	
GO-300-C	( GO-300 SERIES )	
GD-300-D	( GD-300 SERIES )	
GD-300-E	( GO-300 SERIES )	
IO-346-A		
US 72-24-03 US 79-05-09	OIL FILTER ADAPTER OIL PRESSURE RELIEF VALVE HOUSING	M66-6 M79-2R1
US 91-19-03 US 94-06-09	CHAMPION OIL FILTERS P/N'S CH48108 & CH48109 BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 95-03-14	ENGINE MOUNT BRACKETS	MSB94-9
ID-360 SERIES US 88-03-06	OIL FILTER	MOO 4
US 91-19-03	CHAMPION DIL FILTERS P/N'S CH48108 & CH48109	M88-4
US 92-04-09 US 93-10-02	ROCKER SHAFT HOLD DOWN STUD FAILURE CYLINDER VALVE RETAINING KEY	M92-4R1 93-12
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
US 97-26-17 US 98-19-02	CRANKSHAFT - AIRMELT OR VACUUM ARC REMELT (VAR) SUPERIOR AIR PARTS PISTON PINS - P/N SA629690	CSB96-8, MSB96-10 SUPERIOR MSB 96-001
ID-360-A	( IO-360 SERIES )	SUPERIOR MISE 96-001
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 74-18-07 US 81-13-10R1	CYLINDER ASSEMBLIES OIL PUMP DRIVE GEAR	
IO-360-AB	(_ID-360 SERIES )	
US 70-14-07 US 74-18-07		M70-10R1
US 81-13-1,0R1	OIL PUMP DRIVE GEAR	
IO-360-C US 70-14-07	( IO-360 SERIES )	M70 4004
US 74-18-07	FUEL INJECTION PUMP ADJUSTING NEEDLE CYLINDER ASSEMBLIES	M70-10R1
US 81-13-10R1 US 98-17-11	OIL PUMP DRIVE GEAR CRANKSHAFT INSPECTION	
IO-360-D	( IO-360 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 74-18-07 US 81-13-10R1	CYLINDER ASSEMBLIES OIL PUMP DRIVE GEAR	
ID-360-G	( IO-360 SERIES )	
US 81-13-10R1	OIL PUMP DRIVE GEAR	
ID-360-GB	( IO-360 SERIES )	
	OIL PUMP DRIVE GEAR	
IO-360-K US 81-13-10R1	( ID-360 SERIES ) OIL PUMP DRIVE GEAR	
IO-360-KB	( IO-360 SERIES )	
US 81-13-10R1	OIL PUMP DRIVE GEAR	
US 91-19-03	CHAMPION OIL FILTERS P/N'S CH48108 & CH48109	
US 92-04-09	ROCKER SHAFT HOLD DOWN STUD FAILURE	M92-4R1
US 93-10-02 US 94-06-09	CYLINDER VALVE RETAINING KEY BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	93-12 CSB 641
US 95-08-10	INSPECT TURBOCHARGER OIL OUTLET CHECK VALVE	CSB 95-1 REV A
US 97-26-17 US 98-19-02	CRANKSHAFT - AIRMELT OR VACUUM ARC REMELT (VAR) SUPERIOR AIR PARTS PISTON PINS - P/N SA629690	CSB96-8, MSB96-10 SUPERIOR MSB 96-001
	( LTSIO-360 SERIES )	
US 81-13-10R1	OIL PUMP DRIVE GEAR	
	( LTSIO-360 SERIES ) OIL PUMP DRIVE GEAR	
US 81-13-10R1 US 81-23-02	OIL FILTER ADAPTER GASKET	10-81

MAKE / CONSTRUCTEUR

MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER SUBJECT
ORIGINE NUMERO DE CONSIGNE SUJET

(SERIES / SERIE)

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF
TELEDYNE CONTINENTAL LTSID-360-KB US 81-13-10R1 US 81-23-02	( LTSID-360 SERIES )	10-81
LTS10-360-RB	( LTSIO-360 SERIES )	
TSIO-360 SERIES US 88-03-06	OIL FILTER	M88-4
US 91-19-03 US 92-04-09	CHAMPION OIL FILTERS P/N'S CH48108 & CH48109 ROCKER SHAFT HOLD DOWN STUD FAILURE	M92-4R1
US 93-10-02 US 94-06-09 US 97-26-17 US 98-19-02	CYLINDER VALVE RETAINING KEY BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CRANKSHAFT - AIRMELT OR VACUUM ARC REMELT (VAR) SUPERIOR AIR PARTS PISTON PINS - P/N SA629690	
TSID-360-A US 71-09-03 US 74-18-07	( TSIO-360 SERIES )  FUEL INJECTION PUMP GASKET  CYLINDER ASSEMBLIES	M70-17
US 81-13-10R1	OIL PUMP DRIVE GEAR	•••••
TSI0-360-C US 74-18-07 US 74-18-08	( TSIO-360 SERIES ) CYLINDER ASSEMBLIES FUEL NOZZLE LINES	M74-5A
US 81-13-10R1	OIL PUMP DRIVE GEAR	107-4 34
TSIO-360-CB US 74-18-07 US 74-18-08	( TSIO-360 SERIES ) CYLINDER ASSEMBLIES FUEL NOZZLE LINES	M74-5A
US 74-18-08 US 81-13-10R1	OIL PUMP DRIVE GEAR	W/4-5A
TS10-360-E US 81-13-10R1 US 95-08-10	( TSIO-360 SERIES ) OIL PUMP DRIVE GEAR INSPECT TURBOCHARGER OIL OUTLET CHECK VALVE	CSB 95-1 REV A
TS10-360-EB US 81-13-10R1 US 81-23-02 US 95-08-10	OIL PUMP DRIVE GEAR OIL FILTER ADAPTER GASKET	10-81 CSB 95-1 REV A
TSID-360-F US 81-13-10R1 US 95-08-10	( TSIO-360 SERIES ) OIL PUMP DRIVE GEAR INSPECT TURBOCHARGER OIL OUTLET CHECK VALVE	CSB 95-1 REV A
TSID-360-FB US 81-13-10R1 US 95-08-10	( TSIO-360 SERIES ) OIL PUMP DRIVE GEAR INSPECT TURBOCHARGER OIL OUTLET CHECK VALVE	CSB 95-1 REV A
TSIO-360-GB US 81-13-10R1 US 81-23-02 US 95-08-10	( TSIO-360 SERIES ) OIL PUMP DRIVE GEAR OIL FILTER ADAPTER GASKET INSPECT TURBOCHARGER OIL OUTLET CHECK VALVE	10-81 CSB 95-1 REV A
TS10-360-H	( TSID-360 SERIES )	CSB 95-1 KEV A
TSIO-360-KB US 81-13-10R1	( TSID-360 SERIES ) OIL PUMP DRIVE GEAR	
US 81-23-02 US 95-08-10	OIL FILTER ADAPTER GASKET INSPECT TURBOCHARGER OIL OUTLET CHECK VALVE	10-81 CSB 95-1 REV A
TSIO-360-LB US 95-08-10		CSB 95-1 REV A
TS10-360-MB	( TSID-360 SERIES )	
TSIO-360-MB1 US 95-08-10	( TSIO-360 SERIES ) INSPECT TURBOCHARGER OIL OUTLET CHECK VALVE	CSB 95-1 REV A
TS10-360-RB	( TSIO-360 SERIES )	
US 56-06-01 US 63-15-01	PISTON PIN / OIL PUMP GEAR / EXHAUST VALVE EXHAUST VALVES	M56-2
US 88-03-06 US 91-19-03	OIL FILTER CHAMPION DIL FILTERS P/N'S CH48108 & CH48109	M88-4
ENGINES / MOTELIPS		IANNIADY / IANNITED 2000

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE
SUJET
SUJET

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
TELEDYNE CONTINENTAL O-470 SERIES (CONTINUED / SUITE) US 93-08-17 US 93-10-02 US 94-06-09 US 96-12-22 US 97-21-02 US 98-01-08 US 98-17-11 US 99-19-01	OIL PICK-UP TUBE CYLINDER VALVE RETAINING KEY BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL FILTER ADAPTERS ASSEMBLIES PISTON PIN PLUG WEAR EXHAUST ROLLER ROCKER ARMS	ATTACHED SKETCH CSB97-10
0-470-A	( O-470 SERIES )	
0-470-B	( O-470 SERIES )	
0-470-G US 79-05-09 US 85-08-02	( D-470 SERIES ) OIL PRESSURE RELIEF VALVE HOUSING CYLINDER ASSEMBLY	M79-2R1 M85-3
0-470-GCI	( O-470 SERIES )	
<b>0-470-J</b> US 73-13-04 US 79-05-09	( O-470 SERIES )  CARBURETOR BOWL DRAIN PLUG OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
0-470-K US 73-13-04 US 79-05-09 US 85-08-02 US 96-12-04	( O-470 SERIES )  CARBURETOR BOWL DRAIN PLUG  OIL PRESSURE RELIEF VALVE HOUSING  CYLINDER ASSEMBLY  SUPERIOR AIR PARTS PISTONS P/N SAG26992, P15	M79-2R1 M85-3
D-470-KC	( D-470 SERIES )	
0-470-L US 73-13-04 US 79-05-09 US 85-08-02 US 96-12-04	( O-470 SERIES ) CARBURETOR BOWL DRAIN PLUG OIL PRESSURE RELIEF VALVE HOUSING CYLINDER ASSEMBLY SUPERIOR AIR PARTS PISTONS P/N SAG26992, P15	M79-2R1 M85-3
<b>D-470-LCK</b> US 73-13-04 US 85-08-02 US 96-12-04	( D-470 SERIES ) CARBURETOR BOWL DRAIN PLUG CYLINDER ASSEMBLY SUPERIOR AIR PARTS PISTONS P/N SA626992, P15	M85-3
<b>US</b> 79-05-09 <b>US</b> 85-08-02	CYLINDER ASSEMBLY	M79-2R1 M85-3
US 73-13-04 US 73-13-04 US 79-05-09 US 85-08-02 US 96-12-04	( O-470 SERIES ) CARBURETOR BOWL DRAIN PLUG OIL PRESSURE RELIEF VALVE HOUSING CYLINDER ASSEMBLY SUPERIOR AIR PARTS PISTONS P/N SA626992, P15	M79-2R1 M85-3
<b>D-470-RCK</b> US 73-13-04 US 85-08-02 US 96-12-04	( O-470 SERIES ) CARBURETOR BOWL DRAIN PLUG CYLINDER ASSEMBLY SUPERIOR AIR PARTS PISTONS P/N SA626992, P15	M85-3
<b>0-470-S</b> US 79-05-09 US 85-08-02	( O-470 SERIES ) OIL PRESSURE RELIEF VALVE HOUSING CYLINDER ASSEMBLY	M79-2R1 M85-3
<b>0-470-U</b> US 79-05-09	( O-470 SERIES ) OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
<b>0-470-UTS</b> US 96-12-04	( O-470 SERIES ) SUPERIOR AIR PARTS PISTONS P/N SA626992, P15	
0-470-4	( 0-470 SERIES )	
0-470-11	( D-470 SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
TELEDYNE CONTINENTAL		
0-470-11B	( O-470 SERIES )	
0-470-15	( D-470 SERIES )	
0-470-15	( U TIU SERIES )	
0-470-50	( O-470 SERIES )	
IO-470 SERIES		****
US 88-03-06	OIL FILTER	M88-4
US 91-19-03	CHAMPION OIL FILTERS P/N'S CH48108 & CH48109	M91-10R1
US 93-08-17 US 93-10-02	OIL PICK-UP TUBE CYLINDER VALVE RETAINING KEY	93-12
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	
115 96-12-22	FNGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US 97-21-02	PISTON PIN PLUG WEAR	CSB97-10
US 98-17-11	CRANKSHAFT INSPECTION	
US 99-19-01	CRANKSHAFT NDT INSPECTION	MSB 99-3C
ID-470-A	( IO-470 SERIES )	
IO-470-A	( 10 4/0 JERIES )	
ID-470-C	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US 85-08-02	CYLINDER ASSEMBLY	M85-3
10 470 0	( 10 470 CEDIEC )	
US 70-14-07	( ID-470 SERIES ) FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 70-14-07	CYLINDER ASSEMBLIES	M73-2
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
IO-470-DCE	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 72-20-02	CYLINDER ASSEMBLIES ADJUSTING NEEDLE	M73-2 M79-2R1
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M7 5-2K1
IO-470-E	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 72-20-02	CYLINDER ASSEMBLIES	M73-2
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
	( and Convey )	
IO-470-F	( IO-470 SERIES )	M70-10R1
US 70-14-07 US 72-20-02	FUEL INJECTION PUMP ADJUSTING NEEDLE CYLINDER ASSEMBLIES	M70-10R1 M73-2
US 72-20-02 US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79~2R1
, , , , , , , , , , , , , , , , , , , ,	TE THEODORG HEERE THEY HOUSEN	
IO-470-H	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 72-20-02	CYLINDER ASSEMBLIES	M73-2
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
IO-470-J	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
ID-470-K	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
10-470-1	( 10-470 SERIES )	
IO-470-L US 70-14-07	( IO-470 SERIES ) FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 72-20-02	CYLINDER ASSEMBLIES	M73-2
US 77-05-04	PROPELLER OPERATION / DIL FILTER / CRANKSHAFT	M77-6
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
	( )	
IO-470-M	( IO-470 SERIES )	M70-1001
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1 M73-2
US 72-20-02	CYLINDER ASSEMBLIES	MI S Z
ID-470-N	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 72-20-02	CYLINDER ASSEMBLIES	M73-2
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
TO-470-B	( IO_470 SERIES )	
10-470-P	( IO-470 SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE	(SERIES / SERIE)	
ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT	REFERENCE SERVICE BULLETIN
		BULLETIN DE SERVICE DE REF.
TELEDYNE CONTINENTA		
IO-470-S US 70-14-07	( IO-470 SERIES )	
US 72-20-02	FUEL INJECTION PUMP ADJUSTING NEEDLE CYLINDER ASSEMBLIES	M70-10R1
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M73-2 M79-2R1
		W/9-2R1
IO-470-U US 70-14-07	( IO-470 SERIES )	
US 70-14-07 US 72-20-02	FUEL INJECTION PUMP ADJUSTING NEEDLE CYLINDER ASSEMBLIES	M70-10R1
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M73-2 M79-2R1
		W/79-2R1
ID-470-V	( IO-470 SERIES )	
US 70-14-07 US 72-20-02	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
US 79-05-09	CYLINDER ASSEMBLIES OIL PRESSURE RELIEF VALVE HOUSING	M73-2 M79-2R1
		W/79-2R1
IO-470-VO	( IO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
TSIO-470 SERIES		
US 72-20-02	CYLINDER ASSEMBLIES	M73-2
US 75-09-13	TURBOCHARGER OIL INLET ADAPTERS	
US 88-03-06	OIL FILTER	M88-4
US 91-19-03 US 93-10-02	CHAMPION DIL FILTERS P/N'S CH48108 & CH48109 CYLINDER VALVE RETAINING KEY	02.40
US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	93-12 CSR 641
US 96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	
US 99-19-01	CRANKSHAFT NDT INSPECTION	MSB 99-3C
ТЅ10-470-В	( TCIO-470 CEDIEC )	
US 70-14-07	( TSID-470 SERIES )  FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
	TOLE INCLUTION TOWN ADDOCTING NEEDLE	MI/O-TORT
TSID-470-C	( TSIO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
TS10-470-D	( TSIO-470 SERIES )	
US 70-14-07	FUEL INJECTION PUMP ADJUSTING NEEDLE	M70-10R1
O-520 SERIES		
US 96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
0-520-FTS	( 0-520 SERIES )	
D-520-KAH-1	( O-520 SERIES )	
GTSIO-520 SERIES		
US 80-09-11	STARTER TORSIONAL DAMPENER / GEAR SHAFT	
US 86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
US 88-03-06	OIL FILTER	M88-4
US 91-19-03	CHAMPION OIL FILTERS P/N'S CH48108 & CH48109 CYLINDER VALVE RETAINING KEY	92-12
US 93-10-02 US 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	93-12 CSB 641
US 96-12-22	ENGINE OIL FILTER ADAPTERS ASSEMBLIES	ATTACHED SKETCH
US 98-17-11	CRANKSHAFT INSPECTION	
US 99-19-01	CRANKSHAFT NDT INSPECTION	MSB 99-3C
GTS10-520-C	( GTSIO-520 SERIES )	
US 75-09-13	TURBOCHARGER OIL INLET ADAPTERS	
US 77-13-22	ENGINE CRANKCASE	M77-14
05 /9-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US 81-24-06	FUEL PUMP	M-80-26R1
GTS10-520-D	( GTSIO-520 SERIES )	
US 75-09-13	TURBOCHARGER OIL INLET ADAPTERS	
US 77-13-22	ENGINE CRANKCASE	M77-14
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING FUEL PUMP	M79-2R1 M-80-26R1
US 81-24-06	FUEL PUMP	
GTS10-520-H	( GTSIO-520 SERIES )	
US 75-09-13	TURBOCHARGER OIL INLET ADAPTERS	1477 44
US 77-13-22	ENGINE CRANKCASE	M77-14 M79-2R1
US 79-05-09 US 81-24-06	OIL PRESSURE RELIEF VALVE HOUSING FUEL PUMP	M-80-26R1
50 51 24 06	. CEE 1 ON	

MAKE / CONSTRUCTEUR

MAKE / CONSTRUCTEUR (SERIES / SERIE) MODEL / MODELE ORIGIN AD NUMBER SUBJECT
ORIGINE NUMERO DE CONSIGNE SUJET REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF. TELEDYNE CONTINENTAL GTS10-520-L US 79-05-09 ( GTSIO-520 SERIES ) OIL PRESSURE RELIEF VALVE HOUSING
OIL PRESSURE CHECK 80-25-06R1 M79-2R1 M80-30 81-24-06 FUEL PUMP M-80-26R1 115 520-M (GTSIO-520 SERIES ) GTS10-520-M OIL PRESSURE RELIEF VALVE HOUSING M79-2R1 US 80-25~06R1 OIL PRESSURE CHECK M80-30 US 81-24-06 FUEL PUMP M-80-26R1 GTS10-520-N OIL PRESSURE CHECK M80-30 M-80-26R1 LEAR SIGLER ROMEC ROTARY FUEL PUMPS M87-6 IO-520 SERIES US 77-13-22 ENGINE CRANKCASE M77-14 115 115 115 US US US US 98-17-11 99-19-01 CRANKSHAFT INSPECTION
CRANKSHAFT NOT INSPECTION 115 MSB 99-30 ( 10-520 SERIES )

FUEL INJECTION PUMP ADJUSTING NEEDLE

OIL PRESSURE RELIEF VALVE HOUSING ID-520-A US 70-14-07 US 79-05-09 M70-10R1 M79-2R1 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 US US 70-14-07 FUEL INJECTION US 72-24-03 US 90-14-03 IO-520-B FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1 OIL FILTER ADAPTER M66-6 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 ( IO-520 SERIES ) IO-520-BA US 70-14-07 FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1 US 72-24-03 OIL FILTER ADAPTER M66-6 OIL PRESSURE RELIEF VALVE HOUSING 115 79-05-09 M79-2R1 86-13-04R3 87-14-02 88-17-03 CYLINDER HEAD / BARREL M86-7R5, M87-19 STARTER ADAPTER SHAFTGEAR / FREON COMPRESSOR US M87-13 STARTER ADAPTER SHAFTGEAR ASSEMBLY 115 M87-24, M88-5, -6 O-520-BB (IO-520 SERIES )

US 70-14-07 FUEL INJECTION PUMP ADJUSTING NEEDLE

US 72-24-03 OIL FILTER APPIER

US 72-05-09 OIL PRESSIDE PELIFE VALVE HOUSING IO-520-BB M70-10R1 M66-6 OIL PRESSURE RELIEF VALVE HOUSING US 79-05-09 M79-2R1 79-05-09 OIL PRESSURE RELIEF VALVE HOUSING
86-13-04R3 CYLINDER HEAD / BARREL
87-14-02 STARTER ADAPTER SHAFTGEAR / FREON COMPRESSOR M86-7R5, M87-19 115 US M87-13 US 88-17-03 STARTER ADAPTER SHAFTGEAR ASSEMBLY M87-24, M88-5, -6 70-14-07 (ID-520 SERIES )
70-14-07 FUEL INJECTION
72-24-03 OIL FILTER AD79-05-09
86-13-047 IO-520-C US FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1 OIL FILTER ADAPTER 115 M66-6 OIL PRESSURE RELIEF VALVE HOUSING US M79-2R1 86-13-04R3 CYLINDER HEAD / BARREL ENGINE MOUNT BRACKETS US M86-7R5, M87-19 95-03-14 115 MSRQ1-Q IO-520-CB ( IO-520 SERIES ) 70-14-07 FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1 115 72-24-03 79-05-09 US OIL FILTER ADAPTER US OIL PRESSURE RELIEF VALVE HOUSING M79-2R1 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 ENGINE MOUNT BRACKETS US 95-03-14 MSB94-9 ( 10-520 SERIES ) TO-520~D US 70-14-07 FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE TELEDYNE CONTINENTAL IO-520-D ( IO-(CONTINUED / SUITE) ( ID-520 SERIES ) US 77-05-04 US 79-05-09 PROPELLER OPERATION / OIL FILTER / CRANKSHAFT OIL PRESSURE RELIEF VALVE HOUSING M79-2R1 US 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 10-520-Е ( IO-520 SERIES ) US 70-14-07 FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10P1 OIL PRESSURE RELIEF VALVE HOUSING 79-05-09 US M79-2R1 US 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 IO-520-F ( IO-520 SERIES ) US 70-14-07 US 77-05-04 US 79-05-09 FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1 PROPELLER OPERATION / OIL FILTER / CRANKSHAFT M77-6
OIL PRESSURE RELIEF VALVE HOUSING M79-2R M79-2R1 86-13-04R3 US CYLINDER HEAD / BARREL M86-7R5, M87-19 ( 10-520 SERIES ) 70-14-07 FUEL INJECTIO 86-13-04R3 IO-520-J US FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1 LIS CYLINDER HEAD / BARREL M86-7R5, M87-19 -K ( ID-520 SERIES ) ID-520-K US FUEL INJECTION PUMP ADJUSTING NEEDLE M70-10R1 US 79-05-09 OIL PRESSURE RELIEF VALVE HOUSING M79-2R1 115 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 0-520-L US 77-05-04 79-05-09 ( IO-520 SERIES ) 520 SERIES )
PROPELLER OPERATION / OIL FILTER / CRANKSHAFT M77-6
OIL PRESSURE RELIEF VALVE HOUSING M79-2R1 US 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 IO-520-M ( IO-520 SERIES )
US 79-05-09 OIL PRESSURE IO-520-M OIL PRESSURE RELIEF VALVE HOUSING M79-2R1 US 86-13-04R3 CYLINDER HEAD / BARREL M86-7R5, M87-19 IO-520-MB ( IO-520 SERIES ) US 79-05-09 OIL PRESSURE RELIEF VALVE HOUSING M79-2R1 CYLINDER HEAD / BARREL 86-13-04R3 M86-7R5, M87-19 LTSIO-520-AF CHAMPION OIL FILTERS P/N'S CH49108 & CH48109 US 91-19-03 93-10-02 CYLINDER VALVE RETAINING KEY US CRANKSHAFT - AIRMELT OR VACUUM ARC REMELT (VAR) US 97-26-17 CSB96-8, MSB96-10 CRANKSHAFT NDT INSPECTION MSB 99-3C US 99-19-01 TSIO-520 SERIES SIO-520 SERILU
US 80-01-04
US 81-24-06
US 87-23-08 CYLINDER HOLDDOWN FLANGES M-80-26R1 FUEL PUMP CRANKSHAFT M87-5R1 88-03-06 OIL FILTER M88-4 US CHAMPION OIL FILTERS P/N'S CH48108 & CH48109 91-19-03 93-08-17 OIL PICK-UP TUBE M91-10R1 115 CYLINDER VALVE RETAINING KEY 93-12
FUEL PUMP DRIVE COUPLING M93-9R1
BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION CSB 641 LIS 93-10-02 93-10-02 93-16-15 94-06-09 96-12-22 97-26-17 98-01-08 US US ENGINE OIL FILTER ADAPTERS ASSEMBLIES
CRANKSHAFT - AIRMELT OR VACUUM ARC REMELT (VAR)

ATTACHED SKETCH
CSB96-8, MSB96-10 US US EXHAUST ROLLER ROCKER ARMS
CRANKSHAFT NDT INSPECTION US MSB 99-3C 99-19-01 115

86-13-04R3 89-24-01R1 US 20 JANUARY/JANVIER 2000

TSI0-520-AE

TSIO-520-B

US

US

US

US

US

TS10-520-AF

US 86-13-04R3

69-18-05

71-09-03 72-24-03

75-05-12 77-13-22 79-05-09

75-09-13

ENGINES/MOTEURS

M86-7R5, M87-19

M86-7R5, M87-19

M69-8

M66-6

M70-17

M79-2R1

M90-6

TURBOCHARGER OIL SCAVENGE PUMP DRIVE GEAR

( TSIO-520 SERIES )

( TSIO-520 SERIES )

( TSIO-520 SERIES )

CYLINDER HEAD / BARREL

OIL FILTER ADAPTER

CYLINDER HEAD / BARREL

SCAVENGE OIL PUMP GEARS

FUEL INJECTION PUMP GASKET

TURBOCHARGER OIL INLET ADAPTERS
ENGINE CRANKCASE

OIL PRESSURE RELIEF VALVE HOUSING

MODEL /	NSTRUCTEUR MODELE	(SERIES / SERIE)	DECEDENCE CEDVICE BUILTETIN
ORIGIN ORIGIN	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
	'NE CONTINENTAL -520-BB	( TSIO-520 SERIES )	
US	69-18-05	TURBOCHARGER OIL SCAVENGE PUMP DRIVE GEAR	M69-8
US	71-09-03	FUEL INJECTION PUMP GASKET	M70-17
US	72-24-03	OIL FILTER ADAPTER	M66-6
US	77-13-22	ENGINE CRANKCASE	M77-14
US	79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US	86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
US	89-24-01R1	SCAVENGE OIL PUMP GEARS	M90-6
TSIO-	-520-BE	( TSIO-520 SERIES )	·
US	69-18-05	TURBOCHARGER OIL SCAVENGE PUMP DRIVE GEAR	M69-8
US	71-09-03	FUEL INJECTION PUMP GASKET	M70-17
US	72-24-03	OIL FILTER ADAPTER	M66-6
US	77-13-22	ENGINE CRANKCASE	M77-14
US	84-19-04	ENGINE DRIVEN FUEL PUMP	
US	84-25-05	TURBOCHARGER OIL SCAVANGE RESERVOIR	
US	86-08-07	ENGINE DRIVEN FUEL PUMP	MOO EDE MOE 10
US	86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
US	87-14-02	STARTER ADAPTER SHAFTGEAR / FREON COMPRESSOR	M87-13
US	87-26-08	CRANKSHAFT - PISTON PINS	M87-25
US	88-17-03	STARTER ADAPTER SHAFTGEAR ASSEMBLY	M87-24, M88-5, -6
US	89-14-01	CRANKSHAFT	M89-14
TSIO-	-520-C	( TSIO-520 SERIES )	
US	70-13-03	BALANCE TUBE ASSEMBLY	M70-5
US	77-05-04	PROPELLER OPERATION / OIL FILTER / CRANKSHAFT	M77-6
US	77-13-22	ENGINE CRANKCASE	M77-14
US	79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US	86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
	.,		
	-520-D	( TSIO-520 SERIES )	8800 0
US	69-18-05	TURBOCHARGER OIL SCAVENGE PUMP DRIVE GEAR	M69-8
US	71-09-03	FUEL INJECTION PUMP GASKET	M70-17
US	75-09-13	TURBOCHARGER DIL INLET ADAPTERS ENGINE CRANKCASE	M77-14
US	77-13-22	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US US	79-05-09 89-24-01R1	SCAVENGE DIL PUMP GEARS	M90-6
03	05-24 OIKI	SCAVENGE DIE FUMF GEARS	1.130 0
TSIO-	-520-E	( TSIO-520 SERIES )	
US	69-18-05	TURBOCHARGER OIL SCAVENGE PUMP DRIVE GEAR	M69-8
US	71-09-03	FUEL INJECTION PUMP GASKET	M70-17
US	72-24-03	CIL FILTER ADAPTER	M66-6
US	75-09-13	TURBOCHARGER OIL INLET ADAPTERS	
US	77-13-22	ENGINE CRANKCASE	M77-14
US	79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US	86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
US	89-24-01R1	SCAVENGE OIL PUMP GEARS	M90-6
TSIO-	-520-EB	( TSIO-520 SERIES )	
US	69-18-05	TURBOCHARGER OIL SCAVENGE PUMP DRIVE GEAR	M69-8
US	71-09-03	FUEL INJECTION PUMP GASKET	M70-17
US	72-24-03	OIL FILTER ADAPTER	M66-6
US	77-13-22	ENGINE CRANKCASE	M77-14
US	79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US	86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
US	89-24-01R1	SCAVENGE OIL PUMP GEARS	M90-6
TOTO	500 H	( TCIO EQO CEDIFC )	
	-520-H -77-05-04	( TSIO-520 SERIES ) PROPELLER OPERATION / OIL FILTER / CRANKSHAFT	M77-6
US US	77-05-04	ENGINE CRANKCASE	M77-14
US	77-13-22 79-05 <b>-</b> 09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US	86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
	30 10 0110		
	-520-J	( TSIO-520 SERIES )	
US	71-09-03	FUEL INJECTION PUMP GASKET	M70-17
US	72-24-03	OIL FILTER ADAPTER	M66-6
US	75-09-13	TURBOCHARGER OIL INLET ADAPTERS	****
US	77-13-22	ENGINE CRANKCASE	M77-14
US	78-06-01	INDUCTION SYSTEM INTAKE TUBE	M70 004
US	79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US	82-09-01	FUEL PRESSURE REGULATOR	M82-5
US	86-13-04R3	CYLINDER HEAD / BARREL SCAVENGE DIL PUMP GEARS	M86-7R5, M87-19 M90-6
US	89-24-01R1	SCAVENGE UIL PUMP GEARS	מ-ספויו

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT SUJET

		BULLETIN DE SERVICE DE REF.
TELEDYNE CONTINENT	AL	
TS10-520-K	( TSIO-520 SERIES )	
US 75-09-13	TURROCHARCER OTL TANKET ARABET	
US 77-13-22		M77-14
		M79-2R1
05 82-09-01	OIL PRESSURE RELIEF VALVE HOUSING FUEL PRESSURE REGULATOR CYLINDER HEAD / BARREL	M82-5
US 89-24-01R1	CYLINDER HEAD / BARREL	M86-7R5, M87-19
05 05 24 OTKT	SCAVENGE DIL PUMP GEARS	M90-6
TS10-520-L	( TSIO-520 SERIES )	
US 76-13-09	EXHAUST ELBOW / TURBO ADAPTER	M7C-14
US 77-13-22	ENGINE CRANKCASE	M77-14
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US 86-13-04R3		1400 000 000
US 88-17-03	STARTER ADAPTER SHAFTGEAR ASSEMBLY	M87-24, M88-5, -6
TSID-520-M	( TSID-520 SERIES )	
US 77-05-04		
US 79-05-09	PROPELLER OPERATION / OIL FILTER / CRANKSHAFT OIL PRESSURE RELIEF VALVE HOUSING	M77-6
US 79-05-09 US 80-22-05	CRANKSHAFT FRONT OIL SEAL	M79-2R1 M80-20
US 86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
		710, 710
TSI0-520-N	( TSIO-520 SERIES )	
US 77-13-22	ENGINE CRANKCASE	M77-14
US 78-06-01 US 79-05-09	INDUCTION SYSTEM INTAKE TUBE	
US 82-09-01	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US 86-13-04R3	FUEL PRESSURE REGULATOR CYLINDER HEAD / BARREL	M82-5
US 89-24-01R1	SCAVENGE OIL PUMP GEARS	M86-7R5, M87-19 M90-6
	SOMETIME SIE FORM GEARS	14190-6
TSI0-520-NB	( TSIO-520 SERIES )	
US 77-13-22	ENGINE CRANKCASE	M77-14
US 78-06-01	INDUCTION SYSTEM INTAKE TUBE	
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US 82-09-01	UIL PRESSURE RELIEF VALVE HOUSING FUEL PRESSURE REGULATOR CYLINDER HEAD / BARREL	M82-5
US 89-24-01R1	SCAVENGE OIL PUMP GEARS	
05 05 24 OTKT	SCAVENGE OIL POWP GEARS	M90-6
TS10-520-P	( TSIO-520 SERIES )	
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US 80-22-05	CRAINSHAFT FRUNT UIL SEAL	M80-20
US 86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
TS10-520-R	7.00 500 550 550	
US 77-05-04	( TSIO-520 SERIES ) PROPELLER OPERATION / OIL FILTER / CRANKSHAFT	M77-C
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M77-6 M79-2R1
	CRANKSHAFT FRONT OIL SEAL	
US 86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
TS10-520-T	( TSIO-520 SERIES )	
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1
US 86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
TS10-520-UB	( TSIO-520 SERIES )	
US 86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
US 87-14-02	STARTER ADAPTER SHAFTGEAR / FREON COMPRESSOR	M87-13
US 88-17-03	STARTER ADAPTER SHAFTGEAR / FREON COMPRESSOR STARTER ADAPTER SHAFTGEAR ASSEMBLY SCAVENGE OIL PUMP GEARS	M87-24, M88-5, -6
		M90-6
US 89-24-03	TURBOCHARGER INLET ASSEMBLY	BEECH SB # 70
7570 F00 ::=	( TOTO FOR SERVES )	
TSIO-520-VB	( TSIO-520 SERIES )	M70-204
US 79-05-09	OIL PRESSURE RELIEF VALVE HOUSING	M79-2R1 M86-7R5, M87-19
US 86-13-04R3 US 89-24-01R1	CYLINDER HEAD / BARREL SCAVENGE OIL PUMP GEARS	M90-6
US 98-17-11	CRANKSHAFT INSPECTION	
TSI0-520-WB	( TSIO-520 SERIES )	
US 86-13-04R3	CYLINDER HEAD / BARREL	M86-7R5, M87-19
US 87-14-02	STARTER ADAPTER SHAFTGEAR / FREON COMPRESSOR	M87-13
US 88-17-03	STARTER ADAPTER SHAFTGEAR ASSEMBLY	M87-24, M88-5, -6
IO-550 SERIES		
US 88-03-06	OIL FILTER	M88-4
US 91-19-03	CHAMPION OIL FILTERS P/N'S CH48108 & CH48109	
	OTI BICK-IID TUBE	M91-10R1
US 93-08-17	OIL PICK-UP TUBE	M91-TORT

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE SUBJECT
SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SOJET	BULLETIN DE SERVICE DE REF.
10-550	NE CONTINENTAL D SERIES NUED / SUITE)		
US US US	93-10-02 93-16-15 94-06-09 96-12-22	CYLINDER VALVE RETAINING KEY FUEL PUMP DRIVE COUPLING BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION ENGINE OIL FILTER ADAPTERS ASSEMBLIES	93-12 M93-9R1 CSB 641 ATTACHED SKETCH
US	98-01-08 99-19-01	EXHAUST ROLLER ROCKER ARMS CRANKSHAFT NDT INSPECTION	MSB 99-3C
	96-13-04R3 87-14-02 88-17-03	( IO-550 SERIES )  CYLINDER HEAD / BARREL  STARTER ADAPTER SHAFTGEAR / FREON COMPRESSOR  STARTER ADAPTER SHAFTGEAR ASSEMBLY	M86-7R5, M87-19 M87-13 M87-24, M88-5, -6
ID-550 US US	95-03-14	( IO-550 SERIES ) CYLINDER HEAD / BARREL ENGINE MOUNT BRACKETS	M86-7R5, M87-19 MSB94-9
10-550	)-D	( IO-550 SERIES )	
10-550	)-F	( IO-550 SERIES )	
10-550	)-L	( IO-550 SERIES )	
US	93-10-02 99-19-01	CYLINDER VALVE RETAINING KEY CRANKSHAFT NDT INSPECTION	93-12 MSB 99-3C
TS10-5	550-C	( TSIO-550 SERIES )	
R-670 US	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
<b>W-670</b> - US	- <b>6A</b> 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
<b>W-670</b> - US	- <b>6N</b> 94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
W-670-			
	94-06-09	BENDIX MAGNETOS CAPACITORS/OPEN CIRCUIT CONDITION	CSB 641
W-670-			
FR	1 SERIES 90-064(B)	MONITORING OF VIBRATIONS	
FR	92-078(B)R2 98-311(A)R1 98-394(A)	REDUCTION GEARBOX MODULE (MO 5 ) PINION 2ND STAGE NOZZLE GUIDE VANES (NGV2) GAS GENERATOR - REAR BEARING	292.72.0157 292.72.0181R3, R4 292.72.0163R1
ARRIEL FR FR FR FR FR	1B 79-252(B) 86-029(B) 86-147(B) 95-069(B)R1 98-493(A)	( ARRIEL 1 SERIES )  REDUCTION GEARS - MAGNETIC DRAIN PLUGS TURBINE CASING REAR BEARING OIL PRESSURE LINE FREE POWER TURBINE FREEWHEEL REAR BEARING SUPPORT	72-292-0021 72-292-0093 72-292-088 292-72-0208 292.72.0213
ARRIEL FR	1D 95-069(B)R1	( ARRIEL 1 SERIES )	292-72-0208
FR	1999-391(A)	INSTALLATION OF A SLEEVE IN THE BLEED VALVE BOSS  ( ARRIEL 1 SERIES )	292 72 0261
FR	95-069(B)R1 1999-391(A)	FREE POWER TURBINE FREEWHEEL INSTALLATION OF A SLEEVE IN THE BLEED VALVE BOSS	292-72-0208 292 72 0261
ARRIEL FR		( ARRIEL 1 SERIES ) INSTALLATION OF A SLEEVE IN THE BLEED VALVE BOSS	292 72 0261
	- <b>151</b> 1999-391(A)	( ARRIEL 1 SERIES ) INSTALLATION OF A SLEEVE IN THE BLEED VALVE BOSS	292 72 0261

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CON

(SERIES / SERIE)
SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
TURBOM	ECA		
	L 2 SERIES		
ARRIE	L 2B	( ARRIEL 2 SERIES )	
FR	1999-285(A)	FUEL PUMP MATERIAL THICKNESS	292 73 2803
FR	1999-392(A)	INSTALATION OF A SLEEVE IN THE BLEED VALVE BOSS	292 72 2054
	L 251	( ARRIEL 2 SERIES )	
FR FR	1999-126(A) 1999-285(A)	HYDROMECHANICAL UNIT	292 73 2039
FR	1999-392(A)	FUEL PUMP MATERIAL THICKNESS INSTALATION OF A SLEEVE IN THE BLEED VALVE BOSS	292 73 2803
ARRIU	S 2F		202. 12. 2004
	1999-233(A)	REPLACEMENT OF FUEL INJECTOR MANIFOLDS	A 319 73 4001 NO.2
APTOIL	STE IIIB		
FR	64-003-001	MICRO-PUMP ASSEMBLY	
FR FR	64-004-002 98-432(A)	START LIMITATIONS	
FR	1999-005(A)	REAR FACE OF THE INJECTION WHEEL ELECTRICAL FUEL COCK	218-72-0099 218-80-0093
ARTOU	CTE IIID4		2.5 00 0055
FR	STE III <b>B1</b> 98-432(A)	REAR FACE OF THE INJECTION WHEEL	218-72-0099
FR	1999-005(A)	ELECTRICAL FUEL COCK	218 80 0093
ASTAZO	DU II A		
FR	73-045	COMPRESSOR ROTOR	
ASTAZO	A III UC		
MAKILA	Λ 1Λ		
FR	83-211(B)	FUEL CONTROL	73-298-0017
	85-113(B) 91-226(B)	GAS GENERATOR/POWER TURBINE OIL PRESSURE LINES	72-298-0034,035
	98-075(A)	FCU - MODIFICATION MASTER & AUXILIARY CAMS DISCONTINUE USE OF 7,5 CST OIL	72-298-00-59 A298.71.0137
	DIVISION		
SCARAE			
US	51-04-02	CYLINDER HOLDDOWN NUTS / STUDS	A-17
	SCARAB 50		
US	51-04-02	CYLINDER HOLDDOWN NUTS / STUDS	A-17
	SCARAB 165		
US	51-04-02	CYLINDER HOLDDOWN NUTS / STUDS	A-17
	SCARAB 185J		
US	51-04-02	CYLINDER HOLDDOWN NUTS / STUDS	A-17
	SCARAB 185K	OVERTICAL PROPERTY AND A CONTROL	4.47
US	51-04-02	CYLINDER HOLDDOWN NUTS / STUDS	A-17
WILLIAM			
FJ44-1 US	97-01-05	HIGH PRESSURE TURBINE (HPT) DISKS	ASB FJ44-A72-30
US	99-07-04	HIGH PRESSURE TURBINE DISK	FJ44-A-72-38
WSK PZL	. KALISZ		
AI-14R	lA		
	IR-M18		
PL PL	56/BD/86	LOCKING NUT & LEVER BAROMETRIC FUEL CONTROL UNIT ADDITION TO APPROVED OIL LIST	56/BD/86 91/E/95
	91/E/95	ADDITION TO AFFROYED OIL LIST	51, 2, 35
WSK PZL PZL-3S	RZESZOW		
CF	CF-83-27R2	DOWTY ROTL PROP CR289/3-110-F/1, /11, /12 PROHIBIT	50/PZL-3S/83
PL	77/PZL-3S/87	AIRWORTHINESS LIMITATIONS	77/PZL-3S/87 83/PZL-3S/89
PL PL	83/PZL-3S/89 84/PZL-3S/89	IGNITION LEADS OPERATING & SERVICING MANUAL CHANGES	83/PZL-35/89 84/PZL-3S/89
PL	86/PZL-3S/90	OPERATION OF C1 VERSION OF PZL-3S ENGINE	86/PZL-3S/90
PL	87/PZL-3S/90	OPERATING & SERVICING MANUAL CHANGES	87/PZL-3S/90

MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO D	(SERIES / SERIE) R SUBJECT SE SUJET	REFERENCE SERVICE BUILTIN
ORIGINE NUMERO D	E CONSIGNE SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
·		

MAKE /	co	NST	RU	CT	EUR
MODE	1 /	MO	DEI	E	

(SERIES / SERIE) AD NUMBER NUMERO DE CONSIGNE

SUBJECT

	20351	BULLETIN DE SERVICE DE REF
AEROPRODUCTS		
<b>A6441FN-606</b> US 60-17-01	BLADE THRUST MEMBER THICKNESS	7271 1 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
US 65-05-01	PROPELLER BLADE CRACKS / FAILURES	63-125, 63-127 82
US 65-06-02 US 67-08-01	CUFF RING FATIGUE CRACKS PROPELLER CHANGE	168
US 67-17-01	PROPELLER FIXED SPLINE	
US 67-20-01 US 74-10-07	PITCH LOCK RESTRICTER / MASTER GEAR RETENTION BOLT	63-317
US 79-24-07	LIFE LIMITS / CORROSION & REPLATING FLUORESCENT MAGNETIC PARTICLE INSPECTION	
	A TANTIOLE INST ECTION	
A6441FN-606A US 67-08-01	PROPELLER CHANGE	
US 67-17-01	PROPELLER FIXED SPLINE	
US 67-20-01 US 74-10-07	PITCH LOCK RESTRICTER / MASTER GEAR RETENTION BOLT LIFE LIMITS / CORROSION & REPLATING	63-317
US 79-24-07	FLUORESCENT MAGNETIC PARTICLE INSPECTION	
AVCO LYCOMING		
F220		
AVIA		
V500A		
CK V 500A/6A	INSPECTION OF OIL DISTRIBUTOR FLANGE FOR CRACKS	V 500A/6A
CK V 500A/7A CK V 500A/8A	INSPECTION OF P 7900.01 DIL DISTRIBUTION FLANGE ALTERNATE OVERHAUL PERIODS	V 500A/6A
	THE OF ELVINOR 1 ELVIDOO	
BEECH B200-3A799		Advantage
US 76-10-12	BLADE SURFACE DETERIORATION / CRACKS	
215~1~07		
215-1-09		
215-207-88		
278 SERIES		
US 62-17-01	WELDS - AFT SIDE HUB BARREL / HYDRAULIC CYLINDER	6
US 77-11-03	PITCH CONTROL BOLTS / STEEL PITCH CONTROL YOKE	SI 0302-248
278	( 278 SERIES )	
278-100-1	( 278 SERIES )	
278-100-7	( 278 SERIES )	
278-100-7H	( 278 SERIES )	
279-100		
CHRITEC		
CURTISS C644S-B314		
US 53-05-01	PROP SLIP RING, BRUSH CAP CONNECTOR PLUG & HARNESS	
55501		
55518		
33310		
DEHAVILLAND PD143/312/1		
PD237/323/1		
DOWTY ROTOL R139/4-20-4/19E		
UK 1211 PRE 80		61-A753
UK 1212 PRE 80		61-754 VP 1941
UK 1236 PRE 80 UK 1239 PRE 80	NEW OPERATING CYLINDER INTRODUCED	VP 2480
UK 1240 PRE 80	LOCKING SEGMENTS FOR BLADE BEARING RETAINING BOLTS	
UK 1243 PRE 80 UK 1244 PRE 80		61-A521 61-521
UK 1245 PRE 80		61-380

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMBER SUBJECT
ORIGINE NUMBERO DE CONSIGNE SUJET

DRIGINE	NUMERO DE CONSIGNE	2015)	BOLLETIN DE SERVICE DE RET.
DOWTY I	ROTOL		
R139/	4-20-4/19E		
	NUED / SUITE)		
	1246 PRE 80	OPERATING PINS - INSPECTION FOR CRACKING	61-711
UK	1247 PRE 80	OPERATING PINS - INSPECTION FOR CRACKING EYEBOLT & OPERATING LINK GROUP - SEIZURE	61-4753
UK	1247 FRE 80	DE-EMBRITTLEMENT OF LINKS, LINK PINS & EYEBOLTS	
UK	1248 PRE 80	DEFENDENT OF LINES, LINE FINS & LILLOUIS	VD 0070 04-744
	1207 FRE 00	LOCKING SEGMENTS - BLADE BEARING RETAINING BOLTS	61-542-3
UK	002-12-81	HUB GROUP AND DRIVING CENTRE ASSEMBLY	61-542-3
D175/	4-30-4/13E		
		NEW OPERATING CYLINDER INTRODUCED	61-564R5
	1183 PRE 80 1186 PRE 80	NEW OPERATING CYLINDER INTRODUCED LOCKING SEGMENTS/BLADE BEARING RETAINING BOLTS	61-71/D3
UK		DEMOVAL OF BLADE CORPORTON & SUBSECUENT PROTECTION	61-2660
UK	1187 PRE 80	REMOVAL OF BLADE CORROSION & SUBSEQUENT PROTECTION	
UK	1188 PRE 80	REMOVAL OF BLADE CORROSION & SUBSEQUENT PROTECTION	
UK	1189 PRE 80	BLADE ROOT BEARINGS ULTIMATE LIFE OF BLADES RA25899	61-380
UK	1192 PRE 80		61-542-6
UK	1194 PRE 80	OPERATING PINS-INSPECTION FOR CRACKING AT OVERHAUL	
UK	1195 PRE 80	OPERATING PINS-INSPECTION FOR CRACKING	61-A733
UK	1197 PRE 80	EYEBOLT & OPERATING LINK GROUP - CADIUM PLATING	61-A753
		The state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the s	
UK	1199 PRF 80	EYEBOLI & OPERATING LINK GROUP/LINK PINS & EYEBOLI INSPECTION OF HUB DRIVING CENTRES EXCESSIVE BLADE CORROSION INSPECTION OF HUBS FOR CRACKS IN FRONT WALL	61-857
UK	1201 PRE 80	EXCESSIVE BLADE CORROSTON	61-888
UK	1201 FRE 80	INSPECTION OF HUBS FOR CRACKS IN FRONT WALL	61-909
UK	1202 PRE 60	PITCH LOCK GROUP - CRACKING OF CYLINDER COVER	61-1042R1
UK	011-10-86	PITCH LOCK GROUP - CRACKING OF CYLINDER COVER	61-1042R1
R184/	4-30-4/50		
UK	1184 PRE 80	INSP. HUB DRIVING CENTRE - INCORRECT MACHING	61-858
UK	1205 PRE 80	PITCH LOCK GROUP LOCK SUPPORT SLEEVE	2032
UK	1206 PRE 80		VP 2676, 61-714
UK	1200 FRE 80	I TEE OF HID & DRIVING CENTRE ACCEMBLITES	G1_E/2_10D2
UK	1208 PRE 80 1209 PRE 80	CDACKS HUD DDIVING CENTRE (CHIECEDEAM)	01-042-1083
UK	1209 PRE 80 1211 PRE 80 1212 PRE 80	CRACKS - HUB DRIVING CENTRE (GULFSTREAM)  EYEBOLT & LINK GROUP (DART ENGINED AIRCRAFT)  EYEBOLT & LINK GROUP (DART ENGINED AIRCRAFT)  HUB DRIVING CENTRES - INCORRECT MACHINING	01-633
UK	1211 PRE 80 1212 PRE 80	EYEBUL! & LINK GROUP (DART ENGINED AIRCRAFT)	61-A/53
UK		EYEBOLI & LINK GROUP (DART ENGINED AIRCRAFT)	61-754
UK	1213 PRE 80	HUB DRIVING CENTRES - INCORRECT MACHINING EXCESSIVE BLADE CORROSION	61-858
UK	1214 PRE 80		61-888
UK	007-03-88	PROPELLER - HUB CONTACT SWITCH BRUSHES	61-1054
UK	009-03-92	PROPELLER - HUB CONTACT SWITCH BRUSHES PITCH LOCK ASSY - LOCK SUPPORT (G159)	61-1091
2400/	4 00 4/50		
	4-30-4/50	DITCH LOCK CURPORT CLEEVE	C1 00C
UK	1161 PRE 80	PITCH LOCK SUPPORT SLEEVE	61-906
UK	1181 PRE 80	INTRODUCTION OF PREPRIMER FOR PROPELLER BLADES	VP_1941
UK	1182 PRE 80	PITCH LOCK GROUP LOCK SUPPORT SLEEVE	185
UK	1183 PRE 80	NEW OPERATING CYLINDER INTRODUCED  INSP. HUB DRIVING CENTRE - INCORRECT MACHINING LOCKING SEGMENTS/BLADE BEARING RETAINING BOLTS	61-564
ÜK	1184 PRE 80	INSP. HUB DRIVING CENTRE - INCORRECT MACHINING	61-858 (VP 2486)
UK	1186 PRE 80	LOCKING SEGMENTS/BLADE BEARING RETAINING BOLTS	61-714 (VP 2676)
UK	1187 PRE 80	REMOVAL OF BLADE CORROSION & SUBSEQUENT PROTECTION	61-266C
UK	1188 PRE 80	REMOVAL OF BLADE CORROSION & SUBSEQUENT PROTECTION	61-266E
UK	1189 PRE 80	NO. 20 & NO. 30 SIZE BLADE ROOT BEARINGS	61-380
UK	1192 PRE 80	HITTMATE LIFE OF BLADES RA 25899	61-542-6
	1193 PRE 80	ULTIMATE LIFE OF BLADES RA 25899 LIFE OF HUB & DRIVING CENTRE ASSEMBLIES	61-542-18R3
UK	1194 PRE 80		
UK	1105 DDC 00	OPERATING PINS - INSPECTION FOR CRACKING A: OVERHADE	61-A733
UK	1195 PRE 80	OPERATING PINS-INSPECTION FOR CRACKING AT OVERHAUL OPERATING PINS - INSPECTION FOR CRACKING OPERATING PINS - INSPECTION FOR CRACKING	61-A740
UK	1196 PRE 80		
UK	1197 PRE 80	EYEBOLT & OPERATING LINK GROUP - CADMIUM PLATING	
UK	1198 PRE 80	EYEBOLT & OPERATING LINK GROUP/LINK PINS & EYEBOLT	
UK	1199 PRE 80	INSPECTION OF HUB DRIVING CENTRES	61-857
UK	1200 PRE 80	INSPECTION OF HUB DRIVING CENTRES	61-858
UK	1201 PRE 80	EXCESSIVE BLADE CORROSION	61-888
UK	1206 PRE 80	LOCKING SEGMENTS - BLADE BEARING RETAINING BOLTS	VP 2676, 61-714
ÚK	1211 PRE 80	EYEBOLT & LINK GROUP (DART ENGINED AIRCRAFT)	61-A753
UK	1212 PRE 80	EYEBOLT & LINK GROUP (DART ENGINED AIRCRAFT)	61-754
UK	1213 PRE 80	HUB DRIVING CENTRES - INCORRECT MACHINING (F27)	61-858
UK	1215 PRE 80	PITCH LOCK SUPPORT SLEEVE	61-906
UK	013-05-84	PITCH LOCK SUPPORT SLEEVE HUB AND DRIVING CENTRE ASSEMBLIES MODIFICATION NO. (C)VP3008	61-882
		MODIFICATION NO (C)/P2009	61-954R5
UK	012-09-87		01 00 1110
UK	013-09-87	MARKING OF BLADES - LIFE IDENTIFICATION	61-961R5
UK	014-09-87	PROPELLER BLADES - LIMITATION ON TAKEOFFS	61-1044
UK	007-03-88	PROPELLER - HUB CONTACT SWITCH BRUSHES	61-1054
UK	009-03-92	PITCH LOCK ASSY - LOCK SUPPORT (F27)	61-1091
D102/	1-30-4/61		
	4-30-4/61 1161 PRE 80	PITCH LOCK SUPPORT SLEEVE	61-906
UK		INTRODUCTION OF PREDDIMED FOR PRODUCT ED DIABEC	VD 4044
UK	1181 PRE 80		VP 1941
UK	1182 PRE 80		185
UK	1183 PRE 80	NEW OPERATING CYLINDER INTRODUCED	61-564

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

			BULLETIN DE SERVICE DE REF
DOWTY	ROTOL		
	/4-30-4/61		
	INUED / SUITE)		
UK	1184 PRE 80	INSP HUR DRIVING CENTRE INCORRECT MAGUSTATIO	Tarre rates investor to the control of the
UK	1186 PRE 80		61-858 (VP 2486)
UK	1187 PRE 80		61-714 (VP 2676)
UK	1188 PRE 80	REMOVAL OF BLADE CORROSION & SUBSEQUENT PROTECTION	61-2665
UK	1189 PRE 80	BLADE ROOT BEARINGS	61-380
UK	1192 PRE 80	ULTIMATE LIFE OF BLADES RA 25899	61-542-6
UK	1193 PRE 80	LIFE OF HUB & DRIVING CENTRE ASSEMBLIES	61-542-1883
UK	1194 PRE 80	OPERATING PINS-INSPECTION FOR CRACKING AT OVERHAUL	61-711
UK	1195 PRE 80	OPERATING PINS - INSPECTION FOR CRACKING	61-A733
UK	1196 PRE 80		61-A740
UK	1197 PRE 80 1198 PRE 80		61-A753
UK	1199 PRE 80	EYEBOLT & OPERATING LINK GROUP/LINK PINS & EYEBOLT	
UK	1200 PRE 80	INSPECTION OF HUB DRIVING CENTRES INSPECTION OF HUB DRIVING CENTRES	61-857
UK	1200 PRE 80	EXCESSIVE BLADE CORROSION	61-858
UK	1206 PRE 80		61-888
UK	1211 PRE 80	EYEBOLT & LINK GROUP (DART ENGINED AIRCRAFT)	61-A753
UK	1212 PRE 80	EYEBOLT & LINK GROUP (DART ENGINED AIRCRAFT)	61-754
UK	1213 PRE 80	(Balti Eligites Allocal)	61-858
UK	1215 PRE 80	PITCH LOCK SUPPORT SLEEVE	
UK	013-05-84	HUB AND DRIVING CENTRE ASSEMBLIES	61-882
UK	012-09-87	MODIFICATION NO. (C)VP3008	61-05/05
UK	013-09-87	MARKING OF BLADES - LIFE IDENTIFICATION	61-961R5
UK	014-09-87	PROPELLER BLADES - LIMITATION ON TAKEOFFS	61-1044
UK	007-03-88	PROPELLER - HUB CONTACT SWITCH BRUSHES PITCH LOCK ASSY - LOCK SUPPORT (F27)	61-1054
UK	009-03-92	PITCH LOCK ASSY - LOCK SUPPORT (F27)	61-1091
	4-30-4/22		
UK	1157 PRE 80	OPERATING PINS - INSPECTION FOR CRACKING LIFE OF HUB & DRIVING CENTRE ASSEMBLIES	61-887
UK UK	1173 PRE 80	CREDATING DING LINGSCOTION FOR CRACKING (NG 740)	61-542-18R3
UK	1175 PRE 80 1176 PRE 80	OPERATING PINS - INSPECTION FOR CRACKING (HS 748)	
UK	1176 PRE 80		61-A753 61-754
UK	1178 PRE 80	INSPECTION OF HUB FOR CRACKING FRONT WALL (HS 748)	
UK	1179 PRE 80		61-857
UK	1180 PRE 80	EXCESSIVE BLADE CORROSION (HS 748)	61-888
UK	1211 PRE 80	EYEBOLT & LINK GROUP (DART ENGINED AIRCRAFT)	61-A753
UK	1212 PRE 80		61-754
UK	1267 PRE 80	LOCKING SEGMENTS - BLADE BEARING RETAINING BOLTS	VP 2676, 61-714
UK	011-10-86	PITCH LOCK GROUP - CRACKING OF CYLINDER COVER	61-1042R1
UK	012-10-86	PITCH LOCK GROUP - CRACKING OF CYLINDER COVER PROPELLER THREADS - BUTTRESS THREADS	61-1043R4
UK	006-03-88	PROPELLER HUBS - FRONT WALL SNOUT	61-1053R3
	4-30-4/49	DATE OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PR	
UK	011-10-86	PITCH LOCK GROUP - CRACKING OF CYLINDER COVER	61-1042R1
UK	012-10-86	PROPELLER THREADS - BUTTRESS THREADS	61-1043R4
B200/	2 00 5/7		
K306/	3-82-F/7		
R321/	4-82-F/8		
110217	4 02 1/0		
R333/	4-82-F/12		
R390/	4-123-F/27		
UK	003-11-88		61-A1021R14
UK	006-01-94	INSPECTION OF COUNTERWEIGHT ARMS FOR FORGING FOLDS	
UK	002-11-96	PROPELLER - BLADE PITCH SEIZURE	SF340-61-88
UK	006-10-99	CRACKS ORIGINATING FROM REAR HUB HALF INSERT HOLES	SF340-61-95R1
EAGLE			
D-400			
D 501	D		
D-504	-B		
D-500	- AE		
D-562	-45		
D-650			
D-620			
D-731			
0 731			
D-738			

MAKE / CONSTRUCTEUR

MODEL / MODELE

ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

FLOTTORP W6OMY49		
7845		
HAMILTON STANDARD 2B2O SERIES		
2B20	( 2B2O SERIES )	
2B20-15	( 2B2O SERIES )	
2B20-207	( 2B2O SERIES )	
2B20-223	( 2B2O SERIES )	
2B20-225	( 2B2O SERIES )	
2B20-229	( 2B2O SERIES )	
2B20-241	( 2B2O SERIES )	
2B20-251	( 2B2O SERIES )	
2B20-317	( 2B2O SERIES )	
2B20-329	( 2B2O SERIES )	
2B20-337	( 2B2O SERIES )	
2D20-241		
2D30 SERIES US 56-22-01 US 57-13-05	ALUMINUM ALLOY PROPELLERS SHANK CORROSION ON ALUMINUM BLADES	210,217,385,385A, 390,414,414A,508
2D30	( 2D30 SERIES )	
2D30-100	( 2D3O SERIES )	
2D30-227	( 2D30 SERIES )	
2D30-233	( 2D3O SERIES )	
2D30-235	( 2D30 SERIES )	
2D30-237	( 2D3O SERIES )	
2D30-241	( 2D30 SERIES )	
2D30-245	( 2D30 SERIES )	
2D30-247	( 2D30 SERIES )	
2D30-259	( 2D3O SERIES )	
2D30-301	( 2D30 SERIES )	
2D30-303	( 2D30 SERIES )	,,,,,
2D30-305	( 2D30 SERIES )	
2D30-401	( 2D30 SERIES )	
2030-405	( 2D30 SERIES )	
2030-421	( 2D30 SERIES )	
2D30-425	( 2D30 SERIES )	
2D40-211		
12D40 SERIES US 56-22-01 US 57-13-05	ALUMINUM ALLOY PROPELLERS SHANK CORROSION ON ALUMINUM BLADES	210,217,385,385A, 390,414,414A,508

INDEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN CANADA INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA			
MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.	
HAMILTON STANDARD			
12D40	( 12D40 SERIES )		
12D40-211	( 12D40 SERIES )		
12D40-305	( 12D40 SERIES )		
12D40-401	( 12D40 SERIES )		
12040-403	( 12D40 SERIES )		
12D40-405	( 12D40 SERIES )		
12D40-407	( 12D40 SERIES )		
12D40-425	( 12D40 SERIES )		
12D40-610A12	( 12D40 SERIES )		
22D30 SERIES US 56-22-01 US 57-13-05 US 81-13-06R2	ALUMINUM BLADE CORROSION SHANK CORROSION ON ALUMINUM BLADES PROPELLER BLADE	210,217,385,385A 390,414,414A,508	
22030	( 22D30 SERIES )		
22D30-49	( 22D30 SERIES )		
22D30~201	( 22D30 SERIES )		
22D30-237	( 22D30 SERIES )		
22D30-301	( 22D30 SERIES )		
22D30-303	( 22D30 SERIES )		
22D30-303P	( 22D30 SERIES )		
22D30-313	( 22D30 SERIES )		
22D30-317	( 22D30 SERIES )		
22D30~331	( 22D30 SERIES )		
22D30-349	( 22D30 SERIES )		
22D30-369	( 22D30 SERIES )		
22D30-401	( 22D30 SERIES )		
22D30-403	( 22D30 SERIES )		
22D30-405	( 22D30 SERIES )		
22D40 SERIES US 56-22-01 US 57-13-05 US 81-13-06R2	ALUMINUM BLADE CORROSION SHANK CORROSION ON ALUMINUM BLADES PROPELLER BLADE	210,217,385,385A 390,414,414A,508	
22D40	( 22D40 SERIES )		
22D40-505	( 22D40 SERIES )		
22D40-507	( 22D40 SERIES )		
3D40 SERIES			
3D40	( 3D40 SERIES )		

3D40-127

3D40-225

3D40-231

( 3D40 SERIES )

( 3D40 SERIES )

( 3D40 SERIES )

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
HAMILTON STANDARD 3D40-235	( 3D40 SERIES )	
3D40-277	( 3D40 SERIES )	
23D40 SERIES US 57-13-05 US 81-13-06R2	SHANK CORROSION ON ALUMINUM BLADES PROPELLER BLADE	390,414,4144,508
23D40	( 23D40 SERIES )	
23D40-301	( 23D40 SERIES )	
23D40-303	( 23D4O SERIES )	
23D40-311	( 23D4O SERIES )	
23D40-315	( 23D4O SERIES )	
33D50 SERIES US 57-13-05 US 64-03-03 US 81-13-06R2	SHANK CORROSION ON ALUMINUM BLADES ALUMINUM BLADES IMPACTED BY SOLID OBJECTS PROPELLER BLADE	390,414,414A,508 596,596A,596B,602A
33D50-119	( 33D50 SERIES )	
43D50 SERIES  US 54-01-01  US 54-01-02  US 56-22-01  US 57-13-05  US 58-22-01  US 64-03-03  US 81-13-06R2	REVERSE SOLENOID VALVE PLUNGER SPRING LOW PITCH STOP WEDGE RETURN SPRINGS / INSERTS ALUMINUM BLADE CORROSION SHANK CORROSION ON ALUMINUM BLADES BLADE FACE ALIGNMENT - OVERHAUL PROCEDURES ALUMINUM BLADES IMPACTED BY SOLID OBJECTS PROPELLER BLADE	273, 273A 210,217,385,385A 390,414,414A,508 546A 596,596A,596B,602A
43D50-311	( 43D50 SERIES )	
43D50-321	( 43D50 SERIES )	
43D51 SERIES US 54-01-01 US 54-01-02 US 81-13-06R2	REVERSE SOLENOID VALVE PLUNGER SPRING LOW PITCH STOP WEDGE RETURN SPRINGS / INSERTS PROPELLER BLADE	273, 273A
43D51	( 43D51 SERIES )	
43D51-355	( 43D51 SERIES )	
23E50 SERIES US 57-13-05 US 64-03-03 US 81-13-06R2	SHANK CORROSION ON ALUMINUM BLADES ALUMINUM BLADES IMPACTED BY SOLID OBJECTS PROPELLER BLADE	390,414,414A,508 596,596A,596B,602A
23E50	( 23E50 SERIES )	
23E50-473	( 23E50 SERIES )	
23E50-489	( 23E50 SERIES )	
23E50-505	( 23E50 SERIES )	
43E50-473		
43E60 SERIES US 54-01-01 US 54-01-02 US 55-05-02 US 56-22-01 US 57-13-05 US 58-08-04 US 58-08-05 US 58-22-01 US 60-03-04 US 64-03-03 US 81-13-06R2	REVERSE SOLENOID VALVE PLUNGER SPRING LOW PITCH STOP WEDGE RETURN SPRINGS / INSERTS BARREL & SPIDER AREA / BARREL BOLTS ALUMINUM BLADE CORROSION SHANK CORROSION ON ALUMINUM BLADES DOME CAP / PITCH LOCK RPM SENSITIVE HYDRAULIC PITCH LOCK BLADE FACE ALIGNMENT - OVERHAUL PROCEDURES DISPOSITION ALUMINUM BLADES EXPERIENCING IMPACT ALUMINUM BLADES IMPACTED BY SOLID OBJECTS PROPELLER BLADE	273, 273A 316 210,217,385,385A 390,414,414A,508 496D 387, 472, 472A 546A 546A, 596, 602 596,596A,596B,602A
US 60-03-04 US 64-03-03	DISPOSITION ALUMINUM BLADES EXPERIENCING IMPACT	546A, 596, 6

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUJETT

ORIGINE NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HAMILTON STANDARD		
43E60	( 43E60 SERIES )	
43E60-435	( 43E60 SERIES )	
<b>43E60-573</b> US 50-52-01	( 43E60 SERIES )	
43E60-581	BLADE INSPECTION  ( 43E60 SERIES )	177, 193
43E60-583	( 43E60 SERIES )	
33LF-325	TOROU JUNIUS	······································
24D50 SERIES		
US 81-13-06R2	PROPELLER BLADE	
24050-65	( 24D50 SERIES )	
24D50-105	( 24D50 SERIES )	
24E60 SERIES	000051150 01105	
US 81-13-06R2		
24E60	( 24E60 SERIES )	
<b>54H60 SERIES</b> US 56-22-01	ALUMINUM BLADE CORROSION	210,217,385,385A
US 57-13-05 US 58-22-01	SHANK CORROSION ON ALUMINUM BLADES BLADE FACE ALIGNMENT - OVERHAUL PROCEDURES	390,414,414A,508 546, 546A
US 64-03-03 US 98-24-34	ALUMINUM BLADES IMPACTED BY SOLID OBJECTS PROPELLER BLADE CRACKS	596,596A,596B,602A ASB 54H60-61-A135
54H60-77	( 54H60 SERIES )	
US 86-01-07 US 97-13-07	PROPELLER VALVE HOUSING COVER INPUT GEAR PROPELLER BLADES	61-A119 ASB 54H60-61-A133R1
54H60-117	( 54H6O SERIES )	
US 74-25-09 US 75-03-05	OIL TRANSFER TUBE  FLUID TRANSFER HOUSING EXTENSION SLEEVE	54H60-A68 59R1
US 76-05-06 US 97-13-07	PITCHLOCK REGULATOR EXTENSION SLEEVE THREAD PROPELLER BLADES	73R1 ASB 54H60-61-A133R1
24PF-305		
US 79-25-09 US 81-12-05	BELLCRANKS & PIVOTS LIFE LIMIT BARREL / BEARING RACEWAY SURFACES	13 17R2
14RF-9		
US 93-06-06 US 94-06-05	TITANIUM (A1) NITRIDED TRANSFER TUBE TORQUE CHECK PROPELLER HUB RETAINING NUTS	ASB 14RF-9-61-A57 TR # 61-7
US 95-22-12 US 96-08-01R1	PCU - SERVO BALLSCREW INTERNAL SPLINE (BIS) WEAR BLADE SHANK INSPECTION	14RF-9-61-A53R7 14RF-9-61-86,A90,A92
US 96-08-02	BLADE SHANK INSPECTION	14RF-9-61-A91,A95
US 96-25-20	TRANSFER TUBE ASSEMBLIES & PROP CONTROL UNITS	14RF-9-61-64
14SF-5 US 88-20-08	"RYNITE" BLADE RETAINING RINGS	14SF-61-A21R2
US 93-06-06 US 95-22-12	TITANIUM (A1) NITRIDED TRANSFER TUBE PCU - SERVO BALLSCREW INTERNAL SPLINE (BIS) WEAR	ASB 14SF-61-A61 14SF-61-A59R6
US 96-08-02	BLADE SHANK INSPECTION	14RF-9-61-A91,A95
US 96-25-20	TRANSFER TUBE ASSEMBLIES & PROP CONTROL UNITS	14SF-61-70
14SF-7 US 88-20-08	"RYNITE" BLADE RETAINING RINGS	14SF-61-A21R2
US 93-06-06 US 95-22-12	TITANIUM (A1) NITRIDED TRANSFER TUBE PCU - SERVO BALLSCREW INTERNAL SPLINE (BIS) WEAR	
US 96-08-02 US 96-25-20	BLADE SHANK INSPECTION TRANSFER TUBE ASSEMBLIES & PROP CONTROL UNITS	14RF-9-61-A91,A95 14SF-61-70
14SF-15		
US 93-06-06 US 95-22-12	TITANIUM (A1) NITRIDED TRANSFER TUBE PCU - SERVO BALLSCREW INTERNAL SPLINE (BIS) WEAR	ASB 14SF-61-A61 14SF-61-A59R6
US 96-08-02	BLADE SHANK INSPECTION TRANSFER TUBE ASSEMBLIES & PROP CONTROL UNITS	14RF-9-61-A91,A95 14SF-61-70
US 96-25-20	TRANSIER TODE ASSEMBLIES & PROF CONTROL UNITS	1-131 01 10

MAKE / CONSTRUCTEUR  MODEL / MODELE  ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HAMILTON STANDARD		
145F-19 US 93-06-06 US 95-22-12 US 96-08-02 US 96-25-20	TITANIUM (A1) NITRIDED TRANSFER TUBE PCU - SERVO BALLSCREW INTERNAL SPLINE (BIS) WEAR BLADE SHANK INSPECTION TRANSFER TUBE ASSEMBLIES & PROP CONTROL UNITS	ASB 14SF-61-A61 14SF-61-A59R6 14RF-9-61-A91,A95 14SF-61-70
14SF-23 US 93-06-06 US 95-22-12 US 96-08-02 US 96-25-20	TITANIUM (A1) NITRIDED TRANSFER TUBE PCU - SERVO BALLSCREW INTERNAL SPLINE (BIS) WEAR BLADE SHANK INSPECTION TRANSFER TUBE ASSEMBLIES & PROP CONTROL UNITS	ASB 14SF-61-A61 14SF-61-A59R6 14RF-9-61-A91,A95 14SF-61-70
<b>H5131</b> US 50-12-01	BLADE SHANK FATIGUE / MAXIMUM ENGINE RPM	
5404		
HARTZELL BHC-A2VF SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
BHC-A2VF-1	( BHC-A2VF SERIES )	
BHC-A2VF-1A	( BHC-A2VF SERIES )	
BHC-A2VF-1DB	( BHC-A2VF SERIES )	
BHC-A2VF-3	( BHC-A2VF SERIES )	
BHC-A2XF SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
BHC-A2XF-1	( BHC-A2XF SERIES )	
BHC-A2XF-1A	( BHC-A2XF SERIES )	
BHC-C2YF-1 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
BHC-C2YF-1	( BHC-C2YF-1 SERIES )	
BHC-C2YF-1A	( BHC-C2YF-1 SERIES )	
BHC-C2YF-1BF	( BHC-C2YF-1 SERIES )	
BHC-C2YF-2 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
BHC-C2YF-2C	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CH	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CHUF	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CK	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CKF	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CKFU	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CKUF	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CL	( BHC-C2YF-2 SERIES )	
BHC-C2YF-2CLKUF	( BHC-C2YF-2 SERIES )	
BHC-C2YK SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
	( BHC-C2YK SERIES )	
5.70 02 11 151	Constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the constitution of the consti	

MODEL / MODELE (
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
HARTZELL BHC-C2YK-2CKLF	( BHC-C2YK SERIES )	
BHC-12YF-1BF US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
BHC-J2YF SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
BHC-J2YF-1BF	( BHC-J2YF SERIES )	
BHC-J2YF-2CUF	( BHC-J2YF SERIES )	
BHC-92ZF-1		
CHC-C2YK-1A US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-A2VF SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-A2VF-1A	( HC-A2VF SERIES )	
HC-A2VF-2	( HC-A2VF SERIES )	
HC-A2VF-2B	( HC-A2VF SERIES )	
HC-A2VF-2C	( HC-A2VF SERIES )	
HC-A2VK SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-A2VK-1	( HC-A2VK SERIES )	
HC-A2VK-1B	( HC-A2VK SERIES )	
HC-A2VK-1D	( HC-A2VK SERIES )	
HC-A2VK-1DI	( HC-A2VK SERIES )	
HC-A2VK-2	( HC-A2VK SERIES )	
HC-A2V2O SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-A2V20-1	( HC-A2V2O SERIES )	
HC-A2V20-1A	( HC-A2V2O SERIES )	
HC-A2V2O-4	( HC-A2V2O SERIES )	
HC-A2V2O-4A	( HC-A2V2O SERIES )	
HC-A2V20-4AI	( HC-A2V2O SERIES )	
HC-A2X SERIES  CF CF-81-13  US 85-14-10R2  US 97-18-02	BLADE CLAMP P/N C-1301 PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-A2XF-1A	( HC-A2X SERIES )	
HC-A2XF-2	( HC-A2X SERIES )	
HC-A2XK-1	( HC-A2X SERIES )	
	( HC-A2X SERIES )	
HC-A2X20-1	( HC-A2X SERIES )	
HC-A2X2O-1A	( HC-A2X SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-A2X2O-4	( HC-A2X SERIES )	
HC-A2X20-4A	( HC-A2X SERIES )	
HC-A2X20-4AI	( HC-A2X SERIES )	
HC-C2YF-1 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-C2YF-1A	( HC-C2YF-1 SERIES )	
HC-C2YF-1BF	( HC-C2YF-1 SERIES )	
HC-C2YK-1 SERIES US 64-20-01 US 77-12-06 US 90-02-23	PLASTIC PITCH CHANGE BLOCKS BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	86 118A 164
HC-C2YK-1	( HC-C2YK-1 SERIES )	
HC-C2YK-1A	( HC-C2YK-1 SERIES )	
HC-C2YK-1AF	( HC-C2YK-1 SERIES )	
HC-C2YK-1B	( HC-C2YK-1 SERIES )	
HC-C2YK-1BF	( HC-C2YK-1 SERIES )	
HC-C2YK-1BFI	( HC-C2YK-1 SERIES )	
HC-C2YK-1BI	( HC-C2YK-1 SERIES )	
HC-C2YK-1BIF	( HC-C2YK-1 SERIES )	
HC-C2YK-1BL	( HC-C2YK-1 SERIES )	
HC-C2YK-1BLF	( HC-C2YK-1 SERIES )	
HC-C2YK-1BR	( HC-C2YK-1 SERIES )	
HC-C2YK-1BU	( HC-C2YK-1 SERIES )	
HC-C2YK-1GF US 77-12-06	( HC-C2YK-1 SERIES ) BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-C2YK-1LB US 77-12-06	( HC-C2YK-1 SERIES ) BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-C2YK-2 US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-C2YK-2B SERIES US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-C2YK-2B	( HC-C2YK-2B SERIES )	
HC-C2YK-2C SERIES US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-C2YK-2C	( HC-C2YK-2C SERIES )	
HC-C2YK-2CE	( HC-C2YK-2C SERIES )	
HC-C2YK-2CEU	( HC-C2YK-2C SERIES )	
HC-C2YK-2CFU	( HC-C2YK-2C SERIES )	
HC-C2YK-2CG	( HC-C2YK-2C SERIES )	
HC-C2YK-2CGF	( HC-C2YK-2C SERIES )	

IND	SEV OF AIDWORTHWISE THE	
INDE	EX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN C X DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU (	ANADA
MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL		and the second second
HC-C2YK-2CGFU	( HC-C2YK-2C SERIES )	
HC-C2YK-2CGU	( HC-C2YK-2C SERIES )	
HC-C2YK-2CGUF	( HC-C2YK-2C SERIES )	
HC-C2YK-2CLE	( HC-C2YK-2C SERIES )	
HC-C2YK-2CLEUF	( HC-C2YK-2C SERIES )	
HC-C2YK-2CLGFU	( HC-C2YK-2C SERIES )	
HC-C2YK-2CU	( HC-C2YK-2C SERIES )	
HC-C2YK-2CUF	( HC-C2YK-2C SERIES )	
HC-C2YK-2R SERIES		
US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-C2YK-2RB	( HC-C2YK-2R SERIES )	
HC-C2YK-2RBF	( HC-C2YK-2R SERIES )	
HC-C2YK-4 SERIES US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-C2YK-4	( HC-C2YK-4 SERIES )	
HC-C2YK-4AF	( HC-C2YK-4 SERIES )	
HC-C2YK-4BF	( HC-C2YK-4 SERIES )	
HC-C2YK-4CF	( HC-C2YK-4 SERIES )	
HC-C2YK-4F	( HC-C2YK-4 SERIES )	
HC-C2YL-1 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-C2YL-1A	( HC-C2YL-1 SERIES )	

	( NO DEIN 4 SENIES )	
HC-C2YL-1 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-C2YL-1A	( HC-C2YL-1 SERIES )	
HC-C2YL-1B	( HC-C2YL-1 SERIES )	

HC-C2Y	L-1BLF	( HC-C2YL-1 SERIES )	
HC-C2Y	L-4 SERIES		
US	77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A

( HC-C2YL-1 SERIES )

HC-C2YL-4	( HC-C2YL-4 SERIES )
HC-C2YL-4BF	( HC-C2YL-4 SERIES )
HC-C2YL-4F	( HC-C2YL-4 SERIES )
HC-C2YR-1B SERIES	

HC-C2YR-1B SERIES US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-C2YR-1BF	( HC-C2YR-1B SERIES )	
HC-C2YR-1BK	( HC-C2YR-1B SERIES )	
HC-C2YR-1BL	( HC-C2YR-1B SERIES )	
HC-C2YR-1BLF	( HC-C2YR-1B SERIES )	

HC-C2YR-2 SERIES US 77-12-06 BLADE SHANK CRACKS / BLADE FAILURE 118A	
LIC 77-40-00 PLADE SHANK CDACKS / PLADE EATLINE 118A	
US //- 12-06 BEADE SHAIR CRACKS / BEADE FATEBRE	
US 90-02-23 PROPELLER HUB 164	

HC-C2YL-1BF

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	( SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-C2YR-2	( HC-C2YR-2 SERIES )	
HC-C2YR-2CEU	( HC-C2YR-2 SERIES )	
HC-C2YR-2CEUF	( HC-C2YR-2 SERIES )	
HC-C2YR-2CLEU	( HC-C2YR-2 SERIES )	
HC-C2YR-2CLEUF	( HC-C2YR-2 SERIES )	
HC-C2YR-2CUF	( HC-C2YR-2 SERIES )	
HC-C2YR-2RBS	( HC-C2YR-2 SERIES )	
HC-C2YR-4CF US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-D2X20 SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-D2X20-7	( HC-D2X2O SERIES )	
HC-D2X20-8	( HC-D2X20 SERIES )	
HC-D2V SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61~217R1
HC-D2V20-3	( HC-D2V SERIES )	
HC-D2V2O-3E	( HC-D2V SERIES )	
HC-D2V20-7C	( HC-D2V SERIES )	
HC-D2V20-8D	( HC-D2V SERIES )	
HC-E2YK-1BF US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-E2YK-2 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-E2YK-2BTF	( HC-E2YK-2 SERIES )	
HC-E2YK-2RB US 71-21-09	( HC-E2YK-2 SERIES ) PROPELLER AIR CHARGE / SPRING BACKUP KIT	62
HC-E2YK-2RBS US 71-21-09	( HC-E2YK-2 SERIES ) PROPELLER AIR CHARGE / SPRING BACKUP KIT	62
HC-E2YK-2RBSF US 71-21-09	( HC-E2YK-2 SERIES ) PROPELLER AIR CHARGE / SPRING BACKUP KIT	62
HC-E2YL-1BF US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-E2YL-2 SERIES US 71-21-09 US 77-12-06	PROPELLER AIR CHARGE / SPRING BACKUP KIT BLADE SHANK CRACKS / BLADE FAILURE	62 118A
HC-E2YL-2ASF	( HC-E2YL-2 SERIES )	
HC-E2YL-2B US 64-20-01	( HC-E2YL-2 SERIES ) PLASTIC PITCH CHANGE BLOCKS	86
HC-E2YL-2BS US 64-20-01	( HC-E2YL-2 SERIES ) PLASTIC PITCH CHANGE BLOCK	86
HC-E2YL-2BSF US 64-20-01	( HC-E2YL-2 SERIES ) PLASTIC PITCH CHANGE BLOCK	86

MAKE / CONSTRUCTEUR

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-E2YL-2BSQ US 64-20-01	( HC-E2YL-2 SERIES ) PLASTIC PITCH CHANGE BLOCK	
HC-E2YL-2C	( HC-E2YL-2 SERIES )	
HC-E2YL-2RBS	( HC-E2YL-2 SERIES )	
HC-E2YR-1B SERIES US 77-12-06 US 90-02-23	BLADE SHANK CRACKS / BLADE FAILURE PROPELLER HUB	118A 164
HC-E2YR-1B	( HC-E2YR-1B SERIES )	
HC-E2YR-1BF	( HC-E2YR-1B SERIES )	
HC-E2YR-1BLF	( HC-E2YR-1B SERIES )	
HC-E2YR-2A SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-E2YR-2AFT	( HC-E2YR-2A SERIES )	
HC-E2YR-2ATF		
HC-E2YR-2B SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-E2YR-2B	( HC-E2YR-2B SERIES )	
HC-E2YR-2BT	( HC-E2YR-2B SERIES )	
HC-E2YR-2BTF	( HC-E2YR-2B SERIES )	
HC-E2YR-2R SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-E2YR-2R	( HC-E2YR-2R SERIES )	
HC-E2YR-2RB US 71-21-09	( HC-E2YR-2R SERIES ) PROPELLER AIR CHARGE / SPRING BACKUP KIT	
HC-E2YR-2RBS US 71-21-09	( HC-E2YR-2R SERIES ) PROPELLER AIR CHARGE / SPRING BACKUP KIT	62
HC-E2YR-2RBSF	( HC-E2YR-2R SERIES ) PROPELLER AIR CHARGE / SPRING BACKUP KIT	
HC-F2YL-2 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-F2YL-2UF	( HC-F2YL-2 SERIES )	
HC-F2YR-1 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
	( HC-F2YR-1 SERIES )	
HC-F2YR-1F	( HC-F2YR-1 SERIES )	
HC-F2YR-2UF US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-I2YR-1BF US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-M2YR SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-M2YR-1BF		
HC-M2YR-1BFI	( HC-M2YR SERIES )	
HC-M2YR-2CEUF	( HC-M2YR SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)

ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HA-12UF-1		
HC-12V SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-12V20	( HC-12V SERIES )	
HC-12V20-3C	( HC-12V SERIES )	
HC-12V2O-3E	( HC-12V SERIES )	
HC-12V2O-6L	( HC-12V SERIES )	
HC-12V20-7A	( HC-12V SERIES )	
HC-12V20-7C	( HC-12V SERIES )	
HC-12V20-7CI	( HC-12V SERIES )	
HC-12V2O-7D	( HC-12V SERIES )	
HC-12V20-8CI	( HC-12V SERIES )	
HC-12V2O-8D	( HC-12V SERIES )	
HC-12X SERIES  CF CF-81-13  US 56-17-03  US 58-07-01	BLADE CLAMP P/N C-1301 A-57 VALVE TUBE SPLIT RINGS	38 58
US 59-01-03 US 59-26-01	SPLIT RINGS HUB SPIDERS	64
US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-12X20-1 US 64-28-01	( HC-12X SERIES ) HUB SPIDERS	32
HC-12X20-3 US 64-28-01	( HC-12X SERIES ) HUB SPIDERS	32
HC-12X20-3AC	( HC-12X SERIES )	
HC-12X2O-3C	( HC-12X SERIES )	
HC-12X2O-3CI	( HC-12X SERIES )	
HC~12X2O-3E	( HC-12X SERIES )	
HC-12X2O-3N HC-12X2O-7B	( HC-12X SERIES ) ( HC-12X SERIES )	
US 64-28-01 US 65-21-04	HUB SPIDERS PROPELLER BEARINGS	32 82
<b>HC-12X20-7C</b> US 65-21-04	( HC-12X SERIES ) PROPELLER BEARINGS	82
HC-12X20-7D US 65-21-04	( HC-12X SERIES ) PROPELLER BEARINGS	82
HC-12X20-7E US 65-21-04	( HC-12X SERIES ) PROPELLER BEARINGS	82
<b>HC-12X20-8</b> US 65-21-04	( HC-12X SERIES ) PROPELLER BEARINGS	82
HC-12X20-8C US 65-21-04	( HC-12X SERIES ) PROPELLER BEARINGS	82
HC-12X20-8D US 65-21-04	( HC-12X SERIES ) PROPELLER BEARINGS	82

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT SUJET

HARTZELL	1-217R1
HC-82VF SERIES   US 85-14-10R2   PROPELLER BLADE CLAMP ASSEMBLIES   1598   HC-82VF-1   (HC-82VF SERIES )   HC-82VF-1BB   (HC-82VF SERIES )   HC-82VF-1BB   (HC-82VF SERIES )   HC-82VF-1BD   (HC-82VF SERIES )   HC-82VF-1BD   (HC-82VF SERIES )   HC-82VF-1BI   (HC-82VF SERIES )   HC-82VF-1BI   (HC-82VF SERIES )   HC-82VF-1BI   (HC-82VF SERIES )   HC-82VF-1BI   (HC-82VF SERIES )   HC-82VF-1DB   (HC-82VF SERIES )   HC-82VF-1DB   (HC-82VF SERIES )   HC-82VF-1DB   (HC-82VF SERIES )   HC-82VF-1DB   (HC-82VF SERIES )   HC-82VF-1DBI   (HC-82VF SERIES )   HC-82VF-1DBI   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF-2   (HC-82VF SERIES )   HC-82VF-2   (HC-82VF-2   (HC-82VF-2   (HC-82VF-2   (HC-82VF-2   (HC-82	
HC-82VF-1	
HC-82VF-1BB (HC-82VF SERIES) HC-82VF-1BBI (HC-82VF SERIES) HC-82VF-1BD (HC-82VF SERIES) HC-82VF-1BI (HC-82VF SERIES) HC-82VF-1BN (HC-82VF SERIES) HC-82VF-1D (HC-82VF SERIES) HC-82VF-1DB (HC-82VF SERIES) HC-82VF-1DBI (HC-82VF SERIES) HC-82VF-1DBI (HC-82VF SERIES)	
HC-82VF-1BBI (HC-82VF SERIES)  HC-82VF-1BD (HC-82VF SERIES)  HC-82VF-1BI (HC-82VF SERIES)  HC-82VF-1BN (HC-82VF SERIES)  HC-82VF-1D (HC-82VF SERIES)  HC-82VF-1DB (HC-82VF SERIES)  HC-82VF-1DBI (HC-82VF SERIES)  HC-82VF-1DBI (HC-82VF SERIES)	
HC-82VF-1BD ( HC-82VF SERIES )  HC-82VF-1BI ( HC-82VF SERIES )  HC-82VF-1BN ( HC-82VF SERIES )  HC-82VF-1D ( HC-82VF SERIES )  HC-82VF-1DB ( HC-82VF SERIES )  HC-82VF-1DBI ( HC-82VF SERIES )  HC-82VF-2 ( HC-82VF SERIES )	
HC-82VF-1BI (HC-82VF SERIES)  HC-82VF-1BN (HC-82VF SERIES)  HC-82VF-1D (HC-82VF SERIES)  HC-82VF-1DB (HC-82VF SERIES)  HC-82VF-1DBI (HC-82VF SERIES)  HC-82VF-2 (HC-82VF SERIES)	
HC-82VF-1BN ( HC-82VF SERIES ) HC-82VF-1D ( HC-82VF SERIES ) HC-82VF-1DB ( HC-82VF SERIES ) HC-82VF-1DBI ( HC-82VF SERIES ) HC-82VF-2 ( HC-82VF SERIES )	
HC-82VF-1D ( HC-82VF SERIES )  HC-82VF-1DB ( HC-82VF SERIES )  HC-82VF-1DBI ( HC-82VF SERIES )  HC-82VF-2 ( HC-82VF SERIES )	
HC-82VF-1DB ( HC-82VF SERIES ) HC-82VF-1DBI ( HC-82VF SERIES ) HC-82VF-2 ( HC-82VF SERIES )	
HC-82VF-1DBI (HC-82VF SERIES)  HC-82VF-2 (HC-82VF SERIES)	
HC-82VF-2 ( HC-82VF SERIES )	
the service of	
HC-82VF-2B ( HC-82VF SERIES )	
HC-82VF-2BI (HC-82VF SERIES )	
HC-82VK SERIES  US 85-14-10R2 PROPELLER BLADE CLAMP ASSEMBLIES 159B  US 97-18-02 NDT INSPECTION OF BLADE, HUB AND CLAMPS HC-SB-61	1-217R1
HC-82VK-1B ( HC-82VK SERIES )	
HC-82VK-1D ( HC-82VK SERIES )	
HC-82VK-1DB ( HC-82VK SERIES )	
HC-82VK-1DI ( HC-82VK SERIES )	
HC-82VK-1DN ( HC-82VK SERIES )	
HC-82VK-2 ( HC-82VK SERIES )	
HC-82VL SERIES  US 85-14-10R2 PROPELLER BLADE CLAMP ASSEMBLIES 159B  US 97-18-02 NDT INSPECTION OF BLADE, HUB AND CLAMPS HC-SB-61	-217R1
HC-82VL-1D ( HC-82VL SERIES )	
HC-82VL-2B ( HC-82VL SERIES )	
HC-82VL-2C (HC-82VL SERIES)	
HC-82VL-2CI (HC-82VL SERIES)	
HC-82VL-2D (HC-82VL SERIES)	
HC-82X SERIES	
HC-82XF-1 SERIES       CF CF-81-13     BLADE CLAMP P/N C-1301       US 53-15-03     PITCH CHANGE LINK SCREWS     24       US 58-06-02     A-159 SPLIT RINGS     57	-217R1

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
HARTZELL HC-82XF-1 SERIES (CONTINUED / SUITE) US 58-07-01 US 59-01-03 US 60-16-04 US 85-14-10R2 US 97-18-02	SPLIT RINGS SPLIT RINGS GUIDE COLLARS PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	58 64 71 1598 HC-SB-61-217R1
HC-82XF-1 US 58-09-02	( HC-82XF-1 SERIES ) PISTON GUIDE ROD / JACK ASSEMBLY	39, 47
HC-82XF-1B	( HC-82XF-1 SERIES )	
HC-82XF-1BB	( HC-82XF-1 SERIES )	
HC-82XF-1BI	( HC-82XF-1 SERIES )	
HC-82XF-1BN	( HC-82XF-1 SERIES )	
HC-82XF-1DB	( HC-82XF-1 SERIES )	
HC-82XF-1DBI	( HC-82XF-1 SERIES )	
HC-82XF-2 SERIES  CF CF-81-13  US 58-06-02  US 58-07-01  US 59-01-03  US 85-14-10R2  US 97-18-02	BLADE CLAMP P/N C-1301 A-159 SPLIT RINGS SPLIT RINGS SPLIT RINGS PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	57 58 64 159B HC-SB-61-217R1
HC-82XF-2	( HC-82XF-2 SERIES )	
HC-82XF-2B	( HC-82XF-2 SERIES )	
HC-82XF-2BI	( HC-82XF-2 SERIES )	
HC-82XF-6 SERIES  CF CF-81-13  US 58-06-02  US 58-07-01  US 59-01-03  US 85-14-10R2  US 97-18-02	BLADE CLAMP P/N C-1301 A-159 SPLIT RIONGS SPLIT RINGS SPLIT RINGS PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	57 58 64 159B HC-SB-61-217R1
HC-82XF-6	( HC-82XF-6 SERIES )	
HC-82XG-2BX US 59-09-03	( HC-82X SERIES ) PROPELLER / ENGINE RETAINING BOLTS	41, 68
HC-82XK-1 US 60-16-04	( HC-82X SERIES ) GUIDE COLLARS	71
HC-82XK-1D US 60-16-04	( HC-82X SERIES ) GUIDE COLLARS	71
HC-82XK-2CI	( HC-82X SERIES )	
HC-82XL-1B	( HC-82X SERIES )	
HC-82XL-1C	( HC-82X SERIES )	
HC-82XL-1D US 60-16-04	( HC-82X SERIES ) GUIDE COLLARS	71
HC-82XL-1DB	( HC-82X SERIES )	
HC-82XL-2	( HC-82X SERIES )	
HC-82XL-2B	( HC-82X SERIES )	
HC-82XL-2C	( HC-82X SERIES )	

MAKE / CONS	TRUCTEUR
MODEL / MO	DELE
OPIGINI	AD MUNADED

(SERIES / SERIE) ORIGIN AD NUMBER SUBJECT
ORIGINE NUMERO DE CONSIGNE SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-82XL-2CI	( HC-00V CENTER )	
HC-82XL-6B	( HC-82X SERIES )	
HC-82XL-6D	( HC-82X SERIES )	
HC-82XL-6DL	( HC-82X SERIES )	
HC-82X20-1B	( HC-82X SERIES )	
HC-92WK SERIES	( HC-82X SERIES )	
US 95-11-08	BLADE CLAMP SCREW INSPECTION	202
HC-92WK-1D	( HC-92WK SERIES )	
HC-92WK-2	( HC-92WK SERIES )	
HC-92WK-2A	( HC-92WK SERIES )	
HC-92WK-2B	( HC-92WK SERIES )	
HC-92WK-8L	( HC-92WK SERIES )	
HC-92ZK SERIES CF CF-81-13 US 95-11-08	BLADE CLAMP P/N C-1301 BLADE CLAMP SCREW INSPECTION	202
HC-92ZK-1	( HC-92ZK SERIES )	
HC-92ZK-1D	( HC-92ZK SERIES )	
HC-92ZK-2A	( HC-92ZK SERIES )	
HC-92ZK-2B	( HC-92ZK SERIES )	
HC-92ZK-5D	( HC-92ZK SERIES )	
HC-92ZK-8D	( HC-92ZK SERIES )	
US 60-16-04	GUIDE COLLARS	71
HC-92ZK-8K US 60-16-04	( HC-92ZK SERIES ) GUIDE COLLARS	71
HC-92ZK-8L US 60-16-04	( HC-92ZK SERIES ) GUIDE COLLARS	71
HA-B3Z30-1		
HC-A3V SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES  NDT INSPECTION OF BLADE, HUB AND CLAMPS	1598 HC-SB-61-217R1
HC-A3VF-2 CF CF-81-13	( HC-A3V SERIES ) BLADE CLAMP P/N C-1301	
HC-A3VF-2B CF CF-81-13	( HC-A3V SERIES ) BLADE CLAMP P/N C-1301	
HC-A3VF-2D CF CF-81-13	( HC-A3V SERIES ) BLADE CLAMP P/N C-1301	
HC-A3VF-2L CF CF-81-13	( HC-A3V SERIES ) BLADE CLAMP P/N C-1301	
HC-A3VF-3L	( HC-A3V SERIES ) BLADE CLAMP P/N C-1301	
HC-A3VK-1X	( HC-A3V SERIES )	
HC-A3VK-2A	( HC-A3V SERIES )	
HC-A3VK-2B	( HC-A3V SERIES )	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-A3VK-4	( HC-A3V SERIES )	
HC-A3V2O-3C	( HC~A3V SERIES )	
HC-A3V20-3L	( HC-A3V SERIES )	
HC-A3X SERIES US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-A3XF-2B	( HC-A3X SERIES )	
HC-A3XK-2B	( HC-A3X SERIES )	
HC-A3X20-1	( HC-A3X SERIES )	
HC-A3X20-5L	( HC-A3X SERIES )	
HC-B3MN-3 US 96-18-14	HUB REPLACEMENT / BLADE, CLAMP INSPECTION	136H
HC-B3MN-3MI US 96-18-14	HUB REPLACEMENT / BLADE, CLAMP INSPECTION	136H
HC-B3P30 SERIES		
HC-B3P30-1E	( HC-B3P30 SERIES )	
HC-B3P30-2E	( HC-B3P30 SERIES )	
HC-B3P30-4B	( HC-B3P30 SERIES )	
HC-B3R30 SERIES		
HC-B3R30-1	( HC-B3R30 SERIES )	
HC-B3R30-1E	( HC-B3R30 SERIES )	
HC-B3R30-2E	( HC-B3R30 SERIES )	
HC-B3R3O-2EA	( HC-B3R30 SERIES )	
HC-B3R30-2F	( HC-B3R30 SERIES )	
HC-B3R30-4	( HC-B3R30 SERIES )	
HC-B3R30-4B	( HC-B3R30 SERIES )	
HC-B3TN-2 SERIES CF CF-81-13 US 72-08-04 US 74-14-01 US 83-08-01R1 US 96-15-04 US 96-18-14	BLADE CLAMP P/N C-1301 PROPELLER BLADES PROPELLER BLADES PROPELLER ATTACHMENT BOLTS ONE-TIME FLUORESCENT DYE PENETRANT INSPECTION HUB REPLACEMENT / BLADE, CLAMP INSPECTION	97 105 140 HC-ASB-61-220 136H
HC-B3TN-2B	( HC-B3TN-2 SERIES )	
HC-B3TN-3 SERIES  CF CF-81-13  US 72-08-04  US 74-14-01  US 83-08-01R1  US 96-15-04  US 96-18-14	BLADE CLAMP P/N C-1301 PROPELLER BLADES PROPELLER BLADES PROPELLER ATTACHMENT BOLTS ONE-TIME FLUORESCENT DYE PENETRANT INSPECTION HUB REPLACEMENT / BLADE, CLAMP INSPECTION	97 105 140 HC-ASB-61-220 136H
HC-B3TN-3	( HC-B3TN-3 SERIES )	
HC-B3TN-3B	( HC-B3TN-3 SERIES )	
HC-B3TN-3BT	( HC-B3TN-3 SERIES )	
HC-B3TN-3BY	( HC-B3TN-3 SERIES )	

# INDEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN CANADA

(SERIES / SERIE) SUBJECT	
SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
( HC-B3TN-3 SERIES )	
( HC-B3TN-3 SERIES )	
( HC-B3TN-3 SERIES )	
( HC-B3TN-3 SERIES )	
( HC-B3TN-3 SERIES )	
PROPELLER BLADES	97
PROPELLER BLADES PROPELLER ATTACHMENT BOLTS	105
PROP BLADE - PILOT TUBE BORE AREA	140
PROPELLER BLADE / SHANK AREA	136E
ONE-TIME FLUORESCENT DYE PENETRANT INSPECTION	HC-ASB-61-220
TIOB REFLACEMENT / BLADE, CLAMP INSPECTION	136H
( HC-B3TN-5 SERIES )  NEEDLE BEARING / PILOT TUBE HOLE	95
( HC-B3TN-5 SERIES )	
PROPELLER BLADE SHANK	
( HC-B3W30 SERIES )	
( HC-B3W3O SERIES )	
BLADE CLAMP P/N C-1301	
BLADE CLAMP P/N C-1301	
RELATIVE BLADE ANGLE / BLADE CLAMP CLEARANCE	69, 83
PROPELLER BLADE SHANK	
( HC-B3Z30-2 SERIES )	
( HC-B3Z30-2 SERIES )	
( HC-B3Z30-2 SERIES )	
	118A 165E
( HC-C3YF-1 SERIES )	
BLADE SHANK CRACKS / BLADE FAILURE	118A
INSPECTION OF PROP HUBS	165E
( HC-C3YK-1 SERIES )	
	( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  ( HC-B3TN-3 SERIES )  PROPELLER BLADES PROPELLER BLADES PROPELLER BLADE S PROPELLER BLADE S PROPELLER BLADE / PILOT TUBE BORE AREA PROPELLER BLADE / SHANK AREA ONE-TIME FLUORESCENT DYE PENETRANT INSPECTION HUB REPLACEMENT / BLADE, CLAMP INSPECTION HUB REPLACEMENT / PILOT TUBE HOLE  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  ( HC-B3TN-5 SERIES )  BLADE CLAMP P/N C-1301  BLADE CLAMP P/N C-1301  RELATIVE BLADE SHANK  ( HC-B3Z30-2 SERIES )  ( HC-B3Z30-2 SERIES )  ( HC-B3Z30-2 SERIES )  BLADE SHANK CRACKS / BLADE FAILURE INSPECTION OF PROP HUBS  ( HC-C3YF-1 SERIES )  BLADE SHANK CRACKS / BLADE FAILURE

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-C3YN-2LU	( HC-C3YN-2 SERIES )	
HC-C3YN-5 SERIES		
HC-C3YN-5A	( HC-C3YN-5 SERIES )	
HC-C3YR-1 SERIES US 77-12-06 US 94-17-13	BLADE SHANK CRACKS / BLADE FAILURE INSPECTION OF PROP HUBS	118A 165E
HC-C3YR-1	( HC-C3YR-1 SERIES )	
HC-C3YR-1RF	( HC-C3YR-1 SERIES )	
HC-C3YR-2 SERIES US 77-12-06 US 94-17-13	BLADE SHANK CRACKS / BLADE FAILURE INSPECTION OF PROP HUBS	118A 165E
HC-C3YR-2	( HC-C3YR-2 SERIES )	
HC-C3YR-2AU	( HC-C3YR-2 SERIES )	
HC-C3YR-2CUF	( HC-C3YR-2 SERIES )	
HC-C3YR-2EUF	( HC-C3YR-2 SERIES )	
HC-C3YR-2FU	( HC-C3YR-2 SERIES )	
HC-C3YR-2U	( HC-C3YR-2 SERIES )	
HC-C3YR-2UF	( HC-C3YR-2 SERIES )	***************************************
HC-D3V20-6L US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NOT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-D3X20-6L US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NOT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-E3YR-1 SERIES US 77-12-06 US 94-17-13	BLADE SHANK CRACKS / BLADE FAILURE INSPECTION OF PROP HUBS	118A 165E
HC-E3YR-1K SERIES US 94-17-13	INSPECTION OF PROP HUBS	165E
HC-E3YR-1KLF	( HC-E3YR-1K SERIES )	
HC-E3YR-1R	( HC-E3YR-1 SERIES )	
HC-E3YR-1RF	( HC-E3YR-1 SERIES )	
HC-E3YR-1RLF	( HC-E3YR-1 SERIES )	
HC-E3YR-2 SERIES US 77-12-06 US 94-17-13	BLADE SHANK CRACKS / BLADE FAILURE INSPECTION OF PROP HUBS	118A 165E
HC-E3YR-2A	( HC-E3YR-2 SERIES )	
HC-E3YR-2AF	( HC-E3YR-2 SERIES )	
HC-E3YR-2AFT	( HC-E3YR-2 SERIES )	
HC-E3YR-2AL	( HC-E3YR-2 SERIES )	
HC-E3YR-2ALF	( HC-E3YR-2 SERIES )	
HC-E3YR-2ALFT	( HC-E3YR-2 SERIES )	
HC-E3YR-2ALT	( HC-E3YR-2 SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE (SE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE)

SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-E3YR-2ALTF	( HC-E3YR-2 SERIES )	
HC-E3YR-2AT	( HC-E3YR-2 SERIES )	
HC-E3YR-2ATE	( HC-E3YR-2 SERIES )	
HC-E3YR-2ATF	( HC-E3YR-2 SERIES )	
HC-E3YR-2ATFL	( HC-E3YR-2 SERIES )	
HC-E3YR-7LF		
HC-F3YR-1RF		
US 77-12-06 US 94-17-13	BLADE SHANK CRACKS / BLADE FAILURE INSPECTION OF PROP HUBS	118A 165E
HC-F3YR-2 SERIES	SLADE CHANG AS A STATE OF	
US 77-12-06 US 94-17-13	BLADE SHANK CRACKS / BLADE FAILURE INSPECTION OF PROP HUBS	1.18A 165E
HC-F3YR-2	( HC-F3YR-2 SERIES )	
HC-F3YR-2UF	( HC-F3YR-2 SERIES )	
HC-I3YR-1RF		
HC-13X SERIES US 58-07-01	SPLIT RINGS	58
US 59-01-03	SPLIT RINGS	64
US 85-14-10R2	PROPELLER BLADE CLAMP ASSEMBLIES	159B
US 97-18-02	NDT INSPECTION OF BLADE, HUB AND CLAMPS	HC-SB-61-217R1
HC-13X20-5L	( HC-13X SERIES )	
HC-13X20-6L	( HC-13X SERIES )	
HC-83V20 SERIES		
US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES  NDT INSPECTION OF BLADE, HUB AND CLAMPS	159B HC-SB-61-217R1
HC-83V20-1B	( HC-83V2O SERIES )	
HC-83V20-2	( HC-83V20 SERIES )	
HC-83X SERIES		
CF CF-81-13	BLADE CLAMP P/N C-1301	
US 57-08-04 US 58-07-01	SECURING SCREW SAFETY LINK BAR / ARM	46
US 59-01-03	SPLIT RINGS SPLIT RINGS	58 64
US 85-14-10R2	PROPELLER BLADE CLAMP ASSEMBLIES	159B
US 97-18-02	NDT INSPECTION OF BLADE, HUB AND CLAMPS	HC-SB-61-217R1
HC-83X20-2	( HC-83X SERIES )	
HC-83X20-2A	( HC-83X SERIES )	
HC-83X20-2C	( HC-83X SERIES )	
HC-83X20-2CI	( HC-83X SERIES )	
HC-93Z SERIES US 57-08-04	SECURING SCREW SAFETY LINK BAR / ARM	46
HC-93Z20-1BI	( HC-93Z SERIES )	
HC-93Z20-2C1 US 58-04-02	( HC-93Z SERIES ) SPLIT RING AND BEARING	55
PHC-A3VF SERIES		
CF CF-81-13	BLADE CLAMP P/N C-1301	1598
US 85-14-10R2 US 97-18-02	PROPELLER BLADE CLAMP ASSEMBLIES NDT INSPECTION OF BLADE, HUB AND CLAMPS	HC-SB-61-217R1

INDEX OF AIRWORTHINESS DIRECTIVES APPLICABLE IN CANADA INDEX DES CONSIGNES DE NAVIGABILITE EN VIGUEUR AU CANADA MAKE / CONSTRUCTEUR MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE (SERIES / SERIE) REFERENCE SERVICE BULLETIN HART7F11 PHC-A3VF-2B ( PHC-A3VF SERIES ) ( PHC-A3VF SERIES ) PHC-A3VE-4 PHC-C3YF-1R SERIES BLADE SHANK CRACKS / BLADE FAILURE 1184 US 77-12-06 INSPECTION OF PROP HUBS 165E 94-17-13 ( PHC-C3YF-1R SERIES ) PHC-C3YE-1RE PHC-C3YF-2 SERIES US 77-12-06 BLADE SHANK CRACKS / BLADE FAILURE 118A PHC-C3YF-2F (PHC-C3YF-2 SERIES ) ( PHC-C3YF-2 SERIES ) PHC-C3YF-2FU ( PHC-C3YF-2 SERIES ) PHC-C3YF-2UF PHC-C3YR-1 SERIES US 77-12-06 US 94-17-13 BLADE SHANK CRACKS / BLADE FAILURE 1184 INSPECTION OF PROP HUBS 165E ( PHC-C3YR-1 SERIES ) PHC-C3YR-1RF PHC-G3YF-1 SERIES ( PHC-G3YF-1 SERIES ) PHC-G3YF-1RF PHC-J3YF-1 SERIES ( PHC-J3YF-1 SERIES ) PHC-J3YF-1RF PHC-J3YF-2 SERIES

DIS 77-12-06 BLADE SHANK CRACKS / BLADE FAILURE 1184 ( PHC-J3YF-2 SERIES ) PHC-J3YF-2UF HC-B4MN-5AL PROPELLER ATTACHMENT BOLTS 140 US 83-08-01R1 US 87-15-04 153 PITCH CHANGE ROD / SPRING ASSEMBLY INSPECTION OF HUB ARM AND BLADE HUB REPLACEMENT / BLADE, CLAMP INSPECTION US 94-03. A186 136H HC-B4MP-3 SERIES PROPELLER ATTACHMENT BOLTS 140 US 83-08-01R1 US 96-18-14 HUB REPLACEMENT / BLADE, CLAMP INSPECTION 136H ( HC-B4MP-3 SERIES ) HC-B4MP-3A ( HC-B4MP-3 SERIES ) HC-B4MP-3B HC-B4MP-3C ( HC-B4MP-3 SERIES ) HC-B4TN-3 SERIES BLADE CLAMP P/N C-1301 CF CF-81-13 PROPELLER BLADES 97 115 72-08-04 US 74-14-01 US 83-08-01R1 105 PROPELLER BLADES PROPELLER ATTACHMENT BOLTS 140 INSPECTION OF HUB ARM AND BLADE 94-03-11 A186 US CHECK FOR CRACKS IN PROPELLER HUB ARM BORE A196A 95-03-03 HUB REPLACEMENT / BLADE, CLAMP INSPECTION 136H US 96-18-14 ( HC-B4TN-3 SERIES ) HC-B4TN-3 ( HC-B4TN-3 SERIES ) HC-B4TN-3A

HC-B4TN-5 SERIES

CF CF-81-13

74-14-01

83-08-01R1

HC-B4TN-3B

US

US

105

140

140C

( HC-B4TN-3 SERIES )

BLADE CLAMP P/N C-1301

PROPELLER ATTACHMENT BOLTS

PROPELLER BLADES

PROPELLER MID-BLADE

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

ORIGINE NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
HARTZELL HC-B4TN-5 SERIES (CONTINUED / SUITE) US 94-03-11 US 95-01-02 US 96-18-14	INSPECTION OF HUB ARM AND BLADE INSPECT/REPLACEMENT PROP BLADE/HUB HUB REPLACEMENT / BLADE, CLAMP INSPECTION	A186 A182A, A183A
HC-B4TN-5C	( HC-B4TN-5 SERIES )	136H
HC-B4TN-5DL	( HC-B4TN-5 SERIES )	
HC-B4TN-5F	( HC-B4TN-5 SERIES )	
HC-B4TN-5GL	( HC-B4TN-5 SERIES )	
HC-B4TN-5JL	( HC-B4TN-5 SERIES )	
HC-B4TN-5ML	( HC-B4TN-5 SERIES )	
HC-C4YR-2 SERIES US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	
HC-C4YR-2	( HC-C4YR-2 SERIES )	118A
HC-C4YR-2FC	( HC-C4YR-2 SERIES )	
HC-D4N-3 SERIES US 96-15-04	ONE-TIME FLUORESCENT DYE PENETRANT INSPECTION	
HC-D4N-3A	( HC-D4N-3 SERIES )	HC-ASB-61-220
HC-D4N-3C	( HC-D4N-3 SERIES )	
HC-E4A SERIES US 96-15-04	ONE-TIME FLUORESCENT DYE PENETRANT INSPECTION	HC-ASB-61-220
HC-E4A-3A US 98-02-07 US 98-17-04	( HC-E4A SERIES ) BLADE COUNTERWEIGHT CLAMP BOLTS PROPELLER BLADE COUNTERWEIGHT CLAMPS	61-219R1 HC-ASB-61-237
HC-E4A-3D	( HC-E4A SERIES )	
HC-E4A-3I US 98-02-07 US 98-17-04	( HC-E4A SERIES ) BLADE COUNTERWEIGHT CLAMP BOLTS PROPELLER BLADE COUNTERWEIGHT CLAMPS	61-219R1 HC-ASB-61-237
US 98-17-04	( HC-E4A SERIES ) PROPELLER BLADE COUNTERWEIGHT CLAMPS	HC-ASB-61-237
HC-E4N-3 SERIES		
HC-E4N-3A HC-E4N-5 SERIFS	( HC-E4N-3 SERIES )	
HC-E4N-5B	( HC-E4N-5 SERIES )	
HC-F4YR-2 US 77-12-06	BLADE SHANK CRACKS / BLADE FAILURE	118A
HC-B5MA-3 SERIES US 96-18-14	HUB REPLACEMENT / BLADE, CLAMP INSPECTION	136H
HC-B5MA-3D	( HC-B5MA-3 SERIES )	
HC-B5MP-3 SERIES CF CF-81-13 US 83-08-01R1 US 86-06-02 US 96-15-04 US 96-18-14	BLADE CLAMP P/N C-1301 PROPELLER ATTACHMENT BOLTS PROPELLER ATTACHMENT BOLTS ONE-TIME FLUORESCENT DYE PENETRANT INSPECTION HUB REPLACEMENT / BLADE, CLAMP INSPECTION	140 140A ISSUE 5 HC-ASB-61-220 136H
HC-B5MP-3A	( HC-B5MP-3 SERIES )	

MAKE / CONSTRUCTEUR  MODEL / MODELE  ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
HARTZELL HC-B5MP-3C US 87-05-01 US 87-16-02	( HC-B5MP-3 SERIES )  BLADE PILOT TUBE BORE AREA  PROPELLER BLADE CHANGE TO HC-B5MP-3C/M10876ASK	136C 136D
US 87-05-01 US 87-16-02	( HC-B5MP-3 SERIES ) BLADE PILOT TUBE BORE AREA PROPELLER BLADE CHANGE TO HC-B5MP-3C/M10876ASK	136C 136D
HC-E5N HC-A6A-3		
HOFFMANN		
<b>HO-27 SERIES</b> GY 1998-322/2	PROPELLER MOUNTING BOLTS	61-11-03 E10 REV A
HO~27-HM-183-150	( HO-27 SERIES )	
HD-27-HM-186-150	( HO-27 SERIES )	
HO-V62		
HO-V62-R		
HO-V62-R160		
HD-V62R/L160T GY 83-150/4	ROOT ATTACHMENT OF BLADES	4C, 4CR1
HO-V123F		
HO-V352F/170FQ		
LEWIS L11BK42		
L11C-43		
L11CK		
L55CK-43		
MCCAULEY B2A34C2O5		
B2D34C US 70-04-01 US 82-27-02R1 US 91-15-04	MID-BLADE AND TIP FAILURES / FOD OR CRACKS PROPELLER BLADE SHANK PROPELLER BLADE THREADED RETENTION AREA	76 146 184
B2D34C2O2		
B2D34C2O6		
<b>B2D34C2O7</b> US 82-27-02R1	PROPELLER BLADE SHANK	146
B2D34C2O8		
B2D34C211		
B2D34C212		
B2D34C213		
B2D34C214 US 82-27-02R1	PROPELLER BLADE SHANK	146
B2D34C217 US 82-27-02R1	PROPELLER BLADE SHANK	146
<b>B2D34C218</b> US 82-27-02R1	PROPELLER BLADE SHANK	146

MAKE	C	NC	STA	RU	CT.	ΕU
MOD	EI.	/ IN/	OD	FI	E	

ORIGIN AD NUMBER

(SERIES / SERIE)

ORIGINE NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
MCCAULEY		
B2D34C219 US 82-27-02R1	PROPELLER BLADE SHANK	
B2D34C220	THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE S	146
US 82-27-02R1	PROPELLER BLADE SHANK	146
B2D37C224-B		
B3D32C		
B3D32C412		
B3D32C414		
B3D32C417		
B3D32C407		
B3D36C424		
B3D36C428		
B3D36C429		
B3D36C431		
B3D36C432		
B5JFR36C1103		
C2A34C US 82-27-02R1	PROPELLER BLADE SHANK .	146
C2A34C2O4		
US 82-27-02R1	PROPELLER BLADE SHANK	146
C2A36C SERIES US 64-24-04	BLADE THREADED SHANK	48C
C2A36C32AE	( C2A36C SERIES )	
US 68-08-01	PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
C3D36C415		
C5JFR36C1104		
D-1093 US 54-12-02	WIRDATION STDESS SLIDVEY / CORDOSTON OR CALLTAG	
	VIBRATION STRESS SURVEY / CORROSION OR GALLING	
US 68-10-03	HUB ALIGNMENT DOWELS / MOUNTING STUDS / STUD HOLES	
US 75-24-13 US 77-13-17	PROPELLER HUB BLADE ACTUATING PINS / WASHERS	111 99, 99-1, 99-2, 99-3
US 78-01-13	PROPELLER HUB	128A
D2AF34C30 US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
US 91-15-04	PROPELLER BLADE THREADED RETENTION AREA	184
D2AF34C46		
<b>D2AF34C52</b> US 75-24-13	PROPELLER HUB	111
US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
D2AF34C54		
CF CF-68-17 US 68-10-03	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES HUB ALIGNMENT DOWELS / MOUNTING STUDS / STUD HOLES	
D2AF34C59		
US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
D2AF34C61 US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
20 JANUARY / JANUARD		PODEL LEDS /HELTOES

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
MCCAULEY D2AF34C61 (CONTINUED / SUITE) US 91-15-04	PROPELLER BLADE THREADED RETENTION AREA	184
D2AF34C71 US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
D2AF34C81 US 77-13-17 US 91-15-04	BLADE ACTUATING PINS / WASHERS PROPELLER BLADE THREADED RETENTION AREA	99, 99-1, 99-2, 99-3 184
D2AF34C91 US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
D2AF34C301		
D2AF34C302		
D2AF34C3O3		
D2AF34C305 US 78-01-13	PROPELLER HUB	128A
D2AF34C306		
D2AF34C307		
D2AF34C308 US 82-27-02R1	PROPELLER BLADE SHANK	146
<b>D2AF34C310</b> US 82-27-02R1	PROPELLER BLADE SHANK	146
D2AF36C48		
D2A34C US 68-08-01 US 68-10-03 US 77-13-17 US 77-16-01	PROPELLER CYLINDER ATTACHMENT SCREWS HUB ALIGNMENT DOWELS / MOUNTING STUDS / STUD HOLES BLADE ACTUATING PINS / WASHERS BLADE ACTUATING PINS / WASHER	92, 94
D2A34C49 CF CF-68-17 US 68-08-01 US 68-10-03 US 77-16-01	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES PROPELLER CYLINDER ATTACHMENT SCREWS HUB ALIGNMENT DOWELS / MOUNTING STUDS / STUD HOLES BLADE ACTUATING PINS / WASHER	SERVICE MAN 660115 92, 94
D2A34C50 US 77-16-01	BLADE ACTUATING PINS / WASHER	
D2A34C58 US 68-08-01 US 77-16-01 US 91-15-04	PROPELLER CYLINDER ATTACHMENT SCREWS BLADE ACTUATING PINS / WASHER PROPELLER BLADE THREADED RETENTION AREA	92, 94 184
D2A34C67 US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
D2A34C90		
D2A34C98 US 91-15-04	PROPELLER BLADE THREADED RETENTION AREA	184
D2A34C2O3		
D2A36C SERIES US 64-24-04	BLADE THREADED SHANK	48C
D2A36C US 68-08-01 US 77-16-01	( D2A3GC SERIES ) PROPELLER CYLINDER ATTACHMENT SCREWS BLADE ACTUATING PINS / WASHER	92, 94
D2A36C33 CF CF-68-17	( D2A36C SERIES ) PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES	SERVICE MAN 660115

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT
SUJET

ORIGINE	NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
MCCAUL			
D2A36	C33 NUED / SUITE)	( D2A36C SERIES )	
US	68-08-01	PROPELLER CYLINDER ATTACHMENT SCREWS	
US	77-16-01	BLADE ACTUATING PINS / WASHER	92, 94
D3AF3	2C80		
	77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
US	95-24-05R1	VISUAL & DYE PENETRANT INSPECTIONS OF PROP HUBS	SL 1993-11A
D3AF32			
US	95-24-05R1	VISUAL & DYE PENETRANT INSPECTIONS OF PROP HUBS	SL 1993-11A
D3A320			
US US	68-08-01 71-17-03	PROPELLER CYLINDER ATTACHMENT SCREWS PROPELLER HUB	92, 94
US	77-13-17	BLADE ACTUATING PINS / WASHERS	89 99, 99-1, 99-2, 99-3
US	85-08-08	PROPELLER HUB	33, 33-1, 33-2, 39-3
D3A320	88		
US US	68-08-01 71-17-03	PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
	77-13-17	PROPELLER HUB BLADE ACTUATING PINS / WASHERS	89
D3A320		TO THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF THE STATE OF TH	33, 33-1, 99-2, 99-3
US	68-08-01	PROPELLER CYLINDER ATTACHMENT SCREWS	00 04
US	71-17-03	PROPELLER HUB	92, 94 89
US	85-08-08	PROPELLER HUB	
D3A32C	403		
D3A32C	409C		
D3A32C	444		
DSASZC	411		
D3A34C US	77-26-03	DIADE AND AND AND AND AND AND AND AND AND AND	
US	82-27-02R1	BLADE ACTUATING PIN SCREWS PROPELLER BLADE SHANK	129 146
D3A34C	401		
	77-26-03 82-27-02R1	BLADE ACTUATING PIN SCREWS	129
US	82-27-02R1	PROPELLER BLADE SHANK	146
D3A34C	401C		
US US	77-26-03 82-27-02R1	BLADE ACTUATING PIN SCREWS PROPELLER BLADE SHANK	129
		PROPELLER BLADE SHANK	146
D3A34C	402 77-26-02	DI ADE ACTUATING DIN CODOUG	100
US	77-26-03 82-27-02R1	BLADE ACTUATING PIN SCREWS PROPELLER BLADE SHANK	129 146
D3A34C4			
		HUB FAILURE - CORROSION AND/OR FATIGUE	154B
US	CF-91-40 82-27-02R1	PROPELLER BLADE SHANK	146
D3A34C4	403/80VA-0		
CF	CF-91-40	HUB FAILURE - CORROSION AND/OR FATIGUE	154B
0.5	82-27-02R1	PROPELLER BLADE SHANK	146
D3A34C4 US		DDODELLED DIADE CHANIV	146
03	82-27-02R1	PROPELLER BLADE SHANK	146
D3A34C4 US	<b>104</b> 82-27-02R1	PROPELLER BLADE SHANK	146
		PROFECLER BLADE SHAIN	140
D3A34C4		DDODELLED BLADE SHANK	146
US	82-27-02R1	PROPELLER BLADE SHANK	146
D3A36C4	135		
D3A36C4	136		
E2A34C			
US	68-08-01	PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
US '	72-25-07	PROPELLER BLADES / HUB	81, 87, 88

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
MCCAULEY E2A34C (CONTINUED / SUITE)		
US 77-16-01 US 83-24-11R1 US 91-15-04	BLADE ACTUATING PINS / WASHER RETENTION THREADS - BLADES & FERRULES PROPELLER BLADE THREADED RETENTION AREA	151A 184
E2A34C73 US 68-08-01 US 72-25-07 US 77-16-01 US 83-24-11R1 US 91-15-04	PROPELLER CYLINDER ATTACHMENT SCREWS PROPELLER BLADES / HUB BLADE ACTUATING PINS / WASHER RETENTION THREADS - BLADES & FERRULES PROPELLER BLADE THREADED RETENTION AREA	92, 94 81, 87, 88 151A 184
1A90		
1A90/CF		
1A90/CF6950		
1A90/CF7038		
1A90/CF7040		
1A90/CF7042		
1A90/CF7043		
1A90/CF7044		
1A90/CF7050		
1A90/CF7052		
1A90/CF7139		
1A90/CF7142		
1A90/CF7144		
1A90/CF7146		
1A90/CF7147		
1A90/CF7148		
1A90/CF7150		
1A90/CF7151		
1A90/CF7152		
1A90/CF7154		
1A90/CF7247		
1A90/CF7343		
1A90/CF7347		
1A90/CF7348		
1A90/CF7350		
1A90/CF7351		
1A90/CF7443		
1A90/CF7445		
1A90/CF7447		
1A90/CF7449		

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)

ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET		REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
MCCAULEY 1A90/CF7535			
1A90/CF7538			
1A90/CH7150			
1A90/LM7142		······································	
1A100			
1A100/ACM			
1A100/ACM6948			
1A100/ACM7254			
1A100/DCM			
1A100/DCM6948			
1A100/HCM			
1A100/MCM			
1A100/MCM6450			
1A100/MCM6948			
1A100/MCM6950			
1A101			
1A101/DCM			
1A101/DCM6948			, , , , ,
1A101/DCM6950			
1A101/DCM6952			
1A101/DCM6954			
1A101/DCM6956			
1A101/DCM7148			
1A101/GCM 1A101/HCM			
1A101/HCM6948			
1A101/HCM6954			
1A101/HCM6968			
1A101/PCM			
1A101/PCM6948			
1A102			
1A102/DCM			
1A102/DCM6948			
1A103 US 89-26-10 US 97-06-16	HUB BOLT HOLES / FORWARD FACE ARE PROPELLER HUB INSPECTION	A (REWORK)	169C 221B
1A103/TCM US 89~26-10 US 97-06-16	HUB BOLT HOLES / FORWARD FACE ARE PROPELLER HUB INSPECTION	A (REWORK)	169C 221B
55 57 00 16	1101 201 101		

MAKE / CONSTRUCTEUR MODEL / MODELE	(SERIES / SERIE)	REFERENCE SERVICE BULLETIN
ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	BULLETIN DE SERVICE DE REF.
MCCAULEY		
1A103/TCM6956 US 89-26-10 US 97-06-16	HUB BOLT HOLES / FORWARD FACE AREA (REWORK) PROPELLER HUB INSPECTION	169C 221B
1A103/TCM6958 US 89-26-10 US 97-06-16	HUB BOLT HOLES / FORWARD FACE AREA (REWORK) PROPELLER HUB INSPECTION	169C 221B
1A103/TCM7553 US 97-06-16	PROPELLER HUB INSPECTION	2218
1A105		
1A105/SCM		
1A105/SCM6950		
1A105/SCM6951		
1A105/SCM7148		
1A105/SCM7152		
1A105/SCM7153		
1A105/SCM7154		
1A105/SCM7156		
1A105/SCM7157		
1A170 US 82-27-01	CENTER RELIEF BORE / BOLT HOLES / HUB AREA	
1A170/BMS (STC)		
1A170/CFA		
1A170/CFA7660		
1A170/DF7453		
1A170/DF7653		
1A170/DM		
1A170/DM7353		
1A170/DM7355		
1A170/DM7356		
1A170/DM7452		
1A170/DM7456		
1A170/DM7551		
1A170/DM7553		
1A170/DM7644		
1A170/DM7645		
1A170/DM7647		
1A170/DM7648		
1A17O/DM7649		
1A170/DM7650		
1A170/DM7651		

MAKE / CONSTRUCTEUR

(SERIES / SERIE)

MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

MCCAULEY 1A170/DM7652

1A170/DM7653

1A170/DM7654

1A170/EFA

1A170/FFA

US 82-27-01

CENTER RELIEF BORE / BOLT HOLES / HUB AREA

1A170/FFA7563 82-27-01

CENTER RELIEF BORE / BOLT HOLES / HUB AREA

1A170/GM

1A170/GM7446

1A170/GM7448

1A170/GM7450

1A170/GM7452

1A170/GM7453

1A170/GM7455

1A170/GM7458

1A170/GM7852

1A170/SFC

1A170/SFC7652

1A175

1A175/ATM

1A175/ATM7249

1A175/ATM8042

1A175/DM

1A175/DM7649

1A175/DM7652

1A175/DM7653

1A175/DM7654

1A175/DM8040

1A175/DM8241

1A175/ETM

1A175/ETM8042

1A175/FC8467

1A175/FC8470

1A175/GM

1A175/GMA

1A175/GMA8040

1A175/GMA8044

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)
SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
MCCAULEY 1A175/GMA8242		
1A175/GM6946		
1A175/GM7142		
1A175/GM7448		
1A175/GM7455		
1A175/GM8238		
1A175/GM8241		
1A175/GM8242		
1A175/GM8243		
1A175/GM8244		
1A175/GM8245		
1A175/SFC		
1A175/SFC8040		
1A200		
1A200/DFA		
1A200/DFA8242		
1A200/DFA8245 1A200/FA		
1A200/FA8043		
1A200/FA8242		
1A200/FA8243		
1A200/FA8248		
1A200/FA8452		
1A200/FA8454		
1A200/FA9043		
1A200/FM		
1A200/FM8945		
1A200/FM9042		
1A200/FM9045		
1A200/FM9047		
1A200/FM9052		
1A200/HFA		
1A200/HFA8039		
1A200/HFA8041		
1890		
1B90/CF7045		
1B90/CM		

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIE:
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)
SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
MCCAULEY 1B90/CM6460		
1B90/CM6558		
1B90/CM6654		
1B90/CM6852		
1B90/CM6948		
1B90/CM6950		
1B90/CM7038		
1B90/CM7040		
1B90/CM7042		
1B90/CM7044		
1B90/CM7046		
1B90/CM7047		
1B90/CM7052		
1B90/CM7138		
1B90/CM7140		
1B90/CM7141		
1B90/CM7142 1B90/CM7143	······································	
1B90/CM7144		
1B90/CM7145		
1B90/CM7146		
1B90/CM7147		
1B90/CM7148		
1B90/CM7149		
1B90/CM7150		
1B90/CM7151		
1B90/CM7152		
1B90/CM7154		
1B90/CM7242		
1B90/CM7243		
1B90/CM7245		
1B90/CM7340		
1B90/CM7341		
1B90/CM7342		
1B90/CM7343		
1B90/CM7345		
1B90/CM7346		

MAKE / CONSTRUCTEUR
MODEL / MODELE (SERIES / SERIE)
ORIGIN AD NUMBER
ORIGINE NUMBERO DE CONSIGNE SUJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE	SERVICE DE REF.
MCCAULEY 1890/CM7347			
1B90/CM7348			
1B90/CM7351			
1B90/CM7438			
1B90/CM7440			
1B90/CM7441			
1B90/CM7442			
1B90/CM7443		 	
1B90/CM7444			
1B90/CM7445			
1B90/CM7447			
1B90/CM7449			
1B90/CM7450			
1B90/CM7545			
1B90/ECM			
1B175			
1B175/MFC			
1B175/MFC8455			
1B175/MFC8467			
18235			
1B235/BFA		 	
1B235/BFA7762			
1090		 	
1C90/ALM			
1C90/ALM7242 1C90/ALM7246		 	
1C90/ALM7250			
1C90/CLM		 	
1C90/CLM72			
1C90/CLM7240			
1C90/CLM7242			
1C90/CLM7246		 	
1C90/CLM7250			
1C90/LM			
1C90/LM7242			
1C90/LM7244			
1C90/LM7246			

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE 6

(SERIES / SERIE) SUBJECT

ORIGINE NUMERO DE CONSIGNE	SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF
MCCAULEY 1C90/LM7249		
1C90/LM7250		
1C90/LM7252		
1C90/LM7446		
10160		
1C160/CTM		
1C160/CTM7553		
1C160/CTM7555		
1C160/CTM7557		
1C16O/DM7557		· ···· ··· ···· ···· ··· · · · · · · ·
1C16O/DTM		
1C160/DTM7533		
1C160/DTM7553		
1C160/DTM7557		
1C172		
1C172/AGM		
1C172/AGM7059		
1C172/AGM7250		
1C172/AGM7254		
1C172/AGM7264		
1C172/BTM		
1C172/BTM7359		
1C172/CM		
1C172/EM		
1C172/EM7249 1C172/EM7651		
1C172/EM7652		
1C172/EM7653		
1C172/EM7654		
1C172/EM7655		
1C172/EM7656		
1C172/MDM		
1C172/MDM7653		
1C172/MDM7654		
1C172/MDM7655		
1C172/MGM		
1C172/MGM7458		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

CATORIC INDIVIEND BE CONSTONE		
MCCAULEY 1C172/MTM		
1C172/MTM7458		······································
1C172/MTM7553		
1C172/MTM7648		
1C172/MTM7653		
1C172/SBTM		
1C172/SBTM7359		
1C172/TM		
1C172/TM5376		
1C172/TM7359		
1C172/TM7448		
1C172/TM7456		
1C172/TM7458		
1C172/TM7648		
1C172/TM7653		
1C172/TM7656		
1C172/TM7996		
1C200/FC8467		
1C235/LFA7570		
1P235		
2AF34C55	DENETRANT / MACHETIC INCRECTION DI ADEC / EEDDIN EC	CEDVICE MAN GGO115
CF CF-68-17 US 68-10-03 US 71-18-02	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES HUB ALIGNMENT DOWELS / MOUNTING STUDS / STUD HOLES	
US 71-18-02 US 77-13-17	PROPELLER COUNTERWEIGHT ASSEMBLY BLADE ACTUATING PINS / WASHERS	93, 93-1, 93-2 99, 99-1, 99-2, 99-3
2AF34C502		
2AF36C39	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES	SERVICE MAN GGO11E
CF CF-68-17 US 63-10-04	BLADE THREADED SHANK	53
2AF36C89	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES	SERVICE MAN GGO115
CF CF-68-17	PENETRANT / MAGNETIC INSPECTION BLADES / FERROLES	SERVICE MAN 660115
2A31C21		
2A34C SERIES 2A34C		
US 68-08-01	PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
US 77-13-17 US 77-16-01	BLADE ACTUATING PINS / WASHERS BLADE ACTUATING PINS / WASHER	99, 99-1, 99-2, 99-3
US 82-27-02R1	PROPELLER BLADE SHANK	146
US 83-24-11R1	RETENTION THREADS - BLADES & FERRULES	151A
<b>2A34C22</b> US 77-13-17	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
2A34C50		
CF CF-68-17	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES	
US 68-08-01 US 77-16-01	PROPELLER CYLINDER ATTACHMENT SCREWS BLADE ACTUATING PINS / WASHER	92, 94

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	(SERIES / SERIE) SUBJECT SUBJECT SUBJECT	REFERENCE SERVICE BULLETIN
MCCAULEY		BULLETIN DE SERVICE DE REF.
2A34C66		
CF CF-68-17 US 68-08-01	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES PROPELLER CYLINDER ATTACHMENT SCREWS	SERVICE MAN 660115
US 77-16-01 US 83-24-11R1	BLADE ACTUATING PINS / WASHER	92, 94
US 91-15-04	RETENTION THREADS - BLADES & FERRULES PROPELLER BLADE THREADED RETENTION AREA	151A
2A34C66N	THE TOTAL AREA	184
US 68-08-01 US 77-16-01	PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
US 83-24-11R1	BLADE ACTUATING PINS / WASHER RETENTION THREADS - BLADES & FERRULES	
US 91-15-04	PROPELLER BLADE THREADED RETENTION AREA	151A 184
2A34C2O1		
US 82-27-02R1	PROPELLER BLADE SHANK	146
2A34C2O3	22225	
US 82-27-02R1	PROPELLER BLADE SHANK	146
<b>2A34C2O3B</b> US 82-27-02R1	PROPELLER BLADE SHANK	
2A34C2O9	- MOTELLIN DEADLE STIANK	146
2A34C2O9		
<b>2A34C216</b> US 82-27-02R1	DDODELLED BLADE CHARK	
	PROPELLER BLADE SHANK	146
2A34C221B		
2A34C4O1	( 2A34C SERIES )	
2A36C SERIES		
CF CF-68-17 US 64-24-04	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES BLADE THREADED SHANK	
2A36C		48C
US 68-08-01	( 2A36C SERIES ) PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
US 77-16-01 US 83-24-11R1	BLADE ACTUATING PINS / WASHER RETENTION THREADS - BLADES & FERRULES	
US 98-25-13	BLADE THREADED RETENTION AREA CRACKS	151A SL 1989-5
2A36C1	( 2A36C SERIES )	
US 77-16-01	BLADE ACTUATING PINS / WASHER	
2A36C18	( 2A36C SERIES )	
US 77-16-01	BLADE ACTUATING PINS / WASHER	
<b>2A36C23</b> US 68-08-01	( 2A36C SERIES )	
US 77-16-01	PROPELLER CYLINDER ATTACHMENT SCREWS BLADE ACTUATING PINS / WASHER	92, 94
US 83-24-11R1 US 98-25-13	RETENTION THREADS - BLADES & FERRULES BLADE THREADED RETENTION AREA CRACKS	151A SL 1989-5
		2F 1302-2
<b>2A36C23-DP</b> US 68-08-01	( 2A36C SERIES ) PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
US 77-16-01 US 98-25-13	BLADE ACTUATING PINS / WASHER BLADE THREADED RETENTION AREA CRACKS	
2A36C29		SL 1989-5
2A36C29 US 68-08-01	( 2A36C SERIES ) PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
US 77-16-01	BLADE ACTUATING PINS / WASHER	
2D34C		
US 70-04-01 US 77-16-01	MID-BLADE AND TIP FAILURES / FOD OR CRACKS BLADE ACTUATING PINS / WASHER	76
2D34C9	, , , , , , , , , , , , , , , , , , , ,	
US 77-16-01	BLADE ACTUATING PINS / WASHER	
US 91-15-04	PROPELLER BLADE THREADED RETENTION AREA	184
2D34C14		
2D34C53		
US 70-04-01	MID-BLADE AND TIP FAILURES / FOD OR CRACKS	76

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

ORIGINE NUMERO DE CONSIGNE	2015.1	DOLLETIN DE SENTISE DE MEN
MCCAULEY 2D34C53 (CONTINUED / SUITE) US 91-15-04 2D34C215	PROPELLER BLADE THREADED RETENTION AREA	184
2D36C SERIES US 64-24-04	BLADE THREADED SHANK	48C
2D36C	( 2D36C SERIES )	
US 70-04-01 US 77-16-01	MID-BLADE AND TIP FAILURES / FOD OR CRACKS BLADE ACTUATING PINS / WASHER	76
2D36C14	( 2D36C SERIES )	CERVICE MAN COOLE
CF CF-68-17 US 70-04-01 US 77-16-01	PENETRANT / MAGNETIC INSPECTION BLADES / FERRULES MID-BLADE AND TIP FAILURES / FOD OR CRACKS BLADE ACTUATING PINS / WASHER	76
2D36C28	( 2D36C SERIES )	
3AF32C SERIES		
3AF32C	DIADE ACTUATING DING / WACHEDS	99, 99-1, 99-2, 99-3
US 77-13-17 US 83-13-06	BLADE ACTUATING PINS / WASHERS PROPELLER COUNTERWEIGHT BOLTS	147
3AF32C75	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
US 77-13-17 US 95-24-05R1		SL 1993-11A
3AF32C87	DIADE ACTUATING DANG / MACHEDO	00 00 1 00 0 00 0
US 77-13-17 US 95-24-05R1	BLADE ACTUATING PINS / WASHERS VISUAL & DYE PENETRANT INSPECTIONS OF PROP HUBS	99, 99-1, 99-2, 99-3 SL 1993-11A
3AF32C504		4.47
US 83-13-06	PROPELLER COUNTERWEIGHT BOLTS	147
3AF32C505 US 83-13-06	PROPELLER COUNTERWEIGHT BOLTS	147
<b>3AF32C506</b> US 83-13-06	PROPELLER COUNTERWEIGHT BOLTS	147
<b>3AF32C507</b> US 83-13-06	PROPELLER COUNTERWEIGHT BOLTS	147
3AF32C508 US 83-13-06	PROPELLER COUNTERWEIGHT BOLTS	147
3AF32C509		
US 83-13-06	PROPELLER COUNTERWEIGHT BOLTS	147
3AF32C511		
3AF32C512C	,	
3AF32C515	( 3AF32C SERIES )	
3AF32C521	( 3AF32C SERIES )	
3AF32C522	( 3AF32C SERIES )	
3AF32C523	( 3AF32C SERIES )	
3AF32C528	( 3AF32C SERIES )	
	BLADE ACTUATING PINS / WASHERS VISUAL & DYE PENETRANT INSPECTIONS OF PROP HUBS	99, 99-1, 99-2, 99-3 SL 1993-11A
3AF34C502		
3AF34C503		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSI (SERIES / SERIE) SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUBJET SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
MCCAULE 3AF340			
3AF340			
US	77-13-17 95-24-05R1	BLADE ACTUATING PINS / WASHERS	99, 99-1, 99-2, 99-3
US	95-24-05R1	VISUAL & DYE PENETRANT INSPECTIONS OF PROP HUBS	SL 1993-11A
3AF370	516		
3A32C	C0 00 04		
US	68-08-01	PROPELLER CYLINDER ATTACHMENT SCREWS	92, 94
<b>3A32C7</b> US	<b>6</b> 68-08-01	PROPELLER CYLINDER ATTACHMENT SCREWS	00.00
3A32C4	06	TOTAL OF ETHELIT ATTACHMENT SCREWS	92, 94
3FF32C	E01		
	78-06-02	BLADE ACTUATING PIN SCREWS	404
		BLADE ACTUATING PIN SCREWS	13.1
3GFR34			
3GFR34	C701		
3GFR34	C702		
3GFR34	C703		
4HFR34			
4HFR34			
4HFR34			
<b>41D592</b> 0	6 54-12-02	VIBRATION STRESS SURVEY / CORROSION OR GALLING	
MT PROPI	FIIFR		
	A/170-08		
	90-214/2 93-088	INSPECT BLADE ROOT LAG SCREWS	44
	94-098	PROPELLER SERVO ELECTRIC MOTOR REPLACEMENT OF PU EROSION STRIP	6
MTV-9-	3 SERIES		
		( MTV-9-B SERIES )	
		METAL EROSION STRIP	#8
MTV-9-E	3-C/C200-15	( MTV-9-B SERIES )	
MTV-14	SERIES		
MTV-14-	- D	( MTV-14 SERIES )	
PZL-WARS			
AW-2-30	) 1393009	PROPELLER LIFE LIMITS & TBO'S	1393009
US-1220	1181134	EXTENSION OF SERVICE LIFE	1181134
	1188163	PROPELLER MAINT & REPAIR	1188163
US-1320	OOA		
	13283001	TECHNICAL REVISIONS	13283001
	13283002 13283003	TECHNICAL REVISIONS	13283002 13283003
PL	13284004	GREASE NIPPLES	
PL	13284005 13285007	SEALING PLUGS	13284005
PL ·	13285007		13285007
PL .	13285008	DESIGN MODIFICATION	13285008
PL ·	13286010	DESIGN MODIFICATION EXTENSION OF TBO FOLLOWING FIRST OVERHAUL DESIGN MODIFICATIONS	13286010
	13288011	DESIGN MODILION 1500	13286011 13288013
	13288014	EXTENSION OF SERVICE LIFE AFTER 1 ST MAIN OVERHAUL	
	13288015	EXTENSION OF SERVICE LIFE X/R TO MSB # 13288014	

MAKE / CONSTRUCTEUR MODEL / MODELE ORIGIN AD NUMBER

(SERIES / SERIE)

SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
PZL-WARSZAWA US-132000A (CONTINUED / SUITE) PL 13288016 PL 13289018 PL 13289019	EXTENSION OF SERVICE LIFE AFTER 2 ND MAIN OVERHAUL REPLACEMENT PLUGS IN STARPIECE AXLE HOLES SERVICE LIFE - STARPIECE & AXLE ASSEMBLY	13288016 13289018 13289019
S & S CANADIAN S & S 220D SENSENICH CS-3FR5 US 63-19-04 43K10107	BLADE SHANK / SPLIT RETAINING GROOVE BLADE FERRULE	133R1, R-9
69CK SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
69CK-0-48	( 69CK SERIES )	
69CK-0-52	( 69CK SERIES )	
69E US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M69CK SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M69CK	( M69CK SERIES )	
M69CK-0-48	( M69CK SERIES )	
M69CK-0-50	( M69CK SERIES )	
M69CK-0-52	( M69CK SERIES )	
M69CK-50	( M69CK SERIES )	
M69CK-52	( M69CK SERIES )	
W69C-23		
W69EK		
W69J-28		
70D SERIES		
70D-40	( 70D SERIES )	
70D-42	( 70D SERIES )	
70L		
70LY-36		
W70D-42		
W70DK-42		
W70LY-34		
72 SERIES	TO CEDITE.	
72-42	( 72 SERIES )	
72-48	( 72 SERIES )	
72-50	( 72 SERIES )	
72A SERIES		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE)

ONIGINE NOWERO DE CONS	IGNE SUJET	BULLETIN DE SERVICE DE REF.
SENSENICH 72A-48	( 72A SERIES )	
72AM-2	( 72A SERIES )	
72C SERIES		
72C-42	( 72C SERIES )	
72C-44	( 72C SERIES )	
<b>72CK SERIES</b> US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
72CK	( 72CK SERIES )	
72CK-0-42		
72CK-0-48	( 72CK SERIES )	
72CK-0-50	( 72CK SERIES )	
72CK-0-52	( 72CK SERIES )	
72CK-0-54	( 72CK SERIES )	
72CK-0~55	( 72CK SERIES )	
72CK-0-56	( 72CK SERIES )	
72CK-40		
72CK-42		
72CK-44		
72CK-48	( 72CK SERIES )	
72CK-52	( 72CK SERIES )	
72CK-56	( 72CK SERIES )	
72CK-58-0	( 72CK SERIES )	
72CKS6-0-52	( 72CK SERIES )	
72CKS6-0-54	( 72CK SERIES )	
72CKS6~0-56	( 72CK SERIES )	
72CKS12-0-52	( 72CK SERIES )	
<b>72DF SERIES</b> US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
72DF-48	( 72DF SERIES )	
72DF-49	( 72DF SERIES )	
72GK SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
72GK-42		
72GK-44		
72GK-48	( 72GK SERIES )	
72GK-50	( 72GK SERIES )	
W72-42		
W72A-48		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER DE CONSIGNE SUBJECT
SUBJECT
SUBJECT

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

ORIGINE NUMERO DE CONSIGNI	E SUJET	BULLETIN DE SERVICE DE REF
SENSENICH W72C-42		
W72CK-42		
W72CK-44		
W72FK-48		
W72GK-46		
W72GK-48		
W72T2FK43		
<b>74CK SERIES</b> US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
74CK-0-40		
74CK-0-42		
74CK-0-44		
74CK-0-46	( 74CK SERIES )	
74CK-2-36	( 74CK SERIES )	
74CK-2-44	( 74CK SERIES )	
74CK-2-46	( 74CK SERIES )	
74DC SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
74DC-0-54	( 74DC SERIES )	
74DC-0-56	( 74DC SERIES )	
74D SERIES		
74DMS9	( 74D SERIES )	
74DM6 SERIES US 60-11-08 US 66-23-02	PILOT BORE WATER SOLUBLE MID-BLADE DECAL	R-8-1 R-11, R-12, R-12A
74DM6	( 74DM6 SERIES )	
74DM6-0-45	( 74DM6 SERIES )	
74DM6-0-48	( 74DM6 SERIES )	
74DM6-0-50	( 74DM6 SERIES )	
74DM6-0-52	( 74DM6 SERIES )	
74DM6-0-53	( 74DM6 SERIES )	
74DM6-0-54	( 74DM6 SERIES )	
74DM6~0-55	( 74DM6 SERIES )	
74DM6-0-56	( 74DM6 SERIES )	
74DM6-0-57	( 74DM6 SERIES )	
74DM6-0-58	( 74DM6 SERIES )	
74DM6-0-60	( 74DM6 SERIES )	
74DM6-0-61	( 74DM6 SERIES )	
74DM6-0-64	( 74DM6 SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER ODE CONSIGNE
SUJECT

ORIGINE NUMERO DE CONSIGNE	SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
SENSENICH	( ZADMO CERTER )	
74DM6-0-65	( 74DM6 SERIES )	
74DM6-0-66	( 74DM6 SERIES )	
74DM6-1-58	( 74DM6 SERIES )	
74DM6-3-64	( 74DM6 SERIES )	
<b>74DM6S5 SERIES</b> US 60-11-08	PILOT BORE	0.04
US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
74DM6S5-0-54	( 74DM6S5 SERIES )	
74DM6S5-0-58	( 74DMGS5 SERIES )	
74DM6\$5-0-60	( 74DMGS5 SERIES )	
74DM6S5-2-64		
US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
<b>74DM6S8 SERIES</b> US 60-11-08	PILOT BORE	R-8-1
US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
74DM6S8-0-54	( 74DM6S8 SERIES )	
74DM6S8-0-58	( 74DM6S8 SERIES )	
74DM6S8-1	( 74DM6S8 SERIES )	
74DM6S8-1-48	( 74DM6S8 SERIES )	
74DM6S8-1-49	( 74DM6S8 SERIES )	
74DM6S8-1-51	( 74DM6S8 SERIES )	
74DM6S8-1-52	( 74DM6S8 SERIES )	
74DM6S8-1-54	( 74DM6S8 SERIES )	
74DM6S8-1-56	( 74DM6S8 SERIES )	
74DM7 SERIES		
US 60-11-08 US 66-23-02	PILOT BORE WATER SOLUBLE MID-BLADE DECAL	R-8-1 R-11, R-12, R-12A
74DM7	( 74DM7 SERIES )	
74DM7-0-56	( 74DM7 SERIES )	
74DM7-4-59	( 74DM7 SERIES )	
74DM8-0-58	( ) 45M SERVES )	
US 60-11-08	PILOT BORE	R-8-1 R-11, R-12, R-12A
US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	111, 11 12, 11 128
<b>74DR SERIES</b> US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
74DR-0-56	( 74DR SERIES )	
74DR-0-58	( 74DR SERIES )	
74FK SERIES		
74FK-47	( 74FK SERIES )	
74FK-49	( 74FK SERIES )	
74FKT SERIES		
74FKT-42	( 74FKT SERIES )	

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMBER O DE CONSIGNE SUBJECT
SUJET

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF

ORIGINE NUMERO DE CONSIGI	NE SUJE!	DOLLET IN DE DENVIOL DE NET
SENSENICH 74FM SERIES		
74FM-50	( 74FM SERIES )	
74FM-52	( 74FM SERIES )	
M74CK SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M74CK-0-40	( M74CK SERIES )	
M74CK-0-44	( M74CK SERIES )	
M74CK-0-46	( M74CK SERIES )	
M74CK-0-48	( M74CK SERIES )	
M74CK-0-58	( M74CK SERIES )	
M74CK-2	( M74CK SERIES )	
M74CK-2-38	( M74CK SERIES )	
M74CK-2-42	( M74CK SERIES )	
M74CK-2-44	( M74CK SERIES )	
M74CK-2-46	( M74CK SERIES )	
M74DC SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M74DC-0-55	( M74DC SERIES )	
M74DC-0-56	( M74DC SERIES )	
M74DC-0-60	( M74DC SERIES )	
M74DC-0-62	( M74DC SERIES )	
M74DC-O-63	( M74DC SERIES )	
M74DM SERIES US 60-11-08 US 66-23-02	PILOT BORE WATER SOLUBLE MID-BLADE DECAL	R-8-1 R-11, R-12, R-12A
M74DM	( M74DM SERIES )	
M74DM-0-48	( M74DM SERIES )	
M74DM-0-50	( M74DM SERIES )	
M74DM-0-52	( M74DM SERIES )	
M74DM-0-53	( M74DM SERIES )	
M74DM-0-54	( M74DM SERIES )	
M74DM-0-56	( M74DM SERIES )	
M74DM-O-57	( M74DM SERIES )	
M74DM-O-58	( M74DM SERIES )	
M74DM-0-59	( M74DM SERIES )	
M74DM-0-60	( M74DM SERIES )	
M74DM-0-61	( M74DM SERIES )	
M74DM-O-61 M74DM-O-62	( M74DM SERIES ) ( M74DM SERIES )	

#### DA ADA

MAKE / CONSTRUCTEUR  MODEL / MODELE (SERIES / SERIE)  ORIGIN AD NUMBER SUBJECT ORIGINE NUMERO DE CONSIGNE SUJET	

		The second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of the second of th
SENSENICH M74DM-0-74	( M74DM SERIES )	
M74DM-1-56	( M74DM SERIES )	
M74DM-2-52	( M74DM SERIES )	
M74DM-6-0-52	( M74DM SERIES )	
M74DM-49	( M74DM SERIES )	
M74DM-56	( M74DM SERIES )	
M74DM-58	( M74DM SERIES )	
M74DM-60	( M74DM SERIES )	
M74DM-61	( M74DM SERIES )	
M74DMS SERIES		
US 60-11-08 US 66-23-02	PILOT BORE WATER SOLUBLE MID-BLADE DECAL	R-8-1 R-11, R-12, R-12A
M74DMS-0-58	( M74DMS SERIES )	
M74DMS~0~60	( M74DMS SERIES )	
M74DMS-2-64	( M74DMS SERIES )	
M74DMS-60	( M74DMS SERIES )	
M74DMS6 SERIES		
US 60-11-08 US 66-23-02	PILOT BORE WATER SOLUBLE MID-BLADE DECAL	R-8-1 R-11, R-12, R-12A
M74DMS6-0-50	( M74DMS6 SERIES )	
M74DMS6-0-52	( M74DMS6 SERIES )	
M74DMS6-0-58	( M74DMS6 SERIES )	
M74DMS6-0-60	( M74DMS6 SERIES )	
M74DMS8-1-56		
US 60-11-08 US 66-23-02	PILOT BORE WATER SOLUBLE MID-BLADE DECAL	R-8-1 R-11, R-12, R-12A
M74DM6~0-58		
US 60-11-08	PILOT BORE	R-8-1
US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M74DR SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M74DR	( M74DR SERIES )	
M74DR-0-55	( M74DR SERIES )	
M74DR-0-61	( M74DR SERIES )	
M74DR-53	( M74DR SERIES )	
M74DR-56	( M74DR SERIES )	
W74FKT-42		
<b>76AK-2 SERIES</b> US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
76AK-2-40	( 76AK-2 SERIES )	
76AK-2-42	( 76AK-2 SERIES )	
76AK-2-44	( 76AK-2 SERIES )	

REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.

( SERIES / SERIE) SUBJECT SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
( 76AK-2 SERIES )	
( 76AK-2 SERIES )	
BLADE TIP FAILURES WATER SOLUBLE MID-BLADE DECAL	R-2 R-11, R-12, R-12A
( 76AM6 SERIES )	
WATER SOLUBLE MID-BLADE DECAL PROPELLER RPM LIMITATIONS	R-11, R-12, R-12A R-14A
( 76EM8 SERIES )	
•	
•	
•	
•	
( 76EM8 SERIES )	
( 76EM8 SERIES )	
( 76EM8 SERIES )	
( 76EM8 SERIES )	
	( 76AK-2 SERIES ) ( 76AK-2 SERIES )  BLADE TIP FAILURES WATER SOLUBLE MID-BLADE DECAL ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES ) ( 76AMG SERIES )

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGINE NUMERO DE CONSIGNE

(SERIES / SERIE) SUBJECT SUJET

CATOME NOMERO DE CONSTANT	E SUJE!	BULLETIN DE SERVICE DE REF.
SENSENICH M76AK-2 SERIES US 66-23-02	WATER SOLUBLE MID DLADE DEGLE	
M76AK-2	( M76AK-2 SERIES )	R-11, R-12, R-12A
M76AK-2-40	( M76AK-2 SERIES )	
M76AK-2-41	( M76AK-2 SERIES )	
M76AK-2-42	( M76AK-2 SERIES )	
M76AK-2-43	( M76AK-2 SERIES )	
M76AK-2-44	( M76AK-2 SERIES )	
M76AK-2-45	( M76AK-2 SERIES )	· · · · · · · · · · · · · · · · · · ·
M76AK-2-46	( M76AK-2 SERIES )	
M76AK-2-48	( M76AK-2 SERIES )	
M76AM-2 SERIES	·	
US 54-05-02 US 66-23-02	BLADE TIP FAILURES WATER SOLUBLE MID-BLADE DECAL	R-2 R-11, R-12, R-12A
M76AM-2	( M76AM-2 SERIES )	,,
M76AM-2-42	( M76AM-2 SERIES )	
M76AM-2-43	( M76AM-2 SERIES )	
M76AM-2-44	( M76AM-2 SERIES )	
M76AM-2-46	( M76AM-2 SERIES )	
M76AM-2-48	( M76AM-2 SERIES )	
M76AM-2-50	( M76AM-2 SERIES )	
M76AM-2-52	( M76AM-2 SERIES )	
M76AM-2-54	( M76AM-2 SERIES )	
M76AM-2-56	( M76AM-2 SERIES )	
M76AM-2-58	( M76AM-2 SERIES )	
M76AM4 US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M76AM6-2 SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
M76AM6-2-46	( M76AM6-2 SERIES )	
M76AM6-2-52	( M76AM6-2 SERIES )	
M76EMM-0-60	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
US 66-23-02 US 69-09-03R3	PROPELLER RPM LIMITATIONS	R-14A
M76EMMS SERIES US 66-23-02	WATER SOLUBLE MID-BLADE DECAL	R-11, R-12, R-12A
US 69-09-03R3	PROPELLER RPM LIMITATIONS	R-14A
M76EMMS	( M76EMMS SERIES )	
M76EMMS-0-56	( M76EMMS SERIES )	
M76EMMS-0-60	( M76EMMS SERIES )	
M76EMM8S5 US 66-23-02 US 69-09-03R3	WATER SOLUBLE MID-BLADE DECAL PROPELLER RPM LIMITATIONS	R-11, R-12, R-12A R-14A
		DDODELL EDS /HELTCES

MAKE / CONSTRUCTEUR MODEL / MODELE

(SERIES / SERIE)

ORIGIN AD NUMBER ORIGINE NUMERO DE CONSIG	SUBJECT NE SUJET	REFERENCE SERVICE BULLETIN BULLETIN DE SERVICE DE REF.
SENSENICH		
W76CK-44		
W79CFL-60		
W85RB-46		
W85RW-57		
86C-67		
86R-61		
W86BAS		
W86CA-69		
W86R-58		
W86R-61		
90HA-86		
W90T6JB-72		
W92HA-76		
W96JA-56		
W96JA-58		
W96JA-60		
W98AA-64		
W98AA-66		
UNIVAIR		
F1C7660-2		
F12 SERIES US 64-07-03	BOLTS - SPINNER BULKHEAD TO PRO	OPELLER FLANGE
F12	( F12 SERIES )	
F12A	( F12 SERIES )	
F12A-5	( F12 SERIES )	
F200	00000115011101/001101010100010000000000	VODDED 45 CD 40
US 47-50-13 US 50-34-01	PROPELLER HUB / BALANCING BANDS BLADE RETAINING FLANGES	KOPPER'S 22, 23E, 24
US 73-20-08	PROPELLER BLADE TIPPING	29
F200-H US 47-50-13	PROPELLER HUB / BALANCING BANDS	
US 50-34-01 US 73-20-08	BLADE RETAINING FLANGES PROPELLER BLADE TIPPING	KOPPER'S 22, 23E, 24 29
F200-00-74B		
R003-231-72		
R003-232-T		
R003-232-72T		
220-1		
US 73-20-08	PROPELLER BLADE TIPPING	29
65A-64		
65A-66		

MAKE / CONSTRUCTEUR
MODEL / MODELE
ORIGIN AD NUMBER
ORIGIN NUMBER SUBJECT
ORIGINE NUMERO DE CONSIGNE
SUJET

ORIGINE NUMERO DE CONSIGNE	SUJET	BULLETIN DE SERVICE DE REF.
UNIVAIR 6628C-27		
69A50E		· · · · · · · · · · · · · · · · · · ·
69L-42		
69L-44		
69L-46		
72A-44		
72A-46		
72A-48		
72A-50		
72K-48		
72KA-48		
72L-46		
73B-58		
74A-48		
86R-60		

MAKE / CONS	STRUCTEUR AD NUMBER	SUBJECT
ORIGINE	AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET

MAKE / CONS	TRUCTEUR
COLCIA	

ORIGIN AD NUMBER SUBJE
ORIGINE NUMERO DE CONSIGNE SUJE

SUBJECT

ORIGINE	NUMERO DE CONSIGNE	SUJET
A.P.I.	_	
FR	96-293(B)R1	APS 3200 AUXILIARY POWER UNIT (APU) - SOFTWARE MALFUNCTION - AIRBUS A319, A320, A321
ABG SEI	MCA	
FR	91-254(AB)	AIR CONDITIONONG UNITS COLD AIR PACKS PN'S 3502 A03 & 3502 D01 (AEROSPATIALE AS 332)
AC GENE	ERAL MOTORS	
US	54-04-01	AC LA-87 SPARK PLUGS - APPROVED OPERATIONS
US	54-21-01	AC DIAGHRAGM TYPE FUEL PUMPS - SEDIMENT BOWL CAP SCREW & SURGE CHAMBER
ACS/GE	RDES PRODUCTS	
US	93-05-06	ACS & GERDES IGNITION SWITCHES - INSP/LIBRICATE - ACS SB92-01 - CESSNA, PIPER, SCHWEZER A/C
ADS SUF	PPLY COMPANY	
us	77-05-05	AD SUPPLY CO, AIR SPARES INTL, SPENCER AIRCRAFT UNAPPROVED APPLIANCES ON BOEING AIRCRAFT
AERAZUR	₹	
FR	90-128(AB)	LIFE RAFTS - INSTALLED ON AEROSPATIALE A/C -REMOVAL OF SUCTION PIPETT E - SB 332.60.002
FR	91-166(AB)	LIFERAFTS INSTALLED ON AEROSPATIALE A/C - CONTAINER COVER RIVETS & VENT HOLE GAS GEN VALVE
FR	92-051(AB)R1	C10, C10 PN & 1014 - LIFE JACKETS PACKING POUCH CLOSURES
FR	92-246(AB)	LIFERAFTS TYPE 346 - DETERIORATION OF TOPPINGUP & DEFLATION CAP FLANGES - SB 346.60.001
FR	96-112(AB)	LIFE RAFT TYPE 606 - INFLATION/DEFLATION VALVES - VARIOUS AC AND FALCON 900 SERIES
AERAZUR	EFA	
FR	88-059(AB)	PARACHUTE (TYPES 350A,B,AP,351, 352,353) OPENING SYSTEM, RIPCORD SHEATH ATTACHMENT FITTING
AE ROQU I	P	
FR	88-132(AB)R1	601 HOSE ASSEMBLIES OIL & FUEL SYSTEM HOSE ASSEMBLIES 003R1
AEROSON	IC CORP	
US	80-17-04	FUEL FLOW TRANSDUCERS P/N 33184-1 & 32622-6
AEROSPA	CE LIGHTING	
US	95-22-01	CABIN FLUORESCENT LIGHTING SYSTEMS - LAMP & LAMP CONNECTORS - INFO BULLETIN: IB 90-001
AIR ASS	OCIATES	
US	50-18-03	M-264 SAFETY BELTS INCOPRORATING WARREN MCARTHUR END FITTINGS, P/N 275-AS26
AIR CRU	ISERS	
US	65-24-01	EMERGENCY EVACUATION SLIDES, P/N 15D22129, INSTALLED ON BOEING 727 SERIES AIRPLANES
US	66-18-01	EMERGENCY EVACUATION SLIDES, P/N 15D22129, -1 INSTALLED ON BOEING 727 SERIES AIRPLANES

	NSTRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET
AIR CR	RUISERS	
	NUED / SUITE) 71-02-01	LIFE RAFT MODELS 12D11751-7, -8 & 18D23350-5 CYLINDER & VALVE ASSEMBLY - SB 111-70-1
US	73-01-03	AD-8 LIFE JACKET - INFLATOR MANIFOLD STEM ASSEMBLY - SB 112-72-1
US	75-26-06	LIFE RAFT SYSTEMS - SEPARATION AT THE HOSE CONNECTING FITTING BODY - SB 111-74-1R1
US	76-07-02	EMERGENCY EVACUATION SYSTEMS, P/N 19D22368-2 THRU -9 & P/N 22D30022-1 THRU -4,
US	82-05-06	LIFE RAFTS P/N D23835-403 GAS RELEASE MECHANISM - SB 111-81-1
ÜS	90-21-02	TSO-C69A EMERGENCY EVACUATION SLIDE/RAFT SYSTEM, P/N D30659 - BOEING 757 AIRPLANES
US	91-24-07	EMERGENCY EVACUATION SLIDE(P/N D31005 & D30543) INFLATION CABLE - BAE 146 AIRCRAFT
US	92-10-06	EMERGENCY EVACUATION SLIDE SYSTEM - P/N D31021-101, -103 - SB O01-25-8R4 - AIRBUS A300 A/C
AIR LI	QUIDE	
FR	97-088(AB)R1	SMOKE HOOD TYPE 15-40 F - REMOVAL OF SMOKE HOODS FROM SERVICE DUE TO VISOR DEFECTS
	NE MFG	
US	64-01-01	VACUUM PUMPS MODELS 113A1, 113A2, 113A5 & 113A8 SPLINED DRIVE COUPLINGS
US	70-22-02	MODELS 1H7, 1H10, 1H16 & 1H26 SERIES FUEL SELECTOR VALVES - CONTROL ARM ROLL PIN
US	76-16-02	113A, 221CC, 222CW, 200 & 220 SERIES ENGINE DRIVEN VACUUM PUMPS
US	79-13-08	DRY AIR PUMPS INSTALLED AFTER MAY 15, 1979
AIRCRA	FT BATTERIES	
CF	CF-96-21	THIS AD CANCELS FAA AD 72-19-04 - RE NICAD BATTERY THERMAL RUNAWAYS
AIRCRA	FT BELT & TRIM	
US	54-20-01	MODEL LBM-1900 SAFETY BELTS MANUFACTURED PRIOR TO APRIL 1, 1954 NONCOMPLIANCE WITH TSO C22
AIRCRA	FT BELTS INC	
US	98-25-10R1	PER SB A2626-E010, MULTI SEAT RESTRAINT SYSTEMS FAILURES DUE TO BUCKLE ASSY LOCKING
AIRCRA	FT METAL PROD.	
US	79-26-05	INSPECTION OF OIL & FUEL HOSES P/N 762506
AIRCRA	FT RADIO CORP.	
US	74-08-01	AUTOPILOT SERVO ACTUATORS PA-500A, PA-520A & PA-520B - AUTOPILOT ACTUATOR JAMMING
AIRCRA	FT SPRAYING	
us	48-34-02	ALL AIRCRAFT ENGAGED IN SULPHUR DUSTING MOST HAVE MODIFIED EXHAUST SYSTEMS & HOPPERS
US	57-25-01	A/C IN SPRAYING OPS MUST HAVE DIAPHRAGM TYPE SPRAY PRESSURE REGULATORS VENTED EXTERNALLY

ORIGIN	ISTRUCTEUR AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET		
AIRCRA	AIRCRAFT TANK SERV.			
US	82-18-09	FUEL SYSTEM - REMOVAL OF TYGOTHANE TUBING SYSTEMS COMPONENTS		
AIRESE	ARCH			
us	70-03-07	GTP30-141 PLACARD APU OPERATION PROHIBITED IN FLIGHT, EXCEPT IN EMERGENCY		
US	74~10-11	TSCP 700-4B APU (DOUGLAS DC10) FUEL CONTROL FATIGUE CRACKS PRESSURE REGULATOR BODY		
US	74-11-03	GTCP36-4A, -6, -16 & -28 FUEL CONTROL UNITS UNACCEPTABLE CASE CASTING WALL THICKNESS		
US	74-24-09	GTCP30-54, -59, -70 & -92 APU - TURBINE WHEEL & SEAL CLEARANCES & FATIGUE CRACKS		
us	75-01-06	GTCP660-4, -4R APU (BOEING 747) FUEL PUMP BODY FATIGUE CRACKS		
US	75-05-17	GTCP660-4, -4R APU (BOEING 747) IMPROVED COMPRESSOR ASSEMBLIES		
US	77-17-06	TSCP700-4B, -5 APU (DOUGLAS DC10) FIRST STAGE COMPRESOR DISCS P/N 969600-1, -2		
US	78-10-04	TSCP700-4B, -5 APU (DOUGLAS DC10) FIRST STAGE COMPRESSOR DISKS P/N 969600-1, -2		
US	79-18-12	GTCP85 SERIES APU EXHAUST PIPE ASSEMBLY P/N 379529, 976987-1 & 899607-1		
AIRGLAS	SKIS			
CF	CF-80-18	MODEL LW3600-180, 180A WHEEL SKIS - TO PREVENT PITCHDOWN IN FLIGHT MODIFY IAW SB LW3600-3		
AIROTE	СН			
US	85-09-01	PARACHUTE HARNESS - CABLE HOUSING/RIP CORD PIN - DRAWING # FC-2B		
AIRTELL				
US	97-01-12	CENTAURUS MODEL C3-100 GROUND PROXIMITY WARNING SYSTEM(GPWS)-REPLACE IAW TSO C-92B 8/19/75		
ALL OME	GA/VLF SYS.			
FR	1999-472(AB)	MANUFACTURERS HAVE DECLARED CERTAIN OMEGA/VLF SYS OBSOLETE AND Y2K READINESS NOT PERFORMED		
ALLIED	SIGNAL			
US	94-01-05	TRAFFIC ALERT & COLLISION AVOIDANCE SYSTEM(TCAS) II PROCESSORS - VERSION 6.04A LOGIC		
US	95-07-03	GTCP85 SERIES APU/INSTALL EXHAUST CENTERBODY - 707, 727, L-382, DC-8-70 & DC-9/MD-80 A/C		
us	95-26-15R1	AUDIO OUTPUT OF CAS-81 TRAFFIC ALERT & COLLISION AVOIDANCE SYSTEM (TCAS) - AFM AMENDMENT		
US	97-05-03R1	GLOBAL POSITIONING SYSTEMS - MODELS GNS-XLS & GNS-XL - FLIGHT MANUAL LIMITATION		
US	98-08-20	BENDIX/KING MODEL KSA 470 AUTO SERVO ACTUATORS - P/N'S 065-0076-10/065-0076-015;S/N 1-3081		
US	98-14-03	KT 76A ATC TRANSPONDERS - P/N 066-1062-00/10/02 REPLACE RESISTORS MODULES RM401 & RM402 1		
US	99-12-06	VHF - NAVIGATION RECEIVERS VN 411B - REMOVE & REINSTALL NAV RECEIVERS TO MOD 21 STATUS		
US	99-23-24	ILS RECEIVER - GLIDESLOPE DATA		

MAKE / CONSTRU ORIGIN AD ORIGINE NU	NUMBER	SUBJECT SUJET			
AM-SAFE	AM-SAFE				
US 8'	7-17-06	RESTRAINT SYSTEM - SEAT BELT AS PER TSO C22F			
AMI INDUS	STRIES				
US 8	3-21-06R1	CREW SEAT 716 & 865 SERIES - SEAT FRAME ASSEMBLY BRACE KIT P/N 865K90000-1, -3			
US 9	3-07-05	PILOT & CO-PILOT SEATS - MODEL 1108 - LAP BELT ATTACHMENT LINKS - SB 25-1108-03 - DHC-8			
ANDREA RA	ADIO				
US 6	2-13-01	AN/AIC-10A, -18 INTERCOM SETS - ATTENUATION RANGE			
AP PRECIS	SION HYDS				
uk o	19-04-91	HYDRAULIC POWER SELECTOR VALVE STICKING PLUNGER - HS 748 - SB # AIR44880-29-01R2			
ARTEX AIR	RCRAFT				
US 8	1-21-05	ELT - ARTEX BATTERY PACK AS PER TSO-C91			
AUTO CRAI	r				
US 6	1-20-01	SAFETY BELTS AS PER TSO C22			
US 6	2-23-01	SAFETY BELTS AS PER TSO C22			
AUXILIARY	Y POWER INTL				
US 9	7-03-06	MODEL APS3200 APU - ELECTRONIC CONTROL BOX - REPLACEMENT OF SOFTWARE - AIRBUS AIRCRAFT			
AVIATECH					
CF C	F-91-04	PREMATURE WEAR & FRAYING OF PILOT & CO-PILOT SHOULDER HARNESS - TSO C39A			
AVIOINTER	RIORS				
IT 9	7-346	ALVEN SEATS - INSPECTION/MODIFICATION OF SEAT BELT ATTACHMENTS AS PER SB 000128 - 26/11/97			
IT 9	9-421	FORMERLY ALVEN: INSPECT/REPLACE OF SEAT REF. POLTRONE AVIOINTERIORS ALERT SB 312/912-01R1			
B/E AEROS	SPACE				
ND 9	3-168(AB)	INVENTUM GALLEY MODEL DR1 & DR6 WATER HEATERS - NO PRV VALVE - SB DR1/DR6-25-4,-5			
ВЕЕСН					
US 5	5-08-01	SAFETY BELT BUCKLES P/N 113652 - PIN & SNAP RING RETAINERS			
US 6	66-02-01	BAK-109 AIR CONDITIONERS - COMPRESSOR MOTOR FANS			
BENDIX					
US 6	60-04-01	MI-51B AMSPEAKER - SPEAKER CONE CARBON RESISTORS			
US 6	3-09-01	TYPE 9054 FUEL FLOW TRANSMITTERS - MOTOR MOUNTING FRAME CRACKS			
us 6	55-21-01	BENDIX 765 & GARWIN G-760 STARTERS - POSITIVE JAW DISENGAGEMENT			
US 7	72-04-02	P/N 2601901, 2603561 INBOARD WHEEL HALVES & ASSEMBLIES (TSO C26B) - NDT INSPECTION			
US 7	73-10-02	RSA-5AD1, -5AB1, -1OAD1 FUEL INJECTORS - DIAPHRAGM ASSEMBLIES P/N 2529470			

	STRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET	
BENDIX			
	NUED / SUITE) 74-26-09	MODEL S-20, S-200 & S-1200 SERIES MAGNETOS - SOLID STEEL DRIVE SHAFT BUSHING	
US	76-07-12	P/N 10-357,-126 & -157 SERIES IGNITION SWITCHES - REPAIR & REPLACEMENTSB 583	
US	78-18-04	MODEL D-2000, D-2200 SERIES MAGNETOS CARRY OUT SB 590A, 600, 587 & 584B	
US	79-12-07	MODEL D-2000, D-2200 SERIES 6 & 8 CYLINDER MAGNETOS - DISTRIBUTOR BLOCK BUSHINGS	
us	79-18-06	MODEL D-2000, D-2200 SERIES 4, 6 & 8 CYLINDER MAGNETOS - SB 605	
US	79-21-08	MODEL RSA-5, -7 & -10 SERIES FUEL INJECTION SYSTEMS - FUEL FLOW CUTOFF / LOCKNUT	
US	79-26-03	MODEL RSA-5AD1 FUEL INJECTORS P/N 2524145-8, -9 REGULATOR STEM & LOCK NUT SB RS-68	
US	80-17-14	MODEL D-2000, D-2200 SERIES 4, 6 & 8 CYLINDER MAGNETOS - SB 605A	
US	81-01-06	M-4 AUTOPILOT / YD-4YAW DAMPER PRIMARY SERVO MODEL 3013 SERIES MODIFICATION SB M-4D-060	
US	81-12-06R1	MODEL D-3000, D-3200 SERIES MAGNETOS - DISTRIBUTOR GEAR ROTATING ELECTRODES - SB 618, 619	
US	81-17-01	STARTING VIBRATOR ASSEMBLIES - IGNITION LOSS DUE TO PRIMARY LEAD GROUNDING SB 614	
US	82-11-05	MODEL D-2000, D-2200 SERIES MAGNETOS - DISTRIBUTOR GEAR ELECTRODE -SB 617	
US	82-13-01	MODEL S-1200 SERIES MAGNETOS - DISTRIBUTOR BLOCK BUSHINGS - SB 613	
US	82-20-01	MODEL S4LN, S4RN, S6LN, S6RN, D4LN, D4RN, D6LN & D6RN SERIES  MAGNETOS - IMPULSE COUPLING	
US	88-25-01	BENDIX / KING - KDM7000B DISTANT MEASURING EQUIPMENT (DME)	
BENDIX	KING		
CF	CF-91-14R1	RNAV COMPUTER KNC 667 CLEARANCE PROCEDURE - KNS 660 DISABLING PROCEDURE	
US	92-18-08	KAP 150/KFC 150 FLIGHT CONTROL SYSTEMS INSTALLED ON PIPER PA46-310P & PA46-350P - SB 312	
BFGOODE	ICH		
US	99-25-07	BRAKE ASSY P/N 2-1598 OR 2-1600 INSTALLED ON AIRBUS MODEL A319 AND A320 SERIES AIRCRAFT.	
BRACKET	T		
us	81-15-03	ENGINE INLET AIR FILTERS IAW STC SA693CE & SA71GL - FAILURE / INGESTION CARBURETOR THROAT	
US	96-09-06	AIR FILTER ASSEMBLIES BA-2010,-4106,-4106-1,-4210,-5110,-5110A,-6110,-8910,AAF-117,AAF-118	
BRIDGES	BRIDGESTONE		
JN	4135-95	BRIDGESTONE (H)49 SIZE RETREADED TIRES - INSPECTION/REPLACEMENT - BOEING 747 A/C -5110A,-6110,-8910,AAF-117,AAF-118	
BRIGGS	& STRATTON		
US	50-04-01	TYPE A-8 IGNITION SWITCHES - INTERNAL SWITCH LEVER STOPS	
US	53-26-01	TYPE B-5 IGNITION SWITCHES - FOD ENTRY CAUSING GROUNDING	

	NSTRUCTEUR  AD NUMBER E NUMERO DE CONSIGNE	SUBJECT SUJET
BRONZ	AVIA	
FR	88-024(B)	AIR EQUIPMENT RESCUE HOIST (AEROSPATIALE A/C) P/N'S 76375, 76370 - TRAVEL RETURN SPRING
FR	88-043(B)	AIR EQUIPMENT WINCHES (TYPES 76370,-010,-011,-020,-030) RUBBER STOP SB 25.62.0G
FR	88-087(B)	AIR EQUIPMENT RESCUE HOISTS (P/N'S 76370-010,-011,-020,-030) ATTACHMENT BRACKETS
FR	88-114(B)	AIR EQUIPMENT - RESCUE WINCHES (TYPE 76365) - CONTROL BOX - ADJUSTMENT DEVICES
BROWN	LINE	
US	59-24-03	MODEL WB-2002-2 SAFETY BELTS / BELT BUCKLES - NON-CONFORMITY TO TSO-C22
BRUCE	INDUSTRIES	
US	88-11-08	AIRCRAFT LIGHTING BALLASTS P/N 05241-1 - ASB A05241-33-20-01
CESSNA	A AIRCRAFT CO.	
US	96-12-22	OIL FILTER ADAPTERS ASSEMBLIES, SEE ATTACHED SKETCH
CHADW	I CK	
US	80-08-04	AUXILIARY FUEL SYSTEMS - C-20 INSTALLED ON HUGHES 369 / C-22 INSTALLED ON BELL 206
CHAMP	ION	
US	77-12-05	CH48108 & CH48109 OIL FILTERS - INTERNAL BYPASS VALVE FAILURE - SALES BULLETIN 77-13
CHROMA	ALLOY	
US	74-24-07	RLB-6 SERIES RESCUE LOCATOR BEACONS INCORPORATING BATTERY PACKS.COMPLIANCE WITH TSO C19
CLEVE	LAND AIRCRAFT	
US	71-06-08	6.00-6 WHEEL / BRAKE ASSEMBLY P/N 3080C/37-200A - BRAKE DISC ASSEMBLY - SB ESB7000-2 REV A
COLLIN	NS AVIONICS	
US	50-48-02	MODEL 51R-1, -2 RECEIVERS - REPLACEMENT OF ALLITE OR THORDARSON 90/15 D CYCLE FILTERS
US	52-13-01	MODEL 51R-1,-2 RECEIVERS - REMOVAL OF B + VOLTAGE FROM 90/150 CYCLE FILTER INPUT CIRCUIT
US	75-12-10	AP106 AUTOPILOT - MODIFICATION OF 161H1 PROGRAMMER IAW SB 6
US	76-07-09	MODEL 332C-10 RADIO MAGNETIC INDICATOR - TO PRECLUDE VOR ERROR CARRY OUT MOD IAW SB 6
US	85-22-10	FLIGHT DIRECTOR & HORIZONTAL SITUATION INDICATOR
US	86-22-10	DME-42, P/N 622-6263-002, DISTANCE MEASURING EQUIPMENT TRANSCEIVERS
US	86-25-01	VOR-ILS NAVIGATION RECEIVERS 51RV-4 - TSO C34C, C36C, C40A
US	92-11-09	TPR-720 ATC RADAR BEACON SYSTEM / MODE S TRANSPONDERS - 737, 747, 767, DC-10, F28 AIRCRAFT
US	93-04-02	TDR-94D MODE S TRANSPONDER - P/N 622-9210-002 - PLACARD TCAS II - SB TDR94/94D-34-6R2

ORIGIN	ISTRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET
COLLIN	S/ROCKWELL	
US	94-01-06	TRAFFIC ALERT & COLLISION VOIDANCE SYSTEM (TCAS) II PROCESSORS - SB
US	94-02-02	ENSURE CORRECT OPERATION OF DME IAW SB 20, SB 25, AND SB 26
DAVIS	AIRCRAFT	
US	57-14-02	MODEL FDC-1650 SAFETY BELTS - REWORK OF RELEASE FITTING
US	64-10-03	FDC-2700 SERIES SAFETY BELTS MANUFACTURED PRIOR TO 1 SEPT 1963 - IMPROPER LATCHING
us	89-09-02	SAFETY BELTS - "ULTEM" LATCH COVER - P/N FDC-6400B SERIES - TSO C22F METALLIC TAG
DETROI	T ALLISON	
US	82-12-04	COMBINED POWER TURBINE & PROPELLER GOVERNOR ASSY P/N 6875708 GROUND FUNCTIONAL CHECK
DEUTSC	Н	
US	78-25-03	P/N 94B010000F0160 & P/N 94F010000F0166 HOSE ASSEMBLIES
DOWTY	AEROSPACE WOLV	
UK	002-09-99	LUBE ROLLS ROYCE DART ACCESORY GEARBOX DRIVE SHAFT PER DOWTY WOLVERHAMTON SB 83-518 09/99
DOWTY	ROTOL	
UK	006-02-88	NOSE LANDING GEAR - ABUTMENT PLATE SCREWS (SD3-60 A/C) - SB 32-57SD
UK	007-02-89	LANDING GEAR - NOSE UNDERCARRIAGE LIFE LIMITS(HS 748 A/C) - SB 32-77E R6
UK	020-06-90	MLG LOCK JACK ON BAE 146WITH LOCK JACK NOS. 104275001
DUNLOP		
UK	013-07-95	LANDING GEAR BRAKE UNIT (BAE146) DUNLOP SB 32-1105
EDISON		
us	52-23-01	P/N 35534 FIRE DETECTORS IN JUNCTION BOXES - ADEQUATE CLEARENCE TO AVOID GROUNDING
US	66-07-03	EDISON & GARWIN ENGINE GAUGE UNIT DATE STAMP BEFORE 1 APRIL 1961 - FUEL PRESSURE DIAPHRAGM
EDO		
US	47-50-05	MODEL 92-1400 EDO FLOATS - WIREPULL ATTACHMENT FRONT & REAR STRUTS
US	62-06-02	345 & 345A AIRBORNE LORAN A RECEIVERS - MODIFY AS PER EDO BULLETIN 27
US	62-17-04	249A287O (A MODEL ONLY) FLOATS - LONGITUTIONAL CRACKS ON STREAMLINED STRUTS
EI DUPO	ONT DE NEMOURS	
US	91-15-15	TSO-C116 CREWMEMBER PROTECTIVE BREATHING EQUIPMENT - REMOVE VELCRO INSERT SPACERS - SB 002
EISEMAI	NN .	
US	69-09-01	AM-4, -6 & LA-4, -6 MAGNETOS - ELECTRICALLY SHORTED COIL WINDINGS
ELITE (	CARPETS	
CF	CF-83-22	REAPPLICATION OF FIRE PROTECTION AGENT AFTER WASHING CARPET

ORIGIN	NSTRUCTEUR  AD NUMBER  E NUMERO DE CONSIGNE	SUBJECT SUJET		
EON C	EON CORPORATION			
US	80-05-04	MODEL E2900 & E8000 SAFETY BELTS & HARNESSES - REPLACEMENT OF LATCH & BUCKLE		
US	87-04-19	E6000 BUCKLE ASSEMBLIES INCORPORATED ON SAFETY BELT ASSEMBLIES - TSO C22		
EROS				
FR	91-175(AB)R1	FULL FACE MASK MF-10 SERIES - PLASTIC SHELL PIN WHICH SECURES FACE PIECE WINDOWS		
FR	91-176(AB)	DXYGEN MASK MA 10, MB 10 & MC 10 SERIES - LOCK WHICH SECURES MASK TO REGULATOR		
FR	92-085(AB)R2	SERIES MF10 FULL FACE MASKS RADIO HOSE CORD CLAMP - EROS SB MF10-35-47 R1		
US	94-06-04	SERIES MF10-( )-() FULL FACE MASK REGULATORS - FACE PIECE & MASK SECURING SCREW		
ESB W	I SCO			
US	79-07-02	EXIDE AC 78M & WILLARD W 78M BATTERIES MANUFACTURED DURING DEC 1978, JAN 1979 & FEB 1979		
ESSEX				
US	93-14-12	PELS MODEL 4566M37B PROTECTIVE BREATHING EQUIPMENT - NECK SEAL LEAKAGE - SB 001R1		
EUREKA	A WILLIAMS			
US	65-06-04	SURVIVOR LOCATOR LIGHT MODEL EW-101-WL-()-8 - ACID EMITTING BATTERIES		
FACET				
CF	CF-88-04	REMOVAL OF STC LABELS TO PREVENT ENGINE INGESTION - AEROSPATIALE AS 355, MBB B0105, BK117		
FACET	AEROSPACE			
US	88-02-04	MA-3PA CARBURETOR - SB A1-87 LOOSE METERING SLEEVE		
us	89-04-02	MA-4-5, MA-5, & MA-6AA CARBURETORS - SB A1-88 REPLACEMENT OF AIR METERING STOP PIN		
FAIRCH	HILD CAMERA			
US	65-05-03	MODEL 5424() SERIES FLIGHT DATA RECORDERS - MOD / SB 159 TO IMPROVE CRASH SURVIVABILITY		
FAIRCH	HILD INDUSTRIES			
US	81-04-06	COCKPIT VOICE RECORDER MODEL A100 SERIES - THERMAL INSULATION AS PER SB CVR A140		
FAIREY	FAIREY REED			
CF	CF-62-07	METAL PROPELLERS - TRANSVERSE FATIGUE FAILURES OF THE BLADE SHEET		
FEDERAL SKIS				
CF	CF-53-13	MODIFICATION OF SKI & WHEEL-SKI INSTALLATIONS TO COMPLY WITH ANGULAR TRAVEL REQUIREMENTS		
US	54-02-02	AWB-2100, AWB-2500 & AWB-2500A WHEEL SKIS - REVISED RIGGING AS PER FEDERAL DRAWING 11D1077		
US	55-04-01	MODEL AWB-2500A WHEEL SKIS - TO PRECLUDE MAIN SKIS PITCHING FORWARD RE-RIG AS PER SB 102		

MAKE / CON ORIGIN ORIGINE	ISTRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET
FEEL		
UK	005-04-92	SB A25-20-1232 SEAT 111/115 AISLE SECTIONS FOR CRACKING
UK	006-03-93	SB A25-20-1287 SEAT 121 AISLE SECTIONS INSPECTION OR REPLACEMENT
UK	017-03-93	SB A25-20-1294 SEAT 121 AISLE SECTIONS REPLACEMENT
FIRE F	IGHTING ENTRP.	
UK	018-10-90	HALON 1211 & WATER GLYCOL PORTABLE FIRE EXT( SB A26-106)
FIREST	ONE	
US	78-20-12	REPLACEMENT OF FIRESTONE TIRES SIZE 18X5.5 MACH I, 10 PLY RATING P/N 00490
FIRST	TECHNOLOGY	
UK	004-09-92	HALDN 1211 & WATER GLYCOL CABIN PORTABLE FIRE EXTINGUISHER - TRIGGER REPLACEMENT SB26-108
UK	007-11-97	FIRE EXTINGUISHERS - HALON 1211 & 1301 BETWEEN SERIAL #'S 7967-10356 - SB 26-110
FLI-LI	TE	
CF	CF-59-05	SKI MODEL 3000 (CESSNA 180) - REPLACE YOKE ARM WITH REINFORCED YOKE ARM - SB 1
FLIGHT	EQUIPMENT	
US	82-18-10	639 & 675 SERIES SEATS - REPLACE TRACK LOCK FITTING P/N 31620 WITH P/N 33667
FROST E	NGINEERING	
US	81-06-02	EMERGENCY DESCENT DEVICES - INSPECT FOR BROKEN HANDLE STRAPS AS PER SB 379103-25-002
G Q SEC	CURITY	
US	91-02-05	79A1684-( ) PARACHUTE CANOPIES APPROVED UNDER TSO C23B - DETERIORATING CANOPY MATERIAL
GARRETI	-	
CF	CF-83-34R2	MODEL GTCP 36-50, -55 & -100 SERIES APU - FUEL SOLENDID VALVE & ELECTRONIC CONTROL UNIT
US	73-07-02	REPLACEMENT OF MODEL RESCU/88 EMERGENCY LOCATOR TRANSMITTER P/N 627484
US	85-14-02R2	GTCP331 SERIES APU - COOLING FAN ASSEMBLY - SB GTCP331-49-5546
US	87-24-11	GTCP 85 SERIES APU - TURBINE SHROUD CONTAINMENT RING - SB 85-49-5689
US	91-25-04	MODEL TSCP700-4B APU (PRE S/N 90697) HIGH PRESSURE TURBINE DISC - DOUGLAS DC-10
US	92-21-05	GTCP 36-280 & GTCP 36-300 APU'S - TIESHAFT SEPARATION - AIRBUS A320 & BOEING 737 AIRCRAFT
US	96-18-17	APU HPT TURBINE DISK REPLACEMENT
us	97-04-04	APU - MODEL GTCP-85 - CONTAINMENT SHROUD/RINGFOR ONE-PIECE CAST TURBINE WHEELS
us	97-19-18	TSCP700-4B,-5 APU'S. 1ST STAGE LPC DISKS P/N 3606429-1 REPLACE IAW SB TSCP700-49-7266

	ISTRUCTEUR  AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET		
	GARRETT/AIRESEARCH			
US	92-16-06	ALL ENGINE STARTERS DISTRIBUTED BY CLASSIC AVIATION INC- A/C 707,727,737 & DC-8,DC-9,DC-10		
GENERA	L			
CF	48-5	INSTALLATION OF FLARE PISTOL EXTERNAL DISCHARGE CHUTE		
CF	CF-58-02	RELOCATION OF RADIO EQUIPMENT INSTALLED UNDER AN ENGINE FUEL PRIMER DUE TO FIRE HAZARD		
CF	CF-58-03	INDEPENDENT ENERGY SOURCE FOR EMERGENCY EXIT LIGHTING ON FAR 25 AIRCRAFT		
CF	CF-59-01	MOUNTING OF HAND HELD FIRE EXTINGUISHERS AWAY FROM HOT AIR HEATERS OR HEATER OUTLETS		
CF	CF-63-01	CARRIAGE OF EXTERNAL LOADS - REPLACEMENT OF LEATHER STRAPPING WITH APPROVED WEBBING		
CF	CF-81-29R2	EMERGENCY LOCATOR TRANSMITTER - REMOVAL OF LITHIUM BATTERIES - AIRWORTHINESS NOTICE # B014		
CF	CF-83-31R2	LAVATORY FLUSH PUMP MOTOR WITHOUT THERMAL PROTECTIVE DEVICE - PERIODIC CHECK FOR OPERATION		
CF	CF-90-03R2	EXHAUST TYPE COCKPIT/CABIN HEATERS (MUFF) INSPECT PIPES & TUBES TO DETECT DETERIORATION		
CF	CF-98-15	EXTERNAL RESCUE SYSTEMS CAR 702.21		
GODFRE	Υ			
US	68-23-01	CABIN SUPERCHARGERS TYPE 15 MARK 6,9 & 14 - OIL METERING UNIT & BEARING COVER NUTS		
US	69-21-02	CABIN SUPERCHARGER TYPE 15 MARKS 6,9 & 14 - BANJO ADAPTER IN THE OIL FILTER ASSEMBLY		
GOODRI	СН			
US	71-14-02	REPLACEMENT OF 26X6.6, PR 14, TUBELESS 200 MPH TIRES		
us	74-24-10	MAIN WHEEL ASSEMBLY P/N 3-1306 MANUFACTURED PRIOR TO 1 JAN 1972 UNDER TSO C26B - HUB AREA		
US	81-03-03	BRAKE ASSEMBLIES & BRAKE LINING CUPS REWORK & REPLACEMENT - SB 390 & 391		
us	83-22-08	EMERGENCY EVACUATION SLIDE/RAFTS P/N 7A1340, 7A1342, 7A1371 & 7A1373 - SB 25-081R1		
US	83-26-03	17.5X5.75-8, 12PR, 210 MPH & 18X5.5, 10PR, 210MPH AIRCRAFT TIRES		
US	84-24-04	EMERGENCY EVACUATIONSLIDE/RAFTS P/N 7A1340, 7A1342, 7A1371 & 7A1373 SERIES - SB 25-093R1		
US	85-06-02	MAIN LANDING GEAR WHEEL ASSEMBLIES - TIE BOLT NUTS P/N 63-347B RX3 - SB 439, 440		
US	89-02-05	7 MAN LIFERAFT P/N 100102-() AS PER TSD C70 - INFLATING CYLINDER		
GOODRICH BF AVIONICS				
US	98-25-02	SKYWATCH ANTENNA		
GOODYEAR				
US	75-05-05	MAIN WHEEL ASSEMBLIES P/N 5000757-1, -2 MPI ALL WHEEL ATTACHING BOLTS P/N MS 21250 10060		
US	78-05-06	FLEXIBLE FUEL CELLS CONSTRUCTION TYPE BTC-39 MANUFACTURED BETWEEN 1961 & 1971 - LEAK CHECK		

ORIGIN	NSTRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET
	<i>AR</i> NUED / SUITE) 89-03-01R1	32X8.8R16, 10PR, P/N 328Q08G2 RADIAL TIRES - LIFE LIMITS - SB
		32-002R1(ATR 42 )
	<b>ACHUTES</b> 023-01-89	4.8M S.A.C. CANOPY CANOPY MESH PANELS
CO 650	UDITY	25-01
GQ SEC		
	89-13-03	TYPE 350, 850 PARACHUTE ASSY & 4.8M SAC PARACHUTES - ACID TEST FOR FAA APPROVED CANOPIES
	, HERB M.	
US	84-10-03	HERBIE HOG PARACHUTES - REPLACE PLASTIC HANDLE WITH "MARTIN BAKER"  TYPE METAL HANDLE
HAMILL		
US	80-05-02	MODEL GA-4 & GA-5 SAFETY BELT ASSEMBLIES - FAILURE TO MEET TSO C22F STANDARDS
HARTZE	LL	
CF	CF-81-13	BLADE CLAMP P/N C-1301 INSTALLED ON HARTZELL PROPS O/H AT AERO PROP CALGARY JAN 80 /APR 81
HAWKER	ENERGY PROD	
UK	M1-89/2	18AH/25AH BATTERIES CAPACITY LOSS OF SEALED LEAD ACID A/C BATTERIES M1-89/2
HEATH 1	TECNA	
US	87-23-01	STC SA2365NM (BOEING 747) - SB 74000-25-007 - CEILING WIRE BUNDLES
HONEYWE	LL	
US	80-18-05	STARS FLIGHT DIRECTOR SYSTEM FDS - REVISE CIRCUIT HOOK-UP AS PER MAINT MAN # 15-3321-01
US	85-07-03R1	SPERRY SPZ-7000, WITH FZ-700 COMPUTER - EXCURSIONS FROM GLIDE SLOPE DURING ILS APPROACH
US	86-14-01	SPERRY AHZ-600 ATTITUDE HEADING REFERENCE SYSTEM (AHRS) - ATTITUDE / HEADING INFORMATION
us	87-06-02	MODEL SG-810, -811, -610 ELECTRONIC FLIGHT INSTRUMENT SYSTEMS (EFIS) SYMBOL GENERATORS
US	87-16-07	ELECTRONIS FLIGHT INSTRUMENT SYSTEMS (EFIS) MODELS EDZ 601, 603, 801, 803, 611 & 811
US	89-02-10R1	FMZ-800 FLIGHT MANAGEMENT SYSTEM (FMS) NAVIGATION COMPUTERS
us	89-20-06	FMZ-800 FLIGHT MANAGEMENT SYSTEMS (FMS) MODEL NZ-600, -800 & -900 NAVIGATION COMPUTERS
US	90-01-03	AH-600 ATTITUDE & HEADING REFERENCE SYSTEM (AHRS)
us	90-06-13	VG-14A VERTICAL GYRO - AUTOPILOT ERRONEOUS ATTITUDE DISPLAY & ERRATIC FUNCTION
us	91-08-51	FLIGHT MANAGEMENT SYSTEM (FMS) SOFTWARE ANOMALY - FLIGHT MANUAL REVISION & PLACARD
US	94-01-04	TRAFFIC ALERT & COLLISION AVOIDANCE SYSTEM(TCAS) - VERSION 6.04A LOGIC -SB 4066010-34-SW16
US	99-01-14	IC-600 INTEGRATED AVIONICS COMPUTERS - MODIF Y THE COMPUTER IAW SB # 7017000-22-43

ORIGIN	NSTRUCTEUR  AD NUMBER E NUMERO DE CONSIGNE	SUBJECT SUJET
HTL AL	DV TECHNOLOGY	
US	86-19-03	FIRE EXTINGUISHER DISCHARGE OUTLETS - PHYSICAL & TOP VIEW X-RAY INSPECTIONS
INDIAN	NA MILLS & MFG	
CF	CF-91-39	MODELS IMM-111050-20, -21, -22 SAFETY BELT ASSEMBLIES - REMOVAL OF DECORATIVE COVER
US	79-16-02	MODEL IMM 111040-1, -2, -3, -4 & -8 SAFETY BELT ASSYS - FAILURE TO MEET TSO C22F STANDARDS
INDUCT	TION AIR FILTER	
US	84-26-02	ALL PAPER INDUCTION AIR FILTERS - INSPECT FOR DETERIORATION & POSSIBLE ENGINE INGESTION
INTL 1	INFLATABLES	
US	71-14-03	INSPECT PASSENGER EVACUATION SLIDE REGULATOR P/N 68240 IAW SB 33-102, VOL 1, NO. 101
US	73-11-03	INSPECT PASSENGER EVACUATION SLIDES P/N 70003 FOR EVIDENCE OF CORROSION
IPECO		
US	90-09-08	TSO-C39A CREW SEATS - FAILURE OF THE SEAT BACK STRUCTURE
JANAER	RO	
US	96-20-07	MODELS B1500, B2030, B3040 & B4050 COMBUSTION HEATERS TSO C20 INSP IAW D/H MANUAL 24E25-1
JET EL	LECTRONICS	
US	80-18-08	MODEL PS-823() SERIES EMERGENCY POWER SUPPLIES MODIFICATION IAW SB 501-1075-16E
US	80-19-19	MODEL DAC-2000 & DAC-7000 AREA NAVIGATION (RNAV) SYSTEMS - PLACARD
US	82-21-04	MODEL PS-835 SERIES EMERGENCY POWER SUPPLY MODIFY IAW SB 501-1228-7
KING F	RADIO	
US	75-05-07	MODEL KCS-55 PICTORIAL NAVIGATION SYSTEM UNITS - MODIFY IAW ASB KI 525-1 & KG 102-6
US	85-23-07	KAP 100, 150 & KFC 150 AUTOPILOT SYSTEMS TSO C9C,C52A - MODIFY AS PER ASB KC 190/191/192-9
US	85-25-02	KAP 100, 150, KFC 150, 200 - PITCH & ROLL SERVO ACTUATOR MOD AS PER ASB KS 177/178-3
KOLLS	MAN	
US	69-24-05	A4086910021, A4186910028 & A4186910029 ALTIMETERS - MODIFY AS PER SB 188R1, 189
US	75-05-14	ALTITUDE REPORTING ALTIMETERS #'S B454510001 & B454510011 REPLACE OR MOD AS PER SB 264
L'HOTE	ELLIER	
CF	CF-93-19	GLIDERS/POWER GLIDERS-SECURITY OF BALL & SWIVEL FLT CONTROL CONNECTORS-TECH DATA IM 10.01A
LEAR		
US	51-26-02	L-2 SERIES AUTOPILOTS SERVO CLUTCH REPLACEMENT AS PER SB L-2-16, L-2-44

ORIGIN	DNSTRUCTEUR N AD NUMBER NE NUMERO DE CONSIGNE	SUBJECT SUJET
LEIGH		
CF	CF-76-24	SHARC 7 EMERGENCY LOCATOR TRANSMITTER C/W LITHIUM BATTERY CELLS - CORROSION TEST - SB 009
US	74-18-15	SHARC 7 SERIES EMERGENCY LOCATOR TRANSMITTER - INSTALLATION STATIC ELECTRICITY SUPPRESSOR
LETIF		
GΥ	96-212/2	ATTITUDE & HEADING REFERENCE SYSTEMS(AHRS), LCR-92,LCR-92S, LCR-92H - NON-COMPLIANCE
LITHI	UM BATTERIES	
US	79-18-05	LITHIUM SULFUR DIOXIDE (LISO2) BATTERIES - COMPLIANCE WITH TSO C97
LITTO	N SYSTEMS	
US	75-22-13	LTN-72 INERTIAL NAVIGATION SYSTEM - POWER LOSS WARNING INDICATION AS PER SB 34-72-80
LOCKHI	EED AIRCRAFT	
US	65-01-03	MODELS 109C & 109D FLIGHT RECORDER - CRASH SURVIVABILITY OF FLIGHT RECORDER - SB 31-12
US	75-08-17	MODEL 209 DIGITAL FLIGHT DATA RECORDER - INSTALLATION OF VIBRATION ISOLATORS
LUCAS	AIR EQUIPMENT	
FR	90-121(AB)	ELECTRIC HOISTS (AEROSPATIALE A/C) GUIDE PINCABLE GUIDE ASSEMBLY ~ P /N 709595-100
FR	91-125(AB)	IMPROVED ELECTRICAL BONDING SB 25.62-OL
FR	94-116(AB)R1	ELECTRIC HOISTS - P/N 76375 & 76378 EQUIPPED WITH ELECTRONIC CONTROL BOXES P/N 61148
MACLEC	OD	
CF	CF-75-12	PRESSURE ALTIMETERS P/N 135-13503, -13503-M - TEST TO ENSURE ADHERENCE TO TSO C10B LIMITS
MARATH	ON POWER TECH	
CF	CF-95-16	PC-250 SERIES INVERTERS - INSPECT FOR MOISTURE SENSITIVITY - IAW SB 111692-014
MARECO	)	
US	62-24-05	MODEL 15-1 SAFETY BELTS - DISENGAGEMENT OF BUCKLE LOCKING CAM
MARVEL	SCHEBLER	
CF	CF-63-09	MODEL MA-3 & MA-4 SERIES CARBURETORS - LOCK WIRING OF FLOAT BOWL SCREWS - SB A5-63
US	63-22-03	MODEL MA4-5 CARBURETORS - REPLACEMENT OF PRIMARY & MAIN VENTURI
US	69-24-03	MA-3, -4, -5, -6 & HA-6 CARBURETORS - FLUSH & CLEAN CARBURETOR & INSPECT DRAIN PLUG CAVITY
US	72-06-05R2	MA-3, -4, -5, -6 & HA-6 CARBURETORS - INSPECTION OF THROTTLE ARM TO PREVENT SEPARATION
US	77-13-16	MODEL HA-6 CARBURETOR - POSITIVE RETENTION OF THE IDLE NEEDLE ASSEMBLY
US	79-08-06	HA-6 CARBURETOR - REPLACEMENT

MAKE / CONS ORIGIN ORIGINE	TRUCTEUR AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET
MCCAULE	Y	
us	74-13-06	MAIN WHEEL ASSEMBLIES P/N D-30063-1, -2, & -4 WHEEL FLANGE ATTACHING BOLTS
US	75-12-07	DCF290D1A/T2, DCFS290D1A/T2, DCFU290D1A/T2 & DCFUS290D1A/T2 PROP GOVERNORS REPLACE SB 108
MECHANI	CAL PRODUCTS	
US	87-06-09	4001, 4200, 4310 & 8500 SERIES CIRCUIT BREAKERS INSTALLED AFTER JULY 23, 1984
MICHELI	N ACFT TIRES	
US	95-24-10	P/N 028-520-1 (22X5.75/10PR) MAIN LANDING GEAR TIRE FAILURES (RUPTURE)
MICRODO	ıT	
US	71-21-10	MODEL 1410 COCKPIT VOICE RECORDER - VISUAL TEST CIRCUIT LIGHT ILLUMINATION - SB 4-A
MITCHEL	L	
US	70-15-18	CENTURY II & III SERIES AUTOPILOT SYSTEMS - SERVO BRIDLE CABLE CLAMPS - SB MB-1
US	72-02-06	MODEL AK SERIES AUTOMATIC PILOT INSTRUMENTS - SERVO CONTROL WHEEL SHAFT - SB MB-6
US	73-13-11	MODEL AK SERIES AUTOMATIC PILOT INSTRUMENTS - AUTOMATIC PILOT ROLL SERVO - SB MB-8
us	77-16-10	MODEL NSD-360 NAVIGATION SYSTEMS - PLACARD RESTRICTED USE - NAV FLAG ADAPTER - SB MB-13
MORANE	SAULNIER	
FR	90-229(AB)R2	UNAPPROVED FOAM-TYPE AIR-FILTER ELEMENTS - SB RALLYE 149
NARCO		
US	77-02-08	MODEL ELT-10 EMERGENCY LOCATOR TRANSMITTER - BATTERY CORROSION INSPECTION & FUNCTIONAL CHK
NORDSKO	G INDUSTRIES	
US	93-23-01	WATER HEATERS & COFFEE MAKERS - REPLACEMENT OF NUPRO PRV - SB 93-34 - FAR 25 AIRCRAFT
US	94-14-03	WATER HEATERS & COFFEE MAKERS - REPLACEMENT OF NUPRO PRV - SB 93-35 - FAR 25 AIRCRAFT
02 CORF	PORATION	
US	91-10-05	MASK PRESENTATION UNIT P/N'S 121, 150, 151 &152 SERIES - LANYARD RELEASE PIN
PACIFIC	INFLATABLES	
US	80-07-13	REMOVAL FROM SERVICE P/N 4000 & 4000E SERIES FLOTATION DEVICES
PACIFIC	SCIENTIFIC	
US	80-01-05R1	FLIGHT CREWS & ATTENDANTS SEAT BELTS - INSTALLATION OF ROTARY BUCKLE WITH BLACK BODY PLATE
US	83-11-03	FLIGHT ATTENDANTS RESTRAINT SYSTEM ROTARY BUCKLE ASSEMBLY - COVER REPLACEMENT
US	87-20-05	TSO-C22F LAP BELT ASSEMBLIES P/N 1107177 BELT RETRACTOR SHAFTS
US	93-09-07	FIRE EXTINGUISHER PRESSURE SWITCH TEST IAW ASB 26A1106 - AIRBUS A320, BOEING 757 200 A/C

	STRUCTEUR AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET			
	SCIENTIFIC				
	JUED / SUITE) 94-21-06	LAP BELTS ASSEMBLIES LISTED IN SB'1108435-25-01 & 1108460-25-01 - INABILITY TO EGRESS SEAT			
US	97-04-15	FIRE EXTINGUISHER BOTTLE (SQUIBS) - P/ N 13083-10 & 25 - VISUAL INSPECTION			
PAN AV	ION				
US	67-18-04	MODEL PA-5 LIFE VESTS - REPLACEMENT OF 8 GRAM CO2 CARTRIDGE WITH A 12 GRAM CO2 CARTRIDGE			
US	74-22-03	MODEL C-30A LIFE RAFTS - PRESSURE CHECK GAS REGULATOR ASSEMBLY & GAS BOTTLE - SB 26-74			
US	75-16-23	PAN AVION & PATTEN LSR-174(), -174(2) EVACUATION SLIDES - REPLACEMENT OF INFLATION HOSES			
PARA-FL	ITE				
us	86-22-07	SWIFT RESERVE CANOPY P/N 82700, SERIAL # R3-2750 THRU R3-3471			
PARACHU	ITES DE FRANCE				
FR	94-134(AB)	MODEL P512- PERIODICITY OF MAINT MAN/PACKING AMENDMENT OF MAINT MAN PER SB 001, 3 MAY 94			
FR	95-131(AB)	"FRENCH" CONNECTOR LINKS TIGHTENING - APPLIES TO P512 PARACHUTES DELIVERED IN LAST YEAR			
PARKER	HANNIFIN				
US	86-01-06	AIRBORNE DRY AIR PUMPS & AUXILIARY DRY AIR PUMPS INSTALLED ON PISTON ENGINE AIRPLANES			
US	98-23-01	AIRBORNE DRY AIR PUMPS - B1-19-1 FLEXIBLE COUPLING INSTALLED AFTER 1 JAN 98 - ASL # 48			
PATHFIN	DER				
US	74-19-02	EMERGENCY LOCATOR TRANSMITTER, ALL MODELS - CORROSION INSPECTION - "G" FORCE PLUNGER AREA			
PIONEER	PARACHUTE				
US	86-24-03R1	K-XX, K-XXII & 26 FT CANOPIES - OBLITERATION OF TSO C23B DUE TO UNDERSTRENGTH MATERIAL			
PRATT &	WHITNEY				
CF	CF-76-02	ST6L-73 APU ENGINE -LOCKHEED L 1011 - SUNDSTRAND 025277 FUEL PUMP - SB 9043, 9046			
CF	CF-93-09	PW901A APU - IDLER GEAR & COOLING FAN SHAFTS- OIL STRAINER - SB A16159R1 - BOEING 747			
PRECISE	FLIGHT				
US	93-12-04	PULSELITE UNITS - MODEL 1210-2405-2 - S/N X00150 THROUGH X01371 - STC SA4005NM			
PRECISE	FLIGHT, INC.				
US	99-24-10	TO DETECT PROBLEMS WITH THE STANDBY VACUUM SYSTEM BEFORE FAILURE OR MALFUNCTION.			
PRECISI	PRECISION AIRMOTIVE				
us	93-19-04	MODEL MA3, MA3A, MA3PA, MA3SPA & MA4SPA CARBURETORS - CFS FLOATS P/N CF 30-766 SB CF1-92R1			
US	94-25-04	(FACET/MARVEL SCHEBLER) MODEL HA-6 CARBURETORS - MIXTURE CONTROL SHAFT SCREW CLIP/SB MSA-6			

ORIGIN	NSTRUCTEUR AD NUMBER NUMERO DE CONSIGNE	SUBJECT SUJET
(CONTI	SION AIRMOTIVE NUED / SUITE) 98-01-06	MODEL MA-3,-3A,-3PA,-3SPA, MA4-SPA CARBURETTORS INSP OF PRIMARY VENTURI -SB MSA-2R1
PRESSE	D STEEL TANK	
υS	75-22-22	DOT-3HT-3000 COMPRESSED GAS CYLINDERS - REMOVAL FROM SERVICE WRONG COMPOSITION STEEL
PRESTO	LITE	
US	72-15-02	ALTERNATOR COOLING FANS P/N PU 1605 SERIES - INSPECTION & REPLACEMENT
US	76-02-07	ALV-9400 THRU ALV-9410 SERIES GEAR DRIVEN ALTERNATORS - INSPECTION ROTOR SHAFT & BEARING
PTC AE	ROSPACE	
US	94-20-07	MODEL 91700 OXYGEN SYSTEM - DC-10 AIRCRAFT - VERIFY CONFIGURATION & FUNCTIONING/SB 25-1233
PTC SE	ATING PRODUCTS	
US	96-12-09	MODEL 950 SERIES PASSENGER SEAT EQUIPPED WITH FOOTREST ASSY.IAW SB 25-1192A & 25-1330
PURE A	IIR INC	
US	80-08-14	CARBURETOR AIR INLET FILTER INSTALLED PER STC SA69NW - FOAM FILTER ELEMENT
PURITA	N BENNETT	
US	81-08-04	OXYGEN MASKS P/N 174039, 174010-01, 174010-03 & ZMR100 SERIES - DIAPHRAGM & PLATE ASSEMBLY
US	93-24-16	PROTECTIVE BREATHING EQUIPMENT (PBE) 119003 UNIT - DETERIORATED NECK SEAL - SB 119003-35-1
US	94-19-06	SWEEP-ON MODEL 2000 CREW OXYGEN MASKS - SB 174250-35-1
US	97-11-10	SERIAL 174290 CONSTANT FLOW AIRLINE PORTABLE OXYGEN MASKS - MASK REPLACEMENT
US	97-18-03	SWEEP ON OXYGEN MASKS - CONE & SEAL ASSEMBLIES P/N'S 210543 & 210543-01
US	99-08-21	PASSENGER AND PORTABLE OXYGEN MASKS THAT HAVEELASTOMER CURE DATE BETWEEN SEP 93 - MAR 97
PYROTE	CTOR	
US	78-14-09	FIRE DETECTORS P/N 30-207 SERIES - REPLACEMENT OF FAULTY DETECTORS
RAJAY		
US	65-02-03	MODEL 315A10 TURBOCHARGER - INSPECTION OF TURBINE SCROLL
US	80-16-05	SKY-DX MODEL 2600, 2800 & 2900 SERIES DXYGEN REGULATORS
US	81-19-04	STC MODIFICATION - INSPECT POWERPLANT FUEL, AIR & OIL HOSES AS PER SL 28
RAPCO		
US	97-16-10	RAPCO PRESSURE FILTERS
RAZORE	BACK FABRICS	
US	72-22-02	REPLACEMENT OF STITCHING CORD ON AIRCRAFT COVERED WITH FIBER GLASS USING RAZORBACK METHOD

ORIGIN	NSTRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET
RELATI	VE WORKSHOP	
US	99-01-11	ALL VECTOR II AND III PARACHUTE SYS. BUILT BETWEEN JAN 96 AND JAN 98 REF SB#091098-B
RIGGIN	IG INNOVATIONS	
US	93-08-02	SKYHOOKS RESERVE PILOTCHUTES SPRING TEST - P/N 2233-() - SERIAL # 2405-5551 - SB 1513 A
ROSEMO	OUNT INC	
US	80-12-15	MODELS 856 AE-12, -13 & -15 PITOT STATIC PROBES - RESISTANCE CHECK OF PROBE HEATER ELEMENT
ROTO M	IASTER	
US	82-27-03	RAJAY MODEL 325E10 & 3AT6EE10J2 TURBOCHARGER - TURBINE HOUSING CRACKS - SL 27 REV A
RUPERT	PARACHUTE	
us	61-08-02	SAFETY BELTS MODEL 50, N50, 65, 80 & S-2194 - NON COMPLIANCE WITH TSO C22 - SL 27
RUSSEL	.L	
US	56~21-04	RM-3 & RM-4 SAFETY BELTS EQUIPPED WITH RUSCO TOQ-L-LOK BUCKLES NON-COMPLIANCE TSO C22B
US	61-20-03	RUSCO MODEL RM23 SAFETY BELTS EQUIPPED WITH D-832B BUCKLES NON-COMPLIANCE TSO C22B
SAFT A	IMERICA	
US	98~20-17	NICKEL CADMIUM BATTRIES MANUFACTURED PRIOR TO DECEMBER 1997 - INSTALLED IN DC-9 AIRCRAFT
SARGEN	IT INDUSTRIES	
US	74-17-01	PASSENGER EVACUATION SLIDES & SLIDE/RAFTS - PICO REGULATOR P/N 30001 -MOD PER SB 25-51
SCHWIE	N	
US	65-18-02	MODEL S-27200 TURN & BANK INDICATORS - REPLACEMENT OF ZINC DIE CAST ROTOR WITH STEEL ROTOR
SCOTT	AVIATION	
us	73-26-05	CHEMICAL DXYGEN GENERATORS P/N 801386-01, -02 & -03 & 801462-01, -02 & -03 CORROSION INSP
US	84-02-08	OXYGEN CYLINDERS - DISCHARGE & RECHARGE WITH AVIATION BREATHING OXYGEN
US	85-26-03	CONSTANT-FLOW DXYGEN MASKS - INSPECTION FOR IMPROPERLY DRILLED DXYGEN CONNECTORS .
US	92-16-15	OXYGEN MASKS CONNECTORS P/N 289-57 - 727, 737, 747, 757, 767, DC8, DC9, DC10, F28 & F100
SEXTAN	IT (CROUZET)	
FR	1999-472(AB)	YEAR 2000B ROLLOVER, OBSOLETE NAV SYSTEMS OMEGA/VLF OR OMEGA
SHAKES	PERE CONTROLS	
US	50-05-02	FLEXIBLE PUSH-PULL CONTROLS - SECURING OF MALE ADAPTER TO FLEXIBLE CONTROL TO BODY TUBE
SICMA	AERO SEAT	
FR	1994-085(AB)R2	PASSENGER SEATS - AFT TRACK FITTING P/N 90-000120-790-0 - SB A90-25-002 REV A, -005R1


	NSTRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET
	AERO SEAT	
	NUED / SUITE) 98-341(B)R1	CABIN ATTENDENT SEATS - INSTALLATION OF PROTECTIVE PLATES - AIRBUS A/C A319, A320, A321
FR	1999-004(AB)	CABIN ATTENDENT SEATS - INSTALLATION OF PROTECTIVE PLATES - AIRBUS A/C A319, A320, A321
SIERRA	NENGINEERING	
US	74-14-07	MODEL 289-601 OXYGEN MASKS - INSTALL A RETAINING DISK TO SECURE THE RESERVOIR TO FACEPIECE
SIMCA	AERO SEAT	
FR	97-134(AB)	REPLACEMENT OF LEG COLLARS ON ALL AERO SEATS AS PER SERVICE BULLETIN # 95-25-003
SKYFOR	CE AVIONICS	
UK	005-10-99	REMOVE NICKEL HYDRIDE AND LITHIUM BATERIES SKYFORCE AVIONICS ALERT SB TRSY037C
SLICK	ELECTRO	
US	74-18-05	MODEL 447, 662, 664, 667, 668, 676 & 680 - IMPULSE COUPLING - SB 1-71
US	80-06-05	HARDNESS TESTS ON IMPULSE COUPLING RIVETS
US	81-16-05	MODEL 4200 & 6200 MAGNETOS - INSPECTION FOR CRACKED COILS - SB 1-81
SOLOY	CONVERSIONS	
US	80-23-02	TRANSMISSION OIL LUB JETS - HILLER UH12 & BELL 47 AIRCRAFT CONVERTED TO TURBINE POWER
SOUTHW	IND	
CF	CF-61-16	940-B12, -B24 & -D12HEATERS - MODIFY TO ADD FUEL & IGNITION SHUT-OFF & OVERHEAT SWITCH
SPRAGU	E ENGINEERING	
US	70-10-04	ACCUMULATOR ASSEMBLIES P/N A200-25, -50 - REPLACEMENT OF ALUMINUM END CAPS WITH STEEL CAPS
STEWAR	T WARNER	
US	80-25-07R1	OIL COOLER INSPECTION FOR LEAKS & PLACARD INSTALLATION
US	81-09-09	MODEL 8240, 8253, 8259 & 8472 SERIES COMBUSTION HEATERS (TSO C20) - GENERAL INSPECTION
STRONG	ENTERPRISES	
US	80-13-01	REPLACEMENT OF PLASTIC RIP CORD HANDLE WITH METAL HANDLE
SUNDST	RAND	
US	78-01-01	ANGLE OF ATTACK SENSORS - MODIFICATION OF SELF TEST CIRCUIT IN SUNDSTRAND PROBE
US	83-16-01R1	MODEL AV-557 SERIES VOICE RECORDERS - INSPECTION FOR TAPE DECK HOUSING CONNECTOR SOCKETS
US	84-03-09	MODEL 573A DIGITAL FLIGHT DATA RECORDER - INSPECTION TO DETERMINE MODIFICATION STATUS
US	96-25-12	T-62T-40C SERIES APU COMPRESSOR WHEELS
SUPERI	OR AIR PARTS	
US	96-12-04	PMA PISTONS, P/N SA626992 & SA626992P15 INSTALLED IN CONTINENTAL ENGINES O-470-K, -L, -R

ORIGIN	NSTRUCTEUR  AD NUMBER  E NUMERO DE CONSIGNE	SUBJECT SUJET
SUPERI	OR FLOW	
US	67-01-04	REPLACEMENT OF SUPERIOR FLOW OIL FILTER ELEMENTS
SWITLI	K PARACHUTE	
us	83-01-06	CO2 INFLATION VALVE MANIFOLDS - INSPECTION OF LOWER SHOULDER IN VALVE STEM
US	89-06-01	CARBON DIOXIDE INFLATORS - TSO-C13 LIFE PRESERVERS & TSO-C72 INDIVIDUAL FLOATATION DEVICES
TECO		
US	67-18-05	REMOVAL OF TECO MODEL 603 AIRCRAFT SEATS FROM CIVIL AIRCRAFT
TELEDY	'NE CONTINENTAL	
us	96-12-07	MODEL S-20, S-1200, D-2000 & D-3000 SERIES MAGNETOS - IMPULSE COUPLING - MSB 645 & SB 639
TELEDY	NE/BENDIX	
US	94-01-03R2	S-20, S-200,S-600 & S-1200 MAGNETOS - IGNITION COILS & ROTATING MAGNETS - MSB # 644
TERRA	CORPORATION	
US	95-01-01	TRT 250 TRANSPONDERS- P/N 0900-0250-00,-20,-30 MOD/REPLACE IAW SB-104(TCAS INTERROGATION)
TEXAS	INSTRUMENT	
US	90-09-10	6TC6-7.5, -10 & 6TC20-7.5 & -10 CIRCUIT BREAKERS - POTENTIAL OVERHEATING
THOMPS	ON	
CF	CF-58-13	TFD 900-1, -3 ENGINE DRIVEN FUEL PUMPS - REPLACEMENT DUE TO INCORRECT LINER INSTALLATION
US	55-26-02	MODEL TF-1100-2, -M2 FUEL PUMPS - REPLACEMENT OF DRIVE PIN - SB EDS-176A
TRACOR	AEROSPACE	
US	90-05-09	TA-7800 OMEGA/VLF NAVIGATION SYSTEMS - SB 138000-00-01
TRANSP	PORT AIRCRAFT	
us	74-08-09R2	US MANUFACTURED FAR 25 AIRCRAFT - INSTALL / PLACARD "NO SMOKING IN LAVATORY "
US	76-05-02	PROHIBITION OF FLIGHT ATTENDANTS USING SIDE FACING SEATS IN TRANSPORT CATEGORY AIRCRAFT
US	99-04-10	REPLACEMENT OF DAY-RAY CABIN SIDEWALL FLUORESCENT LIGHT BALLASTS WITH BRUCE INDUSTRIES
UNITED	DATA CONTROL	
US	65-14-06	MODEL F-542 SERIES FLIGHT DATA RECORDER - TO IMPROVE CRASH SURVIVABILITY MOD AS PER UDC SB
	INSTRUMENTS	
US	74-24-13	ALTIMETERS P/N 5932 & 5934 REPLACE OR MODIFY AS PER SB #1
US	86-05-02	ALTIMETER P/N 5934 SERIES PRESSURE SENSITIVE THAT DO NOT HAVE ENCODING CAPABILITIES
UNIVER	SAL OIL	
US	80-22-06	MODEL 900 SERIES AIRCRAFT SEATS - INSPECTION FOR CRACKS IN REAR STRETCHER TUBE - SB 25-634

	NSTRUCTEUR  AD NUMBER  NUMERO DE CONSIGNE	SUBJECT SUJET
VARIOU	JS MANUFACTURER	
US	99-23-22R1	TRANSPORT CAT. AIRPLANES EQUIPPED WITH ANY MODE C XPDR WITH SINGLE GILLHAM CODE ALT.
VOLPAR	?	
US	81-18-07	VOLPAR TRICYCLE LANDING GEAR - INSPECTION & REPLACEMENT MLG WALKING BEAM UPPER ATTACH BOLT
WALTER	R KIDDE	
US	59-24-02	SMOKE DETECTORS - KIDDE MODEL A4532-M1, & C-O-TWO MODELS ASDC-2, ASDT-3 - FALSE INDICATION
US	64-13-04	INFLATION VALVES ON INFLATABLE ESCAPE SLIDES & LIFE RAFTS - INADEQUATE INFLATION
us	84-18-07	NON-FIRING OF FIRE EXTINGUISHER DISCHARGE CARTRIDGES (KIDDE & OVERLAND AVIATION CO)
WEBER	AIRCRAFT	
US	87-06-07	TSO C39A PASSENGER & FLIGHT ATTENDANT SEATS - AFT SEAT TRACK FITTINGS
WESTON	I GARWIN	
US	67-26-04	MODEL 22-374 SERIES ALTIMETERS - MODIFICATION OR REPLACEMENET
WHELEN	ENGINEERING	
US	75-05-04	A427 STROBE LIGHT FLASH TUBE - INSTALLATION OF PRESSURE SENSITIVE VINYL TO PREVENT ARCING
WIPAIR	E SKIS INC.	
CF	CF-59-05R1	CRACKS LOCATED BETWEEN THE YOKE ARMS ON MODEL 3000 SKIS.NOTE FORMERLY FLI-LITE SKIS
WOOD E	LECTRIC	
US	70-22-04	105, 106, 107, 108, 147, 152, 254, 447, 448, & 2100 SERIES CIRCUIT BREAKERS - INSPECTION
WOODWA	RD	
US	70-16-01	TURBO PROPELLER GOVERNORS MOUNTED ON UNITED AIRCRAFT OF CANADA (P&W) PTGA SERIES ENGINES
US	70-26-02	MODEL 210 SERIES PROPELLER GOVERNORS - INSPECT PROP GOVERNOR LEVER ARM - SB 33534
US	81-25-01	MODEL F210681 GOVERNOR (MAULE M5 235C AIRPLANES) - REPLACE GOV TO PREVENT FLYWGHT FAILURE
3-RING	INCORPORATED	
US	84-06-05	PARACHUTE HARNESSES (TSO C23B) - TEST / REPLACEMENT OF RELEASE RINGS P/N RW-1-82, -83

This index of airworthiness directives, mandatory service bulletins and equivalent notices is provided for information only. As Transport Canada cannot be assured of receiving notification of all such notices issued by foreign airworthiness authorities, this list cannot be guaranteed for completeness.

Cet index de consignes de navigabilité, de bulletins de service obligatoires et des instructions équivalentes est fournie à titre d'information seulement. Étant donné que Transports Canada, ne peut pas obtenir la garantie qu'il recevra tous ces avis émis par d'autres autorités de navigabilité étrangères, on ne peut pa garantir que cette liste est complète.



#### CANADIAN AIRWORTHINESS DIRECTIVES

The publication *CANADIAN AIRWORTHINESS DIRECTIVES* (TP9856E) contains the full text of all current Transport Canada Airworthiness Directives (ADs) and is available in book form. The order includes a monthly supplement of all new or revised ADs issued during the previous month, along with an updated accumulative index for the year.

ITEM	CATALOGUE NUMBER	(Canada)	PRICE (Outside Canada)	QUANTITY	SUBTOTAL
1998 Edition ADs to 31 December 1997	T51-2-3-1998E	\$39.95	US \$39.95		
1999 Revision Supplement to 31 December 1998	T51-2-3-1998-99-1E	\$24.95	US \$24.95		
		Shipping a	and Handling \$5.40		
		Add 6% fo	or orders over \$200.		
		GST 7% (	Canada only)		
		Total Amor	unt Enclosed		

#### Five easy ways to order your copy:

- 1. Mail: Canadian Government Publishing, Ottawa, CANADA K1A 0S9
- 2. **Telephone:** (819) 956-4800
- 3. Fax: (819) 994-1498 For orders by Visa or Mastercard: 1-800-565-7757
- 4. E-mail: publications@pwgsc.gc.ca Internet: http://publications.pwgsc.gc.ca
- 5. Also available through bookstores.

#### Method of Payment (please no cash)

	Cheque or Money Order (pay	able to the Receiver General for Canada)
01: /	CGPC Account No.	
Ship to:		
	Purchase Order No.	
	VISA / MasterCard	
	Credit Card Expiry Date	Name of Bank
	Signature	Date

#### CONSIGNES de NAVIGABILITÉ CANADIENNES

La publication *CONSIGNES de NAVIGABILITÉ CANADIENNES* (TP9856F) contient le texte complet de toutes les consignes de navigabilité (CN) de Transports Canada. Le service de commande comprend un service de supplément mensuel de toutes les CN nouvelles ou révisées au cours du mois précédent, ainsi qu'un répertoire cumulatif mis à jour pour l'année en cours.

ITEM	NUMÉRO de CATALOGUE	(Canada)	RIX (à l'étranger)	QUANTITÉ	SOUS-TOTAL
Édition 1998 CN au 31 décembre 1997	T51-2-3-1998F	39,95 \$	39,95 \$ US		
Révision 1999 Supplément au 31 décembre 1998	T51-2-3-1998-99-1F	24,95 \$	24,95 \$ US		
		Expédition et manutention 5,40 \$			
		Ajouter 6% pour commandes plus de 200,00 \$			
		TPS ajouter 7% (Canada seulement)			
		Montant total inclus			

#### Cinq façons de placer votre commande :

- 1. Courrier: Les Éditions du gouvernement du Canada, Ottawa, CANADA K1A 0S9
- 2. Téléphone: (819) 956-4800
- 3. Télécopieur: (819) 994-1498 Pour commandes par carte Visa ou Mastercard: 1-800-565-7757
- Aussi disponible dans les boutiques de livres.

#### Genre de paiement (s.v.p. pas de comptant) Chèque ou mandat-poste (payable au Receveur général du Canada)

Expédier à :	Numéro de compte GCCE					
	Numéro de commande d'achat					
	Carte VISA / MasterCard					
	Date d'expiration de la carte Nom de la banque					
	Signature					
,						

Transports Canada Sécurité et sûreté Aviation civile

Canada

#### INDEX of AIRWORTHINESS DIRECTIVES APPLICABLE in CANADA

This index (Transport Canada Publication TP9857) provides an organized list of all Canadian and foreign Airworthiness Directives, and equivalent notices, which are known to Transport Canada to be applicable to aircraft in the Canadian Civil Aircraft Register on the date of publication.

The index is sold individually or by a yearly subscription of four issues, by Canadian Government Publishing. Completed order forms must be sent directly to:

Canadian Government Publishing Ottawa, CANADA K1A 0S9

Fax: (819) 994-1498 Phone: (819) 956-4800

No.	ITEM	ORDER NUMBER	PRICE (Canada) (Outside Canada)		QUANTITY	TOTAL
1	Annual Subscription - 4 Issues	T51-3-IND	\$ 210.00	US \$ 210.00		
2	Single Issue		\$ 57.95	US \$ 57.95		
3	SHIPPING & HANDLING					
	- Annual Subscription		Included in basic price			
	- Single Issue		\$ 5.40	US \$ 5.40	1111	
4	7% GST (Canada only)					
5	TOTAL AMOUNT ENCLOSED					

	5	TOTAL	AMOUNT E	NCLOSED	→ ·
Pu co ple	rchase mpanie ase use	s and educat purchase or	accepted from quional institutions ders only.)	(Please No Cash) governments, registered . (Federal Government -	
1	CCGP Acc				Ship To:
	VISA / Mass	erCard Expiry Date	Name of Bank		
	Signature TP9857 (0:	3-97)		Date	En français au vers

INDEX des CONSIGNES de NAVIGABILITÉ en VIGUEUR au CANADA

Cet index (publication TP 9857 de Transports Canada) présente une liste organisée de toutes les consignes de navigabilité canadiennes et étrangères, et les avis équivalents, qui sont connues de Transports Canada d'être en vigueur pour les aéronefs du Registre d'aéronefs civils canadien à la date de publication.

Cet index est vendu individuellement ou par abonnement annuel de quatre exemplaires, par Les Éditions du gouvernement du Canada. Envoyer votre commande dûment remplie directement à :

Les Éditions du gouvernement du Canada Ottawa CANADA K1A 0S9

Télécopieur: (819) 994-1498 Téléphone: (819) 956-4800

Nº	ARTICLE	N° de COMMANDE	COÛT		QUANTITÉ	TOTAL
1	Abonnement annuel - 4 exemplaires	T51-3-IND	210,00 \$	210,00 \$ US		
2	Un exemplaire		57,95 \$	57,95 \$ US		
3	EXPÉDITION et MANUTENTION					
	- Abonnement annuel		Incluses			
	- Un exemplaire		5,40 \$	5,40 \$ US		
4	7% TPS (Canada seulement)					
5	MONTANT TOTAL INCLUS				$\rightarrow$	

5 MONTANT	TOTAL INCLU	s <del>-</del>			$\longrightarrow$	
Genre de paiement Les commandes d'achat s homologuées et institution s.v.p., utiliser les comman Chèque ou mandat postal (payat	ont acceptées d ls d'éducation. ( des d'achat seul	Gouvernement lement.)	ents, firme	es		
N° de compte GCCE				Expédier à:		
Carle VISA / MasterCard  Date d'expiration de la carte  Signature	Nom de la banque	Date				
Commande TP9857 (03-97)						English on reve



